SHARP SERVICE MANUAL



CODE: 00ZMX3640/S2E

DIGITAL FULL COLOR MULTIFUNCTIONAL SYSTEM

MX-2640N/2640NR ▲ MX-3140N/3140NR /3140N A MODEL MX-3640N/3640NR

NOT	E FOR SERVICING	
[1]	PRODUCT OUTLINE	1-1
[2]	SPECIFICATIONS	2-1
[3]	CONSUMABLE PARTS	3-1
[4]	EXTERNAL VIEW AND INTERNAL STRUCTURE	4-1
[5]	ADJUSTMENTS AND SETTINGS	5-1
[6]	SIMULATION	6-1
[7]	TROUBLESHOOTING	
[8]	FIRMWARE UPDATE	8-1
[9]	MAINTENANCE	9-1
[10]	DISASSEMBLY AND ASSEMBLY	10-1
[11]	VARIOUS STORAGE DATA HANDLING	
[12]	SERVICE WEB PAGE	
[13]	OPERATIONAL DESCRIPTIONS.	13-1
[14]	ELECTRICAL SECTION	
[15]	TOOL LIST	15-1

. .____

Parts marked with " Δ " are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

SHARP CORPORATION

This document has been published to be used for after sales service only. The contents are subject to change without notice.

CONTENTS

[8] FIRMWARE UPDATE

NOTE FOR SERVICING

	1.	Precautions for servicing	. i
	2.	Warning for servicing	. i
	3.	Note for installing site	. i
	4.	Note for handling PWB and electronic parts	.ii
	5.	Note for repairing/replacing the LSU	iii
	6.	Note for handling the drum unit, the transfer unit,	
		the developing unit	iii
	7.	Screw tightening torque	iii
[1]	PR	ODUCT OUTLINE	
	1.	System diagram 1	-1
	2.	Option list1	-2
[2]	SP	ECIFICATIONS	
	Α.	Basic specifications	-1
[3]	СС	ONSUMABLE PARTS	
	1.	Supply system table	-1
	2.	Maintenance parts list	-3
	3.	Definition of developer/drum life end	-5
	4.	Production number identification	-5
	5.	Environmental conditions	-6
[4]	FX	TERNAL VIEW AND INTERNAL STRUCTURE	
1.1	1	External view 4	-1
	2	Internal structure 4	-3
	3	I/F connectors 4	-4
	4	Operation panel 4	-5
	5.	Sensors and detectors	-6
	6.	Switches. 4	-8
	7.	Clutches and solenoids	-9
	8.	Motors	10
	9.	Rollers	11
	10.	. Lamps	13
	11.	Fans and filter4-	14
	12.	. Heater	15
	13.	. PWB/Memory device	16
	14.	. Fuses and Thermostats	18
[5]	AD	JUSTMENTS AND SETTINGS	
	1.	General	-1
	2.	Adjustment item list	-1
	3.	Details of adjustment	-3
[6]	SI		
[•]	1	General and purpose 6	-1
	2	Starting the simulation 6	-1
	3	List of simulation codes 6	-3
	4.	Details of simulation	-9
[7]	тр		-
[1]	1	Error code and troubleshooting 7	_1
	י. 2	IAM and troubleshooting	36
	۲. ک	Image send communication report code	40
	J. ⊿		40 42
	4.	Diai tono	10

	1.	Outline	8-1
	2.	Update procedure	8-1
[9]	MA	INTENANCE	
	1.	Works necessary when executing	0.4
	~		9-1
	2.		9-2
	3.		9-4
[10]	DIS		
	1.	Disassembly of Units	. 10-1
	2.	Disassembly and assembly of each unit	10-22
[11]	VA	RIOUS STORAGE DATA HANDLING	
	1.	HDD/SD card memory map	. 11-1
	2.	Necessary steps when replacing the PWB,	44.0
	~	HDD and the SD Card	. 11-3
	3.		. 11-8
[12]	SE		
	1.		. 12-1
	2.	Details and operation procedures	. 12-1
[13]	OP	PERATIONAL DESCRIPTIONS	
	1.	Operation panel section	. 13-1
	2.	Scanner section	. 13-3
	3.	Manual paper feed section	. 13-5
	4.	Tray paper feed section	. 13-7
	5.	Paper registration section (Paper transport section)	13-10
	6.	Paper exit section.	13-11
	7.	ADU section	13-13
	8.	LSU section	13-15
	9.	Process section	13-18
	10.	Fusing section	13-48
	11.	RSPF section	13-51
	12.	Fan and filter	13-57
	13.	Operations and specifications of counters	13-58
[14]	EL	ECTRICAL SECTION	
	1.	Block diagram	. 14-1
	2.	Power line diagram	. 14-9
	3.	Actual wiring chart	14-13
	4.	Signal list	14-28
[15]	то	OL LIST	. 15-1

Symbols in this manual

The lists of symbols used in this manual are shown below. The meaning of each symbol described in the table must be understood for proper servicing.

1. Symbols used for notes and cautions

Symbol	Meaning		
	CAUTION	Indicates a general caution item.	
CAUTION HIGH TEMPERATURE	HIGH TEMP	Be careful of a high temperature in the fusing section.	
CAUTION HIGH VOLTAGE	HIGH VOLTAGE	Be careful of an electric shock where a high voltage is applied such as the high voltage PWB, the main charger, and the process section.	
DANGER	DANGER	Indicates danger.	
	HANDLE WITH CARE	Indicates a part which requires special care for handling such as the HDD, and the LSU.	
\oslash	INHIBIT	Indicates inhibit.	
\bigotimes	NO ELECTROSTATIC CHARGE	Be careful to keep away from static electricity. (PWB's and electric parts)	
	NO DUST, FINGER PRINT, DIRT, SCRATCH	Be careful not to touch directly, such as the optical section, the photoconductor, and the DV roller. Also be careful not to scratch.	
	NO SCRATCH		
	NO LIGHT	Be careful not to expose to light, such as the photoconductor, and the test chart.	
	NO SOLVENT	Be careful not to use a solvent in cleaning, etc.	
\bigotimes	NO DISASSEMLE	Do not disassemble. Not serviceable. Example CCD unit.	

Symbol	Meaning		
OK	OK/GOOD	Indicates a correct procedure or result in an adjustment, etc.	
NG	NO GOOD	Indicates a wrong procedure or result in an adjustment, etc.	
Note	NOTE	Indicates a note.	
Important	IMPORTANT	Indicates an important item.	
	REFER	Indicates a reference page, etc.	
new	NEW	Indicates a new technology, a new method, or a new item.	
Example	EXAMPLE	Indicates a description using an example.	

2. Symbols used in the work contents

Symbol	Meaning (Work content)		
	Adhesion	Indicates that a seal, etc. is attached.	
	Adjustment	Indicates an adjustment.	
Minin,	Measure a dimension or a size.	Indicates that a dimension or a length is measured.	
	Apply grease	Indicates that grease is to be applied.	
GREASE	Apply conductive grease	Indicates conductive grease is applied	
	Cleaning (Dry)	Indicates clean with a dry cloth.	
	Cleaning (Wet)	Indicates clean with a cloth dampened with water.	
ALCOHOL	Cleaning (Alcohol)	Indicates clean with alcohol.	
	Cleaning (Blower)	Indicates cleaning is done with a blower/ brush.	

Symbol	Meaning (Work content)			
	Cleaning	Indicates that cleaning is		
	(Vacuum)	performed with a		
		vacuum cleaner.		
	Cleaning	Indicates that cleaning is		
	(Brusn)	performed with a brush.		
	Oil	Indicates that oil is		
OIL		applied to lubricate.		
	Apply powder.	Indicates that setting		
		power is applied to the		
and the second		photoconductor drum,		
		the transfer belt, etc.		
	Replace	Indicates that a part is		
		replaced.		
	Chaol	Indicates that a check		
	Спеск	Indicates that a check		
42		(replacement,		
		adjustment, cleaning) is		
	04	performed.		
17	Cut	Indicates that cutting is		
lê/		performea.		
_				
	Loosen	Indicates that a screw is		
	200001	loosened.		
*				
	Connect	Indicates that a		
$\rightarrow \leftarrow$		connector is connected.		
	Disconnect	Indicates that a		
$\leftarrow \rightarrow$	Disconnect	Indicates that a		
		connector is		
		disconnected.		
	Remove a	Indicates that a harness		
	harness.	is unsecured.		
	Attach a harness.	Indicates that a harness		
		is secured.		
	D is along			
→ ↓ ← ←	Remove a clamp.			
Т				
	Attach a clamp			
>יקרי <	Allaon a olamp.			
	Release a hook.	Indicates that a hook is		
		released.		
	Fix a book	Indicates that a book is		
	Ніх а поок.	Indicates that a nook is		
「ん		fixea.		
	Disengage the			
	nawl.			
1	P			

Symbol	Meaning (Work content)		
	Engage the pawl.		
PAINT LOCK	Screw lock	Indicates that a screw is secured with adhesive.	
	Unlock		
OFF	Turn OFF the power.		
"	Disconnect the power plug.		

3. Symbols used for kinds of parts

Symbol	Meanin	g (Kinds of parts)
N	Maintenance part	Indicates a part which is replaced in a maintenance procedure.
СР	Consumable part	Indicates a consumable part such as a photoconductor, developer, a transfer belt, etc.
WP	Waste part	Indicates a waste part which is consumed but excluded from the above consumable parts. (A roller, a seal, etc.)
UN	Unit part	Indicates a part which is designated as a unit.
	Included part	Indicates a part which is included in the package

4. Symbols used for additional descriptions

Symbol	Meaning	
TOP VIEW	View from the top	Indicates from which angle the drawing is
BOTTOM VIEW	View from the bottom	viewed.
FRONT VIEW	View from the front	
REAR VIEW	View from the back	

NOTE FOR SERVICING

1. Precautions for servicing

- When servicing, disconnect the power plug, the printer cable, the network cable, and the telephone line from the machine, except when performing the communication test, etc.
- It may cause an injury or an electric shock.
- There is a high temp erature area inside the machin e. Use extreme care when servicing.
- It may cause a burn.
- There is a high voltage section inside the machine which may cause an electric shock. Be careful when servicing.
- Do not disassemble the laser unit. Do not insert a reflective material such as a screwdriver in the laser beam path.
 It may damage eyes by reflection of laser beams.
- When servicing with the machine opera ting, be care ful not to squeeze you hands by the ch ain, the belt, the gear, and other driving sections.
- Do not leave the machine with the cabinet disassembled.
 Do not allow any person other than a serviceman to touch inside the machine. It may cause an electric shock, a burn, or an injury.
- When servicing, do not breathe toner, developer, and ink excessively. Do not get them in the eyes.

If toner, developer, or ink enters your eyes, wash it away with water immediately, and consult a doctor if necessary.

- The machine has got sharp edges inside. Be careful not to damage fingers when servicing.
- Do not throw toner or a toner cartridge in a fire. Otherwise, toner may ignite and burn you.
- When replacing a lithium battery on a PWB, only use the specified replacement battery.

If a battery of different specification is used, it may cause a machine malfunction or breakdown.

• When carrying a unit with PWB or electronic parts installed to it, be sure to put it in an anti-static-electricity bag.

It may otherwise cause a machine breakdown or malfunction.



(200V series only)

2. Warning for servicing

 Be sure to connect the power cord only to a power outlet that meets the specified voltage and current requirements.
 Avoid complex wiring, which may lead to a fire or an electric shock.

It may cause a fire or an electric shock.

- If there is any abnormality such as a smoke or an abnor mal smell, interrupt the job and disconnect the power plug.
 It may cause a fire or an electric shock.
- Be sure to connect the grounding wire. If an electric leakage occurs without grounding, a fire or an electric shock may result.
 To protect the machine and the power unit from lightening, grounding must be made.
- When connecting the grounding wire, never connect it to the following points.
- Gas tube
- Lightning conductor
- A water pipe or a water faucet, which is not r ecognized as a grounding object by the authorities.
- Grounding wire for telephone line

It may cause an explosion, a fire or an electric shock.

• Do not damage, break, or stress the power cord. Do not put heavy objects on the power cable. Do not stress, forcibly bend, or pull the power cord.

It may cause a fire or an electric shock.

- Keep the power cable away from a heat source.
 Do not insert the power plug with dust on it into a power outlet.
 It may cause a fire or an electric shock.
- Do not place liqu ids or foreign metallic objects inside the machine.

It may cause a fire or an electric shock.

 Do not touch the power cord, insert the phone jack, oper ate the machine, or perform service on the machine with wet or oily hands.

It may cause an electric shock.

3. Note for installing site

Do not install the machine at the following sites.

 Place of high temperature, high humidity, low temperature, low humidity, place under an extreme change in temperature and humidity.

Paper may get damp and form condensation inside the machine, causing paper jam or copy dirt.

For operating and storing conditions, refer to the specifications described later.



· Place of extreme vibrations

It may cause a breakdown.



Poorly ventilated place

An electrostatic type copier will produce ozone.

The quantity of ozone produced is designed to a low level so as not to affect human bodies. However, continuous use of such a machine may produce an ozone smell. Install the machine in a well ventilated place.



• Place of direct sunlight.

Plastic parts and ink may be defor med, discolored, or may undergo qualitative change.

It may cause a breakdown or output quality problems.



Place which is full of organic gases such as ammonium

The organic photo-conductor (OPC) drum used in the machine may undergo qualitative change due to organic gases such as ammonium.

Installation of this mach ine near a diazo-type copier and blue print machine may result in poor quality output.



· Place of much dust

When dust or contaminants enters the machine, it may cause a breakdown or poor quality output.



Place near a wall

The machine will require ventilation.

If ventilation is not proper, poor output or machine failure may result.



Unstable or irregular surface

If the machine is dropped or tips over, it may cause injury or machine malfunction.

Use an optional desk or an exclusive-use desk.

When using the optional desk, be sure to fix the adjuster and lock the casters.

4. Note for handling PWB and electronic parts

When handling the PWB and the electronic p arts, be sur e to observe the following precautions in order to prevent against damage by static electricity.

• When in transit or storing, put the parts in an anti-static bag or an anti-static case and do not touch them with bare hands.



- When and after removing the parts from an anti-static bag (case), use an earth band as shown below:
 - Put an earth band to your arm, and connect it to the machine.



• When repairing or r eplacing an electronic part, perform the procedure on an anti-static mat.



5. Note for repairing/replacing the LSU

When repairing or replacing, be sure to observe the following items.

- * When repairing or replacing the LSU, be sure to disconnect the power plug from the power outlet.
- * When repairing or replacing the LSU, follow the procedures described in this Service Manual.
- * When checking the operations after repairing the LSU, keep all the parts including the cover installed and perform the operation check.
- * Do not modify the LSU.
- * When visually checking the inside of the machine for the operation check, be careful not to allow laser beams to enter the eyes.

If the above precaution is neglected or the LSU is modified, ones safety may be at risk.

6. Note for handling the drum unit, the transfer unit, the developing unit

When handling the OPC drum unit, the transfer unit, and the developing unit, strictly observe the following items.

If these items are neglected, a trouble may be generated in the copy and print image quality.

Drum unit

- * Avoid working at a place with strong lights.
- * Do not expose the OPC drum to lights including interior lights for a long time.
- * When the OPC drum is removed from the machine, cover it with light blocking material. (When using paper, use about 10 sheets of paper to cover it.)
- * Be careful not to attach fingerprints, oil, grease, or other foreign material on the OPC drum surface.

Transfer unit

* Be careful not to leave fingerprints, oil, grease, or other foreign material on the transfer roller, primary transfer belt, and the secondary transfer belt.

Developing unit

* Be careful not to leave fingerprints, oil, grease, or other foreign material on the developing unit.

7. Screw tightening torque

The screws used in this machine are largely classified into three types.

These types are classified according to the shape of the screw grooves and use positions.

The table below shows the types of the screws and the tightening torques depending on the use position.

When tightening the screws for repair or maintenance, refer to the table.

However, for the other conditions of tightening screws than specified on this table, or under special circumstances, the details are described on the separate page. Refer to the descriptions on such an exception.

Important

Especially for the screw fixing positions where there is an electrode or a current flows, use enough care to tighten securely to avoid loosening.

Screw kinds and tightening torques

Normal screws, set screws (including step screws)

Screw diameter	Material to be fixed	Tightening torque (N·m)	Tightening torque (kgf⋅cm)	Tightening torque (lbft)
M2.6	Steel plate	0.8 - 1.0	8 - 10	0.6 - 0.7
M3	Steel plate	1.0 - 1.2	10 - 12	0.7 - 0.9
M4	Steel plate	1.6 - 1.8	16 - 18	1.2 - 1.3

Tapping screws (for iron)

Screw diameter	Material to be fixed	Tightening torque (N·m)	Tightening torque (kgf⋅cm)	Tightening torque (lbft)
M3	Steel plate (Plate thickness 0.8mm or above)	1.0 - 1.2	10 - 12	0.7 - 0.9
M4	Steel plate (Plate thickness 0.8mm or above)	1.6 - 1.8	16 - 18	1.2 - 1.3
M3	Steel plate (Plate thickness less than 0.8mm)	0.6 - 0.8	6 - 8	0.4 - 0.6
M4	Steel plate (Plate thickness less than 0.8mm)	1.2 - 1.4	12 - 14	0.9 - 1.0

Tapping screw (for plastic)

Screw diameter	Material to be fixed	Tightening torque (N·m)	Tightening torque (kgf⋅cm)	Tightening torque (lbft)
M3	Plastic resin	0.6 - 0.8	6 - 8	0.4 - 0.6
M4	Plastic resin	1.0 - 1.2	10 - 12	0.7 - 0.9

Name in the manual	Model name
26cpm machine	MX-2640N/2640NR
31cpm machine	MX-3140N/3140NR/3140N A
36cpm machine	MX-3640N/3640NR

[1] PRODUCT OUTLINE

1. System diagram





2. Option list

	Model name	Description	MX-2640N MX-3140N	MX-3640N	MX-3140N A	MX-2640NR MX-3140NR MX-3640NR	Remarks
Document Feed System		REVERSING SINGLE PASS FEEDER	STD	STD	STD	STD	
	MX-DE12	STAND/1x500 SHEET PAPER DRAWER	OPT	OPT	OPT	OPT	
	MX-DE13	STAND/2x500 SHEET PAPER DRAWER	OPT	OPT	OPT	OPT	
Paper Feed	MX-DE14	STAND/3x500 SHEET PAPER DRAWER	OPT	OPT	OPT	OPT	
System	MX-DE20	STAND/500&2000 SHEET PAPER DRAWER	OPT	OPT	OPT	OPT	
	MX-LC11	LARGE CAPACITY TRAY	OPT	OPT	OPT	OPT	
	MX-LT10	LONG PAPER FEEDING TRAY	OPT	OPT	OPT	OPT	
	MX-TR13 N	EXIT TRAY UNIT	OPT	OPT	OPT	OPT	
	MX-TU12	EXIT TRAY CABINET	STD/OPT	STD/OPT	OPT	OPT	*1
	MX-FN17	FINISHER	OPT	OPT	OPT	OPT	
	MX-PN11A		OPT	OPT	_	OPT	
	MX-PN11B		OPT	OPT	OPT	OPT	
D	MX-PN11C	PUNCH MODULE	OPT	OPT	_	OPT	
Paper Exit	MX-PN11D		OPT	OPT	—	OPT	
System	MX-FN10	SADDLE STITCH FINISHER	OPT	OPT	OPT	OPT	
	MX-RB10 N	PAPER PASS UNIT	OPT	OPT	OPT	OPT	
	MX-PNX5A		OPT	OPT	_	OPT	
	MX-PNX5B		OPT	OPT	OPT	OPT	
	MX-PNX5C	PUNCH MODULE	OPT	OPT	_	OPT	
	MX-PNX5D		OPT	OPT	_	OPT	
		PRINTER EXPANSION KIT	STD	STD	STD	STD	
Printer		PS3 EXPANSION KIT	STD	STD	STD	STD	
Expansion	MX-PUX1	XPS EXPANSION KIT	OPT	OPT	OPT	OPT	
	MX-PF10	BARCODE FONT KIT	OPT	OPT	OPT	OPT	
	MX-FX11	FACSIMILE EXPANSION KIT	OPT	OPT	_	OPT	*2
Image Send	AR-SU1	STAMP UNIT	OPT	OPT	OPT	OPT	
Expansion	MX-FWX1	INTERNET FAX EXPANSION KIT	OPT	OPT	OPT	OPT	
	MX-EB11	ENHANCED COMPRESSION KIT	OPT	OPT	OPT	OPT	
Authentication /	MX-FR41U	DATA SECURITY KIT	OPT	OPT	OPT	—	
Security	MX-EB12 N	MIRRORING KIT	OPT	OPT	OPT	OPT	
-	MX-USX1	SHARPDESK 1 LICENSE KIT	OPT	OPT	OPT	OPT	
	MX-USX5	SHARPDESK 5 LICENSE kit	OPT	OPT	OPT	OPT	
	MX-US10	SHARPDESK 10 LICENSE KIT	OPT	OPT	OPT	OPT	
	MX-US50	SHARPDESK 50 LICENSE KIT	OPT	OPT	OPT	OPT	
	MX-USA0	SHARPDESK 100 LICENSE KIT	OPT	OPT	OPT	OPT	
	MX-AMX1	APPLICATION INTEGRATION MODULE	OPT	OPT	OPT	OPT	
	MX-UN01A	SHARP OSA NETWORK SCANNER TOOL 1 LICENSE KIT	OPT	OPT	OPT	OPT	
Application /	MX-UN05A	SHARP OSA NETWORK SCANNER TOOL 5 LICENSE KIT	OPT	OPT	OPT	OPT	
Solution	MX-UN10A	SHARP OSA NETWORK SCANNER TOOL 10 LICENSE KIT	OPT	OPT	OPT	OPT	
	MX-UN50A	SHARP OSA NETWORK SCANNER TOOL 50 LICENSE KIT	OPT	OPT	OPT	OPT	
	MX-UN1HA	SHARP OSA NETWORK SCANNER TOOL 100 LICENSE KIT	OPT	OPT	OPT	OPT	
	MX-AMX2	APPLICATION COMMUNICATION MODULE	STD/OPT	STD/OPT	STD	STD	*1
	MX-AMX3	EXTERNAL ACCOUNT MODULE	STD/OPT	STD/OPT	STD	STD	*1
	MX-AM10	WEB BROWSING EXPANSION KIT	OPT	STD/OPT			*1
	MX-KB11 N	KEYBOARD	STD/OPT	STD/OPT	OPT	OPT	*1
Othor	MX-PC12	PLASMACLUSTER ION GENERATOR	OPT	OPT	_	_	*2
	MX-XB16	PLASMACLUSTER ION GENERATOR MOUNTING	OPT	OPT	_	_	*2

*1 : Option for some destinations

*2 : No support for some destinations

[2] SPECIFICATIONS

1. Basic specifications

(1) Engine Specification

Photo-conductor kind	OPC (Diameter: Black:
Copying method	Electronic photo (Laser)
Developing system	Dry, 2-component magnetic brush development
Charging system	Charged saw-tooth method
Transfer system	Intermediate/secondary transfer belt
Separation system	Natural separation method * Sub separation claw is equipped.
Cleaning system	Counter blade
Fusing system	Belt method
Waste toner disposal	No toner recycling system / Waste toner bottle system
Toner supply during operation	N/A
Outer Color	Pastel white, natural wave design

(2) Engine speed (ppm)

Tray 1 - 4

Paper size	26cpm machine		31c mac	31cpm machine		36cpm machine	
	Monochrome	Color	Monochrome	Color	Monochrome	Color	
A3, 11" x 17", 8K	14	14	15	15	17	17	
B4, 8.5" x 14", 8.5" x 13",	16	16	17	17	20	20	
8.5" x 13.4", 8.5" x 13.5"							
A4, B5, 8.5" x 11", 16K	26	26	31	31	36	36	
A4R, 16KR, 8.5" x 11"R, B5R, 7.25" x10.5"R	19	19	20	20	23	23	
A5R, 5.5" x 8.5"R	19	19	20	20	27	27	
Extra	13	13	14	14	16	16	
Heavy paper (A3, 11" x 17", 8K)	7	7	7	7	8	8	
Heavy paper	7	7	7	7	8	8	
(B4, 8.5" x 14", 8.5" x 13",							
8.5" x 13.4", 8.5" x 13.5")							
Heavy paper (A4, B5, 8.5" x 11", 16K)	12	12	12	12	14	14	
Heavy paper	9	9	9	9	11	11	
(A4R, B5R, 8.5" x 11"R,							
7.25" x 10.5"R, 16KR)							
Heavy paper (A5R, 5.5" x 8.5"R)	12	12	12	12	14	14	
Heavy paper (Extra)	7	7	7	7	8	8	

Manual paper feed

Paper size	26cpm machine		31c macl	31cpm machine		36cpm machine	
	Monochrome	Color	Monochrome	Color	Monochrome	Color	
A3, 11" x 17", 8K	14	14	15	14	17	17	
B4, 8.5" x 14", 8.5" x 13",	16	16	17	16	20	20	
8.5" x 13.4", 8.5" x 13.5"							
A4, 8.5" x 11", 16K	26	23	26	23	31	31	
B5	26	26	26	26	31	31	
A4R, 16KR, 8.5" x 11"R	19	19	20	19	23	23	
B5R, 7.25" x 10.5"R	19	19	20	20	23	23	
A5R, 5.5" x 8.5"R	19	19	20	20	27	27	
A3W, 12" x 18" *2	13	13	14	13	16	16	
OHP (A4, 8.5" x 11")	12	11	12	11	14	14	
OHP (A4R, 8.5" x 11"R)	9	9	9	9	11	11	
Extra	13	13	14	13	16	16	
Envelope (Monarch, Com-10, DL, C5,	8	7	8	7	10	10	
Chokei-3, Chokei-4,							
Youkei-2, Youkei-4,							
Kakugata-2, Kakugata-3)							
Heavy paper (A3, 11 x 17, 8K)	7	6	7	6	8	8	
Heavy paper	7	6	7	6	8	8	
(B4, 8.5" x 14", 8.5" x 13",							
8.5" x 13.4", 8.5" x 13.5")							
Heavy paper (A4, 8.5" x 11", 16K, B5)	12	11	12	11	14	14	

Paper size	260 mag	cpm chine	31c mac	pm hine	36 mao	cpm chine
	Monochrome	Color	Monochrome	Color	Monochrome	Color
Heavy paper (A4R, 16KR, 8.5" x 11"R, B5R, 7.25" x 10.5"R)	9	9	9	9	11	11
Heavy paper (A5R, 5.5" x 8.5"R)	12	11	12	11	14	14
Heavy paper (A3W, 12" x 18")	7	6	7	6	8	8
Heavy paper (Extra)	7	6	7	6	8	8
Heavy paper (Post Card HIGH) *1	12	12	12	12	14	14
Heavy paper (Post Card LOW) *1	7	7	7	7	8	8

*1: Switched by the service simulation setting. Postcard is set Low before shipment.

(3) Printable area

A3 Wide *1	297 x 420mm	12" x 18" * ¹	279 x 432mm
A3	293 x 413mm	11" x 17"	275 x 425mm
B4	253 x 357mm	8.5" x 14"	212 x 349mm
A4	206 x 290mm	8.5" x 13.5"	212 x 336mm
B5	178 x 250mm	8.5" x 13.4"	212 x 333mm
A5	144 x 203mm	8.5" x 13"	212 x 323mm
Postcard	96 x 141mm	Executive	180 x 260mm
8K	266 x 383mm	8.5" x 11"	212 x 272mm
16K	191 x 263mm	5.5" x 8.5"	136 x 209mm
Custom	Min: 96mm x 141mm	Max: 297mm x	432mm

*1: The printable area for A3W/12" x 18" must be as large as the A3/11" x 17" page full bleed (299 x 450mm).

Void area	Lead edge: 4mm or less
Image loss	Rear edge: 2 mm or more, and 5 mm or less
	Total of the lead edge and the rear edge: 8mm or less
	FR total: 4mm±2mm or less

(4)Engine resolution

Resolution*1	Сору	Writing
		600 x 600dpi
		9,600 (equivalent) x 600dpi
	Print	Writing
		600 x 600dpi
		9,600 (equivalent) x 600dpi
		1,200 x 1,200dpi
Gradation *2	Сору	Writing
(256 levels)		600 x 600dpi x 4bit
		9,600 (equivalent) x 600dpi
	Print	Writing
		PCL:
		600 x 600dpi x 1bit
		600 x 600dpi x 4bit
		9,600 (equivalent) x 600dpi
		1,200 x 1,200dpi x 1bit
		PS:
		600 x 600dpi x 1bit
		600 x 600dpi x 4bit
		9,600 (equivalent) x 600dpi
		1,200 x 1,200dpi x 1bit

*1: Resolustion: 600dpi (default)

*2: The Dither and Error Diffusion methods using 8 bit input will be performed.

(5)Scanner section

a.Resolution/Gradation

Scanning		Monochrome	Color
Resolution (dpi)	Platen	600 x 600dpi	600 x 600dpi
		600 x 400dpi	
		600 x 300dpi (default)	
	RSPF	600 x 600dpi	600 x 600dpi
		600 x 400dpi (default)	
Exposure lamp	White LE	D	
Reading gradation	10bit		

Output gradation	BW: 1bit
	Grayscale: 8bit
	Full Color: each color RGB 8bit

b.Document table

Туре	Document table fixed system (Flat bed)
Scanning area	297 x 432mm
Original standard position	Left rear reference
Detection	Yes
Detection size	Automatic detection (One type of detection unit to be switched for software destination)
Dehumidifying heater (Scanner section)	Supplied as a service parts

(6)Document feeder

Туре	RSPF (Reversing singl	e pass feeder)
Scan speed	Monochrome	Color (A4/8.5" x 11")
	(A4/8.5" x 11")	
Сору	Single:	Single:
	50-sheet/min.	36-sheet/min.
	(600 x 400dpi, 4bit)	(600 x 600dpi, 4bit)
	36-sheet/min.	Double:
	(600 x 600dpi, 4bit)	17-page/min.
	Double:	(600 x 600dpi, 4bit)
	20-page/min.	
	(600 x 400dpi, 4bit)	
	17-page/min.	
	(600 x 600dpi, 4bit)	
FAX	Single: 50-sheet/min.	NA
	(200 x 200dpi, 1bit)	
	Double: 20-page/min.	
	(200 x 200dpi, 1bit)	
Internet FAX	Single: 50-sheet/min.	NA
	(200 x 200dpi, 1bit)	
	Double: 20-page/min.	
	(200 x 200dpi, 1bit)	
Scanner	Single: 50-sheet/min.	Single: 50-sheet/min.
	(200 x 200dpi, 1bit)	(200 x 200dpi, 8bit)
	Double: 20-page/min.	Double: 20-page/min. (200
	(200 x 200dpi, 1bit)	x 200dpi, 8bit)
Original setup	Upward standard (1 to	N feeding standard)
direction		
Original standard	Center standard (Rear	one-side standard for
position	random feeding)	
Original transport	Sheet-through method	
method	_	

Original size	Standard size			
	Inch-1: 11" x 17", 8.5" x 14", 8.5" x 11", 8.5" x 11"R,			
	5.5" x 8.5", A3, A4			
	Inch-2: 11" x 17", 8.5" x 13", 8.5" x 11", 8.5" x 11"R,			
	5.5" x 8.5", A3, A4			
	Inch-3: 11" x 17", 8.5" x 13.4", 8.5" x 11",			
	8.5" x 11"R, 5.5" x 8.5", A3, A4			
	AB-1: 11" x 17", 8.5" x 14", 8.5" x 11", A3, B4, A4,			
	A4R, B5, B5R, A5			
	AB-2: 11" x 17", 8.5" x 13", 8.5" x 11", A3, B4, A4,			
	A4R, A5, 8K, 16K, 16KR			
	AR-4 11" x 17" 8 5" x 13 4" 8 5" x 11" A3 R4 A4			
	A4R, B5, B5R, A5			
	AB-5: 11" x 17", 8.5" x 13.5", 8.5" x 11", A3, B4, A4,			
	A4R, B5, B5R, A5			
	Long 1000 mm(monochrome binary only)			
	paper			
Mix paper feed	Enabled			
(Same series,				
same width paper)				
Random feeding	Enabled			
(feeding of different	Only the following combinations of 2 size types are			
types / different	allowed:			
widths)	A3 and B4; B4 and A4R; A4 and B5; B5 and A5;			
	and 11-inch and 8.5-inch. AMS available. 2-sided			
	scanning is disabled during random feeding.			
Original copy	Single:			
weight	Thin paper: 9 - 13 lb bond (35 - 49 g/m ²)			
	Plain paper: 13 - 32 lb bond (50 - 128 g/m ²)			
	I nin paper mode (39 pages/minute (A4,			
	8.5" x 11", 600 x 400dpi) / 26 pages/			
	minute (A4, 8.5" x 11", 600 x 600dpi) is set			
	up for the thin paper.			
	Duplex: 13 - 28 lb bond (50 - 105 g/m ²)			
Max. loading	Max. 100 sheets (21lbs Bond, 80g/m ²), or Max.			
capacity of	height: 1/2 inch, 13mm or less			
documents				
Un-acceptable				
	OHP, second original paper, tracing paper, carbon			
originals for	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or			
originals for feeding.	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or breakage, pasted paper, cutout document,			
originals for feeding.	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or breakage, pasted paper, cutout document, document printed with ink ribbon, documents with			
originals for feeding.	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or breakage, pasted paper, cutout document, document printed with ink ribbon, documents with perforation other than 2- or 3-holes (Perforated			
originals for feeding.	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or breakage, pasted paper, cutout document, document printed with ink ribbon, documents with perforation other than 2- or 3-holes (Perforated document by punch unit is allowed.)			
originals for feeding. Detection	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or breakage, pasted paper, cutout document, document printed with ink ribbon, documents with perforation other than 2- or 3-holes (Perforated document by punch unit is allowed.) Yes			
originals for feeding. Detection Paper detection	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or breakage, pasted paper, cutout document, document printed with ink ribbon, documents with perforation other than 2- or 3-holes (Perforated document by punch unit is allowed.) Yes Auto detection			
originals for feeding. Detection Paper detection size	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or breakage, pasted paper, cutout document, document printed with ink ribbon, documents with perforation other than 2- or 3-holes (Perforated document by punch unit is allowed.) Yes Auto detection			
originals for feeding. Detection Paper detection size Paper feeding	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or breakage, pasted paper, cutout document, document printed with ink ribbon, documents with perforation other than 2- or 3-holes (Perforated document by punch unit is allowed.) Yes Auto detection Right hand feeding			
originals for feeding. Detection Paper detection size Paper feeding direction	OHP, second original paper, tracing paper, carbon paper, thermal paper, paper with wrinkles, folds, or breakage, pasted paper, cutout document, document printed with ink ribbon, documents with perforation other than 2- or 3-holes (Perforated document by punch unit is allowed.) Yes Auto detection Right hand feeding			

(7)	Paper	feed	section
-----	-------	------	---------

a.Basic specifications

Туре	Standard	1-stage paper feed tray + multi manual paper feed tray
	Full option	4-stage paper feed tray + multi manual paper feed tray
Dehumidifying heater		Service parts (Supported by kit)

Tray	Tray 1	Manual paper feed tray		
Paper capacity Plain paper	500 sheets	100 sheets		
(80g/m ²)				
Paper size	Refer to the separate table of feedable paper type.			
Paper size	No (Guide adjustment	Yes		
detection	and size input)			
Paper type settings	Yes			
Changing of paper	Switched by users			
size				
Universal handle	Yes	-		
	(With the handle lock			
	mechanism)			

Tray	Tray 1	Manual paper feed tray
Default Paper Size Setting	A4 (8.5" x 11")	-
Paper remaining quantity detection	Paper empty and 3 steps (100%, 67%, 33%, and paper empty)	Only detection of paper empty
Paper size display window	Yes	-

b. Extra paper capacity

Paper type	Paper feed tray	Manual feed tray
Postcard	NA	20 sheets
Envelope	NA	20 sheets
OHP	NA	20 sheets
Heavy paper	200 sheets	40 sheets
Tab paper	NA	20 sheets
Glossy paper	NA	1 sheet
Others	NA	1 sheet

c. Size of paper which can be fed

Paper feed excites		Main unit tray			Optiona	I Drawer			Manual paper	
	raper leeu section		Tray 1	Tray 2	Tray 3	Tray 4	Tandem (Left)	Tandem (Right)	LCC	feed tray
Paper	12" x 18" (A3W)		-	-	-	-	-	-	-	Yes
size	11" x 17"		Yes	Yes	Yes	Yes	-	-	-	Yes
	8.5" x 14" (216 x 356)		Yes	Yes	Yes	Yes	-	-	-	Yes
	8.5" x 13.5" (216 x 343)		Yes	Yes	Yes	Yes	-	-	-	Yes
	8.5" x 13.4" (216 x 340)		Yes	Yes	Yes	Yes	-	-	-	Yes
	8.5" x 13" (216 x 330)		Yes	Yes	Yes	Yes	-	-	-	Yes
	8.5" x 11"		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	8.5" x 11"R		Yes	Yes	Yes	Yes	-	-	-	Yes
	7.25" x 10.5"R		Yes	Yes	Yes	Yes	-	-	-	Yes
	5.5" x 8.5"R		Yes	Yes	Yes	Yes	-	-	-	Yes
	A3		Yes	Yes	Yes	Yes	-	-	-	Yes
	B4		Yes	Yes	Yes	Yes	-	-	-	Yes
	A4		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	A4R		Yes	Yes	Yes	Yes	-	-	-	Yes
	B5		Yes	Yes	Yes	Yes	Yes	-	Yes	Yes
	B5R		Yes	Yes	Yes	Yes	-	-	-	Yes
	A5R		Yes	Yes	Yes	Yes	-	-	-	Yes
	8K		Yes	Yes	Yes	Yes	-	-	-	Yes
	16K		Yes	Yes	Yes	Yes	-	-	-	Yes
	16KR		Yes	Yes	Yes	Yes	-	-	-	Yes
	JPC *1		-	-	-	-	-	-	-	Yes
	Envelope		-	-	-	-	-	-	-	Yes
	Custom		Yes	Yes	-	-	-	-	-	Yes
	Long paper Width: 90-279mm Length: 433-1200mm		-	-	-	-	-	-	-	Yes
Paper	Thin paper	13-16lb bond (55-59g/m ²)	No	No	No	No	No	No	No	Yes
type	Plain paper	16-28lb bond (60-105g/m ²)	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		Recycled paper	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		Color paper	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		Letter head	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		Pre printed	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		Pre Punched	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Heavy paper	28lb bond-80lb cover 106-220g/m ²	Yes	Yes	Yes	Yes	-	-	-	Yes
		80lb Cover-140lb Index 221-256g/m ²	-	-	-	-	-	-	-	Yes
		140lb Index-110lb Cover 257-300g/m ²	-	-	-	-	-	-	-	Yes
	Envelope	75-90g/m ²	-	-	-	-	-	-	-	Yes
	OHP Transparency		-	-	-	-	-	-	-	Yes
	Label		-	-	-	-	-	-	-	Yes
	Tab paper		-	-	-	-	-	-	-	Yes
	Grossy paper		-	-	-	-	-	-	-	Yes
	User settings 1 - 7		Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

(8) Paper exit section

a. Exit Capacity

Exit location	Center	Right side (option)
Exit Capacity	400 sheets (A4/8.5" x 11": 80g/m ³)	100 sheets (A4/8.5" x 11": 80g/m ³)

b. Size of paper which can be discharged

Paper exit section			Dunley	Main unit center tray		Right exit tray
			Duplex	Exit tray Off set		
Paper	12" x 18" (A3W)		-	Yes	-	Yes
size	11" x 17"		Yes	Yes	Yes	Yes
	8.5" x 14" (216 x 356)		Yes	Yes	Yes	Yes
	8.5" x 13.5" (216 x 343)		Yes	Yes	Yes	Yes
	8.5" x 13.4" (216 x 340)		Yes	Yes	Yes	Yes
	8.5" x 13" (216 x 330)		Yes	Yes	Yes	Yes
	8.5" x 11"		Yes	Yes	Yes	Yes
	8.5" x 11"R		Yes	Yes	Yes	Yes
	7.25" x 10.5"R		-	Yes	Yes	Yes
	5.5" x 8.5"R		Yes	Yes	Yes	Yes
	A3		Yes	Yes	Yes	Yes
	B4		Yes	Yes	Yes	Yes
	A4		Yes	Yes	Yes	Yes
	A4R		Yes	Yes	Yes	Yes
	B5		Yes	Yes	Yes	Yes
	B5R		Yes	Yes	Yes	Yes
	A5R		Yes	Yes	Yes	Yes
	8K		Yes	Yes	Yes	Yes
	16K		Yes	Yes	Yes	Yes
	16KR		Yes	Yes	Yes	Yes
	JPC		-	Yes	Yes	Yes
	Envelope		-	Yes	-	-
	Long paper Width: 90-279mm Length: 433-1200mm		-	Yes	-	-
Paper	Thin paper	13-16lb bond (55-59g/m ²)	-	Yes	Yes	Yes
type	Plain paper	16-28lb bond (60-105g/m ²)	Yes	Yes	Yes	Yes
		Recycled paper	Yes	Yes	Yes	Yes
		Color paper	Yes	Yes	Yes	Yes
		Letter head	Yes	Yes	Yes	Yes
		Pre printed	Yes	Yes	Yes	Yes
		Pre Punched	Yes	Yes	Yes	Yes
	Heavy paper	28lb bond - 80lb Cover (106-220g/m ²)	Yes	Yes	Yes	Yes
		80lb Cover-140lb Index 221-256g/m ²	-	Yes	Yes	Yes
		140lb Index-110lb Cover 257-300g/m ²	-	Yes	Yes	-
	Envelope	75-90g/m ²	-	Yes	-	-
	OHP Transparency		-	Yes	-	Yes
	Label		-	Yes	-	Yes
	Tab paper		-	Yes	-	-
	Grossy paper		-	Yes	Yes	-
	User settings 1 - 7		Yes	Yes	Yes	Yes

(9)Operation panel

Size	10.1 inch	
Туре	Dot matrix LCD, touch panel	
Display dot number	1024x600 dot (WSVGA)	
LCD back-light	LED lamp back-light system	

(10)Controller board

CPU		ARM11: 600MHz		
		ARM9: 400MHz/during 1W energy save mode: 75MHz		
So	C	Intel Atom D525 1.8GHz		
Int	erface			
Eth	hernet	1port		
	Interface	10Base-T, 100Base-TX, 1000Base-T		
	Support Protocol	TCP/IP (IPv4, IPv6), IPX/SPX, EtherTalk		
US sp	SB 2.0 (high eed) (host)	2port (Simultaneous use of the front/rear ports is enable.)		
US sp	B 2.0 (high eed) (device)	1port		
US	B-HUB (host)	Internal: 4port • For Front USB Port • For Wifi • For IC Card Reader • For Key Board		
Se	erial I/F	1port		
Me	emory	See the section "Memory/Hard disk".		
Me	emory slot	Main unit: On Board		

(11) Memory/Hard disk

SD	Com pact	For Image process	For P	rinting	HDD*
card	Flash	On Board	On Board	SLOT	
4GB	8GB	1GB (STD)	2GB (STD)	1GB (STD)	320GB (STD)

*: HDD capacity depends on procurement and sourcing status.

Memory area	Boot/Program area
(SD card)	FAX data storage area
	1GB

(12) Warm-up time

	Main power SW
Warm-up time*1	18sec. or less
Pre heat	Yes
Jam recovery time*2	37sec. or less

*1: Result may change depending on conditions.

*2: Conditions: Leave the machine for 60 sec. after door open, standard condition, Polygon stops.

(13) Wireless LAN specification

Туре	Built-in type
Compliance standards	Wireless LAN Standard Protocol
	IEEE802.11n/g/b
Transmission method	OFDM (IEEE 802.11n/g), DS-SS (IEEE
	802.11b)
Transmission frequency	IEEE802.11n/g/b:2.4GHz 11b(1 - 14ch) / 11g/
range	n(1 - 13ch)
(center frequency	
Security	WEP, WPA-PSK, WPA-EAP*1, WPA2-PSK,
	WPA2-EAP*1
Number of max concurrent	5
connection	

*1: Cannot be used in Access Point mode.

B. Copy functions

(1) First copy time

Engine	26cpm machine		31cpm machine		36cpm machine	
Engine	Monochrome	Color	Monochrome	Color	Monochrome	Color
Platen	5.9 sec.	8.1 sec.	5.8 sec.	7.9 sec.	5.2 sec.	6.8 sec.
RSPF	9.1 sec.	11.6 sec.	9.1 sec.	11.6 sec.	8.1 sec.	10.6 sec.

(2) Job Speed

Engino	26cpm	26cpm machine		31cpm machine		36cpm machine	
Engine	Monochrome	Color	Monochrome	Color	Monochrome	Color	
S to S	26cpm (100%)	26cpm (100%)	31cpm (100%)	31cpm (100%)	36cpm (100%)	36cpm (100%)	

C. Printer function

(1) Printer driver supported OS

OS		Custom PCL6	Custom PS	PPD	PC-FAX
Windows	XP	CD-ROM	CD-ROM	CD-ROM	CD-ROM
	XP (x 64)	CD-ROM	CD-ROM	CD-ROM	CD-ROM

	OS	Custom PCL6	Custom PS	PPD	PC-FAX
Windows	Server 2003	CD-ROM	CD-ROM	CD-ROM	CD-ROM
	Server 2003 (x 64)	CD-ROM	CD-ROM	CD-ROM	CD-ROM
	Vista	CD-ROM	CD-ROM	CD-ROM	CD-ROM
	Vista (x 64)	CD-ROM	CD-ROM	CD-ROM	CD-ROM
	Server 2008	CD-ROM	CD-ROM	CD-ROM	CD-ROM
	Server 2008 (x 64)	CD-ROM	CD-ROM	CD-ROM	CD-ROM
	Server 2012x64	Web	No	Web	Web
	Windows 7	CD-ROM	CD-ROM	CD-ROM	CD-ROM
	Windows 7 (x 64)	CD-ROM	CD-ROM	CD-ROM	CD-ROM
	Windows 8	Web	No	Web	Web
	Windows 8 (x 64)	Web	No	Web	Web
Mac	X 10.4	No	No	CD-ROM	No
	X 10.5	No	No	CD-ROM	Web
	X 10.6	No	No	CD-ROM	Web
	X 10.7	No	No	CD-ROM	Web
	X 10.8	No	No	No	No

(2)PDL emulation/Font

PDL (Command)		Installed font	Option font
PCL6 compatibility	STD	European outline font = 80 styles	Barcode font = 28 styles
		Line printer iont (BIVIP) = 1 style	
Postscript3	STD	European outline font = 136 styles	-

D. FAX function

(1) Transmission method

Transmission time	Less than 3 sec (Super G3)
	Less than 7 sec (G3 ECM)
Compression/	MH, MR, MMR, JBIG
expansion system	(Fixed to ECM for MMR or JBIG.)
Modem speed	33.6kbps \rightarrow 2.4kbps automatic fallback
Resolution	8 x 3.85 line/mm, 8 x 7.7 line/mm,
	8.15.4 line/mm, 16 x 15.4 line/mm (Standard
	memory is used for transmit/receive.)
Intercommunication	G3/Super G3: Standard (V.34, V.17, V.33, V.29,
	V.27ter)
Communication line	General telephone line (PSTN), ISDN (When TA
	is installed.) Private Branch Exchange (PBX)
ECM	Yes

(2) Number of Support Line

Standard	1 line
Expansion	Not provided

(3) Transmission Mode

RSPF/OC	Yes (Switching during the reading is not feasible)
transmission switching	

(4) Image Quality/Image Process

Half tone reproduction	Equivalent to 256 levels (Valid only when	
	monochrome document is scanned.)	
Exposure adjustment	Auto / Manual (5 steps)	
FAX quality selection	Standard (8 x 3.85 lines/mm (203.2 x 97.8dpi))	
	Fine (8 x 7.7 lines/mm (203.2 x 195.6dpi))	
	Super Fine (8 x 15.4 lines/mm (203.2 x 391dpi))	
	Ultra Fine (16 x 15.4 lines/mm (406.4 x 391dpi))	
	Half-tone (Combination with normal character is	
	invalid.)	

(5) Record Size

Max. record width	293mm	
Record size	(AB series)	
	A3, B4, A4, A4R, B5, B5R, A5R	
	(Inch series)	
	11 x 17, 8.5 x 13, 8.5 x 14, 8.5 x 11, 8.5 x 11R,	
	8.5 x 5.5R	

* If the document length exceeds A3 size, it is divided and printed.

 * For printing the list, A5R and 8.5 x 5.5R cannot be used.

(6) Dial

Manual dialing	To be entered by 10-key, # key, * key	
Re-dialing	The previous 8 items (max.) can be saved, and	
	one of them can be selected.	
	One-touch call is available.	
One-touch dialing	2000 items including the group dialing items	
Group dialing	2000 items including the one-touch dialing	
	items	
Program dialing	Max. 48 items	
Chain dialing	Max. 64 digits including one-touch dialing,	
	10-key dialing, and pause.	
Dial search	Alphabet order search, User index groups	
Quick search	Yes	
LDAP search	Yes	
Sub address	Yes	
Password	Yes	
Memory box registration	Yes	

* LDAP: Lightweight Directory Access protocol

(7) Memory for Transmit/Receive

FAX transmission data	HDD
FAX reception data	SD card

(8) Function

r		
Transmit	Calling function	Yes
function		Requires the frequency
		setting for each destination.
	PBX function	Germany, France only
	Memory transmit	Yes (Definable destinations :
		94 destinations)
	On-hook	Yes
	Quick online transmit	Yes
	Direct transmit	Yes
	Manual transmit	Yes
	Auto re-call mode	Yes
	Time indication function	Yes
	Sequential broadcasting	Yes
	function	
	F code interface	Yes
	broadcasting indication	Only one interface station
	function	can be specified.
	F code interface	Yes
	broadcasting function	
	F code confidential send	Yes
	function	
	Polling	Yes
		Even with another company
		machine
	Sequential polling function	Yes
		Even with another company
	E ando polling	Machine
	P-code politing	Yee
	E codo bullotin boord	Yee
	function	res
	Auto reduction transmit	Yes
		$A3 \rightarrow B4, A3 \rightarrow A4, B4 \rightarrow A4$
	Rotation transmit	Yes
		Counterclockwise rotation of
	Dueleu trez errit	90 degrees
	Duplex transmit	Yee
	function	Yes
Transmit	Long length original transmit	Only when RSPF is used.
function		Transmission is enable up to
		1000mm.
	Mixed documents function	Only when RSPF is used.
	Zoom transmit	Yes
	2 in 1 transmit	Yes
	Card shot transmit	Only when transmitting from OC
	Thin paper scan function	Available except for duplex scan
	Edge erase transmit function	Yes
		Only for the fixed sizes
	Job build	Yes
	Page division transmit	Yes
	Cover	No
	Index	No
	Transmit message adding	No
	function	

Receive	Auto receive	Yes
function	Manual receive	Yes
	DRD call function	Distinctive Ring Detection
		North America: Standard,
		Pattern 1 – 5
		Australia/New Zealand/Hong
		Kong: ON/OFF (TEL/FAX)
	Memory receive	Yes
	Transfer function	Yes
		Number of registration: 1
		item
	Specified receive function	Yes (Number of registration)
		Rejection numbers: Max.50
		items
	Receive data print condition	Yes
	function	
Receive	Receive data staple setting/	Yes
function	Copy number setting	
	Rotation receive	Yes
		Output by clockwise rotation
		of 90 degrees
	Divided receive	Yes
		Divided print is not made in
		duplex mode
	Duplex receive	Yes
	E-code confidential receive	Ves
Created	Drint hold	Vee
Special	Print hold	res
Tunction	Document Admin	Yes
	Inbound Routing	Yes
	Sender registration function	Yes
	Sender print function	Yes
	On-hook dialing function	Yes
	Retransmit function	Yes
	Pause function	Yes
		Pause time is 1 – 15 sec.
	Sound volume setting	Yes
	function	
	Tone pulse select function	Tone, Pulse, Auto
	•	(North America/Taiwan)
		* For the other destina-
		tions, set with the soft
		switch
	External phone connection	Ves
	Memory remaining consoity	Vee
	check function	Only the integral part is
	CHECK TURCION	displayed
	Dealeun	Vec
	Back up	ies
	Registered data read/write	Yes
	Tunction	
	Report/List	Yes
	Destination check function	Yes
	Broadcasting destination	Yes
	display function	
	Transmit job change function	Yes
	Save-energy function	Yes
	Line monitor display function	Yes
Special	FAST	Yes
function		Facsimile Automated Service
		Technology
	Time adjust function	Yes
		Summer time ON/OFF
	PC-FAX	Yes
	Color mode	No
		Yes
	Sender registration function	100
	Sender registration function	Number of registration: 1 for
	Sender registration function	Number of registration: 1 for standard sender name and
	Sender registration function	Number of registration: 1 for standard sender name and address. And 18 sender
	Sender registration function	Number of registration: 1 for standard sender name and address. And 18 sender names can be registered.
	Sender registration function	Number of registration: 1 for standard sender name and address. And 18 sender names can be registered. No
	Default destination setting Unauthorized scan	Number of registration: 1 for standard sender name and address. And 18 sender names can be registered. No Yes
	Default destination setting Unauthorized scan prevention function	Number of registration: 1 for standard sender name and address. And 18 sender names can be registered. No Yes
	Default destination setting Unauthorized scan prevention function	Number of registration: 1 for standard sender name and address. And 18 sender names can be registered. No Yes
	Default destination setting Unauthorized scan prevention function Filing-each-page function Re-operation function	Number of registration: 1 for standard sender name and address. And 18 sender names can be registered. No Yes

Special function	User account function	Yes Max. 200 items additionally to the default
	Counter function	Yes

E. Image send function

(1)Mode

Mode	Scanner	Internet Fax/Direct SMTP
suport mode	E-mail/FTP server/SMB	
	Desktop	

(2) Support System

Mode	Scanner	Internet Fax/Direct SMTP
Compression server protocol	SMTP/SMTP-SSL FTP(TCP/IP)/FTPS	POP3 server SMTP server
	SMB*1 HTTP/HTTPS	ESMTP server

*1 Network environment for SMB

(3) Supported image

Mode	Scanner	Internet Fax/Direct SMTP
Format / method	Mono 2gradation : TIFF/PDF/Encrypted PDF/PDF/A/XPS Color/Grayscale : Color TIFF/JPEG/PDF Encrypted PDF/PDF/A/ XPS	Monochrome : TIFF-FX (TIFF-F/ TIFF-S) Color/Grayscale : N/A
Compression method	Mono 2gradation : Non-compression G3 MH / G4 MMR Color/Grayscale : JPEG (high/middle/ low)	Monochrome : G3 MH / G4 MMR Color/Grayscale : N/A

(4) Specification of Addresses

Mode	Scanner	Internet Fax/Direct SMTP
Max. number of registrations	Total 2000 keys FTP/Desktop/SMB address shall be the same as those for other modes. Maximum 2000 addresses shall be able tobe registered	
Number of addresses can be registered in one Group key	Max. 500 addresses	
Number of addresses can be registered by inputting directly in Group keys	6000 addresses (included in the 2000 keys)	
Import/export of the address book	Yes	Yes
Disable registering destination from operation panel	Yes	Yes
Disable registering destination on Web page	Yes	Yes
Disable regisstration using network scanner tool	Yes	N/A
Disable [RESEND] on Image send mode	Yes	Yes
Disable selection from address book	Yes	Yes
Disable direct entry	Yes	Yes

(5) Function

Function	Scanner	Internet Fax/Direct SMTP
Job Build	YES	YES
Slow scan mode	YES	YES
Mixed size original	YES	YES
Original count	YES	YES
Edge erase	Yes (Edge/Side)	Yes (Edge/Side)
Dual page scan	YES	YES
Card shot	Yes (Ration: 63-400%)	Yes (Ration: 63-400%)
Time specified send	Yes	Yes
Blank page skip	Yes	N/A
Filling	Yes	Yes
Quick file	Yes	Yes
Multi shot	N/A	Yes
Preview	Yes	Yes

F. Power consumption

The full configuration can be operated with the rated power source.

Maximum rated power	100 V	200 V
Consumption ^{*1}	1.44 kW	1.84 kW
Energy consumption rate	Not applicable	
Network/Fax waiting power consumption	 W Condition: No USB port The network protocol is TCP/ IP only. The Ethernet connection part- ner supports 10M/100MBASE or 10M/100M/ 1000MBASE and auto negoti- ation setting. * Exclude the case of use Fax and Network at once) * Norht America Default : Wake up mode 	_
Moving time to pre- heat mode	1 minutes (default)	
Recovery time from pre-heat mode	10 sec.	
Moving time to sleep mode	1 minutes (default) * Printer mode: 10s	ec.(default)
Recovery time from sleep mode	18 sec.	

*1: Power switch ON, dehumidity heater OFF



G. Dimensions and Weight

Outer dimension	W608 x D680 x H834mm 23 15/16 x 26 25/32 x 32 61/64 inch
Footprint	W608xD680mm 23 15/16 x 26 25/32 inch
Dimension occupied by the machine	W928xD680mm with manual tray extended 36 17/32 x26 25/32 inch W988xD680mm with right tray extended 38 57/64 x 26 25/32 inch
Weight Main Unit (including photoreceptor / not including consumables)	76kg 167.5 lbs

H. Ambient conditions



[3] CONSUMABLE PARTS

1. Supply system table

(1) North America, Middle America, South America

ltem	Content		Life	Model name	Quantity in collective package	Remarks
Toner cartridge (Black)	Toner cartridge (Black toner)	x 1	24K	MX-36NT-BA	10	* Life: A4/Letter size at area coverage 5% (Reference: 20K for A4/ Letter 6%)
Toner cartridge (Cyan)	Toner cartridge (Cyan toner)	x 1	15K	MX-36NT-CA	10	* Life: A4/Letter size at area coverage 5%
Toner cartridge (Magenta)	Toner cartridge (Magenta toner)	x 1	15K	MX-36NT-MA	10	
Toner cartridge (Yellow)	Toner cartridge (Yellow toner)	x 1	15K	MX-36NT-YA	10	
Developer (Black)	Developer (Black developer)	x 1	840K rotaion	MX-36NV-BA	10	Developer/Drum unit Standard Printable number
Developer (Cyan/Magenta/ Yellow: 3 colors/set)	Developer (Cyan/Magenta/Yellow: 3 colors/set) (Developer (each colors))	x 1	840K rotaion	MX-36NV-SA	10	BK:26cpm120K / 31cpm 135K/ 36cpm150
Drum	OPC drum	x 1	840K rotaion	MX-36NR-SA	10	CL:26/31/36cpm 120K Maximum Printable number
Drum unit	OPC drum unit (Process unit + OPC drum) Color identification seal (B/C/M/Y) x 1 each Charger cleaner	x 1 x 1 x 1	840K rotaion	MX-36NU-SB	10	BK:26cpm 140K / 31cpm 155K/170K CL:26/31/36cpm 140K

(2) Europe, Australia, New Zealand, Korea

Item	Content		Life	Model name	Quantity in collective package	Remarks
Toner cartridge (Black)	Toner cartridge (Black toner)		24K	MX-36GT-BA	10	* Life: A4/Letter size at area coverage 5% (Reference: 20K for A4/ Letter 6%)
Toner cartridge (Cyan)	Toner cartridge (Cyan toner)	x 1	15K	MX-36GT-CA	10	* Life: A4/Letter size at area coverage 5%
Toner cartridge (Magenta)	Toner cartridge (Magenta toner)	x 1	15K	MX-36GT-MA	10	
Toner cartridge (Yellow)	Toner cartridge (Yellow toner)	x 1	15K	MX-36GT-YA	10	
Developer (Black)	Developer (Black developer)	x 1	840K rotaion	MX-36GV-BA	10	Developer/Drum unit Standard Printable number
Developer (Cyan/Magenta/ Yellow: 3 colors/set)	Developer (Cyan/Magenta/Yellow: 3 colors/set) (Developer (each colors))	x 1	840K rotaion	MX-36GV-SA	10	BK:26cpm120K / 31cpm 135K/ 36cpm150
Drum	OPC drum	x 1	840K rotaion	MX-36GR-SA	10	CL:26/31/36cpm 120K Maximum Printable number
Drum unit	OPC drum unit (Process unit + OPC drum) Color identification seal (B/C/M/Y) x 1 each Charger cleaner	x 1 x 1 x 1	840K rotaion	MX-36GU-SA	10	BK:26cpm 140K / 31cpm 155K/170K CL:26/31/36cpm 140K

(3) Asia, Hong Kong

ltem	Content		Life	Model name	Quantity in collective package	Remarks
Toner cartridge (Black)	Toner cartridge (Black toner)	x 1	24K	MX-36AT-BA	10	* Life: A4/Letter size at area coverage 5% (Reference: 20K for A4/ Letter 6%)
Toner cartridge (Cyan)	Toner cartridge (Cyan toner)	x 1	15K	MX-36AT-CA	10	* Life: A4/Letter size at area coverage 5%
Toner cartridge (Magenta)	Toner cartridge (Magenta toner)	x 1	15K	MX-36AT-MA	10	
Toner cartridge (Yellow)	Toner cartridge (Yellow toner)	x 1	15K	MX-36AT-YA	10	
Developer (Black)	Developer (Black developer)	x 1	840K rotaion	MX-36AV-BA	10	Developer/Drum unit Standard Printable number
Developer (Cyan/Magenta/ Yellow: 3 colors/set)	Developer (Cyan/Magenta/Yellow: 3 colors/set) (Developer (each colors))	x 1	840K rotaion	MX-36AV-SA	10	BK:26cpm120K / 31cpm 135K/ 36cpm150
Drum	OPC drum	x 1	840K rotaion	MX-36AR-SA	10	CL:26/31/36cpm 120K Maximum Printable number
Drum unit	OPC drum unit (Process unit + OPC drum) Color identification seal (B/C/M/Y) x 1 each Charger cleaner	x 1 x 1 x 1	840K rotaion	MX-36AU-SA	10	BK:26cpm 140K / 31cpm 155K/170K CL:26/31/36cpm 140K

(4) Middle East, Taiwan, Africa, Israel, Phillipines

ltem	Content		Life	Model name	Quantity in collective package	Remarks
Toner cartridge (Black)	Toner cartridge (Black toner)	x 1	24K	MX-36FT-BA	10	* Life: A4/Letter size at area coverage 5% (Reference: 20K for A4/ Letter 6%)
Toner cartridge (Cyan)	Toner cartridge (Cyan toner)	x 1	15K	MX-36FT-CA	10	* Life: A4/Letter size at area coverage 5%
Toner cartridge (Magenta)	Toner cartridge (Magenta toner)	x 1	15K	MX-36FT-MA	10	
Toner cartridge (Yellow)	Toner cartridge (Yellow toner)	x 1	15K	MX-36FT-YA	10	
Developer (Black)	Developer (Black developer)	x 1	840K rotaion	MX-36FV-BA	10	Developer/Drum unit Standard Printable number
Developer (Cyan/Magenta/ Yellow: 3 colors/set)	Developer (Cyan/Magenta/Yellow: 3 colors/set) (Developer (each colors))	x 1	840K rotaion	MX-36FV-SA	10	BK:26cpm120K / 31cpm 135K/ 36cpm150
Drum	OPC drum	x 1	840K rotaion	MX-36FR-SA	10	CL:26/31/36cpm 120K Maximum Printable number
Drum unit	OPC drum unit (Process unit + OPC drum) Color identification seal (B/C/M/Y) x 1 each Charger cleaner	x 1 x 1 x 1	840K rotaion	MX-36FU-SA	10	BK:26cpm 140K / 31cpm 155K/170K CL:26/31/36cpm 140K

1 : '14/Jun**2. Maintenance parts list**

(1) North America, Middle America, South America

	Model			Li	Life		
ltem	name	Content		26/31cpm	36cpm	collective package	Remarks
Fusing belt kit	MX-361FB	Fusing belt	x 1	200K	240K	10	
		Fuser belt guide collar	x 2				
Pressure roller kit	MX-230LH	Fusing roller	x 1	200K	240K	10	
		Pressure roller	x 1				
Web cleaning kit	MX-360WB	Web roller	x 1	200K	200K	10	
		Web guide shaft	x 2				
		Web pressure roller	x 1				
		Web pressure roller bearing	x 2				
Primary transfer belt kit	MX-230B1	Primary transfer belt AR	x 1	200K	240K	10	
Primary transfer blade kit	MX-230TL	Primary transfer blade AR	x 1	200K	240K	10	
PTC kit	MX-230CU	PTC unit	x 1	200K	200K	10	
Secondary transfer belt kit	MX-230B2	Secondary transfer belt D3	x 1	300K	360K	10	
Filter kit	MX-361FL	Ozone filter	x 1	300K	360K	10	
Toner collection container	MX-230HB	Toner collection container (with LSU cleaner x 2)	x 1	50K	50K	10	5% coverage for each color; 25% color ratio
Main charger kit	MX-230MK	Main charger unit Cleaning gum AS AR Cleaning blade AR	x 1 x 1 x 1	Drum 840K Rotation	Drum 840K Rotation	10	Maximum Printable Number 26cpm : 140K (BK) / 140K (CL) 31cpm : 155K (BK) / 140K (CL) 36cpm : 170K (BK) / 140K (CL)
Staple cartridge	AR-SC3	Staple cartridge	х З	2000 times x 3	2000 times x 3	40	For MX-FN10(Saddle stitch)
Staple cartridge	MX-SCX1	Staple cartridge	х З	5000 times x 3	5000 times x 3	20	For MX-FN10/FN17
Finish stamp cartridge	AR-SV1	Finish stamp cartridge	x 2	-	-	20	
Primary transfer belt unit	MX-230U1	Primary transfer belt unit	x 1	-	-	1	For servicing rotation
Secondary transfer belt unit	MX-230U2	Secondary transfer belt unit	x 1	-	-	1	For servicing rotation
Fusing unit	MX-361FU1	Fusing unit (Heater lamp 120V)	x 1	-	-	1	For servicing rotation
Fusing unit	MX-361FU	Fusing unit (Heater lamp 230V)	x 1	-	-	1	For servicing rotation

Note

When shipping, the parts are packed in the unit of 10 sets. In the market, however, they are treated in the unit of 1 set. Model name: Composed of the parts of 1 set

(2) Europe, Eastern Europe, Australia, New Zealand, Korea, Taiwan

	Model	Content		Li	fe	Quantity in	
ltem	name			Te Content		26/31cpm	36cpm
Fusing belt kit	MX-361FB	Fusing belt	x 1	200K	240K	10	
		Fuser belt guide collar	x 2				
Pressure roller kit	MX-230LH	Fusing roller	x 1	200K	240K	10	
		Pressure roller	x 1				
Web cleaning kit	MX-360WB	Web roller	x 1	200K	200K	10	
		Web guide shaft	x 2				
		Web pressure roller	x 1				
		Web pressure roller bearing	x 2				
Primary transfer belt kit	MX-230B1	Primary transfer belt AR	x 1	200K	240K	10	
Primary transfer blade kit	MX-230TL	Primary transfer blade AR	x 1	200K	240K	10	
PTC kit	MX-230CU	PTC unit	x 1	200K	200K	10	
Secondary transfer belt kit	MX-230B2	Secondary transfer belt D3	x 1	300K	360K	10	
Filter kit	MX-361FL	Ozone filter	x 1	300K	360K	10	
Toner collection container	MX-230HB	Toner collection container (with LSU cleaner x 2)	x 1	50K	50K	10	5% coverage for each color; 25% color ratio
Main charger kit	MX-230MK	Main charger unit Cleaning gum AS AR Cleaning blade AR	x 1 x 1 x 1	Drum 840K Rotation	Drum 840K Rotation	10	Maximum Printable Number 26cpm : 140K (BK) / 140K (CL) 31cpm : 155K (BK) / 140K (CL) 36cpm : 170K (BK) / 140K (CL)
Staple cartridge	AR-SC3	Staple cartridge	х З	2000 times x 3	2000 times x 3	40	For MX-FN10(Saddle stitch)
Staple cartridge	MX-SCX1	Staple cartridge	х З	5000 times x 3	5000 times x 3	20	For MX-FN10/FN17
Finish stamp cartridge	AR-SV1	Finish stamp cartridge	x 2	-	-	20	
Primary transfer belt unit	MX-230U1	Primary transfer belt unit	x 1	-	-	1	For servicing rotation
Secondary transfer belt unit	MX-230U2	Secondary transfer belt unit	x 1	-	-	1	For servicing rotation
Fusing unit	MX-361FU2	Fusing unit (Heater lamp 110V)	x 1	-	-	1	For servicing rotation
Fusing unit	MX-361FU	Fusing unit (Heater lamp 230V)	x 1	-	-	1	For servicing rotation

Note

When shipping, the parts are packed in the unit of 10 sets. In the market, however, they are treated in the unit of 1 set.

Model name: Composed of the parts of 1 set

(3) Asia, Middle East

Item	Model name	Content		Li	ife	Quantity in collective	Remarks
				26/31cpm	36cpm	package	
Fusing belt kit	MX-361FB	Fusing belt	x 1	200K	240K	10	
		Fuser belt guide collar	x 2				
Pressure roller kit	MX-230LH	Fusing roller	x 1	200K	240K	10	
		Pressure roller	x 1				
Web cleaning kit	MX-360WB	Web roller	x 1	200K	200K	10	
		Web guide shaft	x 2				
		Web pressure roller	x 1				
		Web pressure roller bearing	x 2				
Primary transfer belt kit	MX-230B1	Primary transfer belt AR	x 1	200K	240K	10	
Primary transfer blade kit	MX-230TL	Primary transfer blade AR	x 1	200K	240K	10	
PTC kit	MX-230CU	PTC unit	x 1	200K	200K	10	
Secondary transfer belt kit	MX-230B2	Secondary transfer belt D3	x 1	300K	360K	10	
Filter kit	MX-361FL	Ozone filter	x 1	300K	360K	10	
Toner collection container	MX-230HB	Toner collection container (with LSU cleaner x 2)	x 1	50K	50K	10	5% coverage for each color; 25% color ratio
Main charger kit	MX-230MK	Main charger unit Cleaning gum AS AR Cleaning blade AR	x 1 x 1 x 1	Drum 840K Rotation	Drum 840K Rotation	10	Maximum Printable Number 26cpm : 140K (BK) / 140K (CL) 31cpm : 155K (BK) / 140K (CL) 36cpm : 170K (BK) / 140K (CL)
Staple cartridge	AR-SC3	Staple cartridge	х 3	2000 times x 3	2000 times x 3	40	For MX-FN10(Saddle stich)
Staple cartridge	MX-SCX1	Staple cartridge	х З	5000 times x 3	5000 times x 3	20	For MX-FN10/FN17
Finish stamp cartridge	AR-SV1	Finish stamp cartridge	x 2	—	—	20	
Primary transfer belt unit	MX-230U1	Primary transfer belt unit	x 1	_	_	1	For servicing rotation
Secondary transfer belt unit	MX-230U2	Secondary transfer belt unit	x 1	_	_	1	For servicing rotation
Fusing unit	MX-361FU	Fusing unit (Heater lamp 230V)	x 1	_	_	1	For servicing rotation

Note

When shipping, the parts are packed in the unit of 10 sets. In the market, however, they are treated in the unit of 1 set. Model name: Composed of the parts of 1 set.

(4) Hong Kong

				Li	fe	Quantity in	
ltem	Model name	Content		26/31cpm	36cpm	collective package	Remarks
Fusing belt kit	MX-361FB	Fusing belt	x 1	200K	240K	10	
		Fuser belt guide collar	x 2				
Pressure roller kit	MX-230LH	Fusing roller	x 1	200K	240K	10	
		Pressure roller	x 1				
Web cleaning kit	MX-360WB	Web roller	x 1	200K	200K	10	
		Web guide shaft	x 2				
		Web pressure roller	x 1				
		Web pressure roller bearing	x 2				
Primary transfer belt kit	MX-230B1	Primary transfer belt AR	x 1	200K	240K	10	
Primary transfer blade kit	MX-230TL	Primary transfer blade AR	x 1	200K	240K	10	
PTC kit	MX-230CU	PTC unit	x 1	200K	200K	10	
Secondary transfer belt kit	MX-230B2	Secondary transfer belt D3	x 1	300K	360K	10	
Filter kit	MX-361FL	Ozone filter	x 1	300K	360K	10	
Toner collection container	MX-230HB	Toner collection container (with LSU cleaner x 2)	x 1	50K	50K	10	5% coverage for each color; 25% color ratio
Main charger kit	MX-230MK	Main charger unit	x 1	Drum	Drum	10	Maximum Printable Number
		Cleaning gum AS AR	x 1	840K	840K		26cpm : 140K (BK) / 140K (CL)
		Cleaning blade AR	X 1	Rotation	Rotation		31cpm : 155K (BK) / 140K (CL) 36cpm : 170K (BK) / 140K (CL)
Staple cartridge	AR-SC3	Staple cartridge	х З	2000 times x 3	2000 times x 3	40	For MX-FN10(Saddle stich)
Staple cartridge	MX-SCX1	Staple cartridge	x 3	5000 times x 3	5000 times x 3	20	For MX-FN10/FN17
Finish stamp cartridge	AR-SV1	Finish stamp cartridge	x 2	_	—	20	
Primary transfer belt unit	MX-230U1	Primary transfer belt unit	x 1	_	—	1	For servicing rotation
Secondary transfer belt unit	MX-230U2	Secondary transfer belt unit	x 1		_	1	For servicing rotation
Fusing unit	MX-361FU	Fusing unit (Heater lamp 230V)	x 1	_	_	1	For servicing rotation

Note

When shipping, the parts are packed in the unit of 10 sets. In the market, however, they are treated in the unit of 1 set.

Model name: Composed of the parts of 1 set

3. Definition of developer/drum life end

When the developer/drum counter reaches the maximum printable count.

When the developer/drum rpm reaches the specified count.

When either of the above reach the specified count, it is judged as life end.

In an actual case, the ratio of monochrome output and color output may differ greatly.

When data of mixed documents (monochrome and color) are output, monochrome document data may be output in the color mode in order to prevent against fall in the job efficiency. (ACS auto color selection).

In addition, when correction or warm-up operation is performed as well as output operation, the developer and the drum rotates.

Therefore, the developer/drum consuming level cannot be determined only by the copy/print quantity. When, therefore, the rpm reaches the specified amount, it is judged as life end.

To check the developer/drum life, use SIM22-13.

However, when the copy/print quantity is large and the developer/ drum counter reaches the maximum printable quantity even if the rpm does not reach the specified amount, it is judged as life end. The table which shows the relation between the standard printable quantity and the maximun printable quantity in the specified rpm amount is as follows.







* Standard printable quantity means the printing quantity under the specified developer/drum count by using the specified test data with the color ratio of 30% under the following intermitment sheet.

26cpm : 3 sheets 31/36cpm : 4 sheets

		Develop cou	Develop rota	er/drum tion		
	Standar able qu	d print- Jantity	Maximu able qu	m print- uantity	Mono- chrome	Color
	Mono- chrome	Color	Mono- chrome	Color	840K Rotation	840K Rotation
26cpm	120K	120K	140K	140K		
31cpm	135K	120K	155K	140K		
36cpm	150K	120K	170K	140K		

4. Production number identification

A. OPC drum



The lot number is comprised of 10 digits. Each digit indicates the content as follows.

The number is printed on the flange on the front side.

- 1: Number
 - For this model, this digit is 2.
- 2: Alphabet
 - Indicates the model conformity code.
- 3: Number
- Indicates the end digit of the production year.

 4: Number or X, Y, Z Indicates the production month.
 X stands for October, Y November, and Z December.

5/6: Number Indicates the day of the production date.

X stands for October, Y November, and Z December. Number

- Number Indicates the day of the month of packing. X stands for October, Y November, and Z December.
- 8/9: Number Indicates the day of the packing date.10: Alphabet

): Alphabet Indicates the production factory.



The lot number is 8 digits in length. Each digit indicates the content as follows.

The number is printed on the right under side of the back surface of the developer bag.

- 1: Alphabet
- Indicates the production factory.
- 2: Number Indicates the production year.
- 3/4: Number
- Indicates the production month. 5/6: Number
- Indicates the production day.
- 7: Hyphen 8: Number
- Indicates the production lot.

C. Toner cartridge

The label indicating the management number is attached to the side of the toner cartridge.



- □: Unit code/Model name
- Color code (Black: BK /Cyan: CY /Magenta: MA /Yellow: YE)
- ▲: Destination
- Skating
- Production place
- O: Production date (YYYYMMDD)
- O: Serial number
- riangle: Version number

5. Environmental conditions



Standard environmental	Temperature	20 – 25 °C
conditions	Humidity	65 ± 5 %RH
Usage environmental	Temperature	10 – 35 °C
conditions	Humidity	20 – 85 %RH
Storage period	Toner/Develop manufactured unsealed state Drum: 36 mont under unsealed	er: 24 months from the month (Production lot) under hs from the manufactured month d state

[4] EXTERNAL VIEW AND INTERNAL STRUCTURE

1. External view



No.	Name	Function/Operation
1	Reversing single pass feeder	This automatically feeds and scans multiple originals.
		Both sides of 2-sided originals can be automatically scanned.
2	Front cover	Open this cover to switch the main power switch to "On" or "Off" or to replace a toner cartridge.
3	Output tray (center tray)	Output is delivered to this tray.
4	Operation panel	This is used to select functions and enter the number of copies.
5	Exit tray unit (right exit tray)*	When installed, output can be delivered to this tray.
6	Bypass tray	Use this tray to feed paper manually.
		When loading a large sheet of paper, be sure to pull out the bypass tray extension.
7	Finisher*	This can be used to staple output. A punch module can also be installed to punch holes in output.
8	USB connector (A type)	Supports USB 2.0 (Hi-Speed).
		This is used to connect a USB device such as USB memory to the machine.
		For the USB cable, use a shielded cable.
9	Tray 1	This holds paper.
10	Tray 2 (when a paper feed tray is installed or	This holds paper.
	when the Stand/500&2000 sheet paper drawer	
	is installed)*	
11	Tray 3 (when a paper feed tray is installed or	This holds paper.
	when the Stand/500&2000 sheet paper drawer	
	is installed)*	
12	Tray 4 (when a paper feed tray is installed or	This holds paper.
	when the Stand/500&2000 sheet paper drawer	
	is installed)*	
13	Tray 5 (when a large capacity tray is installed)*	This holds paper.
14	Saddle stitch finisher*	This can be used to staple output. The saddle stitch function for folding and stapling output and the fold
		function for folding output in half are also available.
		A punch module can also be installed to punch holes in output.
15	Keyboard*	This is a keyboard that is incorporated into the machine. When not used, it can be stored under the
		operation panel.
16	Paper pass unit*	Transports paper to the finisher.

* Peripheral device.

A. Automatic document feeder and document glass



No.	Name	Function/Operation
1	Paper feed roller	This roller rotates to automatically feed the original.
2	Document feeding area cover	Open this cover to remove an original misfeed or clean the paper feed roller.
3	Original guides	These help ensure that the original is scanned correctly.
		Adjust the guides to the width of the original.
4	Document feeder tray	Place originals in this tray. 1-sided originals must be placed face up.
5	Original exit tray	Originals are delivered to this tray after scanning.
6	Scanning area	Originals placed in the document feeder tray are scanned here.
7	Original size detector	This detects the size of an original placed on the document glass.
8	Document glass	Use this to scan a book or other thick original that cannot be fed through the automatic document feeder.

2. Internal structure



No.	Name	Function/Operation	Note
1	Toner cartridges	These contain toner for printing. When the toner runs out in a cartridge, the cartridge of the color that ran	
		out must be replaced.	
2	Fusing unit	Heat is applied here to fuse the transferred image onto the paper.	Important The fusing unit is hot. Take care not to burn yourself when removing a paper misfeed.
3	Transfer belt	During full color printing, the toner images of each of the four colors on each of the photoconductive drums are combined together on the transfer belt. During black and white printing, only the black toner image is transferred onto the transfer belt.	Do not touch or damage the transfer belt. This may cause a defective image.
4	Right side cover	Open this cover to remove a misfeed.	
5	Paper reversing section cover	This is used when 2-sided printing is performed. Open this cover to remove a paper misfeed.	
6	Bypass tray	Use this tray to feed paper manually. When loading a large sheet of paper, be sure to pull out the bypass tray extension.	
7	Main power switch	This is used to power on the machine. When using the fax or Internet fax functions, keep this switch in the "on" position.	
8	Waste toner box	This collects excess toner that remains after printing.	
9	Waste toner box release lever	Move this lever when you need to release the waste toner box lock to replace the waste toner box or clean the laser unit.	
10	Handle	Pull this out and grasp it when moving the machine.	
11	Right cover of paper drawer (when a paper drawer is installed)	Open this to remove a paper misfeed in tray 2, tray 3 or tray 4.	
12	Paper tray right side cover	Open this to remove a paper misfeed in tray 1.	
13	Right side cover release lever	To remove a paper misfeed, pull and hold this lever up to open the right side cover.	

3. I/F connectors



When the fax expansion kit is installed



No.	Name	Function/Operation
1	USB connector (A type)	Supports USB 2.0 (Hi-Speed).
		This is used to connect a USB device such as USB memory to the machine.
2	USB connector (B type)	Supports USB 2.0 (Hi-Speed).
		A computer can be connected to this connector to use the machine as a printer.
		For the USB cable, use a shielded cable.
3	LAN connector	Connect the LAN cable to this connector when the machine is used on a network.
		For the LAN cable, use a shielded type cable.
4	Service-only connector	Important
		This connector is for use only by service technicians.
		Connecting a cable to this connector may cause the machine to malfunction.
		Important note for service technicians:
		The cable connected to the service connector must be less than 3 m (118") in length.
5	Power plug	
6	Extension phone socket	When the fax function of the machine is used, an extension phone can be connected to this socket.
7	Telephone line socket	When the fax function of the machine is used, the telephone line is connected to this socket.

4. Operation panel



No.	Name	Function/Operation
1	Touch panel	Messages and keys appear in the touch panel display.
		Touch the displayed keys to perform a variety of operations.
		When a key is touched, a beep sounds and the selected item is highlighted. This provides confirmation as you
		perform an operation.
2	Main power indicator	This lights up when the machine's main power switch is in the "on" position.
3	[POWER] key ()	Use this key to turn the machine power on and off.
4	[POWER SAVE] key (()) / indicator	Use this key to put the machine into auto power shut-off mode to save energy.
	0	The [POWER SAVE] key (③) blinks when the machine is in auto power shut-off mode.
5	[Home Screen] button	Touch this key to display the home screen.
		Frequently used settings can be registered in the home screen to enable quick and easy operation of the
		machine.

5. Sensors and detectors



Signal name	Name	Туре	Function/Operation	Note
1TUD_CL	Transfer mode detector (CL)	Transmission type	Detects separation of the transfer belt and the transfer mode. (Detection is made by combination of 1TUD_CL/1TUD_K signals.)	
1TUD_K	Transfer mode detector (BK)	Transmission type	Detects separation of the transfer belt and the transfer mode. (Detection is made by combination of 1TUD_CL/1TUD_K signals.)	
2TUD	Secondary transfer position detector	Transmission type	Detects the position (separation) of the secondary transfer unit.	
APPD1	ADU paper transport detector 1	Transmission type	Detects paper entry and paper pass in the ADU.	
APPD2	ADU paper transport detector 2	Transmission type	Detects paper pass in the ADU transport roller 8.	
BD	Laser beam detector	Pin diode	Detects laser beams (monitor.)	
CLUD1	Paper feed tray upper limit sensor (Paper feed tray 1)	Transmission type	Detects the upper limit of the paper lift up. (Paper feed tray 1)	
CPED1	Paper empty sensor (Paper feed tray 1)	Transmission type	Detects paper empty. (Paper feed tray 1)	
CPFD1	Paper transport detector (Paper feed tray 1)	Transmission type	Detects paper pass in the paper transport section of the paper feed tray 1.	
CSPD1	Paper remaining quantity sensor (Paper feed tray 1)	Transmission type	Detects the paper remaining quantity. (Paper feed tray 1)	
CSS11	Paper feed tray size detector (Paper feed tray 1)	Tact switch	Detects closing of the paper feed tray. (Paper feed tray 1)	

Signal name	Name	Туре	Function/Operation	Note
CSS11 - 14	Paper feed tray size detector	Tact switch	Detects the paper size.	36cpm machine
	(Paper feed tray 1)		Detects closing of the paper feed tray. (Paper feed tray 1)	only
DHPD_CL	OPC drum rotation sensor (CL)	Transmission type	Detects rotation and the phase of the OPC drum (CL).	
DHPD_K	OPC drum rotation sensor (BK)	Transmission type	Detects rotation and the phase of the OPC drum (BK).	
DSW_ADU	ADU paper guide open/close detector	Transmission type	Detects open/close of the ADU paper guide.	
DSW_C1	Transport cover open/close detector (Paper feed tray 1)	Transmission type	Detects open/close of the transport section cover. (Paper feed tray 1)	
HLPCD	Fusing pressure detector	Transmission type	Detects the fusing pressure state.	1
HPOS (SHPOS)	Shifter home positions sensor	Transmission type	Detects the shifter home position.	
HUD_M/TH_M	Temperature/humidity sensor	Thermistor	Detects the temperature and the humidity. (For the process	Analog
MHPS	Scanner home position sensor	Transmission type	Detects the scanner home position.	
MPED	Paper empty sensor (Manual paper feed tray)	Transmission type	Detects presence of paper. (Manual paper feed tray)	
MPLD	Paper length detector (Manual paper feed tray)	Transmission type	Detects the paper length. (Manual paper feed tray)	
MPWS	Paper width detector	Volume-type resistor	Detects the paper width. (Manual paper feed tray)	+
OCSW	Paper size detection trigger	Transmission type	Detects generation of the paper size detection trigger signal.	
	sensor			4
POD1	Paper exit detector 1	Transmission type	Detects paper transport from the fusing section.	<u> </u>
POD2	Paper exit detector 2	Transmission type	Detects paper transport to the face-down paper exit tray.	+
POD3	Paper exit detector 3	Transmission type	Detects paper transport to the right paper exit tray.	
PPD1	Paper transport detector 1	Transmission type	Detects paper pass in front of the transport roller 5.	
PPD2	Paper transport detector 2	Reflection type	Detects paper pass in the transport roller 5 in front of the registration roller.	
PRTPD	Paper exit tray paper detector (Right paper exit tray)	Transmission type	Detects paper empty in the paper exit tray (Right paper exit tray).	
REGS_F/IMGDS	Registration sensor F (Image density sensor)	Reflection type	Detects color shift. (F side) / Detects the toner patch density.	
REGS_R	Registration sensor R (Image density sensor)	Reflection type	Detects the toner patch density.	
SCOV	RSPF cover open/close detector	Micro switch	Detects open/close of the RSPF cover.	1
SOCD	RSPF open/close sensor	Transmission type	Detects open/close of the RSPF unit.	1
SPED	Document sensor	Transmission type	Detects document empty in the RSPF paper feed tray.	
SPLS1	Paper size detector 1	Transmission type	Detects the document length in the RSPF paper feed tray.	
SPLS2	Paper size detector 2	Transmission type	Detects the document length in the RSPF paper feed tray.	
SPPD1	Document transport sensor 1	Transmission type	Detects paper feed and the document size in random paper feed.	
SPPD2	Document transport sensor 2	Transmission type	Detects paper pass.	1
SPPD3	Document transport sensor 3	Transmission type	Detects paper pass.	
SPPD4	Document transport sensor 4	Transmission type	Detects paper exit and switchback.	
SPWS	Document size detector	Volume-type resistor	Detects the document width.	
TCS_C	Toner sensor (C)	Magnetic sensor	Detects toner supply from the toner cartridge. Detects the toner density (C).	Analog detection
TCS_K	Toner sensor (K)	Magnetic sensor	Detects toner supply from the toner cartridge.	Analog detection
TCS_M	Toner sensor (M)	Magnetic sensor	Detects toner supply from the toner cartridge.	Analog
TCS_Y	Toner sensor (Y)	Magnetic sensor	Detects the toner density (M).	Analog
TFD2	Paper exit tray full detector	Transmission type	Detects paper full in the center paper exit tray.	
TFD3	Paper exit tray full detector	Transmission type	Detects paper full in the right paper exit tray.	
TH_LM_IN	(Right paper exit tray) Fusing temperature sensor	Thermistor	Detects the surface temperature of the fusing roller (B).	Analog
TH_UM_IN	Fusing temperature sensor	Non-contact thermistor	Detects the surface temperature at the center of the fusing	detection Analog
TH_US_IN	(Main) Fusing temperature sensor (Sub)	Thermistor	belt (roller). Detects the suffered temperature at the edge section of the	detection Analog
			fusing belt (roller).	detection
TH1_LSU	LSU temperature sensor	I hermistor	Detects the temperature in the LSU. (For correction of the LSU distortion)	Analog detection
TNFD	Waste toner full detector	Mechanical switch	Detects full of waste toner.	1
WEBEND	Web end detector	Transmission type	Detects web end of the fusing unit.	

6. Switches



Signal name	Name	Туре	Function/Operation
DHSW	Dehumidifier heater switch	Seesaw switch	Turns ON/OFF the power line of the dehumidifier heater.
DSW_F	Front door open/close switch	Micro switch	Detects open/close of the front door. Detects ON/OFF of the power line of the fusing unit, the motors, and the LSU laser.
DSW_R	Right transport unit (right door) open/close switch	Micro switch	Detects open/close of the right paper transport section (right door). Detects ON/OFF of the power line of the fusing unit, the motors, and the LSU laser.
MSW	Main power switch	Seesaw switch	Turns ON/OFF the main power.
PWRSW	Operation panel power switch	Push switch	Turns ON/OFF the power on the secondary side.

7. Clutches and solenoids



Signal name	Name	Туре	Function/Operation
1TURC_1	Primary transfer separation clutch 1	Magnetic clutch	Controls separation of the primary transfer unit.
1TURC_2	Primary transfer separation clutch 2	Magnetic clutch	Controls separation of the primary transfer unit.
2TURC	Secondary transfer separation clutch	Magnetic clutch	Controls separation of the secondary transfer unit.
CPFC1	Tray vertical transport clutch 1	Magnetic clutch	Controls the transport roller of the paper feed tray 1 section.
CPUC1	Paper feed clutch (Paper feed tray 1)	Magnetic clutch	Controls ON/OFF of the paper feed roller in the paper feed tray 1 section.
			(Paper feed tray 1)
MPFS	Paper feed solenoid (Manual paper feed)	Magnetic solenoid	Controls the paper feed roller. (Manual paper feed)
PFC_HPFC	Transport roller clutch	Magnetic clutch	Controls the transport roller 4.
SPRS	Paper exit roller pressure control solenoid	Magnetic solenoid	Controls ON/OFF of the transport power of the paper exit roller. (Releases the
	(RSPF)		paper exit roller pressure when reversing paper.)
SRRC	Registration roller clutch (RSPF)	Magnetic clutch	Controls the registration roller. (Controls the timing of document transport.)
STMPS	Stamp solenoid	Magnetic solenoid	Drives the finish stamp.
WEBS	Web drive solenoid	Magnetic solenoid	Drives the web.



Signal name	Name	Туре	Function/Operation
ADUM	ADU motor	Stepping motor	Drives the ADU and the transport roller in the right paper exit section.
BTM	Transfer belt drive motor	DC brushless motor	Drives the transfer belt. (For 36 cpm machine)
CLUM1	Paper tray lift motor (Paper feed tray 1)	DC brush motor	Lifts the lift plate of the paper feed tray. (Paper feed tray 1)
CPFM	Paper feed motor	DC brushless motor	Drives the paper feed section.
DVM_CL	Developing motor (CL)	DC brushless motor	Drives the developing/OPC drum section (CL).
DVM_K	Developing motor (K)	DC brushless motor	Drives the developing/black OPC drum (BK)/transfer section.
FUM	Fusing motor	DC brushless motor	Drives the fusing section.
MIM	Scan motor	Stepping motor	Drives the scanner unit. (scan, return operations)
OSM*	Offset motor	Stepping motor	Offsets (shifts) paper.
PFM	Transport motor	Stepping motor	Drives the transport rollers 5 and 9.
PGM	Polygon motor	DC brushless motor	Scans laser beams.
POM	Paper exit motor	Stepping motor	Drives the roller in the paper exit section.
PRM	Fusing pressure control motor	Stepping motor	Controls ON/OFF of the fusing roller pressure.
RRM	Registration motor	Stepping motor	Drives the registration roller.
			(Controls the timing of the transfer image for the paper.)
SPFM	RSPF transport motor	Stepping motor	Transports a document.
SPM/SPUM	RSPF paper feed motor	Stepping motor	Feeds a document.
TNM_C	Toner motor (C)	Stepping motor	Supplies toner from the toner cartridge (C) to the developing unit.
TNM_K	Toner motor (K)	Stepping motor	Supplies toner from the toner cartridge (K) to the developing unit.
TNM_M	Toner motor (M)	Stepping motor	Supplies toner from the toner cartridge (M) to the developing unit.
TNM_Y	Toner motor (Y)	Stepping motor	Supplies toner from the toner cartridge (Y) to the developing unit.

9. Rollers



No.	Name	Function/Operation		
1	Transport roller 1 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to		
		paper.		
2	Transport roller 1 (Drive)	Transports paper fed from the paper feed desk tray to the transport roller 4.		
3	Paper pickup roller (No. 1 paper feed tray)	Feeds paper to the paper feed roller.		
4	Separation roller (No. 1 paper feed tray)	Separates paper to prevent double-feeding.		
5	Paper feed roller (No. 1 paper feed tray)	Feeds paper to the paper transport section.		
6	Transport roller 2 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to		
		paper.		
7	Transport roller 2 (Drive)	Transports paper fed from the paper feed tray 1 to the transport roller 3.		
8	Transport roller 3	Transports paper from the transport roller 2 to the transport roller 4.		
9	Paper feed roller (Manual paper feed tray)	Feeds paper to the paper transport section.		
10	Separation roller (Manual paper feed tray)	Separates paper to prevent double-feeding.		
11	Transport roller 4 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to		
		paper.		
No.	Name	Function/Operation		
-----	------------------------------------	--	--	--
12	Transport roller 4 (Drive)	Transports paper from the transport rollers 1 and 3 to the transport roller 5.		
13	Transport roller 5 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.		
14	Transport roller 5 (Drive)	Transports paper to the registration roller. Paper is buckled between the registration roller and this roller to correct the paper skew and the relation between images and paper.		
15	Registration roller (Drive)	Transports paper to the transfer section. / Controls the transport timing of paper and adjusts relative relations between the image and paper		
16	Registration roller (Idle)	Apply a pressure to paper and the registration roller to provide the transport power of the transport roller to paper.		
17	Transport roller 6 (Drive)	Transports paper transported from the fusing section to the paper exit section and the switchback section.		
18	Transport roller 6 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.		
19	Transport roller 7 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.		
20	Transport roller 7 (Drive)	Transports paper transported from the switchback section to the transport roller 8.		
21	Transport roller 8 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.		
22	Transport roller 8 (Drive)	Transports paper transported from the transport roller 7 to the transport roller 9.		
23	Transport roller 9 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.		
24	Transport roller 9 (Drive)	Transports paper transported from the transport roller 8 to the transport roller 5.		
25	Paper exit roller 1 (Idle)	Apply a pressure to paper and the paper exit roller to provide the transport power of the paper exit roller to paper.		
26	Paper exit roller 1 (Drive)	Transports paper to the left paper exit section.		
27	Paper exit roller 2 (Idle)	Apply a pressure to paper and the paper exit roller to provide the transport power of the paper exit roller to paper.		
28	Paper exit roller 2 (Drive)	Discharges paper to the right paper exit tray.		
29	Fusing roller (F1)	Heats the fusing belt.		
30	Fusing roller (F2)	The cushion layer of the roller forms a wide nip between the fusing belt and fusing roller (B).		
31	Fusing roller (B)	Heats the back surface of paper to fuse toner on the paper.		
32	Fusing web roller	Cleans the fusing roller (B) and the fusing belt.		
33	Document pickup roller (RSPF)	Feeds a document to the paper feed roller.		
34	Paper feed roller (RSPF)	Feeds a document to the transport section. Makes a buckle on paper between the registration roller and this roller to correct the start position of document skew and document image scan.		
35	Separation roller (RSPF)	Separates a document to prevent double-feeding.		
36	Transport auxiliary roller (RSPF)	Reduces friction between a document and the paper guide to transport the document smoothly to the registration roller.		
37	Registration roller (Drive) (RSPF)	Transports a document to the transport roller 2. / Controls the transport timing of the document and adjusts the document scanning timing.		
38	Registration roller (Idle) RSPF)	Apply a pressure to a document and the registration roller to provide the transport power of the transport roller to the document.		
39	Transport roller 2 (Idle) (RSPF)	Apply a pressure to a document and the transport roller to provide the transport power of the transport roller to the document.		
40	Transport roller 2 (Drive) (RSPF)	Transports a document transported from the registration roller to the document scanning section.		
41	Transport roller 3 (Idle) (RSPF)	Apply a pressure to a document and the transport roller to provide the transport power of the transport roller to the document.		
42	Transport roller 3 (Drive) (RSPF)	Transports a document transported from the document scanning section to the paper exit roller.		
43	Paper exit roller (Idle) (RSPF)	Apply a pressure to a document and the paper exit roller to provide the transport power of the paper exit roller to the document.		
44	Paper exit roller (Drive) (RSPF)	Discharges a document. Switchbacks the document and transports it to the registration roller when scanning the back surface.		
45	Transport roller 10 (Drive)	Transports paper from manual paper feed section to the transport roller 9.		
46	Transport roller 10 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.		
47	Paper exit roller 3 (Drive)	Transports paper to paper exit roller 2 or transport roller 7.		
48	Paper exit roller 3 (Idle)	Apply a pressure to paper and the paper exit roller to provide the transport power of the paper exit roller to paper.		



Signal name	Name	Туре	Function/Operation
CCFT	LCD backlight	LED	LCD backlight
CL_ON	Scanner lamp	LED	Radiates light onto a document for the CCD to scan the document image.
DL_BK	Discharge lamp (K)	LED	Discharges electric charges on the OPC drum (K).
DL_C	Discharge lamp (C)	LED	Discharges electric charges on the OPC drum (C).
DL_M	Discharge lamp (M)	LED	Discharges electric charges on the OPC drum (M).
DL_Y	Discharge lamp (Y)	LED	Discharges electric charges on the OPC drum (Y).
HL_LM	Heater lamp (HL_LM)	Halogen lamp	Heats the fusing roller (B).
HL_UM/US	Heater lamp (HL_UM/US)	Halogen lamp	Heats the fusing roller (F1) and the fusing belt.

11. Fans and filter



Signal name	Name	Function/Operation		
FUFM	Fusing cooling fan	Cools the fusing section and the paper exit section.		
POFM	Paper exit cooling fan	cools the fusing section and the paper exit section.		
POFM2	Paper exit cooling fan	Cools the fusing section and the paper exit section.		
PROFM	Process fan motor 1	Discharges air and cools the process section.		
PROFM2	Process fan motor 2	Discharges air and cools the process section.		
PSFM	Power cooling fan motor	Cools the power unit.		
LSUFM	LSU cooling fan	Cools the LSU.		

No.	Name	Function/Operation	
1	Toner filter	Prevents toner splash.	
2	Ozone filter	Absorbs ozone generated in the image process section.	



Signal name	Name Function/Operation			
DHS	Scanner dehumidifying heater	Dehumidifies the scanner section to prevent it from dew condensation.		
DHT1	Paper dehumidifying heater (Paper feed tray 1)	Dehumidifies the paper feed tray section to prevent paper from absorbing humidity which causes degraded image quality and paper jams.		

13. PWB/Memory device



No.	Name	Function/Operation
1	MFP control PWB	Controls image data (compression, decompression, and filing), and controls the whole machine.
		Converts print data (PCL/PS) into image data.
2	Right door PWB	Interfaces the right door unit signal.
3	PCU PWB	Controls the engine section.
4	SCU PWB	Controls the scanner and the operation section.
5	Scanner lamp drive PWB	Drives the scanner lamp
6	CCD PWB	Scans document images and performs A/D conversion of the scanning signal.
7	USB I/F PWB	USB I/F
8	HW-KEY PWB	Outputs the key operation signal.
9	PW-KEY PWB	Turns ON/OFF the power on the secondary side.
10	LVDS PWB	Converts the display data signal to the LCD display signal. Controls the touch panel.
11	USB CONV PWB	Converts to the USB connection.
12	Wireless LAN PWB	Connects the network with the wireless LAN.
13	LD PWB	Drives the laser diode and controls the power.
14	LSU mother PWB	Controls the LSU. Generates the video data. Interfaces the MFP PWB, the scanner control PWB, the
		operation PWB, the PCU PWB, and the FAX unit.
15	Driver PWB	Drives the motor.
16	HL control PWB	Drives the heater lamp.
17	DC POWER PWB	Generates the DC voltage.
18	High voltage PWB (MC/DV PWB)	Generates the main charger voltage and the DV bias voltage.
19	High voltage PWB (TC PWB)	Generates the transfer voltage.
20	AC POWER PWB	Generates the AC voltage.
21	Document size detection PWB (Light emitting)	Drives the LED for the document size detection.
22	Document size detection PWB (Light receiving)	Outputs the document size detection signal.
23	RSPF driver PWB	Drives the motor, the solenoid, and the clutch in the RSPF section.
24	SD card memory	Stores the MFP PWB program data, the FAX image data, and the font data.
25	DIMM memory	Memory for the printer
26	Compact Flash memory	Stores the printer program data.
27	CF Card	Stores the DSK program data.
28	HDD	Stores the MFP PWB program data, the filing data, the e-manual data, the watermark data, the log data,
		and the authentication data. Also used as a work memory.



Signal name	Name	Туре	Section
F1	Fuse	8.0A(215) AC 250V	AC Power PWB
F2	Fuse	3.15A(215) AC 250V	AC Power PWB
F151	Fuse	6.3A(218) AC 250V	AC Power PWB
F152	Fuse	6.3A(218) AC 250V	AC Power PWB
F153	Fuse	6.3A(218) AC 250V	AC Power PWB
F154	Fuse	4.0A(218) AC 250V	AC Power PWB
F155	Fuse	6.3A(218) AC 250V	AC Power PWB

Signal name	Name	Туре	Function/Operation
TS LM	Thermostat LM	Mechanical thermostat	Shuts down the heater lamp (HL_LM) circuit when the fusing section is overheated.
TS UM	Thermostat UM	Mechanical thermostat	Shuts down the heater lamp (HL_UM) circuit when the fusing section is overheated. (Center section)
TS US	Thermostat US	Mechanical thermostat	Shuts down the heater lamp (HL_US) circuit when the fusing section is overheated. (Edge section)

[5] ADJUSTMENTS AND SETTINGS

1. General

Each adjustment item in the adjustment item list is associated with a specific Job number. Perform the adjustment procedur es in the sequence of Job numbers from the smallest to the greatest.

However, there is no need to perform all the adjustment items. Perform only the necessary adjustments according to the need.

Unnecessary adjustments can be omitted. Even in this case, however, the sequence from the smallest to the gr eatest Job number must be observed.

If the above precaution should be neglected, the adjustment would not complete normally or trouble may occur.

2. Adjustment item list

Job No.	Adjustment item list S				Simulation	
ADJ 1	Adjust the developing unit	1A	Adjust the developing doctor gap)		
		1B	Adjust the developing roller main	n pole p	osition	
		1C	Toner density control reference v	alue se	etting	25-2
ADJ 2	Adjusting high voltage values	2A	Adjust the main charger grid volt	age		8-2
		2B	Adjust the developing bias voltage	je		8-1
		2C	Transfer current and voltage adju	ustmen	t	8-6
ADJ 3	Image density sensor adjustment	3A	Image density sensor adjustmen	Image density sensor adjustment		
ADJ 4	Image lead edge position, image	4A	Print image main scanning direct	tion aut	omatic magnification ratio adjustment (Print engine)	50-28
	loss, void area, image off-center,	4B	Print image off-center automatic	adjustr	nent (Print engine) (Each paper feed tray)	50-28
	image magnification ratio	4C	Copy mode image lead edge pos	sition, i	mage loss, void area, image off-center, sub	50-28
	adjustment		scanning direction image magnif	ication	ratio automatic adjustment (Scanner)	
	(Automatic adjustment)		(Document table mode)			
		4D	Copy mode image lead edge pos	sition, i	mage loss, void area, image off-center, sub	50-28
	Drint anning impage distantion	_ ^	scanning direction image magnif	ication	ratio automatic adjustment (Scanner) (RSPF mode)	50.00
ADJ 5	Print engine image distortion	5A	Print engine image distortion adj	ustmer	It (Manual adjustment) / OPC drum phase	50-22
	adjustment / Color registration	۶D	Brint angina imaga akow (LSL)		Nuetmont (Manuel adjustment)	50 20 (64 1)
	adjustment (Print engine section)	ЪD	(No need to adjust normally)	kew) at	justnent (Manual aujustnent)	50-20 (04-1)
		50	Color registration offset adjustme	nt (No	need to adjust normally)	50-20
	Scan image distortion	64	Scapper (reading) unit parallelist	n adius	tment	00 20
7.000	adjustment	6R	Scan image (sub scanning direct	tion) die	stortion adjustment	
	(Document table mode)	60	Scan image (main scanning direc	ction) c	listortion adjustment	
AD.I.7	Scanner image skew adjustment (ew adjustment (RSPF mode)				64-2
AD.1.8	Control mage skew adjustment (FOFF mode)					48-1
AD.1.9	Print lead edge image position adju	rint lead edge image position adjustment (Printer mode)				50-5
ADJ 10/	Color balance and density		Note before execution of the ima	ide dua	lity adjustment	000
SET1	adjustment		Copy image quality check	90 940		
	,		Printer image quality check			
		10A	Scanner calibration (CCD calibra	ation)		63-3 (63-5)
		SET	Color balance adjustment	1A	Copy color balance adjustment target setup	63-7/8/11
		1	target setup	1B	Printer color balance adjustment target setup	67-26/27/28
		10B	Copy/Printer color balance and c	lensity	adjustment (Automatic adjustment)	46-74
			(Basic adjustment)			
		10C	Copy image quality adjustment	10C	Copy color balance and density adjustment	46-24
			(Basic adjustment)	(1)	(Automatic adjustment)	
				10C	Copy color balance and density adjustment	46-21
				(2)	(Manual adjustment)	
		10D	Copy / Image send / FAX	10D	Color copy density adjustment (for each color	46-1
			image quality adjustment	(1)	copy mode) (separately for the low-density area	
			(Individual adjustment)		(No pood to adjust permelly)	
				100	(No field to adjust fiormally)	46.2
				(2)	monochrome copy mode) (separately for the low-	40-2
				(2)	density area and the high-density area)	
					(No need to adjust normally)	
				10D	Color copy color balance, gamma adjustment	46-10
				(3)	(for each color copy mode)	
					(No need to adjust normally)	
				10D	Monochrome copy density, gamma adjustment	46-16
				(4)	(for each monochrome copy mode)	
				L	(No need to adjust normally)	
				10D	Automatic monochrome (Copy/Scan/FAX) mode	46-19
				(5)	document density scanning operation (exposure	
					operation) conditions setting	

Job No.	Adjustment item list S				Simulation	
ADJ 10/	Color balance and density	10D	Copy / Image send / FAX	10D	Document low density image density reproduction	46-32
SET1	adjustment		image quality adjustment	(6)	adjustment in the automatic monochrome (Copy/	
			(Individual adjustment)		Scan/FAX) mode (No need to adjust normally)	
					(Background density adjustment in the scanning	
					section)	
				10D	Copy/Scan low density image density adjustment	46-63
				(7)	(for each mode) (No need to adjust normally)	46.27
				(8)	adjustment (edge gamma, density adjustment)	40-27
				(0)	(Text_Map mode) (No need to adjust normally)	
				10D	Monochrome (Copy/Scan/FAX) mode color	46-37
				(9)	document reproduction adjustment	
				. ,	(No need to adjust normally)	
				10D	Color copy mode dark area gradation (black	46-38
				(10)	component quantity) adjustment	
					(No need to adjust normally)	
				10D	Color (Copy/Scan) mode sharpness adjustment	46-60
				(11)	(No need to adjust normally)	
				10D	Copy high density image density reproduction	46-23
				(12)	setting	
					(Normally unnecessary to the setting change)	
				10D	Copy color balance adjustment (Single color copy	46-25
				(13)	mode)	
				400	(No need to adjust normally)	10.0
				10D	RSPF mode (Copy/Scan/FAX) density adjustment	46-9
				(14)	(No need to adjust normally	00.50
				10D	Automatic color balance adjustment by the user	26-53
				(15)	(Copy color balance automatic adjustment ENABLE softing and adjustment)	
				100	Convigamma, color balance adjustment for each	46.54
				(16)	dither	40-54
				(10)	(Automatic adjustment)	
				10D	Dropout color adjustment (Normally not required)	46-55
				(17)		10 00
				10D	Watermark adjustment (Normally not required)	46-66
				(18)		
		10E	Printer image quality	10E	Printer color balance adjustment	67-24
			adjustment (Basic adjustment)	(1)	(Automatic adjustment)	
				10E	Printer color balance adjustment	67-25
				(2)	(Manual adjustment)	
		10F	Printer image quality	10F	Printer density adjustment (Low density section	67-36
			adjustment	(1)	density adjustment) (No need to adjust normally)	
			(Individual adjustment)	10F	Printer high density image density reproduction	67-34
				(2)	setting (Supporting the high density section tone	
				105	gap) (No need to adjust normally)	07.54
				10F	Automatic adjustment for each dither	67-54
				(3)	normally)	
				10F	Automatic color balance adjustment by the user	26-53
				(4)	(Printer color balance automatic adjustment	20 00
				· , ,	ENABLE setting and adjustment)	
					(Normally unnecessary to the setting change)	
ADJ 11	Paper size sensor adjustment	11A	Manual paper feed tray paper size	ze (widt	h) sensor adjustment	40-2
		11B	RSPF paper feed tray document	size (v	vidth) sensor adjustment	53-6
ADJ 12	Document size detection	12A	Document size sensor detection	point a	djustment	41-1
	adjustment	12B	Adjust the sensitivity of the origin	nal size	sensor	41-2
ADJ 13	Touch panel coordinate setting					65-1
ADJ 14	Fusing paper guide position adjust	tment				
ADJ 15	Print image position, image	15A	Print image magnification ratio a	djustme	ent (main scanning direction) (Print engine)	50-10
	magnification ratio, void area,	455	(ivianuai adjustment)		· · · · · · · · · · · · · · · · · · ·	50.40/50//
	engine) (Manual adjustment)	15B	Print image print area adjustmer	it (Print	engine) (Manual adjustment)	50-10/50/1
		15C	Print image off-center adjustmen	nt (Print	engine) (Manual adjustment)	50-10
ADJ 16	Scan image magnification ratio	16A	Scan image magnification ratio a	aajustm	ent (main scanning direction) (Manual adjustment)	48-1
	aujustinent (Manuai aujustinent)	16R	Scan image magnification ratio	adiustm	ent (sub scanning direction) (Manual adjustment)	48-1/48-5
		.00	(Document table mode)	ະພາດອາດ		10 1/40-0
		16C	Scan image magnification ratio	adjustm	ent (main scanning direction) (Manual adjustment)	48-1
			(RSPF mode)	.,		
		16D	Scan image magnification ratio a	adjustm	ent (sub scanning direction) (Manual adjustment)	48-1
			(RSPF mode)		- ,	
ADJ 17	Scan image off-center	17A	Scan image off-center adjustment	nt (Man	ual adjustment) (Document table mode)	50-12
1	adjustment (Manual adjustment)	17B	Scan image off-center adjustment	nt (Man	ual adjustment) (RSPF mode)	50-12/50-6

Job No.	Adjustment item list S			
ADJ 18	Copy image position, image loss	Copy image position, image loss 18A Copy image position, image loss, void area adjustment (Manual adjustment)		
	adjustment (Manual adjustment)	(Document table mode)		
		18B	8B Image scanning position adjustment (Manual adjustment) (RSPF mode)	
		18C	Copy image position, image loss, void area adjustment (Manual adjustment) (RSPF mode)	50-6
ADJ 19	Finisher and punch unit adjustments (alignment, punch hole position, staple position)			

3. Details of adjustment

ADJ 1 Adjust the developing unit

1-A Adjust the developing doctor gap

This adjustment must be performed in the following cases:

- * The developing unit has been disassembled.
- * When the print image density is low.
- * When there is a blur on the print image.
- * When there is unevenness in the print image density.
- * The toner is excessively dispersed.

Important

Be careful not to attach a fingerprint, oil, grease, or a foreign material on the DV roller during the procedure. Also be careful not to scratch the DV roller surface.

If a fingerprint, oil, grease, or a foreign material is erroneously attached to the DV roller during the procedure, remove all developer from the developing unit and clean the roller with alcohol.

Important

Do not exert force when holding the DV Unit.

1) Remove the developing unit from the main unit, and remove the developing doctor cover.



2) Loosen the developing doctor fixing screw.



3) Insert a thickness gauge of 0.65mm in between 40mm - 70mm from the edge of the developing doctor.

Important

Note for use of a thickness gauge

- Do not insert the gauge diagonally.
- The gauge must pass freely.
- The advisable point of measurement is the MIN point of the DV roller oscillation.



 Push the developing doctor in the arrow direction, and tighten the fixing screw of the developing doctor. (Perform the similar procedure for the front frame and the rear frame.)



5) Check that the doctor gaps at two positions in 40mm - 70mm from the both sides of the developing doctor are in the range of 0.65 ± 0.05 mm.



1-B Adjust the developing roller main pole position

This adjustment must be performed in the following cases:

- * The developing unit has been disassembled.
- * When the print image density is low.
- * When there is a blur on the print image.
- * When there is unevenness in the print image density.
- * The toner is excessively dispersed.

Important

Be careful not to leave a fingerprint, oil, grease, or a foreign material on the DV roller during the procedure. Also be careful not to scratch the DV roller surface.

If a fingerprint, oil, grease, or a foreign material is erroneously attached to the DV roller during the procedure, remove all developer from the developing unit and clean the roller with alcohol.



Do not exert force when holding the DV Unit.

- 1) Remove the developing doctor cover, and place the developing unit on a flat surface.
- 2) Attach a piece of string to a sewing needle or pin.
- Hold the thread and bring the ne edle near the developing roller. (Do not use a paper clip because too heavy. It will not provide a correct position.)
- Mark the developing roller surface on the extension line of the needle with the needle at 2 - 3mm fr om the developing roller edge. (Never touch the needle tip to the developing roller.)

Important

Marking must be made at the edge section (non-image area) of the DV roller.



5) Measure the distance between the marking position and the DV doctor edge A position, and confirm that the distance is 20.0 ± 0.5 mm.

If the distance is not within the above r ange, adjust the D V roller main pole position in the following procedures.



 Remove the developing unit rear cover, loosen the fixing screw of the DV r oller main pole adjustment plate, and move the adjustment plate in the arrow direction to adjust.



Repeat procedures 3) - 6) until the DV roller main pole position comes to the specified range.

 After completion of the adjustment of the DV ro ller main pole position, fix the DV roller main pole adjustment plate with the fixing screw.

1-C Toner density control reference value setting

This adjustment must be performed in the following cases:

* When developer is replaced.

Important

Be sure to execute this adjustment only when developer is replaced. Never execute it in the other cases.

Important

Perform the toner density reference control level adjustment with the toner cartridges removed.

If adjustment is performed with toner cartridges installed, the EE-EL trouble code or an over-toned condition may occur.

1) With the front cabinet open, enter SIM25-2.



- 2) Close the front cabinet.
- 3) Select a developing unit to be adjusted.
- When [EXECUTE] key is pressed, it is highlighted. The DV roller rotates, and the toner density sensor detects toner density, and the output value is displayed.

The above operation is executed for 1.5 minutes, and the average value of the toner density sensor detection level is set (saved) as the reference toner density control value.

When the reference toner density control adjustment operation is completed, [EXECUTE] key returns to normal from highlight. This makes known about whether the adjustment operation is completed or not.

The above operation is executed each of the lower speed mode and the middle speed mode, and the re ference toner density control value is set for each of them.

Important

If the operation is interrupted within 1.5 minutes, the adjustment result is not reflected.

When [EXECUTE] key is pressed during the operation, the operation is stopped and [EXECUTE] key returns to the normal display.

If [EE-EU], [EE-EL], or [EE-EC] is displayed, setting of the reference toner density control value is not completed normally.

Troubleshoot the cause, remove the cause, and perform setting again.

Error display	Error name	Detail of error
EE-EL	EL abnormality	Sensor output level less than 1.0V, or control
		voltage over 8.0V.
EE-EU	EU abnormality	Sensor output level over 2.3V, or control
		voltage less than 2.0V.
EE-EC	EC abnormality	Sensor output level: other than $1.65\pm0.13V$

- 5) Cancel SIM 25-2.
- 6) Confirm that "Install the toner cartridge" is displayed, and install the toner cartridge by the following procedures.
- 7) Shake the toner cartridge horizontally several times.



8) Open the front cabinet, and insert each toner cartridge.





Be sure to install the color cartridges to their proper positions. Avoid installation to a different color position.



Do not forcibly insert the toner cartridge. Push it in until the cartridge is securely locked in place.

Important

Developing units removed, be sure to remove the toner cartridges as well to prevent toner clogging.

Color toner cartridge positions



- 9) Close the front cabinet.
- 10) Confirm that "Toner replenishment in progress" is displayed, and wait until the display disappears. (It takes 30 sec - 6 min.)

Note

This procedure is for checking the toner supply operation from the toner cartridge to the D V unit. The operation time differs depending on the toner quantity in the toner cartridge, uneven distribution of toner, and the interna I state of the toner cartridge.

Important

Do not perform operations which interrupt the above operation, such as opening the front cover, entering the SIM mode, and turning OFF/ON the power. If this precaution is ignored, Trouble codes F2-40 - 43 or F2-64 - 67 or a over-toned condition may occur.

Important

When replacing developer, always replace all the three color s of Yellow, Magenta, and Cyan.

If only one color is replaced, color balance may be adversely affected. Black developer can be replaced individually.

Important

When developer is replaced, be sure to p erform the color balance adjustment.

Important

When not replacing the developer, do not execute SIM25-2.

ADJ 2 Adjusting high voltage values

2-A Adjust the main charger grid voltage

This adjustment must be performed in the following cases:

- $^{\ast}\,$ When the MC/DV high voltage power PWB is replaced.
- * U2 trouble has occurred.
- * The PCU PWB has been replaced.
- * The EEPROM of the PCU PWB has been replaced.
- 1) Enter the SIM 8-2 mode.



2) Select an output mode and an item to be adjusted.

Item/Display (Mode)						Actual	voltage
			Content		Adjustment range	26cpm/31 cpm machine	36cpm machine
MIDDLE	Α	MIDDLE SPEED GB_K	Main charger grid voltage (Middle speed mode)	К	150 - 850	-620V±5V	-625V±5V
	В	MIDDLE SPEED GB_C	Main charger grid voltage (Middle speed mode)	С	150 - 850	-620V±5V	-625V±5V
	С	MIDDLE SPEED GB_M	Main charger grid voltage (Middle speed mode)	Μ	150 - 850	-620V±5V	-625V±5V
	D	MIDDLE SPEED GB_Y	Main charger grid voltage (Middle speed mode)	Y	150 - 850	-620V±5V	-625V±5V
LOW	Α	LOW SPEED GB_K	Main charger grid voltage (Low speed mode)	К	150 - 850	-610V±5V	-610V±5V
	В	LOW SPEED GB_C	Main charger grid voltage (Low speed mode)	С	150 - 850	-590V±5V	-590V±5V
	С	LOW SPEED GB_M	Main charger grid voltage (Low speed mode)	Μ	150 - 850	-590V±5V	-590V±5V
	D	LOW SPEED GB_Y	Main charger grid voltage (Low speed mode)	Y	150 - 850	-590V±5V	-590V±5V

3) Enter the adjustment value (specified value) in the middle speed mode, and press [OK] key.

Enter the adjustment value of each mode which is specified on the label attached on the MC/DV high voltage power PWB.

GBK:XXX GBC:XXX GBM:XXX GBY:XXX

The default values specified for each model must be changed as follows.

26cpm/31cpm machine: +5 36cpm machine: +10



When [EXECUTE] key is pressed, the voltage entered in the procedure 3) is outputted for 30sec and the set value is saved.

When [EXECUTE] key is pressed again, the output is stopped.

Important

Note that the adjustment value may differ depending on the MC/DV high voltage power PWB.

Since the adjustment value label is attached on the MC/DV high voltage PWB, the PWB must be r emoved in order to check the adjustment value.

This is a troublesome procedure. Therefore, it is advisable to put down the adjustment value in advance.

When the adjustment value (specified value) of the midd le speed mode is set, the adjustment values of the othe r modes are auto - matically set according to the middle speed mode setting in a cer-tain relationship.



Since the high voltage output cannot be checked with a digital multi meter in this model, a judgmen t of the output must be made by checking the print image quality.

2-B Adjust the developing bias voltage

This adjustment must be performed in the following cases:

- * When the MC/DV high voltage power PWB is replaced.
- * U2 trouble has occurred.
- * The PCU PWB has been replaced.
- * The EEPROM of the PCU PWB has been replaced.
- 1) Enter the SIM 8-1 mode.



2) Select an output mode and an item to be adjusted.

ltem/Di	spla	y (Mode)	Content		Adjustment range	Actual voltage
MIDDLE	A	MIDDLE SPEED DVB_K	Developing bias voltage (Middle speed mode)	к	0 - 600	–450V ±5∨
	В	MIDDLE SPEED DVB_C	Developing bias voltage (Middle speed mode)	С	0 - 600	-450V ±5V
	С	MIDDLE SPEED DVB_M	Developing bias voltage (Middle speed mode)	М	0 - 600	–450V ±5V
	D	MIDDLE SPEED DVB_Y	Developing bias voltage (Middle speed mode)	Y	0 - 600	–450V ±5∨

ltem/Di	Item/Display (Mode)		Content		Adjustment range	Actual voltage
LOW	A	LOW SPEED DVB_K	Developing bias voltage (Low speed mode)	к	0 - 600	-450V ±5V
	В	LOW SPEED DVB_C	Developing bias voltage (Low speed mode)	С	0 - 600	–430V ±5V
	С	LOW SPEED DVB_M	Developing bias voltage (Low speed mode)	М	0 - 600	–430V ±5V
	D	LOW SPEED DVB_Y	Developing bias voltage (Low speed mode)	Y	0 - 600	-430V ±5V

 Enter the adjustment value (specified value) in the middle speed mode, and press [OK] key.

Enter the adjustment value of each mode which is specified on the label attached on the MC/DV high voltage power PWB.



When [EXECUTE] key is pressed, the voltage entered in the procedure 3) is outputted for 30sec and the set value is saved. When [EXECUTE] key is pressed again, the output is stopped.

Important

Note that the adjustment value may differ depending on the MC/DV high voltage power PWB.

Since the adjustment value label is attached on the MC/DV high voltage PWB, the PWB must be r emoved in order to check the adjustment value.

This is a troublesome procedure. Therefore, it is advisable to put down the adjustment value in advance.

When the adjustment value (specified value) of the midd le speed mode is set, the adjustment values of the othe r modes are auto-matically set according to the middle speed mode setting in a certain relationship.



Since the high voltage output cannot be checked with a digital multi meter in this model, a judgmen t of the output must be made by checking the print image quality.

2-C Transfer current and voltage adjustment

This adjustment must be performed in the following cases:

- * When the TC high voltage PWB is replaced.
- * U2 trouble has occurred.
- * The PCU PWB has been replaced.
- * The EEPROM of the PCU PWB has been replaced.
- 1) Enter the SIM 8-6 mode.



2) Select an item to be adjusted.

	Item/Display		Content			Setting range	Default value	Actual output value
Α	TC1 LOW SPEED CL K	Primary transfer	Color	K	Low speed	51 - 255	80	6μΑ
В	TC1 MIDDLE SPEED CL K	bias adjustment			Middle speed	51 - 255	109	10µA
С	TC1 LOW SPEED CL C	value		С	Low speed	51 - 255	80	6μΑ
D	TC1 MIDDLE SPEED CL C				Middle speed	51 - 255	109	10µA
Е	TC1 LOW SPEED CL M			М	Low speed	51 - 255	80	6μΑ
F	TC1 MIDDLE SPEED CL				Middle speed	51 - 255	109	10µA
	Μ							
G	TC1 LOW SPEED CL Y			Y	Low speed	51 - 255	80	6μΑ
Н	TC1 MIDDLE SPEED CL Y				Middle speed	51 - 255	109	10μΑ
1	TC1 LOW SPEED BW K		Black/White	K	Low speed	51 - 255	80	6μΑ
J	TC1 MIDDLE SPEED BW				Middle speed	51 - 255	109	10µA
	к							
K	TC2 PLAIN CL SPX	Secondary transfer	Color	Standard	Front surface	51 - 255	103	–40μA
L	TC2 PLAIN CL DPX	bias adjustment		paper	Back surface	51 - 255	90	–30μA
М	TC2 PLAIN BW SPX	value	Black/White		Front surface	51 - 255	103	–40μA
Ν	TC2 PLAIN BW DPX				Back surface	51 - 255	90	–30μA
0	TC2 HEAVY1 CL SPX		Color	Heavy	Front surface	51 - 255	83	–25µA
Р	TC2 HEAVY1 CL DPX			paper 1	Back surface	51 - 255	76	–20µA
Q	TC2 HEAVY1 BW SPX		Black/White		Front surface	51 - 255	69	–15μA
R	TC2 HEAVY1 BW DPX				Back surface	51 - 255	69	–15μA
S	TC2 HEAVY2 CL		Color	Heav	/y paper 2	51 - 255	83	–25µA
Т	TC2 HEAVY2 BW		Black/White			51 - 255	69	–15μA
U	TC2 OHP CL		Color		OHP	51 - 255	69	–15μA
V	TC2 OHP BW		Black/White			51 - 255	69	–15μA
W	TC2 ENVELOPE CL		Color	Er	ivelope	51 - 255	69	–15μA
Х	TC2 ENVELOPE BW		Black/White			51 - 255	69	–15μA
Y	TC2 THIN CL		Color	Th	in paper	51 - 255	103	–40μA
Ζ	TC2 THIN BW		Black/White			51 - 255	103	–40μA
AA	TC2 GLOSSY CL		Color	Glo	ss paper	51 - 255	83	–25μA
AB	TC2 GLOSSY BW		Black/White			51 - 255	69	–15μA
AC	TC2 CLEANING	Secondary transfer	Cleaning p	process (neg	ative pole)	51 - 255	59	–8μA
AD	TC2 CLEAN LOW SPD	cleaning bias	Low	speed print i	mode	0 - 255	26	0V
AE	TC2 CLEAN MIDDLE SPD	adjustment value	Middle	e speed print	t mode	0 - 255	26	0V
AF	TC2 CLEAN CLEANING		Cleaning	g bias (posit	ive pole)	0 - 255	102	500V
AG	PTC LOW SPEED CL	PTC current	Color	Lov	w speed	51 - 255	73	–200μA
AH	PTC MIDDLE SPEED CL	adjustment value		Mide	dle speed	51 - 255	73	–200μA
AI	PTC LOW SPEED BW		Black/White	Lov	w speed	51 - 255	73	–200µA
AJ	PTC MIDDLE SPEED BW			Mide	dle speed	51 - 255	73	–200µA
AK	CASE VOLT LOW CL	PTC voltage	Color	Lov	w speed	0 - 255	0	0V
AL	CASE VOLT MID CL	adjustment value		Mide	dle speed	0 - 255	0	0V
AM	CASE VOLT LOW BW		Black/White	Lov	w speed	0 - 255	0	0V
AN	CASE VOLT MID BW			Mide	dle speed	0 - 255	0	0V

3) Enter the adjustment value (specified value), and press [OK] key.

When [EXECUTE] key is pressed, the voltage entered in the procedure 3) is outputted for 30sec and the set value is saved. When [EXECUTE] key is pressed again, the output is stopped.

By setting the default value (specified value), the specified output is provided.

ADJ 3 Image density sensor adjustment

Before executing this adjustment, check to confirm the following items.

- * Check to confirm that the color image density sensor (image registration sensor F) and the black image density sensor (image registration sensor R) are clean.
- * Check to confirm that the image density sensor calibration plate is clean.
- * Check to confirm that the transfer belt is clean and free from scratches.

3-A Image density sensor adjustment

The transfer belt surface are used to make the sensitivity adjustment of the color image density sensor (image registration sensor F) and the black image density sensor (image registration sensor R).

This adjustment executes automatically at the outset of registration adjustment operation and process control operation as well as SIM44-2.

Normally, therefore, it is not required to perform this adjustment. It is performed only when the sensor is replaced or when the adjustment result is checked.

1) Enter SIM44-2 mode.

						D 🗇
TEST SIMULATION	NO. 44-0	02				CLOSE
PROCON GAIN ADJUS	STMENT					
PCS_F_CL_KA		500	PCS_R BELT MIN	0		10KEY
PCS_F LED ADJ		32	PCS_R BELT DIF	0		
PCS_R LED ADJ		40	REG_F LED ADJ	32		EATT BACK CLEAR
PCS_F_CL_DARK		0	REG_F DARK	0		$\neg \neg \neg$
PCS_F DARK		0	REG_F GRND	0		1 2 3
PCS_R DARK		0	REG_R LED ADJ	40	(în l	
PCS_F GRND		0	REG_R DARK	0		4 5 6
PCS_F BELT MAX		0	REG_R GRND	0		
PCS_F BELT MIN		0	REG_F BELT MAX	0	₽	7 8 9
PCS_F BELT DIF		0	REG_F BELT MIN	0		
PCS_R GRND		0	REG_F BELT DIF	0		
PCS_R BELT MAX		0	REG_R BELT MAX	0		
				EXECUT	E1/2	MONO COLOR

2) Press [EXECUTE] key.

The sensitivity adjustments of the color image density sensor (image registration sensor F) and the black image density sensor (image registration sensor R) are automatically performed. After completion of the adjustment, the adjustment result is displayed and [EXECUTE] key returns to the normal display. If the adjustment is not completed normally, "ERROR" is displayed.

Mode	Error display	E	rror content
Adjustment value for process control	BK_SEN_ ADJ_ERR	Black image density sensor adjustment abnormality	PCS_K LED ADJ error (The target value is not obtained after retried three times.)
operation mode	CL_SEN_ ADJ_ERR	Color image density sensor adjustment abnormality	PCS_CL LED ADJ error (The target value is not obtained after retried three times.)
	BELT_READ_ ERR	Transfer belt surface reading abnormality	PCS_K GRND error (The surface detection level is maximum or the minimum value difference is outside a reference range.)

Mode	Error display	E	rror content
Adjustment value for image registration	REG_SEN_ F_ADJ_ERR	Registration sensor F adjustment abnormality	REG_F LED ADJ error (The target value is not obtained after retried three times.)
operation mode	REG_SEN_ R_ADJ_ERR	Registration sensor R adjustment abnormality	REG_R LED ADJ error (The target value is not obtained after retried three times.)
	REG_BELT_ F_READ_ ERR	F side transfer belt surface reading abnormality	REG_F GRND error (The surface detection level is maximum or the minimum value difference is outside a reference range.)
	REG_BELT_ R_READ_ ERR	R side transfer belt surface reading abnormality	REG_R GRND error (The surface detection level is maximum or the minimum value difference is outside a reference range.)

When an error occurs, check the following sections for any abnormality.

- · Color image density sensor (image registration sensor F)
- Black image density sensor (image registration sensor R)
- PCU PWB
- Transfer belt (dirt, scratch)
- · Transfer belt cleaner
- If any abnormality is found, repair and adjust again.

If an error occurs, the adjustment result is not revised.

ADJ 4 Image lead edge position, image loss, void area, image off-center, image magnification ratio adjustment (Automatic adjustment)

The following adjustment items can be executed automatically with SIM50-28.

* ADJ 15

Print image position, image mag nification ratio, void ar ea, offcenter adjustment (Print engine) (Manual adjustment)

- * ADJ 16 Scan im
- Scan image magnification ratio adjustment (Manual adjustment)
- * ADJ 17
 - Scan image off-center adjustment (Manual adjustment)
- * ADJ 18
 - Copy image position, image loss adjustment (Manual adjustment)

(Menu in SIM50-28 mode)

Display/Item	Content
OC ADJ	Image loss off-center sub scanning direction image
	magnification ratio adjustment (Document table mode)
BK-MAG ADJ	Main scanning direction image magnification ratio
	adjustment
SPF ADJ	Image loss off-center sub scanning direction image
	magnification ratio adjustment (RSPF mode)
SETUP/	Print lead edge adjustment, image off-center (each paper
PRINT ADJ	feed tray, duplex mode) adjustment
RESULT	Adjustment result display
DATA	Display of data used when an adjustment is executed

4-A Print image main scanning direction automatic magnification ratio adjustment (Print engine)

1) Enter the SIM50-28 mode.

r	ADJUSTMENT: SERVICE		
	OC ADJ	BK-MAG ADJ	
	SPF ADJ	SETUP/PRINT ADJ	
	RESULT	DATA	

- 2) Select [BK-MAG ADJ] with the key.
- Select the paper feed tray with paper in it with the key. (Any paper size will do.)

	C	0
TEST SIMULATION NO. 50-28	CL	.OSE
AUTO IMAGE POSITION ADJUSTMENT:SERVICE		
MFT CS1 CS2		
		₩.
	_	
EXECUT		1/1

- Press [EXECUTE] key. The adjustment pattern is printed out.
- 5) Set the adjustment pattern on the document table.

Important

Fit the adjustment pattern correctly with the document guide. In this case, put 5 sheets of white paper on the printed adjustment pattern.



6) Press [EXECUTE] key.

	D 0
TEST SIMULATION NO. 50-28	CLOSE
AUTO IMAGE POSITION ADJUSTMENT: SERVICE	
NOW EXECUTING	
	EXECUTE

The following item is automatically adjustment.

- * Print image main scanning di rection image magnification ratio.
- 7) Press [OK] key.

The adjustment result becomes valid.

	C 0
TEST SIMULATION NO. 50-28	CLOSE
AUTO IMAGE POSITION ADJUSTMENT:SERVICE	
BK-MAG : ** (**)	
	1
	(m)
	<u> </u>
REPRINT	RETRY DATA OK

4-B Print image off-center automatic adjustment (Print engine) (Each paper feed tray)

1) Enter the SIM50-28 mode.



- 2) Select [SETUP/PRINT ADJ] with the key.
- 3) Select [ALL] with the key.



Note

By pressing [LEAD] or [OFFSET] key, the following items can be executed individually.

- * [LEAD]: Print image lead edge image position adjustment
- * [OFFSET]: Print image off-center adjustment
- When [ALL] is selected, both of the ab ove two items are executed simultaneously.
- 4) Select a paper feed tray to be adjusted.



5) Press [EXECUTE] key.

The adjustment pattern is printed out.

6) Set the adjustment pattern on the document table.



Fit the adjustment pattern correctly with the document guide. In this case, put 5 sheets of white paper on the printed adjustment pattern.



- 7) Press [EXECUTE] key.
 - The following item is automatically adjustment.
 - * Print image lead edge image position adjustment
 - * Print image off-center adjustment
- 8) Press [OK] key.

The adjustment result becomes valid.

Perform procedures 4) to 7) for each paper feed tray.

4-C Copy mode image lead edge position, image loss, void area, image off-center, sub scanning direction image magnification ratio automatic adjustment (Scanner) (Document table mode)

1) Enter the SIM50-28 mode.



2) Select [OC ADJ] with the key.

 Select the paper feed tray with paper in it with the key. (Any paper size will do.)



- Press [EXECUTE] key. The adjustment pattern is printed out.
- 5) Set the adjustment pattern on the document table.

Important

Fit the adjustment pattern correctly with the document guide. In this case, put 5 sheets of white paper on the printed adjustment pattern.



6) Press [EXECUTE] key.

	<u>v 0</u>
TEST SIMULATION NO. 50-28	CLOSE
AUTO IMAGE POSITION ADJUSTMENT:SERVICE	
PLEASE WAIT	
NOW EXECUTING	
REPRINT	EXECUTE

The following item is automatically adjustment.

 Copy lead edge image reference position adjustment, image off-center, sub scanning direction image magnification ratio automatic adjustment Press [OK] key. The adjustment result becomes valid.

	応 0
TEST SIMULATION NO. 50-28	CLOSE
AUTO IMAGE POSITION ADJUSTMENT:SERVICE	
SIMULATION COMPLETE	
PLEASE PUSH CA KEY	
	_
	1
	0
	1

- 4-D Copy mode image lead edge position, image loss, void area, image off-center, sub scanning direction image magnification ratio automatic adjustment (Scanner) (RSPF mode)
- 1) Enter the SIM50-28 mode.

		C 0
TEST SIMULATION NO. 50-28		CLOSE
AUTO IMAGE POSITION ADJUSTMENT:SERVICE		
OC ADJ	BK-MAG ADJ	
SPF ADJ	SETUP/PRINT ADJ	
RESULT	DATA	
		1
		[]
		6
		1

2) Press the [SPF ADJ] key.



- Proceed to one of the three screens for selecting the cassette used to print RSPF adjustment patterns by selecting the corresponding button:
 - SIDE1: RSPF adjustment for the front side
 - SIDE2: RSPF adjustment for the back side

ALL: RSPF adjustment for both the front and back sides

- Select one of the casset tes that can be u sed to print RSPF adjustment patterns. (Multiple selection is not allowed.)
- Press the [EXECUTE] key, and the machine starts self-print of RSPF adjustment patterns.
 - * The screen shows a message indicating that the machine is self-printing RSPF adjustment patterns.
 - When self-print finishes, the next screen appears where you can start RSPF adjustments.

6) RSPF adjustment patterns are loaded into the RSPF. (Set so that the pattern surface faces up.)



- * By pressing the [REPRINT] key, you can retur n to the cassette selection screen and have the machine self-print RSPF adjustment patterns again.
- 7) Press the [EXECUT E] key, and the machine st arts reading RSPF adjustment patterns (for the front side).
 - * The screen shows a message indicating that the machine is reading and calculating RSPF adjustment patterns (for the front side).

The machine starts calculating the adjustment amount (for the front side) after it has read the patterns for the front side. After the machine has finished calculating the adjustment amount for the fr ont side, the next screen appe ars where you can have the machine st art reading RSPF adju stment patterns (for the back side).

Adjustment Item List

- RSPF original leading edge adjustment (front side)
- RSPF original off-center adjustment (front side)
- RSPF original sub-scan magnification adjustment (front side)
- 8) RSPF adjustment patterns are loaded into the RSPF. (Set so that the pattern surface faces down.)



- * By pressing the [REPRINT] key, you can return to the cassette selection screen and have the machine self-print RSPF adjustment patterns again.
- Press the [EXECUTE] key, and the machine st arts loading RSPF adjustment patterns (for the back side).
 - * The screen shows a message indicating that the machine is reading RSPF adjustment patterns (for the back side).
 The machine starts calculating the adjustment amount (for the back side) after it has read the patterns for the back side.

After the machine has finis hed calculating the adjustment amount for the back side, the next screen appears where you can view the results of the adjustments.

<Adjustment Item List>

- RSPF original leading edge adjustment (back side)
- RSPF original off-center adjustment (back side)
- RSPF original sub-scan magnification adjustment (back side)

10) The adjustment result screen appears.

This screen shows the current values along with the previous values in parentheses.

- * By pressing the [REPRINT] key, you can return to the cassette selection screen and have the machine self-print RSPF adjustment patterns (for the front and back sides) again.
- * To have the machine start re-reading the RSPF adjustment patterns (front and back sides), press the [RESCAN] key.
- * To return to the top menu without saving the adjustment values into EEPROM and RAM, press the [RETRY] key.
- * To display the data used for adjustment, press the [DA TA] key.
- 11) To save the adjust ment values into EEPROM and RAM and return to the top menu, press the [OK] key.
 - * To return to the result screen, press the [BACK] key.

ADJ 5 Print engine image distortion adjustment / OPC drum phase adjustment / Color registration adjustment (Print engine section)

This adjustment must be performed in the following cases:

- * When the color shift occurs.
- * When the LSU is replaced.
- * When the LSU is removed from the main unit.
- * When the unit is installed or when the installing place is changed.
- * When maintenance work is performed. (Replacement of the OPC drum, the OPC cartridge, the transfer unit, the transfer belt, etc.)
- * When [ADJ 4A] / [ADJ 16A] Print engine image magnification ratio adjustment (BK) (main scanning direction) is performed.
- * U2 trouble has occurred.
- * When the PCU PWB is replaced.
- * When EEPROM on the PCU PWB is replaced.
- * When the color phase is not proper even after execution of the color balance adjustment.
- * When the OPC drum drive section is disassembled.
- * When the primary transfer unit is replaced. (when it is removed from the machine)
- * When the developing unit or the OPC drum unit is removed from the machine.

5-A Print engine image distortion adjustment (Manual adjustment) / OPC drum phase adjustment (Automatic adjustment) / Color registration adjustment (Automatic adjustment)

This adjustment performs the print engine image distor tion adjustment, the OPC drum phase adjustment, and the color registration adjustment simultaneously.

1) Enter SIM50-22 mode.



2) Press [EXECUTE] key.

[EXECUTE] key is highlighted and the image registration automatic adjustment is started. (It takes about 15 sec to complete the adjustment.)

 When the adjustment is completed, [EXECUTE] key returns to the normal display, and the value of the adjustment r esult is displayed.

The current skew level for ea ch color is d isplayed on the SKEW display section.

Display/ Item	Content		Content		ay/ Content Display Default N		NOTE
MAIN F	С	Registration adjustment value main scanning	1.0 - 199.0	100			
		Desistantian adjustment value main according	4.0.400.0	100			
	IVI	direction (Magenta laser writing position F side)	1.0 - 199.0	100			
	Y	Registration adjustment value main scanning direction (Yellow laser writing position F side)	1.0 - 199.0	100			
MAIN R	С	Registration adjustment value main scanning direction (Cyan laser writing position R side)	1.0 - 199.0	100			
	М	Registration adjustment value main scanning direction (Magenta laser writing position R side)	1.0 - 199.0	100			
	Y	Registration adjustment value main scanning direction (Yellow laser writing position R side)	1.0 - 199.0	100			
SUB	С	Registration adjustment value sub scanning direction (Cyan drum \rightarrow Black drum)	1.0 - 199.0	100			
	М	Registration adjustment value sub scanning direction (Magenta drum \rightarrow Black drum)	1.0 - 199.0	100			
	Y	Registration adjustment value sub scanning direction (Yellow drum \rightarrow Black drum)	1.0 - 199.0	100			
SKEW	С	Print skew amount calculation result (Cyan)	-99.9 - 99.9	0	If the value is positive (+), "L" is displayed at the head of the		
	Μ	Print skew amount calculation result (Magenta)	-99.9 - 99.9	0	value. If negative (–), "R" is displayed.		
	Y	Print skew amount calculation result (Yellow)	-99.9 - 99.9	0	If the value is in the range of $-2.1 - +2.1$, "(OK)" is displayed at the bottom of the value. In the other cases, "(NG)" is displayed.		
ALL_ ROTATE	Print skew amount calculation result (Overall)		-99.9 - 99.9	0	If the value is positive (+), "L" is displayed at the head of the value. If negative (–), "R" is displayed. If the value is in the range of $-1.6 - +1.6$, "(OK)" is displayed at the bottom of the value. In the other cases, "(NG)" is displayed.		
PHASE	OP	C drum phase adjustment value	1 - 8	1			

4) Write down the displayed skew level.

Meaning of the skew level value and the adjustment procedure

- * If "OK" is displayed for all items of SKEW ALL_ROTATE, C, M, and Y, there is no need to perform the adjustment.
- * When "R" is displayed at the head of the value, turn the LSU skew adjustment screw clockwise.
- * When "L" is displayed at the head of the value, turn the LSU skew adjustment screw counterclockwise.
- * The turning amount of the adjustment screw corresponds to each adjustment value. "ALL_ROTATE" indicates the number of rotations, and C, M, and Y indicate numbers of clicks.

The display value is rounded at the decimal point.

* "ALL_ROTATES" shows the number of rotations of adjustments for all the adjustment screws. "C, M, an d Y (SKEW)" shows the number of adjustment click steps for each adjustment screw of C, M, and Y.

Contents in ()

MIAN, SUB: Difference from the previous adjustment value of image registration.

Example:

If 105 for this time and 103 for the previous time,

it is displayed as 105.0 (+2.0).

SKEW, ALL_ROTATE: Judgment of the LSU skew adjustment result. OK or NG.

PHASE: OPC drum phase adjustment value of the previous time

5) If the display of ALL_ROTATE is NG, turn all the LSU skew adjustment screws to adjust, and perform the procedures 2) to 4).

Repeat the procedures 2) to 5) until the display of ALL_ROTATE becomes OK. If the display of ALL_ROTATE is OK, go to the procedure 6).

For the adjustment, remove the front cover and the waste toner box, and turn the skew adjustment screw.



6) Repeat the procedures 2) to 4) again, and check to confirm that C, M, and Y (SKEW) are OK.

If any of them is NG , turn the LSU ske w adjustment screw of the corresponding color to adjust.



Important

When the adjustment is made by turning the LSU skew adjustment screw of K, the states of C, M and Y (SKEW) are changed. Execute SIM50-22 to check to confirm that C, M, and Y (SKEW) are OK. When an abnormality occurs, "ERROR" is displayed.

In this case, check each drive section and the process section.

The adjustment result can be checked by the following manual adjustment mode.

- * ADJ 5B
 - Image skew adjustment (Manual adjustment) (SIM50-20)
- * ADJ 5C Color registration offset adjustment (SIM50-20)

Note

When the color registration is greatly shifted due to replacement of the LSU, etc, if SIM50-22 is used to per form the color registration automatic adjustment, an error may occur.

In this case, the adjustment may be properly executed by setting the adjustment items A - I of SIM50-20 to "10 0" and executing the automatic adjustment again.

If color shift in an actual print image differs in the center, the front side, and the r ear side, the color shift offset adjustment can improve it. (Refer to ADJ 5C.)

Normally there is a difference in color shift in several dots. Perform the adjustment only when the adjustment is required.

5-B Print engine image skew (LSU skew) adjustment (Manual adjustment) (No need to adjust normally)

If a more accurate adjustment than the automatic adjustment ADJ 5A is required, use this method of adjustment.

This adjustment is made by changing the parallelism of the LSU unit scan laser beams for the OPC drum.

- 1) Enter the SIM 50-20 or 64-01 mode.
- Select the paper feed tray with A3 (11" x 17") paper in it, and press [EXECUTE] key.
- The image skew (image registration) adjustment p attern is printed.
- Check the printed black image for any skew. Use the four cross points printed in black to measur e the squareness.

There are following two methods of checking the black image for any skew (right angle).

Method 1

Measure the distances between opposing corners of the rectangle print pattern, and compare the two distances to check the squareness.

Method 2

Check the squareness of the vertical and horizontal sides of the rectangle print pattern by using A3 or 1 $1" \times 17"$ paper sides.

Important

In the case of Method 2, the right angle of paper to be used may not be exact. Be sure to check the right angle of paper to be used in advance.



Method 1

Measure the length of the diagonal lines of the rectangle print pattern.

Calculate the difference between the measured lengths C and D of the diagonal lines.

Check to insure that the difference between C and D is in the following range.

C - D = 0.8mm

If the difference between C and D is in the above range, there is no need to adjust.

Method 2

Fit the side of A3 or 11" x 17" paper to the long side of the rectangle print pattern.

Measure the slant (skew) of the vertical side for the horizontal side of paper as shown in the figure.

If the above distance is 0.5mm or less, there is no need to adjust.

If the above condition is not satisfied, perform the following procedure.

 Open the front cover, remove the waste toner box, and turn the four LSU image skew adjustment screws in the same direction by the same amount.

For the adjustment, remove the front cove r and the waste toner box, and turn the skew adjustment screw.



(Skew adjustment screw rotation direction)

When C is greater than D in the method 1 or there is some skew in the direction A in the method 2, turn the screw clockwise.

When C is smaller than D in the method 1 or the re is some skew in the direction B in the method 2, turn the screw counterclockwise.

(Reference of the rotation amount of the skew adjustment screw)

In case of the method 1, 0.8mm/about 1.5 rotations

In case of the method 2, 0.5mm/about 1.5 rotations

Repeat the procedures 2) to 6).

After completion of the black image skew adjustment, go to the procedure 7).

- 6) Perform the same procedures as 1) and 2).
- 7) Check the printed color image for any skew.

If the difference between the shift amounts on the F and R sides is within \pm 1 scale of the fine adjustment check scale, there is no need to perform the adjustment.

Measure the skew amount from the print patterns on the front and rear sides of each color.





C: Main scan sub scan fine adjustment pattern

In each Y/M/C color print pattern printed separately in the F side and in the R side, note the same print color pattern and check to confirm that the F side and the R side are in the same condition.

Rough adjustment pattern check:

Check the sub scan rough adjustment color image shift check section on the R side and the F side of each color, use the center position of the black scale as the reference, and check the balance in shifts of the color image line positions in the positive and the negative directions. The balance in the R side must be the same as that in the F side.

Fine adjustment pattern check:

Check the square frames on the R side and the F side of each color. (Normally five sections of high density can be seen.) Check the sub scanning direction position of the center area of high density (one of the above five sections). These must be on the same position on the R side and the F side.

In this case, use the sub scan direction color image shift check scale (fine adjustment) as the reference.

Visually check the color density and make the darkest section as the center, and use it as the read value of the shift amount. Check that the difference in the center position of the dark density section is within ± 1 step.

The positional relations of the front and the rear frame of the print color patterns of a same color are compared. There is no need that all the colors are in the same state. Compare only the positional relations of color patterns of a same color.

If the above condition is not satisfied, perform the following procedure.

 Turn the LSU skew adjustment screw of the adjustment target color to adjust.

(Skew adjustment screw rotation direction)

When the F side is skewed to the right side for R side: Turn the screw clockwise.

When the F side is skewed to the left side for the R side: Turn the screw counterclockwise.

(Reference of the rotation amount of the skew adjustment screw)

Skew of difference by one step between F and R sides (Difference by one scale of the fine adjustment check scale) / Turn for about 2 clicks.

Repeat the procedures 7) to 8) until a satisfactory result is obtained.

5-C Color registration offset adjustment (No need to adjust normally)

This adjustment is used to set the offset value for the automatic color registration adjustment (ADJ 5A).

If there is any difference in color phase at the center and the four corners of an actual print image, this adjustment may improve it. Especially when there is any color shift at the center area, this adjustment may improve it effectively.

This adjustment cannot eliminate color shifts in all the areas, but average the overall color shifts.

After the automatic a djustment, use this color r egistration offset adjustment to correct color shift partially, performing the adjustment efficiently.

Before execution of this adjustment, check to confirm that the following adjustment has been properly made.

* ADJ 5A or ADJ 5B image skew adjustment (LSU unit)

[Kinds of adjustment values]

There are following two kinds of registration adjustment values.

- Base registration adjustment value: XXX(FRONT)/XXX(REAR) They are manual adjustment values and automatic adjustment values, and reflected when the automatic registration adjustment is executed. It varies for every operation of the automatic registration adjustment.
- Offset adjustment values: OFFSETXXF/OFFSETXXR
 They are the offset adjustment values added to the above base registration adjustment values, and ar e not change d unless
 SIM50-20 is executed to change.
- 1) Enter SIM50-20 mode.
- 2) Select the paper feed tray with A3 (11" x 17") paper in it.
- 3) Press [EXECUTE] key.

The color image registration check pattern is printed.



Reference arrow mark

4) Check the color image registration.

There are 6 color image registration patterns in total; two on each of the F side, the R side, and the center. Check all the patterns to confirm that they are within the specified range. Also check to confirm that there is not much shift in each color image registration check pattern.

Note

There are two kinds of adjustment: one in the main scanning direction and the other in the sub scanning direction. The vertical direction in the above figure is that in the main scanning direction, and the horizontal direction is that in the sub scanning direction.

There are also two kinds of adjustments: the rough adjustment and the fine adjustment. Perform the rough adjustment then perform the fine adjustment deliberately.

For the main scan direction image registration, the of fset on the F side, the R side, and at the center is independently adjusted.

If there is a difference in the sub scanning direction image registration between the F and R sides, perform the skew adjustment (ADJ 5A).



Check the print p atterns of the rough adjustment and the fine adjustment of 18 check patterns.

How to check the rough adjustment pattern and input of the adjustment value:

Visually check the color image registration check section, use the center position of the black scale as the reference, and check the shift balance in the positive and negative directions at the color image line position.

Use the center position of the bl ack scale as the r eference, and check that the color image line is symmetrical in the positive side and the negative side.

If shift is in the arrow mark X1 and Y1, increase the adjustment value. If shift is in the arrow mark X2 and Y2, decrease the adjustment value.

The reference arrow on the check pattern faces the positive direction.

(Reference adjustment value)

1 scale/10 (When the set value is changed by 10, shift is made by 1 scale.)

How to check the fine adjustment pattern and input of the adjustment value:

Check to confirm that the darkest spot (one of 5 spots seen normally) is within the center area of the image registration adjustment reference frame in the square frame.

At that time, use the color image r egistration check scale (fine adjustment) as the reference.

Visually check and consider the darkest section of color density as the center, and measure the shift from it.

Check to confirm that the center of the dark density section is within \pm 1 step.

(If the fine adjustment pr int pattern is in the range of 0 \pm 1 for the fine adjustment reference pattern scale, there is no need to adjust.) If shift is in the arrow mark X1 and Y1, increase the adjustment value. If shift is in the arrow mark X2 and Y2, decrease the adjustment value.

(Reference adjustment value)

1 scale/1 (When the set value is changed by 1, shift is made by 1 scale.)

If there is a considerable difference in color shift in the square and at the center area, perform the adjustment.

Select an adjustment item (OFF SET X F / OFF SET X R / OFF SET X S), and change the adjustment value to adjust.

OFF SET X F: F side main scanning direction registration offset set value (The color shift on the F side and at t he center area is changed.)

OFF SET X D: R side main scanning direction registration offset set value (The color shift on the R side and at the center ar ea is changed.)

OFF SET X S: Sub scanning direction registration offset set value (Color is shifted to the sub scanning direction overall.)

Important

When the adjustment value of OFF SET X F and OFF SET X R are changed, the color at the center area will be affected. Consider this when executing the adjustment.

(Adjustment conditions and method)

To adjust evenly overall, adjust so that the color shifts on the F side, the R aide and at the center are of the same level.

To adjust with the center area most focused, adjust so that the color shift at the center becomes smaller than that on the F side and the R side.

When the of fset adjustment value is 0, if the color registration adjustment (automatic adjustment) is performed, the color shift on the F side and that on the R side are automatically adjusted to be smaller than that on the center area.

Display/Item		Content	Adjustment	Default value	
A	CYAN (FRONT)	Image registration adjustment value (Main scanning direction) (Cyan) (F side)	1 - 199	100	
В	CYAN (REAR)	Image registration adjustment value (Main scanning direction) (Cyan) (R side)	1 - 199	100	
С	MAGENTA (FRONT)	Image registration adjustment value (Main scanning direction) (Magenta) (F side)	1 - 199	100	
D	MAGENTA (REAR)	Image registration adjustment value (Main scanning direction) (Magenta) (R side)	1 - 199	100	
E	YELLOW (FRONT)	Image registration adjustment value (Main scanning direction) (Yellow) (F side)	1 - 199	100	
F	YELLOW (REAR)	Image registration adjustment value (Main scanning direction) (Yellow) (R side)	1 - 199	100	
G	CYAN (SUB)	Image registration adjustment value (Sub scanning direction) (Cyan)	1 - 199	100	
Н	MAGENTA (SUB)	Image registration adjustment value (Sub scanning direction) (Magenta)	1 - 199	100	
I	YELLOW (SUB)	Image registration adjustment value (Sub scanning direction) (Yellow)	1 - 199	100	
J	OFFSET CF	Image registration offset adjustment value (Main scanning direction) (Cyan) (F side)	1 - 199	100	
К	OFFSET CR	Image registration offset adjustment value (Main scanning direction) (Cyan) (R side)	1 - 199	100	
L	OFFSET MF	Image registration offset adjustment value (Main scanning direction) (Magenta) (F side)	1 - 199	100	

Display/Item		Content	Adjustment value range	Default value
М	OFFSET MR	Image registration offset adjustment value (Main scanning direction) (Magenta) (R side)	1 - 199	100
N	OFFSET YF	Image registration offset adjustment value (Main scanning direction) (Yellow) (F side)	1 - 199	100
0	OFFSET YR	Image registration offset adjustment value (Main scanning direction) (Yellow) (R side)	1 - 199	100
Р	OFFSET CS	Image registration offset adjustment value (Sub scanning direction) (Cyan)	1 - 199	100
Q	OFFSET MS	Image registration offset adjustment value (Sub scanning direction) (Magenta)	1 - 199	100
R	OFFSET YS	Image registration offset adjustment value (Sub scanning direction) (Yellow)	1 - 199	100

ADJ 6 Scan image distortion adjustment (Document table mode)

This adjustment must be performed in the following cases:

- * When the scanner (reading) section is disassembled.
- * When the copy image is distorted.

6-A Scanner (reading) unit parallelism adjustment

Before execution of this ad justment, remove the document t able glass.

 Remove the lamp unit, and then loosen the scr ews which are fixing the scanner unit A and the drive wire. Release the scanner unit A from the drive wire.



 Turn the scanner drive pulley manually and sh ift the scanner unit B to bring it into contact with the stopper.
 When the scanner unit B is in contact with the two stoppers on the front and the rear frames simultaneously, the parallelism is proper.



If this requirement is not met, do the following steps.

3) Loosen the fixing screw of the pulley angle on the front frame side of the scanner unit B.



4) Adjust the position of the pulley angle on the front frame side of the scanner unit B so that it is in contact with two stoppers on the front and the rear frames simultaneously. 5) Fix the pulley angle on the front frame side of the scanner unit B.

If a satisfactory result is not obtained from the above procedures, perform the following procedures.

Loosen the fixing screw of the scanner unit drive pulley which is not in contact.

Without moving the scann er unit drive shaft, turn the scanner unit drive pulley manually and adjust so that the scanner unit B is in contact with both stoppers on the front frame and the rear frame simultaneously. (Change the relative position of the scanner unit drive pulley and the drive shaft.) Fix the scanner unit drive pulley fixing screw.



6) With the scanner unit B in cont act with both stoppers, fit the edge of the scanner unit A with the right edge of the frame, and fix the scanner unit A with the fixing screw.



6-B Scan image (sub scanning direction) distortion adjustment

 Make a test chart on A3 (11" x 17") paper as shown below. (Draw a rectangular with four right angles.)



Set the test chart prepared in the procedure 1) on the document table. (Shift the test chart edge 30mm from the reference position as shown below .) With the document co ver open, make a copy on A3 (11" x 17") paper.



Check for distortion in the sub scanning direction.
 If La = Lb, there is no distortion.



If there is any distortion in the sub scanning direction, perform the following procedures.

 Loosen either one of the fixing screws of the scanner unit drive pulley. (Either one on the front frame or on the rear frame will do.)



- 5) Without moving the scanner unit drive shaft, manually turn the scanner unit drive pulley to change the parallelism of the scanner unit A and B. (Change the relative position of the scanner unit drive pulley and the drive shaft.)
- 6) Tighten the scanner unit drive pulley fixing screw.

Repeat the procedures 2) - 6) until the condition of the procedure 3) is satisfied.

6-C Scan image (main scanning direction) distortion adjustment

 Make a test chart on A3 (11" x 17") paper as shown below. (Draw a rectangular with four right angles.)



- 2) Set the test chart prepared in the procedure 1) on the document table, and make a copy on A3 (11" x 17") paper.
- Check for distortion in the main scanning direction.
 If the four angles of the rectangle of the copy image are r ight angles, it is judged that there is no distortion. (The work is completed.)



If there is any distortion in the main scanning direction, perform the following procedure. 4) Check the difference (distortion balance) between left-hand and right-hand side images distortions.



If Lc = Ld, the distortion on the left is equal to that on the right. (The distortions are balanced.)

If the above condition is satisfied, go to the procedure 6).

If not, perform the following procedures.

5) Change the height balance of the scanner rail on the fr ont frame side.



Remove the lower cabinet of the oper ation panel. Loosen the scanner rail fixing screw to change the balance between the right and the left heights of the scanner rail.

Repeat the procedures 2) - 5) until the difference between the image distortions (distortion balance) is deleted.

- 6) Without changing the balance of the scanner rail on the front frame side, change the overall height.
- Set the test chart prepared in the procedure 1) on the document table, and make a copy on A3 (11" x 17") paper. Check that the distortion in the main scanning direction is within the specified range.

Repeat the procedures 6) and 7) until the distortion in the main scanning direction is in the specified range.

3) Open the RSPF unit, and loosen the fixing screw of the hinge.

ADJ 7 Scanner image skew adjustment (RSPF mode)

This adjustment must be performed in the following cases:

- * The RSPF section has been disassembled.
- * When replacing the RSPF unit.
- * The RSPF unit generates skewed scanned images.
- Create an adjustment chart by printing in duplex mode the selfprint pattern (grid pattern) specified in Simulation 64-2.
 SIM 64-2 set values

A = 1, B = 1, C = 254, D = 255

Make sure that the print grid p attern is almost in parallel with the paper edges, and app ly position marks A and B to the leading and trailing edges of the paper surface lead edge section.



- Copy the adjustment chart (created in step 1) to A3 (11" x 17") paper in RSPF duplex mode, and then check the image for skews (Set in the RSPF feed tray so that the mark on the adjustment chart is at the edge).
 - · Check with one of the following methods.

Check Method 1

(Front side)

Make sure that the output satisfies the condition: $|a-b| \pm 1 \text{ mm}$



Check Method 2

Check that the squareness of the main scanning direction print line for the longitu dinal direction of p aper is within 1.0mm.



If the copy image is not in the above state, perform the procedure 3).



- Slide the RSPF unit in the arrow direction to make the skew adjustment.
- Make a copy again and measure (a) and (b) on the copied test chart. Repeat procedures 2) to 5) until the condition ((a) - (b) = ± 1mm or less) is satisfied.

ADJ 8 Scan image focus adjustment

This adjustment must be performed in the following cases:

- * The CCD unit has been removed from the machine.
- * The CCD unit has been replaced.
- * When the copy image focus is not properly adjusted.
- * When the copy magnification ratio in the copy image main scanning direction is not properly adjusted.
- * U2 trouble has occurred.
- 1) Enter the SIM 48-1 mode.

ſ		2 0
ĺ	TEST SIMULATION NO. 48-01	CLOSE
I	MAGNIFICATION ADJUSTMENT	
I	A: 50 : CCD (MAIN)	
I	A: 50 B: 50 : CCD (SUB)	
I	[1 ~ 99] C: 50 : SPF(MAIN)	
I	D: 50 : SPF(SUB)	
I	E: 50 : SPFB (MAIN)	
	F: 50 : SPFB (SUB)	
		₽
		Or
I		OK

- Set the adjustment item CCD (MAIN) to 50 (default value). Select the adjustment item with the scr oll key, and enter the adjustment value with 10-key and press [OK] key.
- 3) Place a scale on the original table as illustrated below.



- Make a normal copy on A4 paper. Go to the copy mode, and make a copy.
- 5) Compare the copied image of the scale an d the actual scale length in terms of length.
- 6) Obtain the copy magnification ratio correction ratio in the main scanning direction from the following formula.

Main scanning dir ection copy magnification ratio correction ratio = (Original size - Copy image size) / Original size x 100% (Example)

Compare the scale of 10mm with the scale of 10mm on the copy image.

Main scanning dir ection copy magnification ratio correction ratio = $(100 - 99) / 100 \times 100 = 1$



If the copy magnification ratio is not satisfactory, perform the following procedures.

- 7) Remove the document table glass.
- 8) Remove the dark box cover.
- To prevent against shift of the CCD unit optical axis, mark the CCD unit base as shown below.



Note

This procedure must be executed also when the CCD unit is replaced.

10) Loosen the CCD unit fixing screws.



Important

Never loosen the screws marked with X.

If any one of these screws is loo sened, the position and the angle of the CCD unit base may be changed to ca use a problem, which cannot be adjusted in the market. In that case, the whole scanner unit must be replaced.

11) Slide the CCD unit in the arrow direction (CCD sub scanning direction) to change the installing position.

When the copy image is longer than the original scale, shift the CCD unit in the direction B. When the copy image is shorter than the original scale, shift the CCD unit in the direction A.

One scale of mark-off line corresponds to 0.2%.

At that time, fix the CCD unit so t hat it is in parallel with the scale on the front and the rear side of the CCD unit base.

* Fix the CCD unit so that it is in parallel with the line marked in procedure 9).



12) Make a copy and check the copy magnification ratio again. If the copy magnification ratio is not in the ran ge of $100 \pm 1\%$, repeat the procedures of 9) - 11) until the condition is satisfied.



By changing the CCD unit fixing position with the simulation 48-1 adjustment value at 50, the copy magnification ratio is adjusted within the specified range ($100 \pm 1.0\%$) and the specified resolution is obtained based on the optical system structure.

ADJ 9 Print lead edge image position adjustment (Printer mode)

This adjustment must be performed in the following cases:

- * When the registration roller section is disassembled.
- * When the LSU is replaced or removed.
- * U2 trouble has occurred.
- * The PCU PWB has been replaced.
- * The EEPROM of the PCU PWB has been replaced.

Note

This adjustment is performed by the user to increase the lead edge void area to gre ater than the st andard value (3mm) in the printer mode.

1) Enter the SIM 50-5 mode.



 Select the set it em L with the scroll key, and enter the value corresponding to the paper feed tray with A4 (11" x 8.5") paper in it.

	Display/Item	em Content		Default
A	DEN-C	Printer lead edge image position adjustment	1 - 99	30
В	DEN-B	Rear edge void area adjustment	1 - 99	30
С	FRONT/REAR	FRONT/REAR void area adjustment	1 - 99	20
D	DENB-MFT	Manual feed rear edge void area adjustment correction value	1 - 99	50
E	DENB-CS1	Tray 1 rear edge void area adjustment correction value	1 - 99	50
F	DENB-CS2	Tray 2 rear edge void area adjustment correction value	1 - 99	50
G	DENB-CS3	Tray 3 rear edge void area adjustment correction value	1 - 99	50
н	DENB-CS4	Tray 4 rear edge void area adjustment correction value	1 - 99	50
Ι	DENB-LCC	LCC rear edge void area adjustment correction value	1 - 99	50

Display/Item		Con	tent	Setti rang	ng je	Default	
J	J DENB-ADU ADU rear ed adjustment of		ADU rear edg adjustment co	e void area prrection value	1 - 9	99	50
К	DENB-HV		Heavy paper correction value		1 - 9	99	50
L	MULTI CC	UNT	Number of print		1 - 9	99	1
м	PAPER	MFT CS1 CS2 CS3 CS4	Tray selection	Manual paper feed Tray 1 Tray 2 Tray 3 Tray 4	1 - 5	1 2 3 4 5	2 (CS1)
N	DUPLEX	YES NO	Duplex print selection	Yes No	0 - 1	0 1	1 (NO)

3) Press [EXECUTE] key.

The adjustment pattern is printed.

4) Measure the distance from the paper lead edge the adjustment pattern to the image lead edg e, and check to confirm that it is in the standard adjustment value range.

Standard adjustment value: 4.0 \pm 1.0mm



If the above requirement is not met, do the following steps.

- 5) Select the adjustment t arget of the p aper feed mode adjustment item DENC with the scroll key.
- 6) Change the adjustment value.

Enter the adjustment value and press the [OK] key or the [EXECUTE] key.

When [EXECUTE] key is pressed, the adjustment pattern is printed.

When the adjustment value is increased, the distance from the paper lead edge to the image lead edge is increased. When the adjustment value is decreased, the distance is decreased. When the set value is changed by 1, the distance is changed by about 0.1mm.

Repeat the procedures 4) - 6) until the condition of 4) is satisfied.

ADJ 10 Color balance/density adjustment

- (1) Note before execution of the color balance/density adjustment
- * Requisite conditions before execution of the color balance/density adjustment

Before execution of the color balance/density adjustment, check to insure that the adjustments which affect the color balance/density have been completed properly.

The importance levels of them are shown below.

(Since the following items affect the co lor balance/density directly, they must be adjusted or set before execution of the image quality adjustments.)

1) The following adjustment items must be adjusted properly.

Job No	Adjustment item	Simulation
ADJ	Print engine image distortion adjustment / OPC drum	50-22/20
5	phase adjustment / Color registration adjustment	
	(Print engine section)	

(Though the following items affect the color balance/density, there is no need to adjust them frequently. When, however, a trouble occurs, they must be checked and adjusted.)

1) The following items must be adjusted properly.

Job No	Adjustment item			Simulation
ADJ	Adjust the	ADJ	Adjust the developing	
1	developing unit	1A	doctor gap	
		ADJ	Adjust the developing	
		1B	roller main pole position	
		ADJ	Toner density control	25-2
		1C	reference value setting	
ADJ	Adjusting high	ADJ	Adjust the main charger	8-2
2	voltage values	2A	grid voltage	
		ADJ	Adjust the developing	8-1
		2B	bias voltage	
		ADJ	Transfer current and	8-6
		2C	voltage adjustment	
ADJ	Scan image focus adjustment			48-1
8				

Note for the color balance/density check and adjustments

• For the color balance adjustments, be sure to use the paper specified for color (recommended paper).

Note that, if another kind of paper is used for the color balance adjustment, proper image qualities (color balance, density) may not be obtained.

 When setting the adjustment p attern on the document t able in the automatic color balance adj ustment procedures, place 5 sheets of white paper on the adjustment pattern in order to prevent back copying and adverse effects of paper wrinkles as far as possible.

(2) Relationship between the servicing job contents and the color balance/density check and adjustment

Note that the jobs before and after execution of the color balance/ density check and adjustment depend on the machine status and the servicing conditions.

Follow the flowchart of the color balance/density adjustment procedures depending on the actual conditions.

There are following four, major cases.

- 1) When installing (When a printer option is installed)
- 2) When a periodic maintenance is performed.
- When a repair, an inspection, or a maintenance is performed. (When a consumable part is replaced.)
- When an inst allation, a re pair, or inspection is per formed. (Without replacement of a consumable part)

(3) Copy color balance and density check

Important

Before checking the copy color b alance and density, be sure to execute the following jobs.

- * Execute the high density imag e correction (Process correction) forcibly. (SIM 44-6)
- * Execute the half-tone image correction forcibly. (SIM 44-26)

Method 1

Make a copy of the gray test chart (UKOG-0162FCZZ) and a copy of the servicing color test chart (UKOG-0326FCZZ/UKOG-0326FC11), and check that they are proper.

a. Note for execution of the color balance and density check in the color copy mode

To check the copy color balance and density, use the gray test chart (UKOG-0162FCZZ) and the servicing color test chart (UKOG-0326FCZZ/UKOG-0326FC11). Set the cop y density level to "3" in the Text/Printed Photo mode (Manual), and make a copy.

At that time, all the color balance a djustments in the use r adjustment mode must be set to the default (center).

In addition, be sure to use the specified paper for color.

b. Note for checking the monochrome copy mode density

To check the den sity, use the gr ay test cha rt (UKOG-0162FCZZ). Set the copy density level to "Manual 3" in the Text/ Printed Photo mode (Manual).

In addition, all the color balance ad justments in the use r adjustment mode must be set to the default (center).

Check with the gray test chart (UKOG-0162FCZZ)

In the copy density check with the gray test chart, check to insure the following conditions.

Important

For the color (gray) balance, u se the servicing color test chart (UKOG-0326FCZZ/UKOG-0326FC11) to check.





Check with the servicing color test chart (UKOG-0326FCZZ/ UKOG-0326FC11)

In the copy color balance check with the servicing color test chart, check to insure the following conditions.



a. Color copy check items (Check to confirm the following:)

- 1) There are 12 void areas.
- 2) Registrations (one point for the main scanning, and one point for the sub scanning) are not shifted.
- 3) The resolution of 5.0 (5 points) can be seen.

- The color difference in gray balance between the F and the R sides is not so great.
- 5) There are no white and black streaks.
- 6) Color texts are clearly reproduced.
- 7) The background density is not so light.



b. Monochrome copy check items (Check to confirm the following:)

- 1) There are 12 void areas.
- 2) The resolution of 4.0 (5 points) can be seen.
- The density difference between the F and the R sides is not so great.
- 4) There are no white and black streaks.
- 5) The background density is not so light.
- 6) The black low-density gradation is copied slightly.



(Method 2)

Use SIM46-21 to print the color balance adjustment sheet, and check each process (CMY) black patch color balance and the black patch in order to confirm that the co lor balance adjustment is proper or not more precisely.



If the color balance of each patch of the process black (CMY mixed color) is slightly shifted to Magenta, it means that the adjustment is proper. If the color balance of the adjustment pattern printed in this mode is slightly shifted to Magenta, it is converted into the natural gray color balance by the color table in an actual cop y mode. (When the color balance target is DEF 1.)

(4) Printer color balance/density check

Important

Before checking the copy color balance and the density, be sure to execute the following procedures in advance.

- * Execute the high density imag e correction (Process correction) forcibly. (SIM 44-6)
- * The half-tone image correction is forcibly executed. (SIM 44-26) (Method 1)

Execute SIM 64-5 to print the print test pattern.

Important

Set each set value to the default and press [EXECUTE] key . The print test pattern is printed.



The print density must be changed gradually from the lighter level to the dar ker level. The density changing direction must not be reversed. The density level of each co lor must be almost at the same level.

(Method 2)

Use SIM 67-25 to p rint the color b alance adjustment she et and compare each process (CMY) black patch color balance and the black patch to check the color balance.



The print density must be changed gradually from the lighter level to the darker level. The density changing direction must not be reversed.

The density level of each color must be almost at the same level.

Patch B may not be copied.

Patch A must not be copied.

If the color balance of each patch of the process black (CMY mixed color) is slightly shifted to Magenta, it means that the adjustment is proper. In an actual print mode, it is converted into the natural gray color balance by the color table. (When the color balance target is DEF 1.)

10-A Scanner calibration (CCD calibration)

This adjustment must be performed in the following cases:

- * When the CCD unit is replaced.
- * When a U2 trouble is occurred.
- * When the scanner control PWB is replaced.
- * When the EEPROM on the scanner control PWB is replaced.
- (1) Note before adjustment
- Check that the table glass, No. 1, 2, 3 mirrors, and the lens surface are free from dirt and dust.

(If there is some dust and dirt, wipe and clean with alcohol.)

 Check to confirm that the patches in BK1 and BK2 arrays of the SIT chart (UKOG-0280FCZZ or UKOG-0280FCZ1) are free from dirt and scratches.

If they are dirty, clean them.

If they are scratched or streaked, replace with new one.

(2) Adjustment procedures

 Set the SIT chart (UKOG-0280FCZZ or UKOG-0280FCZ1) to the reference position on the left rear frame side of the document table.

Set the chart so that the lighter density side of the p tch is on the left side.





If the SIT chart is not available, execute SIM 63-5 to set the CCD gamma to the default. In this case, however, the adjustment accuracy is lower when compared with the adjustment method using the SIT chart.

Important

Check to insure that the SIT chart (U KOG-0280FCZZ or UKOG-0280FCZ1) is in close contact with the document table.

Note

UKOG-0280FCZZ is equivalent to UKOG-0280FCZ1.

2) Enter the SIM 63-3 mode and press [EXECUTE] key.

The automatic oper ation is st arted. During the adjustment, [EXECUTE] is highlighted. After completion of the adjustment, [EXECUTE] returns to the normal display.

	0
TEST SIMULATION NO. 63-03	CLOSE
SCANNER COLOR BALANCE AUTO ADJUSTMENT	
SET THE CHART ON DSPF AND TOUCH [EXECUTE]	
	(m)
E	XECUTE 1/1



Since the SIT chart (UKOG-0280FCZZ or UKOG-0280FC Z1) is easily discolored by sunlight (especially ultraviolet rays) and humidity and temperature, put it in a bag (such as a dar k file) and store in a dark place of low temperature and low humidity.

SET 1 Color balance adjustment target setup

a. General

When the automatic color balance adjustment is executed, a certain color balance (gamma) is used as the target.

- There are following three kinds of the target.
- Factory color balance (gamma) target
- Service color balance (gamma) target
- User color balance (gamma) target

In the above three, only the service color balance target can be set to a desired level.

This setting is required in the following cases.

- * When the color balance and density adjustments are executed manually (SIM46-21) (SIM67-25)
- * U2 trouble has occurred.
- * When the MFP PWB is replaced.
- * When the EEPROM on the MFP PWB is replaced.
- * The scanner control PWB has been replaced.
- * The EEPROM on the scanner control PWB has been replaced.
- * When the user requests for customizing the color balance.
- * When the se rvice color balance target gamma is judged as improper.

SET 1A Copy color balance adjustment target setup

· Each color balance target for the copy color balance adjustment

Туре		Descriptions
A	Factory color balance (gamma) target	There are three kinds of the color balance target, and each of them is specified according to the machine design. Use SIM 63-11 to select one of them as the factory target. The default setting (factory setting) is the color balance (DEF1) which emphasizes color reproduction.
В	Service color balance (gamma) target	This target is used when the user requests to customize the color balance to user's desired level. In advance, the user's unique color balance must be registered as the service color balance target. The above registration (setting) is made by the serviceman with SIM 46-21 to adjust the color balance and with SIM 63-7 to register it. This color balance target is used when the user executes the color balance target. When, therefore, the service color balance target is changed, the color balance target of the user's color balance adjustment is also changed. When, however, SIM 63-8 is executed, the color balance target set with SIM 63-11. The default setting (factory setting) of the color balance target. (Emphasized on color reproduction (DEF1)) If the user does not request for customizing the color balance, be sure to use SIM 63-8 to set the color balance target.
С	User color	Same color balance as the service color balance
	balance (gamma) target	(gamma) target When the service color balance target is changed, this color balance target is also changed accordingly.
Relationship between the factory target and the service target and the color balance target for the user color balance adjustment in the copy color balance adjustment (Automatic adjustment) (SIM 46-74/46-24)

Color balance target in the copy color balance automatic adjustment (SIM 46-24)



By use of SIM 63-11, one of the following color balances can be set as the factory color balance target. Each of the three color balances cannot be changed. (Fixed)



 Service color balance target in the copy color balance adjustment ((Automatic adjustment) SIM 46-74/46-24).

For the service color balance t arget, an option al color balance can be adjusted with SIM 46-21 and registered with SIM 63-7. When, however, SIM 63-8 is executed, the color balance is set to the same balan ce as the factory co lor balance target set with SIM 63-11.

Color balance target in the user color balance adjustment

This color balance is same as the service color balance target in the copy color balance adjustment (Automatic adjustment) (SIM 46-74/46-24). When, therefore, the service color balance target is changed, this target is also changed accordingly.

(Meaning of the service co lor balance target gamma data and the purpose of registration)

This procedure must be executed only when the color balance is customized with SIM 46-21.

If the color balance is not customized, this procedure is not required.

After completion of the customized color balance adjustment (Manual) with SIM 46-21 according to the user's r equest, use SIM 63-7 to register the service color balance target data by using adjustment pattern that was printed in this mode.



In this case, be sure to use A4 or $\,$ 11" x 8.5" paper for printing the adjustment pattern by SIM 46-21.

By this procedure, the service color balance target is revised.

It is recommended to keep the printed adjustment pattern created with SIM 46-21. This adjustment pattern can be used to register the same color balance target to another machine.

It is also useful to register the service color balance target data. Do not fold it and keep it under the circumstances which protect it from discoloration and dirt.

The service color balance t arget data is registered immediately after the color balance adjustment (Manual) with SIM 46-21.

If a considerable time has passed after completion of the color balance adjustment (Manual) with SIM 46-21, the color balance of the adjustment pattern at the time of adjustment differs from the color balance of the adjustment pattern printed after a considerable time. Never use such a pattern for the adjustment.

The accuracy of the service colo r balance target data can be judges as follows.

When result of the color valan ce adjustment (Auto) with selecting the service color balance target in SIM 46-74/46-24 is unsatisfactory or abnormal.

In that case, the registered service target data for the color balance adjustment (Auto) may be improper.

This may be caused when an improper or abnormal color balance adjustment pattern was used to register the service color balance target data for the color balance adjustment with SIM 63-7.

The color balance adjustment pattern used in registr ation was made and printed by the color balance adjustm ent (Manual) with SIM 46-21. This procedure may have been executed erroneously

a. Setting procedure

(Setting procedure of an optional color balance (gamma) as the service color balance target)

 Use SIM 46-21 (Copy color balance adjustment (manual adjustment) mode) to print two sheets of the color patch image (adjustment pattern).

Important

In this case, be sure to use A4 or 11" x 8.5" paper for printing the adjustment pattern by SIM 46-21.

If the color balance is shifted from the standard, an adjustment is required. If not, an adjustment is not required. When an optional color balance is requested by the user, make an adjustment.

2) Enter the SIM 63-7 mode.



- 3) Press [SETUP] key.
- Set the color patch image (adjustment pattern) correctly adjusted and printed in the copy color balance adjustment (Manual adjustment) (SIM 46-21) (ADJ 10C (2)) on the document table.

The color patch image (adjustment pattern) printed with S IM 64-7 can be used instead. In this case, however, check that the printed pattern is normal.

(When the color patch image (adjustment pattern) is printed by SIM 64-7, set the item B (PROC ADJ) to "0 (YES)" and press [EXECUTE] key to print.)

A color patch image (adjustment pattern) printed by another machine can be used.

Set the pattern so that the light density side is on the left side. Place 5 sheet s of white p aper on the color p atch image (adjustment pattern).

If the color balance could not be adjusted satisfactorily with SIM 46-21 (Color balance adjustment (Manual)), do not execute SIM 63-7 to register the service color balance target data.

5) Press [EXECUTE] key.

	0
TEST SIMULATION NO. 63-07	CLOSE
SCANNER TARGET OF COLOR CALIB SETUP:SERVICE	
SET THE CHART ON PLATEN AND TOUCH [EXECUTE].	
	EXECUTE

The color patch image (adjustment pattern) is read.

 Press [REPEAT] key, set the second color patch image (adjustment pattern), and execute the procedure 5) again.



The color balance (gamma) target set level of each color (KCMY) can be checked with K/C/M/Y keys.

Check that the set level is increased in the sequence of B - Q (MAX). If there is no variation or variation is reversed, it is judged as abnormal.

In case of an abnormality, repair the problem and try again.

7) Press [OK] key.

The color balance (gamma) of the color patch image (adjustment pattern) used in the procedure 5) is set as the service target.

(Procedures to set the service color balance target and the color balance target for the user color balance adjustment to the same color balance as the factory color balance target)



This procedure must not be executed when the copy color balance was adjusted with SIM 46-21 to a unique color balance requested by the user and it was reg istered as the service color balance t arget with SIM 63-7.

When the factory color balance t arget is changed with SIM 63-11, be sure to execute this procedure.

1) Enter the SIM 63-8 mode.

		© 0
TEST SIMULATION NO. 63-08		CLOSE
STANDARD SCANNER TARGET SET	TING: SERVICE	
Al	RE YOU SURE? YES NO EXECUT?	E)

SET 1B Printer color balance adjustment target setup

· Color balance target for the printer color balance adjustment

- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The service color balance target and the color balance target for the user color balance adjustment are set to the same color balance as the factory color balance target.

Туре	Descriptions
A Factory color balance (gamma) target	There are three kinds of the color balance targets, and each of them is specified according to the machine design. Use SIM 67-26 to select one of them as the factory target. The default setting (factory setting) is the color balance (DEF1) which emphasizes color reproduction.
B Service color balance (gamma) target	This target is used when the user requests to customize the color balance to user's desired level. In advance, the user's unique color balance must be registered as the service color balance target. The above registration (setting) is made by the serviceman with SIM 67-27 to register it. This color balance target is used when the user executes the color balance adjustment. When, therefore, the service color balance target is changed, the color balance target of the user's color balance adjustment is also changed. When, however, SIM 67-28 is executed, the color balance is set to the factory color balance target set with SIM 67-26. The default setting (factory setting) of the color balance is same as the factory color balance target. (Emphasized on color reproduction (DEF1)) If the user does not request for customizing the color balance, be sure to use SIM 67-28 to set the color balance to the factory color balance balance, be sure to use SIM 67-28 to set the color balance to the factory color balance target.
C User color balance (gamma) target	Same color balance as the service color balance (gamma) target When the service color balance target is changed, this color balance target is also changed accordingly.

 Relationship between the factory target and the service target and the color balance target for the user color balance adjustment in the printer color balance adjustment (Automatic adjustment) (SIM 46-74/76-24)



• Factory target in the printer color balance adjustment (Automatic adjustment) (SIM 46-74/67-24) By use of SIM 67-26, one of the following color balances can be set as the factory color balance target. Each of the three color balances cannot be changed. (Fixed)



 Service color balance target in the printer color balance adjustment (Automatic adjustment) (SIM 46-74/67-24).

For the service color balance t arget, an option al color balance can be adjusted with SIM 67-25 and registered with SIM 67-27. When, however, SIM 67-28 is executed, the color balance is set to the same balance as the factory color balance target set with SIM 67-26.

 Color balance target in the user color balance adjustment
 This color balance is same as the service color balance target in the printer color balance adjustment (Automatic adjustment) (SIM 46-74/67-24). When, there fore, the service color balance target is changed, this target is also changed accordingly.

(Meaning of the service color balance target gamma data and the purpose of registration)

If the color balance is not cust omized, this procedure is not required.

After completion of the customized color balance adjustment (Manual) with SIM 67-25 according to the user's request, use SIM 67-27 to register the service color balance target data by use of the printed adjustment pattern.

Important

In this case, be sure to use A4 or 11" x 8.5" paper for printing the adjustment pattern by SIM 67-25.

By this procedure, the service color balance target is revised.

It is recommended to keep the printed adjustment pattern created with SIM 67-25. This adjustment pattern can be used to register the same color balance target to another machine.

It is also useful to register the service color balance target data. Do not fold it and keep it under the circumstances which protect it from discoloration and dirt.

The service color balance target data is basically registered immediately after the color balance adjustment (Manual) with SIM 67-25. If a considerable time has passed after completion of the color balance adjustment (Manual) with SIM 67-25, the color balance of the adjustment pattern at the time of adjustment differs from the color balance of the adjustment pattern printed after a considerable time. Never use such a pattern for the adjustment.

The correctness of the service color balance target data can be judged as follows.

When result of the color valance adjustment (Auto) with selecting the service color balance target in SIM 67-24 is unsatisfactory or abnormal.

In that case, the registered service target data for the color balance adjustment (Auto) may be improper.

This may be caused when an improper or abnormal color balance adjustment pattern was used to register the service color balance target data for the color balance adjustment with SIM 67-27.

The color balance adjustment pattern used in re gistration was made and printed by the color balance adjustment (Manual) with SIM 67-25. This procedure may have been executed erroneously.

a. Setting procedure

(Setting procedure of an optional color balance (gamma) as the service color balance target)

 Use SIM 67-25 (Printer color ba lance adjustment (manual adjustment) mode) to print two sheets of the color patch image (adjustment pattern).

Important

In this case, be sure to use A4 or 11" x 8.5" paper for printing the adjustment pattern by SIM 67-25.

If the color balance is shifted from the standard, an adjustment is required. If not, an adjustment is not required. When an optional color balance is requested by the user, make an adjustment.

2) Enter the SIM 67-27 mode.



- 3) Press [SETUP] key.
- Set the color patch image (adjustment pattern) correctly adjusted and printed in the printer color balance adjustment (Manual adjustment) (SIM 67-25) (ADJ 10E (2)) on the document table.

A color p atch image (adjustment p attern) printed by another machine can be used.

Set the pattern so that the light density side is on the left side. Place 5 sheet s of w hite paper on t he color p atch image (adjustment pattern).

This procedure must not be executed when the copy color balance (manual) was adjusted with SIM 67-25 to a unique color balance requested by the user an d it was re gistered as the service color balance target with SIM 67-27.

5) Press [EXECUTE] key.



The color patch image (adjustment pattern) is read.

 Press [REPEAT] key, set the second color p atch image (adjustment pattern), and execute the procedure 5) again.

		▶ 0
TEST	ULATION NO. 67-27	CLOSE
SCANNER	TARGET OF PRINTER COLOE CALIB SETUP:SERVICE BASE:8800	
	#B: 227, #C: 624, #D: 908, #E: 124	19, #F: 2074,
	#G: 3298, #H: 18951, #I: 76117, #J: 12849	95, #K: 165225,
	#L: 184155, #M: 189254, #N: 194377, #0: 19727	76,
		1
		④
К	СМУ	REPEAT OK 1/1

The color balance (gamma) target set level of each color (K, C, M and Y) can be checked with K/C/M/Y keys.

Check that the set level is increased in the sequence of B - Q (MAX). If there is no variation or variation is reversed, it is judged as abnormal.

In case of an abnormality, repair the problem and try again.

7) Press [OK] key.

The color balance (gamma) of the color patch image (adjustment pattern) used in the procedure 5) is set as the service target. (Procedures to set the service color balance target and the color balance target for the user color balance adjustment to the same color balance as the factory color balance target)

Important

This procedure must not be executed when the copy color balance was adjusted with SIM 67-25 to a unique color balance requested by the user and it was reg istered as the service color balance t arget with SIM 67-27.

When the factory color balance t arget is changed with SIM 67-26, be sure to execute this procedure.

1) Enter the SIM 67-28 mode.

TIST SIRULATION NO. 67-28 CLOSE STANDARD SCANNER TARGET OF PRINTER COLOR CALIB:SERVICE		© 0
STANDARD SCANNER TARGET OF PRINTER COLOR CALIB:SERVICE	TEST SIMULATION NO. 67-28	CLOSE
	STANDARD SCANNER TARGET OF PRINTER COLOR CALIB:SERVICE	
ARE YOU SURE? YES NO EXECUTE	ARE YOU SURE? YES	NO EXECUTE

- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The service color balance target and the color balance target for the user color balance adjustment are set to the same color balance as the factory color balance target.

10-B Copy/Printer color balance and density adjustment (Automatic adjustment) (Basic adjustment)

This adjustment must be performed in the following cases:

- * When a consumable part (developer, OPC drum, transfer belt) is replaced.
- * When the CCD unit is replaced.
- * When the scanner (reading) section is disassembled.
- * When the scanner (reading) unit is replaced.
- * U2 trouble has occurred.
- * When the MFP PWB is replaced.
- * When the EEPROM on the MFP PWB is replaced.
- * The scanner control PWB has been replaced.
- * The EEPROM on the scanner control PWB has been replaced.

a. General

SIM46-74 is used to perform the automatic copy color balance and density adjustment (SIM46-24) and the automatic printer color balance and density adjustment (SIM67-24) continuously.

Since it is desirable to perform the copy color balance adjustment (automatic adjustment) before the automatic printer color balance and density adjustment, it is advisable to perform the adjustment in this mode.

This mode is also advisable to effectively perform both of the automatic copy color balance and density adjustment (SIM46-24) and the automatic printer color balance and density adjustment (SIM67-24). It saves considerable time when compared with per forming each of the auto copy/printer color balance and the density adjustment individually.

The color balance adjustment (automatic adjustment) is used to adjust the copy density of each of Cyan, Magenta, Yellow, and Black automatically.

When this adjustment is executed, the color balance adjustments of all the copy/printer modes are revised.

b. Adjustment procedures

(Auto color balance adjustment by the serviceman)



1) Enter the SIM46-74 mode.



2) Press [EXECUTE] key.

The high density process control is performed, and the copy color patch image (adjustment pattern) is printed out. (A4/11" x 8.5" or A3/11" x 17" paper is automatically selected.)

	© 0
TEST SIMULATION NO. 46-74	CLOSE
ENGINE AUTO ADJUSTMENT (SERVICE)	
PROCON EXECUTING	
	EXECUTE

 Set the color patch image (adjustment pattern) paper printed in procedure 2) on the document table.

Set the color p atch image (adjustment p attern) printed in the procedure 2) on the do cument table. Place the color p atch image so that the fine lines are on the left side. At that time, place 5 sheets of white paper on the printed color patch image (adjustment pattern).



4) Select [FACTORY] target, and press [EXECUTE] key.

When the color balance is customized by the manual color balance adjustment (SIM 46-21) according to the user's request, and the color balance is registered with SIM63-7 as the service target, if the color balance is required to be adjusted, select the [SERVICE] target.

		0 0
TEST SIMULATION NO. 46-74		CLOSE
ENGINE AUTO ADJUSTMENT (SERVICE)		
PLEASE SELECT THE MODE(FACTORY) OR (SERVICE) AND PLACE		
THE PRINTED TEST PATCH ON DOCUMENT GLASS THEN PRESS [EXECUTE].		
*LIGHT AREA AT LEFT SIDE ON DOCUMENT GLASS.		
FACTORY	EXECUTE	

The copy color balance adjustment is automatically executed and prints the color balance check patch image.

If there is any streak or unclear print on the printed check pattern, check the print engine for any problems.



5) Press [EXECUTE] key.

The printer color patch image (adjustment pattern) is printed out. (A4/11" x 8.5" or A3/11" x 17" paper is automatically selected.)

		Q	0
	TEST SIMULATION NO. 46-74	[CLOSE
Ī	ENGINE AUTO ADJUSTMENT (SERVICE)		
	CONFIRM THE ADJ PATCH AND PRESS [EXECUTE] TO ADJ OF REGISTRATION EXE.		
	AND PRINT THE TEST PATCH.		
	(PLEASE USE SPECIFIED TYPE OF A3 OR $11^{\prime\prime} \times 17^{\prime\prime}$ SIZE PAPER		
	FOR THIS ADJUSTMENT)		
	E	XECUTE)

6) Set the color p atch image (adjustment p attern) printed in the procedure 5) on the document table.

Set the color p atch image (adjustment p attern) printed in the procedure 2) on the do cument table. Place the color p atch image so that the fine lines are on the left side. At that time, place 5 sheets of white paper on the printed color patch image (adjustment pattern).

	PRINTER CALIBRATION	
+		+
		+
+		+

7) Select [FACTORY] target, and press [EXECUTE] key. When the color balance is customized with the manual color balance adjustment (SIM 67-25) according to the user's request and the color balance is registered as the service target with SIM 67-27, if the color balance is adjusted to that color balance, select the [SERVICE] target.

		0
TEST SIMULATION NO. 46-74	CLO	SE
ENGINE AUTO ADJUSTMENT (SERVICE)		_
PLEASE SELECT THE MODE(FACTORY) OR (SERVICE) AND PLACE		
THE PRINTED TEST PATCH ON DOCUMENT GLASS THEN PRESS [EXECUTE].		
*LIGHT AREA AT LEFT SIDE ON DOCUMENT GLASS.		
FACTORY SERVICE	EXECUTE	

The printer color balance adjustment (step 1) is au tomatically performed and the color balance check patch image is printed out.

If there is any streak or unclear print on the printed check pattern, check the print engine for any problems.



 The initial setting menu of the halftone image correction is displayed. Press [OK] key.

The initial setting of the half tone image correction is performed.

	© 0
TEST SIMULATION NO. 46-74	CLOSE
ENGINE AUTO ADJUSTMENT (SERVICE)	
CONFIRM THE ADJUSTED PATCH AND PRESS [OK] TO REGISTER THIS PATCH DATA	
	OK

 Wait until [EXECUTE] key is displayed. When it is displayed, press it.

The halftone image correction is performed.

 When "COMPLETED T HIS PROCEDURE" is displayed, the adjustment operation is completed. Cancel SIM46-74.

	¢	0
TEST SIMULATION NO. 46-74	CL	OSE)
ENGINE AUTO ADJUSTMENT (SERVICE)		
COMPLETE THIS PROCEDURE.		
PLEASE QUIT THIS MODE.		
ОК		
RESULT		
L		

Important

The adjustment result becomes valid only when the both adjustments in the copy mode and in the printer mode are completed.

For example, if the copy color balance adjustment (automatic adjustment) is performed and the simulation is canceled, the adjustment result is invalid.

11) Check the copy color balance and density.

(Refer to the item of the copy co lor balance and den sity check.)

When satisfactory color balance and density are not obtained from the automatic adjustment by selecting the factory target in procedure 4), change the factory color balance target with SIM 63-11 and repeat the procedures from 1).

If a satisfactory result is not obtained with the above procedure, perform the manual color balance adjustment (ADJ 10C (2)).

Also when the service target is selected in procedure 4) to execute the automatic adjustment and a satisfactory result is not obtained, perform the manual color balance adjustment (ADJ 10C (2)).

12) Check the printer color balance and density.

(Refer to the item of the printer color balance and density check.)

When satisfactory color balance and density are not obtained from the automatic adjustment by selecting the factory target in procedure 7), change the factory color balance target with SIM 67-26 and repeat the procedures from 1).

If a satisfactory result on the color ba lance and the density is not obtained with the automatic adjustment, execute the manual adjustment (SIM 67-25) (ADJ 10E (2)).

Also when the service target is selected in procedure 7) to execute the automatic adjustment and a satisfactory result is not obtained, perform the manual color balance adjustment (ADJ 10E (2)).

If the color balance or density is not in the satisfactor y level even after execution of the automatic and man ual adjustments, there may be another cause.

Troubleshoot the cause, rep air or perform necessary works, and repeat the adjustment from the beginning.

10-C Copy quality adjustment (Basic adjustment)

This adjustment must be performed in the following cases:

- * When a consumable part (developer, OPC drum, transfer belt) is replaced.
- * The CCD unit has been replaced.
- * When the scanner (reading) section is disassembled.
- * When the scanner (reading) unit is replaced.
- * U2 trouble has occurred.
- * When the MFP PWB is replaced.
- * When the EEPROM on the MFP PWB is replaced.
- * The scanner control PWB has been replaced.
- * The EEPROM on the scanner control PWB has been replaced.

10-C (1)

Copy color balance and density adjustment (Automatic adjustment)

a. General

The color balance adjustment (automatic adjustment) is used to adjust the copy density of each of Cyan, Magenta, Yellow, and Black automatically.

When this adjustment is executed, the color balance adjustments of all the copy modes are revised.

There are following two modes in the auto color balance adjustment.

- 1) Auto color balance adjustment by the serviceman (SIM 46-24 is used.)
- Auto color balance adjustment by the user (The user program mode is used.) (The color balance target is the service target.) The auto color balance adjustment by the user is provided to reduce the number of service calls.

If the copy color balance is lost for some reason, the user can use this color balance adjustment to recover the balance.

When, however, the machine has a fatal problem or when the machine condition is greatly changed, this function does not work effectively.

If the machine condition is dramatically changed, a fatal problem occurs, or the normal color t argets cannot be obtained, service must recalibrate the machine to specification.

To perform the adjustment, the above difference must be fully understood.

b. Adjustment procedure

(Auto color balance adjustment by the serviceman)



1) Enter the SIM 46-24 mode.



2) Press [EXECUTE] key. (A4/11" x 8.5" or A3/11" x 17" paper is automatically selected.)

The color patch image (adjustment pattern) is printed out.

3) Set the color patch image (adjustment pattern) paper printed in procedure 2) on the document table.

Place the printed color patch image (adjustment pattern) paper on the document table so that the thin lines on the paper are on the left side. Place 5 sheet s of white paper on the printed color patch image (adjustment pattern) paper.



4) Select [FACTORY] target, and press [EXECUTE] key. When the color balance is customized with the manual color balance adjustment (SIM 46-21) according to the user's request and the color balance is registered as the service target with SIM 63-7, if the color balance is adjusted to that color balance, select the service target.

	© 0
TEST SIMULATION NO. 46-24	CLOSE
ENGINE HALFTONE AUTO ADJUSTMENT MODE (REGULAR)	
PLEASE SELECT THE MODE(FACTORY) OR (SERVICE) AND PLACE	
THE PRINTED TEST PATCH ON DOCUMENT GLASS THEN PRESS [EXECUTE].	
*LIGHT AREA AT LEFT SIDE ON DOCUMENT GLASS.	
FACTORY SERVICE	EXECUTE

The copy color balance adjustment is automatically executed to print the color balance check patch image. Wait until the operation panel shown in procedure 5) is displayed.



 Press [OK] key on the operation panel. According to data of this adjustment, the initial setting of the halftone image correction is performed.

	C 0
TEST SIMULATION NO. 46-24	CLOSE
ENGINE HALFTONE AUTO ADJUSTMENT MODE (REGULAR)	
CONFIRM THE ADJUSTED PATCH AND PRESS [OK] TO REGISTER THIS PATCH DATA	
ОК	

Note

After pressing [OK] key, the initial setting of the halftone image correction is started. During the operation, "NOW REGISTER-ING THE NEW TARGET OF HALFTONE PROCON." is displayed. This operation takes several minutes.

After completion of the operation, "PLEASE QUIT THIS MODE" is displayed.

Do not cancel the simulation until "PLEASE QUIT THIS MODE" is displayed.

	C 0
TEST SIMULATION NO. 46-24	CLOSE
ENGINE HALFTONE AUTO ADJUSTMENT MODE (REGULAR)	
COMPLETED THIS PROCEDURE	
PLEASE QUIT THIS MODE.	

- Check the color balance and density. (Refer to the item of the copy co lor balance and den sity check.)
- 7) Use SIM44-26 to execute the halftone image correction. (Forcible execution)

Enter the SIM44-26 mode and press [EXECUTE] key. [EXECUTE] key is highlighted and the operation is started.

	© 0
TEST SIMULATION NO. 44-26	CLOSE
HALF TONE DENSITY CORRECT EXECUTION	
TOUCH [EXECUTE] THEN EXECUTION START.	
	EXECUTE

It takes several minutes to complete the operation. After completion of the operation, "COMPLETE" is displayed.

(Normal end (Auto transition))

		0
TEST SIMULATION NO. 44-26		CLOSE
HALF TONE DENSITY CORRECT EXECUTION		
RESULT		
COMPLETE		
	RESULT	TE

(Abnormal end (Auto transition))



After completion of the operation, the simulation is canceled.

 Use the servicing color test chart (UKOG-0326FCZZ/UKOG-0326FC11) in the Text/Photo mode (Manual) to check the copy color balance and density. (Refer to the item of the copy color balance and density check.)

If the copy color balance and density are not satisfactory, perform the following procedures.

- Execute the initial settin g of the halftone image corr ection. (SIM 44-21)
- 10) Execute the half tone image correction. (Forcible execution) (SIM44-26)

 Use the servicing color test chart (UKOG-0317FCZZ/UKOG-0317FC11) in the Text/Printed Photo mode (Manual) to check the copy color balance/density. (Refer to the item of the copy color balance and density check.)

Though the above procedur es 9) - 11) are performed, the copy color balance and density are not in the specified range, there may be another cause.

Troubleshoot the cause, repair or perform necessary works, and repeat the adjustment from the beginning.

When satisfactory color balance and density are not obtained from the automatic adjustment by selecting the factory t arget in procedure 4), change the factory color balance target with SIM 63-11 and repeat the procedures from 1).

If a satisfactory result on the color balance and the density is not obtained with the a utomatic adjustment, execute the manual adjustment (SIM 46-21) (ADJ 10C (2)).

Also when the service target is selected in procedure 7) to execute the automatic adjustment and a satisfactory result is not obtained, perform the manual color balance adjustment (ADJ 10C(2)).

If the color balance or density is not in the satisfactory level even after execution of the automa tic and manual adju stments, there may be another cause.

Troubleshoot the cause, repair or perform necessary works, and repeat the adjustment from the beginning.

10-C (2)

Copy color balance and density adjustment (Manual adjustment)

a. General

The color balance adjustment (Manual adjustment) is used to adjust the copy density of CMYK. This is used at the following situation. When the result of auto adjustment described above is not existing within the range of reference. When a fine adjustment is required. When there is request from the user for changing (customizing) the color balance.

This manual adjustment is executed only for the color patch which could not adjusted properly in the automatic adjustment.

If the color balance is improper, execute the automatic color balance adjustment in advance, and execute this adjustment for better efficiency.

b. Adjustment procedure

Copy color balance and density adjustment (Manual adjustment) procedure flowchart (SIM46-21)





2) Press [EXECUTE] key. (A4/11" x 8.5" or A3/11" x 17" paper is automatically selected.)

The color balance adjustment pattern is printed.

3) Check that the following specification is satisfied or the color balance is satisfactory.

If not, execute the following procedures.



The print density must be changed gradually from the lighter level to the darker level. The density changing direction must not be reversed.

The density level of each color must be almost at the same level.

Patch B may not be copied.

Patch A must not be copied.

When, however, the color balance is adjusted according to a request from the user, there is no need to set to the standard color balance stated above.

If the color balance of each patch of the process black (CMY mixed color) is slightly shifted to Magenta, it means that the adjustment is proper. If the color balance of the adjustment pattern printed in this mode is slightly shifted to Magenta, it is converted into the natural gray color balance by the color correction table in an actual copy mode. (When the color balance target is DEF 1.)

- Select the color to be adjusted with the color select key, and select the adjustment point with the scroll key.
- Enter the adjustment value with 10-key and press [OK] key. The adjustment value is set in the range of (1 - 999). When SIM 46-24 is used to adju st the automatic color balance and density, all the set values of this simulation are set to 500.

To increase the density, increase the adjustment value. To decrease the density, decrease the adjustment value.

Repeat procedures of 2) - 5) until the condition of 3) is satisfied.

When the overall density is low, or when the density is high and patch A is copied, use the arrow key to adjust all the adjustment values of A - Q (MAX) to a same level collectively. Then, adjust each patch density individually. This is an efficient way of adjustment.

Referring to the black/gray patches, adjust so that each process (CMY) black/gray patch color balance of A - Q (MAX) approaches the black/gray patch level as far as possible.

6) Make a copy of the servicing color test chart (UKOG-0326FCZZ/UKOG-0326FC11) and a use r's document according to necessity in the normal copy mode, the text/Printed Photo mode (Manual) to check the adjustment result.
(Defeate the items of the service select between (density of the service)

(Refer to the item of the copy color balance/density check.)

7) Execute SIM 44-21. (Execute the initial setting of the halftone image correction.)



It takes several minutes to complete the opera tion. After completion of the operation, "COMPLETE" is displayed.

(Normal end (Auto transition))



(Abnormal end (Auto transition))

		© 0
TEST SIMULATION NO. 44-21		CLOSE
HALF TONE PROCON STANDARD VALUE REGISTER		
RESULT		
ERROR: K, C, M, Y		
	RESULT	TE

After completion of the operation, the simulation is canceled.

Note

This procedure is to save the copy color balance adjustment data as the reference data for the halftone correction.

Immediately after execution of ADJ 10C (2) (Color balance adjustment, Manual) with SIM 46-21, be sure to execute this procedure.

When ADJ 10C (1) (Color balance adjustment, Auto) is executed with SIM 46- 24, this procedure is automatically executed.

8) Use SIM 44-26 to execute the halftone image corr ection. (Forcible execution)

Enter the SIM 44-26 mode and press [EXECUTE] key. [EXECUTE] key is highlighted and the operation is started.

	0 🗇
TEST SIMULATION NO. 44-26	CLOSE
HALF TONE DENSITY CORRECT EXECUTION	
TOUCH [EXECUTE] THEN EXECUTION START.	
	EXECUTE

It takes several minutes to complete the operation. After completion of the operation, "COMPLETE" is displayed.

(Normal end (Auto transition))

	C	0
TEST SIMULATION NO. 44-26	CL	OSE
HALF TONE DENSITY CORRECT EXECUTION		
RESULT		
COMPLETE		
RESULT	Е	

(Abnormal end (Auto transition))

	© 0
TEST SIMULATION NO. 44-26	CLOSE
HALF TONE DENSITY CORRECT EXECUTION	
ERROR SENSOR ADJUSTMENT	
	EXECUTE

After completion of the operation, the simulation is canceled.

9) Make a copy of th e servicing color test chart (UKOG-0317FCZZ/UKOG-0317FC11) and a use r's document according to necessity in the T ext/Printed Photo mode (Manual) and check the adjustment result a gain. (Refer to the it em of the copy color balance/density check.)

If the copy color balance and density are not adjusted to the specified level, there may be another cause.

Troubleshoot the cause, and rep air or perform proper treatments, and try all the procedures of the print image adjustment from the beginning.



If the color balance is customized, use SIM 63-7 to register the color balance as the service target.

If the color b alance is not customized, t his procedure is not required.

If the customized color balance is registered as the service target, the automatic color balance adjustment can be made in the next color balance adjustment.

10-D Copy / Image send / FAX image quality adjustment (Individual adjustment)

a. General

This adjustment is used to execute the fine adjustment in each mode only when a satisfactory image quality is not obtained by the basic adjustments ADJ 10B and ADJ 10C or there is a request from the user. Normally there is no need to execute this adjustment.

In this adjustment, the adjustment result may be applied to the image send mode and the FAX mode as well as the copy mode.

This must be well understood for execution of the adjustment.

		Copy MODE		IMAGE SEND(SCAN) MODE			MODE				
		Colo	or mode	Mono	ochrome	Colo	or mode	Mono	ochrome		
		Auto	Manual		Manual	Auto	Manual		Manual	FAX	Printer
46-01	Color copy density adjustment (for each color copy mode) (separately for the low- density area and the high-density area) (No need to adjust normally)	0	0	-	-	-	-	-	-	-	-
46-02	Monochrome copy density adjustment (for each monochrome copy mode) (separately for the low-density area and the high-density area) (No need to adjust normally)	-	-	0	0	-	-	-	-	-	-
46-04	Color image send mode image density adjustment (for each mode) (No need to adjust normally)	-	-	-	-	0	0	-	-	-	-
46-05	Monochrome image send mode image density adjustment (for each mode) (No need to adjust normally)	-	-	-	-	-	-	0	0	-	-
46-08	Image send mode RGB color balance adjustment (separately for the low-density area and the high-density area) (No need to adjust normally)	-	-	-	-	0	0	-	-	-	-
46-09	RSPF mode (Copy/Scan/FAX) density adjustment (No need to adjust normally)	0	0	0	0	0	0	0	0	0	-
46-10	Color copy color balance, gamma adjustment (for each color copy mode) (No need to adjust normally)	0	0	-	-	-	-	-	-	-	-
46-16	Monochrome copy density, gamma adjustment (for each monochrome copy mode) (No need to adjust normally)	-	-	0	0	-	-	-	-	-	-
46-19	Automatic monochrome (Copy/Scan/FAX) mode document density scanning operation (exposure operation) conditions setting (Normally no need to set)	-	-	0	-	-	-	0	-	0	-
46-21	Copy color balance and density adjustment (Manual adjustment)	0	0	0	0	-	-	-	-	-	-
46-23	Copy high density image density reproduction setting (Normally unnecessary to the setting change)	0	0	0	0	-	-	-	-	-	-
46-24	Copy color balance and density adjustment (Automatic adjustment)	0	0	0	0	-	-	-	-	-	-
46-25	Copy color balance adjustment (Single color copy mode) (No need to adjust normally)	-	0	-	-	-	-	-	-	-	-
46-26	Single color copy mode color balance default setting	-	0	-	-	-	-	-	-	-	-
46-27	Color copy, text, line image reproduction adjustment (edge gamma, density adjustment) (Text, Map mode) (No need to adjust normally)	0	0	-	-	-	-	-	-	-	-
46-30	Copy mode sub scanning direction resolution setting	0	0	-	-	-	-	-	-	-	-
46-32	Document low density image density reproduction adjustment in the automatic monochrome (Copy/Scan/FAX) mode (No need to adjust normally) (Background density adjustment in the scanning section)	-	-	0	-	-	-	0	-	0	-
46-36	2-color (red, black) copy mode fine color adjustment (No need to adjust normally)	-	0	-	-	-	-	-	-	-	-
46-37	Monochrome (Copy/Scan/FAX) mode color document reproduction adjustment (No need to adjust normally)	-	-	0	0	-	-	0	0	0	O (*3)
46-38	Color copy mode dark area gradation (black component quantity) adjustment (No need to adjust normally)	0	0	-	-	-	-	-	-	-	-
46-39	FAX send image sharpness adjustment	-	-	-	-	-	-	-	-	0	-
46-40	FAX send image density adjustment (Collective adjustment of all the modes)	-	-	-	-	-	-	-	-	0	-

			Сору	MODE		IMAGE SEND(SCAN) MODE					
		Colo	or mode	Mono	ochrome node	Colo	or mode	Mono m	ochrome node		
		Auto	Manual	Auto	Manual	Auto	Manual	Auto	Manual	FAX	Printer
46-41	FAX send image density adjustment (Normal text mode)	-	-	-	-	-	-	-	-	0	-
46-42	FAX send image density adjustment (Fine text mode)	-	-	-	-	-	-	-	-	0	-
46-43	FAX send image density adjustment (Super fine mode)	-	-	-	-	-	-	-	-	0	-
46-44	FAX send image density adjustment (Ultra fine mode)	-	-	-	-	-	-	-	-	0	-
46-45	FAX send image density adjustment (600dpi mode)	-	-	-	-	-	-	-	-	0	-
46-46	FAX send image density adjustment (RGB RIP)	-	-	-	-	-	-	-	-	O (*2)	-
46-47	Copy image, image send image, FAX send image (JPEG) compression ratio setting (Normally unnecessary to the setting change)	0	0	0	0	0	0	0	0	O (*3)	O (*3)
46-51	Gamma manual adjustment for the copy mode heavy paper and the image process mode (dither) (No need to adjust normally)	0	0	0	0	-	-	-	-	-	-
46-52	Gamma default setting for the copy mode heavy paper and the image process mode (dither)	0	0	0	0	-	-	-	-	-	O (*4)
46-54	Copy gamma, color balance adjustment for each dither (Automatic adjustment) (No need to adjust normally)	0	0	0	0	-	-	-	-	-	O (*4)
46-55	Dropout color setting	-	-	-	-	-	-	-	0	-	-
46-58	Pseudo resolution UP function setting	0	0	0	0	-	-	-	-	-	-
46-59	Pseudo resolution UP function adjustment	0	0	0	0	-	-	-	-	-	0
46-60	Color (Copy/Scan) mode sharpness adjustment (No need to adjust normally)	0	0 (1 copy)	-	-	0	-	-	-	-	0
46-61	Area separation recognition level adjustment (No need to adjust normally)	0	O (*1)	0	0 (*1)	0	O (*1)	0	O (*1)	-	-
46-62	ACS, area separation, background image process, automatic exposure mode operation conditions setting (Normally unnecessary to the setting change)	0	0	0	0	0	0	0	0	-	-
46-63	Copy/Scan low density image density adjustment (for each mode) (No need to adjust normally)	0	0	0	0	0	0	0	0	-	-
46-65	Color correction table setting	0	0	-	-	-	-	-	-	-	0
46-66	Watermark adjustment	0	0	0	0	-	-	-	-	-	-
46-74	Printer/Copy color balance and density adjustment (Automatic adjustment) (Basic adjustment)	0	0	0	0	-	-	-	-	-	0
46-90	High-compression PDF image process operation setting (Normally unnecessary to the setting change)	-	-	-	-	0	0	-	-	-	-
46-91	Black text emphasis fine adjustment		-	-	-	0	0	-	-	-	-

*1: Text Printed Photo / Copy document, Text Printed Photo only

*2: Printer RGB save \rightarrow FAX resend only

*3: Printer RGB save only

*4: Only the watermark is related.

10-D (1)

Color copy density adjustment (for each color copy mode) (separately for the lowdensity area and the high-density area) (No need to adjust normally)

The density is adjusted in each copy mode individually. This adjustment must be performed in the following cases:

- * When there is necessity to change the copy density of the low density and high density part at each copy density individually.
- * When there is necessity to change the density gradient of the copy by each the copy mode individually.
- * When there is necessity to change all copy density by each the copy mode individually.
- * When there is request from the user.
- 1) Enter the SIM 46-1 mode.



2) Select the copy mode to be adjusted with the scroll key.

	Display/Item	Content	Setting range	Default	
Α	AUTO	Auto	LOW	1 - 99	50
			HIGH	1 - 99	50
В	TEXT	Text	LOW	1 - 99	50
			HIGH	1 - 99	50
С	TEXT/PRINTED	Text/Printed	LOW	1 - 99	50
	PHOTO	Photo	HIGH	1 - 99	50
D	TEXT/PHOTO	Text/Photograph	LOW	1 - 99	50
			HIGH	1 - 99	50
Е	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
			HIGH	1 - 99	50
F	PHOTOGRAPH	Photograph	LOW	1 - 99	50
			HIGH	1 - 99	50
G	MAP	Мар	LOW	1 - 99	50
			HIGH	1 - 99	50
н	LIGHT	Light document	LOW	1 - 99	50
			HIGH	1 - 99	50
1	TEXT	Text (Copy	LOW	1 - 99	50
	(COPY TO COPY)	document)	HIGH	1 - 99	50
J	TEXT/PRINTED	Text/Printed	LOW	1 - 99	50
	PHOTO	Photo (Copy	HIGH	1 - 99	50
	(COPY TO COPY)	document)	1.014	1 00	
к	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
	(COPY TO COPY)	(Copy document)	HIGH	1 - 99	50
L		lext (Color topo	LOW	1 - 99	50
	(COLOR TONE	(Color lone	HIGH	1 - 99	50
м		Text/Printed	LOW	1_99	50
101	PHOTO	Photo	HIGH	1_99	50
	(COLOR TONE	(Color tone	mon	1 55	00
	ENHANCEMENT)	enhancement)			
Ν	TEXT/PHOTO	Text/Photograph	LOW	1 - 99	50
	(COLOR TONE	(Color tone	HIGH	1 - 99	50
	ENHANCEMENT)	enhancement)			
0	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
	(COLOR TONE	(Color tone	HIGH	1 - 99	50
D		Photograph		1 00	50
Г		(Color tone		1 - 99	50
	ENHANCEMENT)	enhancement)	пібп	1 - 99	50
Q	MAP	Map	LOW	1 - 99	50
_	(COLOR TONE	(Color tone	HIGH	1 - 99	50
	ENHANCEMENT)	enhancement)			
R	SINGLE COLOR	Single color	LOW	1 - 99	50
			HIGH	1 - 99	50
S	SINGLE COLOR	Single color	LOW	1 - 99	50
	(COPY TO COPY)	(Copy document)	HIGH	1 - 99	50
Т	TWO COLOR	Two-color	LOW	1 - 99	50
		(Red/Black) copy	HIGH	1 - 99	50
U	TWO COLOR	Two-color	LOW	1 - 99	50
	(COPY TO COPY)	(Red/Black) copy (Copy document)	HIGH	1 - 99	50

3) Enter the adjustment value with 10-key and press [OK] key. When adjusting the copy density on the low density part, select "LOW" mode and change the adjustment value. When adjusting the copy density on the high density part, select "HIGH" mode and change the adjustment value.

When the adjustment value is increased, the copy density is increased. When the adjustment value is decreased, the copy density is decreased.

4) Make a copy and check the adjustment result.

Switch the adjustment simulation mode and the normal copy mode alternately, and adjust and check the adjustment result. Repeat switching the adjustment simulation mode and the normal copy mode and changing the adjustment value and checking the copy until a satisfactory result is obtained.

10-D (2)

Monochrome copy density adjustment (for each monochrome copy mode) (separately for the low-density area and the high-density area)

(No need to adjust normally)

The density is adjusted in each copy mode individually. This adjustment must be performed in the following cases:

- * When there is necessity to change the copy density of the low density and high density part at each copy density individually.
- * When there is necessity to change the density gradient of the copy by each the copy mode individually.
- * When there is necessity to change all copy density by each the copy mode individually.
- * When there is request from the user.
- 1) Enter the SIM 46-2 mode.

0 🗇 NO. 46-02 IMULATION SURE ADJUSTMENT(B/W)[COPY A: 50 : AUTO1 A: <u>50</u> 50 : AUT02 C. 50 : TEXT ~ 99] D. 50 : TEXT/PRINTED PHOTO E: 50 : TEXT/PHOTO F: 50 : PRINTED PHOTO Ŷ G: 50 : PHOTOGRAPH H: 50 : MAP ŧ I: 50 : TEXT(COPY TO COPY) I: 50 : TEXT/PRINTED PHOTO (COPY TO COPY) K: 50 : PRINTED PHOTO(COPY TO COPY) L: 50 : LIGHT LOW HIGH \mathbb{V} OK



			▼	
				C 0
TEST SIMULATION	N0.	46-02		CLOSE
EXPOSURE ADJUSTME	NT (B/	W)[COP	1	
\square	A	45 :	AUT01	
A: <u>45</u>	В.	50 ÷	AUT02	
[1~99]	c.	50 :	TEXT	
~~~~~~~~~~~	D:	50 :	TEXT/PRINTED PHOTO	
	E:	50 :	TEXT/PHOTO	
	F:	50 :	PRINTED PHOTO	<b>A</b>
	G:	50 :	PHOTOGRAPH	
	H:	50 :	MAP	₽
	Ι:	50 :	TEXT (COPY TO COPY)	
	J:	50 :	TEXT/PRINTED PHOTO(COPY TO COPY)	
	К:	50 :	PRINTED PHOTO(COPY TO COPY)	
	L:	50 :	LIGHT	
LOW		Γ	HIGH 🛛	OK

2) Select the copy mode to be adjusted with the scroll key.

	Display/Item	Content		Setting range	Default
Α	AUTO1	Auto 1	LOW	1 - 99	50
			HIGH	1 - 99	50
В	AUTO2	Auto 2	LOW	1 - 99	50
			HIGH	1 - 99	50
С	TEXT	Text	LOW	1 - 99	50
			HIGH	1 - 99	50
D	TEXT/PRINTED	Text/Printed	LOW	1 - 99	50
	PHOTO	Photo	HIGH	1 - 99	50
Е	TEXT/PHOTO	Text/Photograph	LOW	1 - 99	50
			HIGH	1 - 99	50
F	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
			HIGH	1 - 99	50
G	PHOTOGRAPH	Photograph	LOW	1 - 99	50
			HIGH	1 - 99	50
Н	MAP	Мар	LOW	1 - 99	50
			HIGH	1 - 99	50
Т	TEXT	Text (Copy	LOW	1 - 99	50
	(COPY TO COPY)	document)	HIGH	1 - 99	50
J	TEXT/PRINTED	Text/Printed	LOW	1 - 99	50
	PHOTO	Photo (Copy	HIGH	1 - 99	50
	(COPY TO COPY)	document)			
к	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
	(COPY TO COPY)	(Copy document)	HIGH	1 - 99	50
L	LIGHT	Light document	LOW	1 - 99	50
			HIGH	1 - 99	50

3) Enter the adjustment value with 10-key and press [OK] key. When adjusting the copy density on the low density part, select "LOW" mode and change the adjustment value. When adjusting the copy density on the high density part, select "HIGH" mode and change the adjustment value.

When the adjustment value is increased, the copy density is increased. When the adjustment value is decreased, the copy density is decreased.

4) Make a copy and check the adjustment result. Switch the adjustment simulation mode and the normal copy mode alternately, and adjust and check the adjustment result. Repeat switching the adjustment simulation mode and the normal copy mode and changing the adjustment value and checking the copy until a satisfactory result is obtained.

# 10-D (3)

# Color copy color balance, gamma adjustment (for each color copy mode) (No need to adjust normally)

This adjustment is used to execute the color balance adjustment for each density level in each color copy mode.

This adjustment must be performed in the following cases:

- * When there is necessity to change the color balance and gamma by each the copy mode individually.
- * When there is request from the user.

#### 1) Enter the SIM 46-10 mode.



- 2) Select the copy mode to be adjusted with the mode key.
- Select a color to change the adjustment value with the colo r key.
- Select the density level (point) to be adjusted with the scroll key.

	Item/Display	Density level (Point)	Adjustment value range	Default
А	POINT1	Point 1	1 - 999	500
В	POINT2	Point 2	1 - 999	500
С	POINT3	Point 3	1 - 999	500
D	POINT4	Point 4	1 - 999	500
Е	POINT5	Point 5	1 - 999	500
F	POINT6	Point 6	1 - 999	500
G	POINT7	Point 7	1 - 999	500
Н	POINT8	Point 8	1 - 999	500
Ι	POINT9	Point 9	1 - 999	500
J	POINT10	Point 10	1 - 999	500
К	POINT11	Point 11	1 - 999	500
L	POINT12	Point 12	1 - 999	500
М	POINT13	Point 13	1 - 999	500
Ν	POINT14	Point 14	1 - 999	500
0	POINT15	Point 15	1 - 999	500
Р	POINT16	Point 16	1 - 999	500
Q	POINT17	Point 17	1 - 999	500

 Enter the adjustment value with 10-key and press [OK] key. When the adjust ment value is increased, the density is increased. When the adjustment value is decreased, the density is decreased.

When the arrow key is pre ssed, the color densities selected with the color keys are collectively adjusted.

That is, all the density levels (points) from the low density point to the high density point can be adjusted collectively.

When [EXECUTE] key is pressed, the adjustment pattern is printed out.

This adjustment pattern can be used to check the color balance and the density for each density level (point).

6) Make a copy and check the adjustment result.

Switch the adjustment simulation mode and the normal copy mode alternately, and adjust and check the adjustment result. Repeat switching the adjustment simulation mode and the normal copy mode and changing the adjustment value and checking the copy until a satisfactory result is obtained.

### 10-D (4)

# Monochrome copy density, gamma adjustment (for each monochrome copy mode) (No need to adjust normally)

This adjustment is used to execute the density adjustment for each density level in each monochrome copy mode.

This adjustment must be performed in the following cases:

- * When it is required to change the gamma in each copy mode.
- * When there is request from the user.



2) Select the density level (point) to be adjusted with the scroll key.

	Item/Display	Density level (Point)	Adjustment value range	Default
Α	POINT1	Point 1	1 - 999	500
В	POINT2	Point 2	1 - 999	500
С	POINT3	Point 3	1 - 999	500
D	POINT4	Point 4	1 - 999	500
Е	POINT5	Point 5	1 - 999	500
F	POINT6	Point 6	1 - 999	500
G	POINT7	Point 7	1 - 999	500
Н	POINT8	Point 8	1 - 999	500
I	POINT9	Point 9	1 - 999	500
J	POINT10	Point 10	1 - 999	500
К	POINT11	Point 11	1 - 999	500
L	POINT12	Point 12	1 - 999	500
Μ	POINT13	Point 13	1 - 999	500
N	POINT14	Point 14	1 - 999	500
0	POINT15	Point 15	1 - 999	500
Ρ	POINT16	Point 16	1 - 999	500
Q	POINT17	Point 17	1 - 999	500

 Enter the adjustment value with 10-key and press [OK] key. When the a djustment value is incr eased, the density is increased. When the adjustment value is decreased, the density is decreased.

When the arrow key is pressed, the densit ies are collectively adjusted.

That is, all the density levels (points) from the low density point to the high density point can be adjusted collectively.

When  $\left[ \text{EXECUTE} \right]$  key is pressed, the adjustment pattern is printed out.

The density at each density leve I (point) can be checked by referring to this printed adjustment pattern. However, it is more practical to make a copy and check it.

This adjustment pattern can be used to check the color balance and the density for each density level (point).

4) Make a copy and check the adjustment result.

Switch the adjustment simulation mode and the normal copy mode alternately, and adjust and check the adjustment result.

Repeat switching the adjustment simulation mode and the normal copy mode and changing the adjustment value and checking the copy until a satisfactory result is obtained.

# 10-D (5)

# Automatic monochrome (Copy/Scan/FAX) mode document density scanning operation (exposure operation) conditions setting (Normally no need to set)

Use for setting the condition of read operation (Exposure) for document density in monochrome auto copy mode.

When a copy with correct density is not obtained by type of document, change the setting.

This setting is required in the following cases.

- * When a proper density copy is not obtained in the monochrome automatic copy mode.
- * When a document with images near its lead edge is copied.
- * When a document with colored background is copied.
- 1) Enter the SIM 46-19 mode.

					© 0
TEST SIMULATION	NO. 46-19				CLOSE
EXPOSURE MODE SET	UP (B/W-AE)				
AE_MODE		MODE 1	MODE2		
AE_STOP_COPY	· [	REALTIME	STOP	PRESCAN	
AE_STOP_FAX	· [	OFF	ON		
AE_STOP_SCAN	· [	REALTIME	STOP	PRESCAN	
AE_FILTER	· [	SOFT	NORMAL	SHARP	
AE_WIDTH	:	FULL	PART		4
					3
					1
					1

 Set REALTIME, STOP or PRE-SCAN to a djustment item AE STOP COPY. For contents of each setting item, refer to below. Change the setting value of "AE WIDTH" item to "FULL" or "PART", in some cases.

Display/Item	Content	Set value	Default
AE_MODE	Auto exposure mode	MODE1, MODE2	MODE1
AE_STOP_COPY	Auto B/W exposure Stop (for copy)	REALTIME/ STOP/PRESCAN	STOP
AE_STOP_FAX	Auto B/W exposure Stop (for FAX)	ON/OFF	ON
AE_STOP_SCAN	Auto B/W exposure Stop (for scanner)	REALTIME/ STOP/PRESCAN	STOP
AE_FILTER	Auto exposure filter	SOFT	NORMAL
	setting	NORMAL	
		SHARP	
AE_WIDTH	AE exposure width	FULL	FULL
		PART	

# Note

MODE1: High gamma (Improves the image contrast)

MODE2: Normal gamma

STOP:

Reads the density of 3 - 7 mm area from leading edge of document, decides the output image density according to the density of that part. (The output image density is constant at whole area.) REALTIME:

Reads the density of wid th of the document one by one, decides the output image density accord ing to the density of each part of the document. (The output image density may be not const ant at whole area.)

### PRESCAN:

Once the densities on the document surface are scanned, the output image density is deter mined according to the average of the scanned densities. (The output image den sity is even for all the surface.)

# AE WIDTH FULL:

Document density reading area in monochrome auto mode is 3 - 7 mm (leading edge of document) x Document width. No relationship to PRESCAN MODE

#### AE WIDTH PART:

Document density reading area in monochrome auto mode is 3 - 7 mm (leading edge of document) x 100 mm (width). No relationship to PRESCAN MODE

#### Operation in monochrome auto copy mode:

When the density of the document of the read area is light, output image density is increased by control. When the density of the document of the read area is dark, output image density is decreased by control.







# 10-D (6)

# Document low density image density reproduction adjustment in the automatic monochrome (Copy/Scan/FAX) mode (No need to adjust normally) (Background density adjustment in the scanning section)

Use for the reproducibility adjustment of document background density in monochrome auto copy mode.

This adjustment is required in the following cases.

- * When there is a desire not to reproduce the background of the document. When there is a desire to reproduce the low density image of the document.
- * When there is request from the user.
- 1) Enter the SIM 46-32 mode.



- 2) Select the adjustment mode with the scroll key.
- 3) Enter the adjustment value with 10-key and press [OK] key. When the adjustment value is increased, r eproducibility of the background and the low density image is increased. When the adjustment value is decreased, reproducibility of the background and the low density image is decreased.

Display/Item		Content	Set value	Default
Α	COPY : OC	Copy mode (for OC)	1 - 250	196
В	COPY : RSPF	Copy mode (for RSPF)	1 - 250	196
С	SCAN : OC	Scanner mode (for OC)	1 - 250	196
D	SCAN : RSPF	Scanner mode (for RSPF)	1 - 250	196
ш	FAX : OC	FAX mode (for OC)	1 - 250	196
F	FAX : RSPF	FAX mode (for RSPF)	1 - 250	196

# 10-D (7) Copy/Scan low density image density adjustment (for each mode) (No need to adjust normally)

This adjustment is used to adjust the image density in the low density area in the copy/scanner mode.

This adjustment is required in the following cases.

- * When there is a desire not to reproduce the background of the document. When there is a desire to reproduce the low density image of the document.
- * When there is request from the user.
- 1) Enter the SIM 46-63 mode.



#### 2) Select the copy mode to be adjusted with the scroll key.

	Display/Item	Content	Set value	Default
A	COLOR COPY : TEXT/PRINTED PHOTO	Text print (color copy)	1 - 9	3
В	COLOR COPY : TEXT	Text (color copy)	1 - 9	3
С	COLOR COPY : PRINTED PHOTO	Printed photo (color copy)	1 - 9	5
D	COLOR COPY : PHOTOGRAPH	Photograph (color copy)	1 - 9	5
E	COLOR COPY : TEXT/PHOTO	Text/Photograph (color copy)	1 - 9	3
F	COLOR COPY : MAP	Map (color copy)	1 - 9	5
G	COLOR COPY : LIGHT	Light document (color copy)	1 - 9	6
Н	COLOR COPY : TEXT/PRINTED PHOTO (COPY TO COPY)	Copy document, Text print (color copy)	1 - 9	5
Ι	COLOR COPY : TEXT (COPY TO COPY)	Copy document, Text (color copy)	1 - 9	5
J	COLOR COPY : PRINTED PHOTO (COPY TO COPY)	Copy document, Printed photo (color copy)	1 - 9	5
к	COLOR PUSH:TEXT/ PRINTED PHOTO	Text print (color PUSH)	1 - 9	3
L	COLOR PUSH:TEXT	Text (color PUSH)	1 - 9	3

	Display/Item	Content	Set value	Default
М	COLOR PUSH:	Printed photo	1 - 9	5
	PRINTED PHOTO	(color PUSH)		
Ν	COLOR PUSH:	Photograph	1 - 9	5
	PHOTOGRAPH	(color PUSH)		
0	COLOR PUSH:	Text/Photograph	1 - 9	3
	TEXT/PHOTO	(color PUSH)		
Ρ	COLOR PUSH: MAP	Map (color PUSH)	1 - 9	5

3) Enter the adjustment value with 10-key and press [OK] key.

When the adjustment value is increased, r eproducibility of the background and the low density image is increased. When the adjustment value is decreased, reproducibility of the background and the low density image is decreased.

### 10-D (8)

# Color copy, text, line image reproduction adjustment (edge gamma, density adjustment) (Text, Map mode) (No need to adjust normally)

### Adjustment 1

By changing Text/Printed Photo, Text/Photograph, automatic copy mode Text, line image edge se ction gamma and the density, the reproducibility of text and line profile can be varied optionally.

With this adjustment, the density and the thickness of fine text and lines can be varied.

Check the result of this adjustment by text/printed photo copy mode (manual).

This adjustment is required in the following cases.

- * When the rep roducibility of text and line copy image is to be changed.
- * When there is request from the user.
- 1) Enter the SIM 46-27 mode.



#### 2) Select the mode to be adjusted with the scroll key.

	Display/Item (Copy mode)	Content	Adjust- ment range	Default	
A	(SLOPE)	Black character edge gamma skew adjustment	1 - 99	50	
E	BLACK TEXT (INTERCEPT)	Black character edge density adjustment	1 - 99	50	
C	COLOR TEXT (SLOPE)*1	Color character edge gamma skew adjustment	1 - 99	50	
C	COLOR TEXT (INTERCEPT)	Color character edge density adjustment	1 - 99	50	
E	ED TEXT (SLOPE)	Text/Map mode gamma adjustment (Text/Map mode)	1 - 99	50	
F	ED TEXT (INTERCEPT)	Text/Map mode density adjustment (Text/Map mode)	1 - 99	50	

#### 3) Enter the adjustment value with 10-key.

When the adjustment values of item A and C are changed, the gamma at the line edge section is changed.

When the adjustment value is increased, the image contrast of character edge and line edge is increased. When the adjustment value is decreased, the image contrast of character and line edge is decreased.

When the adjustment value of the adjustment item B and D are increased, the image den sity at the line e dge section is increased, and vice versa.

- 4) Press [OK] key.
- 5) Make a copy in mono chrome text/printed photo copy mode (manual), check the copy.

When checking, use a copy of the document with a thin character and line image.

If a satisfactory result is not obtained, return to the SIM 46-27 mode and change the adjustment value.

Repeat the above procedures until a satisfactory result is obtained.

#### Adjustment 2

This adjustment is used to change the gamma and the density in the Text/Map copy mode.

This adjustment is required in the following cases.

- * To change the con trast and the density of the T ext/Map copy mode images.
- * When there is request from the user.

#### 1) Enter the SIM 46-27 mode.



2) Select the mode to be adjusted with the scroll key.

Display/Item (Copy mode)		Content	Adjust- ment range	Default
A	BLACK TEXT (SLOPE)	Black character edge gamma skew adjustment	1 - 99	50
В	BLACK TEXT (INTERCEPT)	Black character edge density adjustment	1 - 99	50
С	COLOR TEXT (SLOPE)*1	Color character edge gamma skew adjustment	1 - 99	50
D	COLOR TEXT (INTERCEPT)	Color character edge density adjustment	1 - 99	50
E	ED TEXT (SLOPE)	Text/Map mode gamma adjustment (Text/Map mode)	1 - 99	50
F	ED TEXT (INTERCEPT)	Text/Map mode density adjustment (Text/Map mode)	1 - 99	50

3) Enter the adjustment value with 10-key.

When the adjustment value of the adjustment item  ${\sf E}$  is changed, the gamma (contrast) is changed.

When the adjustment value is incr eased, the contrast is increased, and vice versa.

When the adjustment value of the adjustment item F is increased, the image density is increased, and vice versa.

- 4) Press [OK] key.
- 5) Make a copy in the Text/Map copy mode (manual), and check the output print.

If a satisfactory result is not obtained, use SIM46-27 to change the adjustment value.

Repeat the above procedures until a satisfactory result is obtained.

# 10-D (9) Monochrome (Copy/Scan/FAX) mode color document reproduction adjustment (No need to adjust normally)

Use to adjust the reproducibility for the red image and the yellow image when printing color document th at included the red/yellow image in monochrome copy mode.

This adjustment is required in the following cases.

- * When there is desire t o change reproducibility of yellow/red image in case of making a color copy of the color document in monochrome copy mode.
- * When there is request from the user.
- 1) Enter the SIM 46-37 mode.



2) Select the mode to be adjusted with the scroll key.

Display/Item (Copy mode)		Content	Adjustment range	Default
А	R/G	Gray making setting (R/G)	0 - 99	21
В	B/G	Gray making setting (B/G)	0 - 99	0

3) Enter the adjustment value with 10-key.

When the adjustment value of adjustment item A is increased, copy density of red image is decreased. When the adjustment value is decreased, copy density of red image is increased. When the adjustment value of adjustment item B is increased, copy density of red image is increased. When the adjustment value is decreased, copy density of red image is decreased.

- 4) Press [OK] key.
- Make a copy in monochrom e text/printed photo copy mode (manual), check the copy.

If a satisfactory result is not obtained, return to the SIM 46-37 mode and change the adjustment value.

Repeat the above procedures until a satisfactory result is obtained.

# <u>10-D</u> (10)

# Color copy mode dark area gradation (black component quantity) adjustment (No need to adjust normally)

Use to adjust the black ingredient amount in the color copy mode. (except character and line image)

As a result of this adju stment, the gradation of the shad e part changes.

This adjustment is required in the following cases.

- * When reproduction as solid of black image is required.
- * To make the black background and the dark area darker
- * When change of gradation of the shade part is required.
- * When there is request from the user.
- 1) Enter the SIM 46-38 mode.



- 2) Select the AUTO MODE or the MANUAL MODE with the mode key.
- 3) Select the mode to be adjusted with the scroll key.

Display/Item (Copy mode)		Select button	Content	Default
MANUAL	TEXT PRT	(-) LUT2	Text print	NORMAL
		(-) LUT1	(Manual)	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	TEXT	(-) LUT2	Text (Manual)	NORMAL
		(-) LUT1		
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	PRINTED	(-) LUT2	Printed photo	NORMAL
	PHOTO	(-) LUT1	(Manual)	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	PHOTO	(-) LUT2	Photograph	NORMAL
		(-) LUT1	(Manual)	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	TEXT PHOTO	(-) LUT2	Text/	NORMAL
		(-) LUT1	Photograph	
		NOMAL	(Manual)	
		(+) LUT1		
		(+) LUT2		
	MAP	(-) LUT2	Map (Manual)	(+) LUT1
		(-) LUT1		
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	CP ORG/	(-) LUT2	Сору	NORMAL
	TEXT PRT	(-) LUT1	document/	
		NOMAL	Text printed	
		(+) LUT1	(Manual)	
		(+) LUT2		
	COPY ORG/	(-) LUT2	Сору	NORMAL
	TEXT	(-) LUT1	document/	
		NOMAL	Text (Manual)	
		(+) LUT1		
		(+) LUT2		
	COPY ORG/	(-) LUT2	Сору	NORMAL
	PHOTO	(-) LUT1	document/	
		NOMAL	Printed photo	
		(+) LUT1	(Manual)	
		(+) LUT2	1	
	LIGHT	(-) LUT2	Light	(+) LUT1
	ORIGINAL	(-) LUT1	document	
		NOMAL	(Manual)	
		(+) LUT1	1	
		(+) LUT2	1	

Display/Ite	m (Copy mode)	Select button	Content	Default
AUTO	AUTO0	(-) LUT2	Auto mode	NORMAL
		(-) LUT1	judgment 0	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	AUTO1	(-) LUT2	Auto mode	NORMAL
		(-) LUT1	judgment 1	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	AUTO2	(-) LUT2	Auto mode	NORMAL
		(-) LUT1	judgment 2	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	AUTO3	(-) LUT2	Auto mode	NORMAL
		(-) LUT1	judgment 3	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	AUTO4	(-) LUT2	Auto mode	NORMAL
		(-) LUT1	judgment 4	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	AUTO5	(-) LUT2	Auto mode	NORMAL
		(-) LUT1	judgment 5	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	AUTO6	(-) LUT2	Auto mode	NORMAL
		(-) LUT1	judgment 6	
		NOMAL		
		(+) LUT1		
		(+)       <b>T</b> 2		

 Press the black ingredient amount select button.
 When reproduction as solid of black image is required: Selects + button

When there is desire to darken copy of black image: Selects + button

When a dark color image is reproduced in the black: Selects - button

5) Make a copy in color copy mode and check the copy.

If a satisfactory result is not obtained, return to the SIM 46-38 mode and change the adjustment value.

Repeat the above procedures until a satisfactory result is obtained.

# 10-D (11) Color (Copy/Scan) mode sharpness adjustment (No need to adjust normally)

Use for sharpness adjustment of the high density image in color copy mode.

This adjustment changes smoothness (asperity) in the image shade part.

#### 1) Enter the SIM 46-60 mode.



2) Select the mode to be adjusted with the scroll key.

	Display/Item		Content		Setting range	Default	NOTE
Α	SCREEN FILTER	Н	Sharpness (filter) adjustment of dot pattern	Strong emphasis	1	3 (Auto)	Apply to auto copy mode
	LEVEL	L	image in auto copy mode	Soft emphasis	2		only
		AUTO		Auto	3		
В	AUTOMODE	SOFT	Sharpness (filter) adjustment for the auto	SOFT	1	2	
	FILTER LEVEL	CENTER	copy mode	CENTER	2	(CENTER)	
		HIGH		HIGH	3		
С	COLOR COPY:	OFF	Soft filter applying setting to C, M, Y image	OFF	0	1 (ON)	Available for the high
	CMY	ON	in color copy mode	ON	1		density image except
D	COLOR COPY:K	OFF	Soft filter applying setting to K image in	OFF	0	1 (ON)	text and line image
		ON	color copy mode	ON	1		
Е	SINGLE COLOD:	OFF	Soft filter applying setting to C, M, Y image	OFF	0	1 (ON)	When setting ON,
	CMY	ON	in single color copy mode	ON	1		smoothness in the image
F	2 COLOR COPY:	OFF	Soft filter applying setting to C, M, Y image	OFF	0	1 (ON)	shade part improves by
	CMY	ON	in 2-color copy mode	ON	1		applying soft filter.
G	2 COLOR COPY:	OFF	Soft filter applying setting to K image in	OFF	0	1 (ON)	(asperity decreases)
	К	ON	color copy mode	ON	1		
н	B/W COPY	OFF	Soft filter applying setting in monochrome	OFF	0	1 (ON)	
		ON	copy mode	ON	1		
Ι	COLOR PUSH:	OFF	Soft filter applying setting to image in push	OFF	0	1 (ON)	
	RGB	ON	scan color mode	ON	1		
J	B/W PUSH	OFF	Soft filter applying setting to image in push	OFF	0	1(ON)	
		ON	scan monochrome mode	ON	1		

Input numeric value corr esponding to sharp ness level (filter process mode).

When selecting AUTO, filter is selected according to dot pattern state automatically and adjusts sharpness.

Adjustment item A:

- This adjustment is required in the following cases.
- * When changing the shar pness of copy image in copy mode. (obtain crispy image) (decreases moire)
- * When there is desire to improving smoothness in the image shade part (for decrease of asperity)
- * To make the black background and the dark area darker.
- * To reproduce the gradation change in the dark area.
- * When there is request from the user.

Input small numeric value to obtain crispy image. Input large numeric value to decrease moire.

- Adjustment item B: Select HIGH to obtain clear images. Select SOFT to reduce moire.
- Adjustment item C J:

When setting ON, smoothness in the image shade part improves by applying soft filter. (asperity decreases)

- 4) Press [OK] key.
- 5) Make a copy and check the copy image.

If a satisfactory result is not obtained, return to the SIM 46-60 mode and change the adjustment value.

Repeat the above procedures until a satisfactory result is obtained.

# 10-D (12)

# Copy high density image density reproduction setting (Normally unnecessary to the setting change)

If a tone gap occurs on part of high density in copy mode, or if there is necessity to increase the density of the p art of high density, change the setting.

This setting is normally not  $\boldsymbol{r}$  equired. When, howe ver, there are case of following, change the setting.

- * When a tone gap occurs on part of high density.
- * When there is a necessity to incr ease the density of the part of high density.
- * When there is request from the user.

# a. Adjustment procedure

1) Enter the SIM 46-23 mode.



2) Select the item A, B with the scroll key.

Display/Item			Content	Setting range	Default
A	CMY (0:ENABLE 1:DISABLE)	0	CMY engine maximum density correction mode Enable	0 1	0
		1	CMY engine maximum density correction mode Disable	0-1	0
В	K (0: ENABLE	0	K engine maximum density correction mode Enable	0 1	1
	1: DISABLE)	1	K engine maximum density correction mode DIsable	0-1	I
С	CYAN MAX TARGET	Sca ma	anner target value for CYAN ximum density correction	0 - 999	500
D	MAGENTA MAX TARGET	Sca MA cor	anner target value for GENTA maximum density rection	0 - 999	500
E	YELLOW MAX TARGET	Sca YEI cor	anner target value for LLOW maximum density rection	0 - 999	500
F	BLACK MAX TARGET	Sca BL/ cor	anner target value for ACK maximum density rection	0 - 999	500

- * If a tone gap occurs on part of high density, set 0 to item A and B The density of high density p art decreases. Howe ver, the tone gap is better.
- * In case of more increase of the density on high density part, set 1 to item A and B.

The tone gap may occur in high density part.

# Important

Do not change the setting values of item C, D, E and F. If these values are changed, density of the high density part is changed.

If these values are changed, be sure to execute the copy color balance density adjustment. (Auto adjustment)

# 10-D (13)

# Copy color balance adjustment (Single color copy mode) (No need to adjust normally)

This adjustment is used to set the color balance and the density in the single color copy mode to the user's request.

The adjustment is made by changing Y, M, C components of each color.

This adjustment is not required normally, but executed when there is a request from the user.

When the default adjust ment value is changed, this adjustment is required in the following cases.

- * When it is required to change the color balance in the single color copy mode.
- * When there is request from the user.

#### a. Adjustment procedure

1) Enter the SIM 46-25 mode.



- 2) Select the color to be adjusted with the scroll key.
- 3) Select the color (YMC) to be adjusted with the color key.
- 4) Enter the adjustment value with 10-key.

	Dianlay/Itam	Adjustment renge		Default	
	Display/item	Aujustment range	С	м	Y
А	RED	0 - 255	0	255	200
В	GREEN	0 - 255	255	0	255
С	BLUE	0 - 255	255	200	0
D	YELLOW	0 - 255	0	0	255
ш	MAGENTA	0 - 255	0	255	0
F	CYAN	0 - 255	255	0	0

- 5) Press [OK] key.
- 6) Make a copy in the single color copy mode and check the copy.

If a satisfactory result is not obtained, return to the SIM 46-25 mode and change the adjustment value.

Repeat the above procedures until a satisfactory result is obtained.

# 10-D (14)

# RSPF mode (Copy/Scan/FAX) density adjustment (No need to adjust normally)

This setting is normally not required, however, in the following cases, make changes to the setting:

- * When copy in RSPF mode differs from copy in document table mode.
- * When copy density in RSPF mode is low or too high.
- * When the RSPF unit is replaced.
- * When the RSPF unit is disassembled.
- * The CCD unit has been replaced.
- * U2 trouble has occurred.
- * When the MFP PWB is replaced.
- * When the EEPROM on the MFP PWB is replaced.
- a. Adjustment procedure
- 1) Enter the SIM 46-9 mode.



F, 53 · FAX HIGH

 Select the mode to be adjusted with the scroll key.
 When adjusting density on low density part, select "A (COPY LOW)". When adjusting density on high density part, select "D (COPY HIGH)".

I	ltem/Display	Content	Setting range	Default
A	COPY : LOW	RSPF copy mode exposure adjustment (Low density side)	1 - 99	48
В	SCAN : LOW	RSPF scanner mode exposure adjustment (Low density side)	1 - 99	48
С	FAX : LOW	PSPF FAX mode exposure adjustment (Low density side)	1 - 99	48
D	COPY : HIGH	RSPF copy mode exposure adjustment (High density side)	1 - 99	53
E	SCAN : HIGH	RSPF scanner mode exposure adjustment (Low density side)	1 - 99	53
F	FAX : HIGH	RSPF FAX mode exposure adjustment (High density side)	1 - 99	53

3) Enter the adjustment value with 10-key.

In case of increase of image density, input large numeric value. Or in case of diluting the image density, input small numeric value.

- 4) Press [OK] key.
- 5) Make a copy in the RSPF mode and check the copy.

If a satisfactory result is not obtained, return to the SIM 46-9 mode and change the adjustment value.

Repeat the above procedures until a satisfactory result is obtained.

10-D (15)

# Automatic color balance adjustment by the user (Copy color balance automatic adjustment ENABLE setting and adjustment)

#### a. General

In the user program mode, the user can execute the auto color calibration (auto adjustment of the copy color balance and density). This adjustment is to set Enable/Disable of the above user operation with SIM 26-53.

# Important

This setting must b e set to EN ABLE only when the user's understanding on the automat ic adjustment of the copy color balance and density and the user's operational ability are judged adequate enough to execute the adjustment.

When set to enable, operation procedures must be fully explained to the user.

#### b. Setting procedure

1) Enter the SIM 26-53 mode.



2) Select ENABLE or DISABLE with 10-key.

When disabling, set to "0" (N  $\,$  O). When enabling, set to "1" (Yes).

3) Press [OK] key.

When set to DISABLE, the menu of the user auto color calibration (automatic adjustment of copy color balance and density) is not displayed in the user program mode.

# (Auto color calibration by the user (Auto color balance adjustment))

# Important

This adjustment is based on the service target color balance set with SIM 63-7 and SIM 63-8. If, therefore, the ab ove settings are not properly performed, this adjustment cannot be made properly.

- 1) Enter the system setting mode.
- 2) Enter the copy setting mode.
- 3) Press the auto color calibration key.
- Press [EXECUTE] key.

The color patch image (adjustment pattern) is printed out.

 Set the color patch image (adjustment pattern) printed in procedure 4) on the document table.

Set the patch image so that the thin line is on t he left side as shown in the figure.

At that time, place 5 sheets of white paper on the above color patch image (adjustment pattern).



 Press [EXECUTE] key, and the copy color balance adjustment is executed automatically. After completion of the adjustment, the display returns to the original operation screen.

To execute the printer color balance adjustment successively, perform the procedures same as the above.

# 10-D (16) Copy gamma, color balance adjustment for each dither (Automatic adjustment)

#### a. General

This simulation is used to improve the image quality in  $\ \ a \ \ certain$  mode. (Refer to the list in procedure 6.)

# b. Adjustment procedures

- 1) Enter the SIM46-54 mode.
- 2) Press [EXECUTE] key.

A4/11" x 8.5" or A3/11" x 17" paper is automatically selected. The color patch image (adjustment pattern) is printed.

3) Set the patch image (adjustment pattern) printed in the procedure 2) on the document t able so that the thin lines on the printed patch image (adjustment pattern) are on the left side. Place 5 sheets of white p aper on the printed p atch image (adjustment pattern).



4) Press [EXECUTE] key.

The color balance and the density are automatically adjusted. The adjustment pattern is printed out. Check it for any abnormality.

5) Press [OK] key.

The list of the adjustment items (for each dither) is displayed.

6) Select an adjustment item (for each dither).

Select item (Mode/ Image)	Content
Heavy Paper*1	Adjustment item to improve the color balance
Black Edge	Adjustment item (K) to improve the reproduction of lines, text density, and thickness
Color Edge	Adjustment item (Color) to improve the reproduction of lines, text density, and thickness
B/W	Adjustment item to improve the density and gradation in the monochrome text mode and the map mode.
Color Ed	Adjustment item to improve the color balance in the text mode and the map mode.
B/W 600dpi	Adjustment item to improve the density and gradation in the monochrome printed photo mode and the photography mode.

*1: When performing adjustments in the heavy paper mode, load paper in the manual paper feed tray.

7) Press [EXECUTE] key.

A4/11" x 8.5" or A3/11" x 17" paper is automatically selected. The patch image (adjustment pattern) is printed out.

In the monochrome mode, only the monochrome p attern is printed.

8) Set the patch image (adjustment pattern) printed in the procedure 7) on the document t able so that the thin lines on the printed patch image (adjustment pattern) are on the le ft side. Place 5 sheets of w hite paper on the printed patch image (adjustment pattern).



9) Press [EXECUTE] key.

The color balance and the density are automatically adjusted, and the machine goes to the state of procedure 6). To complete the adjustment and enable the adjustment result, press [OK] key.

 Make a copy, and check the copy image quality. (Refer to the item of the printer color balance and density check.)

# Note

Use SIM46-52 to reset the adjustment values to the default values.

# 10-E Printer image quality adjustment (Basic adjustment)

Requisite condition before execution of the printer color balance/density adjustment

Before execution of the printer color balance/density adjustment, the copy color balance/density adjustment must have been completed properly.

#### This adjustment is required in the following cases.

- * Basically same as when the copy color balance/density adjustment is required.
- * After the copy color balance/density adjustment.

# 10-E (1)

# Printer color balance adjustment (Automatic adjustment)

#### a. General

The color balance adjustment (auto adjustment) is used to adjust the print density of each color (Cyan, Magenta, Yellow, Black) automatically with SIM 67-24 or the user program.

When this adjustment is executed, the color balance adjustments of all the print modes are revised.

There are following two modes in the auto color balance adjustment.

- 1) Auto color balance adjustment by the serviceman (SIM 67-24 is used.)
- Auto color balance adjustment by the user (The user program mode is used.) (The color balance target is the service target.) The auto color balance adjustment by the user is provided to reduce the number of service calls.

If the print color balance is lost for some reasons, the user can use this color balance adjustment to recover the balance.

When, however, the machine has a fatal problem or when the machine condition is greatly changed, this function does not work effectively.

On the other hand, the auto color balance adjustment by the serviceman functions to recover the normal color balance though the machine condition is greatly changed. If the machine has a fatal problem, repair and adjust it for obtaining the normal color balance.

To perform the adjustment, the above difference must be fully understood.

#### b. Adjustment procedure

(Auto color balance adjustment by the serviceman)

Printer color balance and density adjustment (Automatic adjustment) procedure flowchart (SIM67-24)



#### 1) Enter the SIM 67-24 mode.



2) Press [EXECUTE] key. (A4/11" x 8.5" or A3/11" x 17" paper is automatically selected.)

The color patch image (adjustment pattern) is printed out.

3) Set the color patch image (adjustment pattern) paper printed in procedure 2) on the document table.

Place the printed color patch image (adjustment pattern) paper on the document table so that the thin lines on the paper are on the left side. Place 5 sheet s of white paper on the printed color patch image (adjustment pattern) paper.



4) Select [FACTORY] key, and press [EXECUTE] key. When the color balance is customized with the manual color balance adjustment (SIM 67-25) according to the user's request and the color balance is registered as the service target with SIM 67-27, if the color balance is adjusted to that color balance, select the service target.

	1	2 0
TEST SIMULATION NO. 67-24	[	CLOSE
PRINTER ENGINE HALFTONE AUTO ADJUSTMENT MODE (REGULAR)		
PLEASE SELECT THE MODE(FACTORY) OR (SERVICE) AND PLACE		
TEST PRINTED TEST PATCH ON DOCUMENT GLASS THEN PRESS [EXECUTE]		
*LIGHT AREA AT LEFT SIDE ON DOCUMENT GLASS		
FACTORY	EXECUTE	)

The copy color balance adjustment is automatically executed and prints the color balance check patch image. Wait until the operation panel shown in the procedure 5) is displayed.



5) Press [OK] key on the operation panel.

	© 0
TEST SIMULATION NO. 67-24	CLOSE
PRINTER ENGINE HALFTONE AUTO ADJUSTMENT MODE (REGULAR)	
CONFIRM THE ADJUSTED PATCH AND PRESS [OK] TO REGISTER THIS PATCH DATA	
	OK

# Note

After pressing [OK] key, the initial setting of the halftone image correction is started. During the operation, "NOW REGISTER-ING THE NEW TARGET OF HALFTONE" is displayed. This operation takes several minutes.

After completion of the operation, "PLEASE QUIT THIS MODE" is displayed.

Do not cancel the simulation until "PLEASE QUIT THIS MODE" is displayed.

	0 🗇
TEST SIMULATION NO. 67-24	CLOSE
PRINTER ENGINE HALFTONE AUTO ADJUSTMENT MODE (REGULAR)	
COMPLETED THIS PROCEDURE.	
PLEASE QUIT THIS MODE.	

After completion of the operation, the simulation is canceled.

6) Check the color balance and density.

(Refer to the item of the printer color balance and density check.)

When satisfactory color balance and density are not obtained from the automatic adjustment by selecting the factory target in procedure 4), change the factory color balance target with SIM 67-26 and repeat the procedures from 1).

If a satisfactory result on the color ba lance and the density is not obtained with the automatic adjustment, execute the manual adjustment (SIM 67-25) (ADJ 10E (2)).

Also when the service target is selected in procedure 4) to execute the automatic adjustment and a satisfactory result is not obtained, perform the manual color balance adjustment (ADJ 10E (2)).

If the color balance or density is not in the satisfactor y level even after execution of the automatic and man ual adjustments, there may be another cause.

Troubleshoot the cause, rep air or perform necessary works, and repeat the adjustment from the beginning.

# 10-E (2)

# Printer color balance adjustment (Manual adjustment)

#### a. General

The color b alance adjustment (Manual adjustment) is used to adjust the printer density of C, M, Y and K. This is used at the following situation. When the r esult of auto adjustment descr ibed above is not existing within the range of reference. When a fine adjustment is required. When the re is request from the user for changing (customizing) the color balance.

In this manual adjustment, adjust only the color patch which could not adjusted properly in the automatic adjustment.

If the color balance is improper, execute the automatic color balance adjustment in advance, and execute this adjustment for better efficiency.

#### b. Adjustment procedure




2) Press [EXECUTE] key. (A4/11" x 8.5" or A3/11" x 17" paper is automatically selected.)

The color balance adjustment pattern is printed.

 Check that the following specification is satisfied or the color balance is satisfactory.

If not, execute the following procedures.



The print density must be changed gradually from the lighter level to the darker level. The density changing direction must not be reversed.

The density level of each color must be almost at the same level.

Patch B may not be copied.

Patch A must not be copied.

When, however, the color balance is adjusted according to a request from the user, there is no need to set to the standard color balance stated above.

If the color balance of each patch of the process black (CMY mixed color) is slightly shifted to Magenta, it means that the adjustment is proper. In an actual pr int mode, it is converted into the natural gray color balance by the color t able. (When the color balance target is DEF 1.)

- Select the color to be adjusted with the color select key, and select the adjustment point with the scroll key.
- 5) Enter the adjustment value with 10-key and press [OK] key. The adjustment value is set in the range of (1 - 999). When SIM 67-24 is used to adju st the automatic color balance and density, all the set values of this simulation are set to 500.

To increase the density, increase the adjustment value. To decrease the density, decrease the adjustment value.

Repeat procedures of 2) - 5) until the condition of 3) is satisfied.

When the overall density is low, or when the density is high and patch A is copied, use the arrow key to adjust all the adjustment values of A - Q (MAX) to a same level collectively.

Then, adjust each patch density individually. This is an efficient way of adjustment.

Referring to the black/gray patches, adjust so that each process (CMY) black/gray patch color balance of A - Q (MAX) approaches the black/gray patch level as far as possible. 6) Check the color balance and density.

(Refer to the item of the printer color balance and density check.)  $\label{eq:color}$ 



If the color balance is customized, use SIM 67-27 to r egister the color balance as the service target.

If the color balance is not customized, this procedure is not required.

If the customized color balance is registered as the service target, the automatic color balance adjustment can be made in the next color balance adjustment.

# **10-F** Printer image quality adjustment (Individual adjustment)

#### a. General

This adjustment is used to execute the fine adjustment in each mode only when a satisfactory image quality is not obtained by the basic adjustments ADJ 10E (1) and ADJ 10E (2) or there is a request from the user. Normally there is no need to e xecute this adjustment.

This must be well understood for execution of the adjustment.

### 10-F (1)

### Printer density adjustment (Low density section density adjustment) (No need to adjust normally)

This adjustment is used to adjust the image density in the low density area in the printer mode.

Adjust to reproduction setting of the low density image.

This adjustment is required in the following cases.

- * When it is required not to reproduce images in the low density section, or to reproduce low-density images.
- * When there is request from the user.
- 1) Enter the SIM 67-36 mode.



 Enter the adjustment value and press the [OK] key. In case of increase of the image density on low density part, increase the adjustment value. For diluting the image density on low density part, decrease the adjustment value.

### 10-F (2)

### Printer high density image density reproduction setting (Supporting the high density section tone gap) (No need to adjust normally)

When a tone gap is generated in the high densit y section in the printer mode, the setting is changed to lower the density in the high density section.

This setting is normally not required, however, in the following cases, a change of setting must be made.

- * When a tone gap occurs on part of high density.
- * To lower the density in the high density section.

### a. Adjustment procedure

1) Enter the SIM 67-34 mode.







2) Select the item A, B with the scroll key.

Display/Item			Content	Setting range	Default
A	CMY (0: ENABLE 1:DISABLE)	0	CMY engine maximum density correction mode Enable	0 - 1	0
		1	CMY engine maximum density correction mode Disable		
В	K (0:ENABLE 1: DISABLE)	0	K engine maximum density correction mode Enable	0 - 1	1
		1	K engine maximum density correction mode Disable		
С	CYAN MAX TARGET	Sca CY/ cor	anner target value for AN maximum density rection	0 - 999	500

Display/Item		Content	Setting range	Default
D	MAGENTAMAX TARGET	Scanner target value for MAGENTA maximum density correction	0 - 999	500
E	YELLOW MAX TARGET	Scanner target value for YELLOW maximum density correction	0 - 999	500
F	BLACK MAX TARGET	Scanner target value for BLACK maximum density correction	0 - 999	500

* If a tone gap occurs on part of high density, set 0 to item A and B The density of high density part decreases. However, the tone gap is better.

* In case of more increase of the density on high density part, set 1 to item A and B.

The tone gap may occur in high density part.

### Important

If the setting values of item C, D, E and F are changed, density of the high density part is changed.

When these values are changed, be sure to perform the printer color balance and density adjustment. (Automatic adjustment)

### 10-F (3)

### Printer gamma adjustment for each dither (Automatic adjustment) (No need to adjust normally)

#### a. General

This adjustment is used to adjust the color balance and the density in the mono chrome mode, the he avy paper mode, and the g loss paper mode.

This simulation is used to improve image quality in these modes and images.

### b. Adjustment procedures

- 1) Enter the SIM67-54 mode.
- 2) Press [EXECUTE] key.

A4/11" x 8.5" or A3/11" x 17" paper is automatically selected. The color patch image (adjustment pattern) is printed out.

3) Set the color p atch image (adjustment p attern) printed in the procedure 2) on the document t able so that the thin lines on the printed color patch image (adjustment pattern) are on the left side. Place 5 sheets of white paper on the printed color patch image (adjustment pattern).



4) Press [EXECUTE] key.

The color balance adjustment is automatically performed. The adjustment pattern is printed out. Check it for any abnormality.

5) Press [OK] key.

The list of the adjustment items (for each dither) is displayed.

6) Select an adjustment item (for each dither).

Select item (Mode/Image)	Content
Heavy Paper	Adjustment item to improve the color balance in the heavy paper mode
B/W	Adjustment item to improve the density and gradation in the monochrome mode
Gloss Paper	Adjustment item to improve the color balance in the gloss paper mode
1200dpi 1bit	Adjustment item to improve the color balance in 1200dpi mode

#### 7) Press [EXECUTE] key.

A4/11" x 8.5" or A3/11" x 17" paper is automatically selected. The color patch image (adjustment pattern) is printed out.

8) Set the color patch image (adjustment pattern) printed in the procedure 7) on the document table so that the thin lines on the printed color patch image (adjustment pattern) are on the left side. Place 5 sheets of white paper on the printed color patch image (adjustment pattern).



9) Press [EXECUTE] key.

The color balance adjustment is automatically performed, and the machine goes to the state of procedure 6).

10) When [OK] key is pressed, the adjustment result is registered and the adjustment mode is terminated. When [EXECUTE] key is pressed, the adjustment r esult is registered and the screen is shifted to the other item (Mode/Image) select menu.

To execute the adjustment of the other item (Mode/Image), press [EXECUTE] key.

After completion of all the adjustments of the items (Mode/ Image), press [OK] key, and the adjustment results are registered.

 Make a print, and check the print image quality. (Refer to the item of the printer color balance and density check.)

### Note

Use SIM67-52 to reset the adjustment values to the default values.

10-F (4)

### Automatic color balance adjustment by the user (Printer color balance automatic adjustment ENABLE setting and adjustment) (Normally unnecessary to the setting change)

#### a. General

In the user program mode, the user can execute the auto color calibration (auto adjustment of the printer color balance and density). This adjustment is to set Enable/Disable of the above user operation with SIM 26-53.

### Important

This setting must be set to EN ABLE only when the user's understanding on the automat ic adjustment of the copy color balance and density and the user's operational ability are judged enough to execute the adjustment.

When set to enable, operation procedures must be fully explained to the user.

### b. Setting procedure

### 1) Enter the SIM 26-53 mode.



2) Select ENABLE or DISABLE with 10-key.

When disabling, set to "0"  $\,$  (NO). When enabling , set to "1" (Yes).

3) Press [OK] key.

When set to DISABLE, the menu of the user auto color calibration (automatic adjustment of printer color balance and density) is not displayed in the user program mode.

(Auto color calibration by the user (Auto color balance adjustment))

### Important

This adjustment is based on the service target color balance set with SIM 67-27 or S IM 67-28. If, therefore, the above settings are not properly performed, this adjustment cannot be made properly.

- 1) Enter the system setting mode.
- 2) Enter the printer setting mode.
- 3) Press the auto color calibration key.
- 4) Press [EXECUTE] key.

The color patch image (adjustment pattern) is printed out.

5) Set the color patch image (adjustment pattern) printed in procedure 4) on the document table.

Set the patch image so that the thin line is on t he left side as shown in the figure.

At that time, place 5 sheets of white paper on the above color patch image (adjustment pattern).



6) Press [EXECUTE] key, and the printer color balance adjustment is executed automatically.

To execute the copy color balance adjustment successively, perform the procedures same as the above.

### ADJ 11 Paper size sensor adjustment

## 11-A Manual paper feed tray paper size (width) sensor adjustment

This adjustment must be performed in the following cases:

- * The manual paper feed tray section has been disassembled.
- * The manual paper feed tray unit has been replaced.
- * U2 trouble has occurred.
- * The PCU PWB has been replaced.
- * The EEPROM of the PCU PWB has been replaced.

#### 1) Enter the SIM 40-2 mode.



Open the manual paper feed guide to the maximum width position.



3) Press [EXECUTE] key.

[EXECUTE] key is high lighted. Then it returns to the normal display.

The maximum width position d etection level of the manual paper feed guide is recognized.

- 4) Set the manual paper feed guide to the A4 size.
- 5) Press [EXECUTE] key.

[EXECUTE] key is high lighted. Then it returns to the normal display.

The A4 size width position detection level of the manual paper feed guide is recognized.

- 6) Set the manual paper feed guide to the width for the A4R size.
- Press [EXECUTE] key. [EXECUTE] key is high lighted. Then it returns to the normal display.

Set the manual paper feed guide to the width for the A4R size.

- Open the manual paper feed guide to the minimum width position.
- 9) Press [EXECUTE] key.

[EXECUTE] key is high lighted. Then it returns to the normal display.

The minimum width position detection level of the manual paper feed guide is recognized.

If the above operation is not completed nor mally, "ERROR" is displayed.

When the operation is completed normally, the above data are saved to the memory and "COMPLETE" is displayed.

# 11-B RSPF paper feed tray document size (width) sensor adjustment

This adjustment must be performed in the following cases:

- * The RSPF paper feed tray section has been disassembled.
- * The RSPF paper feed tray unit has been replaced.
- * When a U2 trouble occurs.
- * The scanner PWB has been replaced.
- * The EEPROM on the scanner PWB has been replaced.
- 1) Enter the SIM 53-6 mode.

	© 0
TEST SIMULATION NO. 53-06	CLOSE
SPF TRAY ADJUSTMENT TRAYVOLMAX TRAY ADJUSTMENT.	
PRESS [EXECUTE] TO START	
EXECU	TE

2) Open the RSPF paper feed guide to the maximum width position.



3) Press [EXECUTE] key.

The maximum width detection level is recognized.

- 4) Open the RSPF paper feed guide to the width for the A4R size.
- Press [EXECUTE] key. The A4R width detection level is recognized.
- 6) Open the RSPF paper feed guide to the width for the A5R size.
- Press [EXECUTE] key. The A5R width detection level is recognized.
- 8) Open the RSPF paper feed guide to the minimum width position.
- 9) Press [EXECUTE] key.

The minimum width detection level is recognized.

* When each of the above operations has been complete d, the "COMPLETE" message appears; when any of the operations has failed, the "ERROR" message appears.

### ADJ 12 Document size detection adjustment

This adjustment must be performed in the following cases:

- * When the original size sensor section has been disassembled.
- * When the original size sensor section has been replaced.
- * When U2 trouble has occurred.
- * When the scanner control PWB is replaced.
- * When the EEPROM on the scanner control PWB is replaced.

### 12-A Document size sensor detection point adjustment

1) Enter the SIM 41-1 mode.



Loosen the original cover switch actuator adjustment scr ew and slide the actuator position so that t he display OCSW is returned to the normal display when the height of the arm unit top from the table glass is  $20.2 \pm 0.25$ mm by slowly tilting the document detection arm unit in the arrow direction and adjust. (If the ON timing of the original cover switch is shifted, the document detection function may malfunction.)



# 12-B Adjust the sensitivity of the original size sensor

#### 1) Enter the SIM41-2 mode.



- Execute the sensor adjustment without document.
   With the document cover open, without placing a document on the table glass, press [EXECUTE] key.
- Place A3 (11" x 17") paper on the document table and press [EXECUTE] key.

If the adjustment is completed normally, "DOCUMENT SIZE PHOTO SENSOR LEVEL IS ADJUESTED" is displayed.

### ADJ 13 Touch panel coordinate setting

- This adjustment must be performed in the following cases:
- * The operation panel has been replaced.
- * U2 trouble has occurred.
- * The scanner control PWB has been replaced.
- * The EEPROM on the scanner control PWB has been replaced.
- 1) Enter the SIM 65-1 mode.



2) Precisely press the cross mark points (4 positions).

When the cross mark is pressed precisely, a buzzer sounds and the display is reversed. When all the four points are pressed and the touch panel adjustment is completed, the display returns to the simulation sub number entry screen.

In case of a n error, the display returns to the entry screen again.

Check to confirm that ther e is no shift between the display frame and the detection position when the touch p anel is pressed.

* When pressing the touch panel, never use a sharp tip (such as a needle or a pin).

### ADJ 14 Fusing paper guide position adjustment

Normally there is no need to perform this adjustment. In the following cases, perform this adjustment.

- * When a paper jam occurs in the fusing section.
- * When wrinkles are made on paper in the fusing section.
- * When an image deflection or an image blur is generated in the paper rear edge section.
- Loosen the fusing paper guide fixing screws on the two positions in the front/rear frame direction.
- Use the fusing paper guide position scale as the reference to shift the paper guide in the arrow direction A or B.



The standard fixing position is at two scales in direction B from the marking scale center. However, the position may be varied depending on the situation.

- * When a wrinkle is made on paper, change the position in the error direction A.
- * When an image deflection or unclear image is generated in the lead edge area of p aper, change the position in the arrow direction B.

### ADJ 15 Print image position, image magnification ratio, void area, off-center adjustment (Print engine) (Manual adjustment)

Note

Normally if the adjustment is executed by ADJ 4 (automatic adjustment), there is no need to execute this adjustment.

Only when the manual adjustment is required, execute this adjustment.

In other words, this manual adjustment is executed when a satisfactory result is not obtained from the automatic adjustment (ADJ 4).

### 15-A Print image magnification ratio adjustment (main scanning direction) (Print engine) (Manual adjustment)

This adjustment must be performed in the following cases:

- * When the LSU (writing) unit is replaced.
- * U2 trouble has occurred.
- * The PCU PWB has been replaced.
- * The EEPROM of the PCU PWB has been replaced.
- 1) Enter the SIM 50-10 mode.



- 2) Set A4 (11" x 8.5") paper in the paper feed tray.
- 3) Select the paper feed tray set in procedure 2) with the scroll key.
- Press [EXECUTE] key. The check pattern is printed out.

5) Check that the inside dimension of the printed halftone is 240  $\pm$  0.5mm.



If the above requirement is not met, do the following steps.

- 6) Change the set value of set item A.
  - When the set value is changed by 1, the dimension is changed by 0.1mm.

When the set value is increased, the BK image magnification ratio in the main scanning direction is increased. When the set value is decreased, the BK image magnification ratio in the main scanning direction is decreased.

Repeat procedures 2) - 6) until a satisfactory result is obtained.

# **15-B** Print image print area adjustment (Print engine) (Manual adjustment)

This adjustment must be performed in the following cases:

- * When the LSU is replaced or removed.
- * When a paper tray is replaced.
- * When the paper tray section is disassembled.
- * When the manual feed tray is replaced.
- * When the manual feed tray is disassembled.
- * When the duplex mode paper transport section is disassembled.
- * When the registration roller section is disassembled.
- * U2 trouble has occurred.
- * The PCU PWB has been replaced.
- * The EEPROM of the PCU PWB has been replaced.

### Note

Before execution of this adjustment, be sure to execute the print image magnification r atio adjustment (ADJ 15A) (main scanning direction) (print engine) (manual adjustment).



- 2) Set A4 (11 x 8.5") paper to all the paper feed trays. Select an adjustment item of the target paper feed tray among items B N and enter t he adjustment value. T hen select item "O" to select the paper feed tray which is to be used for executing test printing.
- 3) Press [EXECUTE] key.

The adjustment pattern is printed.

4) Check the adjustment pattern to confirm that the items below are in the range of the standard values.

	Content	Standard adjustment value
Х	Lead edge void area	4.0 ± 1.0mm
Y	Rear edge void area	2.0 - 5.0mm
Z1/Z2	FRONT/REAR void area	$2.0\pm2.0$ mm



If the above condition is not satisfied, or if it is set to a desired condition, execute the simulation 50-1.

### Note

Feed paper from all the paper feed trays to confirm.

5) Enter the SIM 50-1 mode.

				<b>©</b> 0
TEST SIMULATION	NO. 5	50-01		CLOSE
LEAD EDGE ADJUSTN	MENT V	ALUE		
	A:	50 :	RRCA	
A: 50	B	50 :	RRCB-CS12	
[0~99]	C.	50 :	RRCB-CS34	
	D:	50 :	RRCB-LCC	
	E:	50 :	RRCB-MFT	
	F:	50 :	RRCB-ADU	1
	G:	30 :	LEAD	
	H:	20 :	SIDE	
	Ι:	40 :	DENA	
	J:	30 :	DENB	
	К:	20 :	FRONT/REAR	
	L:	50 :	OFFSET_OC	
				OK
				rc 0
TEST SIMULATION	NO. 3	50-01		CLOSE
TEST SIMULATION LEAD EDGE ADJUSTM	NO. S	50-01 ALUE		CLOSE
TEST SIMULATION	NO. 3 MENT V	50-01 ALUE 60 :	RRCA	© 0 CLOSE
TEST SIMULATION	NO. 3 MENT V	50-01 ALUE 60 : 50 :	RRCA RRCB-CS12	CLOSE
$\begin{array}{c} \hline \hline$	NO. 3 MENT V B: C:	50-01 ALUE 50 : 50 :	RRCA RRCB-CS12 RRCB-CS34	C O
$\frac{\overline{\text{TEST}} \text{SIMULATION}}{\text{LEAD} EDGE ADJUSTM}$ A: 60 [ 0 ~ 99 ]	NO. 3 MENT V B: C: D:	50-01 ALUE 50 : 50 : 50 :	RRCA RRCB-CS12 RRCB-CS34 RRCB-LCC	CLOSE
$\frac{\overline{\text{TEST}} \text{SIMULATION}}{\text{LEAD} \text{ Edge Adjust}}$ A: 60 [ 0 ~ 99 ]	NO. 3 MENT V B: C: D: E:	50-01 ALUE 50 : 50 : 50 : 50 :	RRCA RRCB-CS12 RRCB-CS34 RRCB-LCC RRCB-MFT	© 0 CLOSE
$\begin{array}{c} \hline 115T\\ \hline 115T\\ EDGE & ADJUST\\ \hline A: \hline 60\\ \hline 0 & \sim 99 \end{array}$	NO. I MENT V B: C: D: E: F:	50-01 ALUE 50 : 50 : 50 : 50 : 50 :	RRCA RRCB-CS12 RRCB-CS34 RRCB-LCC RRCB-MPT RRCB-ADU	
$\frac{11551}{11551}$ SIMULATION LEAD EDGE ADJUSTI A: 60 [ 0 ~ 99 ]	NO. 3 MENT V A: B: C: D: E: F: G:	50-01 ALUE 50 : 50 : 50 : 50 : 50 : 30 :	RRCA RRCB-CS12 RRCB-CS34 RRCB-LCC RRCB-LCC RRCB-ADU LEAD	
$\frac{1}{1} \sum_{i=1}^{n} \text{Simulation} \\ \text{Eade Edge Adjusts} \\ A: 60 \\ [0 ~ 99 ]$	NO. 3 MENT V B: C: D: E: F: G: H:	50-01 ALUE 50 : 50 : 50 : 50 : 30 : 20 :	RRCA RRCB-CS12 RRCB-CS34 RRCB-LCC RRCB-MPT RRCB-MPT LEAD SIDE	
TEST         SIMULATION           LEAD         EDGE         ADJUSTI           A:         60         0 ~ 99 ]	NO. 1 MENT V A: B: C: E: F: G: H: I:	50-01 ALUE 50 : 50 : 50 : 50 : 30 : 30 : 30 :	RRCA RRCB-CS12 RRCB-CS34 RRCB-LCC RRCB-ADU LEAD SIDE DENA	CLOSE
$\frac{1}{1000} SIMULATION$ $A: 60$ $[0 - 99]$	NO. 3 HENT V B: D: E: F: G: H: I: J:	50-01 ALUE 50 : 50 : 50 : 50 : 50 : 30 : 20 : 30 : 40 :	RRCA RRCB-CS12 RRCB-CS34 RRCB-LCC RRCB-MFT RRCB-ADU LEAD SIDE DENA DENB	
$\frac{1151^{\circ}}{1160^{\circ}}$ SIMULATION A: 60 [ 0 ~ 99 ]	NO. 3 HENT V B: D: E: F: G: H: I: J: K:	50-01         ALUE         60       :         50       :         50       :         50       :         50       :         30       :         30       :         30       :         20       :         20       :         20       :	RRCA RRCB-CS12 RRCB-CS12 RRCB-CS34 RRCB-LCC RRCB-NPT RRCB-NPT RRCB-ADU LEAD SIDE SIDE DENA DENA DENA DENA	
$\frac{\overline{1851}}{1184} \text{SIMULATION}$ $A: 60$ $[0 \sim 99]$	NO. 3 MENT V B: D: E: F: G: H: I: J: L:	50-01 ALUE 50 : 50 : 50 : 50 : 50 : 30 : 30 : 40 : 20 : 30 : 3	RRCA RRCB-CS12 RRCB-CS34 RRCB-LCC RRCB-LCC RRCB-ADU LEAD SIDE DENA DENA DENA DENA DENA DENA DENA DE	

 Select an adjustment item (DENA, DENB, FRONT/REAR) with the scroll key, enter the adjustment value, and press [OK] key.

Item/Display		Content	Setting range	Default value
Void area adjustment	DENA	Lead edge void area adjustment	1 - 99	40
	DENB	Rear edge void area adjustment	1 - 99	30
	FRONT/ REAR	FRONT/REAR void area adjustment	1 - 99	20
Sub scanning	DENB-MFT	Manual feed correction value	1 - 99	50
direction	DENB-CS1	Tray 1 correction value	1 - 99	50
print area	DENB-CS2	Tray 2 correction value	1 - 99	50
correction	DENB-CS3	Tray 3 correction value	1 - 99	50
value	DENB-CS4	Tray 4 correction value	1 - 99	50
	DENB-LCC	LCC correction value	1 - 99	50
	DENB-ADU	ADU correction value	1 - 99	50
	DENB-HV	Heavy paper correction value	1 - 99	50

When the adjustment value is increased, the void a rea is increased. When the adjustment value is de creased, the void area is decreased.

When the adjustment value is changed by 1, the void area is changed by 0.1mm.

### Note

The adjustment value and the actual void area are related as follows:

Adjustment value/10 = Actual void area

### Note

When the amount of the rear edge void is different between each paper feed tray, change the adjustment value of item (DENB-XXX) in SIM50-1 and adjust.

The adjustment item (DENB) have a effect on the paper of all paper feed tray.

That is, adjustment value of item (DENB-XXX) fine adjusts to adjustment item (DENB) for each paper tray.

After execution of the above, perform procedures 1) - 4) to check that the void area is within the specified range.

Though the lead edge void area adjustment value is proper, if the lead edge void ar ea is not within the specified range, change the adjustment value of item (RRCB-XXX) in SIM 50-1.

Repeat the above procedures until a satisfactory result is obtained.

### 15-C Print image off-center adjustment (Print engine) (Manual adjustment)

This adjustment must be performed in the following cases:

- * When the LSU is replaced or removed.
- * When a paper tray is replaced.
- * When the paper tray section is disassembled.
- * When ADJ 3A Print engine image magnification ratio adjustment (Main scanning direction) is performed.
- * When the manual feed tray is replaced.
- * When the manual feed tray is disassembled.
- * When the duplex mode paper transport section is disassembled.
- * When the registration roller section is disassembled.
- * U2 trouble has occurred.
- * The PCU PWB has been replaced.
- * The EEPROM of the PCU PWB has been replaced.

### Note

Before execution of this adjustment, check to insu re the following item.

- * The print image magnification ration adjustment (ADJ 15A) (main scanning direction) (Print engine) (Manual adjustment) has been properly adjusted.
- 1) Enter SIM 50-10 mode.



2) Select the target paper feed tray (MAIN-XX) with the scroll key.

Display/Item	Content	Setting range
NO	Not select	1

- Set A4 (11" x 8.5") paper in the paper feed tray selected in procedure 2).
- Press [EXECUTE] key.

The adjustment pattern is printed.

5) Check that the adjustment pattern image is printed in the correct position.

Measure the dimension of the void area in the front and the rear frame direction of the adjustment pattern, and check that all the following conditions are satisfied.



RV: REAR VOID AREA

FV: FRONT VOID AREA

 $RV + FV \le 4.0mm$ 

- RV = 2.0  $\pm$  2.0mm
- $\text{FV} = 2.0 \pm 2.0 \text{mm}$

If the above requirement is not met, do the following steps.

6) Change the adjustment value.

Enter the adjustment value and press the [OK] key or the [EXECUTE] key.

When [EXECUTE] key is pressed, the adjustment pattern is printed.

When the adjustment value is increased, the adjustment pattern is shifted to the front frame side. When it is decreased, the adjustment pattern is shifted to the rear frame side.

When the set value is changed by 1, the shift distance is changed by about 0.1mm.

Repeat procedures 3) - 6) until the conditions of procedure 5) are satisfied.

In case a satisfactory result cannot be obtained by repeating the above procedures, perform the following procedure.

7) Loosen the paper feed tray of f-center adjustment scr ews (2 pcs.) at the center section of the lift plate of the paper feed tray, and change the gear unit position in the front/rear frame direction. Repeat the adjustment procedures from 4).



### Note

Normally if the adjustment is executed by ADJ 4 (automatic adjustment), there is no need to execute this adjustment.

Only when the manual adjustment is required, execute this adjustment.

In other words, this manual adjustment is executed when a satisfactory result is not obtained from the automatic adjustment (ADJ 4).

### ADJ 16 Scan image magnification ratio adjustment (Manual adjustment)

### Note

Normally if the adjustment is executed by ADJ 4 (automatic adjustment), there is no need to execute this adjustment.

Only when the manual adjustment is required, execute this adjustment.

In other words, this manual adjustment is executed when a satisfactory result is not obtained from the automatic adjustment (ADJ 4).

### **16-A** Scan image magnification ratio adjustment (main scanning direction) (Manual adjustment) (Document table mode)

### Important

If the default adjustment value of the scan image magnification ration adjustment (main scanning direction) of SIM 48-1, copy image quality may be degraded. Therefore, this adjustment must be executed only when there is a special necessity. This adjustment must be performed in the following cases:

- * When the copy magnification ratio in the copy image main scanning direction is not properly adjusted.
- * When the scanner motor is replaced.
- * U2 trouble has occurred.
- * When the scanner control PWB is replaced.
- * When the EEPROM of the scanner control PWB is replaced.

Before this adjustment, the focus adjustment ( CCD unit installing position adjustment) must have been completed.

1) Place a scale on the document table as shown in the figure below.



2) Enter the SIM 48-1 mode.

			₪ 0
TEST SIMULATION N	NO. 48-01		CLOSE
MAGNIFICATION ADJUS	STMENT		
$\square$	A: 50:	CCD (MAIN)	
A: <u>50</u>	B: 50 :	CCD (SUB)	
[ 1 ~ 99 ]	C: 50 :	SPF (MAIN)	
1	D: 50 :	SPF (SUB)	
1	E: 50 :	SPFB(MAIN)	
1	F: 50 :	SPFB (SUB)	1
			-
			•
			OK

- Make a normal copy and obtain the copy magnification ratio. Press [CLOSE] key to shift from the simulation mode to the copy mode, and make a copy.
- 4) Check that the copy magnificati on ratio is within the specified range ( $100 \pm 1.0\%$ ).

If the copy magnification ratio is within the specified range (100  $\pm$  1.0%), the adjustment is completed. If the copy magnification ratio is not within the specified range, per form the following procedure.

 Change the CCD (MAIN) adjustment value of Simulation 48-1. When the adjustment value is increased, the copy magnification ratio is increased.

When the adjustment value is changed by 1, the copy magnification ratio is changed by about 0.02%.

Repeat the procedures 3) - 5) until the copy magnification ratio is within the specified range (100  $\pm$  1.0%).

### **16-B** Scan image magnification ratio adjustment (sub scanning direction) (Manual adjustment) (Document table mode)

This adjustment must be performed in the following cases:

- * When the copy magnification ratio in the copy image sub scanning direction is not properly adjusted.
- * When the scanner motor is replaced.
- * U2 trouble has occurred.
- * When the scanner control PWB is replaced.
- * When the EEPROM of the scanner control PWB is replaced.
- 1) Place a scale on the document table as shown in the figure below.



### 2) Enter the SIM 48-1 mode.



 Make a normal copy and obtain the copy magnification ratio. Go to the copy mode, and make a copy.



4) Check that the copy magnificati on ratio is within the specified range (100  $\pm$  1.0%).

If the copy magnification ratio is within the specified range (100  $\pm$  1.0%), the adjustment is completed. If the copy magnification ratio is not within the specified range, per form the following procedure.

 Change the CCD (SUB) adjustment value of Simulation 48-1. When the adjustment value is increased, the copy magnification ratio in the sub scanning direction is increased. When the adjustment value is changed by 1, the copy magnification ratio is changed by about 0.1%.

Repeat the procedures 3) - 5) until the copy magnification r atio is within the specified range (100  $\pm$  1.0%).

### 16-C Scan image magnification ratio adjustment (main scanning direction) (Manual adjustment) (RSPF mode)

This adjustment must be performed in the following cases:

- * When the scan control PWB is replaced.
- * When the EEPROM on the scan control PWB is replaced.
- * When U2 trouble occurs.
- * When the copy magnification ratio of the RSPF mode copy image in the main scanning direction is not proper.
- * When the RSPF is disassembled.

#### a. Adjustment procedures

1) Place the duplex adjustment chart shown below on the document tray of the RSPF.

The adjustment chart is prepared by the following procedures. Use A4 (11"  $\times 8.5$ ") paper, and put marks on both sides and both surfaces of the paper at 10mm from each edge.



- 2) Make a duplex copy at the normal ratio on A4 paper.
- 3) Measure the images on the co py paper and the original images.



4) Obtain the image magnification ratio according to the following formula:

Image magnification ratio = Original size / Original size x 100 (%)

Image magnification ratio = 99 / 100 x 100 = 99 (%)

If the image magnification ratio is within the specified range (100  $\pm$  0.8%), there is no need to perform the adjustment.

If it is not within the specified range, perform the following procedures.

5) Enter the SIM 48-1 mode.



Item	Display	Content	Setting range	Default value
A	CCD(MAIN)	SCAN main scanning magnification ratio adjustment (CCD)	1 - 99	50
В	CCD(SUB)	SCAN sub scanning magnification ratio adjustment (CCD)	1 - 99	50
С	SPF(MAIN)	RSPF document front surface magnification ratio adjustment (Main scan)	1 - 99	50
D	SPF(SUB)	RSPF document front surface magnification ratio adjustment (Sub scan)	1 - 99	50
E	SPFB(MAIN)	RSPF document back surface magnification ratio adjustment (Main scan)	1 - 99	50
F	SPFB(SUB)	RSPF document back surface magnification ratio adjustment (Sub scan)	1 - 99	50

6) Select an adjustment item of SPF (MAIN)/SPFB (MAIN) with the scroll key.

SPF (MAIN)	Main scanning direction image magnification ratio (Front surface)
SPFB (MAIN)	Main scanning direction image magnification ratio (Back surface)

7) Enter an adjustment value with 10-key, and press [OK] key. When the adjustment value is increased, the image magnification ratio is increased. When the adjustment value is changed by 1, the image magnification ratio is changed by 0.02%.

Make a normal copy and obtain the copy magnification ratio.
 Repeat the procedures of 1) - 8) until a satisfactor y result is obtained.

### 16-D Scan image magnification ratio adjustment (sub scanning direction) (Manual adjustment) (RSPF mode)

This adjustment must be performed in the following cases:

- * When the SCAN CONTROL PWB is replaced.
- * When the EEPROM on the SCAN CONTROL PWB is replaced.
- * When U2 trouble occurs.

RSPF

- * When the copy magnification ra tio of the R SPF mode copy image in the sub scanning direction is not proper.
- * When the RSPF is disassembled.
- Place the duplex adjustment chart shown below on the document tray of the RSPF.

The adjustment chart is prepared by the following procedures. Use A4 (11" x 8.5") paper, and put marks on both sides and both surfaces of the paper at 10mm from each edge.





- 2) Make a duplex copy at the normal ratio on A4 paper.
- Measure the images on the co py paper and the original images.



 Obtain the image magnification ratio according to the following formula:

Image magnification ratio = Original size / Original size x 100 (%)

Image magnification ratio = 99 / 100 x 100 = 99 (%)

If the image magnification ratio is  $% (100\pm0.8\%),$  within the specified range (100 $\pm$ 0.8%), there is no need to perform the adjustment.

If it is not within the specified range, perform the following procedures.

5) Enter the SIM 48-1 mode.



Item	Display	Content	Setting range	Default value
A	CCD(MAIN)	SCAN main scanning magnification ratio adjustment (CCD)	1 - 99	50
В	CCD(SUB)	SCAN sub scanning magnification ratio adjustment (CCD)	1 - 99	50
С	SPF(MAIN)	RSPF document front surface magnification ratio adjustment (Main scan)	1 - 99	50
D	SPF(SUB)	RSPF document front surface magnification ratio adjustment (Sub scan)	1 - 99	50
E	SPFB(MAIN)	RSPF document back surface magnification ratio adjustment (Main scan)	1 - 99	50
F	SPFB(SUB)	RSPF document back surface magnification ratio adjustment (Sub scan)	1 - 99	50

6) Select an adjustment item with the scroll key.

 SPF (SUB)
 Sub scanning direction image magnification ratio (Front surface)

 SPFB (SUB)
 Sub scanning direction image magnification ratio

(Back surface)

 Enter an image magnification ratio adjustment value with 10key, and press [OK] key.

When the adjustment value is increased, the image magnification ratio is increased.

When the adjustment value is changed by 1, the image magnification ratio is changed by 0.1%.

8) Make a normal copy and obtain the copy magnification ratio.

Repeat the procedures of 1) - 8) until a satisfactor y result is obtained.

### ADJ 17 Scan image off-center adjustment (Manual adjustment)

### Note

Normally if the adjustment is executed by ADJ 4 (automatic adjustment), there is no need to execute this adjustment.

Only when the manual adjustment is required, execute this adjustment.

In other words, this manual adjustment is executed when a satisfactory result is not obtained from the automatic adjustment (ADJ 4).

## 17-A Scan image off-center adjustment (Manual adjustment) (Document table mode)

This adjustment must be performed in the following cases:

- * When the scanner (reading) section is disassembled.
- * When the scanner (reading) unit is replaced.
- * When a U2 trouble occurs.
- * When the scanner control PWB is replaced.
- * When the EEPROM on the scanner control PWB is replaced.
- 1) Make a copy of the adjustment chart (made by yourself) in the adjustment mode (document table).



2) Check the copy image center position.

If A - B =  $\pm$  1.0mm, the adjustment is not required.



If the above condition is not satisfied, perform the following procedures.

#### 3) Enter the SIM 50-12 mode.



- 4) Select the adjustment mode OC with the scroll key.
- 5) Enter the adjustment value with 10-key, and press [OK] key. The entered value is set.

When the set value is increased, the main scanning print position is shifted to the front side by 0.1mm.

6) Go to the copy mode, and make a copy.

Repeat the procedures of 1) - 6) until the above condition is satisfied.

### 17-B Scan image off-center adjustment (Manual adjustment) (RSPF mode)

This adjustment must be performed in the following cases:

- * When the scan control PWB is replaced.
- * When the EEPROM on the scan control PWB is replaced.
- * When the scanner (reading) section is disassembled.
- * When the scanner (reading) section is replaced.
- * When U2 trouble occurs.
- * When the RSPF section is disassembled.
- * When the RSPF unit is replaced.

### Important

To execute this adjustment, it is required that the ADJ 17A Scan image off-center adjustment (Document table mode) must have been properly adjusted.

1) Prepare the adjustment chart.

Draw a line at the center of the front surface and the back surface of A4 (11" x 8.5") paper in parallel with the paper transport direction.



- Set the adjustment chart to the RSPF.
- Make a duplex copy in the normal magnification ratio from the manual paper feed tray, and check the image position on the front surface and the back surface of the copy paper.



If the difference is within the range of 0  $\pm$  2.7mmm there is no need to perform the adjustment.

If the adjustment is required, perform the following procedures.4) Enter the SIM 50-12 or 50-6 mode.

(SIM50-12)





			© 0
TESTSIMULATION NO.	50-06		CLOSE
LEAD EDGE ADJUSTMENT V	ALUE (S	F)	
	50 :	SIDE1	
<b>50</b>	50 :	SIDE2	
[ 1 ~ 99 ] _{C:}	20 :	LEAD_EDGE (SIDE1)	
D:	20 :	FRONT_REAR (SIDE1)	
E.	30 :	TRAIL_EDGE (SIDE1)	
F:	30 :	LEAD_EDGE (SIDE2)	<b>A</b>
G:	20 :	FRONT_REAR (SIDE2)	L.
н.	20 :	TRAIL_EDGE (SIDE2)	Ŧ
I:	50 :	OFFSET_SPF1	
J:	50 :	OFFSET_SPF2	
К:	50 :	SCAN_SPEED_SPF1	
			ОК



ltem	Display	Content	Setting range	Default value
A	OC	Document table image off- center adjustment	1 - 99	50
В	SPF(SIDE1)	SPF front surface image off- center adjustment	1 - 99	50
С	SPF(SIDE2)	SPF back surface image off- center adjustment	1 - 99	50

A - C: When the adjustment value is increased, the image position is shifted to the rear frame side.
1step = 0.1mm

	ltem	/Display	Content	Setting range	Default value
A	SIDE1		Front surface document scan position adjustment (CCD)	1 - 99	50
В	SIDE2		Back surface document scan position adjustment (CCD)	1 - 99	50
С	Image loss amount	LEAD_EDGE (SIDE1)	Front surface lead edge image loss amount setting	0 - 99	20
D	setting SIDE1	FRONT_REAR (SIDE1)	Front surface side image loss amount setting	0 - 99	20
E		TRAIL_EDGE (SIDE1)	Front surface rear edge image loss amount setting	0 - 99	40
F	Image loss amount	LEAD_EDGE (SIDE2)	Back surface lead edge image loss amount setting	0 - 99	20
G	setting SIDE2	FRONT_REAR (SIDE2)	Back surface side image loss amount setting	0 - 99	20
Н		TRAIL_EDGE (SIDE2)	Back surface rear edge image loss amount setting	0 - 99	40
I	OFFSET_SPF1		RSPF front surface document off-center adjustment	1 - 99	50
J	OFFSET	_SPF2	RSPF back surface document off-center adjustment	1 - 99	50
К	SCAN_S	PEED_SPF1	RSPF document front surface magnification ratio adjustment (Sub scan)	1 - 99	50
L	SCAN_S	PEED_SPF2	RSPF document back surface magnification ratio adjustment (Sub scan)	1 - 99	50

* Item A, B: When the adjustment value is increased, the scan timing is delayed.

- * Item C H: When the adjustment value is increased, the image loss is increased.
- * Item A H: 1 step = 0.1mm change
- * The SPF r ear edge image loss setting is provided for countermeasures against the ca se when shades are produced.
- 5) Select an adjustment mode with the scroll key.

#### (SIM50-12)

SPF(SIDE1)	Front surface mode
SPF(SIDE2)	Back surface mode

### (SIM50-6)

OFFSET SPF1 Front surface mode OFFSET SPF2 Back surface mode

6) Enter an adjustment value with 10-key, and press [OK] key.
 (Change for change in the adjustment value: 0.1mm/step)
 (When the adjustment value is in creased, the print image is shifted to the rear.)

Repeat the procedures of 2) - 6) until a sat isfactory result is obtained.

### ADJ 18 Copy image position and image loss adjustment (Manual adjustment)

### Note

Normally if the adjustment is executed by ADJ 4 (automatic adjustment), there is no need to execute this adjustment.

Only when the manual adjustment is required, execute this adjustment.

In other words, this manual adjustment is executed when a satisfactory result is not obtained from the automatic adjustment (ADJ 4).

### 18-A Copy image position, image loss, and void area adjustment (Manual adjustment) (Document table mode)

This adjustment must be performed in the following cases:

- * When the scanner (reading) section is disassembled.
- * When the scanner (reading) unit is replaced.
- * When the LSU is replaced or removed.
- * When the registration roller section is disassembled.
- * U2 trouble has occurred.
- * The PCU PWB has been replaced.
- * The EEPROM of the PCU PWB has been replaced.
- * The scanner control PWB has been replaced.
- * The EEPROM on the scanner control PWB has been replaced.

### Note

Before executing this adjustment, be sure to confirm that the ADJ 4/ADJ 5 Print engine image skew, image position, image magnification ratio, void area adjustments has been completed normally.

1) Place a scale on the document table as shown in the figure below.

Place a scale so that it is in parallel with the scanning direction and that its lead edge is in contact with the document guide plate.

Place white paper on the document table so that the scale lead edge can be seen.





3) Set RRCA, LEAD, and SIDE to the default values.

	Item/Display			Content		Default value
A	Lead edge adjust-	RRCA	Document lead edge reference		0 - 99	50
В	ment value	RRCB-CS1	Regis- tration	Standard Tray	1 - 99	60
С		RRCB-DSK	motor	Desk	1 - 99	60
D		RRCB-LCC	ON	LCC	1 - 99	60
Е		RRCB-MFT	timing adjust-	Manual paper feed	1 - 99	60
F		RRCB-ADU	ment	ADU	1 - 99	60
G	Image loss area	LEAD	Lead ed loss are	ge image a setting	0 - 99	40
Н	setting value	SIDE	Side ima area adj	age loss ustment	0 - 99	20
I	Void area adjust-	DENA	Lead ed area adj	ge void ustment	1 - 99	40
J	ment	DENB	Rear edge void area adjustment		1 - 99	30
К		FRONT/ REAR	FRONT	REAR void	1 - 99	20
L	Off-center adjust- ment	OFFSET_ OC	OC document off- center adjustment		1 - 99	50
М	Magnifi- cation ratio correction	SCAN_ SPEED_OC	SCAN sub scanning magnification ratio adjustment (CCD)		1 - 99	50
N	Sub scanning	DENB-MFT	Manual feed correction value		1 - 99	50
0	direction print area	DENB-CS1	Tray 1 correction value		1 - 99	50
Ρ	correction value	DENB-CS2	Tray 2 c value	orrection	1 - 99	50
Q		DENB-CS3	Tray 3 c value	orrection	1 - 99	50

Item/Display			Content	Setting range	Default value
R	Sub scanning	DENB-CS4	Tray 4 correction value	1 - 99	50
S	direction print area	DENB-LCC	LCC correction value	1 - 99	50
Т	correction value	DENB-ADU	ADU correction value	1 - 99	55
U		DENB-HV	Heavy paper correction value	1 - 99	50

 Perform the image lead edge reference position adjustment. Shift to the copy mode, and make a copy at each of 100% and 200% in the document table mode.

When the adjustment value of RRCA is proper, the lead edge image from 4.0mm is not copied in either of 10 0% and 200% copy scale.

If not, change and adjust the RRCA value.

(Adjust so that the lead edge im age from 4.0mm is not copied in either of different copy magnification ratios.)

Repeat the above procedures until a satisfactory result is obtained.



5) Image loss adjustment

When the adjustment item of the image loss below is set to the default value, it is adjusted to the st andard state. If it is not in the below standard state, or when it is set to a desired value, change these adjustment items.

Paper lead edge



Void area: 4.0mm, Image loss: 4.0mm

ltem/ Display	Content		Adjustment range	De- fault value	Standard adjustment value
LEAD	Image loss adjustment	Lead edge image loss adjustment	0 - 99	40	4.0 ± 1.0mm
SIDE		Side image loss adjustment	0 - 99	20	2.0 ± 1.0mm

When the adjustment value is incr eased, the image loss is increased. When the adjustment value is decreased, the image loss is decreased.

When the adjustment value is changed by 1, the void area is changed by 0.1mm.

### 18-B Image scanning position adjustment (Manual adjustment) (RSPF mode)

This adjustment must be performed in the following cases:

- * When the scan control PWB is replaced.
- * When the EEPROM on the scan control PWB is replaced.
- * When the scanner (reading) section is disassembled.
- * When the scanner (reading) section is replaced.
- * When U2 trouble occurs.
- * When the RSPF section is disassembled.
- * When the RSPF unit is replaced.

This simulation is to adjust the scanning position when scanning in the RSPF mode.

If this adjustment is made improperly, the scanner stop position is shifted from the specified position and a shade of the document table may be reflected on the lead edge section of the scan image in the RSPF mode.

 Make a copy in the R SPF mode, and check for any shade on the lead edge section of the copy image.



If there is any shade of the d ocument table on the lead edge section of the copy image, perform the following procedures.

2) Enter the SIM 53-8 mode, and press [MANUAL] key.



3) Enter an adjustment value with 10-key, and press [OK] key. When the set value is increased, the distance from the home position to the RSPF scanning position is increased. When the set value is changed by 1, the scanning position is changed by 0.1mm.

Perform the procedures of 1) - 3) until a sa tisfactory result is obtained.

Important

After execution of this adjustment, be sure to execute ADJ 18C Copy image position, imag e loss, void ar ea adjustment (Ma nual adjustment) (RSPF mode).

### 18-C Copy image position, image loss, void area adjustment (Manual adjustment) (RSPF mode)

This adjustment must be performed in the following cases:

- * When the scan control PWB is replaced.
- * When the EEPROM on the scan control PWB is replaced.
- * When the scanner (reading) section is disassembled.
- * When the scanner (reading) unit is replaced.
- * When U2 trouble occurs.
- * When the RSPF section is disassembled.
- * When the RSPF unit is replaced.

#### a. Adjustment procedures

1) Prepare the adjustment chart.

The adjustment chart can be made by the following procedures.

Use A4 (11" x 8.5") paper and draw arrow marks vertically and horizontally on the front and the back surfaces.

At the same time, put mar ks of the lead edge, the trail edge, the front end, and the rear end as well as the identification marks of the front surface and the back surface.





#### 2) Enter the SIM 50-6 mode.

			© 0
TES SIMULATION NO. 5	50-06		CLOSE
LEAD EDGE ADJUSTMENT V	ALUE (S	PF)	
	50 :	SIDE1	
<b>50</b> B.	50 :	SIDE2	
[1~99] C:	20 :	LEAD_EDGE (SIDE1)	
D:	20 :	FRONT_REAR(SIDE1)	
E:	40 :	TRAIL_EDGE (SIDE1)	
F:	30 :	LEAD_EDGE (SIDE2)	(free)
G:	20 :	FRONT_REAR (SIDE2)	
H:	40 :	TRAIL_EDGE (SIDE2)	•
I:	50 :	OFFSET_SPF1	
J:	50 :	OFFSET_SPF2	
К:	50 :	SCAN_SPEED_SPF1	
			OK

ltem/Display			Content	Setting	Default
				range	value
A	SIDE1		Front surface document scan position adjustment (CCD)	1 - 99	50
В	SIDE2		Back surface document scan position adjustment (CCD)	1 - 99	50
С	Image loss amount	LEAD_EDGE (SIDE1)	Front surface lead edge image loss amount setting	0 - 99	20
D	setting SIDE1	FRONT_REAR (SIDE1)	Front surface side image loss amount setting	0 - 99	20
E		TRAIL_EDGE (SIDE1)	Front surface rear edge image loss amount setting	0 - 99	40
F	Image loss amount	LEAD_EDGE (SIDE2)	Back surface lead edge image loss amount setting	0 - 99	20
G	setting SIDE2	FRONT_REAR (SIDE2)	Back surface side image loss amount setting	0 - 99	20
н		TRAIL_EDGE (SIDE2)	Back surface rear edge image loss amount setting	0 - 99	40
Ι	OFFSET_SPF1		RSPF front surface document off- center adjustment	1 - 99	50
J	OFFSET	_SPF2	RSPF back surface document off-center adjustment	1 - 99	50
К	SCAN_S	PEED_SPF1	RSPF document front surface magnification ratio adjustment (Sub scan)	1 - 99	50
L	SCAN_S	PEED_SPF2	RSPF document back surface magnification ratio adjustment (Sub scan)	1 - 99	50

* Item A, B: When the adjustment value is increased, the scan timing is delayed.

- * Item C H: When the adjustment value is increased, the image loss is increased.
- * Item A H: 1 step = 0.1mm change
- * The RSPF rear edge image loss setting is provided for countermeasures against the case when shades are produced.

#### (Lead edge image loss adjustment)

 Set the lead edge image loss adjustment values (LEAD EDGE (SIDE1/SIDE2) on the front surface and the back surface to the following values.

(Standard set value)

TRAIL EDGE (SIDE 1):

40 Lead edge image loss set value (Front surface) TRAIL EDGE (SIDE 2):

40 Lead edge image loss set value (Back surface)

(When the set value is increased, the lead edge image loss is increased.)

(Change for change in the set value: 0.1mm/step)

2) Make a duplex copy in 100% in the RSPF mode. Check to confirm that the lead edge image loss is within 4.0 ± 1.0mm on the front surface and the back surfa ce. The paper lead edge must be aligned with the presumed image lead edge.



If the above condition is not satisfied, perform the following procedure.

 Enter the adjustment value of SIDE1/SIDE2 with 10-key, and press [OK] key.

Adjust so that the paper lead edge is aligned with the presumed image lead edge.

SIDE1: Front surface lead edge scan position adjustment SIDE2: Back surface lead edge scan position adjustment (When the adjustment value is increased, the print image position is shifted to the delaying direction for the paper.) (Change for change in the set value: 0.1mm/step)

Perform the procedur es of 2) - 3) until a satisfactor y result is obtained.

#### (Rear edge image loss adjustment)

 Make a duplex copy in 100% in the RSPF mode. Check to confirm that the rear edge image loss is 2.0 - 5.0mm on the front surface and the back surface.



If the above condition is not satisfied, perform the following procedure.

Enter the adjustment value of TRAIL EDGE (SIDE1/SIDE2) 2) with 10-key, and press [OK] key.

TRAIL EDGE (SIDE 1):

Rear edge image loss adjustment value (Front surface) TRAIL EDGE (SIDE 2):

Rear edge image loss adjustment value (Back surface) (When the adjustment value is increased, the rear edge image loss is increased.)

(Change for change in the set value: 0.1mm/step)

Perform the procedures of 1) - 2) until a sa tisfactory result is obtained.

#### (Front/rear frame direction image loss adjustment)

Make a duplex copy in 100% in the RSPF mode. Check to 1) confirm that the image losses on the front frame side and the rear frame side are 2.0  $\pm$  2.0mm on the front surface and the back surface.



If the above condition is not satisfied, perform the following procedure.

Enter the adjustment value of FRONT/REAR (SIDE 1) / 2) FRONT/REAR (SIDE 2), and press [OK] key.

FRONT/REAR (SIDE 1):

side edge

Front/Rear image loss adjustment value (Front surface)

### FRONT/REAR (SIDE 2):

Front/Rear image loss adjustment value (Back surface) (When the adjustment value is increased, the front/rear image loss is increased.)

(Change for change in the adjustment value: 0.1mm/step)

Perform the procedures of 1) - 2) until a sa tisfactory result is obtained.

### ADJ 19 Finisher and punch unit adjustments (alignment, punch hole position, staple position)

This adjustment must be performed in the following cases:

- * When the finisher is disassembled.
- * When the finisher control PWB is replaced.
- When the punch unit is disassembled.
- * When the punch control PWB is replaced.
- When the alignment is improper.
- When the punch hole position is shifted.
- * When the staple position is shifted.
- Enter the SIM 3-10 mode. 1)



lte	m/Display	Content	Setting range	Default value	Purpose (Case where the adjustment is required)	Change when the adjustment value is increased or decreased		Change when the adjustment value is changed by 1
A	FRONT ADJUST	Alignment position adjustment (F side alignment plate stop position) (Paper alignment adjustment)	2 - 18	10	This adjustment is used to adjust the paper alignment width when the paper alignment is improper. Alignment is determined by the combination of the both adjustment values of FRONT ADJUST and REAR ADJUST.	F side paper alignment stop position (F/R direction)	When the adjustment value is increased, the alignment plate stop position is shifted to the R side. When the adjustment value is decreased, the alignment plate stop position is shifted to the F side.	0.3665mm
В	REAR ADJUST	Alignment position adjustment (R side alignment plate stop position) (Paper alignment adjustment)	2 - 18	10	When changing the adjustment values of FRONT ADJUST and REAR ADJUST from the default values, be sure to change them by the same variation.	R side paper alignment stop position (F/R direction)	When the adjustment value is increased, the alignment plate stop position is shifted to the F side. When the adjustment value is decreased, the alignment plate stop position is shifted to the R side.	0.3665mm
С	STAPLE REAR	Stapling position adjustment (one position at the rear)	68 - 132	100	When the staple position on the R side is shifted, perform the adjustment.	Staple position (Stapler stop position) (F/R direction)	When the adjustment value is increased, the staple position is shifted to the rear side. When the adjustment value is decreased, the staple position is shifted to the front side.	0.155mm
D	STAPLE FRONT	Stapling position adjustment (one position in front)	68 - 132	100	When the staple position on the F side is shifted, perform the adjustment.	Staple position (Stapler stop position) (F/R direction)	When the adjustment value is increased, the staple position is shifted to the rear side. When the adjustment value is decreased, the staple position is shifted to the front side.	0.155mm
E	STAPLE BOTH	Stapling position adjustment (center position of two positions binding)	68 - 132	100	When the staple off-center is shifted, perform the adjustment.	Staple position (Stapler stop position) (F/R direction)	When the adjustment value is increased, the staple position is shifted to the rear side. When the adjustment value is decreased, the staple position is shifted to the front side.	0.155mm
F	STAPLE PITCH	Stapling position adjustment (staple pitch of two positions binding)	68 - 132	100	When it is required to change the staple interval, perform the adjustment.	Staple position (Stapler stop position) (F/R direction)	When the adjustment value is increased, the staple interval is increased. When the adjustment value is decreased, the staple interval is decreased.	0.155mm
G	PUNCH CENTER	Punch center positioning sensor	37 - 63	50	When the punch off-center is shifted, perform the adjustment.	Punch position (F/R direction)	When the adjustment value is decreased, the punch position is shifted to the front side. When the adjustment value is increased, the punch position is shifted to the rear side.	0.1441mm
H	PUNCH HOLE	Punch hole adjustment (paper transport direction)	42 - 58	50	When the punch hole position is shifted in the transport direction, perform the adjustment.	Punch position (Paper transport direction)	When the adjustment value is increased, the punch position is shifted to the paper lead edge side. When the adjustment value is decreased, the punch position is shifted to the paper rear edge side.	0.2584mm

## [6] SIMULATION

### 1. General and purpose

The simulation mode has the following functions, to display the machine operating status, identify the trouble position and causes in an earlier stage, and to efficiently setup and adjust the machine for improved serviceability.

- 1) Various adjustments
- 2) Setting of the specifications and functions
- 3) Canceling troubles
- 4) Operation check
- 5) Counters check, setting, clear
- 6) Machine operating conditions (operation hysteresis), data check, clear.
- 7) Various (adjustments, setting, operation, counters, etc.) data transport.

The operating procedures and displays depend on the design of the operation panel of the machine.

### 2. Starting the simulation

### Entering the simulation mode

1) Double-click the [HOME] key. (Total use quantity/Toner remaining quantity display mode screen)



- 2) Touch the VER display section. (10-key mode input mode screen)
- Touch the (#) key → Asterisk (*) key → Clear key → Asterisk (*) key → Ready for input of main code of simulation.
- 4) Enter a main SIM code with the 10-key pad then touch the START key or select a main code from the SIM key list on the touch panel.
- 5) Enter a sub code with the 10-key pad, then touch the START key or select a sub code from the code list on the touch panel.
- 6) Select an item with the scroll key and the item key.
- The machine enters the mode corresponding to the selected item. Press [START] key or [EXECUTE] key to start the simulation operation.

To cancel the current simulation mode and change the main code and the sub code, press [BACK] key.

Canceling the simulation mode to return to the normal mode

1) Press [EXIT] key.

Important

Do not turn OFF the power when the machine is in the simulation mode.

If the power switch should be turned OFF in the simulation mode, a malfunction may be resulted. In this case, turn OFF/ON the main power source.



### 3. List of simulation codes

Main	Sub	Functions	Section
Wiaiii	Jub	Functions	
1	1	Used to check the operation of the scanner (reality) with and the control circuit.	
	2	Used to check the sensors in the scanner (reading) section and the related circuits.	Scanner (reading)
	5	Used to check the operation of the scanner (reading) unit and the control circuit.	Scanner (reading)
2	1	Used to check the operations of the automatic document feeder and the control circuit.	RSPF
	2	Used to check the operations of the sensors and the detectors in the automatic document feeder section	RSPF
		and the control circuits.	
	3	Used to check the operations of the loads in the automatic document feeder and the control circuit.	RSPF
3	2	Used to check the operations of the sensors and the detectors in the finisher and the control circuit.	Finisher
	3	Used to check the operation of the load in the finisher and the control circuit.	Finisher
	10	Used to adjust the finisher.	Finisher
4	2	Used to check the operations of the sensors and detectors in the desk, and the control circuit of those.	Desk
	3	Used to check the operations of the loads in the desk, and the control circuit of those.	Desk
	5	Used to check the operations of the paper feed desk paper transport clutch (DTRC).	Desk
5	1	Used to check the operation of the display, LCD in the operation panel, and control circuit.	Operation panel
	2	Used to check the operation of the heater lamp and the control circuit.	Fusing
	3	Used to check the operation of the scanner lamp and the control circuit.	Scanner (reading)
	4	Used to check the operation of the discharge lamp and the control circuit.	Process
6	1	Used to check the operations of the load in the paper transport system (clutches and solenoids) and the control circuits.	Paper transport/Paper exit section
	2	Used to check the operations of each fan motor and its control circuit.	Others
	3	Used to check the operations of the transport unit and the control circuit.	Process (Transport)
	6	Used to perform fusing pressure release and applying, and to check the operations of the control	Fusing
		circuits.	-
	90	Used to reset the machine to the factory setting. (The scanner is set to the lock enable position)	Scanner
7	1	Used to set the operating conditions of aging.	Others
	6	Used to set the operating intermittent aging cycle.	
	8	Used to display the warm-up time.	
	9	Color setting in the color copy test mode (Used to check the copy operation and the image quality for	
	12	The document reading number of sheets setting (for aging operation)	RSPF
8	1	Used to check and adjust the operations of the developing voltage in each print mode and the control	Process (Developing)
		circuit. * When the middle speed is adjusted, the low speed are also adjusted simultaneously.	
	2	Used to check and adjust the operation of the main charger grid voltage in each printer mode and the	Process (Charging)
	6	Light to check and adjust the operation of the transport voltage and the control circuit	Process (Transport)
9	2	Used to check the operations of the sensors and detectors in the paper reverse section (dupley section)	Dunley
3	2	and its control circuit	Duplex
	3	Used to check the operations of the load in the paper reverse section (duplex section) and its control	Duplex
		circuit.	
10	1	Used to check the operations of the toner supply mechanism (toner motor) and the related circuit.	Process (Developing)
13	-		
14	-	Used to cancel the self-diag H3, H4, H5 troubles.	
15	-	Used to cancel the self-diag "U6" trouble.	
16	-		MFP PWB/PCU PWB/SCU PWB
21	1	Used to set the maintenance cycle.	
-22	1	Used to check the print count value in each section and each operation mode.	
	2	Used to check the total number of misfeed and troubles	
	-	(When the number of total jam is considerably great, it is judged as necessary for repair.)	
	3	Used to check misfeed positions and the misfeed count of each position.	
		* Presumption of the faulty point by this data is possible.	
	4	Used to check the trouble (self diag) history.	
	5	Used to check the ROM version of each unit (section).	Firmware
	6	Used to output the setting/adjustment data (simulation, FAX soft switch, counter), the firmware version,	
		and the counter list.	
	8	Used to check the number of operations (counter value) of the finisher, the RSPF, and the scan (reading) unit.	
	9	Used to check the number of use (print quantity) of each paper feed section.	Paper feed, ADU
	10	Used to check the system configuration (option, internal hardware).	· · · ·
	11	Used to check the use frequency (send/receive) of FAX. (Only when FAX is installed)	FAX
	12	Used to check the RSPF misfeed positions and the number of misfeed at each position. (When the	RSPF
		number of misfeed is considerably great, it can be judged as necessary for repair.)	
	13	Used to check the operating time of the process section (OPC drum, DV unit, toner cartridge) and the fusing unit	Process
	14	Used to display the use status of the toner cartridge	Process
	18	Used to display the user data delete history.	
	19	Used to check the values of the counters related to the scan - image send.	
	40	Used to display the error code list and the contents.	
	42	Used to check the JAM/trouble data.	

Main	Sub	Functions	Section
22	43	JAM data details display	
	60	Used to check utility counter mode history data display.	
	90	Used to output the various set data lists.	
23	2	Used to output the trouble history list of paper iam and misfeed.	
		(If the number of troubles of misfeed is considerably great, the judgment is made that repair is required.)	
	80	Used to check the operation of paper feed and paper transport in the paper feed section and the paper	Paper feed, Paper transport
		transport section. Used to output the list of the operation status of the sensor and the detectors in the	
		paper feed section and the paper transport section.	
24	1	Used to clear the jam counter, and the trouble counter.	
		(After completion of maintenance, clear the counters.)	
	2	Used to clear the number of use (the number of prints) of each paper feed section.	
	3	Used to clear the finisher, RSPF, and the scan (reading) unit counter.	
	4	Used to clear the maintenance counter, the printer counters of the transport unit and the fusing unit.	
		(After completion of maintenance, clear the counters.)	
	5	Used to clear the developer counter. (After replacement of developer, clear the counter.)	
	6	Used to clear the copy counter.	
	9	Used clear the printer mode print counter and the self print mode print counter.	
	10	Used to clear the FAX counter. (Only when FAX is installed)	
	12	Used to clear the document filing counter.	
	15	Used to clear the counters related to the scan mode and the image send.	
	35	Used to clear the toner cartridge use status data.	
	60	Used to clear utility counter mode history data.	
25	1	Used to check the operations of the developing section.	Process (Developing section)
	2	Used to make the initial setting of toner density when replacing developer. (Automatic adjustment)	Image process (Photoconductor/
			Developing/Transfer/Cleaning)
	4	Used to display the operation data of the toner supply quantity. (Not used in the market.)	Process
	5	Used to display the toner density correction data. (Not used in the market.)	Process
26	1	Used to set Yes/No of installation of the right paper exit tray.	Paper exit
	2	Used to set the paper size of the large capacity tray (LCC)	Paper exit
		(When the paper size is changed, this simulation must be executed to change the paper size in software.	
	3	Used to set the specifications of the auditor.	Auditor
		(Setting must be made according to the auditor use conditions.)	
	5	Used to set the count mode of the total counter and the maintenance counter. (A3/11x17 size)	
	6	Used to set the specifications (paper, fixed magnification ratio, etc.) of the destination.	
	7	Used to set the machine ID.	
	8	Counter mode setting (Long scale)	
	10	Used to set the trial mode of the network scanner.	
	18	Used to set Disable/Enable of the toner save mode operation. (For the Japan and the UK versions.)	
	30	Used to set the operation mode corresponding to the CE mark (Europe safety standards).	
	22	(For slow start to drive the fusing neater lamp)	Fueing
	32	Used to set the display mode of SIM 22.4 trauble bistory when a same trauble assured repeatedly	Fusing
	35	Used to set the display mode of Sim 22-4 trouble history when a same trouble occurred repeatedly.	
	20	Lised to set Continue/Stop of print when the maintenance life is reached	
	 	Used to set Enable/Disable of the magnification ratio automatic select function (AMS) in the center	
	41	binding mode	
	49	Used to set the print speed of postcards mode	
	50	Used to set functions	
	51	Used to set the specifications of the serial port operation (For PCI)	
	52	Used to set whether non-printed paper (insertion paper, cover paper) is counted up or not	
	53	User auto color calibration (color balance adjustment) Inhibit/Allow setting	
	60	Used to set utility counter mode	
	65	Used to set the finisher alarm mode	
	69	Used to set the operating conditions for toner near end	
	71	Used to set the trial mode of the web browsing function	
	73	Enlargement continuous shoot. A3 wide copy mode image loss (shade delete quantity) adjustment	
	74	Lised to set the OSA trial mode	
	79	Used to set the password of the remote operation panel	
	70	Used to set YES/NO of the pon-up display of user data delete result	
27	1	Used to set non-detection of communication error (17-00) with RIC (FSS function)	
	2	Used to set the sender's registration number and the HOST server telephone number (FSS function)	
	4	Used to set the initial call and toner order auto send (FSS function)	
	-+	Used to set the machine tag No. (This function allows the host computer to check the machine tag No.)	Communication (RIC/MODEM)
	5	(FSS function)	
	6	Used to set of the manual service call (ESS function)	
1		Lised to set of the enable, alort callout (ESS function)	
	7		
	7 9	Used to set the paper transport time recording YES/NO threshold value and shading gain adjustment	
	7 9	Used to set the paper transport time recording YES/NO threshold value and shading gain adjustment retry number. (FSS function)	

Main	Sub	Functions	Section
27	11	Used to check the serial communication retry number and the scanner gain adjustment retry number	
		history. (FSS function)	
	12	Used to check the high density, halftone process control and the automatic registration adjustment error	
		history. (FSS Function)	
	13	Used to check the history of paper transport time between sensors. (FSS function)	
	14	Used to set the FSS function connection test mode.	
	15	Used to display the FSS connection status.	
	16	Used to set the FSS alert send.	
	17	Used to set the FSS paper order alert.	
	18	Used to clear the FSS paper feed retry counter.	
30	1	Used to check the operations of the sensors and the detectors in other than the paper feed section and	
		the control circuits.	
	2	Used to check the operations of the sensors and the detectors in the paper feed section and the control	
		circuits.	
40	2	Manual paper feed tray paper width sensor adjustment.	Paper feed
	7	Used to set the adjustment value of the manual paper feed tray paper width sensor.	Paper feed
41	1	Used to check the operations of the document size sensor and the control circuit.	
	2	Used to adjust the document size sensor detection level.	
	3	Used to check the operations of the document size sensor and the control circuit.	
43	1	Used to set the fusing temperature in each mode.	
	2	Used to set the fusing operation and preheating.	
	20	Used to set the environmental correction under low temperature and low humidity (L/L) for the fusing	
	<u>.</u>	temperature setting (SIM 43-2) in each paper mode.	
	21	Used to set the environment correction under high temperature and high humidity (H/H) for the fusing	
	24	Lend to got the temperature ediustment value	
	24	Used to shock the operation of the fueing web elegning	Fusing
	31	Used to check the operation of the fusing web cleaning.	Fusing
	32	Used to set valious items related to the forcible operation of web cleaning when job end.	Fusing
	25		Fusing
4.4	35	Fusing hip operation check	Fusing
44	1	Used to set each correction operation function in the image forming (process) section.	Image process (Photoconductor/
	2	I lead to adjust the sensitivity of the image density sensor (registration sensor)	Process
	4	Used to set the conditions of the high density process control operation	Process
	6	Used to execute the high density process control forcibly	Process
	9	Used to display the result data of the high density process control operation	Image process (Photoconductor/
	Ũ		Developing/Transfer/Cleaning)
	12	Used to display the operation data of the high density process control and the image density sensor	Image process (Photoconductor/
		(registration sensor).	Developing)
	14	Used to display the output level of the temperature and humidity sensor.	Process (OPC drum, development)/
			Fusing/LSU
	15	Used to set the OPC drum idle rotation.	Process
	17	Process refresh execution	Process
	21	Used to set the halftone process control target.	Process
	22	Used to display the toner patch density level in the halftone process control operation.	Process
	24	Used to display the correction target and the correction level in the halftone process control operation.	Process
	25	Used to set the calculating conditions of the correction value for the halftone process control.	Process
	26	Used to execute the halftone process control compulsory.	Process
	27	Used to clear the correction data of the halftone process control.	Process
	28	Used to set the process control execution conditions.	Process
	29	Used to set the operating conditions of the process control during a job.	Process
	31	Used to adjust the OPC drum phase. (Manual adjustment)	Process
	37	Used to set the development bias correction level in the continuous printing operation.	Developing evictory
	43	Used to display the identification information of the developing unit.	Developing system
40	62	Used to set the process control execution conditions.	Process
46	1	Used to adjust the copy density in the copy mode.	
	2	Used to adjust the depetity in the image condimode.	
	4 5	Used to adjust the density in the image send mode.	
	0	Used to adjust the image condimode color balance PCP	
	a	Used to adjust the scan image density	
	10	Used to adjust the conv color balance and the gamma (for each color conv mode)	
	16	Used to adjust the monochrome copy density and the gamma (for each monochrome copy mode).	
	19	Used to set the operating conditions for the density scanning (exposure) of monochrome auto conv	
		mode documents.	
	21	Copy color balance adjustment (Manual adjustment)	
	23	Used to set the density correction of copy high density section (High density tone gap supported).	
	24	Copy color balance adjustment (Auto adjustment)	
	25	Used to adjust the copy color balance. (Single color copy mode)	
	26	Used to reset the single color mode color balance set value to the default.	
	27	Used to adjust the gamma/density of copy images, texts, and line image edges.	
	30	Used to adjust the resolution in the sub scanning direction in the copy mode.	

Main	Sub	Functions	Section
46	32	Used to adjust the document background density reproducibility in the monochrome auto copy mode.	
	36	Used to adjust the colors in the 2-color copy mode.	
	37	Used to adjust the reproduction capability of monochrome mode color.	
	38	Used to adjust the black component amount in the color copy mode.	
	39	Used to adjust the sharpness of FAX send images.	
	40	Used to adjust the FAX send image density. (Collective adjustment of all the modes)	
	41	Used to adjust the FAX send image density. (Normal)	
	42	Used to adjust the FAX send image density. (Fine)	
	43	Used to adjust the FAX send image density. (Super Fine)	
	44	Used to adjust the FAX send image density. (Ultra fine)	
	45	Used to adjust the FAX send image density. (600dpi).	
	46	Used to adjust the FAX send image density. (RGB RIP)	
	47	Used to set the compression rate of copy and scan images (JPEG).	
	51	Used to adjust the gamma for the copy mode heavy paper mode and the image process mode.	
	52	Used to set the gamma default for the copy mode heavy paper and the image process mode.	
		(After execution of either SIM46-54 or SIM46-51, the adjustment value is reset to the initial value.)	
	54	Used to perform the engine halftone automatic density adjustment (dither).	
	55	Used to adjust the drop out color in the image send mode (monochrome manual text mode).	
	58	Used to set the copy mode pseudo resolution. (Smoothing process)	
	59	Used to perform the copy mode pseudo resolution image process adjustment.	
	60	Used to adjust the snarpness in the color auto copy mode.	
	62	Used to adjust the aperating conditions of the ACS, the area constraint the background image process	
	02	and the auto exposure mode	
	63	Used to adjust the density in the copy low density section	
	65	Used to set the color correction table	
	66	Used to adjust the reproduction capability of watermarks in the copy/printer mode	
	74	Copy color balance adjustment (Auto adjustment)/Printer color balance adjustment (Auto adjustment)	
	90	Used to set the process operation of high-compression PDF images.	
	91	Used to adjust the reproduction capability of black text.	
48	1	Used to adjust the scan image magnification ratio (in the main scanning direction and the sub scanning	
		direction).	
	5	Used to correction the scan image magnification ratio (in the sub scanning direction).	Scanner section
	6	Used to adjust the rotation speed of each motor.	
49	1	Used to perform the firmware update.	
	3	Used to update the operation manual in the HDD.	
	5	Used to perform the watermark update.	
	10	Used to perform the ACU firmware update.	
50	1	Copy image position, image loss adjustment	
	5	Used to adjust the print lead edge image position. (PRINTER MODE)	
	6	Used to adjust the copy image position and the image loss. (RSPF mode)	RSPF
	10	Used to adjust the black print image magnification ratio and the off-center position.	
	40	(The adjustment is made separately for each paper feed section.)	
	12	Used to perform the scan image on-center position adjustment.	
	20	Image registration adjustment (Main scanning direction)	
	22	Used to adjust the image registration (Main scan direction, sub scan direction)	
		(Auto adjustment)/OPC drum phase adjustment (Auto adjustment)	
	24	Used to display the detail data of SIM 44-2, 50-20 and 22.	
	27	Used to perform the image loss adjustment of scanned images in the FAX or image send mode.	
	28	Used to automatically adjust the image loss, void area, image off-center, and image magnification ratio.	
51	1	Used to adjust the ON/OFF timing of the secondary transport voltage.	
	2	Used to adjust the contact pressure (deflection amount) on paper by the main unit and the RSPF resist	
		roller. (This adjustment is performed when there is a considerable variation in the print image position on	
		the paper or when paper jams frequently occur.)	
53	6	Used to adjust the detection level of the RSPF document width.	
	7	Used to adjust the RSPF document size width sensor.	
	8	Used to adjust the document lead edge reference and the RSPF mode document scan position.	
	9	RSPF dirt detection setting	
	10	RSPF dirt detection execution	
55	1	Used to set the specifications of the engine control operations. (SOFT SW)	
	2	Used to set the specifications of the control operation. (SOFT SW)	
	3	Used to set the specifications of the controller operation. (SUF1 SW)	
56	10	Used to set the Special stamp text. (Talwan only)	
50	ו ר	Used to hackup the data in the EEDROM SD Card, and HDD (including user outherstigation data and	
	2	address data) to the USB memory. (Corresponding to the device cloping and the storage backup)	
	3	Used to backup the document filing data to the USB memory	
	4	Used to backup the JOB log data to the USB memory.	
	5	Used to import the SIM22-6 data to a USB memory in the TEXT format.	
	6	Used to import the SIM23-2 data into a USB memory in the TEXT format.	
	7	Used to import SYSLOG data into a USB memory	



8

9

10

11

12

13

14 15

16

17

Main	Sub	Functions	Section
60	1	Used to check the memory operations (read/write) of the MFP PWB.	
61	1	Used to check the LSU polygon motor rotation and laser detection.	LSU
	3	Used to set the laser power	
	4	Used to print the print image skew adjustment pattern. (LSU unit)	
	11	Used to correct the laser power automatically	
	12	Laser power manual correction LSU	
	13	Used to clear the laser power correction value	
62	1	Used to format the hard disk/SD Card. (HDD: Excluding the Operation manual and the watermark data) (SD Card: User data)	
	2	Used to check read/write of the hard disk (partial).	
	3	Used to check read/write of the hard disk (all areas).	
	6	Used to perform the self diagnostics of the hard disk.	
	7	Used to print the hard disk self diagnostics error log.	
	8	Used to format the hard disk/SD Card. (HDD: Excluding the Operation Manual, the watermark data, and the system area) (SD Card: User data)	
	10	Used to clear the job completion list data.	
	11	Used to delete the document filing data.	
	12	Used to set Enable/Disable of auto format in a hard disk trouble.	
	13	Used to format the hard disk. (Operation Manual, watermark data only)	
63	14	Used to delete the document filing management data.	HDD
	20	Used to check the operation of the mirroring hard disk.	Mirroring hard disk
	1	Used to display the shading correction result.	Scanner
	2	Used to perform shading.	
	3	Used to perform scanner (CCD) color balance and gamma auto adjustment.	Scanner
	4	Used to display the SIT chart patch density.	
	5	Used to perform the scanner (CCD) color balance and gamma default setting.	
	6	Used to display the scan level and the density level of the copy color balance adjustment patch.	
	7	Used to register the service target of the copy mode auto color balance adjustment.	
	8	Used to set the default of the service target of the copy mode auto color balance adjustment.	
64	11	Used to set the target color balance of the copy mode auto color balance adjustment.	
	1	Test print. (Self print) (Color mode)	
	2	Test print. (Self print) (Monochrome mode)	
	4	Printer test print. (Self print)	
-	5	Printer test print. (Self print) (PCL)	
	6	Printer test print. (Self print) (PS)	
	7	Used to print the adjustment pattern of the test print .(Self print). (The adjustment pattern of SIM46-21 is printed.)	
65	1	Used to adjust the touch panel (LCD display section) detection coordinates.	Operation panel section
-	2	Used to display the touch panel (LCD display section) detection coordinates.	
	5	Used to check the operation panel key input.	
66	1	Used to display the FAX-related soft SW (2 - 150) on the LCD to allow changing the soft SW while checking with the LCD.	FAX
	2	Used to enter a country code and set the default value for the country code.	FAX
	3	Used to check read/write of the EEPROM and the SDRAM on the MODEM controller and display the result.	FAX
	4	Used to send the selected signals to the line and the main unit speaker. (Send level: max.)	FAX
	5	Used to send the selected signal to the line and the main unit speaker. (Send level: Soft SW setting) (For the kinds of send signals, refer to SIM66-04.)	FAX
	6	Used to print the confidential registration check table (BOX NO., BOX name, passcode. (If there is no confidential registration, no print is made.)	FAX
-	7	Used to output all image data saved in the image memory (Confidential data are also outputted)	FAX

Used to send the selected sound messages to the line and the speaker. (Send level: Max.)

Used to clear the FAX and image send image data. (The confidential data are also cleared.)

Used to send the selected signal at 300bps to the line and the speaker. (Send level: Max.

* For the kings of send signals at 300bps, refer to SIM66-11, 300bps send signal table.

* For details of sound messages, refer to the sound message table of SIM66-08.

Used to execute the dial pulse (10PPS) send test and to adjust the make time.

Used to execute the dial pulse (20PPS) send test and to adjust the make time.

Used to send the DTMF signal to the line and the speaker. (Send level: Max.)

Used to execute the DTFM signal send test and to adjust the send level.

Used to send the selected sound message to the line and the speaker. (Send level: Soft SW setting)

Used to send the selected signal at 300bps to the line and the speaker. (Send level: Soft SW setting)

Used to register dial numbers for SIM66-14/15/16, Dial test. (Up to 20 digits can be registered.)

FAX FAX

FAX

FAX

FAX

FAX

FAX

FAX

FAX

FAX

Main	Sub	Functions	Section
66	18	Used to send the DTMF signal to the line and the speaker. (Send level: Soft SW setting)	FAX
	21	Used to print the selected items (system error, protocol monitor).	FAX
	22	Used to set the handset sound volume. (This simulation can be executed even though the handset	FAX
		setting is set to NO. When, however, the handset is not installed, the sound volume cannot be checked.)	
		(Japan model only)	
	24	Used to clear the FAST save data.	FAX
	29	Used to initialize the telephone book data (the one-touch registration table, the FTP/Desktop expansion	FAX
		table, the group expansion table, the program registration table, the interface memory box table, the	
	20	meta data, inboundRouting, and the DocumentAdmin table).	
	30	Used to display the TEL/LID status change, The display is highlighted by status change.	
	31	Used to set ON/OFF the port for output to TEL/LIO.	FAX
	32	Used to check the lixed data received from the line and to display the result.	
	33	When a signal is detected, the display is highlighted.	FAX
	34	Used to execute the send test and display the time required for sending image data in the test. Used to	FAX
	-	execute send test and display. (Unit: ms)	
	36	Used to check send and receive data from the MODEM controller to the MFP controller or the data line	FAX
		or the command line individually.	
	39	Used to check and change the destination setting saved in EEPROM of the FAX BOX.	FAX
	42	Used to rewrite the program to power control installed in the FAX BOX.	FAX
	43	Used to write the adjustment value into the power control installed in the FAX BOX.	FAX
	61	Used to display the FAX-related soft SW (151 - 250) on the LCD to allow changing the soft SW while	FAX
		checking with the LCD.	
	62	Used to import the FAX receive data into a USB memory in PDF file type.	FAX
67	1/	Printer reset	Printer
	24	Printer color balance adjustment (Auto adjustment)	Printer
	25	Printer color balance adjustment (Manual adjustment)	Printer
	26	Used to set the target color balance of the printer mode auto color balance adjustment.	Printer
-	27	Used to set the service target of the printer mode auto color balance adjustment.	Printer
	28	Used to set the default of the service target of the printer mode auto color balance adjustment.	Printer
	31	Used to clear the printer calibration value.	Printer
	33	Used to change the gamma of the printer screen.	Printer
	34	section tone dap)	Printer
	36	Used to adjust the density in the low density section.	Printer
Ē	41	Used to set the threshold value for the printing judgement in the black color of the black and white	Printer
		printing or the selected color.	
	42	Used to change the gradation by increasing or decreasing the amount of the black color in the black and	Printer
	40	white printing or the selected Color.	Drinter
	43	Used to adjust the printer image filter and trapping	Printer
	40	Used to act the default of the common of the printer across	Printer
	52	Used to set the default of the gamma of the printer screen.	Printer
	54	Printer color balance adjustment (Automatic adjustment for each dither.)	Printer

### 4. Details of simulation

1	

1-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the operation of the scanner (reading) unit and the control circuit.
Section	Scanner (reading)

### Operation/Procedure

1) Select the operation speed with the touch panel key.

2) Press [EXECUTE] key.

Scanning is once performed at the speed corresponding to the scan resolution (operation speed).

Iter	n/Display	Operation mode	Default value
OC SCAN	300DPI	300DPI	300DPI
		(346.0mm/s)	(346.0mm/s)
	400DPI	400DPI	
		(259.5mm/s)	
	600DPI	600DPI	
		(173.0mm/s)	
	1200DPI	1200DPI	
		(86.5mm/s)	

1-2	
Purpose	Operation test/check
Function (Purpose)	Used to check the sensors in the scanner (reading) section and the related circuits.
Section	Scanner (reading)

Operation/Procedure

The operating status of the sensor is displayed.

When "MHPS" is highlighted, the scanner unit is in the home position.

1-5	
Purpose	Operation test/check
Function (Purpose)	Used to check the operation of the scanner (reading) unit and the control circuit.
Section	Scanner (reading)

**Operation/Procedure** 

1) Select the operation speed with the touch panel key.

2) Press [EXECUTE] key.

Scanning is repeated at the speed corresponding to the scan resolution (operation speed).

When [EXECUTE] key is pressed, the operation is terminated.

Iten	n/Display	Operation mode	Default value
OC SCAN	300DPI	300DPI	300DPI
		(346.0mm/s)	(346.0mm/s)
	400DPI	400DPI	
		(259.5mm/s)	
	600DPI	600DPI	
		(173.0mm/s)	
	1200DPI	1200DPI	
		(86.5mm/s)	



2-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the auto- matic document feeder and the control cir- cuit.
Section	RSPF

#### **Operation/Procedure**

- 1) Select the operation mode and the speed with the touch panel key.
- 2) Press [EXECUTE] key.

The RSPF repeats paper feed, transport, and paper exit operations at the speed corresponding to the scan resolution (operation speed).

When [EXECUTE] key is pressed, the operation is terminated.

### [RSPF]

Item/Display		Operation mode	Default value
(SINGLE)	300DPI	300DPI	300DPI
		(259.5mm/s)	(259.5mm/s)
	400DPI	400DPI	
		(259.5mm/s)	
	600DPI	600DPI	
		(173.0 mm/s)	
(DOUBLE)	300DPI	300DPI	300DPI
		(259.5mm/s)	(259.5mm/s)
	400DPI	400DPI	
		(259.5mm/s)	
	600DPI	600DPI	
		(173.0 mm/s)	

2-2	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the sen- sors and the detectors in the automatic document feeder section and the control circuits.
Section	RSPF

#### **Operation/Procedure**

The operating conditions of the sensors and detectors are displayed.

The code names of the sensors and the detectors which are active are highlighted.

Display	Content
SPED	Document sensor
SPPD1	Document transport sensor 1
SPLS1	Paper size detector 1
SPLS2	Paper size detector 2
SOCD	RSPF open/close sensor
SPPD2	Document transport sensor 2
SPPD3	Document transport sensor 3
SPPD4	Document transport sensor 4
SCOV	RSPF cover open/close detector
SSET	SPF installation detection
STMPU	SPF stamp UN installation detection
SWD_LEN	SPF document guide plate position (Unit: 0.1mm)
SWD_AD	SPF document detection volume output AD value



SWD_LEN and SWD_AD are not ON/OFF display.

2-3	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the loads in the automatic document feeder and the control circuit.
Section	RSPF

### **Operation/Procedure**

1) Select a target item of the operation check with the touch panel key.

Press [EXECUTE] key. 2)

The selected load performs the operation.

When [EXECUTE] key is pressed, the operation is terminated.

Display	Content
SPUM_F	RSPF paper feed motor (normal rotation)
SPUM_R	RSPF paper feed motor (reverse rotation)
SPFM_F	RSPF transport motor (normal rotation)
SPFM_R	RSPF transport motor (reverse rotation)
SPRS	Paper exit roller pressure control solenoid (RSPF)
SRRC	Registration roller clutch (RSPF)
STMPS	Stamp solenoid

3

3-2	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the sen- sors and the detectors in the finisher and the control circuit.
Section	Finisher

### Section

**Operation/Procedure** 

The operating conditions of the sensors and detectors are displayed.

The code names of the sensors and the detectors which are active are highlighted.

### Inner finisher (MX-FN17)

Display	Content
FABHS	Paper alignment belt HP sensor
FAPHPS_F	Paper alignment plate HP sensor F
FAPHPS_R	Paper alignment plate HP sensor R
FDRPS	Paper exit roller position sensor
FDTLLS	Paper exit tray lower limit sensor
FDTPD	Delivery tray paper detector
FDTULS	Paper exit tray upper limit sensor
FFL	Fan lock signal
FPCHPS	Punch home position sensor
FPD	Punch unit detection (connector)
FPDFS	Punch dust sensor
FPES1	Punch paper edge sensor 1
FPES2	Punch paper edge sensor 2
FPES3	Punch paper edge sensor 3
FPES4	Punch paper edge sensor 4
FPES5	Punch paper edge sensor 5
FPES6	Punch paper edge sensor 6
FPES7	Punch paper edge sensor 7
FPHPS	Punch unit home position sensor
FPLD1	Paper height detector 1
FPLD2	Paper height detector 2
FPMRS	Punch motor rotation sensor
FPMS	Punch mode sensor
FPPD1	Paper entry detector
FPTS	Punch timing sensor
FSED	Staple empty detector
FSHPS	Staple HP sensor

Display	Content
FSLD	Staple lead edge detector
FSSHPS	Stapler shift home position sensor
FSSS	Staple safety sensor
FSSW	Safety switch
FSTPD	Staple tray paper detector
FTPS	Tray position sensor

### Saddle stitch finisher (MX-FN10)

FATPD	Paper alignment tray paper detector
FCD	Connection detector
FCD1	Cover detector 1
FCD2	Cover detector 2
FDRHS	Delivery roller home position sensor
FDTPD	Delivery tray paper detector
FFL	Fan lock signal
FGHPS	Gripper home position sensor
FPAPHS_F	Paper alignment plate home position sensor F
FPAPHS_R	Paper alignment plate home position sensor R
FPCHPS	Punch home position sensor
FPD	Punch unit detection (connector)
FPDD	Delivery detector
FPDFS	Punch dust sensor
FPES1	Punch paper edge sensor 1
FPES2	Punch paper edge sensor 2
FPES3	Punch paper edge sensor 3
FPES4	Punch paper edge sensor 4
FPHHS	Paper hold home position sensor
FPHPS	Punch unit home position sensor
FPLD	Paper surface detector
FPMRS	Punch motor rotation sensor
FPMS	Punch mode sensor
FPPD1	Paper transport detector 1
FPPD2	Paper transport detector 2
FPPD3	Paper transport detector 3
FPTS	Punch timing sensor
FSAPHS	Saddle alignment plate home position sensor
FSATPD	Saddle paper alignment tray paper detector
FSED	Staple empty detector
FSHS	Staple home position sensor
FSLS	Staple lead edge sensor
FSMRS	Saddle motor rotation sensor
FSPGHS	Saddle paper quide home position sensor
FSPHS	Saddle plate home position sensor
FSRHS	Saddle roller home position sensor
FSSCS	Saddle staple cover sensor
FSSES	Saddle staple sensor
FSSHPS	Stapler shift home position sensor
FSSHS	Saddle staple home position sensor
FSSSHS	Saddle stapler shift home position sensor
FSSSW1	Staple safety switch
FSSSW2	Stapler safety switch 2
FSSW/1	Safety switch 1
FSTPD	Saddle exit tray paper detector
FTUD	Tray lower limit detector
FTIMRS	Tray lift motor rotation sensor
FTPS	Tray position sensor
FTUD	Tray upper limit detector
PDOS	Paper pass cover Open/Close sensor
	Paper pass cover Open/Olde Seriou
PDPPD2	Paper pass paper transport detector 2

3-3	
Purpose	Operation test/check
Function (Purpose)	Used to check the operation of the load in the finisher and the control circuit.
Section	Finisher

### **Operation/Procedure**

Г

- 1) Select the item to be operation checked with the touch panel key.
- 2) Press [EXECUTE] key.

The selected load performs the operation.

When [EXECUTE] key is pressed, the operation is terminated.

### Inner finisher (MX-FN17)

Display	Content
FCF	Cooling fan
FDRLM	Paper exit roller lift motor
FPAM_F	Paper alignment motor F
FPAM_R	Paper alignment motor R
FPAS	Paper alignment solenoid
FPDM	Paper exit motor
FPGS	Paper gate solenoid
FPLDS	Paper height detector solenoid
FPM	Punch motor
FPS	Paddle solenoid
FPSM	Punch shift motor
FPTM	Paper transport motor
FSM	Staple motor
FSSM	Stapler shift motor
FTLM	Tray lift motor

### Saddle stitch finisher (MX-FN10)

Display	Content
FDRLM	Paper exit roller lift motor
FGM	Gripper motor
FPAM_F	Paper alignment motor F
FPAM_R	Paper alignment motor R
FPHS1	Paper holding solenoid 1
FPHS2	Paper holding solenoid 2
FPM	Punch motor
FPSM	Punch shift motor
FPTM1	Paper transport motor 1
FPTM2	Paper transport motor 2
FSDM	Saddle motor
FSDSM	Saddle staple motor
FSM	Staple motor
FSPAM	Saddle paper alignment motor
FSPM	Saddle positioning motor
FSPTM	Saddle paper transport motor
FSSM	Stapler shift motor
FTLM	Tray lift motor
PDCF	Paper pass cooling fan
PDPGS	Paper pass paper gate solenoid
PDPTM	Paper pass paper transport motor

3-10	
Purpose	Adjustment
Function (Purpose)	Used to adjust the finisher.
Section	Finisher
Operation/Procedure	

#### Operation/Procedure

1) Select an adjustment target item with scroll key on the touch panel.

- 2) Enter the set value with 10-key.
- 3) Press [OK] key. (The set value is saved.)

### Inner finisher (MX-FN17)

Item/Display		Content	Setting range	Default value	Purpose (Case where the adjustment is required)	Change i	when the adjustment value is ncreased or decreased	Change when the adjustment value is changed by 1
A	FRONT ADJUST	Alignment position adjustment (F side alignment plate stop position) (Paper alignment adjustment)	2 - 18	10	This adjustment is used to adjust the paper alignment width when the paper alignment is improper. Alignment is determined by the combination of the both adjustment values of FRONT ADJUST and REAR ADJUST.	F side paper alignment stop position (F/R direction)	When the adjustment value is increased, the alignment plate stop position is shifted to the R side. When the adjustment value is decreased, the alignment plate stop position is shifted to the F side.	0.3665mm
В	REAR ADJUST	Alignment position adjustment (R side alignment plate stop position) (Paper alignment adjustment)	2 - 18	10	When changing the adjustment values of FRONT ADJUST and REAR ADJUST from the default values, be sure to change them by the same variation.	R side paper alignment stop position (F/R direction)	When the adjustment value is increased, the alignment plate stop position is shifted to the F side. When the adjustment value is decreased, the alignment plate stop position is shifted to the R side.	0.3665mm
С	STAPLE REAR	Stapling position adjustment (one position at the rear)	68 - 132	100	When the staple position on the R side is shifted, perform the adjustment.	Staple position (Stapler stop position) (F/R direction)	When the adjustment value is increased, the staple position is shifted to the rear side. When the adjustment value is decreased, the staple position is shifted to the front side.	0.155mm
D	STAPLE FRONT	Stapling position adjustment (one position in front)	68 - 132	100	When the staple position on the F side is shifted, perform the adjustment.	Staple position (Stapler stop position) (F/R direction)	When the adjustment value is increased, the staple position is shifted to the rear side. When the adjustment value is decreased, the staple position is shifted to the front side.	0.155mm
E	STAPLE BOTH	Stapling position adjustment (center position of two positions binding)	68 - 132	100	When the staple off-center is shifted, perform the adjustment.	Staple position (Stapler stop position) (F/R direction)	When the adjustment value is increased, the staple position is shifted to the rear side. When the adjustment value is decreased, the staple position is shifted to the front side.	0.155mm

lte	Item/Display Content Setting Default Purpose (Case where the adjustment value is adjustment is required) Change when the adjustment value is increased or decreased		when the adjustment value is ncreased or decreased	Change when the adjustment value is changed by 1				
F	STAPLE PITCH	Stapling position adjustment (staple pitch of two positions binding)	68 - 132	100	When it is required to change the staple interval, perform the adjustment.	Staple position (Stapler stop position) (F/R direction)	When the adjustment value is increased, the staple interval is increased. When the adjustment value is decreased, the staple interval is decreased.	0.155mm
G	PUNCH CENTER	Punch center positioning sensor	37 - 63	50	When the punch off-center is shifted, perform the adjustment.	Punch position (F/R direction)	When the adjustment value is decreased, the punch position is shifted to the front side. When the adjustment value is increased, the punch position is shifted to the rear side.	0.1441mm
Н	PUNCH HOLE	Punch hole adjustment (paper transport direction)	42 - 58	50	When the punch hole position is shifted in the transport direction, perform the adjustment.	Punch position (Paper transport direction)	When the adjustment value is increased, the punch position is shifted to the paper lead edge side. When the adjustment value is decreased, the punch position is shifted to the paper rear edge side.	0.2584mm

### Saddle stitch finisher (MX-FN10)

	Item/Display	Content	Setting range	Default value	Purpose (Case where the adjustment is required)	Change when the a o	djustment value is increased r decreased	Change when the adjustment value is changed by 1
A	SADDLE POSITION	Saddle stitch position adjustment	25 - 75	50	The adjustment is executed when the saddle staple position is shifted.	Saddle paper lead edge striking plate stop position (Up- down direction)	When the adjustment value is increased, the stapling position is shifted to the lead edge of transported paper. When the adjustment value is decreased, the stapling position is shifted to the rear edge of transported paper.	0.2mm
В	FOLDING POSITION	Saddle folding position adjustment	25 - 75	50	The adjustment is executed when the saddle folding position is shifted.	Saddle paper lead edge striking plate stop position (Up- down direction)	When the adjustment value is increased, the folding position is shifted to the lead edge of transported paper. When the adjustment value is decreased, the folding position is shifted to the rear edge of transported paper.	0.2mm
С	FRONT ADJUST	Alignment position adjustment (front)	35 - 65	50	When the paper alignment capability in the stacker section is improper, the paper alignment width is adjusted.	F side paper alignment plate stop position (F/R direction)	When the adjustment value is increased, the alignment position is shifted to the center. When the adjustment value is decreased, the alignment position is shifted to the outside.	0.2mm
D	REAR ADJUST	Alignment position adjustment (Rear)	35 - 65	50		R side paper alignment plate stop position (F/R direction)	When the adjustment value is increased, the alignment position is shifted to the center. When the adjustment value is decreased, the alignment position is shifted to the outside.	0.2mm
E	STAPLE REAR	Stapling position adjustment (Rear, one position)	25 - 75	50	When the stapling position on the R side is shifted, the adjustment is executed.	Stapling position (stapler stop position) (F/R direction)	When the adjustment value is increased, the distance between the stapling position and the paper edge becomes longer. When the adjustment value is decreased, the distance between the stapling position and the paper edge becomes shorter.	0.2mm

	Item/Display	Content	Setting range	Default value	Purpose (Case where the adjustment is required)	Change when the a or	djustment value is increased r decreased	Change when the adjustment value is changed by 1
F	STAPLE REAR R	Stapling position adjustment (Rear, one position /R series)	45 - 75	50	When the stapling position on the R side is shifted with R series paper, the adjustment is executed.	Stapling position (stapler stop position) (F/R direction)	When the adjustment value is increased, the distance between the stapling position and the paper edge becomes longer. When the adjustment value is decreased, the distance between the stapling position and the paper edge becomes shorter.	0.2mm
G	STAPLE FRONT	Stapling position adjustment (one position in front)	25 - 75	50	When the stapling position on the F side is shifted, the adjustment is executed.	Stapling position (stapler stop position) (F/R direction)	When the adjustment value is decreased, the distance between the stapling position and the paper edge becomes shorter. When the adjustment value is increased, the distance between the stapling position and the paper edge becomes longer.	0.2mm
Н	STAPLE FRONT R	Stapling position adjustment (Front, one position / R series)	25 - 55	50	When the stapling position on the F side is shifted with R series paper, the adjustment is executed.	Stapling position (stapler stop position) (F/R direction)	When the adjustment value is decreased, the distance between the stapling position and the paper edge becomes shorter. When the adjustment value is increased, the distance between the stapling position and the paper edge becomes longer.	0.2mm
I	STAPLE BOTH	Stapling position adjustment (Two positions, center)	45 - 55	50	When the staple off- center is shifted, the adjustment is executed.	Stapling position (stapler stop position) (F/R direction)	When the adjustment value is increased, the stapling position is shifted to the front. When the adjustment value is decreased, the stapling position is shifted to the rear.	0.2mm
J	STAPLE PITCH	Stapling position adjustment (Two positions, pitch)	35 - 62	50	When the stapling interval is to be changed, the adjustment is executed.	Stapling position (stapler stop position) (F/R direction)	When the adjustment value is increased, the pitch of two points is widened. When the adjustment value is decreased, the pitch of two points is narrowed.	0.2mm
К	PUNCH CENTER	Punch center adjustment	35 - 65	50	When the punch off- center is shifted, the adjustment is executed.	Punching position (F/R direction)	When the adjustment value is increased, the hole position is shifted to the front. When the adjustment value is decreased, the hole position is shifted to the rear.	0.2mm
L	PUNCH HOLE	Punch hole position adjustment	30 - 60	50	When the punch hole position is shifted in the transport direction, the adjustment is executed.	Punch position (paper transport direction)	When the adjustment value is increased, the punch hole position is shifted to the rear edge of paper. When the adjustment value is decreased, the punch hole position is shifted to the lead edge of paper.	0.2mm
М	SADDLE_ ADJUST_POS	Saddle alignment position adjustment	35 - 65	50	When the paper alignment capability in the saddle section is improper, the paper alignment width is adjusted.	Saddle paper alignment plate stop position (F/R direction)	When the adjustment value is increased, the alignment plate position is shifted to the center. When the adjustment value is decreased, the alignment plate position is shifted to the outside.	0.2mm
N	GRIPPER_ POS	Gripper exit position adjustment	35 - 65	50	When the gripper discharge position is shifted, the adjustment is executed. (When a JAM or trouble occurs, the adjustment is executed.)	Gripper discharge position (Gripper stop position) (F/R direction)	When the adjustment value is increased, the gripper discharge position is shifted to the front. When the adjustment value is decreased, the gripper discharge position is shifted to the rear.	0.2mm

4-2	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the sen- sors and detectors in the desk/large capac- ity tray (LCC), and the control circuit of those.
Section	Desk/Large capacity tray (LCC)

#### **Operation/Procedure**

The operating conditions of the sensors and detectors are displayed.

The code names of the sensors and the detectors which are active are highlighted.

#### Desk

Display	Content			
D1MDC	Desk 1 installation detection connector			
D1PPD	Desk 1 paper transport detector			
D1ULD	Desk 1 upper limit detector			
D1PED	Desk 1 paper empty detector			
D1PQD	Desk 1 remaining paper quantity detector			
D1PRED1	Desk 1 paper rear edge detector 1			
D1PRED2	Desk 1 paper rear edge detector 2			
D1PRED3	Desk 1 paper rear edge detector 3			
D1PRED4	Desk 1 paper rear edge detector 4			
D2MDC	Desk 2 installation detection connector			
D2PPD	Desk 2 paper transport detector			
D2ULD	Desk 2 upper limit detector			
D2PED	Desk 2 paper empty detector			
D2PQD	Desk 2 remaining paper quantity detector			
D2PRED1	Desk 2 paper rear edge detector 1			
D2PRED2	Desk 2 paper rear edge detector 2			
D2PRED3	Desk 2 paper rear edge detector 3			
D2PRED4	Desk 2 paper rear edge detector 4			

### Tandem LCC (MX-DE20)

Display	Content
DPFD1	Desk 1paper transport detector
D1LUD	Desk 1upper limit detector
D1PED	Desk 1paper empty detector
D1PQD	Desk 1remaining paper quantity detector
D1PPD1	Desk 1paper transport detector 1
D1PPD2	Desk 1paper transport detector 2
D2LUD	Desk 2upper limit detector
D2PED	Desk 2paper empty detector
D2PQD	Desk 2remaining paper quantity detector
DCDT	Tandem tray insertion detection

### A4LCC (MX-LC11)

Display	Content
LPFD	LCC transport detector
LUD	LCC tray upper limit detector
LDD	LCC tray lower limit detector
LPED	LCC tray paper empty detector
LCLD	LCC tray open/close detector
LDSW	LCC upper open/close detection switch
LRE	LCC lift motor encoder
L24VM	LCC24V power monitor
LLSW	LCC upper limit switch
LCCD	LCC main unit connection detection

Operation test/check
Used to check the operations of the loads in the desk/large capacity tray (LCC), and the control circuit of those.
Section.

### Section Desk/Large capacity tray (LCC)

#### **Operation/Procedure**

- 1) Select the load item that is required to operation check with the touch panel key.
- 2) Press [EXECUTE] key.

The selected load performs the operation.

When [EXECUTE] key is pressed, the operation is terminated.

### Desk

Display	Content
D1LM	Tray 1 lift-up motor
D1PFC	Tray 1 paper feed clutch
D2LM	Tray 2 lift-up motor
D2PFC	Tray 2 paper feed clutch
DPFM	Desk transport motor
DPTRC	Desk paper transport clutch

#### Tandem LCC (MX-DE20)

Display	Content				
DPFM	Desk transport motor				
DPTRC	Desk paper transport clutch				
D1LM	Tray 1lift-up motor				
D1PFC	Tray 1paper feed clutch				
D2LM	Tray 2lift-up motor				
D2PFC	Tray 2paper feed clutch				
D2PUS	Tray 2paper feed solenoid				

### A4LCC (MX-LC11)

Display	Content				
LPFM	LCC transport motor				
LLM	LCC lift motor				
LPFC	PFC LCC paper feed clutch				
LPFS LCC paper feed solenoid					
LTRC	LCC transport clutch				

4-5	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the paper feed desk paper transport clutch (DTRC) and the LCC paper transport clutch (LTRC).
Section	Desk/Large capacity tray (LCC)

### Operation/Procedure

### Check the ON operation

Press the button of the code name for checking the ON operation.

Checking is started. When the operation is normal, the button on the display is highlighted. When it is abnormal, the button is not highlighted.

### Check the OFF operation

Press the highlighted button which is ON.

When the operation is normal, the highlighted button on the display returns to the normal display. When it is abnormal, the highlighted display is maintained.

Button	Content	
DTRC	Desk transport clutch	
LTRC	LCC transport clutch	

### 5

5-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the operation of the display, LCD in the operation panel, and control circuit.

Operation panel

#### **Operation/Procedure**

Section

The LCD is changed as shown below.

The contrast changes every 2sec from the current level to MAX  $\rightarrow$  MIN  $\rightarrow$  the current level. During this period, each LED is lighted. The LCD display contrast change and the LED lighting status are checked.

5-2	
Purpose	Operation test/check
Function (Purpose) Used to check the operation of the here lamp and the control circuit.	
Section	Fusing

#### **Operation/Procedure**

- 1) Select the item to be operation checked with the touch panel key.
- 2) Press [EXECUTE] key.

The selected heater lamp operates ON/OFF.

When [EXECUTE] key is pressed, the operation is terminated. Heater lamp operation check method:

Remove the front cabinet upper and the paper exit tray, and the lighting status of each heater lamp can be checked through the clearance between the fusing pressure release drive gear and the frame fusing section.

HL_LM	Heater lamp (B) (Back surface)
HL_UM	Main heater lamp (F) (Front surface)
HL_US	Sub heater lamp (F) (Front surface)

5-3	
Purpose	Operation test/check
Function (Purpose)	Used to check the operation of the scanner
	lamp and the control circuit.

Section Scanner (reading)

#### **Operation/Procedure**

1) Select the item to be operation checked with the touch panel key.

2) Press [EXECUTE] key.

The scanner lamp lights up for 10 sec.

When [EXECUTE] key is pressed, the operation is terminated.

5-4	
Purpose	Operation test/check
Function (Purpose)	Used to check the operation of the dis-
	charge lamp and the control circuit.

### Section Process

### **Operation/Procedure**

 Select a target of the operation check with the touch panel key. When [ALL] key is pressed, all the items are selected.

2) Press [EXECUTE] key.

The selected discharge lamp is lighted for 30 sec. When [EXECUTE] key is pressed, the operation is terminated.

DL_K	Discharge lamp K
DL_C	Discharge lamp C
DL_M	Discharge lamp M
DL_Y	Discharge lamp Y

## 6

6-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the load in the paper transport system (clutches and solenoids) and the control circuits.
Section	Paper transport/Paper exit section

#### **Operation/Procedure**

- 1) Select the item to be operation checked with the touch panel key.
- 2) Press [EXECUTE] key.

The selected load performs the operation.

When [EXECUTE] key is pressed, the operation is terminated.

#### Load operation check method:

The load operation is checked by the operation sound. However, there are some loads which cannot be checked with the operation sound.

Section	Item/Display	Content
Transport/	ADUC1	ADU transport clutch 1
process	PFM	Transport motor
	RRM	Registration motor
	POMF (*1)	Paper exit motor (normal rotation)
	POMR (*1)	Paper exit motor (reverse rotation)
	FUM	Fusing motor
	CPFM	Paper feed motor
	OSM	Offset motor
	CPFC1	Tray vertical transport clutch 1
	CPFC2	Tray vertical transport clutch 2
	TRC_DSK	Desk clutch
	TRC_LCC (*2)	LCC clutch
	TRC_FIN	Finisher clutch
	HPFC	Transport roller clutch
	PFC	Vertical transport clutch
	RRC	Registration roller clutch
Paper feed	CLUM1	Paper tray lift motor (Paper feed tray 1)
	CPUC1	Paper feed clutch (Paper feed tray 1)
	CLUM2	Paper tray lift motor (Paper feed tray 2)
	CPUC2	Paper feed clutch (Paper feed tray 2)
	MPFS	Paper feed solenoid (Manual paper feed)

*1: If "Normal rotation" and "Reverse rotation" of a same load are displayed as different items, when the both are selected at the same time, "Normal rotation" is performed. In addition, a change in the rotating direction is accepted only when the operation is stopped.

*2: Displayed but not installed in some models.
6-2	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of each fan motor and its control circuit.
Section	Others

**Operation/Procedure** 

- 1) Select the item to be operation checked with the touch panel key.
- 2) Press [EXECUTE] key.

The selected load performs the operation.

When [EXECUTE] key is pressed, the operation is terminated. Press [ALL] key to select all the fans collectively.

Load operation check method:

The load operation is checked by the operation sound. However, there are some loads which cannot be checked with the operation sound.

Display	Content
PROFM2	Process fan 2
POFM	Paper exit cooling fan (Drives POFM1 and POFM2 at the same time.)
FUFM	Fusing cooling fan
PROFM1	Process fan 1
PSFM	Power cooling fan
LSUFM	LSU cooling fan motor

6-3	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the transport unit and the control circuit.
Section	Process (Transport)

#### **Operation/Procedure**

1) Select the operation mode with the mode select button.

Mode select button	Content
TC1	Primary transfer (normal rotation)
TC1_R	Primary transfer (reverse rotation)
TC2	Secondary transfer

 When [EXECUTE] key is pressed, the operation of the mode selected in 1) is performed.

Mode select button	Mode display	Content	NOTE
TC1	BLACK	Monochrome mode position	Black mode position $\rightarrow$ Color mode position $\rightarrow$ Black mode
	COLOR	Color mode position	position $\rightarrow$ Drum separation position $\rightarrow$ (Black mode
	FREE	Non-transport position	position) (Repeated in this sequence.)
TC1_R	BLACK	Monochrome mode position	Black mode position $\rightarrow$ Drum separation position $\rightarrow$ Color
	FREE	Non-transport position	mode position $\rightarrow$ (Black mode position) (Repeated in
	COLOR	Color mode position	this sequence.)
TC2	PRINT	Print position	Print position - Transfer
	FREE	Non-transport position	position - Non-transfer position (Repeated in this sequence)

6-6	
Purpose	Operation test/check
Function (Purpose)	Used to perform fusing pressure release and applying, and to check the operations of the control circuits.
Section	Fusing

# Operation/Procedure

- 1) Press [FUSER] key to highlight it.
- Press [EXECUTE] key, and fusing pressure applying and fusing pressure release are repeated.

During this period, the status of the fusing roller pressure is displayed.

PRINT	Fusing pressure applying	Fusing pressure applying $\rightarrow$ Fusing pressure release $\rightarrow$ (Fusing pressure
FREE	Fusing pressure release	applying) The operation is repeated.

6-90	
Purpose	Setting
Function (Purpose)	Used to reset the machine to the factory setting. (The scanner is set to the lock enable position)
Section	Scanner

# Operation/Procedure

1) Press [EXECUTE] key.

The scanner is shifted to the lock enable position and stopped.

When [CLOSE] key is pressed, the display goes into the copy operation menu in the simulation mode.

7-1						
Purpose	Setting					
Function (Purpose)	Used to	set	the	operating	conditions	of
	aging.					

#### Section Operation/Procedure

1) Select an item to be set with the touch panel key.

Others

- 2) Press [EXECUTE] key.
  - The machine is rebooted in the aging mode.

The aging operation condition set by this mode is maintained hereafter unless the power is turned off or the setting is changed.

AGING	Aging operation setup
INTERVAL	Intermittent operation setting
MISFEED DISABLE	JAM detection ignoring setting
FUSING DISABLE	Fusing unit ignoring setting
WARMUP DISABLE	Warming up ignoring setting
DV CHECK DISABLE	Developing unit ignoring setting
SHADING DISABLE	Shading correction operation omitting setting
CCD GAIN FREE	CCD gain adjustment omitting setting

7-6	
Purpose	Setting
Function (Purpose)	Used to set the operating intermittent aging
	cycle.

#### Section Operation/Procedure

- 1) Enter the intermittent aging operation cycle (unit: sec) with 10-key.
- 2) Press [OK] key.
  - The time entered in procedure 1) is set.
  - * The interval time that can be set is 1 to 900 (sec).

The aging operation condition set by this mode is maintained hereafter unless the power is turned off or the setting is changed.

7-8	
Purpose	Operation display
Function (Purpose)	Used to display the warm-up time.
Section	

# **Operation/Procedure**

Press [EXECUTE] key.

Counting of the warm-up time is started and the time required for warm-up is displayed

* Interruption of counting by pressing [EXECUTE] key is inhibited.

7-9	
Purpose	Operation test/check
Function (Purpose)	Color setting in the color copy test mode (Used to check the copy operation and the image quality for each color).

# Section

#### **Operation/Procedure**

- Select the copy color with the touch panel key. (Two or more colors can be selected.) The key of the selected color is highlighted.
- 2) Press [EXECUTE] key.

Copying is performed with the selected color.

К	Setup/cancel of black
С	Setup/cancel of cyan
М	Setup/cancel of magenta
Y	Setup/cancel of yellow

7-12	
Purpose	Operation test/check
Function (Purpose)	The document reading number of sheets
	setting (for aging operation)

# Section RSPF

#### **Operation/Procedure**

- 1) Set document reading quantity with 10-key.
  - (Setting range:0 255)
- 2) Press [OK] key. The set value is saved.

The aging operation condition set by this mode is maintained hereafter unless the power is turned off or the setting is changed.



8-1					
Purpose	Operation test/check/adjustment				
Function (Purpose)	Used to check and adjust the operations of the developing voltage in each print mode and the control circuit. * When the middle speed is adjusted, the low speed are also adjusted simulta- neously.				
Section	Process (Developing)				

Operation/Procedure

- 1) Select a speed with [MIDDLE] and [LOW] keys on the touch panel.
- 2) Select a target item to be adjusted with scroll keys.
- 3) Enter the setting value with 10-key. (The value specified on the label of the high voltage PWB must be entered.)
  - * When the  $\bigtriangleup \bigtriangledown$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 4) Press [EXECUTE] key.

The set value is saved and the voltage entered with step 3) is output for 30 sec.

When [EXECUTE] key is pressed, the output is terminated.

Item/Display (Mode)		Content		Adjustment range	Actual voltage	
MIDDLE	A	MIDDLE SPEED DVB_K	Developing bias voltage (Middle speed mode)	К	0 - 600	-450V ±5V
	В	MIDDLE SPEED DVB_C	Developing bias voltage (Middle speed mode)	С	0 - 600	–450V ±5∨
	С	MIDDLE SPEED DVB_M	Developing bias voltage (Middle speed mode)	М	0 - 600	–450V ±5∨
	D	MIDDLE SPEED DVB_Y	Developing bias voltage (Middle speed mode)	Y	0 - 600	-450V ±5∨
LOW	A	LOW SPEED DVB_K	Developing bias voltage (Low speed mode)	К	0 - 600	-450V ±5V
	В	LOW SPEED DVB_C	Developing bias voltage (Low speed mode)	С	0 - 600	-430V ±5V
	С	LOW SPEED DVB_M	Developing bias voltage (Low speed mode)	М	0 - 600	-430V ±5V
	D	LOW SPEED DVB_Y	Developing bias voltage (Low speed mode)	Y	0 - 600	-430V ±5V

8-2	
Purpose	Operation test/check/adjustment
Function (Purpose)	Used to check and adjust the operation of the main charger grid voltage in each printer mode and the control circuit. * When the middle speed is adjusted, the low speed are also adjusted simulta- neously.
Section	Process (Charging)

## **Operation/Procedure**

- 1) Select a speed with [MIDDLE] and [LOW] keys on the touch panel.
- 2) Select a target item to be adjusted with scroll keys.
- Enter the adjustment value with 10-key. (The value specified on the label of the high voltage PWB must be entered.)
  - * When the  $\bigtriangleup \bigtriangledown$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 4) Press [EXECUTE] key.

The set value is saved and the voltage entered with step 3) is output for 30 sec.

When [EXECUTE] key is pressed, the output is terminated.

					Adjustment	Actual voltage	Actual voltage
Item/Display (Mode)		/Display (Mode)	Content	range	26cpm/31cpm machine	36cpm machine	
MIDDL	Α	MIDDLE SPEED GB_K	Main charger grid voltage (Middle speed mode)	Κ	150 - 850	-620V±5V	-625V±5V
E	В	MIDDLE SPEED GB_C	Main charger grid voltage (Middle speed mode)	С	150 - 850	-620V±5V	-625V±5V
	С	MIDDLE SPEED GB_M	Main charger grid voltage (Middle speed mode)	Μ	150 - 850	-620V±5V	-625V±5V
	D	MIDDLE SPEED GB_Y	Main charger grid voltage (Middle speed mode)	Y	150 - 850	-620V±5V	-625V±5V
LOW	Α	LOW SPEED GB_K	Main charger grid voltage (Low speed mode)	Κ	150 - 850	-610V±5V	-610V±5V
	В	LOW SPEED GB_C	Main charger grid voltage (Low speed mode)	С	150 - 850	-590V±5V	–590V±5V
	С	LOW SPEED GB_M	Main charger grid voltage (Low speed mode)	М	150 - 850	-590V±5V	–590V±5V
	D	LOW SPEED GB_Y	Main charger grid voltage (Low speed mode)	Y	150 - 850	-590V±5V	-590V±5V

8-6	
Purpose	Operation test/check/adjustment
Function (Purpose)	Used to check and adjust the operation of
	the transport voltage and the control circuit.

Section Process (Transport)

**Operation/Procedure** 

1) Select a target item to be adjusted with scroll keys.

2) Enter the set value with 10-key.

Enter the default value specified on the following list.

3) Press [EXECUTE] key.

The set value is saved and the voltage corresponding to the set value is output for 30 sec.

When [EXECUTE] key is pressed, the output is terminated.

Item / Display Content				Setting	g Default value			
						range	26cpm 31cpm machine	36cpm machine
А	TC1 LOW SPEED CL K		Color	K	Low speed	51 to 255	80	80
В	TC1 MIDDLE SPEED CL K			r.	Middle speed	51 to 255	109	117
С	TC1 LOW SPEED CL C			C	Low speed	51 to 255	80	80
D	TC1 MIDDLE SPEED CL C	Primary		C	Middle speed	51 to 255	109	117
ш	TC1 LOW SPEED CL M	transfer		M	Low speed	51 to 255	80	80
F	TC1 MIDDLE SPEED CL M	adiustment		IVI	Middle speed	51 to 255	109	117
G	TC1 LOW SPEED CL Y	value		V	Low speed	51 to 255	80	80
Н	TC1 MIDDLE SPEED CL Y	Talao		T	Middle speed	51 to 255	109	117
	TC1 LOW SPEED BW K		Monochro	K	Low speed	51 to 255	80	80
J	TC1 MIDDLE SPEED BW K		me	K	Middle speed	51 to 255	109	117
К	TC2 PLAIN CL SPX		Color		Front surface	51 to 255	103	110
L	TC2 PLAIN CL DPX		000	Standard	Back surface	51 to 255	90	96
М	TC2 PLAIN BW SPX		Monochro	paper	Front surface	51 to 255	103	110
Ν	TC2 PLAIN BW DPX		me		Back surface	51 to 255	90	96
0	TC2 HEAVY CL SPX		Color		Front surface	51 to 255	83	83
Р	TC2 HEAVY CL DPX	000	Heavy	Back surface	51 to 255	76	76	
Q	TC2 HEAVY BW SPX		Monochro	paper	Front surface	51 to 255	69	69
R	TC2 HEAVY BW DPX	Secondary	me		Back surface	51 to 255	69	69
S	TC2 HEAVY2 CL	transfer	Color	Heavy paper 2		51 to 255	83	83
т	TC2 HEAVY2 BW	bias	Monochro me			51 to 255	69	69
U	TC2 HEAVY3 CL	value	Color		2014/	51 to 255	83	80
V	TC2 HEAVY3 BW		Monochro me	pa	per 3	51 to 255	69	69
W	TC2 OHP CL		Color			51 to 255	69	69
х	TC2 OHP BW		Monochro me	С	HP	51 to 255	69	69
Y	TC2 ENVELOPE CL	]	Color			51 to 255	69	69
Z	TC2 ENVELOPE BW		Monochro me	Env	velope	51 to 255	69	69

Item / Display			Setting	Defaul	t value			
						range	26cpm 31cpm machine	36cpm machine
AA	TC2 THIN CL	Secondary	Color			51 to 255	103	110
AB	TC2 THIN BW	transfer Monochro bias me	Monochro me	Thin	Thin paper		103	110
AC	TC2 GLOSSY CL	adjustment	Color			51 to 255	83	83
AD	TC2 GLOSSY BW	value Monochro me		Gross	spaper	51 to 255	69	69
AE	TC2 CLEANING	Secondary	Secondary Cleaning process (negative pole)		ative pole)	51 to 255	59	59
AF	TC2 CLEAN LOW SPD	transfer		_ow speed print r	node	0 to 255	26	26
AG	TC2 CLEAN MIDDLE SPD	cleaning bias Middle		iddle speed print	mode	0 to 255	26	26
AH	TC2 CLEAN CLEANING	adjustment value Cle		aning bias (positi	ve pole)	0 to 255	102	102
AI	PTC LOW SPEED CL			Color	Low speed	51 to 255	73	73
AJ	PTC MIDDLE SPEED CL	PTC cur	rent	Color	Middle speed	51 to 255	73	73
AK	PTC LOW SPEED BW	adjustment	t value	Manaahrama	Low speed	51 to 255	73	73
AL	PTC MIDDLE SPEED BW			Monochrome	Middle speed	51 to 255	73	73
AM	CASE VOLT LOW CL			Color	Low speed	0 to 255	0	0
AN	CASE VOLT MID CL	PTC volt	tage	000	Middle speed	0 to 255	0	0
AO	CASE VOLT LOW BW	adjustment	t value	Monophroma	Low speed	0 to 255	0	0
AP	CASE VOLT MID BW		-		Middle speed	0 to 255	0	0

# 9

9-2	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the sen- sors and detectors in the paper reverse section (duplex section) and its control cir- cuit.
Section	Duplex

# Operation/Procedure

The operating conditions of the sensors and detectors are displayed.

The code names of the sensors and the detectors which are active are highlighted.

APPD1	ADU paper transport detector 1
APPD2	ADU paper transport detector 2
DSW_ADU	ADU paper guide open/close detector

Operation test/check
Used to check the operations of the load in
the paper reverse section (duplex section) and its control circuit

Section	Duplex

# **Operation/Procedure**

- 1) Select the item to be operation checked with the touch panel key.
- 2) Press [EXECUTE] key.

The selected load performs the operation.

When [EXECUTE] key is pressed, the operation is terminated.

Display	Content
ADUC1	ADU transport clutch 1 (*)
ADUM	ADU motor
ADUGS	ADU gate solenoid

*: Not used, but the button is displayed.



10-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the toner supply mechanism (toner motor) and the related circuit.
Section	Process (Developing)
Operation/Procedure	

- 1) Select a target of the operation check with the touch panel key. When [ALL] key is pressed, all the items are selected.
- Press [EXECUTE] key. The selected load operation is performed for 10 sec.

When [EXECUTE] key is pressed, the operation is terminated.

# Important

This simulation must be executed without installing the toner cartridges.

If this simulation is executed with the toner cartridges installed, toner will be forcibly supplied to the developing unit, resulting in overtoner.

If this simulation is erroneously executed with the toner cartridges installed, overtoner state may be deleted by making a few black background copy in the single color copy mode of the target color.

TNM_K	Toner motor K
TNM_C	Toner motor C
TNM_M	Toner motor M
TNM_Y	Toner motor Y



13		
Purpose	Cancel (Trouble etc.)	
Function (Purpose)	Used to cancel the self-diag "U1" trouble.	
Section		

# **Operation/Procedure**

- 1) Press [EXECUTE] key.
- 2) Press [YES] key to execute cancellation of the trouble.

# 14

14		
Purpose	Cancel (Trouble etc.)	
Function (Purpose)	Used to cancel the self-diag H3, H4, H5	
	troubles.	

# Section

- Operation/Procedure
- 1) Press [EXECUTE] key.
- 2) Press [YES] key to execute cancellation of the trouble.

# 15

15	
Purpose	Clear/Cancel (Trouble etc.)
Function (Purpose)	Used to cancel the self-diag "U6" trouble.
Section	LCC

**Operation/Procedure** 

- 1) Press [EXECUTE] key.
- 2) Press [YES] key to execute cancellation of the trouble.

# 16

16		
Purpose	Clear/Cancel (Trouble etc.)	
Function (Purpose)	Used to cancel the self-diag "U2" trouble.	
Section	MFP PWB / PCU PWB / SCU PWB	
Operation/Procedure		

#### Operation/Procedure

- 1) Press [EXECUTE] key.
- 2) Press [YES] key to execute cancellation of the trouble.

# 21

21-1	
Purpose	Setting
Function (Purpose)	Used to set the maintenance cycle.
Section	

#### **Operation/Procedure**

- * Do not change the default setting value of the maintenance counter on SIM21-1. The replacement timing of the fusing cleaning roller, the filter and PS paper dust removal cleaner may not clarify.
- 1) Select a target item of setting with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key. (The set value is saved.)

	tem/Display	Content	Setting range	Default value
Α	MAINTE-	Mainte-	0:	200K
	NANCE	nance counter	Default	
	COUNTER	(Total)	1 – 300: 1K –	
	(TOTAL)		300K	
			999:	
			Free	
В	MAINTE-	Mainte-	0:	200K
	NANCE	nance counter	Default	
	COUNTER	(Color)	1 – 300: 1K –	
	(COLOR)		300K	
			999:	
			Free	

# 22

22-1	
Purpose	Adjustment/Setting/Operation data output/ Check
Function (Purpose)	Used to check the print count value in each section and each operation mode. (Used to check the maintenance timing.)
Section	

#### **Operation/Procedure**

Change the display page with scroll key on the touch panel.

ltem	Display	Content		
Total output quantity	TOTAL OUT (BW)	Total output quantity of black and white	All prints including jams	
	TOTAL OUT (COL)	Total output quantity of color	All prints including jams	
Total use quantity	TOTAL (BW)	Total use quantity of black and white	Effective paper (including self print, excluding jams)	
	TOTAL (COL)	Total use quantity of full color	Effective paper (including self print, excluding jams)	
	TOTAL (2COL)	Total use quantity of 2-color	Effective paper (including self print, excluding jams)	
	TOTAL (3COL)	Total use quantity of 3-color	Effective paper (including self print, excluding jams)	
	TOTAL (SGL_COL)	Total use quantity of single color	Effective paper (including self print, excluding jams)	
Сору	COPY (BW)	Black and white copy counter	Billing target (excluding self print)	
	COPY (COL)	Full color copy counter	Billing target (excluding self print)	
	COPY (2COL)	2-color copy counter	Billing target (excluding self print)	
	COPY (SGL_COL)	Single color copy counter	Billing target (excluding self print)	

# 14/Jun : '14/Jun

Item	Display	Content		
Print	PRINT (BW)	Black and white	Billing target	
		print counter	(excluding self print)	
	PRINT (COL)	Full color print	Billing target	
		counter	(excluding self print)	
	PRINT (2COL)	2-color print	Billing target	
		counter	(excluding self print)	
	PRINT (3COL)	3-color print	Billing target	
		counter	(excluding self print)	
	PRINT	Single color print	Billing target	
	(SGL_COL)	counter	(excluding self print)	
Document	DOC FIL (BW)	Black and white		
filing		document filing		
		print counter		
	DOC FIL	Color document		
	(COL)	filing print counter		
	DOC FIL	2-color document		
	(2COL)	filing print counter		
	DOC FIL(SGL	Single color		
	COL)	document filing		
		print counter		
Other	OTHER (BW)	Black and white	Self print quantity	
		other counter		
	OTHER (COL)	Color other	Self print quantity	
		counter		
PCI	PCI OPE-	PCI counter	PCI accumulated	
	TIME		operation time (H)	

22-2	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to check the total number of misfeed and troubles. (When the number of total jam is considerably great, it is judged as necessary for repair.)

# Section

#### **Operation/Procedure**

The paper jam, trouble counter value is displayed.

MACHINE JAM	Machine JAM counter
RSPF JAM	RSPF JAM counter
TROUBLE	Trouble counter

22-3	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to check misfeed positions and the misfeed count of each position. * Presumption of the faulty point by this data is possible.
Section	

# Operation/Procedure

The paper jam and misfeed history is displayed from the latest one up to 50 items. (The old ones are deleted sequentially.)

22-4	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to check the trouble (self diag) his- tory.

# Section

# **Operation/Procedure**

The trouble history is displayed from the latest one up to 30 items. (The old ones are deleted sequentially.)

22-5	
Purpose	Others
Function (Purpose)	Used to check the ROM version of each unit (section).
Section	Firmware

#### **Operation/Procedure**

The ROM version of the installed unit in each section is displayed. When there is any trouble in the software, use this simulation to check the ROM version, and upgrade the version if necessary.

S/N	Serial No. (The codes for November and December are "X" and "Y" respectively.)
ICUM(MAIN)	ICUM(MAIN section)
ICUM(SUB)	ICUM(SUB section)
ICUM(BIOS)	ICUM(BIOS section)
ICU (MAIN)	ICU (Main section)
ICU (BOOT)	ICU (Boot section)
ICU (SUB)	ICU (Sub section) (ARM9)
LANGUAGE	Language support data version
UICONTENTS	Contents data for display
PCL (PROFILE)	PCL (Color profile)
PCU	PCU
SCU	SCU
FAX1 (MAIN)	FAX 1-Line (Main section)
FAX2 (MAIN)	FAX 2-Line (Main section)
FAX3 (MAIN)	FAX 3-Line (Main section)
DESK	Desk unit
LCC	LCC
FINISHER	Finisher
PUNCH	Punch unit
NIC	NIC
POWER-CON	Power controller
E-MANUAL	Operation manual (HDD storage)
WATER MARK	Watermark (HDD storage)
ESCP	ESCP font ROM
ACRE (MAIN)	Enhanced compression kit (Main section)
ACRE (DATA)	Enhanced compression kit (Data section)
PCI	PCI
EOSA	Embedded OSA

22-6	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to output the setting/adjustment data (simulation, FAX soft switch, counter), the firmware version, and the counter list.
Section	

#### **Operation/Procedure**

- * When installing or servicing, this simulation is executed to print the adjustment data and set data for use in the next servicing. (Memory trouble, PWB replacement, etc.)
- 1) Select the print list mode with 10-key.

Item/Display		Print list mode	Print content
A	DATA PATTERN	1	Firmware version, counter data, etc.
		2	SIM50-24 data
		3	Data related to the process control

 Press [EXECUTE] key to start printing the list selected in step 1).



22-8

Purpose Function (Purpose)

Adjustment/Setting/Operation data check Used to check the number of operations (counter value) of the finisher, the RSPF, and the scan (reading) unit.

Section **Operation/Procedure** 

The counter values of the finisher, the RSPF, and the scanner related counters are displayed.

SPF	Document feed quantity (The number of sheets of discharged documents)
SCAN	Number of times of scan
STAPLER	Staple counter
PUNCHER	Puncher counter
STAMP	Stamp counter
COVER	Document cover open/close counter
HP_ON	Number of scanner HP detection
OC LAMP TIME	Total lighting time of the scanner lamp (* hour * minutes)
SADDLE STAPLER	Saddle staple counter
SADDLE V FOLD	Saddle finisher V fold counter

22-9	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to check the number of use (print quantity) of each paper feed section.
Section	Paper feed, ADU

**Operation/Procedure** 

The counter values related to paper feed are displayed.

TRAY1	Paper feed counter (Paper feed tray 1)		
TRAY2	Paper feed counter (Paper feed tray 2)		
TRAY3	Paper feed counter (Paper feed tray 3)		
TRAY4	Paper feed counter (Paper feed tray 4)		
MFT TOTAL	Manual paper feed counter (Total)		
MFT HEAVY	Manual paper feed counter (Heavy paper)		
MFT OHP	Manual paper feed counter (OHP)		
MFT ENV	Manual paper feed counter (Envelope)		
LCC	LCC paper feed counter		
ADU	ADU paper transport counter (Paper reverse section)		

22-10	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to check the system configuration
	(option, internal hardware).

# Section

Δ

А

**Operation/Procedure** 

The system configuration is displayed.

(The model names of the installed devices and options are displayed.)

MACHINE	MX-2640N	Main unit
	MX-3140N	
	MX-3640N	
	MX-3140N A	
	MX-2640NR	
	MX-3140NR	
	MX-3640NR	
SPF	STANDARD	Reversing single pass feeder
STAMP	AR-SU1	Finish stamp
DESK	MX-DE12	Stand/1x500 sheet paper drawer
	MX-DE13	Stand/2x500 sheet paper drawer
	MX-DE14	Stand/3x500 sheet paper drawer
	MX-DE20	Stand 500&2000 sheet paper drawer
	MX-LC11	Large capacity tray

PUNCHER	MX-PN11A	Punch unit
	MX-PN11B	
	MX-PN11C	
	MX-PN11D	
	MX-PNX5A	
	MX-PNX5B	
	MX-PNX5C	
	MX-PNX5D	
FINISHER	MX-FN17	Inner finisher
	MX-FN10	Saddle stitch finisher (1K)
FAX1	MX-FX11	Facsimile expansion kit
PRINTER	STANDARD	Printer expansion kit (PCL)
PS	STANDARD	PS expansion kit
XPS	MX-PUX1	XPS expansion kit
SECURITY	MX-FR41U	Data security kit (commercial version)
AIM	MX-AMX1	Application integration module
SDRAM (SYS)	*****MB	SDRAM capacity
SDRAM (ICU)	*****MB	SDRAM capacity
HDD	*****MB	Hard disk capacity
SD	*****MB	SD Card capacity
NIC	STANDARD	NIC
BARCODE	MX-PF10	Bar code font
INTERNET-FAX	MX-FWX1	Internet Fax expansion kit
ACM(*)	MX-AMX2	Application communication module
EAM(*)	MX-AMX3	External account module
PCI	CONNECT	PCI generating unit
CF	****GB	Compact flash capacity

(*) Displayed only in the OSA models.

22-11					
Purpose	Adjustment/Setting/Operation data check				
Function (Purpose)	Used to check the use frequency (send/ receive) of FAX. (Only when FAX is installed)				
Section	FAX				

#### **Operation/Procedure**

The values of the FAX send counter and the FAX receive counter are displayed.

FAX OUTPUT	FAX print quantity counter (for line 1)
FAX SEND	FAX send counter
FAX RECEIVED	FAX receive counter
SEND IMAGES	FAX send quantity counter (for line 1)
SEND TIME	FAX send time
RECEIVED TIME	FAX receive time

22-12				
Purpose	Adjustment/Setting/Operation data check			
Function (Purpose)	Used to check the RSPF misfeed positions and the number of misfeed at each posi- tion. (When the number of misfeed is con- siderably great, it can be judged as necessary for repair.)			
Section	RSPF			

# Section

# **Operation/Procedure**

The paper jam and misfeed history is displayed from the latest one up to 50 items. (The old ones are deleted sequentially.)

# 22-13

# Purpose

Adjustment/Setting/Operation data check

Function (Purpose)

Used to check the operating time of the process section (OPC drum, DV unit, toner cartridge) and the fusing unit

Section Process

#### **Operation/Procedure**

The number of prints and the number of rotations in the process section are displayed.

ltem/Display	Content	Print counter	RPM	Number of	Life meter	Number of remaining
				use days		days
MAINTENANCE ALL	Maintenance counter (Total) (Counter)	Max. 8	Not displayed	0 - 999	0 - 100 (%)	0 - 365
MAINTENANCE COL	Maintenance counter (Color)	Max. 8	Not displayed	0 - 999	0 - 100 (%)	0 - 365
FUSING BELT	Fusing belt	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
FUSING ROLLER	Fusing roller	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
PRESSURE ROLLER	Fusing pressure roller	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
FUSING LOAD	Fusing pressure release roller	Not displayed	Max. 8	Not displayed	Not displayed	Not displayed
SEPARATE PAWL	Fusing separation pawl	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
SEPARATE PLATE	Fusing separation plate	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
FUSING WEB UNIT	Fusing web unit	Max. 8	Not displayed	0 - 999	0 - 100 (%)	0 - 365
FUSING WEB SEND	Fusing web cleaning send counter	0 - 65535	Not displayed	Not displayed	Not displayed	Not displayed
TC1 BELT	Primary transfer belt	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
TRANSFER BLADE	Transfer cleaning blade	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
PTC	PTC	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
TC2 BELT	Secondary transfer belt	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
PS PAPER	Paper dust cleaner	Max. 8	Not displayed	0 - 999	0 - 100 (%)	0 - 365
OZONE FILTER	Ozone filter	Max. 8	Not displayed	0 - 999	0 - 100 (%)	0 - 365
DEVE CTRG (K)	DV unit (K)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DEVE CTRG (C)	DV unit (C)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DEVE CTRG (M)	DV unit (M)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DEVE CTRG (Y)	DV unit (Y)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DRUM CTRG (K)	OPC drum unit (K)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DRUM CTRG (C)	OPC drum unit (C)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DRUM CTRG (M)	OPC drum unit (M)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DRUM CTRG (Y)	OPC drum unit (Y)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
MAIN CHARGER (K)	Main charger (K)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
MAIN CHARGER (C)	Main charger (C)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
MAIN CHARGER (M)	Main charger (M)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
MAIN CHARGER (Y)	Main charger (Y)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DRUM BLADE (K)	OPC drum cleaning blade K	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DRUM BLADE (C)	OPC drum cleaning blade C	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DRUM BLADE (M)	OPC drum cleaning blade M	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
DRUM BLADE (Y)	OPC drum cleaning blade Y	Max. 8	Max. 8	0 - 999	0 - 100 (%)	0 - 365
TONER CTRG (K)	Toner cartridge (K)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	Not displayed
TONER CTRG (C)	Toner cartridge (C)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	Not displayed
TONER CTRG (M)	Toner cartridge (M)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	Not displayed
TONER CTRG (Y)	Toner cartridge (Y)	Max. 8	Max. 8	0 - 999	0 - 100 (%)	Not displayed

# 22-14

Purpose	Adjustment/Setting/Operation data check		
Function (Purpose)	Used to display the use status of the toner		
	cartridge.		

Section Process

**Operation/Procedure** 

The status of the toner cartridge is displayed.

Display item	Content	Accumulated No. of installed cartridges (Unit)	Accumulated No. of near near end (Unit)	Accumulated No. of end (Unit)	Remaining quantity (Unit: %)
		INSTALL	NN END	END	RESIDUAL
TONER (K)	Toner cartridge use counter (K)	0 - 255	0 - 255	0 - 255	0-25%
TONER (C)	Toner cartridge use counter (C)				25-50%
TONER (M)	Toner cartridge use counter (M)				50-75%
TONER (Y)	Toner cartridge use counter (Y)				75-100%

22-18	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to display the user data delete history.
Section	

# **Operation/Procedure**

The date and time of the user data delete are displayed.

Display item		Contont	
Item name	Date	Content	
START	Year/month/day/hour/min.	Delete history (Date and time of operation start)	
END	Year/month/day/hour/min.	Delete history (Date and time of operation end)	

22-19	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to check the values of the counters
	related to the scan - image send.

# Section

#### **Operation/Procedure**

Used to display the counter value related to the network scanner Change the display with scroll key.

Item/Display		Content
Network	NET SCN	Network scanner document read quantity
scanner	ORG_B/W	counter (B/W scan job)
	NET SCN	Network scanner document read quantity
	ORG_CL	counter (Color scan job)
	NET SCN	Network scanner document read quantity
	ORG_2CL	counter (2-Color scan job)
	NET SCN	Network scanner document read quantity
	ORG_SGL	counter (Single-color scan job)
Internet	INTERNET FAX	Number of internet FAX output
FAX	OUTPUT	
	INTERNET FAX	Number of internet FAX sending page
	SEND OUTPUT	
		Number of internet FAX receive
		Number of internet FAX send
	SEND	Number of Internet I AX send
E-Mail	MAIL	Number of times of E-MAIL send
	COUNTER	
FTP	FTP COUNTER	Number of FTP send
Other	SMB SEND	Number of SMB send
	USB CNT	Number of times of USB storage
	TRIAL	Trial mode counter
	MODE_B&C	(B/W & COLOR scan job)
	SCAN TO	SCAN TO HDD record quantity (B/W)
	HDD_B/W	
	SCAN TO	SCAN TO HDD record quantity
	HDD_CL	(COLOR)
	SCAN TO	SCAN TO HDD record quantity
	HDD_2CL	(2-COLOR)
	SCAN TO	SCAN TO HDD record quantity
1	HDD SGL	(SINGLE color)

22-40	
Purpose	Error contents display
Function (Purpose)	Used to display the error code list and the contents.

# Section

Operation/Procedure

1) Select the main error code.

The sub error code and the contents are displayed.

22-42	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to check the JAM/trouble data
Section	

**Operation/Procedure** 

- 1) Select the item to be checked with the touch panel key.
- 2) Printable with [COLOR] and [MONO] keys.

	Cou	Inter		Cor	ntent		Max.	
Display data	Display	Content	JAM CODE/ TROUBLE CODE	DATE/TIME	TOTAL COUNT(BW)	TOTAL COUNT(CL)	number of histories	Remarks
PAPER JAM	PAPER JAM COUNT	Number of machine JAM troubles	Generated JAM code (Machine)	Generated date/time (YY/MM/DD	Total output quantity of black and	Total output quantity of color	50	The head is the latest, and the bottom is the oldest. The max. number of histories is 50.
SPF JAM	SPF JAM COUNT	Number of SPF JAM troubles	Generated JAM code (SPF)	HH:MM:SS)	white		50	When 50 is exceeded, the oldest one is not displayed sequentially.
TROUBLE	TROUBLE COUNT	Number of troubles	Generated trouble code				20	The head is the latest, and the bottom is the oldest. The max. number of histories is 30.
							30	When 30 is exceeded, the oldest one is not displayed sequentially.

22-43	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	JAM data details display
Section	

#### **Operation/Procedure**

1) Select the item to be checked with the touch panel key.

When [COUNTER] key is pressed, the JAM counter, the paper feed counter, and the paper feed retry counter are displayed. When [HISTORY1] key is pressed, the JAM history is displayed.

When [HISTORY2] key is pressed, the temperature and humidity data are displayed.

2) Printable with [COLOR] and [MONO] keys.

# Display data and contents (COUNTER)

Item	Content
PAPER JAM COUNT	Number of machine JAM troubles
PAPER FEED COUNTER	Paper feed counter (Similar with SIM22-09 display content)
PAPER FEED RETRY COUNTER	Paper feed retry counter (Similar with SIM27-18 display content)

#### Display data and contents (HISTORY1)

ltem	Content	Description
NO	No	History number
JAM CODE	JAM Code	Jam code main
DATE/TIME	Date/Time	Occurrence date
TOTAL_BW	Total Count (BW)	Total counter (B/W)
TOTAL_CL	Total Count (CL)	Total counter (color)
P_S (*1)	Paper Size	Paper size
P_T (*1)	Paper Type	Paper type
JOB (*1)	Job Mode	Job mode
JN	Job No	First after JOB start or not
OF	Offset	Paper exit: Offset
EP	Exit Position	Paper exit: Exit position
PC	Punch	Paper exit: Punch
SP	Staple	Paper exit: Staple

*1: Refer to the detail display content of HISTORY1.

# Display data and contents (HISTORY2)

Item	Content
NO.	History number
DATE/TIME	Occurrence date
TH_M	External air temperature sensor temperature/AD value
HUD_M	External air humidity sensor humidity/AD value
TH1_LSU	LSU thermistor 1 temperature/AD value
TH2_LSU	LSU thermistor 2 temperature/AD value
TH_UM	Fusing upper main thermistor (differential) temperature/AD value
TH_UM_CS	Fusing upper main thermistor (compensation) temperature/AD value
TUMD	Fusing upper main thermistor (detection) AD value
TH_US1	Fusing upper sub thermistor (differential) temperature/AD value
TH_US1_CS	Fusing upper sub thermistor (compensation) temperature/AD value
TU1D	Fusing upper sub thermistor (detection) AD value
TH_LM1	Fusing lower main thermistor (differential) temperature/AD value
TH_LM1_CS	Fusing lower main thermistor (compensation) temperature/AD value
TL1D	Fusing lower main thermistor (detection) AD value
TH_US2	Fusing upper sub thermistor 2 temperature/AD value
TH_LM2	Fusing lower main thermistor 2 temperature/AD value

# Detail display content of HISTORY1

Display		Content
NON	Inch series	No paper size
WLG	fixed form	Double Legal
WLR		Double Legal-R
LD		Ledger
LDR		Ledger-R (Double Letter)
LG		
LGR		Legal-R
FC		Foolscap
ECP		Foolscap
		l ottor
IVR		Invoice-R (Mini)
EC		Executive
ECR		Executive-R
A3W		A3W (12x18 in)
AWR		A3W (12x18 in)-R
12		22x17
13		22x17R
14	1	22x34
15		22x34R
16		34x44
17		34x44R
18	1	44x68
10		44x69D
19		44X00R
01A		9812
018		9x12R
01C		13x19
01D		13x19R
MLG		Mexican-Legal
MLR		Mexican-Legal-R
ALG		Asian-Legal
ALR		Asian -Legal-R
EXT	Other	Extra (Special)
A1	AB series	A1
A1R	fixed form	A1R
A2		A2
A2R		A2R
A3		A3
A3R		A3R
A4		A4
A4R		A4R
45		A5
A5P		A5
AJK		ASK
AO		AO
A6R		A6R
B3		B3
B3R		B3K
B4		84
B4R		B4K
B5		B5
B5R	l	B5R
B6		B6
B6R		B6R
54	]	A0x2
55		A0x2 R
A0		A0
A0R		A0R
B0		B0
BOR	1	BOR
	1	B1
R1P	1	B1R
B2P	1	B2
BOD		B2R
	1	
	1	
KöK	{	
K16		K1b
16R		K16R
K32		K32
32R	1	K32R

Display		Content
66	AB series	SRA3
67	fixed form	SRA3R
68		SRA4
69		SRA4R
06A		318 x 469 mm
06B		469 x 318 mm
06C		234 x 318 mm
06D		318 x 234 mm
06E		312 x 440 mm
06F		440 x 312 mm
70		220 X 312 mm
71	Domostio	DPL Desteard
02	special	DBL Postcard P
84	(Envelope)	Postcard
85		Postcard-R
87		119 x 277 mm
89		120 x 235 mm
08B		90 x 205 mm
08D		90 x 185 mm
08F		240 x 332 mm
91		216 x 277 mm
93		197 x 267 mm
95		190 x 240 mm
97		162 x 229 mm
99		142 x 205 mm
09B		119 x 197 mm
09D		120 x 176 mm
09F		114 x 162 mm
0A1		98 x 148 mm
0A3		105 x 235 mm
0A5		95 x 217 mm
040		98 X 190 mm
049		AB series E-version
0AB		AB series L-version
0AC		AB series panorama size
0AD		AB series name card size
0AE		AB series identification photo
0AF		AB series name card small
0B0	Other	A3 width
0B1		B4 width
0B2		A4 width
0B3		A3 width (Long size)
084		B4 width (Long size)
0BC		A4 width (Long size)
		Custom (Small size)
0BF		Custom
0C2	Oversea	Monarch
0C3	special	Monarch-R
0C4	(Envelope)	DL
0C5		DL-R
0C6		C4
0C7		C4-R
0C8		C5
0C9		C5-R
0CA		C6
0CB		C6-R
000		
UCD		
		ISOB5-R
000		Size6-1/2
0D1		Size6-1/2-R
0D2		Size9
0D3		Size9-R
0D8		Com-10
0D9		Com-10-R
0DA		Inch series E-version
0DB		Inch series L-version

Display		Content
0DC	Oversea	Inch series panorama size
0DD	special	Inch series name card large
0DE	(Envelope)	Inch series identification photo
0DF	1	Inch series name card small
0EC	Other	Extra (Special large size)
0ED		Extra (Special small size)
0EF	]	Extra (Special/Not fixed)
0F0		Long size
0FF		JAM (Used for canceling temporary charging in a coin vendor.)

#### Display content detail: Paper type (P_T)

Display	Content
UST	User type
LHP	Letter head paper
PNP	Perforated sheet
RCL	Recycled paper
COL	Color paper
PLN	Standard paper
PRP	Pre printed
OHP	OHP Transparency
HV	Heavy paper
LBL	Label sheet
ENV	Envelope
HG	Postcard
TAB	Tab sheet
THN	Thin paper
US1	User type 1
US2	User type 2
US3	User type 3
US4	User type 4
US5	User type 5
US6	User type 6
US7	User type 7
HV2	Heavy paper 2
PL2	Plain paper 2 (not used)
HV3	Heavy paper 3
HV4	Heavy paper 4
GLS	Glossy paper

# Display content detail: Job mode (JOB)

Display	Content
SHD	Shading.
PCL	Process control
SIM	Test mode (Sim)
ICP	Interruption copy
CP	Сору
FXS	FAX send scan
AXS	AXIS
FXP	FAX reception print
PR	Printer
FXC	FAX communication report print
00A	Zaurus print
SLF	Self/Test print
00C	Document counter
RMT	Remote maintenance
00E	SIM 52-01
00F	Tandem (Cordless handset)
CFP	Confidential print
NET	Network scanner
PRF	Proof print

22-60	
Purpose	Setting/Operation data check
Function (Purpose)	Used to check the utility counter value.
Section	

# **Operation/Procedure**

 Used to display the utility counter value Change the display with [NEXT] key

All setting list (*)	ALL CUSTOM SETTING LIST
Printer test page	PCL SYMBOL SET LIST
	PCL INTERNAL FONT LIST
	PCL EXTENDED FONT LIST
	PS FONT LIST
	PS KANJI FONT LIST (Japan)
	PS EXTENDED FONT LIST
	NIC PAGE
Address registration	INDIVIDUAL LIST
list (*)	GROUP LIST
	PROGRAM LIST (Output Disable)
	MEMORY BOX LIST
	ALL SENDING ADDRESS LIST
Document filing list (*)	DOCUMENT FILING FOLDER LIST
System setting list	ADMIN. SETTINGS LIST (COPY)
	ADMIN. SETTINGS LIST (PRINT)
	ADMIN. SETTINGS LIST (IMAGE SEND)
	ADMIN. SETTINGS LIST (DOC FILING)
	ADMIN. SETTINGS LIST (SECURITY)
	ADMIN. SETTINGS LIST (COMMON)
	ALL ADMINISTRATOR SETTINGS LIST
Receive rejection	ANTI JUNK FAX NUMBER LIST
number table	
Receive rejection/	ANTI JUNK MAIL/DOMAIN NAME LIST
allow address	
domain table	
To E-mail	INBOUND ROUTING LIST
Transfor list	
Web setting list	WER SETTING LIST
Neto dete est list	
weta data set list	METADATA SET LIST

* When the data list print of system setting is inhibition in DSK model, this setting is invalid.

22-90	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to output the various set data lists.
Section	

#### **Operation/Procedure**

- 1) Change the display with scroll key.
- 2) Select the print target with the keys on the touch panel.
- 3) Press [EXECUTE] key to start self print of the list.

All setting list (*)	ALL CUSTOM SETTING LIST
Printer test page	PCL SYMBOL SET LIST
	PCL INTERNAL FONT LIST
	PCL EXTENDED FONT LIST
	PS FONT LIST
	PS KANJI FONT LIST (Japan)
	PS EXTENDED FONT LIST
	NIC PAGE
Address registration	INDIVIDUAL LIST
list (*)	GROUP LIST
	PROGRAM LIST (Output Disable)
	MEMORY BOX LIST
	ALL SENDING ADDRESS LIST
Document filing list (*)	DOCUMENT FILING FOLDER LIST



To E-mail	INBOUND ROUTING LIST
Transfer table list	
To administrator Transfer list	DOCUMENT ADMIN LIST
Web setting list	WEB SETTING LIST
Meta data set list	METADATA SET LIST

* When the data list print of system setting is inhibition in DSK model, this setting is invalid.



23-2	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to output the trouble history list of paper jam and misfeed. (If the number of troubles of misfeed is considerably great, the judgment is made that repair is required.)

# Section

**Operation/Procedure** 

Press [EXECUTE] key to execute print.

The trouble history of paper jams and misfeed is printed.

23-80	
Purpose	Operation test/check
Function (Purpose)	Used to check the operation of paper feed and paper transport in the paper feed sec- tion and the paper transport section. Used to output the list of the operation status of the sensor and the detectors in the paper feed section and the paper transport sec- tion.
Section	Paper feed, Paper transport

# **Operation/Procedure**

A

When [EXECUTE] key is pressed, the timing list of paper feed and paper transport is outputted.

Used to print the operations timing list of the sensors and detectors in the paper feed and transport section.

The timing list of paper feed and paper transport operations of the latest job (copy or print) on the final paper is printed.

Since the paper feed and paper transport routes differ depending on the used paper feed tray and the print operation mode, the sensor and the detectors and the operation timing also differ.

Item	Content
JAM CODE	JAM code
DATA/TIME	JAM occurrence date/time
MODE	Printing mode when JAM occurs
SIZE	Paper size
TYPE	Paper type
PIC TRAY	Paper feed tray
OUT TRAY	Paper exit tray
SECTION	Measurement section of paper feed time
STANDARD	Theoretical paper feed time
JAM-1	Measurement time of the first paper before JAM occurs
JAM	Measurement time of JAM paper
POS/STATUS	MIOP (sensor / load) data when JAM occurs
INF1 (ILLEGAL)	Illegal detection information
INF2(SENSOR)	Sensor information



24-1	
Purpose	Data clear
Function (Purpose)	Used to clear the jam counter, and the trouble counter. (After completion of maintenance, clear the counters.)
Section	

#### **Operation/Procedure**

- 1) Select the item to be cleared with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

MACHINE	Machine JAM counter
SPF	RSPF JAM counter
TROUBLE	Trouble counter

24-2	
Purpose	Data clear
Function (Purpose)	Used to clear the number of use (the num-
	ber of prints) of each paper feed section.

# Section

#### **Operation/Procedure**

- 1) Select the item to be cleared with the touch panel key.
- Press [EXECUTE] key. 2)
- 3) Press [YES] key.

The target counter is cleared.

TRAY1	Tray 1 paper feed counter
TRAY2	Tray 2 paper feed counter
TRAY3	Tray 3 paper feed counter
TRAY4	Tray 4 paper feed counter
MFT TOTAL	Manual paper feed counter (Total)
MFT HEAVY	Manual paper feed counter (Heavy paper)
MFT OHP	Manual paper feed counter (OHP)
MFT ENV	Manual paper feed counter (Envelope)
ADU	ADU paper feed counter
LCC	LCC paper feed counter (LCC)

24-3 Purpose Data clear Function (Purpose) Used to clear the finisher, RSPF, and the scan (reading) unit counter.

# Section

- **Operation/Procedure**
- 1) Select the item to be cleared with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

SPF	RSPF document feed counter (No. of discharged sheets)
SCAN	Scan counter
STAPLER	Staple counter
PUNCHER	Puncher counter
STAMP	Stamp counter
SADDLE STAPLER	Saddle staple counter
SADDLE V FOLD	Saddle finisher V fold counter
COVER	Document cover open/close counter
HP_ON	Number of scanner HP detection
OC LAMP TIME	Total lighting time of the scanner lamp

24-4	
Purpose	Data clear
Function (Purpose)	Used to clear the maintenance counter, the printer counters of the transport unit and the fusing unit. (After completion of maintenance)

# Section

# Operation/Procedure

- 1) Select the item to be cleared with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

Item/Display		Content
Maintenance	MAINTENANCE	Maintenance counter (Total) (Counter)
	ALL	Maintenance counter (Total)
		(Number of use days)
	MAINTENANCE	Maintenance counter (Color) (Counter)
	COL	Maintenance counter (Color)
		(Number of use days)
Fusing	FUSING BELT	Fusing belt (Counter)
		Fusing belt (Number of use days)
		Fusing belt
		(Accumulated number of rotations)
	FUSING	Fusing roller (Counter)
	ROLLER	Fusing roller (Number of use days)
		Fusing roller
		(Accumulated number of rotations)
	PRESS	Pressure roller (Counter)
	ROLLER	Pressure roller (Number of use days)
		Pressure roller
		(Accumulated number of rotations)
	FUSING LOAD	Fusing Pressure release roller
		(Accumulated number of rotations)
Separation	SEPARATE	Separation pawl (Counter)
	PAWL	Separation pawl (Number of use days)
		Separation pawl
		(Accumulated number of rotations)
	SEPARATE	Separation plate (Counter)
	PLATE	Separation plate (Number of use days)
		Separation plate
		(Accumulated number of rotations)
Separation	FUSING WEB	Fusing web unit print counter
		Use day of fusing web unit
		Fusing web cleaning send counter
Transfer	TC1 BELT	Primary transfer belt (Counter)
		Primary transfer belt
		(Number of use days)
		Primary transfer belt
		(Accumulated number of rotations)
	TRANS BLADE	Transfer blade (Counter)
		Transfer blade (Number of use days)
		Transfer blade
		(Accumulated number of rotations)
	TC2 BELT	Secondary transfer belt (Counter)
		Secondary transfer belt
		(Number of use days)
		Secondary transfer belt
	DTO	(Accumulated number of rotations)
	PIC	PIC counter (Counter)
		PIC counter (Number of use days)
		PTC counter
		(Accumulated number of rotations)

Item/Display		Content
Drum	DRUM CTRG K	Drum cartridge (K) (Counter)
		Drum cartridge (K) (Number of use
		days)
		Drum cartridge (K)
		(Accumulated number of rotations)
	DRUM CTRG C	Drum cartridge (C) (Counter)
		Drum cartridge (C)
		(Number of use days)
		Drum cartridge (C)
		(Accumulated number of rotations)
	DRUM CTRG M	Drum cartridge (M) (Counter)
		Drum cartridge (M)
		(Number of use days)
		Drum cartridge (M)
		(Accumulated number of rotations)
	DRUM CTRG Y	Drum cartridge (Y) (Counter)
		Drum cartridge (Y)
		(Number of use days)
		Drum cartridge (Y)
		(Accumulated number of rotations)
Main	MAIN	Main charger (K) (Counter)
charger	CHARGER K	Main charger (K) (Number of use days)
		Main charger (K)
		(Accumulated number of rotations)
	MAIN	Main charger (C) (Counter)
	CHARGER C	Main charger (C) (Number of use days)
		Main charger (C)
		(Accumulated number of rotations)
	MAIN	Main charger (M) (Counter)
	CHARGER M	Main charger (M) (Number of use days)
		Main charger (M)
		(Accumulated number of rotations)
	MAIN	Main charger (Y) (Counter)
	CHARGER Y	Main charger (Y) (Number of use days)
		Main charger (Y)
		(Accumulated number of rotations)
Drum blade	DRUM BLADE	Drum blade K (Counter)
	К	Drum blade K (Number of use days)
		Drum blade K
		(Accumulated number of rotations)
	DRUM BLADE	Drum blade C (Counter)
	С	Drum blade C (Number of use days)
		Drum blade C
		(Accumulated number of rotations)
	DRUM BLADE	Drum blade M (Counter)
	M	Drum blade M (Number of use days)
		Drum blade M
		(Accumulated number of rotations)
	DRUM BLADE	Drum blade Y (Counter)
	Y	Drum blade Y (Number of use days)
		Drum blade Y
		(Accumulated number of rotations)
Other	PS PAPER	PS paper dust cleaner (Counter)
		PS paper dust cleaner
		(Number of use days)
	OZONE FILTER	Ozone filter (Counter)
		Ozone filter (Number of use days)

* The winding counter for the fusing web cleaning is cleared by being synchronized with the fusing web cleaning feed counter.

#### 24-5

Purpose	Da
anpooo	

Function (Purpose)

Data clear

Used to clear the developer counter. (After replacement of developer, clear the counter.)

_____

# Section Operation/Procedure

- 1) Select the item to be cleared with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

# Note

When SIM25-2 is executed, this counter is also cleared automatically.

	Developer cartridge print counter (K)
К	Accumulated number of rotations of the developer cartridge (cm) (K)
	Number of day that used developer (Day) K
	Developer cartridge print counter (C)
С	Accumulated number of rotations of the developer cartridge (cm) (C)
	Number of day that used developer (Day) C
	Developer cartridge print counter (M)
М	Accumulated number of rotations of the developer cartridge (cm) (M)
	Number of day that used developer (Day) M
	Developer cartridge print counter (Y)
Υ	Accumulated number of rotations of the developer cartridge (cm) (Y)
	Number of day that used developer (Day) Y

24-6	
Purpose	Data clear
Function (Purpose)	Used to clear the copy counter.
Section	

#### **Operation/Procedure**

- 1) Select the item to be cleared with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

COPY BW	Copy counter (B/W)
COPY COL	Copy counter (COLOR)
SINGLE COLOR	Single color
2COLOR	2-color

24-9	
Purpose	Data clear
Function (Purpose)	Used clear the printer mode print counter
	and the self print mode print counter.

# Section

## **Operation/Procedure**

- 1) Select the item to be cleared with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

PRINT BW	Print counter (B/W)
PRINT COL	Print counter (COLOR)
PRINT (2COL)	Print counter (2-colors)
PRINT (3COL)	Print counter (3-colors)
PRINT (SGL_COL)	Print counter (Single color)
OTHER BW	Other counter (B/W)
OTHER COL	Other counter (COLOR)

24-10	
Purpose	Data clear
Function (Purpose)	Used to clear the FAX counter. (Only when FAX is installed)

# Section

# **Operation/Procedure**

- 1) Select the item to be cleared with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

FAX OUTPUT	FAX Print quantity counter
FAX SEND	FAX send counter
FAX RECEIVED	FAX receive counter
SEND IMAGES	FAX send quantity counter
SEND TIME	FAX send time
RECEIVED TIME	FAX receive time

24-12	
Purpose	Data clear
Function (Purpose)	Used to clear the document filing counter.
Section	

#### **Operation/Procedure**

- 1) Select the item to be cleared with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

Display	Content
DOC FIL (BW)	Black and white document filing print counter
DOC FIL (COL)	Color document filing print counter
DOC FIL (2COL)	2-color document filing print counter
DOC FIL (SGL_COL)	Single-color document filing print counter

# 24-15 Purpose Function (Purpose) Used to clear the counters related to the

scan mode and the image send.

Section

#### **Operation/Procedure**

- 1) Select the item to be cleared with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

Division	Item/Display	Content
Network	NET SCN ORG_B/W	Network scanner document read
scanner		quantity counter (B/W scan job)
	NET SCN ORG_CL	Network scanner document read
		quantity counter (COLOR scan job)
	NET SCN ORG_2CL	Network scanner document read
		quantity counter (2-color scan job)
	NET SCN ORG_SGL	Network scanner document read
		quantity counter (single color scan
		job)
Internet Fax	INTERNET FAX OUTPUT	Number of internet FAX output
	INTERNET FAX	Number of internet FAX sending
	SEND OUTPUT	page
	INTERNET FAX	Number of internet FAX receive
	INTERNET FAX	Number of internet FAX send
	SEND	
E-mail	MAIL COUNTER	Number of times of E-MAIL send
FTP	FTP COUNTER	Number of FTP send
Other	SMB SEND	Number of SMB send
	USB CNT	Number of times of USB storage
	TRIAL MODE_B&C	Trial mode counter (B/W & COLOR
		scan job)
	SCAN TO HDD_B/W	SCAN TO HDD record quantity (B/W)
	SCAN TO HDD_CL	SCAN TO HDD record quantity (COLOR)
	SCAN TO HDD_2CL	SCAN TO HDD record quantity (2- COLOR)
	SCAN TO HDD_SGL	SCAN TO HDD record quantity (SINGLE color)

24-35

 Purpose
 Data clear

 Function (Purpose)
 Used to clear the toner cartridge use status data.

# Section

- **Operation/Procedure**
- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

The toner cartridge use status data (SIM22-14) are cleared.

## 24-60

Purpose	Data clear
Function (Purpose)	Used to clear the utility counter.
Section	
Operation/Procedure	

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

The utility counter is cleared.



25-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the developing section.
Section	Process (Developing section)

#### **Operation/Procedure**

- 1) Select the process speed with [MIDDLE], [LOW] keys.
- 2) Press [EXECUTE] key.

The developing motor and the OPC drum motor rotate for 3 minutes and the output level of the toner density sensor is displayed.

TCS_K	Toner sensor output value (K)
TCS_C	Toner sensor output value (C)
TCS_M	Toner sensor output value (M)
TCS_Y	Toner sensor output value (Y)
TSG_K	Toner density sensor control voltage level (K)
TSG_C	Toner density sensor control voltage level (C)
TSG_M	Toner density sensor control voltage level (M)
TSG_Y	Toner density sensor control voltage level (Y)

LOW	Process speed: Low speed
MIDDLE	Process speed: Medium speed

# Important

The toner cartridge must be removed before executing this simulation.

If this simulation is executed with the toner cartridge installed, toner will be forcibly supplied to the developing unit, resulting in overtoner and a trouble.

25-2	
Purpose	Setting
Function (Purpose)	Used to make the initial setting of toner density when replacing developer. (Automatic adjustment)
Section	Image process (Photoconductor/Develop- ing/Transfer/Cleaning)

#### **Operation/Procedure**

- 1) Select a color to be adjusted with the touch panel.
- 2) Press [EXECUTE] key.

The developing motor rotates for 1 min 30 sec, and the toner density sensor makes sampling of the toner density. The detected level is displayed.

After stopping the developing motor, the average value of the toner density sampling results is set as the reference toner density control level.

# Important

When the above operation is interrupted on the way, the reference toner concentration level is not set. Also when error code of EE-EC, EE-EL or EE-EU is displayed, the reference toner density level is not set normally.

Do not execute this simulation except when new developer is supplied. If it is executed in other cases, undertoner or overtone may occur, causing a trouble.

Division	Item/Display	Display range	Default value
Toner density control	AT DEVE ADJ_L_K	1 - 255	128
adjustment value in the	AT DEVE ADJ_L_C	1 - 255	128
low speed process mode	AT DEVE ADJ_L_M	1 - 255	128
	AT DEVE ADJ_L_Y	1 - 255	128
Toner density control	AT DEVE ADJ_M_K	1 - 255	128
adjustment value in the medium speed process	AT DEVE ADJ_M_C	1 - 255	128
	AT DEVE ADJ_M_M	1 - 255	128
mode	AT DEVE ADJ_M_Y	1 - 255	128
Toner density sensor	AT DEVE VO_L_K	1 - 255	128
control voltage level in the low speed process mode	AT DEVE VO_L_C	1 - 255	128
	AT DEVE VO_L_M	1 - 255	128
	AT DEVE VO_L_Y	1 - 255	128
Toner density sensor	AT DEVE VO_M_K	1 - 255	128
control voltage level in the medium speed process mode	AT DEVE VO_M_C	1 - 255	128
	AT DEVE VO_M_M	1 - 255	128
	AT DEVE VO_M_Y	1 - 255	128

# Display during execution of the simulation

Item/Display	Content
TCS_K	Toner sensor output value (K)
TCS_C	Toner sensor output value (C)
TCS_M	Toner sensor output value (M)
TCS_Y	Toner sensor output value (Y)
TSG_K	Toner density sensor control voltage level (K)
TSG_C	Toner density sensor control voltage level (C)
TSG_M	Toner density sensor control voltage level (M)
TSG_Y	Toner density sensor control voltage level (Y)

# Error content

Display	Error name	Error content
EE-EL	EL abnormality	The sensor output level is less than 77, or
		the control voltage exceeds 207.
EE-EU	EU abnormality	The sensor output level exceeds 177, or the control voltage is less than 52.
EE-EC	EC abnormality	The sensor output level is outside of 128±3.

25-4	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to display the operation data of the toner supply quantity. (Not used in the mar-
	ket.)

Section Process

**Operation/Procedure** 

The operation data of the toner supply quantity are displayed.

Item/Display	Content	Display range
YLD_CNT_FB	Toner supply FB rate by the yield count	50 - 200
DELTA_DVB	Delta DVB (Process control DVB - Target DVB)	-500 - 500
IDL_DVB	Target DBV	100 - 600
PROCON_DVB	Process control DVB	100 - 600
DV_LIFE	Developer life area	1 - 8
COVERAGE_ AREA	Average print rate area	1 - 10
ENV_AREA	Environment area	1 - 8
MULTI_TIME	Toner supply drive time area (Specified by the DV motor rotation time)	1 - 8
PRO_FB_CNT	No. of remaining times of toner supply for the process control result	0 - 65535
PRO_FB_INT	Interval of toner supply for the process control result	0 - 65535
PRO_FB_RATIO	Correction rate of one-time toner supply for the process control result	-10 -10

Item/Display	Content	Display range
RECV_MODE_ CNT(+)	No. of times of recovery mode (+) (No. of times of compulsory toner supply)	0 - 65535
RECV_MODE_ CNT(-)	No. of times of recovery mode (-) (No. of times of compulsory printing of one-color background image)	0 - 65535

25-5	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to display the toner density correction data. (Not used in the market.)
Section	Process

# **Operation/Procedure**

The toner density correction data are displayed.

Item/Display	Content	Display
		range
TCS OUTPUT	Toner sensor output value	0 - 255
DELTA_TSG	Toner density sensor control voltage level correction value	-255 - 255
TSG_REF	Toner density sensor control voltage level reference value	0 - 255
TN_FALL_CNT_ JOB	Toner fall amount during a job (latest average value)	0 - 255
TN_FALL_ JUDGE_CNT	Toner fall judgment threshold value during a job	0 - 255
TN_FALL_MODE_ CNT	No. of times of job interruption toner supply operation mode	0 - 255
TN_FALL_CNT_ INT	Latest average value of toner fall amount in job interruption toner supply operation	0 - 255
TN_FALL_CNT_ NEW	Latest average value of toner fall amount when installing a new toner cartridge	0 - 255
TCS_ERR_MODE _CNT(+)	No. of times of TCS abnormality detection mode (+) (Undertoner)	0 - 65535
TCS_ERR_MODE _CNT(-)	No. of times of TCS abnormality detection mode (-) (Overtoner)	0 - 65535

# 26

26-1	
Purpose	Setting
Function (Purpose)	Used to set Yes/No of installation of the right paper exit tray.
Section	Paper exit

Operation/Procedure

1) Enter the set value with 10-key.

2) Press [OK] key. (The set value is saved.)

This setting is required to use the right paper exit tray unit.

Item/Display		em/Display	Content
А	0	YES	Paper exit tray: YES
	1	NO	Paper exit tray: NO

26-2	
Purpose	Setting

Function (Purpose)

Used to set the paper size of the large capacity tray (LCC). (When the paper size is changed, this simulation must be executed to change the paper size in software.)

# Section Paper feed

**Operation/Procedure** 

Select a paper size and a weight system to be changed.

ltem	Setting value	Content
Tara	0	8.5x11
(Tandom)	1	A4
(Tandem)	2	B5
	0	8.5x11
LCC	1	A4
	2	B5
	0	Gram
G/LB3 Set	1	LBS

Destination	Setting Value		
	Tray3 (TANDEM)	LCC	G/LBS SET
U.S.A	8.5x11	8.5x11	LBS
CANADA	8.5x11	8.5x11	LBS
INCH	8.5x11	8.5x11	LBS
JAPAN	B5	A4	GRAM
AB_B	A4	A4	GRAM
EUROPE	A4	A4	GRAM
U.K	A4	A4	GRAM
AUS	A4	A4	GRAM
AB_A	A4	A4	GRAM
CHINA	A4	A4	GRAM

26-3	
Purpose	Setting
Function (Purpose)	Used to set the specifications of the auditor.
	(Setting must be made according to the
	auditor use conditions.)

Section Auditor
Operation/Procedure

Select an item to be set with the touch panel.

ltem/D	Display	Content	Default value
BUILT-IN	P10	Built-in auditor mode	P10
AUDITOR		(standard mode) operation.	
OUTSIDE AUDITOR	NONE	No external connection vendor is used.	NONE
	P VENDOR1	Coin vendor mode (Only the copy mode can be controlled.)	
	P VENDOR3	Vendor mode in which signals for the intercard connected to the PCU are used for communication in parallel I/F.	
	P OTHER	Mode for an external auditor connected to the SCU.	
	VENDOR-EX (*1)	Vendor I/F for EQUITRAC	
	VENDOR-EX (MULTI) (*1)	VENDOR-EX + Multi job cueing Enable mode	
	S_VENDOR	Serial vendor mode	
DOC ADJ	ON	Support for the auditor in	OFF
		document filing print	
	OFF	No support for the auditor in document filing print	

ltem/D	isplay	Content	Default value
PF ADJ	ON	Continuous printing is performed in the duplex print mode. If the remaining money expires during continuous printing, the sheets in the machine are discharged without being printed on the back surfaces.	OFF
	OFF	Continuous printing is not performed in the duplex print mode. (The remaining amount is checked for printing every surface in all the printing process.) If the remaining money expires during printing, the sheet is discharged without printing on the back surface.	
VENDOR	MODE1	Vendor mode 1	MODE
MODE (*2)	MODE2	Vendor mode 2	3
	MODE3	Vendor mode 3	
COUNTUP TIMING	FUSER_IN	Mode in which the detection timing of the paper lead edge by the sensor after the paper passes the fusing section is used as the money charging timing.	EXIT_ OUT
	FUSER_OUT	Mode in which the detection timing of the paper rear edge by the sensor after the paper passes the fusing section is used as the money charging timing.	
	EXIT_OUT	Mode in which the detection timing of the paper rear edge by the paper exit sensor of the right paper exit tray or of the after process unit is used as the money charging timing.	

(*1) Displayed only when EQUITRAC.

(*2) Details of the vendor mode

## Details of the vendor mode

	Completion of the	Insufficient n copy	noney during / job	Completion of the
	quantity. (Money remaining)	BW/Color (no money remaining)	Color (Money remaining)	quantity. (No money remaining)
	Condition 1	Condition 2	Condition 3	Condition 4
MODE1	Operation 1	Operation 2	Operation 2	Operation 1
MODE2	Operation 1	Operation 1	Operation 2	Operation 1
MODE3	Operation 1	Operation 3	Operation 2	Operation 3

Operation 1:

Standby during setting time of auto clear. Default is 60 seconds, which can be changed in the system setting.

Operation 2:

Auto clear is not made.

Operation 3:

The display is shifted to the initial screen.

#### 26-5

#### Purpose Setting

Function (Purpose)

Used to set the count mode of the total counter and the maintenance counter. (A3/ 11x17 size)

Section Operation/Procedure

1) Select an item to be set with scroll keys.

- 2) Enter the setting value with 10-key1 = Count up by 1, 2 = Count up by 2
- 3) Press [OK] key.

The set value in step 2) is saved.

Item/Display		Content	Default value
Α	TOTAL (B/W)	Total counter (B/W)	1
В	TOTAL (COL)	Total counter (Color)	(Japan)
			2
			(Except Japan)
С	MAINTE (B/W)	Maintenance counter (B/W)	2
D	MAINTE (COL)	Maintenance counter (Color)	
Е	DEV (B/W)	Developer counter (B/W)	
F	DEV (COL)	Developer counter (Color)	

26-6	
Purpose	Setting
Function (Purpose)	Used to set the specifications (paper, fixed
	magnification ratio, etc.) of the destination.

Section

- Operation/Procedure
- 1) Select an item to be set with the touch panel.
- 2) Press [EXECUTE] key.

The selected set content is saved.

U.S.A.	United States of America
CANADA	Canada
INCH	Inch series, other destinations
JAPAN	Japan
AB_B	AB series (B5 detection), other destinations
EUROPE	Europe
U.K.	United Kingdom
AUS.	Australia
AB_A	AB series (A5 detection), other destinations
CHINA	China

26-7	
Purpose	Setting
Function (Purpose)	Used to set the machine ID.

#### Section

**Operation/Procedure** 

1) Enter the machine ID with the 10-key.

Max. 30 digits of numerals and alphabetical characters can be inputted.

To select a desired character, press the 10-key repeatedly. Refer to the following list and enter characters.

Touch the "CONFIRM" section every time a character is inputted.

To modify an inputted character, delete it with "CLEAR" key and enter the correct character.

2) Press [SET] key to set the contents entered in procedure 1).

# Note

The machine ID can be set also by the Web Page service mode function.

Conventionally, the machine ID has been set by the Web Page function. In this mode, this function is made available in the simulation mode.

			N	umber	of tim	es of k	ey inp	ut		
10-key	1	2	3	4	5	6	7	8	9	10
1	1	-	-	-	-	-	-	-	-	-
2	Α	В	С	а	b	С	2	-	-	-
3	D	Е	F	d	е	f	3	-	-	-
4	G	Н	-	g	h	i	4	-	-	-
5	J	Κ	L	j	k	- 1	5	-	-	-
6	М	Ν	0	m	n	0	6	-	-	-
7	Р	Q	R	S	р	q	r	S	7	-
8	Т	U	V	t	u	v	8	-	-	-
9	W	Х	Y	Ζ	W	х	у	z	9	-
0	0	-	-	-	-	-	-	-	-	-

#### 26-8

Purpose	Setting
Function (Purpose)	Counter mode setting (Long scale)
Section	

#### **Operation/Procedure**

- 1) Select a setting item with the scroll key.
- 2) Enter the set value with 10-key.
- 1 = 1 count up, 2 = 2 count up
- 3) Press [OK] key.

Item/Display		Content	Setting range	Default value	Default value (Taiwan)
A	TOTAL(B/ W) LONG SIZE(S)	Long scale (Small) Total counter (B/W)	1 - 10	3	2
В	TOTAL (COL) LONG SIZE(S)	Long scale (Small) Total counter (Color)	1 - 10	3	2
С	MAINTE (B/W) LONG SIZE(S)	Long scale (Small) Maintenance counter (B/W)	1 - 10	3	2
D	MAINTE (COL) LONG SIZE(S)	Long scale (Small) Maintenance counter (Color)	1 - 10	3	2
E	DEV(B/W) LONG SIZE(S)	Long scale (Small) Developer counter (B/W)	1 - 10	3	2
F	DEV(COL) LONG SIZE(S)	Long scale (Small) Developer counter (color)	1 - 10	3	2
G	TOTAL(B/ W) LONG SIZE(L)	Long scale (Large) Total counter (B/W)	1 - 10	5	2
н	TOTAL (COL) LONG SIZE(L)	Long scale (Large) Total counter (Color)	1 - 10	5	2
Ι	MAINTE (B/W) LONG SIZE(L)	Long scale (Large) Maintenance counter (B/W)	1 - 10	5	2
J	MAINTE (COL) LONG SIZE(L)	Long scale (Large) Maintenance counter (Color)	1 - 10	5	2



	· · · · ·	4/ 1		n	
		<b>T/ U</b>	u		
•					

26-10	
Purpose	Setting
Function (Purpose)	Used to set the trial mode of the network
	scanner.

# Section

- **Operation/Procedure**
- 1) Enter the set value with 10-key.
- 2) Press [OK] key.

The set value in step 1) is saved.

TRIAL MODE	0	Trial mode setting
(0: YES 1: NO)	1	Trial mode cancel (Default)

# 26-18

Æ

Purpose	Setting		
Function (Purpose)	Used to set Disable/Enable of the toner		
	save mode operation.		
	(For the Japan and the UK versions.)		

## Section **Operation/Procedure**

- 1) Select an item to be set with scroll keys.
- Enter the set value with 10-key. 2)
- 3) Press [OK] key.

The set value in step 2) is saved.

ŀ	tem/Display	Content		Default value
А	COPY	0	Copy toner save mode is inhibited	
		1	Copy toner save mode 1	0
		2	Copy toner save mode 2	0
		3	Copy toner save mode 3	
В	PRINTER	0	Printer toner save mode is inhibited	
		1	Printer toner save mode 1	0
		2	Printer toner save mode 2	
		3	Printer toner save mode 3	
С	COPY TS	0	Toner save setting is displayed	
	DISPLAY	1	Toner save setting is not displayed	Refer to the
D	PRINTER	0	0 Toner save setting is displayed	
	TS DISPLAY	1	Toner save setting is not displayed	

Destination	Default value C	Default value D
JAPAN	1 (Not Displayed)	0 (Displayed)
U.K.	1 (Not Displayed)	0 (Displayed)
Other Destination	0 (Displayed)	0 (Displayed)

26-30	
Purpose	Setting
Function (Purpose)	Used to set the operation mode corre- sponding to the CE mark (Europe safety standards). (For slow start to drive the fus- ing heater lamp)

# Section

# **Operation/Procedure**

1) Enter the set value with 10-key.

0	Control allowed
1	Control inhibited

- 2) Press [OK] key.
  - The set value in step 1) is saved.
  - * Even in Enable state, the control may not be executed due to the power frequency, etc.

U.S.A	1 (CE not supported)	EUROPE	0 (CE supported)
CANADA	1 (CE not supported)	U.K.	0 (CE supported)
INCH	1 (CE not supported)	AUS.	0 (CE supported)
JAPAN	1 (CE not supported)	AB_A	0 (CE supported)
AB_B	1 (CE not supported)	CHINA	0 (CE supported)

26-32	
Purpose	Setting
Function (Purpose)	Used to set the specifications of the fusing cleaning operation.
Section	Fusing

#### **Operation/Procedure**

1) Enter the set value with 10-key.

Enable/Disable of the user fusing cleaning function is set.

2) Press [OK] key.

lte	em/Display	Content	Setting	range	Default value
A	CLEANIN G PRINT	User fusing cleaning function is Enable.	0	YES	0(YES)
	SET	User fusing cleaning function is Disable.	1	NO	

26-35	
Purpose	Setting
Function (Purpose)	Used to set the display mode of SIM 22-4 trouble history when a same trouble occurred repeatedly. There are two display modes: display as one trouble and display as several series of troubles
Section	

# **Operation/Procedure**

1) Enter the set value with 10-key.

0	Only once display.
1	Any time display.

2) Press [OK] key.

The set value in step 1) is saved.

26-38	
Purpose	Setting
Function (Purpose)	Used to set Continue/Stop of print when the maintenance life is reached.

# Section

**Operation/Procedure** 

- 1) Enter the set value with 10-key. 2) Press [OK] key.
  - The set value in step 1) is saved.

Item/Display		Content		Default value
A	MAINTENANCE LIFE OVER (0: CONTINUE	0	Setting of Print Continue/ Stop when the maintenance life is over (Print Continue)	0
	1: STOP)	1	Setting of Print Continue/ Stop when the maintenance life is over (Print Stop)	
В	B FUSER WEB END 0 Continue/Stop setting of print (0: CONTINUE 1: STOP) 0 (Print Continue)		1	
		1	Continue/Stop setting of print when the fusing web is end (Print Stop)	

26-41	
Purpose	Setting
Function (Purpose)	Used to set Enable/Disable of the magnifi- cation ratio automatic select function (AMS) in the center binding mode.

# Section

**Operation/Procedure** 

1) Enter the set value with 10-key.

0	AMS Disable
1	AMS Enable

2) Press [OK] key.

The set value in step 1) is saved.

# <Default value of each destination>

U.S.A	0 (Disable)	EUROPE	1 (Enable)
CANADA	0 (Disable)	U.K.	1 (Enable)
INCH	0 (Disable)	AUS.	0 (Disable)
JAPAN	0 (Disable)	AB_A	0 (Disable)
AB_B	0 (Disable)	CHINA	0 (Disable)

26-49	
Purpose	Setting
Function (Purpose)	Used to set the print speed of postcards mode.
Section	

#### **Operation/Procedure**

Select the copy speed mode with the touch panel. (Default: LOW)

Item/Setting value	Content	Default value
LOW	Postcard copy speed LOW	LOW
HIGH	Postcard copy speed HIGH	

26-50				
Purpose	Setting			
Function (Purpose)	Used to set functions.			
Section				

# Operation/Procedure

1) Select a target item of setting with scroll key on the touch panel.

2) Enter the set value with 10-key.

3) Press [OK] key. (The set value is saved.)

Item/Display		Content		Default value
Α	BW REVERSE	0	0 BW reverse copy Disable	
		1	BW reverse copy Enable	to *1
В	COLOR MODE	2-cc	lor/Single color copy mode	Refer
С	FINISHER FUNCTION	0	Finisher special paper The number of paper exit is limited. Finisher special paper The number of paper exit is not limited.	0 Refer to *3
D	COLOR MODE (PRINTER)	0	0 All colors and monochrome counters are displayed.	
		1 All are displayed except for the 3-color print counter.		
		2 Monochrome and full color print counters are displayed.		

Item/Display			Content	Default value	
E	FEED TRAY COLOR	0 Paper feed tray color display ON during paper feed		0	
		1	Paper feed tray color display OFF during paper feed		
F	LONG SIZE PRINT	0 Long size print enable		0	
		1	Long size print disable		
G	WIRELESS SET	0	Disables wireless LAN setting.	*2	
		1 Enables wireless LAN setting.			

(*1) Default values for each destination of item A/B/D

(*2) Corresponding area of Wireless LAN; 1 (Yes)

Not corresponding area of Wireless LAN; 0 (No)

Destination	Item A	Item B	Item D
USA	1	0	2
CANADA	1	0	2
INCH	1	0	2
JAPAN	1	7	2
AB_B	1	0	2
EUROPE	1	0	2
UK	0	0	2
AUS	1	0	2
AB_A	1	0	2
CHINA	1	0	2

(*2) Item B: COLOR MODE set value (OFF: Displayed/ON: Not displayed)

Set value	Mo	2-Color/Single	
Set value	Single	2-color	Counter
0	OFF	OFF	OFF
1	OFF	ON	OFF
2	ON	OFF	OFF
3	ON	ON	OFF
4	OFF	OFF	ON
5	OFF	ON	ON
6	ON	OFF	ON
7	ON	ON	ON

# (*3)

	Target	Target paper setti	ng
	paper	0	1
Inner finisher	Postcard, envelope	The operation is stopped when 10 sheets of a same kind are discharged continuously. When, however, different kinds of sheets are mixed and discharged and 10 or less sheets of a kind are continuously discharged, the operation is stopped by the paper exit tray full detection.	If it is set to "1," the operation is stopped when the paper exit tray is full or when 250 sheets (35.5mm thick) are discharged.
	Label sheet, tab sheet, OHP	The operation is stopped when 100 sheets of a same kind are discharged continuously. When, however, different kinds of sheets are mixed and discharged and 100 or less sheets of a kind are continuously discharged, the operation is stopped by the paper exit tray full detection.	

	Target	Target paper setting		
	paper	0	1	
Saddle Stitch Finishe r	Postcard, envelope	The operation is stopped when 30 sheets of a same kind are discharged continuously. When, however, different kinds of sheets are mixed and discharged and 30 or less sheets of a kind are sheets of a kind are continuously discharged, the operation is stopped by the paper exit tray full detection.	If it is set to "1," the operation is stopped when the paper exit tray is full or when 500 sheets (67mm thick) are discharged.	
Saddle Stitch Finishe r	Label sheet, tab sheet, OHP	The operation is stopped when 100 sheets of a same kind are discharged continuously. When, however, different kinds of sheets are mixed and discharged and 100 or less sheets of a kind are continuously discharged, the operation is stopped by the paper exit tray full detection.	If it is set to "1," the operation is stopped when the paper exit tray is full or when 500 sheets (67mm thick) are discharged.	

 26-51

 Purpose
 Setting

 Function (Purpose)
 Used to set the specifications of the serial port operation. (For PCI)

#### Section

## **Operation/Procedure**

- 1) Enter the set value with 10-key.
- When the PCI is installed, setting is made to 1 or 2.
- 2) Press [OK] key.

Item/Display		Content	Setting range	Default value
A	PCI SETTING	Serial port PCI mode OFF (→For connecting the serial port vendor) Serial port PCI mode ON (JOB status LED: MODE1)	0	0 (Serial port PCI mode OFF)
		Serial port PCI mode ON (JOB status LED: MODE2)		

MODE1: Red LED is light/blink/OFF, MODE2: Red LED always OFF

## Important

When "PCI SETTING" is changed from "0" to "1" or "2," if SIM26-03 "OUTSIDE AUDITOR" is set to "S_VENDOR," "OUTSIDE AUDI-TOR" is changed to "NONE."

26-52	
Purpose	Setting
Function (Purpose)	Used to set whether non-printed paper (insertion paper, cover paper) is counted up or not.
Section	

#### **Operation/Procedure**

1) Enter the set value with 10-key.

0	Count up
1	No count up

2) Press [OK] key.

The set value in step 1) is saved.

Destination	Default
U.S.A	0 (Counted)
CANADA	0 (Counted)
INCH	0 (Counted)

Destination	Default	
JAPAN	1 (Not counted)	
AB_B	0 (Counted)	
EUROPE	0 (Counted)	
U.K.	0 (Counted)	
AUS.	1 (Not counted)	
AB_A	0 (Counted)	
CHINA	0 (Counted)	

26-53	
Purpose	Setting
Function (Purpose)	User auto color calibration (color balance
	adjustment) Inhihit/Allow setting

# Section

# **Operation/Procedure**

1) Enter the set value with 10-key.

Item/Display		Content		Setting range	Default value
А	COPY	Сору	Allow	1	1
	(1:YES 0:NO)	mode	Inhibit	0	
В	PRINTER	Printer	Allow	1	1
	(1:YES 0:NO)	mode	Inhibit	0	

2) Press [OK] key.

The set value in step 1) is saved.

26-60	
Purpose	Setting
Function (Purpose)	Used to set the utility counter mode.
Section	

## **Operation/Procedure**

- 1) Select an item to be set.
- 2) Press [EXECUTE] key.
- 3) Press [YES key.

Item	Display	Content	
Utility	MODE1	Usual counter mode	
Counter	MODE2	Toner save counter mode	
Mode	MODE3	Coverage coounter mode	

26-65				
Purpose	Setting			
Function (Purpose)	Used to set the finisher alarm mode.			
Section				

# Operation/Procedure

Use the touch key to set.

ltem	Set value	Content	Setting range	Default value	NOTE
LIMIT SHEET S	30	Numberof stapling sheets:Ma x. 30 Numberof stapling	30 or 50	50	A4, A4R, B5, 8.5"x 11", 8.5"x 11"R, 16K, 16KR For saddle
	50	sheets:Ma x. 50			stitch finisher

Item	Set	Content	Setting	Default	NOTE	
	value		range	value		
LIMIT	ON	Number of stapling sets: Max. 50 sets	ON or			
COPIES	OFF	Number of stapling sets. Not Limited	OFF			
LIMIT SHEET S (L)	25	Number of stapling sheets. Max. 25			A3, B4, 11" x 17", 8.5" x 14", 8.5" x 13.5",	
	30	Number of stapling sheets.Ma x. 30	25 or 30	25	8.5" x 13.4", 8.5" x 13", 8K For saddle stitch finisher	
Saddla	ON Number of sets loaded in the saddle staples. Limited.				For addla	
Saddle Copies	OFF	Number of sets loaded in the saddle staples. Not Limited.	On or OFF	ON	For saddle stitch finisher	

26-69	
Purpose	Setting
Function (Purpose)	Used to set the operating conditions for toner near end.
Section	

# Section

# **Operation/Procedure**

- 1) Select an item to be set with scroll keys.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

The set value in step 2 is saved.

Item/Display				Content	Setting range	Default value
A	TONER PREPARATION (0:YES 1:NO)			The toner preparation message is displayed.	0 - 1	List of Default values and set values
			1	The toner preparation message is not displayed.		for each destination
В	REMAINING TONER LEVEL	5%	0	Toner preparation at remaining toner level of 5%	0 - 9	
		10%	1	Toner preparation at remaining toner level of 10%		
		15%	2	Toner preparation at remaining toner level of 15%		
		20%	3	Toner preparation at remaining toner level of 20%		

Item/Display				Content	Setting	Default value
В	REMAINING TONER	25%	4	Toner preparation at	0 - 9	List of Default
				level of 25%		set values
		30%	5	Toner preparation at remaining toner level of 30%		for each destination
		35%	6	Toner preparation at remaining toner level of 35%		
		40%	7	Toner preparation at remaining toner level of 40%		
		45%	8	Toner preparation at remaining toner level of 45%		
		50%	9	Toner preparation at remaining toner level of 50%		
С	TONER NEAF END (0:YES 1	R :NO)	0	The toner near end message is displayed.	0 - 1	
			1	The toner near end message is not displayed.		
D	TONER END		1	Operation setup 1	1 - 3	
			2	Operation setup 2		
			3	Operation setup 3		
E	TONER END COUNT		Set nun prin Ena	ting of the nber of copy/ nt/FAX outputs able after TONER	1 - 3	1
F	TONER E-MA	IL	0	AR END. Low status	0 - 1	1
	ALERT	_	,	send of E-mail alert (When the toner preparation message is displayed) (in near near toner end)		
			1	Low status send of E-mail alert (near toner end)		

Item E (TONER	END COUNT)	setting valu	ie and	printable	quan-
tity					

Setting value	Printable quantity at A4/5% equivalent conversion
1	0
2	25
3	50

# <List of Default values and set values for each destination>

	Setting value								
Destination	Toner preparation message	Toner preparation time	Toner near end message	Enable/ Disable of print job continuation at toner end					
U.S.A	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	0 (Displayed)	2 (Print operation stopped)					

	Setting value							
Destination	Toner preparation message	Toner preparation time	Toner near end message	Enable/ Disable of print job continuation at toner end				
CANADA	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	0 (Displayed)	2 (Print operation stopped)				
INCH	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	0 (Displayed)	2 (Print operation stopped)				
JAPAN	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	1 (Not Displayed)	2 (Print operation stopped)				
AB_B	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	0 (Displayed)	2 (Print operation stopped)				
EUROPE	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	0 (Displayed)	2 (Print operation stopped)				
U.K.	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	0 (Displayed)	2 (Print operation stopped)				
AUS.	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	0 (Displayed)	2 (Print operation stopped)				
AB_A	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	0 (Displayed)	2 (Print operation stopped)				
CHINA	0 (Displayed)	4 (Displayed when the toner remaining quantity is 25%.)	0 (Displayed)	1 (Print operation continued)				

(Contents of set items)

A: Enable/Disable setting of the toner preparation message display. B: The toner remaining quantity at which the toner preparation message is displayed.

C: Enable/Disable setting of the toner preparation message display when the toner near end status is reached.

D: Machine operation at toner end

E: Number of allowable copy/print/FAX when the toner near end message is displayed. (Range: 0 - 50 sheets)

The number of output print allowed in item D is based on the assumption that the sheets are of A4 size with print ratio of 5%. (The number of outputs allowed differs depending on the paper size and the print ratio.)



When item A is set to "0" and item E is properly set, printing can be made after toner near end. However, improper phenomena such as insufficient density, thin spots, or improper color balance may result depending on the using conditions. When item E is set to "1" printing is disabled after toner near end. In this case, toner end display is made in the toner near end status, and copy/print/FAX outputs are disabled.

26-71									
Purpose	Settin	g							
Function (Purpose)	Used	to	set	the	trial	mode	of	the	web
	browsing function.								

# Section

#### **Operation/Procedure**

1) Enter the set value with 10-key.

2) Press [OK] key.

	Item/Display		Content	Setting range	Default value
A	WEB BROWSING	0	Web browsing trial mode setting	0 - 1	1
	TRIAL MODE (0: YES 1: NO)	1	Web browsing trial mode canceling		

26-73	
Purpose	Setting
Function (Purpose)	Enlargement continuous shoot, A3 wide copy mode image loss (shade delete quan- tity) adjustment
Section	

#### **Operation/Procedure**

- 1) Select an item to be set with scroll keys.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

When the adjustment value is increased, the image loss (shade delete quantity) is increased.

Item/Display		Content	Setting range	Default value
А	DELETING	Rear frame side	0 - 50	0
	SHADOW ADJ	image loss quantity		(Adjustment
	(M)	(shade delete		amount:
		quantity) adjustment		0.1mm/step)
В	DELETING	Lead edge image	0 - 50	0
	SHADOW ADJ (S)	loss quantity (shade		(Adjustment
		delete quantity)		amount:
		adjustment		0.1mm/step)

26-74					
Purpose	Setting				
Function (Purpose)	Used to set the OSA trial mode.				
Section					

#### **Operation/Procedure**

1) Enter the set value with 10-key.

2) Press [OK] key.

	Item/Display		Content	Setting range	Default value
A	OSA TRIAL MODE (0: YES 1: NO)	0	Used to set the OSA trial mode.	0 - 1	1
		1	OSA trial mode is canceled.		

26-78	
Purpose	Setting
Function (Purpose)	Used to set the password of the remote
	operation panel.

Section

#### **Operation/Procedure**

- 1) Enter a password with 10-key. (5 8 digits) The entered password is displayed on the column of "NEW". In order to correct the entered password, press the [clear] key to delete the entered value one digit by one digit.
- 2) Press [SET] key.

26-79	
Purpose	Setting
Function (Purpose)	Used to set YES/NO of the pop-up display of user data delete result.
Section	

Section

**Operation/Procedure** 

1) Enter the set value with 10-key. The value for the display operation specification after comple-

- tion of user data delete is set.
- 2) Press [OK] key.

Item/Display		Content	Setting	y range	Default value
A	DISP SET	User data delete result pop-up display ON	YES	1	0 (NO)
		User data delete result pop-up display OFF	NO	0	



27-1	
Purpose	Setting
Function (Purpose)	Used to set non-detection of communica-
	tion error (U7-00) with RIC. (FSS function)

# Section

#### **Operation/Procedure**

1) Enter the set value with 10-key.

0	Not detection
1	Detection

2) Press [OK] key.

The set value in step 1) is saved.

27-2	
Purpose	Setting
Function (Purpose)	Used to set the sender's registration num- ber and the HOST server telephone num- ber. (FSS function)
Section	

# **Operation/Procedure**

1) Select an item to be set with touch panel.

- [USER FAX NO] [SERVA TEL NO] Enter the set value with 10-key.
- 2)
- 3) Press [SET] key.

The set value in step 2) is saved.

SERVA TEL_NO. Host server telephone number (Max. 16 digits	
<ul> <li>If the connection process is not completed normally when registering the FSS, calling HOST may be continuously made every tin when the power is turned ON (from OFF) or rebooted. In this case, enter "******** to inhibit calling HOST.</li> </ul>	to the ne r to the

27-4	
Purpose	Setting
Function (Purpose)	Used to set the initial call and toner order auto send. (FSS function)
Section	· · · · · ·

## **Operation/Procedure**

- 1) Select an item to be set with scroll keys.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.
  - The set value in step 2) is saved.

Item/Display			Content	Setti ranc	ng 1e	Default value	Remarks	
А	FSS MODE	NEB1	Set the FSS MODE	Exclusive for send in NE-B mode	0-3	0	1	
		NEB2		Send/Receive in NE-B mode		1		
		NFB1		Exclusive for send in NE-F mode		2		For convenience
								stores
		NFB2		Send/Receive in NE-F mode	1	3		For convenience
								stores
В	RETRY_BUSY		Resend number setting	y when busy	0 - 1	5	2	0: No retry
С	TIMER(MINUTE)_BL	JSY	Resend timer setting (n	ninute) when busy	1 - 1	5	3	
D	RETRY_ERROR		Resend number setting	when error	0 - 1	5	1	0: No retry
E	TIMER(MINUTE)_EF	ROR	Resend timer setting (n	ninute) when error	1 - 1	5	1	
F	FAX RETRY	1	Resend number setting	when FAX initial connection	0 - 1	5	2	Unit: Number of times
G	TONER ORDER	EMPTY	Toner order auto send	Empty	0 - 11	0	6	
	HMING(K)	NEAR_END	timing setting (K)	Near end	-	1		
		0.05	-	0.05	-	2		
		0.1	-	0.1		3		
		0.15	-	0.15		4		
		0.2	-	0.2		5		
		0.25	4	0.25	-	6 		
		0.3	4	0.3	-	7		
		0.35	4	0.35	-	8		
		0.4	4	0.4	-	9		
		0.45		0.45	-	10		
		0.5	Tenendeneuterend	0.5	0 11	11	0	
н			timing softing (C)	Empty Name and	0 - 11	0	6	
		NEAR_END		Near end	-	1		
		0.05	-	0.05	-	2		
		0.1	-	0.1		3		
		0.15	-	0.15	-	4		
		0.2	-	0.2		5 6		
		0.25		0.25		7		
		0.3		0.35		0		
		0.35		0.35		0		
		0.4		0.45	-	10		
		0.5	-	0.5		11		
1	TONER ORDER	EMPTY	Toner order auto send	Empty	0 - 11	0	6	
	TIMING(M)	NEAR END	timing setting (M)	Near end		1	-	
		0.05		0.05		2		
		0.1		0.1		3		
		0.15		0.15		4		
		0.2	1	0.2	1	5		
		0.25	1	0.25	1	6		
		0.3	]	0.3	]	7		
		0.35	]	0.35	]	8		
		0.4		0.4		9		
		0.45		0.45	]	10		
		0.5		0.5		11		
J	TONER ORDER	EMPTY	Toner order auto send	Empty	0 - 11	0	6	
	TIMING(Y)	NEAR_END	timing setting (Y)	Near end	1	1		
		0.05	4	0.05	1	2		
		0.1	4	0.1		3		
		0.15	4	0.15	1	4		
		0.2	4	0.2	1	5		
		0.25	4	0.25	1	6		
		0.3	4	0.3	4	7		
		0.35	4	0.35	4	8		
		0.4	4	0.4	4	9		
		0.45	4	0.45	-	10		
17	TEMPLICTORY	0.5		0.5		11	0.2	11.2
ĸ			Frequency of acquiring	the temperature and humidity history	1 - 14	14U	00	Unit: MIN.
			Log output capacity		0-5	bU	30	UNIT: [KB]

27-5	
Purpose	Setting
Function (Purpose)	Used to set the machine tag No. (This func-
	tion allows the host computer to check the machine tag No.) (FSS function)

# Section

- **Operation/Procedure**
- 1) Enter the password (max. 8 digits) with 10-key.

The entered password is displayed on the column of "NEW". In order to correct the entered password, press the [clear] key to delete the entered value one digit by one digit.

Communication (RIC/MODEM)

2) Press [SET] key.

# 27-6

Purpose	Setting
Function (Purpose)	Used to set of the manual service call. (FSS function)
Section	

# **Operation/Procedure**

1) Enter the set value with 10-key.

0	Allow (Default)
1	Inhibit

2) Press [OK] key.

The set value in step 1) is saved.

27-7	
Purpose	Setting
Function (Purpose)	Used to set of the enable, alert callout
	(FSS function)

# Section

#### **Operation/Procedure**

- 1) Select an item to be set with scroll keys.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

The set value in step 2) is saved.

	Item/Display	Content	Setting range	Default value
А	FUNCTION	FSS function enable	0	1 (NO)
	(0:YES 1:NO)	FSS function disable	1	
В	ALERT	Alert call enable (*1)	0	0 (YES)
	(0:YES 1:NO)	Alert call disable	1	
С	CONNECTION	FAX connection enable	0	0 (FAX)
	(0: FAX	Not used.	1	
	1: No Use 2: HTTP)	HTTP connection enable	2	

#### *1 Alert send timing

No alert cause	Initial state / Trouble / Continuous JAM alert	
Maintenance	When the maintenance timing is reached.	
Service call	When pressing Service call.	
Toner send request	When the toner order automatic send setting is reached.	
Toner collection request	Revision of the toner installation date (only for a new product)	
Alert resend		

#### 27-9 Purpose Setting

Function (Purpose)

Used to set the paper transport time recording YES/NO threshold value and shading gain adjustment retry number. (FSS function)

# Section **Operation/Procedure**

- 1) Select an item to be set with scroll keys. Enter the set value with 10-key.
- 2)
- Press [OK] key. 3)

The set value in step 2) is saved.

Item/Display		Content	Setting range	Default value
A	FEED TIME1	Threshold value of paper transport time between sensors (Machine)	0 - 100	50(%)
В	FEED TIME2	Threshold value of paper transport time between sensors (SPF)	0 - 100	50(%)
С	GAIN ADJUSTMENT RETRY	Threshold value of the gain adjustment retry number	0 - 20	11 (TIMES)
D	JAM ALERT	Continuous JAM alert judgment threshold value (Alert judgment threshold value for continuous JAM's) (Setting of the number of JAM's continuously made at which it is judged as an alert.)	1 - 100	10 (TIMES)

* Items A, B: 0%, standard passing time between sheets of paper; 100%, time for judgment as a jam between sheets of paper.

* Item C: Because of a trouble in shading operation, the number of retry is actually not registered.

27-10	
Purpose	Data clear
Function (Purpose)	Used to clear the trouble prediction history information. (FSS function)
Section	

# **Operation/Procedure**

1) Press [EXECUTE] key.

2) Press [YES] key.

The history information of trouble prediction is cleared.

Target history	Serial communication retry history	
	High density process control error history	
	Halftone process control error history	
	Automatic registration adjustment error history	
	Scanner gain adjustment retry history	
	Paper transport time between sensors	

Ρ

urpose	Others

Function (Purpose)

Used to check the serial communication retry number and the scanner gain adjustment retry number history. (FSS function)

Section

# **Operation/Procedure**

The serial communication retry number history and the scanner gain adjustment retry number history are displayed.

Display Item			
ltom nomo	Occurrence date	Retry	Content
item name	(Display)	number	
LSU1	Year/month/day	8 digits	Serial
	hour: min.: sec.		communication
LSU2	Year/month/day	8 digits	retry number
	hour: min.: sec.		history display
DESK1	Year/month/day	8 digits	
	hour: min.: sec.		
DESK2	Year/month/day	8 digits	
	hour: min.: sec.		
FINISHER1	Year/month/day	8 digits	
	hour: min.: sec.		
FINISHER2	Year/month/day	8 digits	
	hour: min.: sec.		
SCAN GAIN ADJ1	Year/month/day	8 digits	Scanner gain
	hour: min.: sec.		adjustment retry
SCAN GAIN ADJ2	Year/month/day	8 digits	history
	hour: min.: sec.		
SCAN GAIN ADJ3	Year/month/day	8 digits	
	hour: min.: sec.		
SCAN GAIN ADJ4	Year/month/day	8 digits	
	hour: min.: sec.		
SCAN GAIN ADJ5	Year/month/day	8 digits	Scanner gain
	hour: min.: sec.		adjustment retry
			history

27-13	
Purpose	Others
Function (Purpose)	Used to check the history of paper transport
	time between sensors. (FSS function)

# Section Operation/Procedure

Change the display with scroll key.

	Item/Display	Content	Occurrence date	Code between sensors	Passing time	Reference passing time
Main unit	FEED TIME1	History of paper transport time between sensors 1	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME2	History of paper transport time between sensors 2	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME3	History of paper transport time between sensors 3	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME4	History of paper transport time between sensors 4	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME5	History of paper transport time between sensors 5	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME6	History of paper transport time between sensors 6	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME7	History of paper transport time between sensors 7	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME8	History of paper transport time between sensors 8	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME9	History of paper transport time between sensors 9	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME10	History of paper transport time between sensors 10	Year/month/day	5 digits	5 digits (ms)	5 digits (ms)

27-12	
Purpose	Others

Function (Purpose)

 Used to check the high density, halftone process control and the automatic registration adjustment error history. (FSS Function)

# Section

# **Operation/Procedure**

The high density, halftone process control and the automatic registration adjustment error history is displayed.

HV_ERR1	High density process control error history 1
HV_ERR2	High density process control error history 2
HV_ERR3	High density process control error history 3
HV_ERR4	High density process control error history 4
HV_ERR5	High density process control error history 5
H_TONE ERR1	Halftone process control error history 1
H_TONE ERR2	Halftone process control error history 2
H_TONE ERR3	Halftone process control error history 3
H_TONE ERR4	Halftone process control error history 4
H_TONE ERR5	Halftone process control error history 5
AUTO REG ADJ1	Automatic registration adjustment error history 1
AUTO REG ADJ2	Automatic registration adjustment error history 2
AUTO REG ADJ3	Automatic registration adjustment error history 3
AUTO REG ADJ4	Automatic registration adjustment error history 4
AUTO REG ADJ5	Automatic registration adjustment error history 5

	Item/Display	Content	Occurrence date	Code between sensors	Passing time	Reference passing time
RSPF	FEED TIME1 (SPF)	History of paper transport time between SPF sensors 1	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME2 (SPF)	History of paper transport time between SPF sensors 2	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME3 (SPF)	History of paper transport time between SPF sensors 3	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME4 (SPF)	History of paper transport time between SPF sensors 4	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME5 (SPF)	History of paper transport time between SPF sensors 5	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME6 (SPF)	History of paper transport time between SPF sensors 6	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME7 (SPF)	History of paper transport time between SPF sensors 7	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME8 (SPF)	History of paper transport time between SPF sensors 8	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME9 (SPF)	History of paper transport time between SPF sensors 9	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)
	FEED TIME10 (SPF)	History of paper transport time between SPF sensors 10	Year/month/day hour: min.: sec.	5 digits	5 digits (ms)	5 digits (ms)

27-14	
Purpose	Setting
Function (Purpose)	Used to set the FSS function connection
	test mode.

# Section

# **Operation/Procedure**

1) Enter the set value with 10-key.

0	Disable (Default)
1	Enable

2) Press [OK] key.

The set value in step 1) is saved.

27-15	27-15				
Purpose	Operation test/check				
Function (Purpose)	Used to display the FSS connection status.				

# Section Operation/Procedure

The FSS operating status is displayed.

Item/Display	Content	Setting range		Default value
FSS CONNECTION	Used to display the	0 Not		0
	FSS connection	operated		
	status.	1	Operated	

27-16				
Purpose	Setting			
Function (Purpose)	Used to set the FSS alert send.			
Section				

# **Operation/Procedure**

- 1) Enter the set value with 10-key.
  - The value for the FSS alert operation specification is set.
- 2) Press [OK] key.

Item/Display		Content		Setting range	Default value
A	MAINTENAN CE ALERT	Maintenance alert send	Alert send Enable	0	0
	(0:YES 1:NO)	Enable setting	Alert send Disable	1	
В	TONER ORDER	Toner order alert send	Alert send Enable	0	0
	ALERT (0:YES 1:NO)	Enable setting	Alert send Disable	1	
С	TONER CTRG ALERT	Toner cartridge	Alert send Enable	0	0
	(0:YES 1:NO)	replacement alert send Enable setting	Alert send Disable	1	
D	JAM ALERT (0:YES 1:NO)	Continuous JAM alert	Alert send Enable	0	0
		send Enable setting	Alert send Disable	1	
E	TROUBLE ALERT	Trouble alert send Enable	Alert send Enable	0	0
	(0:YES 1:NO)	setting	Alert send Disable	1	
F	PAPER ORDER	Paper order alert send	Alert send Enable	0	0
	ALERT (0:YES 1:NO)	Enable setting	Alert send Disable	1	

#### 27-17

Purpose	Setting
Function (Purpose)	Used to set the FSS paper order alert.

## Section Operation/Procedure

- 1) Select an item to be set.
- 2) Enter the set value with 10-key.

The value for the FSS paper order alert operation specification is set.

3) Press [SET] key.

Item/ Display	Content	Setting range	Default value	NOTE
PAPER TYPE SET	Setting of paper kind for paper order alert	0 - 2	0	0: Standard paper and recycled paper
				1: Standard paper only
				2: Recycled paper only
A3	Paper order number setting [Number of sheets] (A3)	500 - 5000	1250	Unit: No. of sheets for a box
A4	Paper order number setting [Number of sheets] (A4)	500 - 5000	2500	Unit: No. of sheets for a box
B4	Paper order number setting [Number of sheets] (B4)	500 - 5000	2500	Unit: No. of sheets for a box
B5	Paper order number setting [Number of sheets] (B5)	500 - 5000	2500	Unit: No. of sheets for a box
A3: FIRST	Paper order alert number setting (A3) (Number of used sheets)	500 - 10000	1000	Unit: No. of alert sheets for the first time
A4: FIRST	Paper order alert number setting (A4) (Number of used sheets)	500 - 10000	1000	Unit: No. of alert sheets for the first time
B4: FIRST	Paper order alert number setting (B4) (Number of used sheets)	500 - 10000	1000	Unit: No. of alert sheets for the first time
B5: FIRST	Paper order alert number setting (B5) (Number of used sheets)	500 - 10000	1000	Unit: No. of alert sheets for the first time

27-18	
Purpose	Data clear
Function (Purpose)	Used to clear the FSS paper feed retry
	counter.

# Section

## **Operation/Procedure**

- 1) Select an item to be cleared.
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

The target counter is cleared.

Item/Display	Content
TRAY1	Tray 1 paper feed retry counter
TRAY2	Tray 2 paper feed retry counter
TRAY3	Tray 3 paper feed retry counter
TRAY4	Tray 4 paper feed retry counter
MFT	Manual paper feed retry counter



30-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the sen- sors and the detectors in other than the paper feed section and the control circuits.
Section	

# Operation/Procedure

The operating conditions of the sensors and detectors are displayed.

The sensors and the detectors which are turned ON are high-lighted.

PPD1	Paper transport detector 1
PPD2	Paper transport detector 2
POD1	Paper exit detector 1
POD2	Paper exit detector 2
POD3	Paper exit detector 3
TFD2	Paper exit tray full detector (Face-down tray)
TFD3	Paper exit tray full detector (Right paper exit tray)
SHPOS	Shifter home positions sensor
DSW_R	ADU open/close detector
DSW_C	Transport cover open/close detector (Paper feed tray 1)
DSW_F	Front cover open/close detector
DHPD_CL	OPC drum rotation sensor (CL)
DHPD_K	OPC drum rotation sensor (BK)
TNFD	Waste toner full detector
HLPCD	Fusing roller pressure detector
DSW_C2	Transport cover open/close detector (Paper feed tray 2)
PRTPD	Paper exit tray paper detector (Right paper exit tray)
1TUD_CL	Transfer mode detector (CL)
1TUD_K	Transfer mode detector (BK)
2TUD	Secondary transfer position detector
WEBEND	Web end detector (36cpm machine)

30-2	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the sen- sors and the detectors in the paper feed section and the control circuits.
Section	

#### **Operation/Procedure**

The operating conditions of the sensors and detectors are displayed.

The sensors and the detectors which are turned ON are high-lighted.

CPFD1	Paper transport detector (Paper feed tray 1)
CLUD1	Paper feed tray upper limit sensor (Paper feed tray 1)
CPED1	Paper empty sensor (Paper feed tray 1)
CSPD1	Paper remaining quantity sensor (Paper feed tray 1)
CSS11	Paper feed tray size detector (Paper feed tray 1)(*1)
CSS12	
CSS13	
CSS14	
CPFD2	Paper transport detector (Paper feed tray 2)
CLUD2	Paper feed tray upper limit sensor (Paper feed tray 2)
CPED2	Paper empty sensor (Paper feed tray 2)
CSPD2	Paper remaining quantity sensor (Paper feed tray 2)
CSS21	Paper feed tray paper size detector (Paper feed tray 2)
CSS22	
CSS23	
CSS24	
CSS1	Paper feed tray 1 detector
CSS2	Paper feed tray 2 detector (*1)

CSS2SET	Desk installation detection
MPLD	Paper length detector (Manual paper feed tray)
MPED	Paper empty sensor (Manual paper feed tray)

*1: Displayed, but not installed in some models.

# 40

40-2	
Purpose	Adjustment/Setup
Function (Purpose)	Manual paper feed tray paper width sensor adjustment.
Section	Paper feed

# Operation/Procedure

- 1) Open the manual paper feed guide to the max. width (MAX).
- Press [EXECUTE] key. The max. width (MAX) detection level is recognized.
- 3) Open the manual paper feed guide to P1 width (A4).
- Press [EXECUTE] key. The P1 width (A4) detection level is recognized.
- 5) Open the manual paper feed guide to P2 width (A4R).
- 6) Press [EXECUTE] key.
  - The P2 width (A4R) detection level is recognized.
- 7) Open the manual paper feed guide to the min. width (MIN).
- 8) Press [EXECUTE] key.

The min. width (MIN) detection level is recognized.

When the above operation is not performed normally, "ERROR" is displayed. When completed normally, "COMPLETE" is displayed.

MAX POSITION	Manual feed max. width
P1(A4)POSITION	Manual feed P1 position width (A4)
P2(A4R)POSITION	Manual feed P2 position width (A4R)
MIN POSITION	Manual feed min. width

40-7	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the adjustment value of the manual paper feed tray paper width sensor.
Section	Paper feed

- Operation/Procedure
- 1) Select a target item to be adjusted with scroll keys.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

The set value in step 2) is saved.

	Item/Display	Content	Default value
А	MAX POSITION	Manual feed max. width	241
В	P1 (A4) POSITION	Manual feed P1 position width (A4)	231
С	P2 (A4R) POSITION	Manual feed P2 position width (A4R)	140
D	MIN POSITION	Manual feed min. width	19



41-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the document size sensor and the control circuit.
Section	

# **Operation/Procedure**

The operating conditions of the sensors and detectors are displayed.

The sensors and the detectors which are turned ON are high-lighted.

OCSW	Document cover status	Open: Normal display Close: Highlighted
PD1 - 7	Document detection sensor status	No document: Normal display Document present: Highlighted

41-2	
Purpose	Adjustment
Function (Purpose)	Used to adjust the document size sensor
	detection level.

# Section

#### **Operation/Procedure**

 Open the document cover, and press [EXECUTE] key without place a document on the document table.

The sensor level without document is recognized.

2) Set A3 (11" x 17") paper on the document table, and press [EXECUTE] key.

The sensor level when detecting the document is displayed.

When the above operation is normally completed, it is displayed.

41-3	
Purpose	Operation test/check
Function (Purpose)	Used to check the operations of the docu-
	ment size sensor and the control circuit.

# Section

# **Operation/Procedure**

The detection output level (A/D value) of OCSW and the document sensor (PD1 - PD7) is displayed in real time.

The light receiving range of PD1 - PD7 is 1 - 255. (Default: 128)

Item/Display	Content	Detection level range
OCSW	Original cover SW	0-1 ("1" to Close)
PD1	Document detection 1	0 - 255
PD2	Document detection 2	0 - 255
PD3	Document detection 3	0 - 255
PD4	Document detection 4	0 - 255
PD5	Document detection 5	0 - 255
PD6	Document detection 6	0 - 255
PD7	Document detection 7	0 - 255



43-1	
Purpose	Setting
Function (Purpose)	Used to set the fusing temperature in each
	mode.

# Section Operation/Procedure

- Select the SW-A or the SW-B.
- 2) Select an item to be set with scroll keys.
- Select an item to be set with displayed value. The set value in step 3) is saved.

Display	Content	Setting	Default
		range	value
		-10	
	Used to change the fusing	-5	
	temperature setting of plain paper,	0	0
GR	WUP, and Ready series	+5	
OIN		+10	
		-10	
HEAVY	Used to change the fusing	-5	
PAPER	temperature setting of heavy	0	0
GR	paper series	+5	
		+10	
		-10	
THIN	Used to change the fusing	-5	
PAPER	temperature setting of thin paper	0	0
GR	series	+5	
		+10	
		-10	
RECYCL	Used to change the fusing	-5	
ED	temperature setting of recycled paper series	0	0
		+5	
OK		+10	
		-10	
GLOSS	Used to change the fusing	-5	
PAPER	temperature setting of gloss paper	0	0
GR	series	+5	
		+10	
		-10	
ENV	Used to change the fusing	-5	
PAPER	temperature setting of envelope	0	0
GR	series	+5	
		+10	
		0	
PAP	Used to change the fusing	1	
CURL	temperature setting of paper curl	2	0
	improvement	3	
		4	

SW-A Setting value when plain paper is selected in the system setting/ device setting/fusing control setting.

 SW-B Set value when heavy paper is selected in the system setting/ device setting/fusing control setting.
 The set value displayed in this simulation differs depending on plain paper or heavy paper which is selected in the system setting/ device setting/fusing control setting.
 (Example) When plain paper is selected in the system setting/ device setting/fusing control setting, the value of SW-A is displayed.

43-2
------

Purpose

Setting Function (Purpose)

Used to set the fusing temperature and preheating.

# Section

**Operation/Procedure** 

- 1) Select the SW-A or SW-B.
- 2) Select an item to be set with scroll keys.
- 3) Enter the set value with 10-key.
- 4) Press [OK] key.

The set value in step 3) is saved.

# 26cpm/31cpm

Item / Display		Content	Setting	Defa	ult value (S	W-A)	Default value (SW-B)		
			range	Group A	Group B	Group C	Group A	Group B	Group C
А	WARMUP FUMON HL_US T	Fusing motor previous rotation start TH_US set value	30 - 200	50	50	50	50	50	50
в	WARMUP FUMOFF	Fusing motor previous rotation complete time	0 - 255	20	20	20	20	20	20
С	WARMUP END TIME	Warm-up complete time	1 - 255	14	14	14	14	14	14
D	HI_WU_FM_ON_TMP	FM preliminary rotation start TH_UM when warming up at alpha degree C or above	30 - 200	50	50	50	50	50	50
E	HI_WU_END_TIME	Warm-up completion time when warm-up at alpha degree C or above	0 - 255	14	14	14	14	14	14
F	LO_WARMUP_TIME	Setting value applying time in warm-up of 120 degree C or above (Time from Ready completion)	0 - 255	0	0	0	0	0	0
G	HI_WARMUP_TIME	Setting value applying time in warm-up of 120 degree C or above (Time from Ready completion)	0 - 255	0	0	0	0	0	0
н	HI_WARMUP_BORDER	Threshold value alpha to apply the setting value in warm-up of alpha degree C or above	1 - 119	70	70	70	70	70	70
I	JOBEND_FUMON_TIME	After-rotation time after completion of a job	0 - 255	5	5	5	5	5	5
J	HL_UM E-STAR	TH_UM set value when preheating	30 - 200	120	115	120	120	115	120
к	HL_LM E-STAR	TH_LM set value when preheating	30 - 200	100	105	105	100	105	105
L	HL_US E-STAR	TH_US set value when preheating	30 - 200	130	130	130	130	130	130
М	HL_UM PRE-JOB	Resetting from preheating TH_UM set value	30 - 200	120	130	135	155	155	160

# 36cpm

	Item / Display	Content	Setting	Default value (SW-A)			Default value (SW-B)		
			range	Group A	Group B	Group	Group	Group	Group
						С	A	В	С
А	WARMUP FUMON HL_US T	Fusing motor previous rotation start TH_US set value	30 - 200	50	50	50	50	50	50
в	WARMUP FUMOFF	Fusing motor previous rotation complete time	0 - 255	20	20	20	20	20	20
С	WARMUP END TIME	Warm-up complete time	1 - 255	14	14	14	14	14	14
D	HI_WU_FM_ON_TMP	FM preliminary rotation start TH_UM when warming up at alpha degree C or above	30 - 200	50	50	50	50	50	50
Е	HI_WU_END_TIME	Warm-up completion time when warm-up at alpha degree C or above	0 - 255	14	14	14	14	14	14
F	LO_WARMUP_TIME	Setting value applying time in warm-up of 120 degree C or above (Time from Ready completion)	0 - 255	10	10	10	10	10	10
G	HI_WARMUP_TIME	Setting value applying time in warm-up of 120 degree C or above (Time from Ready completion)	0 - 255	10	10	10	10	10	10

	Item / Display	Content	Setting	ting Default value (SW-A)		N-A)	Default value (SW-B)		
			range	Group A	Group B	Group	Group	Group	Group
	1					C	A	В	C
н	HI_WARMUP_BORDER	Threshold value alpha to apply the setting value in warm-up of alpha degree C or above	1 - 119	70	70	70	70	70	70
I	JOBEND_FUMON_TIME	After-rotation time after completion of a job	0 - 255	5	5	5	5	5	5
J	HL_UM E-STAR	TH_UM set value when preheating	30 - 200	120	130	135	120	130	135
к	HL_LM E-STAR	TH_LM set value when preheating	30 - 200	100	105	105	100	105	105
L	HL_US E-STAR	TH_US set value when preheating	30 - 200	145	150	155	145	150	155
М	HL_UM PRE-JOB	Resetting from preheating TH_UM set value	30 - 200	120	145	150	160	165	175

#### **Code descriptions**

TH_UM	Fusing thermistor main (Front surface of paper)	HL_UM	Heater lamp main (Heat roller for front surface of paper)
TH_LM	Fusing thermistor main (Back surface of paper)	HL_LM	Heater lamp main (Heat roller for front surface of paper)
TH_US	Fusing thermistor sub (Front surface of paper)	HL_US	Heater lamp sub (Heat roller for front surface of paper)

SW-A Setting value when plain paper is selected in the system setting/device setting/fusing control setting.

SW-B Set value when heavy paper is selected in the system setting/device setting/fusing control setting. The set value displayed in this simulation differs depending on plain paper or heavy paper which is selected in the system setting/device setting/fusing control setting.

(Example) When plain paper is selected in the system setting/device setting/fusing control setting, the value of SW-A is displayed.

## List of destination groups

Group	Destination							
Group A	JAPAN	-	-	-	-	-		
Group B	U. S. A	CANADA	INCH	-	-	-		
Group C	EUROPE	U. K	AUS.	AB_A	AB_B	CHINA		

43-20	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the environmental correction under low temperature and low humidity (L/ L) for the fusing temperature setting (SIM 43-2) in each paper mode.

# Section

**Operation/Procedure** 

- 1) Select an item to be set with scroll keys.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

The set value in step 2) is saved.

# Correction value: -49 - +49, Input value: Actually inputted value (1 - 99)

	-			-	-	-	
Correction value	-49	-25	-5	0	5	25	49
Input value	1	25	45	50	55	75	99

	Item / Display	Content	Setting range	Default value
А	WARMUP FUMON HL_US T LL	Correction value for fusing motor pre-rotation start TH_US set value under LL environment	1 - 99	40
В	WARMUP FUMOFF LL	Fusing motor prior rotation completion time under LL environment	1 - 99	50
С	WARMUP END TIME LL	Correction value for warm-up completion time under LL environment	1 - 99	80
D	HI_WU_FM_ON_TMP_LL	Correction value for FM prior rotation start TH_UM in warm-up at alpha degree C or above under LL environment	1 - 99	40
E	HI_WU_END_TIME_LL	Correction value for warm-up completion time in warm-up at alpha degree C or above under LL environment	1 - 99	50
F	LO_WARMUP_TIME_LL	Correction value of the setting value applying time in warm-up of 120degree C or below under LL environment (Time from Ready completion)	1 - 99	50
G	HI_WARMUP_TIME_LL	Correction value of the setting value applying time in warm-up of 120degree C or above under LL environment (Time from Ready completion)	1 - 99	50
Н	HI_WARMUP_BORDER_LL	Correction value of the threshold value alpha to apply the setting value in warm-up of alpha degree C or above under LL environment	1 - 99	50
Ι	JOBEND_FUMON_TIME LL	Correction value for the after rotation time when completing a job	1 - 99	50

	Item / Display	Content	Setting range	Default value
J	HL_UM E-STAR LL	Correction value for preheating TH_UM set value under LL environment	1 - 99	55
к	HL_LM E-STAR LL	Correction value for preheating TH_LM set value under LL environment	1 - 99	55
L	HL_US E-STAR LL	Correction value for preheating TH_US set value under LL environment	1 - 99	55
М	HL_UM PRE-JOB LL	Correction value for the set value of TH_UM when restoring from preheating under LL environment	1 - 99	55

* Item WARMUP END TIME LL: 1 Count = 1s Change

Correction value for the other items: 1 count for 1°C change

# **Code descriptions**

TH_UM	Fusing thermistor main (Front surface of paper)	HL_UM	Heater lamp main (Heat roller for front surface of paper)
TH_LM	Fusing thermistor main (Back surface of paper)	HL_LM	Heater lamp main (Heat roller for back surface of paper)
TH_US	Fusing thermistor sub (Front surface of paper)	HL_US	Heater lamp sub (Heat roller for front surface of paper)

# 43-21

Purpose	Adjustment/Setup						
Function (Purpose)	Used to set the environment correction						
	under high temperature and high humidity						
	(H/H) for the fusing temperature setting						
	(SIM 43-2) in each paper mode.						

# Section

# Operation/Procedure

1) Select an item to be set with scroll keys.

- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

The set value in step 2 is saved.

Correction value: -49 - +49, Input value: Actually inputted value (1 - 99)

Correction value	-49	-25	-5	0	5	25	49
Input value	1	25	45	50	55	75	99

Item / Display		Content	Setting	Default value				
			range	range 26cpm/		n/31cpm machine		
				Group A	Group B	Group C	machine	
А	WARMUP FUMON HL_US T HH	Fusing motor previous rotation start TH_UM set value	1 - 99	50	50	50	50	
В	WARMUP FUMOFF HH	Fusing motor previous rotation completion time	1 - 99	50	50	50	50	
С	WARMUP END TIME HH	Warm-up completion time	1 - 99	50	50	50	50	
D	HI_WU_FM_ON_TMP HH	FM preliminary rotation start TH_UM when warming up at alpha degree C or above	1 - 99	50	50	50	50	
Е	HI_WU_END_TIME HH	Warm-up completion time when warm-up at alpha degree C or above	1 - 99	50	50	50	50	
F	LO_WARMUP_TIME_HH	Correction value for AF - AH application time (Time from Ready complete)	1 - 99	50	50	50	50	
G	HI_WARMUP_TIME HH	Correction value for AJ - AL application time (Time from Ready complete)	1 - 99	50	50	50	50	
Н	HI_WARMUP_BORDER_HH	Threshold value alpha to which AN - AP is applied	1 - 99	50	50	50	50	
Ι	JOBEND_FUMON_TIME HH	After-rotation time after completion of a job	1 - 99	50	50	50	50	
J	HL_UM E-STAR HH	TH_UM set value when preheating	1 - 99	40	45	50	45	
K	HL_LM E-STAR HH	TH_LM set value when preheating	1 - 99	40	45	50	45	
L	HL_US E-STAR HH	TH_US set value when preheating	1 - 99	40	45	50	45	
М	HL_UM PRE-JOB HH	Resetting from preheating TH_UM set value	1 - 99	40	45	50	45	

* Item WARMUP END TIME HH: 1 Count = 1s Change

Correction value for the other items: 1 count for  $1^\circ C$  change

## **Code descriptions**

TH_UM	Fusing thermistor main (Front surface of paper)	HL_UM	Heater lamp main (Heat roller for front surface of paper)
TH_LM	Fusing thermistor main (Back surface of paper)	HL_LM	Heater lamp main (Heat roller for back surface of paper)
TH_US	Fusing thermistor sub (Front surface of paper)	HL_US	Heater lamp sub (Heat roller for front surface of paper)

# List of destination groups

Group	Destination							
Group A	JAPAN	APAN						
Group B	U.S.A	CANADA	INCH	-	-	-		
Group C	AB_B	EUROPE	U.K.	AUS.	AB_A	CHINA		
# 43-24 Purpose

Adjustment/Setup

Function (Purpose) Used to set the temperature adjustment value.

Section

#### **Operation/Procedure**

- 1) Select an item to be set with scroll keys.
- Enter the set value with 10-key. 2)
- 3) Press [OK] key.

The set value in step 2 is saved.

Correction value: -49 - +49, Input value: Actually inputted value (1 -99)

Correction value	-49	-25	-5	0	5	25	49
Input value	1	25	45	50	55	75	99

	Item / Display	Content	Setting Value	Default value
А	COOL_DOWN _HEAVY	Cool down time (Heavy paper)	1-60	5
В	COOL_DOWN_OHP	Cool down time (OHP)	1-60	10
С	COOL_DOWN_ENVELOPE	Cool down time (Envelope)	1-60	15
D	FUS_MOTOR	Fusing web motor operating interval	3-20	10

* Each cool down time: 1 count = 1sec change

43-31	
Purpose	Adjustment/Setup
Function (Purpose)	Used to check the operation of the fusing web cleaning.
Section	Fusing

Section

# **Operation/Procedure**

1) Press [EXECUTE] key.

Cleaning the fusing web is performed.

When cleaning the fusing web is completed, "COMPLETE" is 2) displayed.

# Note

The set value may be changed for a design change or an individual arrangement. Except for the above cases, however, the set value must not be changed. If it is changed, a trouble may be occur.

Fusing web unit installation detection state	Operation	Remarks
Fusing web unit not installed	Does not operate	* During this operation, the fusing web cleaning feed
Fusing web unit installed	Operates for the specified time.	counter is counted up.

43-32	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set various items related to the forcible operation of web cleaning when job end.
Section	Fusing
Operation/Procedure	•

- 1) Select an item to be set with the scroll key.
- 2) Enter the set value with 10-key.
- Press [OK] key. 3)

The set value in step 2) is saved.

# Note

The set value may be changed for a design change or an individual arrangement. Except for the above cases, however, the set value must not be changed. If it is changed, a trouble may be occur.

lt	em/Display	n/Display Item		Setting range		Default value
А	JOB END	Fusing web motor	Enable	0 - 1	0	1
	COMPACT	forcible operation	Disable		1	
	CHECK	condition when job end				
В	JOB END	Interval of the print quantity of		1 - 2	00	100
	COMPACT	compulsory action of the fusing				
	INTERVAL	web motor at job end				
С	JOB END	Number of forcible operations of		1 - :	5	1
	COMPACT	the fusing web motor when job				
	CNT	end				

43-34	
Purpose	Adjustment/Setup
Function (Purpose)	Used to check the fusing lower web clean- ing motor operation.
Section	Fusina

- 1) Press [EXECUTE] key.
- The fusing lower web cleaning motor is driven.
- 2) When driving the fusing web cleaning motor is completed, "COMPLETE" is displayed.
- NOTE: The set value may be changed for a design change or an individual arrangement. Except for the above cases, however, the set value must not be changed. If it is changed, a trouble may be occur.

Fusing web unit installation detection state	Operation	Remarks
Fusing lower web unit not installed	Does not operate	* During this operation, the fusing web cleaning feed
Fusing lower web unit installed	Driven by a certain pulse numbers	counter is counted up.

43-35	
Purpose	Adjustment and setting
Function (Purpose)	Fusing nip operation check
Section	Fusing

#### **Operation/Procedure**

- 1) Prepare a black-background image, and put it on the cassette with the black background facing upward.
- 2) Enter the set value with 10-key. (The cassette is specified.)
- 3) Press [EXECUTE] key.
- EXECUTE] key is highlighted and printing is started.
   When printing is executed, a jam is always generated. (As shown in the photo below.)
- 5) Leave the jam paper for about 30sec, then remove the jam paper.
- Measure the width of the gloss change section (nip) of the jam paper, and check to confirm that it is in the range of about 10.5mm - 12mm.
  - * If the difference between F and R is considerably great, the fusing pressure may be insufficient.

Ite	m/Display	item	Content	Setting range		Default value
Α	PAPER	MFT	Cassette selection	1 - 5	1	2 (CS1)
		CS1			2	
		CS2			3	
		CS3			4	
		CS4			5	



# 44

44-1	
Purpose	Setting
Function (Purpose)	Used to set each correction operation func- tion in the image forming (process) section.
Section	Image process (Photoconductor/Develop- ing/Transfer/Cleaning)

### **Operation/Procedure**

- Select an item to be set with the touch panel. (The selected item is highlighted.)
- 2) Press [EXECUTE] key. (The set value is saved.)

# Important

Set the items to the default values unless a change is specially required.

Item/ Display	Content	Setting range	Default value	NOTE
HV	Normal operation high density process control Enable/Disable setting	Normal (Disable: 1: NO)	Enable	
HT	Normal operation halftone process control Enable/Disable setting	Reverse (Enable: 0: YES)	Enable	
тс	Transfer output correction Enable/ Disable setting		Enable	
MD VG	Membrane decrease grid voltage correction Enable/Disable setting		Enable	
MD LD	Membrane laser power voltage correction Enable/Disable setting		Disable	
MD EV	Membrane decrease environment grid voltage correction Enable/Disable setting		Enable	
MD DL	Membrane decrease discharge light quantity correction Enable/ Disable setting		Enable	

Item/	Content	Setting	Default	NOTE
Display	Content	range	value	NOTE
MD DL EV	Membrane decrease	Normal	Disable	
	environment discharge	(Disable:		
	light quantity correction	1: NO)		
	Enable/Disable setting	Reverse		
TN_PIX_	Setting of Enable/	(Enable:	Enable	
SUP	Disable of toner supply	0: YES)		
	control for the yield			
	count			
TN_FB	Setting of Enable/		Enable	
	Disable of the toner			
	the process control			
	result			
TN INT	Setting of Enable/		Enable	
	Disable of toner		LIIUDIC	
	compulsory supply			
	correction for the			
	development traveling			
	distance			
TN_RECV	Setting of Enable/	1	Enable	
	Disable of the toner			
	density recovery			
	operation			
TN_ADJ	Setting of Enable/		Enable	
	Disable of the toner			
	sensor control voltage			
	adjustment in the			
	process control			
TN_EMP	Setting of Enable/	Normal	Enable	
	Disable of the toner	(Disable:		
	falling distance	1: NO)		
	detection control	Reverse		
TN_EMP_	Setting of Enable/	(Enable:	Enable	
INT	Disable of the toner	0: YES)		
	failing distance			
	interruption			
	Sotting of Epoblo/		Enchlo	
	Disable of the new		LIIADIE	
142.00	toner cartridge falling			
	distance detection			
	control			
TN_PIX	Setting of Enable/		Enable	
TBL	Disable of execution of			
	revision of the yield			
	count conversion table			
	for the toner supply			
	control in the halftone			
	process control			
AR_AUTO	Auto registration		Enable	
	adjustment Enable/			
	Disable setting			
AR_ERROR	Auto registration		Enable	
	adjustment execution			
	Pipoblo cotting			
			Exet.	
DM_PHASE	Drum phase fitting		Enable	
	Enable/Disable setting		Exet.1	
PRI_HI			Enable	
	control printer			
	Enable/Disable sotting			
			Enchle	Enables
FIC_ENV	correction Enable/		Enable	Correc-
	Disable setting			tion ON
		1		

44-2	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the sensitivity of the image density sensor (registration sensor).
Section	Process

When [EXECUTE] key is pressed, the adjustment is executed automatically.

After completion of the adjustment, the adjustment result is displayed.

If the adjustment is not executed normally, "ERROR" is displayed.

Classifi- cation	i- Item/Display		Content	Setting range	Default value
PROCON	A	PCS_F_C L_KA	Color image sensor light emitting quantity adjustment value	1 - 255	500
	В	PCS_F LED ADJ	Image sensor light emitting quantity adjustment value F	1 - 255	32
	С	PCS_R LED ADJ	Image sensor light emitting quantity adjustment value R	0 - 255	40
	D	PCS_F_C L_DARK	Dark voltage of color image sensor	0 - 255	0
	E	PCS_F DARK	Dark voltage of image sensor F	0 - 255	0
	F	PCS_R DARK	Dark voltage of image sensor R	0 - 255	0
	Ð	PCS_F GRND	Transfer belt substrate detection level when the item B adjustment is completed	0 - 255	0
	Η	PCS_F BELT MAX	Transfer belt substrate input max. value F	0 - 255	0
	Ι	PCS_F BELT MIN	Transfer belt substrate input min. value F	1 - 255	0
	J	PCS_F BELT DIF	Transfer belt substrate input difference F (Item H - Item I)	0 - 255	0
	К	PCS_R GRND	Transfer belt substrate detection level when the item C adjustment is completed	0 - 255	0
	L	PCS_R BELT MAX	Transfer belt substrate input max. value R	1 - 255	0
	Μ	PCS_R BELT MIN	Transfer belt substrate input min. value R	0 - 255	0
	N	PCS_R BELT DIF	Transfer belt substrate input difference R (Item L - Item M)	0 - 256	0

Classifi- cation	Item/Display		Content	Setting range	Default value
REGIST	0	REG F	Registration sensor	0 - 255	32
		LED ADJ	light emitting		
			quantity		
	_		adjustment value F		
	Р	REG_F	Registration sensor	0 - 255	0
	0	DARK REG E	Transfer belt	0 - 255	0
	Q	GRND	substrate detection	0-233	0
			level when the item		
			B adjustment is		
	<b>D</b>	DE0 D	completed	0 055	10
	ĸ		Registration sensor	0 - 255	40
		LEDINDU	quantity		
			adjustment value R		
	S	REG_R	Registration sensor	0 - 255	0
	-	DARK	dark voltage R	0 055	0
	1	REG_R	substrate detection	0 - 255	0
		OTT	level when the item		
			R adjustment is		
			completed		
	U	REG_F	Transfer belt	0 - 255	0
		DELI WAA	level max, value (F		
			side)		
	V	REG_F	Transfer belt	0 - 255	0
		BELT MIN	substrate detection		
			level min. value (F		
	W	RFG F	Transfer belt	0 - 255	0
		BELT DIF	substrate detection	0 200	Ũ
			level difference		
			(Item U - Item V)		
	х	REG_R BELT MAY	Transfer belt	0 - 255	0
			level max. value (R		
			side)		
	Y	REG_R	Transfer belt	0 - 255	0
		BELI MIN	substrate detection		
			side)		
	Z	REG_R	Transfer belt	0 - 255	0
		BELT DIF	substrate detection		
			level difference		
	ΔΔ	REG E	Toper patch	0 - 255	0
	,	PATCH (K)	detection level R	0 200	Ũ
			(K) in the		
			registration		
	٨Þ	PEC E	adjustment	0 255	0
		PATCH (C)	detection level R	0 - 200	0
		x - 7	(C) in the		
			registration		
	A.C.	PEC F	adjustment	0 255	0
	AC	PATCH	detection level R	0 - 200	U
		(M)	(M) in the		
			registration		
	4.0	DE0 E	adjustment	0 055	
	AD	REG_F PATCH (V)	Ioner patch	0 - 255	0
			(Y) in the		
			registration		
			adjustment		
	AE	REG_R	Toner patch	0 - 255	0
		FAIGH (K)	(K) in the		
			registration		
			adjustment		
	AF	REG_R	Toner patch	0 - 255	0
		PAICH (C)	aetection level R		
			registration		
	L		adjustment		

Classifi- cation	lte	m/Display	Content	Setting range	Default value
REGIST	AG	REG_R PATCH (M)	Toner patch detection level R (M) in the registration adjustment	0 - 255	0
	AH	REG_R PATCH (Y)	Toner patch detection level R (Y) in theregistration adjustment	0 - 255	0

F sensor adjustment abnormalityPCS_F LED ADJ error The target is not reached by 4 times of adjust- ments.R sensor adjustment abnormalityPCS_R LED ADJ error The target is not reached by 4 times of adjustments.Color sensor adjustment abnormalityPCS_F_CL_KA ADJ error The target is not reachedSubstrate scan abnormality FPCS_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration sensor F adjustment abnormalityREG_F LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn </th <th>Error name</th> <th>Error content</th>	Error name	Error content
abnormalityThe target is not reached by 4 times of adjustments.R sensor adjustmentPCS_R LED ADJ errorabnormalityThe target is not reached by 4 times of adjustments.Color sensorPCS_F_CL_KA ADJ erroradjustmentThe target is not reachedabnormalityPCS_F GRND errorSubstrate scanPCS_F GRND errorabnormality FPCS_F GRND errorSubstrate scanPCS_R GRND errorabnormality RPCS_R GRND errorSubstrate scanPCS_R GRND errorabnormality RPCS_R GRND errorSubstrate scanPCS_R GRND errorabnormality RPCS_R GRND errorRegistration sensorREG_F LED ADJ errorF adjustment abnormalityREG_F LED ADJ errorRegistration sensorREG_R LED ADJ errorThe target is not reached by 4 times of adjust- mentsRegistration sensorREG_R LED ADJ errorR adjustment abnormalityREG_R LED ADJ errorThe target is not reached by 4 times of adjust- mentsRegistration substrate F scan abnormalityREG_F GRND errorRed_R GR GRND errorThe difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error<	F sensor adjustment	PCS_F LED ADJ error
R sensor adjustment abnormalityPCS_R LED ADJ error The target is not reached by 4 times of adjustments.Color sensor adjustment abnormalityPCS_F_CL_KA ADJ error The target is not reachedSubstrate scan abnormality FPCS_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration sensor F adjustment abnormalityREG_F LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate F scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. v	abnormality	The target is not reached by 4 times of adjust-
Resister adjustmentPCS_R CLD ADJ entorabnormalityThe target is not reached by 4 times of adjustments.Color sensorPCS_F_CL_KA ADJ erroradjustmentThe target is not reachedabnormalityPCS_F GRND errorSubstrate scan abnormality FPCS_F GRND errorSubstrate scan abnormality RPCS_R GRND errorSubstrate scan abnormality RPCS_R GRND errorRegistration sensor F adjustment abnormalityPCS_R GRND errorRegistration sensor R adjustment abnormalityREG_F LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error 	P concor adjustment	
Color sensor adjustment abnormalityPCS_F_CL_KA ADJ error The target is not reachedSubstrate scan abnormality FPCS_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration sensor F adjustment abnormalityREG_F LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	abnormality	The target is not reached by 4 times of
Color sensor adjustment abnormality       PCS_F_CL_KA ADJ error The target is not reached         Substrate scan abnormality F       PCS_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Substrate scan abnormality R       PCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration sensor F adjustment abnormality       REG_F LED ADJ error The target is not reached by 4 times of adjust- ments         Registration sensor R adjustment abnormality       REG_R LED ADJ error The target is not reached by 4 times of adjust- ments         Registration sensor F adjustment abnormality       REG_R LED ADJ error The target is not reached by 4 times of adjust- ments         Registration substrate F scan abnormality       REG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration substrate R scan abnormality       REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	abriormany	adjustments.
adjustment abnormalityThe target is not reachedSubstrate scan abnormality FPCS_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration sensor F adjustment abnormalityREG_F LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	Color sensor	PCS_F_CL_KA ADJ error
abnormality         Substrate scan abnormality F       PCS_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Substrate scan abnormality R       PCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration sensor F adjustment abnormality       REG_F LED ADJ error The target is not reached by 4 times of adjust- ments         Registration sensor R adjustment abnormality       REG_R LED ADJ error The target is not reached by 4 times of adjust- ments         Registration sensor R adjustment abnormality       REG_R LED ADJ error The target is not reached by 4 times of adjust- ments         Registration substrate F scan abnormality       REG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration substrate R scan abnormality       REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	adjustment	The target is not reached
Substrate scan abnormality FPCS_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration sensor F adjustment abnormalityREG_F LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	abnormality	
abnormality FThe difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration sensor F adjustment abnormalityREG_F LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	Substrate scan	PCS_F GRND error
min. Value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnSubstrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration sensor F adjustment abnormalityREG_F LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	abnormality F	The difference between the max. value and the
Substrate scan abnormality RPCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration sensor F adjustment abnormalityREG_F LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration sensor R adjustment abnormalityREG_R LED ADJ error The target is not reached by 4 times of adjust- mentsRegistration substrate F scan abnormalityREG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turnRegistration substrate R scan abnormalityREG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn		min. value of the substrate detection level is
Substrate scan abnormality R       PCS_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration sensor F adjustment abnormality       REG_F LED ADJ error The target is not reached by 4 times of adjust- ments         Registration sensor R adjustment abnormality       REG_R LED ADJ error The target is not reached by 4 times of adjust- ments         Registration substrate F scan abnormality       REG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration substrate R scan abnormality       REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration substrate R scan abnormality       REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer		belt rotates 2 turn
abnormality R       The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration sensor F adjustment abnormality       REG_F LED ADJ error The target is not reached by 4 times of adjustment abnormality         Registration sensor R adjustment abnormality       REG_R LED ADJ error The target is not reached by 4 times of adjustment abnormality         Registration sensor R adjustment abnormality       REG_R LED ADJ error The target is not reached by 4 times of adjustments         Registration sensor Red_R LED ADJ error The target is not reached by 4 times of adjustments       REG_F GRND error The target is not reached by 4 times of adjustments         Registration sensor abnormality       REG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration substrate R scan abnormality       REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	Substrate scan	PCS_R_GRND error
min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration sensor F adjustment abnormality       REG_F LED ADJ error         The target is not reached by 4 times of adjustment abnormality       REG_R LED ADJ error         Registration sensor R adjustment abnormality       REG_R LED ADJ error         Registration sensor R adjustment abnormality       REG_R LED ADJ error         Registration sensor R adjustment abnormality       REG_F GRND error         Registration sensor abnormality       REG_F GRND error         Registration sensor abnormality       REG_F GRND error         Registration sensor abnormality       REG_F GRND error         Registrate F scan abnormality       REG_R GRND error         Registration substrate R scan abnormality       REG_R GRND error         Registration substrate R scan abnormality       REG_R GRND error         The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	abnormality R	The difference between the max, value and the
greater than the specified value when the transfer belt rotates 2 turn       Registration sensor F adjustment abnormality     REG_F LED ADJ error The target is not reached by 4 times of adjust- ments       Registration sensor R adjustment abnormality     REG_R LED ADJ error The target is not reached by 4 times of adjust- ments       Registration substrate F scan abnormality     REG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn       Registration substrate R scan abnormality     REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn		min. value of the substrate detection level is
belt rotates 2 turn           Registration sensor F adjustment abnormality         REG_F LED ADJ error The target is not reached by 4 times of adjust- ments           Registration sensor R adjustment abnormality         REG_R LED ADJ error The target is not reached by 4 times of adjust- ments           Registration substrate F scan abnormality         REG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn           Registration substrate R scan abnormality         REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn           Registration substrate R scan abnormality         REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer		greater than the specified value when the transfer
Registration sensor F adjustment abnormality       REG_F LED ADJ error The target is not reached by 4 times of adjust- ments         Registration sensor R adjustment abnormality       REG_R LED ADJ error The target is not reached by 4 times of adjust- ments         Registration substrate F scan abnormality       REG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 tum         Registration substrate R scan abnormality       REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 tum		belt rotates 2 turn
F adjustment abnormality       The target is not reached by 4 times of adjust- ments         Registration sensor R adjustment abnormality       REG_R LED ADJ error The target is not reached by 4 times of adjust- ments         Registration substrate F scan abnormality       REG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration substrate R scan abnormality       REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn	Registration sensor	REG_F LED ADJ error
abnormality     Inertis       Registration sensor     REG_R LED ADJ error       R adjustment     The target is not reached by 4 times of adjust- ments       Registration     REG_F GRND error       substrate F scan     REG_F GRND error       abnormality     REG_F GRND error       Registration     substrate detection level is greater than the specified value when the transfer belt rotates 2 turn       Registration     REG_R GRND error       substrate R scan     REG_R GRND error       abnormality     The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer	F adjustment	The target is not reached by 4 times of adjust-
Registration sensor       REG_R LED ADJ error         R adjustment       The target is not reached by 4 times of adjustments         Registration       REG_F GRND error         substrate F scan       REG_F GRND error         abnormality       REG_F GRND error         abnormality       REG_R GRND error         substrate F scan       Belt rotates 2 turn         Registration       REG_R GRND error         substrate R scan       REG_R GRND error         abnormality       REG_R GRND error         runn abnormality       REG_R GRND error         runn abnormality       Registration substrate detection level is greater than the specified value when the transfer         belt rotates 2 turn       The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer	abnormality	
Registration       REG_F GRND error         abnormality       REG_F GRND error         abnormality       REG_F GRND error         abnormality       REG_R GRND error         abnormality       REG_R GRND error         abnormality       REG_R GRND error         Registration       REG_R GRND error         substrate R scan       REG_R GRND error         abnormality       REG_R GRND error         rub difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer         belt rotates 2 turn       The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer	Registration sensor	REG_R LED ADJ error The target is not reached by 4 times of adjust-
Registration substrate F scan abnormality       REG_F GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration substrate R scan abnormality       REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer between the substrate detection level is greater than the specified value when the transfer	abnormality	ments
Substrate F scan abnormality       The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn         Registration substrate R scan abnormality       REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer between the substrate detection level is	Registration	REG F GRND error
abnormality     min. value of the substrate detection level is greater than the specified value when the transfer belt rotates 2 turn       Registration     REG_R GRND error       substrate R scan     The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer	substrate F scan	The difference between the max. value and the
Registration       REG_R GRND error         substrate R scan       The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer	abnormality	min. value of the substrate detection level is
Registration substrate R scan abnormality         REG_R GRND error The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer helt relater 2.		greater than the specified value when the transfer
substrate R scan abnormality       The difference between the max. value and the min. value of the substrate detection level is greater than the specified value when the transfer helt relater 2.	Registration	REG R GRND error
abnormality min. value of the substrate detection level is greater than the specified value when the transfer	substrate R scan	The difference between the max. value and the
greater than the specified value when the transfer	abnormality	min. value of the substrate detection level is
	-	greater than the specified value when the transfer

### 44-4

Purpose

Setting Function (Purpose)

Used to set the conditions of the high density process control operation.

Section

Process

#### **Operation/Procedure**

- 1) Select an item to be set with scroll keys.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

# Important

Set the items to the default values unless a change is specially required.

	Item/Display	Content	Setting	Default
A	PCS_CL TARGET	Color image sensor	1 - 255	204
В	PCS_K TARGET	Black image sensor adjustment target value	1 - 255	204
С	LED_CL OUTPUT	Color image sensor light emitting start level	1 - 255	21
D	LED_K OUTPUT	Black image sensor light emitting start level	1 - 255	21
E	PCS ADJSTMENT LIMIT	Color image sensor adjustment error allowance level	1 - 255	4
F	BELT GROUND DIF	Transfer belt one-turn substrate detection level difference allowance level	1 - 255	1
G	BIAS_CL STANDARD DIF	Developing bias (for color) reference correction voltage	0 - 255	60
Н	BIAS_BK STANDARD DIF	Developing bias (for black) reference correction voltage	0 - 255	0
Ι	BIAS PATCH INTERVAL	Toner patch making developing bias interval	1 - 255	60
J	Y_PAT TARGET ID	Process control target density level (yellow)	1 - 255	40
К	M_PAT TARGET ID	Process control target density level (magenta)	1 - 255	45
L	C_PAT TARGET ID	Process control target density level (cyan)	1 - 255	45
М	K_PAT TARGET ID	Process control target density level (black)	1 - 255	45
Ν	HV BK_GROUND LIMIT	Black image sensor adjustment error allowance level	1 - 255	60

44-6	
Purpose	Adjustment
Function (Purpose)	Used to execute the high density process
	control forcibly.

Process

**Operation/Procedure** 

Section

Press [EXECUTE] key.

In case of a normal completion, the result is saved.

In case of an abnormal completion, "ERROR" is displayed.

(Refer to the table below.)

In case of an ERROR, the previous correction data are saved.

Result display	Content description
COMPLETE	Normal complete
ERROR	Abnormal end
INTERRUPTION	Forcible interruption

Details of error display	Content description
CL_SEN_ADJ_ERR	Color image sensor adjustment abnormality
BK_SEN_ADJ_ERR	Black image sensor adjustment abnormality
K_HV_ERR	K high density process control abnormality
C_HV_ERR	C high density process control abnormality
M_HV_ERR	M high density process control abnormality
Y_HV _ERR	Y high density process control abnormality
TIMEOUT_ERR	Time out

44-9		
Purpose	Operation data display	
Function (Purpose)	Used to display the result data of the high density process control operation.	
Section	Image process (Photoconductor/Develop-	

Image process (Phot ing/Transfer/Cleaning) p

### Operation/Procedure

Select a target display mode with [CPY/PRN], [OTHER] keys.

Mode	Iten	n/Display (*: Correction value)	Content	Display range	Default value
CPY/PRN	P (PROCON)	BLACK : GB ***/*** DV ***/***	High density process control mode	GB: 150 - 850	GB: 630
		CYAN : GB ***/*** DV ***/***	GB/DV data (KCMY)	DV: 0 - 600	DV: 430
		MAGENTA : GB ***/*** DV ***/***	(Output voltage level/base voltage level)		
	N1/NA)	YELLOW : GB ***/*** DV ***/***		00.450.050	
		BLACK : GB ***/*** DV ***/***	Medium speed print mode	GB: 150 - 850	GB: 630
	(MIDDLE))	MAGENTA · GB ***/*** DV ***/***	(Actual output voltage level/base voltage level)	DV. 0 - 000	DV. 430
	. ,,	YELLOW : GB ***/*** DV ***/***			
	N(L)	BLACK : GB ***/*** DV ***/***	Low speed print mode	GB: 150 - 850	GB: 600
	(NORMAL	CYAN : GB ***/*** DV ***/***	GB/DV data (KCMY)	DV: 0 - 600	DV: 400
	(LOW))	MAGENTA : GB ***/*** DV ***/***	(Actual output voltage level/base voltage level)		
		YELLOW : GB ***/*** DV ***/***			
OTHER	TN/TC	TN HUD AREA	Toner density correction humidity area	1 - 8	4
			Ioner density correction humidity AD value	0 - 1023	0
			Transfer correction temperature AD value	0 - 1023	4
			Transfer correction humidity area	1 - 9	4
		TC HUD DATA	Transfer correction humidity AD value	0 - 1023	0
		MD HUD AREA	Membrane decrease correction humidity area	1 - 8	4
		MD HUD DATA	Membrane decrease correction humidity AD value	0 - 1023	0
	DRUM	MD K STEP	Drum membrane decrease correction STEP level	0 - 4	0
		MD C STEP	(KCMY)		
		MD M STEP			
		MD Y STEP			
		MD K DRUM COUNTER	Membrane decrease drum traveling distance area	0 - 20	0
			(KCMT)		
OTHER	LIFE	MD K BEVISE(LIFE) · L *** M ***	MC grid correction voltage level (for the drum	0 - 255	0
0		MD C REVISE(LIFE) : L *** M ***	membrane decrease) (KCMY)	0 200	Ū
		MD M REVISE(LIFE) : L *** M ***			
		MD Y REVISE(LIFE) : L *** M ***			
	EV	MD K REVISE(EV) : L *** M ***	MC grid voltage correction level (for the	0 - 255	0
		MD C REVISE(EV) : L *** M ***	environment) (KCMY)		
		MD M REVISE(EV) : L *** M ***			
			MO anid walte an anomatical lawshift a the should	0.055	
	ALL		membrane decrease) (KCMY)	0 - 255	0
		MD M REVISE(ALL) : L *** M ***			
		MD Y REVISE(ALL) : L *** M ***			
	LD	MD K REVISE(LD) : L *** M ***	Laser power correction level (for the drum	0 - 255	0
		MD C REVISE(LD) : L *** M ***	membrane decrease) (KCMY)		
		MD M REVISE(LD) : L *** M ***			
		MD Y REVISE(LD) : L *** M ***			
	DL	MD K REVISE COL (DL): L *** M ***	Discharge lamp correction level (%) (for the drum	0 - 100	70
		MD C REVISE COL (DL): L *** M ***	membrane decrease)		
	DI EV		Discharge lamp correction level (%) (for the	-100 - 100	0
	DEEV	MD C REVISE COL (DL EV): L *** M ***	environment)	100 100	Ũ
		MD M REVISE COL (DL EV): L *** M ***			
		MD Y REVISE COL (DL EV): L *** M ***			
	CRUM	DESTINATION	CRUM destination (Main unit data)	-	-
		MODEL TYPE	Machine model type	0 - 1	0
		CRUM DEST_K	CRUM destination (CRUM data)	-	-
		CRUM DEST_C			
	CNT		High density process control number of executions	0 - 00000000	0
		PROCON COUNT HT	Halftone process control number of executions	0 - 99999999	0
					~

44-12		
Purpose	Operation data display	
Function (Purpose)	Used to display the operation data of the high density process control and the image density sensor (registration sensor).	
Section	Image process (Photoconductor/Develop-	

Select a display mode with [TARGET] [PATCH] keys.

ing)

Mode	Item/Display	Content	Display	Default
TARGET	ADK SI (K)	Development		value
TARGET		characteristics gradient coefficient (High density process control operation)	9.99	0
	ADK_INT(K)	Development characteristics intercept level (High density process control operation 0V)	-999.9 - 999.9	0
	TARGET (K)	High density process control target density level (K)	0.00 - 255.00	0
	TARGET (C/M/Y)	High density process control target density level (C/M/Y)	0.00 - 255.00	0
	PCS_F_ DARK	F sensor dark potential	0 - 255	0
	PCS_R_ DARK	R sensor dark potential	0 - 255	0
PATCH	n-1	High density process control nth time toner patch density level 1 (n=1-5)	0 - 255	0
	n-2	Toner patch data nth time patch 2 (n=1-5)	0 - 255	0
	n-3	Toner patch data nth time patch 3 (n=1-5)	0 - 255	0
	n-4	Toner patch data nth time patch 4 (n=1-5) • BK only	0 - 255	0
	n-5	Toner patch data nth time patch 5 (n=1-5) • BK only	0 - 255	0
PATCH	n-1	Toner patch data nth time patch 1 (n=6-10)	0 - 255	0
	n-2	Toner patch data nth time patch 2 (n=6-10)	0 - 255	0
	n-3	Toner patch data nth time patch 3 (n=6-10)	0 - 255	0
	n-4	Toner patch data nth time patch 4 (n=6-10) • BK only	0 - 255	0
	n-5	Toner patch data nth time patch 5 (n=6-10) • BK only	0 - 255	0

44-14	
Purpose	Operation data display
Function (Purpose)	Used to display the output level of the temperature and humidity sensor.
Section	Process (OPC drum, development)/Fusing/ LSU

### **Operation/Procedure**

The output levels of the fusing temperature sensor, the machine temperature sensor, and the humidity sensor are displayed.

Item/Display	Content	Display range
TH_UM	Fusing main thermistor	Temperature: $0 = 255^{\circ}C (+1^{\circ}C)$
	(AD value)	AD value: 0-1023
TH_UM_AD1	Fusing thermistor detection	Temperature:
	level for compensation (°C)	0.0-255.0°C (±0.2°C)
	/ (AD value)	AD value: 0-1023
TH_UM_AD2	Fusing thermistor detection	AD value: 0-1023
	level (AD value)	
TH_LM	Fusing thermistor A/D value	Temperature:
	(temperature °C) (Fusing	0 - 255°C (±1°C)
	roller B edge)	AD value: 0-1023
TH_US	Fusing sub thermistor A/D	Temperature:
	value (temperature °C)	0 - 255°C (±1°C)
	(Fusing belt)	AD value: 0-1023
TEMPRATURE	Process control thermistor	Temperature:
	detection level	-40.0 - 60.0°C (±0.1°C)
		AD value: 0-1023
HUMIDITY	Process control humidity	Humidity:
	sensor detection level	5.0-90.0% (±0.1%),
		AD value: 0-1023
TH1_LSU	LSU thermistor detection	Temperature:
	level (A/D value) (°C)	5.0-60.0°C (±0.1°C)
		AD value: 0-255

44-15	
Purpose	Setting
Function (Purpose)	Used to set the OPC drum idle rotation.
Section	Process

### **Operation/Procedure**

- 1) Select an item to be set with the scroll key.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

The initial value must be set unless any special change is required.

0	ltem/ Display	Content	Setting range	Default value
A	TIME	Idle rotation interval (time interval between the previous OPC drum idle rotation and the next one) setting (h)	0 - 255	6
В	AREA1	Environmental area difference judgment threshold value setting (difference between the previous OPC drum idle rotation and the current one)	0 - 5	2
С	AREA2	Environmental area conditions (AND condition of the previous OPC drum idle rotation and the current one)	1 - 15	1
D	CYCLE	Previous rotation time setting (sec) in the process control when recovered from power ON, preheating/sleep mode.	0 - 255	0

The execution YES/NO of the OPC drum idle rotation is determined by the AND condition of TIME, AREA1, and AREA 2. To execute the OPC drum idle rotation, set item B (AREA 1) to "0," and item C (AREA2) to "15." However, idle rotation is performed in a certain interval while in shut off. This must be fully explained to the user.

### 44-17

Purpose	Setting
Function (Purpose)	Process refresh execution
Section	Process

Section F Operation/Procedure

- 1) Select a refresh item with the touch panel key.
- 2) Press [EXECUTE] key.
- 3) The refresh operation is executed.

NOTE: Do not execute this simulation unless specially required.

# Display items and descriptions of contents

Display	Content	
BLADE REFRESH	Blade development refresh	
DRUM REFRESH	Drum refresh	
DEVE REFRESH	Development refresh * DEVE REFLESH execution consume W-Letter A3 100% worth of toner.	

# Display of results and descriptions of items

Display	Content
COMPLETE	Normal completion
ERROR	Abnormal end
INTERRUPTION	Forcible interruption

44-21	
Purpose Adjustment/Setup	
Function (Purpose)         Used to set the halftone process control get.	
Section	Process

# **Operation/Procedure**

Press [EXECUTE] key.

The halftone process control target is set and the operation data are displayed.

Display	Content
COMPLETE	Normal complete
ERROR COLOR SENSOR ADJUSTMENT	Color image density sensor sensitivity adjustment error
ERROR BLACK SENSOR ADJUSTMENT	Black image density sensor sensitivity adjustment error
[YMCK]	High density process control error [YMCK]
OTHER	Other errors

44-22	
Purpose	Operation data display
Function (Purpose)	Used to display the toner patch density level in the halftone process control operation.
Section	Process

# Operation/Procedure

 Select the display mode with [1ST STEP],[2ND STEP] key. The toner patch density level made in the halftone process control operation is displayed.

Item/Display	Content
ID_n	Patch data display
	(PTK: n = 1 - 24, PTC/PTM/PTY: n = 1 - 16)
BASE1	Belt substrate data (START)
BASE5	Belt substrate data (LAST)

44-24	
Purpose	Operation data display
Function (Purpose)	Used to display the correction target and
	the correction level in the halftone process

control operation.

Section Process

### **Operation/Procedure**

- 1) Select the display category with [NEXT] key.
- 2) Select a target adjustment color with [K] [C] [M] [Y] key.

Category	Item/Display	Content
Coefficient	[EX-LOW]	Coefficient of the approximation formula of the minimum density
	[LOW]	Coefficient of the approximation formula of the low density
	[CONNECT]	Coefficient of the approximation formula of when connecting the low density and the medium density
	[MID]	Coefficient of the approximation formula of the medium density
	[HIGH]	Coefficient of the approximation formula of the high density
	[CONNECT POINT]	Each density section connection output ratio
Reference value	[SENSOR_TARGET]	Halftone process control reference value
Correction value	[S_VALUE]	Halftone process control correction value
For printer	[PRINTER_S_VALUE]	Printer halftone process control correction value
	[PRINTER_BASE_ DITHER_VALUE]	Printer halftone process control reference dither value
	[PRINTER_AUTO_ HT_VALUE]	Printer auto density adjustment correction value
Previous correction value	[BEFORE S_VALUE]	Previous halftone process control value

44-25	
Purpose	Setting
Function (Purpose)	Used to set the calculating conditions of the
	correction value for the halftone process control.

Section Process

### **Operation/Procedure**

- 1) Select a target adjustment color with [K] [C] [M] [Y] key.
- 2) Select a target adjustment density level with scroll key on the touch panel.
- 3) Enter the set value with 10-key.
- 4) Press [OK] key.

# Important

Set the items to the default values unless a change is specially required.

	Item/Display	Content	Setting	Default value		
			range	К	CMY	
A	LOW FIELD LOWER LIMIT	Low density approximate expression data lower limit value	0 - 255	98	98	
В	LOW FIELD UPPER LIMIT	Low density approximate expression data upper limit value	0 - 255	60	60	
С	MID FIELD LOWER LIMIT	Medium density approximate expression data lower limit value	0 - 255	90	90	
D	MID FIELD UPPER LIMIT	Medium density approximate expression data upper limit value	0 - 255	6	2	
E	HIGHLIGHT POINT	Reference point of the highlight correction amount	1 - 8	7	7	
F	HIGHTLIGHT VALUE LIMIT	Highlight correction amount limit value	0 - 128	20	20	
G	MAX VALUE LIMIT	Maximum density value correction limit value	0 - 128	20	20	

44-26	
Purpose	Adjustment/Setup
Function (Purpose)	Used to execute the halftone process con- trol compulsory.
Section	Process

# Operation/Procedure

Press [EXECUTE] key.

The halftone process control is performed and the operation data are displayed.

COMPLETE	Normal complete
ERROR COLOR SENSOR ADJUSTMENT	Color image density sensor sensitivity adjustment error
ERROR BLACK SENSOR ADJUSTMENT	Black image density sensor sensitivity adjustment error
[YMCK]	High density process control error [YMCK] error
OTHER	Other errors

44-27	
Purpose	Data clear
Function (Purpose)	Used to clear the correction data of the half- tone process control.
Section	Process

### **Operation/Procedure**

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

The correction data of the halftone process control are cleared.

44-28	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the process control execution conditions.
Section	Process

- 1) Select a target item of setting with scroll key on the touch panel.
- 2) Enter the set value with 10-key.

3) Press [OK] key. (The set value is saved.)



Set the items to the default values unless a change is specially required.

Mode	Item/Display		ay	Content		Setting range	e	Default value
Process control	Α	INITIAL	YES	When warm-up after clearing the counter	Enable	0 - 1	0	0
Enable/Disable			NO	of the OPC drum and the developer unit	Disable		1	
setting	В	SW ON		When supplying the power (when	Color process control	0 - 3	0	3
				canceling power snut-on)	Enable Brooses control Dischlo		1	-
					BK process control Enable		2	
					Pixel count judgment		3	
	С	TIME		After passing the specified time from	Color process control	0 - 3	0	3
	-			leaving READY continuously (Time can be	Enable			-
				changed by INTERVAL TIME)	Process control Disable		1	
					BK process control Enable		2	
					Pixel count judgment		3	
	D	HUM_LIMIT	-	HUM judgment is made when turning ON	Color process control	0 - 2	0	0
				the power and after passing INTERVAL	Enable			-
				TIME.	Process control Disable		1	-
	_				BK process control Enable		2	
	E	ним		The temperature and humidity inside the machine are monitored only during a job at	Color process control	0 - 2	0	0
				the interval set by the item of HUM HOUR.	Process control Disable		1	
				When the changes in the temperature and	BK process control Enable		2	
				the humidity are greater than the specified	Bit process control Enable		-	
				level (the set value of item HUM DIF) in				
				comparison with the previous process				
	F	REV/1	VES	When the accumulated traveling distance	Enable	0 - 1	0	0
			NO	of K or M OPC drum unit reaches the	Inhibit	0-1	1	
			110	specified level after turning ON the power.				
	G	REV2_BK	YES	When the accumulated traveling distance	Enable	0 - 1	0	0
			NO	of K OPC drum unit reaches the specified	Inhibit		1	
				level from execution of the previous				
			VES	density correction.	Enable	0 1	0	0
		KLVZ_OL	NO	of M OPC drum unit reaches the specified	Inhibit	0-1	1	0
			110	level from execution of the previous	in more			
				density correction.				
	I	REFRESH	YES	Select of YES/NO of the manual process	Key operation display	0 - 1	0	1
		MODE	NO	control key with key operation	Key operation NO display		1	
Setting of the	J	DAY		When there is no color job from when the	0: Disable of the specified	0 - 999	0	1
execution				previous color process control was	days judgment			
the process				by this item setting, perform the process	1 - 999: 1 - 999 days		999	
control				control when executing the next warming	passing			
				up.				
	К	HI-COV		Setting of the execution conditions of the	The process control is	0 - 2	0	0
				process control for the print ratio	performed by considering			
					the average print ratio of			
					every 10 pages as the			
					Print ratio judgment inhibit		1	
					(The process control for			
					the target of print ratio is			
					not performed.)			
					The process control is		2	
					performed by considering			
					the average print ratio of			
					criteria in a continuous			
					print job of 30 or more			
					pages.		1	

Mode		Item/Displa	ay	Content		Setting range	)	Default value
Setting of the execution conditions of	L	LO-COV		Setting of the execution judgment of the process control in continuous printing of low print ratio images	Enable Inhibit	0 - 1	0	0
the process control	М	TonerCA-EN	١D	Setting of the process control interval reduction when the toner cartridge remaining quantity is 25% or less (If this is set to Enable, item M RATIO is changed.)	Enable Inhibit	0 - 1	0	1
	N	AVERAGE-I	PAGE	Setting of the number of pages of item HI- COV set value 2	1: 10 pages - 5: 50 pages 1 step corresponds to 10 pages.	1 - 5	1 5	3
	0	LIMIT PAGE	-	Setting of the number of connected jobs of the process control and of the limit number of the process control A number of reservation jobs are connected. When the number of jobs exceeds the specified number of pages (the set value of this setting), the process control is performed. / The process control	1: 10 pages - 10: 100 pages 1 step corresponds to 10 pages.	1 -10	1	10
				REV conditions and the specified number of pages (the set value of this setting).				
	Р	PIX_RATIO	_BK	Magnification ratio setting (%) of the BK ton The set value of 100 corresponds to K print	er count specified value of A4 at the print ratio of 5%.	1 - 999		10
	Q	PIX_RATIO	_CL	Magnification ratio setting (%) of the color (0 value The set value of 100 corresponds to K print	CMY) toner count specified of A4 at the print ratio of 5%.	1 - 999		10
	R	INTERVAL	TIME	Setting of the leaving time when turning ON sleep recovery time) (h: hour)	the power (including the	1 - 255		3
	S	HUM HOUR	8	Interval setting of the temperature and humidity monitoring time of "HUM" (unit: 10 minutes)		1 - 24		2
	Т	HUM_DIF		The specified value of the area difference in humidity between the level at execution of the previous control and the current humidity (Applied to item HUM)		1 - 9		2
	U	BK_RATIO		Magnification ratio setting (%) of the specified value of the BK OPC drum traveling distance of "REV2_BK"		1 - 999 (Entry of 20 corresponds to 100,000mm.)		15
	V	M_RATIO		Magnification ratio setting (%) of the M OPC drum traveling distance of "REV2_CL"		1 - 999 (Entry of 20 corresponds to 100,000mm.)		15
	W	COLOR BORDER		Judgment criteria whether the BK high density process control is individually performed or not (Setting of the ratio of the M OPC drum rotation distance for the K OPC drum rotation distance (%))	0: The BK process control is executed regardless of the M OPC drum traveling distance. 1 - 999: 1 - 999(%)	0 - 999		20
	X	BK ONLY		Setting of the frequency of execution of the 4-color high density process control when only monochrome output is continued (The result of this setting is applied only when the M OPC drum rotation distance is smaller than the set value of COLOR BORDER.)	Frequency of once for 5 times Frequency of once for 1 - 5 times The 4-color high density process control is always performed.	0 - 6	0 1 - 5 6	5
Setting of the	Y Z	HT_DIF	CI	HT process control execution judgment dev	eloping bias variation value	1 - 255 When the color	0	40
execution condition of the		SYNC		process control when turning ON the power		process control is executed.		
adjustment			ALL			Executed regardless of the process control.	1	
			CL/BK			When the color process control and the K process control are executed.	2	
	AA	RG_TEMP_	TIMER	Time interval from registration adjustment a the next execution.	fter turning ON the power to	0 - 240 (MINUTE)		0
	AB	RG_PERM_	TIMER	Setting of inhibit time of execution of the registration adjustment		0 - 15		1
	AC	RG_HOUR_	TIMER	Setting of the interval time of execution of th	ne registration adjustment	0 - 15 (Above)+(HOU	R)	5
	AD	RG_BW_SY	ŃC	Setting of Enable/Disable of the registration adjustment after a monochrome job	Enable Inhibit	0 - 1	0	1

Mode		Item/Display	Content	Setting range	Default value
Setting of the secondary transfer	AE	2TRAN_CLEAN_ TIME1	Secondary transfer cleaning process time judgment threshold value 1 (The total number of sheets for cleaning execution conditions) (Cleaning time: Short)	5 - 999	200
cleaning conditions	AF	2TRAN_CLEAN_ TIME2	Secondary transfer cleaning process time judgment threshold value 2 (The total number of sheets for cleaning execution conditions) (Cleaning time: Medium)	5 - 999	300
	AG	2TRAN_CLEAN_ TIME3	Secondary transfer cleaning process time judgment threshold value 3 (The total number of sheets for cleaning execution conditions) (Cleaning time: Long)	5 - 999	500

When REFRESH MODE setting is enabled (0), the menu of the user process control execution button is displayed on the user system setting menu.

When the color balance or the density change is not within the allowable range, the user can perform the process control manually and forcibly. However, toner is consumed grater than as usual. This point must be explained to the user clearly.

44-29	
Purpose	Setting
Function (Purpose)	Used to set the operating conditions of the
	process control during a job.

Section Process

### **Operation/Procedure**

1) Select a target item of setting with scroll key on the touch panel.

- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

	Item/Display	Content	Setting range			Default value
Α	COPY	During copy job	0 - 2	0 - 2 0: No execution		2
В	PRINTER	During print job		1: HV only		2
С	FAX	During FAX print job	I	2: $HV \rightarrow HT$		2
D	SELF PRINT	During self print	Ĩ			2
Е	CPY TO PRT TABLE	Halftone process control copier -	0 - 1	0:CALCULA	0: Color balance calculation value (Revised every time	0
		printer conversion table select		1:DEFAULT	1: Default (Fixed value)	

HV: High density process control

HT: Halftone process control

44-31	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the OPC drum phase. (Man- ual adjustment)
Section	Process

**Operation/Procedure** 

### Important

For the OPC drum phase adjustment, do not use this simulation, but use SIM50-22 (auto adjustment).

- 1) Select item A with scroll key.
- 2) Enter the value corresponding to the adjustment pattern with 10-key.
- 3) Press [EXECUTE] key. (The adjustment pattern is printed out.)
- 4) Select an adjustment pattern whose deflection is within two scale lines on the adjustment pattern of C,M, Y colors.
- 5) Select item B with scroll key.
- 6) Enter the adjustment pattern sheet number selected in procedure 4).
- 7) Press [EXECUTE] key.
- 8) The adjusted adjustment pattern is printed.

# 44-37 Purpose

Adjustment/Setup

Function (Purpose) Used to set the development bias correction level in the continuous printing operation.

### Section **Operation/Procedure**

- 1) Select a set target color with the touch panel.
- 2) Select a target item with scroll keys.
- 3) Enter the set value with 10-key.
- 4) Press [OK] key. (The set value is saved.)



When the print density is varied in the continuous printing operation, this simulation is used.

Button	Item Display Content		Setting	Default	
	Δ		DV bias correction data 1 in color printing (low speed)	0-5	Value 0
	B		DV bias correction data 2 in color printing (low speed)	0-5	0
	C	DV ADJ CL K L DATA 3	DV bias correction data 3 in color printing (low speed)	0-5	0
	D	DV ADJ CL K M DATA 1	DV bias correction data 1 in color printing (middle speed)	0 - 5	0
	Е	DV ADJ CL K M DATA 2	DV bias correction data 2 in color printing (middle speed)	0 - 5	0
	F	DV_ADJ_CL_K_M_DATA_3	DV bias correction data 3 in color printing (middle speed)	0 - 5	0
	G	DV_ADJ_BK_H_DATA_1	DV bias correction data 1 in monochrome printing (high speed)	0 - 5	0
	Н	DV_ADJ_BK_H_DATA_2	DV bias correction data 2 in monochrome printing (high speed)	0 - 5	0
	I	DV_ADJ_BK_H_DATA_3	DV bias correction data 3 in monochrome printing (high speed)	0 - 5	0
	J	DV_ADJ_START_CL_K_L_1	DV bias correction starting position data 1 in color printing (low speed)	1 - 12	4
	к	DV_ADJ_START_CL_K_L_2	DV bias correction starting position data 2 in color printing (low speed)	1 - 12	3
	L	DV_ADJ_START_CL_K_L_3	DV bias correction starting position data 3 in color printing (low speed)	1 - 12	1
к	М	DV_ADJ_START_CL_K_L_4	DV bias correction starting position data 4 in color printing (low speed)	1 - 12	1
	Ν	DV_ADJ_START_CL_K_M_1	DV bias correction starting position data 1 in color printing (middle speed)	1 - 12	4
	0	DV_ADJ_START_CL_K_M_2	DV bias correction starting position data 2 in color printing (middle speed)	1 - 12	3
	Р	DV_ADJ_START_CL_K_M_3	DV bias correction starting position data 3 in color printing (middle speed)	1 - 12	1
	Q	DV_ADJ_START_CL_K_M_4	DV bias correction starting position data 4 in color printing (middle speed)	1 - 12	1
	R	DV_ADJ_START_BK_H_1	DV bias correction starting position data 1 in monochrome printing (high speed)	1 - 12	4
	S	DV_ADJ_START_BK_H_2	DV bias correction starting position data 2 in monochrome printing (high speed)	1 - 12	3
	т	DV_ADJ_START_BK_H_3	DV bias correction starting position data 3 in monochrome printing (high speed)	1 - 12	1
	U	DV_ADJ_START_BK_H_4	DV bias correction starting position data 4 in monochrome printing (high speed)	1 - 12	1
	A	DV_ADJ_CL_C_L_DATA_1	DV bias correction data 1 in color printing (low speed)	0 - 5	0
	В	DV_ADJ_CL_C_L_DATA_2	DV bias correction data 2 in color printing (low speed)	0 - 5	0
	С	DV_ADJ_CL_C_L_DATA_3	DV bias correction data 3 in color printing (low speed)	0 - 5	0
	D	DV_ADJ_CL_C_M_DATA_1	DV bias correction data 1 in color printing (middle speed)	0 - 5	0
	E	DV_ADJ_CL_C_M_DATA_2	DV bias correction data 2 in color printing (middle speed)	0 - 5	0
	F	DV_ADJ_CL_C_M_DATA_3	DV bias correction data 3 in color printing (middle speed)	0 - 5	0
	G	DV_ADJ_START_CL_C_L_1	DV bias correction starting position data 1 in color printing (low speed)	1 - 12	4
	н	DV_ADJ_START_CL_C_L_2	DV bias correction starting position data 2 in color printing (low speed)	1 - 12	3
С	I	DV_ADJ_START_CL_C_L_3	DV bias correction starting position data 3 in color printing (low speed)	1 - 12	1
	J	DV_ADJ_START_CL_C_L_4	DV bias correction starting position data 4 in color printing (low speed)	1 - 12	1
	к	DV_ADJ_START_CL_C_M_1	DV bias correction starting position data 1 in color printing (middle speed)	1 - 12	4
	L	DV_ADJ_START_CL_C_M_2	DV bias correction starting position data 2 in color printing (middle speed)	1 - 12	3
	М	DV_ADJ_START_CL_C_M_3	DV bias correction starting position data 3 in color printing (middle speed)	1 - 12	1
-	Ν	DV_ADJ_START_CL_C_M_4	DV bias correction starting position data 4 in color printing (middle speed)	1 - 12	1

Button	Item	Display	Content	Setting	Default
	Δ	DV ADI CL M I DATA 1	DV bias correction data 1 in color printing (low speed)	nange 0 - 5	value
	B		DV bias correction data 2 in color printing (low speed)	0-5	0
	C	DV ADJ CL M L DATA 3	DV bias correction data 2 in color printing (low speed)	0-5	0
			DV bias correction data 1 in color printing (now speed)	0-5	0
	F		DV bias correction data 2 in color printing (middle speed)	0-5	0
	F	DV_ADJ_CL_M_M_DATA_3	DV bias correction data 2 in color printing (middle speed)	0-5	0
			DV bias correction data 3 in color printing (middle speed)	0-3	0
	G	DV_ADJ_START_CL_M_L_1	speed)	1 - 12	4
	н	DV_ADJ_START_CL_M_L_2	DV bias correction starting position data 2 in color printing (low speed)	1 - 12	3
М	I	DV_ADJ_START_CL_M_L_3	DV bias correction starting position data 3 in color printing (low speed)	1 - 12	1
	J	DV_ADJ_START_CL_M_L_4	DV bias correction starting position data 4 in color printing (low speed)	1 - 12	1
	к	DV_ADJ_START_CL_M_M_1	DV bias correction starting position data 1 in color printing (middle speed)	1 - 12	4
	L	DV_ADJ_START_CL_M_M_2	DV bias correction starting position data 2 in color printing (middle speed)	1 - 12	3
	М	DV_ADJ_START_CL_M_M_3	DV bias correction starting position data 3 in color printing (middle speed)	1 - 12	1
	N	DV_ADJ_START_CL_M_M_4	DV bias correction starting position data 4 in color printing (middle speed)	1 - 12	1
	А	DV_ADJ_CL_Y_L_DATA_1	DV bias correction data 1 in color printing (low speed)	0 - 5	0
	В	DV_ADJ_CL_Y_L_DATA_2	DV bias correction data 2 in color printing (low speed)	0 - 5	0
	С	DV_ADJ_CL_Y_L_DATA_3	DV bias correction data 3 in color printing (low speed)	0 - 5	0
	D	DV_ADJ_CL_Y_M_DATA_1	DV bias correction data 1 in color printing (middle speed)	0 - 5	0
	E	DV_ADJ_CL_Y_M_DATA_2	DV bias correction data 2 in color printing (middle speed)	0 - 5	0
	F	DV_ADJ_CL_Y_M_DATA_3	DV bias correction data 3 in color printing (middle speed)	0 - 5	0
	G	DV_ADJ_START_CL_Y_L_1	DV bias correction starting position data 1 in color printing (low speed)	1 - 12	4
	н	DV_ADJ_START_CL_Y_L_2	DV bias correction starting position data 2 in color printing (low speed)	1 - 12	3
Y	Ι	DV_ADJ_START_CL_Y_L_3	DV bias correction starting position data 3 in color printing (low speed)	1 - 12	1
	J	DV_ADJ_START_CL_Y_L_4	DV bias correction starting position data 4 in color printing (low speed)	1 - 12	1
	К	DV_ADJ_START_CL_Y_M_1	DV bias correction starting position data 1 in color printing (middle speed)	1 - 12	4
	L	DV_ADJ_START_CL_Y_M_2	DV bias correction starting position data 2 in color printing (middle speed)	1 - 12	3
	М	DV_ADJ_START_CL_Y_M_3	DV bias correction starting position data 3 in color printing (middle speed)	1 - 12	1
	Ν	DV_ADJ_START_CL_Y_M_4	DV bias correction starting position data 4 in color printing (middle speed)	1 - 12	1

44-43	
Purpose	Data display
Function (Purpose)	Used to display the identification informa- tion of the developing unit.
Section	Developing system

The identification number and the identification signal level of the developing unit are displayed.

	Item/Display	Content	Display range	NOTE
Α	DVCH KIND K	K developing unit identification number	1 - 9	The model identification number of the developing unit which
В	DVCH KIND C	C developing unit identification number	1 - 9	is backed up in the EEPROM of the machine.
С	DVCH KIND M	M developing unit identification number	1 - 9	
D	DVCH KIND Y	Y developing unit identification number	1 - 9	
Е	DV_TYP_SEL_K	K developing unit identification detection	0 - 1	0 = High (Open)
F	DV_TYP_SEL_C	C developing unit identification detection	0 - 1	1 = Low (GND)
G	DV_TYP_SEL_M	M developing unit identification detection	0 - 1	
Н	DV_TYP_SEL_Y	Y developing unit identification detection	0 - 1	
I	DVCH_AD_K	K developing unit identification AD value	0 - 255	AD value of the developing unit identification voltage
J	DVCH_AD_C	C developing unit identification AD value	0 - 255	
K	DVCH_AD_M	M developing unit identification AD value	0 - 255	
L	DVCH_AD_Y	Y developing unit identification AD value	0 - 255	

 *  The developing unit is identified by the combination of items E, F, G, H and items I, J, K, and L.

44-62	
Purpose	Setup/Adjustment
Function (Purpose)	Used to set the process control execution conditions.
Section	Process

This simulation allows collective change in the set contents of SIM44-4 and SIM44-28.

A suitable one is selected among a number of options depending on the condition.

1) Select an item to be set.

To change the image density in the high density area, select PROCON TARGET.

To change the frequency of the process control operations, select PROCON MODE.

Di	splay/Item	Content			
PROCON TARGET	CL ID DOWN	The densities of C, M, and Y decrease. (The C/M/Y high density process control target values decrease.)			
	CL ID UP	The densities of C, M, and Y increase. (The C/M/Y high density process control target values increase.)			
	BK ID DOWN	The density of K decreases. (The high density process control target value decreases.)			
	BK ID UP	The density of K increases. (The high density process control target value increases.)			
	ALL ID DOWN	The densities of C, M, Y and K decrease. (The C/M/Y/K high density process control target values decrease.)			
	ALL ID UP	The densities of C, M, Y and K increase. (The C/M/Y/K high density process control target values increase.)			
	NORMAL	The standard density of C, M, Y and K. (The C/M/Y/K high density process control target values are the standard values.)			
PROCON MODE	HIGH QUALITY1	The execution frequency of the process control is high. (It is set when the color image quality is given priority.)			
	HIGH QUALITY2	The execution frequency of the process control is highest. (It is set when the color image quality is given priority.)			
	PRINT PERFORMANCE	The execution frequency of the process control is low. (It is set when the job speed is given priority.)			
	BW MODE	The process control is executed in the normal frequency. (It is set when there are little color jobs and many monochrome jobs.)			
	NORMAL	The process control is executed in the normal frequency.			

(When PROCON TARGET is selected.) 2A) Select the density level.

(When PROCON MODE is selected.)

2B) Select the execution frequency of the process control.

- 3) Press [EXECUTE] key.
- 4) Press [YES] key.

# Note

This simulation may not function with some firmware versions. In such a case, the firmware must be upgraded to the latest version.



46-1	
Purpose	Adjustment (Color copy mode)
Function (Purpose)	Used to adjust the copy density in the copy
	mode.
Section	

### **Operation/Procedure**

- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
  - * When the  $\triangle \bigtriangledown$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 3) Press [OK] key. (The set value is saved.)

To adjust the copy density in the low density area, select the "LOW" mode and change the adjustment value. To adjust the copy density in the high density area, select the "HIGH" mode and change the adjustment value.

When the adjustment value is increased, the copy density is increased. When the adjustment value is decreased, the copy density is decreased.

Item/Display		Contont		Setting	Default
	item/Display	Content		range	value
А	AUTO	Auto	LOW	1 - 99	50
			HIGH	1 - 99	50
В	TEXT	Text	LOW	1 - 99	50
			HIGH	1 - 99	50
С	TEXT/PRINTED	Text/Printed	LOW	1 - 99	50
	PHOTO	Photo	HIGH	1 - 99	50
D	TEXT/PHOTO	Text/Photograph	LOW	1 - 99	50
			HIGH	1 - 99	50
Е	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
			HIGH	1 - 99	50
F	PHOTOGRAPH	Photograph	LOW	1 - 99	50
			HIGH	1 - 99	50
G	MAP	Мар	LOW	1 - 99	50
			HIGH	1 - 99	50
Н	LIGHT	Light document	LOW	1 - 99	50
			HIGH	1 - 99	50
I	TEXT(COPY TO	Text (Copy	LOW	1 - 99	50
	COPY)	document)	HIGH	1 - 99	50
J	TEXT/PRINTED	Text/Printed	LOW	1 - 99	50
	PHOTO (COPY TO	Photo (Copy	HIGH	1 - 99	50
	COPY)	document)			
к	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
	(COPY TO COPY)	(Сору	HIGH	1 - 99	50
		document)			
L	TEXT (COLOR	Text (Color tone	LOW	1 - 99	50
	IONE ENHANCEMENT)	ennancement)	HIGH	1 - 99	50
М		Text/Printed	LOW	1 - 99	50
	PHOTO (COLOR	Photo	HIGH	1 - 99	50
	TONE	(Color tone	11011	1 55	50
	ENHANCEMENT)	enhancement)			
Ν	TEXT/PHOTO	Text/Photograph	LOW	1 - 99	50
	(COLOR TONE	(Color tone	HIGH	1 - 99	50
	ENHANCEMENT)	enhancement)			
0	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
	(COLOR TONE	(Color tone	HIGH	1 - 99	50
_	ENHANCEMENT)	enhancement)	1.014	4 00	50
Р		Photograph (Color topo	LOW	1 - 99	50
		enhancement)	HIGH	1 - 99	50
0		Man	1.0\%/	1 - 99	50
Q	TONE	(Color tone	HIGH	1 - 99	50
	ENHANCEMENT)	enhancement)	11011	1-33	50
R	LIGHT(COLOR	LIGHT	LOW	1 - 99	50
	TONE	DOCUMENT(Co	HIGH	1 - 99	50
	ENHANCEMENT)	lor tone			
1		enhancement)	1		

ltem/Display		Content		Setting range	Default value
S	SINGLE COLOR	Single color	LOW	1 - 99	50
			HIGH	1 - 99	50
Т	SINGLE COLOR	Single color	LOW	1 - 99	50
	(COPY TO COPY)	(Сору	HIGH	1 - 99	50
		document)			
U	TWO COLOR	2-color (red/	LOW	1 - 99	50
		black) copy	HIGH	1 - 99	50
V	TWO COLOR	2-color (red/	LOW	1 - 99	50
	(COPY TO COPY)	black) copy	HIGH	1 - 99	50
		(copy document)			

46-2	
Purpose	Adjustment (Monochrome copy mode)
Function (Purpose)	Used to adjust the copy density in the copy
	mode.

Section

- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
  - * When the riangle  $ilde{
    eq}$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 3) Press [OK] key. (The set value is saved.)

To adjust the copy density in the low density area, select the "LOW" mode and change the adjustment value. To adjust the copy density in the high density area, select the "HIGH" mode and change the adjustment value.

When the adjustment value is increased, the copy density is increased. When the adjustment value is decreased, the copy density is decreased.

	Item/Display	Content		Setting range	Default value
Α	AUTO1	Auto 1	LOW	1 - 99	50
			HIGH	1 - 99	50
В	AUTO2	Auto 2	LOW	1 - 99	50
			HIGH	1 - 99	50
С	TEXT	Text	LOW	1 - 99	50
			HIGH	1 - 99	50
D	TEXT/PRINTED	Text/Printed	LOW	1 - 99	50
	PHOTO	Photo	HIGH	1 - 99	50
Е	TEXT/PHOTO	Text/	LOW	1 - 99	50
		Photograph	HIGH	1 - 99	50
F	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
			HIGH	1 - 99	50
G	PHOTOGRAPH	Photograph	LOW	1 - 99	50
			HIGH	1 - 99	50
н	MAP	Мар	LOW	1 - 99	50
			HIGH	1 - 99	50
Т	TEXT (COPY TO	Text (Copy	LOW	1 - 99	50
	COPY)	document)	HIGH	1 - 99	50
J	TEXT/PRINTED	Text/Printed	LOW	1 - 99	50
	PHOTO (COPY TO	Photo (Copy	HIGH	1 - 99	50
-	COPY)	document)			
к	PRINTED PHOTO	Printed Photo	LOW	1 - 99	50
	(COPY TO COPY)	(Сору	HIGH	1 - 99	50
L	LIQUE	document)	1.014	1 00	50
	LIGHT	Light document	LOW	1 - 99	50
			HIGH	1 - 99	50

46-4	
Purpose	Adjustment (Color scanner mode)
Function (Purpose) Used to adjust the density in the send mode.	
Section	

- **Operation/Procedure**
- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
  - * When the riangle key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 3) Press [OK] key. (The set value is saved.)

When the adjustment value is increased, the image density is increased, and vice versa.

Modo Itom/Display		Itom/Display	Contont	Setting	Default
wode		item/Display	Content	range	value
LOW	А	AUTO	Auto	1 - 99	50
	В	TEXT	Text	1 - 99	50
	С	TEXT/PRINTED	Text/Printed Photo	1 - 99	50
		PHOTO			
	D	TEXT/PHOTO	Text/Photograph	1 - 99	50
	Е	PRINTED PHOTO	Printed Photo	1 - 99	50
	F	PHOTOGRAPH	Photograph	1 - 99	50
	G	MAP	Мар	1 - 99	50
	н	RIP	-	1 - 99	50
HIGH	Α	AUTO	Auto	1 - 99	50
	В	TEXT	Text	1 - 99	50
	С	TEXT/PRINTED	Text/Printed Photo	1 - 99	50
		PHOTO			
	D	TEXT/PHOTO	Text/Photograph	1 - 99	50
	Е	PRINTED PHOTO	Printed Photo	1 - 99	50
	F	PHOTOGRAPH	Photograph	1 - 99	50
	G	MAP	Мар	1 - 99	50
	Н	RIP	-	1 - 99	50

46-5	
Purpose	Adjustment (Monochrome scanner mode)
Function (Purpose)	Used to adjust the density in the image
	send mode.

# Section

# **Operation/Procedure**

- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
  - * When the  $\triangle \bigtriangledown$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 3) Press [OK] key. (The set value is saved.)

When the adjustment value is increased, the image density is increased, and vice versa.

Mode	Item/Display		Content	Setting range	Default value
LOW	А	AUTO	Auto	1 - 99	50
	В	TEXT	Text	1 - 99	50
	С	TEXT/PRINTED PHOTO	Text/Printed Photo	1 - 99	50
	D	TEXT/PHOTO	Text/Photograph	1 - 99	50
	Е	PRINTED PHOTO	Printed Photo	1 - 99	50
	F	PHOTOGRAPH	Photograph	1 - 99	50
	G	MAP	Мар	1 - 99	50
	Н	RIP	_	1 - 99	50

Mode	Item/Display		Content	Setting range	Default value
HIGH	Α	AUTO	Auto	1 - 99	50
	В	TEXT	Text	1 - 99	50
	С	TEXT/PRINTED PHOTO	Text/Printed Photo	1 - 99	50
	D	TEXT/PHOTO	Text/Photograph	1 - 99	50
	Е	PRINTED PHOTO	Printed Photo	1 - 99	50
	F	PHOTOGRAPH	Photograph	1 - 99	50
	G	MAP	Мар	1 - 99	50
	Н	RIP	-	1 - 99	50

46-8		
Purpose	Adjustment (Color scanner mode)	
Function (Purpose)	Used to adjust the image send mode color	
	halance RGB	

# Section

### **Operation/Procedure**

- 1) Select an adjustment target with [R] [G] [B] keys on the touch panel.
- 2) Select an adjustment target item with scroll key on the touch panel.
- 3) Enter the set value with 10-key.
- 4) Press [OK] key. (The set value is saved.)

The color balance can be adjusted separately for the low density area and the high density area.

When the adjustment value is increased, the image density of the target color is increased, and vice versa.

Item/Display		Content	Default value
А	LOW DENSITY POINT	Low density correction amount	50
В	HIGH DENSITY POINT	High density correction amount	50

46-9		
Purpose	Adjustment (RSPF mode)	
Function (Purpose)	Used to adjust the scan image density.	
Section		

#### **Operation/Procedure**

- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
  - * When the  $\triangle \bigtriangledown$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 3) Press [OK] key. (The set value is saved.)

This adjustment result affects the image send mode, the copy mode, and the fax mode.

When the adjustment value is increased, the image density is increased, and vice versa.

#### [RSPF]

	Item/Display	Content	Setting range	Default value
A	COPY : LOW	RSPF copy mode exposure adjustment (Low density side)	1 - 99	48
В	SCAN : LOW	RSPF scanner mode exposure adjustment (Low density side)	1 - 99	48
С	FAX : LOW	RSPF FAX mode exposure adjustment (Low density side)	1 - 99	48
D	COPY : HIGH	RSPF copy mode exposure adjustment (High density side)	1 - 99	53
E	SCAN : HIGH	RSPF scanner mode exposure adjustment (Low density side)	1 - 99	53
F	FAX : HIGH	RSPF FAX mode exposure adjustment (high density)	1 - 99	53

46-10		
Purpose	Adjustment	
Function (Purpose)	Used to adjust the copy color balance and	
	the gamma (for each color copy mode).	

# Section

### **Operation/Procedure**

- 1) Select an adjustment target mode with the touch panel key.
- Select an adjustment target color with [K][C][M][Y] keys on the touch panel.
- 3) Select an adjustment target item with scroll key on the touch panel.
- 4) Enter the set value with 10-key.
  - * When the  $\triangle \ \nabla$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 5) Press [OK] key. (The set value is saved.)

When the adjustment value is increased, the image density is increased, and vice versa.

TEXT	Text
TEXT/PRT PHOTO	Text/Printed Photo
PRINTED PHOTO	Printed Photo
PHOTO + TEXT/PHOTO	Photograph + Text/Printed Photo
MAP	Мар
LIGHT	Light document
COPY ORG	Copy document

Item/Display		Density level (Point)	Setting range	Default value
А	POINT1	Point 1	1 - 999	500
В	POINT2	Point 2	1 - 999	500
С	POINT3	Point 3	1 - 999	500
D	POINT4	Point 4	1 - 999	500
Е	POINT5	Point 5	1 - 999	500
F	POINT6	Point 6	1 - 999	500
G	POINT7	Point 7	1 - 999	500
Н	POINT8	Point 8	1 - 999	500
I	POINT9	Point 9	1 - 999	500
J	POINT10	Point 10	1 - 999	500
Κ	POINT11	Point 11	1 - 999	500
L	POINT12	Point 12	1 - 999	500
Μ	POINT13	Point 13	1 - 999	500
Ν	POINT14	Point 14	1 - 999	500
0	POINT15	Point 15	1 - 999	500
Р	POINT16	Point 16	1 - 999	500
Q	POINT17	Point 17	1 - 999	500

46-16	
Purpose	Adjustment
Function (Purpose)	Used to adjust the monochrome copy den- sity and the gamma (for each monochrome copy mode).

# Section

### **Operation/Procedure**

- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
  - * When the riangle  $\forall$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 3) Press [OK] key. (The set value is saved.)

When the adjustment value is increased, the image density is increased, and vice versa.

Item/Display		Density level (Point)	Setting range	Default value
Α	POINT1	Point 1	1 - 999	500
В	POINT2	Point 2	1 - 999	500
С	POINT3	Point 3	1 - 999	500
D	POINT4	Point 4	1 - 999	500
Е	POINT5	Point 5	1 - 999	500
F	POINT6	Point 6	1 - 999	500
G	POINT7	Point 7	1 - 999	500
н	POINT8	Point 8	1 - 999	500
1	POINT9	Point 9	1 - 999	500
J	POINT10	Point 10	1 - 999	500
К	POINT11	Point 11	1 - 999	500
L	POINT12	Point 12	1 - 999	500
Μ	POINT13	Point 13	1 - 999	500
Ν	POINT14	Point 14	1 - 999	500
0	POINT15	Point 15	1 - 999	500
Ρ	POINT16	Point 16	1 - 999	500
Q	POINT17	Point 17	1 - 999	500

46-19

Purpose Setting

**Function (Purpose)** Used to set the operating conditions for the density scanning (exposure) of monochrome auto copy mode documents.

### Section

**Operation/Procedure** 

Select an item to be set with touch panel.

When an item is selected, it is highlighted and the setting change is saved.

Item/Display	Content	Set value	Default value
AE_MODE	Auto exposure mode	MODE1, MODE2	MODE1
AE_STOP_COPY	Auto B/W exposure Stop (for copy)	REALTIME/ STOP/	STOP
		PRESCAN	
AE_STOP_FAX	Auto B/W exposure Stop (for FAX)	ON/OFF	ON
AE_STOP_SCAN	Auto B/W exposure Stop (for scanner)	REALTIME/ STOP/ PRESCAN	STOP
AE_FILTER	Auto exposure filter	SOFT	NORMAL
	setting	NORMAL	
		SHARP	
AE_WIDTH	AE exposure width	FULL/PART	FULL

# Note

MODE 1	High gamma (high contrast images)
MODE 2	Normal gamma
STOP	The image density in 3 - 7mm area at the lead edge is scanned, and the output image density is determined according to the scanned density. (The output image density is even for all the surface.)
REALTIME	The densities of the document width are scanned sequentially, and the output image density is determined according to the density in each area of document. (The output image density may not be even for all the surface.)
PRESCAN	The densities of the all surface of document are scanned sequentially, and the output image density is determined according to the average of the scanned densities. (The output image density is even for all the surface.)
AE WIDTH FULL	The document density scan area in the monochrome auto mode is 3 - 7mm at the document lead edge x the document width. This is not related to the PRESCAN mode.
AE WIDTH PART	The document density scan area in the monochrome auto mode is 3 - 7mm at the document lead edge x 100mm width. This is not related to the PRESCAN mode.

46-21	
Purpose	Adjustment
Function (Purpose)	Copy color balance adjustment (Manual
	adjustment)

# Section

### **Operation/Procedure**

- 1) Select an adjustment target color with [K][C][M][Y] keys on the touch panel.
- 2) Select an adjustment target item with scroll key on the touch panel.
- 3) Enter the set value with 10-key.
  - * When the  $\triangle \ \nabla$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 4) Press [OK] key. (The set value is saved.)

When the adjustment value is increased, the image density is increased, and vice versa.

When [EXECUTE] key is pressed, the check pattern in printed in the color balance and density corresponding to the adjustment value.

ltem/Display		Density level (Point)	Setting range	Default value
Α	POINT1	Point 1	1 - 999	500
В	POINT2	Point 2	1 - 999	500
С	POINT3	Point 3	1 - 999	500
D	POINT4	Point 4	1 - 999	500
Е	POINT5	Point 5	1 - 999	500
F	POINT6	Point 6	1 - 999	500
G	POINT7	Point 7	1 - 999	500
Н	POINT8	Point 8	1 - 999	500
I	POINT9	Point 9	1 - 999	500
J	POINT10	Point 10	1 - 999	500
К	POINT11	Point 11	1 - 999	500
L	POINT12	Point 12	1 - 999	500
Μ	POINT13	Point 13	1 - 999	500
Ν	POINT14	Point 14	1 - 999	500
0	POINT15	Point 15	1 - 999	500
Р	POINT16	Point 16	1 - 999	500
Q	POINT17	Point 17	1 - 999	500

46-23	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the density correction of copy high density section (High density tone gap supported).
Section	

# Operation/Procedure

1) Enter the set value with 10-key.

0	Frahla
0	Enable
1	Inhibit

2) Press [OK] key. (The set value is saved.)

	Item/Display		Content	Setting range	Default value
A	CMY (0: ENABLE 1: DISABLE)	0	CMY engine highest density correction mode: Enable	0 - 1	0
		1	CMY engine highest density correction mode: Disable		
В	K (0: ENABLE 1: DISABLE)	0	K engine highest density correction mode: Enable	0 - 1	1
		1	K engine highest density correction mode: Disable		

Item/Display		Content	Setting range	Default value
С	CYAN MAX TARGET	Scanner target value for CYAN maximum density correction	0 - 999	500
D	MAGENTA MAX TARGET	Scanner target value for MAGENTA maximum density correction	0 - 999	500
E	YELLOW MAX TARGET	Scanner target value for YELLOW maximum density correction	0 - 999	500
F	BLACK MAX TARGET	Scanner target value for BLACK maximum density correction	0 - 999	500

* When tone gap is generated in the high density area, set items A and B to "0".

The density of high density part decreases. However, the tone gap is better.

* To increase the density in the high density area further, set items A and B to "1".

The tone gap may occur in high density part.

### Important

Do not change the values of items C, D, E, and F. If these values are changed, the density in the high density area is changed.

46-24	
Purpose	Adjustment
Function (Purpose)	Copy color balance adjustment (Auto adjustment)

# Section

**Operation/Procedure** 

- 1) Press [EXECUTE] key.
  - The color patch image (adjustment pattern) is printed out.
- 2) Plate the printed adjustment pattern on the document table, select [FACTORY] or [SERVICE] mode.
- 3) Press [EXECUTE] key.

The copy color balance automatic adjustment is performed, then the adjustment result pattern is printed.

# 4) Press [OK] key.

The halftone correction target registration is processed.

46-25	
Purpose	Adjustment
Function (Purpose)	Used to adjust the copy color balance. (Sin-
	gle color copy mode)

### Section

#### **Operation/Procedure**

- 1) Select an adjustment target color with [C][M][Y] keys on the touch panel.
- 2) Select an adjustment target item with scroll key on the touch panel.
- 3) Enter the set value with 10-key.
- 4) Press [OK] key. (The set value is saved.)

When the adjustment value is increased, the image density of the target color is increased, and vice versa.

_						
Kem/Dianlay		Cotting rounds	Default value			
	item/Display	Setting range	С	М	Y	
Α	RED	0 - 255	0	255	200	
В	GREEN	0 - 255	255	0	255	
С	BLUE	0 - 255	255	150	0	
D	CYAN	0 - 255	255	0	0	
Е	MAGENTA	0 - 255	0	255	0	
F	YELLOW	0 - 255	0	0	255	
G	ORANGE	0 - 255	0	150	255	

	Hom/Dianley	ionlay Satting range		Default value			
	item/Display	Setting range	С	М	Y		
Н	NAVY	0 - 255	255	200	0		
- 1	LIGHT GREEN	0 - 255	150	0	150		
J	LIGHT BLUE	0 - 255	150	20	0		
К	AQUA MARINE	0 - 255	170	0	50		
L	PURPLE	0 - 255	128	255	0		
М	PINK	0 - 255	0	150	20		
Ν	YELLOW GREEN	0 - 255	128	0	255		
0	BEIGE	0 - 255	0	50	170		

# 46-26

Purpose Adjustment

**Function (Purpose)** Used to reset the single color mode color balance set value to the default.

# Section

### **Operation/Procedure**

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

The color balance value of the single color mode is reset to the default value.

46-27	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the gamma/density of copy
	images, texts, and line image edges.

### Section Operation/Procedure

- Select a target item of setting with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key. (The set value is saved.)

	Item/Display (Copy mode)	Content	Setting range	Default value
A	BLACK TEXT (SLOPE)	Black character edge gamma skew adjustment	1 - 99	50
В	BLACK TEXT (INTERCEPT)	Black character edge density adjustment	1 - 99	50
С	COLOR TEXT (SLOPE)	Color character edge gamma skew adjustment	1 - 99	50
D	COLOR TEXT (INTERCEPT)	Color character edge density adjustment	1 - 99	50
Е	ED TEXT (SLOPE)	Text/Map mode gamma adjustment (Text/Map mode)	1 - 99	50
F	ED TEXT (INTERCEPT)	Text/Map mode density adjustment (Text/Map mode)	1 - 99	50

When the adjustment values of items A, C, and E are changed, the gamma of text and line edge image density section is changed.

When the adjustment value is increased, the image contrast of character edge and line edge is increased. When the adjustment value is decreased, the image contrast of character and line edge is decreased.

When the adjustment values of items B, D, and F are increased, the image density of text and line edge section is decreased, and vice versa.

46-30	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the resolution in the sub scanning direction in the copy mode.
	scanning direction in the copy mode.

# Section

### **Operation/Procedure**

- 1) Refer to the following table, and enter the set value corresponding to the resolution mode with 10-key.
- 2) Press [OK] key. (The set value is saved.)

Item/Display		Content		Setting range		Default value
Α	SCAN	Scan resolution	Mode1	0 - 1	0	0
	RESOLUTION	selection	Mode2		1	
	SW	(COPY: COLOR)				

		Resolution in the sub scanning direction (DPI)				
Mode	Scan mode	25-99% [Magnification ratio]	100-200% [Magnification ratio]	201-400% [Magnification ratio]		
Mode1	OC	600	600	600		
	RSPF	600	600	-		
Mode2 OC		400	600	600		
	RSPF	400	600	-		

# 46-32 Purpose Adjustment/Setup

Function (Purpose) Used

**pose)** Used to adjust the document background density reproducibility in the monochrome auto copy mode.

# Section

### **Operation/Procedure**

- 1) Select a target item of setting with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key. (The set value is saved.)

When the adjustment value is increased, reproducibility of the background and the low density image is increased. When the adjustment value is decreased, reproducibility of the background and the low density image is decreased.

lt	tem / Display Content		Setting	Default
			range	value
А	COPY:OC	Copy mode (for OC)	1 - 250	196
В	COPY:RSPF	Copy mode (for RSPF)	1 - 250	196
С	SCAN:OC	Scanner mode (for OC)	1 - 250	196
D	SCAN:RSPF	Scanner mode (for RSPF)	1 - 250	196
Е	FAX:OC	FAX mode (for OC)	1 - 250	196
F	FAX:RSPF	FAX mode (for RSPF)	1 - 250	196

#### 46-36

Purpose Adjustment/Setup

**Function (Purpose)** Used to adjust the colors in the 2-color copy mode.

# Section

### **Operation/Procedure**

1) Select a target adjustment item with scroll key on the touch panel.

2) Enter the set value with 10-key.

3) Press [OK] key. (The set value is saved.)

By changing the density level of each color, the color adjustment in the 2-color copy mode can be performed.

Item/Display			Comtont	Setting	Default value		Default	
		ау	Coment	range	С	М	Y	value
OUTCOLOR	Α	RED	R output color	0 - 255	0	255	200	-
(Output color coefficient)	В	GREEN	G output color	0 - 255	255	0	255	-
	С	BLUE	B output color	0 - 255	255	150	0	-
	D	CYAN	C output color	0 - 255	255	0	0	-
	Е	MAGENTA	M output color	0 - 255	0	255	0	-
	F	YELLOW	Y output color	0 - 255	0	0	255	-
	G	ORANGE	O output color	0 - 255	0	150	255	-
	н	NAVY	N output color	0 - 255	255	200	0	-
	Ι	LIGHT GREEN	LG output color	0 - 255	150	0	150	-
	J	LIGHT BLUE	LB output color	0 - 255	150	20	0	-
	К	AQUA MARINE	AM output color	0 - 255	170	0	50	-
	L	PURPLE	PU output color	0 - 255	128	255	0	-
	М	PINK	P output color	0 - 255	0	150	20	-
	Ν	YELLOW GREEN	YG output color	0 - 255	128	0	255	-
	0	BEIGE	BE output color	0 - 255	0	50	170	-
CHROMA	Α	RED / BLACK	Red extraction mode	0 - 6	-	-	-	3
(Chroma adjustment)			(The red recognition area is adjusted.)					
	В	KS:CHROMATIC	Chromatic color extraction mode	0 - 6	-	-	-	3
			(The chromatic color recognition area is adjusted.)					

46-37	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the reproduction capability of monochrome mode color.
Section	

- 1) Select a target item with scroll keys on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [EXECUTE] key.
- 4) Press [YES] key.

This is to adjust the reproduction capability of red and yellow images when copying color documents with red and yellow images in the monochrome mode.

Applied to the copy mode only.

Item/Display		Content	Setting range	Default value
Α	R-Ratio	Gray making setting (R)	0 - 1000	63
В	G-Ratio	Gray making setting (G)	0 - 1000	877
С	R-Ratio RIP	Print gray making setting (R)	0 - 1000	299
D	G-Ratio RIP	Print gray making setting (G)	0 - 1000	587

B-Ratio	Gray making setting (B) (1000-R-Ratio - G-Ratio)
B-Ratio RIP	Print gray making setting (B) (1000-R-Ratio RIP - G-Ratio RIP)

* B-Ratio: The value of gray making setting (B) is obtained from the formula below.

1000-R-Ratio - G-Ratio

When [DEFAULT] key is pressed, the values are set to the initial values (Default).

When the adjustment value of the adjustment item A is increased, the copy density of red images is decreased. When the adjustment value is decreased, the density is increased.

When the adjustment value of the adjustment item B is increased, the copy density of yellow images is increased. When the adjustment value is decreased, the density in also decreased.

46-38						
Purpose	Adjust	mer	nt/Setup			
Function (Purpose)	Used amour	to nt in	adjust the colo	the r cop	black y mode.	component
Section						

# Operation/Procedure

1) Select the AUTO MODE or the MANUAL MODE with the mode key.

- 2) Select the mode to be adjusted with the scroll key.
- 3) Press the black component amount select key.

This adjusts black ingredient amount in the color copy mode. (except character and line image)

As a result of this adjustment, the gradation of the shade part changes.

ltem	/Display	Select	Content	Default
(Сор	y mode)	button	Content	value
MANUAL	TEXT PRT	(-) LUT2	Text print	NORMAL
		(-) LUT1	(Manual)	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	TEXT	(-) LUT2	Text (Manual)	NORMAL
		(-) LUT1		
		NOMAL		
		(+) LUT1	-	
		(+) LUT2		
	PRINTED	(-) LUT2	Printed photo	NORMAL
	РНОТО	(-) LUT1	(Manual)	
		NOMAL	-	
		(+) LUT1	-	
		(+) LUT2		
	PHOTO	(-) LUT2	Photograph/Text	NORMAL
		(-) LUT1	photograph	
		NOMAL	(Manual)	
		(+) LUT1	-	
		(+) LUT2		
	TEXT	(-) LUT2	Text/Photograph	NORMAL
	РНОТО	(-) LUT1	(Manual)	
		NOMAL	_	
		(+) LUT1	_	
		(+) LUT2		
	MAP	(-) LUT2	Map (Manual)	NORMAL
		(-) LUT1	-	
		NOMAL	-	
		(+) LUT1	-	
	00.000/	(+) LUT2	0 1 1/	NODAAL
	CP ORG/	(-) LUT2	Copy document/	NORMAL
	TEATPRI	(-) LUT1	(Manual)	
		NOMAL	(Manual)	
		(+) LUT1	-	
		(+) LUT2	O and the sum and (	NODMAL
MANUAL	TEYT	(-) LUT2	Text (Manual)	NORMAL
			Text (Manual)	
		(+) LUT2		
		(+) LUT2	Copy dooumont/	
	PHOTO		Printed photo	NORMAL
			(Manual)	
			-	
			1	
	LIGHT	(+) LU12 (-) LUT2	Light document	NORMAL
	ORIGINAL	(-) [ ] [ ] [ ]	(Manual)	NORWAL
	5		(	
			1	
		(+) []]T2	1	

Item/Display		Select	Content	Default
		Dutton	A set a set a sta	Value
AUTO	A0100	(-) LUT2	iudamont 0	NORMAL
		(-) LUT1	Judgment	
			-	
		(+) LUT1	-	
		(+) LUT2	A set a set a sta	NODMAL
	AUTOT	(-) LUT2	Auto mode	NORMAL
			Judgment	
			-	
		(+) LUT1	-	
		(+) LUT2	Auto modo	
	A0102	(-) LUT2	iudament 2	NORWAL
			Judgment 2	
		(+) LUT2	Auto mode	NORMAI
	//0100	(-) LUT1	judament 3	
			, <u>.</u>	
		(+)      T1	-	
		(+) LUT2	-	
	AUTO4	(-)   UT2	Auto mode	NORMAI
		(-)   UT1	judgment 4	
		NOMAL	, ,	
		(+) LUT1		
		(+) LUT2		
	AUTO5	(-) LUT2	Auto mode	NORMAL
		(-) LUT1	judgment 5	
		NOMAL		
		(+) LUT1		
		(+) LUT2		
	AUTO6	(-) LUT2	Auto mode	NORMAL
		(-) LUT1	judgment 6	
		NOMAL		
		(+) LUT1		
		(+) LUT2		

46-39				
Purpose	Adjustment/Setup			
Function (Purpose)	Used to adjust the sharpness of FAX send			
	images.			

Section

### **Operation/Procedure**

- 1) Select a target item with scroll keys on the touch panel.
- 2) Enter the set value with 10-key.
  - 3) Press [OK] key. (The set value is saved.)

Input small numeric value to obtain crispy image. Input large numeric value to decrease moire.

	Item/Display	Content	Setting range	Default value
A	200 x 100 [DPI] OFF	200 x 100 [DPI] halftone OFF	0 - 2	1
В	200 x 200 [DPI] OFF	200 x 200 [DPI] halftone OFF	0 - 2	1
С	200 x 200 [DPI] ON	200 x 200 [DPI] halftone ON	0 - 2	1
D	200 x 400 [DPI] OFF	200 x 400 [DPI] halftone OFF	0 - 2	1
E	200 x 400 [DPI] ON	200 x 400 [DPI] halftone ON	0 - 2	1
F	400 x 400 [DPI] OFF	400 x 400[DPI] halftone OFF	0 - 2	1
G	400 x 400 [DPI] ON	400 x 400[DPI] halftone ON	0 - 2	1
Н	600 x 600 [DPI] OFF	600 x 600[DPI] halftone OFF	0 - 2	1
I	600 x 600 [DPI] ON	600 x 600[DPI] halftone ON	0 - 2	1

46-40	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the FAX send image density.
	(Collective adjustment of all the modes)

# Section

# **Operation/Procedure**

- 1) Set the document on the document table.
- 2) Enter the set value with 10-key.
- Press [EXECUTE] key, or [OK] key When [EXECUTE] key is pressed, the adjustment value is set and the scanned document image is outputted.

Item/Display		Content	Setting range	Default value
А	EXPOSURE	Used to adjust the FAX send	1 - 99	50
	LEVEL(ALL)	image density. (Collective		
		adjustment of all the modes)		

46-41	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the FAX send image density. (Normal)
Section	

- **Operation/Procedure**
- 1) Set the document on the document table.
- 2) Enter the set value with 10-key.
- 3) Press [EXECUTE] key, or [OK] key

When [EXECUTE] key is pressed, the adjustment value is set and the scanned document image is outputted.

Item/Display		Content		Setting range		Default value	
А	A AUTO		Auto		1 - 99		50
В	EXPOSURE	1	Exposure 1		1 - 9	9	50
С	EXPOSURE	2	Exposu	ure 2	1 - 9	9	50
D	D EXPOSURE3		Exposure 3		1 - 9	9	50
Е	EXPOSURE4		Exposure 4		1 - 99		50
F	EXPOSURE	5	Exposu	ure 5	1 - 9	9	50
G	EXECUTE	AUTO	Print	Auto	1 - 6	1	1
	MODE	EXP1	mode	Exposure 1		2	(AUTO)
		EXP2		Exposure 2		3	
		EXP3		Exposure 3		4	
		EXP4		Exposure 4		5	
		EXP5		Exposure 5		6	

To check the adjustment density level of items A - F, set the document and set the setting value of item G according to items A - F, and press [EXECUTE] key.

46-42	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the FAX send image density. (Fine)

### Section

Operation/Procedure

- 1) Set the document on the document table.
- 2) Enter the set value with 10-key.
- 3) Press [EXECUTE] key, or [OK] key

When [EXECUTE] key is pressed, the adjustment value is set and the scanned document image is outputted.

	Item/Display	Content	Setting range	Default value
Α	AUTO	Fine/Automatic	1 - 99	50
В	EXPOSURE1	Fine/Exposure 1	1 - 99	50
С	EXPOSURE2	Fine/Exposure 2	1 - 99	50
D	EXPOSURE3	Fine/Exposure 3	1 - 99	50
Е	EXPOSURE4	Fine/Exposure 4	1 - 99	50
F	EXPOSURE5	Fine/Exposure 5	1 - 99	50
G	AUTO H_TONE	Fine/Automatic/ Halftone	1 - 99	50
н	EXPOSURE1 H_TONE	Fine/Exposure 1/ Halftone	1 - 99	50
I	EXPOSURE2 H_TONE	Fine/Exposure 2/ Halftone	1 - 99	50
J	EXPOSURE3 H_TONE	Fine/Exposure 3/ Halftone	1 - 99	50
К	EXPOSURE4 H_TONE	Fine/Exposure 4/ Halftone	1 - 99	50
L	EXPOSURE5 H_TONE	Fine/Exposure 5/ Halftone	1 - 99	50

Item/Display		Content		Setting range		Default value	
М	EXECUTE	AUTO	Print	Fine/Auto	1 -	1	1
	MODE	EXP1	mode	Fine/	12	2	(AUTO)
				Exposure 1			
		EXP2		Fine/		3	
				Exposure 2			
		EXP3		Fine/		4	
				Exposure 3			
		EXP4		Fine/		5	
				Exposure 4			
		EXP5		Fine/		6	
				Exposure 5			
		AUTO		Fine/		7	
		H_TONE		Automatic/			
				halftone			
		EXP1		Fine/		8	
		H_TONE		Exposure 1/			
				Halftone			
		EXP2		Fine/		9	
		H_TONE		Exposure 2/			
				Halftone			
		EXP3		Fine/		10	
		H_TONE		Exposure 3/			
				Halftone			
		EXP4		Fine/		11	
		H_ONE		Exposure 4/			
		EVDE				40	
				Fine/		12	
		H_TONE		Exposure 5/			
				Haittone			

To check the adjustment density level of items A - L, set the document and set the setting value of item M according to items A - L, and press [EXECUTE] key.

46-43	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the FAX send image density.
	(Super Fine)

# Section

- Operation/Procedure
- 1) Set the document on the document table.
- 2) Enter the set value with 10-key.
- 3) Press [EXECUTE] key, or [OK] key

When [EXECUTE] key is pressed, the adjustment value is set and the scanned document image is outputted.

	Item/Display	Content	Setting range	Default value
Α	AUTO	Super Fine/Auto	1 - 99	50
В	EXPOSURE1	Super Fine/ Exposure 1	1 - 99	50
С	EXPOSURE2	Super Fine/ Exposure 2	1 - 99	50
D	EXPOSURE3	Super Fine/ Exposure 3	1 - 99	50
Е	EXPOSURE4	Super Fine/ Exposure 4	1 - 99	50
F	EXPOSURE5	Super Fine/ Exposure 5	1 - 99	50
G	AUTO H_TONE	Super Fine/ Auto/Halftone	1 - 99	50
Н	EXPOSURE1 H_TONE	Super Fine/ Exposure 1/Halftone	1 - 99	50
I	EXPOSURE2 H_TONE	Super Fine/ Exposure 2/Halftone	1 - 99	50
J	EXPOSURE3 H_TONE	Super Fine/ Exposure 3/Halftone	1 - 99	50
к	EXPOSURE4 H_TONE	Super Fine/ Exposure 4/Halftone	1 - 99	50

ltem/Display		Content		Setting range		Default value	
L	L EXPOSURE5 H_TONE		Super F	Super Fine/		99	50
			Exposu	re 5/Halftone			
М	EXECUTE	AUTO	Print	Super Fine/	1-	1	1
	MODE		mode	Auto	12		(AUTO)
		EXP1		Super Fine/		2	
				Exposure 1			
		EXP2		Super Fine/		3	
				Exposure 2			
		EXP3		Super Fine/		4	
				Exposure 3			
		EXP4		Super Fine/		5	
				Exposure 4			
		EXP5		Super Fine/		6	
				Exposure 5			
		AUTO		Super Fine/		7	
		H_TONE		Auto/			
				Halftone			
		EXP1		Super Fine/		8	
		H_TONE		Exposure 1/			
				Halftone			
		EXP2		Super Fine/		9	
		H_TONE		Exposure 2/			
				Halftone			
		EXP3		Super Fine/		10	
		H_TONE		Exposure 3/			
		5/5/		Halftone			
		EXP4		Super Fine/		11	
		H_TONE		Exposure 4/			
		EVDE		Haintone		40	
		EXP5		Super Fine/		12	
		H_TONE		Exposure 5/			

To check the adjustment density level of items A - L, set the document and set the setting value of item M according to items A - L, and press [EXECUTE] key.

46-44	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the FAX send image density.
	(Ultra fine)

### Section Operation/Procedure

1) Set the document on the document table.

2) Enter the set value with 10-key.

3) Press [EXECUTE] key, or [OK] key

When [EXECUTE] key is pressed, the adjustment value is set and the scanned document image is outputted.

	Item/Display	Content	Setting range	Default value
Α	AUTO	Ultra Fine/Auto	1 - 99	50
В	EXPOSURE1	Ultra Fine/Exposure 1	1 - 99	50
С	EXPOSURE2	Ultra Fine/Exposure 2	1 - 99	50
D	EXPOSURE3	Ultra Fine/Exposure 3	1 - 99	50
Е	EXPOSURE4	Ultra Fine/Exposure 4	1 - 99	50
F	EXPOSURE5	Ultra Fine/Exposure 5	1 - 99	50
G	AUTO H_TONE	Ultra Fine/Auto/	1 - 99	50
		Halftone		
н	EXPOSURE1	Ultra Fine/	1 - 99	50
	H_TONE	Exposure 1/Halftone		
1	EXPOSURE2	Ultra Fine/	1 - 99	50
	H_TONE	Exposure 2/Halftone		
J	EXPOSURE3	Ultra Fine/	1 - 99	50
	H_TONE	Exposure 3/Halftone		
к	EXPOSURE4	Ultra Fine/	1 - 99	50
	H_TONE	Exposure 4/Halftone		
L	EXPOSURE5	Ultra Fine/	1 - 99	50
	H_TONE	Exposure 5/Halftone		

	Item/Disp	olay	(	Content	Sett ran	ting Ige	Default value
Μ	EXECUTE MODE	AUTO	Print mode	Ultra Fine/ Auto	1 - 12	1	1 (AUTO)
		EXP1		Ultra Fine/ Exposure 1		2	· · ·
		EXP2		Ultra Fine/ Exposure 2		3	
		EXP3		Ultra Fine/ Exposure 3		4	
		EXP4		Ultra Fine/ Exposure 4		5	
		EXP5		Ultra Fine/ Exposure 5		6	
		AUTO H_TONE		Ultra Fine/ Auto/ Halftone		7	
		EXP1 H_TONE		Ultra Fine/ Exposure 1/ Halftone		8	
		EXP2 H_TONE		Ultra Fine/ Exposure 2/ Halftone		9	
		EXP3 H_TONE		Ultra Fine/ Exposure 3/ Halftone		10	
		EXP4 H_TONE		Ultra Fine/ Exposure 4/ Halftone		11	
		EXP5 H_TONE		Ultra Fine/ Exposure 5/ Halftone		12	

To check the adjustment density level of items A - L, set the document and set the setting value of item M according to items A - L, and press [EXECUTE] key.

46-45	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the FAX send image density. (600dpi).

# Section

**Operation/Procedure** 

- 1) Set the document on the document table.
- 2) Enter the set value with 10-key.
- Press [EXECUTE] key, or [OK] key When [EXECUTE] key is pressed, the adjustment value is set and the scanned document image is outputted.

	Item/Display	Content	Setting range	Default value
Α	AUTO	600dpi/Auto 1	1 - 99	50
В	EXPOSURE1	600dpi/Exposure 1	1 - 99	50
С	EXPOSURE2	600dpi/Exposure 2	1 - 99	50
D	EXPOSURE3	600dpi/Exposure 3	1 - 99	50
ш	EXPOSURE4	600dpi/Exposure 4	1 - 99	50
F	EXPOSURE5	600dpi/Exposure 5	1 - 99	50
G	AUTO H_TONE	600dpi/Auto/ Halftone 1	1 - 99	50
Н	EXPOSURE1 H_TONE	600dpi/Exposure 1/ Halftone	1 - 99	50
I	EXPOSURE2 H_TONE	600dpi/Exposure 2/ Halftone	1 - 99	50
J	EXPOSURE3 H_TONE	600dpi/Exposure 3/ Halftone	1 - 99	50
к	EXPOSURE4 H_TONE	600dpi/Exposure 4/ Halftone	1 - 99	50
L	EXPOSURE5 H_TONE	600dpi/Exposure 5/ Halftone	1 - 99	50

Item/Display		c	content	Set rar	ting Ige	Default value	
М	EXECUTE	AUTO	Print	600dpi/	1 -	1	1
	MODE		mode	Auto	12		(AUTO)
		EXP1		600dpi/		2	
				Exposure 1			
		EXP2		600dpi/		3	
				Exposure 2			
		EXP3		600dpi/		4	
				Exposure 3			
		EXP4		600dpi/		5	
				Exposure 4			
		EXP5		600dpi/		6	
				Exposure 5			
		AUTO		600dpi/		7	
		H_TONE		Auto/			
				Halftone			
		EXP1		600dpi/		8	
		H_TONE		Exposure			
				1/Halftone			
		EXP2		600dpi/		9	
		H_TONE		Exposure			
		51/50		2/Halftone			
		EXP3		600dpi/		10	
		H_TONE		Exposure			
		EVD4	-	3/Halitone			
		EXP4		600dpi/		11	
		ILIONE		ZXPOSUIE			
			1			10	
				Exposure		12	
		II_IONE		5/Halftone			

To check the adjustment density level of items A - L, set the document and set the setting value of item M according to items A - L, and press [EXECUTE] key.

# 46-46

Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the FAX send image density.
	(RGB RIP)

### Section

**Operation/Procedure** 

- 1) Select a target mode for adjustment.
- 2) Set the document on the document table.
- 3) Enter the set value with 10-key.
- 4) Press [OK] key.

When the set value is increased, the density becomes higher. When the set value is decreased, the density becomes lower.

	Item/Display	Content	Setting range	Default value
A	STANDARD RIP	For Normal/ Halftone OFF mode	1 - 99	50
В	FINE RIP	For Fine/Halftone OFF mode	1 - 99	50
С	FINE RIP H_TONE	For Fine/Halftone ON mode	1 - 99	50
D	SUPER FINE RIP	For Super Fine/ Halftone OFF mode	1 - 99	50
E	SUPER FINE RIP H_TONE	For Super Fine/ Halftone ON mode	1 - 99	50
F	ULTRA FINE RIP	For Ultra fine/ Halftone OFF mode	1 - 99	50
G	ULTRA FINE RIP H_TONE	For Ultra fine/ Halftone ON mode	1 - 99	50

	Item/Display	Content	Setting range	Default value
н	600DPI RIP	For 600dpi/ Halftone OFF mode	1 - 99	50
I	600DPI RIP H_TONE	For 600dpi/ Halftone ON mode	1 - 99	50

46-47	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the compression rate of copy
	and scan images (JPEG).

# Section

# **Operation/Procedure**

- 1) Select a target item with scroll keys on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

The set value is saved.

Operation mode		Item/Dis	splay	Content	Setting range	Default value
FILLING	А	COPY	LOW	Low	0	0 (LOW)
(COLOR)		(C)		compres-		
(COPY				sion (Color)		
(COLOR			MIDDLE	Medium	1	
mode))				compres-		
				sion (Color)		
			HIGH	High	2	
				compres-		
				sion (Color)		
FILLING	в	COPY	LOW	Low	0	0 (LOW)
(GRAY)		(G)		compres-		
(COPY				sion (Gray)		
(Mono-			MIDDLE	Medium	1	
chrome				compres-		
nalitione				sion (Gray)		
mode))			HIGH	High	2	
				compres-		
	_			sion (Gray)	-	
PUSH	С	SCAN	MIDDLE	Medium	0	1
SCAN		(C)	1	compres-		(MIDDLE
(COLOR)				sion mode 1		2)
(Scanner				LOW		
(COIOI mode))				compres-		
mode))				Modium	1	
				compres-		
			2	sion mode 2		
				Medium		
				compres-		
				sion		
			MIDDLE	Medium	2	
			3	compres-	_	
				sion mode 3		
				High		
				compres-		
				sion		

Operation mode		Item/Dis	splay	Content	Setting range	Default value
PUSH SCAN (GRAY) (Scanner (Mono-	D	SCAN (G)	MIDDLE 1	Medium compres- sion mode 1 Low compres-	0	1 (MIDDLE 2)
chrome halftone mode))			MIDDLE 2	Sion Medium compres- sion mode 2 Medium compres- sion	1	
			MIDDLE 3	Medium compres- sion mode 3 High compres- sion	2	

### 46-51

10 01	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the gamma for the copy
	mode heavy paper mode and the image
	process mode.

Section

### **Operation/Procedure**

- 1) Select a target adjustment mode with the touch panel key [PAPER/DITHER].
- Select an adjustment target color with [K][C][M][Y] keys on the touch panel.
- 3) Select a target adjustment density level with scroll key on the touch panel.
- 4) Enter the set value with 10-key.
- Press [EXECUTE] key, or [OK] key.
   When [EXECUTE] key is pressed, the self print image is outputted.

When the image density is insufficient or a background copy is made in heavy paper copy, change this adjustment value to adjust the image density.

Item/Display	Content	Color
HEAVY	Copier heavy paper gamma	KCMY
DITH1	Black edge	К
DITH2	Color edge	KCMY
DITH3	Color error diffusion	KCMY
DITH4	Monochrome error diffusion	К
DITH8	Monochrome dither	К

	Item/Display	Density level (Point)	Setting range	Default value
Α	POINT1	Point 1	1 - 999	500
В	POINT2	Point 2	1 - 999	500
С	POINT3	Point 3	1 - 999	500
D	POINT4	Point 4	1 - 999	500
Е	POINT5	Point 5	1 - 999	500
F	POINT6	Point 6	1 - 999	500
G	POINT7	Point 7	1 - 999	500
Н	POINT8	Point 8	1 - 999	500
1	POINT9	Point 9	1 - 999	500
J	POINT10	Point 10	1 - 999	500
К	POINT11	Point 11	1 - 999	500
L	POINT12	Point 12	1 - 999	500
М	POINT13	Point 13	1 - 999	500
Ν	POINT14	Point 14	1 - 999	500
0	POINT15	Point 15	1 - 999	500
Р	POINT16	Point 16	1 - 999	500
Q	POINT17	Point 17	1 - 999	500

46-52	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the gamma default for the copy mode heavy paper and the image process mode. (After execution of either SIM46-54 or SIM46-51, the adjustment value is reset to the initial value.)
Section	

### **Operation/Procedure**

- Select an item to be set to the default with the touch panel key. To reset the adjustment values of all the items, select [ALL].
- 2) Press [EXECUTE] key.
- 3) Press [YES] key.

46-54	
Purpose	Adjustment
Function (Purpose)	Used to perform the engine halftone auto-
	matic density adjustment (dither).

### Section Operation/Procedure

1) Press [EXECUTE] key.

The high density process control is started to make 48 patch self print. (A4 (11" x 8.5") or A3 (11" x 17") paper in the paper feed tray is used.)

2) Place the 48 patch self print on the document table, and press [EXECUTE] key.

Scanning the 48 patch self print is started.

After scanning the 48 patch self print, the 17 patch self print is automatically printed.

3) Press [OK] key.

After completion of the correction amount registration, the screen shifts to the dither selection menu.

4) Select an item (dither) to be adjusted.

HEAVYPAPER	Copier/gamma for heavy paper
BLACK EDGE	Black edge
COLOR EDGE	Color edge
COLOR ED	Color error diffusion
B/W ED	Monochrome error diffusion
B/W 600	Monochrome dither 600dpi

### 5) Press [EXECUTE] key.

The 48 patch self print is printed.

 Place the 48 patch self print on the document table, and press [EXECUTE] key.

Scanning the 48 patch self print is started.

After scanning the patch, the screen automatically shifts to the dither selection menu.

7) After completion of the adjustment of all the density adjustment items (dither), press [OK] key.

46-55	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the drop out color in the image send mode (monochrome manual text mode).
Section	
0	

In the image send mode (monochrome manual text mode), the range where color images are reproduced as monochrome images is adjusted.

 Enter the adjustment value with 10-key and press [OK] key.
 When the adjustment value is increased, colors dropout becomes easy to narrow the reproduction range. When the adjustment value is decreased, color dropout becomes difficult to widen the reproduction range.

Item/Display		Content	Setting range	Default value
А	CHROMA	Dropout color range adjustment	0 - 6	3

2) Scan the document in the image send mode (monochrome manual text mode), and check the adjustment result.

46-58	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the copy mode pseudo resolu- tion. (Smoothing process)
	tion. (Smoothing process)

### Section Operation/Procedure

1) Select an item (mode) to be set with the button and the scroll key.

- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

1(ON): 9600 (equivalent) x 600 dpi

0 (OFF): 600 x 600 dpi

The setting is reflected only the image edge area.

Mode		Item/Display	Content	Setti	ng	Default
mode		nonii/Diopidy	(copy mode)	rang	je	value
COLOR	А	AUTO	Auto	OFF	0	0 (OFF)
				ON	1	
	В	TEXT	Text	OFF	0	1 (ON)
				ON	1	
	С	TEXT PRT	Text print	OFF	0	0 (OFF)
				ON	1	
	D	PRINTED	Printed Photo	OFF	0	0 (OFF)
		PHOTO		ON	1	
	Е	TEXT PHOTO	Text	OFF	0	0 (OFF)
			photograph	ON	1	
	F	PHOTO	Photograph	OFF	0	0 (OFF)
				ON	1	
	G	MAP	Мар	OFF	0	1 (ON)
				ON	1	
	Н	LIGHT	Light	OFF	0	0 (OFF)
			document	ON	1	
	Ι	CPY TO CPY/	Text (copy	OFF	0	1 (ON)
		TEXT	document)	ON	1	
	J	CPY TO CPY/	Text print	OFF	0	0 (OFF)
		TXT PRT	(copy	ON	1	
			document)			
	к	CPY TO CPY/	Printed Photo	OFF	0	0 (OFF)
		PHOTO	(copy	ON	1	
			document)			

Mode		Item/Display	Content (copy mode)	Setti ranc	ng 1e	Default value
MONO	А	AUTO	Auto	OFF	0	0 (OFF)
				ON	1	. ,
	В	TEXT	Text	OFF	0	1 (ON)
				ON	1	
	С	TEXT PRT	Text print	OFF	0	0 (OFF)
				ON	1	
	D	PRINTED	Printed Photo	OFF	0	0 (OFF)
		PHOTO		ON	1	
	Е	TEXT PHOTO	Text	OFF	0	0 (OFF)
			photograph	ON	1	
	F	PHOTO	Photograph	OFF	0	0 (OFF)
				ON	1	
	G	MAP	Мар	OFF	0	1 (ON)
				ON	1	
	Н	LIGHT	Light	OFF	0	0 (OFF)
			document	ON	1	
	1	CPY TO CPY/	Text (copy	OFF	0	1 (ON)
		TEXT	document)	ON	1	
	J	CPY TO CPY/	Text print	OFF	0	0 (OFF)
		TXT PRT	(copy	ON	1	
			document)			
	к	CPY TO CPY/	Printed Photo	OFF	0	0 (OFF)
		PHOTO	(copy document)	ON	1	

46-59	
Purpose	Adjustment/Setup
Function (Purpose)	Used to perform the copy mode pseudo resolution image process adjustment.
Section	

- 1) Select the MAIN (main scanning direction) or the SUB (sub scanning direction) button.
- 2) Press the button of the adjustment value of the target copy mode.



This adjustment is valid when SIM46-58 Pseudo resolution setting is set to ON.

The thickness of images in the section processed by smoothing is changed.

Positive: The image in the section processed by smoothing becomes thicker.

Negative: The image in the section processed by smoothing becomes thinner.

Scanning direction	Item (copy mode)	Adjustment button	Content	Default value	NOTE
MAIN	COLOR COPY K	(-)2	Color copy For BLACK	0	Main scanning direction smoothing
		(-)1			fine adjustment
		0			Negative (-) direction: The
		(+)1			smoothing section becomes
		(+)2		Positive (+) direct	Positive (+) direction: The
	COLOR COPY C	(-)2	Color copy For CYAN	0 smoothing section becom	smoothing section becomes
		(-)1			thicker.
		0			
		(+)1			
		(+)2			
	COLOR COPY M	(-)2	Color copy For MAGENTA	0	
		(-)1			
		0			
		(+)1			
		(+)2			
	COLOR COPY Y	(-)2	Color copy For YELLOW	0	
		(-)1			
		0			
		(+)1	]		
		(+)2			
	MONO COPY K	(-)2	Monochrome copy For BLACK	0	
		(-)1	]		
		0	]		
		(+)1	1		
		(+)2			
	COLOR PRINT K	(-)2	Color print For BLACK	0	
		(-)1			
		0	1		
		(+)1			
		(+)2			
	COLOR PRINT C	(-)2	Color print For CYAN	0	
		(-)1	]		
		0	]		
		(+)1	1		
		(+)2	]		
	COLOR PRINT M	(-)2	Color print For MAGENTA	0	
		(-)1	]		
		0	1		
		(+)1	]		
		(+)2	]		
-	COLOR PRINT Y	(-)2	Color print For YELLOW	0	
		(-)1	]		
		0	]		
		(+)1	]		
		(+)2			
	MONO PRINT K	(-)2	Monochrome print For BLACK	0	
		(-)1	]		
		0	]		
		(+)1	]		
		(+)2	]		

Scanning direction	Item (copy mode)	Adjustment button	Content	Default value	NOTE	
SUB	COLOR COPY K	(-)2	Color copy For BLACK	0	Sub scanning direction smoothing	
		(-)1			fine adjustment	
		0			Negative (-) direction: The	
		(+)1			smoothing section becomes	
		(+)2			ninner. Resitive (1) direction: The	
	COLOR COPY C	(-)2	Color copy For CYAN	0	0 smoothing section become	smoothing section becomes
		(-)1			thicker.	
		0				
		(+)1				
		(+)2				
	COLOR COPY M	(-)2	Color copy For MAGENTA	0		
		(-)1				
		0				
		(+)1				
		(+)2				
	COLOR COPY Y	(-)2	Color copy For YELLOW	0		
		(-)1				
		0				
		(+)1				
		(+)2				
	MONO COPY K	(-)2	Monochrome copy For BLACK	0		
		(-)1				
		0				
		(+)1				
		(+)2				
	COLOR PRINT K	(-)2	Color print For BLACK	0		
		(-)1				
		0				
		(+)1				
		(+)2				
	COLOR PRINT C	(-)2	Color print For CYAN	0		
		(-)1				
		0				
		(+)1				
		(+)2				
	COLOR PRINT M	(-)2	Color print For MAGENTA	0		
		(-)1				
		0				
		(+)1				
		(+)2		-		
	COLOR PRINT Y	(-)2	Color print For YELLOW	0		
		(-)1				
		0				
		(+)1				
		(+)2				
	MONO PRINT K	(-)2	Monochrome print For BLACK	0		
		(-)1				
		0				
		(+)1				
		(+)2				

46-60	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the sharpness in the color
	auto copy mode.
Section	

- 1) Select a target item with scroll keys on the touch panel.
- 2) Input numeric value corresponding to sharpness level (filter process mode).
- 3) Press [OK] key.

This is used to adjust the sharpness in the color auto copy mode and the smoothness (roughness) in the dark area.

	Item/Display		Content		Setting range	Default value
Α	SCREEN FILTER LEVEL	Н	Sharpness (filter) adjustment of dot pattern image in auto	Strong emphasis	1	3 (Auto)
		L	copy mode	Soft emphasis	2	
		AUTO		Auto	3	
В	CPY CL AUTO FILTER	SOFT	Sharpness (filter) adjustment for the automatic copy mode	SOFT	1	2 (CENTER)
	LEVEL	CENTER	(Text, Printed Photo / Printed Photo images)	CENTER	2	
		HIGH		HIGH	3	
С	CPY PUSH AUTO	SOFT	Sharpness (filter) adjustment for the automatic push scan	SOFT	1	2 (CENTER)
	FILTER LEVEL	CENTER	mode (Text, Printed Photo / Printed Photo images)	CENTER	2	
		HIGH		HIGH	3	
D	COLOR COPY : CMY	OFF	Soft filter applying setting to C, M, Y image in color copy	OFF	0	1 (ON)
		ON	mode	ON	1	
Е	COLOR COPY : K	OFF	Soft filter applying setting to K image in color copy mode	OFF	0	1 (ON)
		ON		ON	1	
F	SINGLE COLOR : CMY	OFF	Soft filter applying setting to C, M, Y image in sigle color	OFF	0	1 (ON)
		ON	copy mode	ON	1	
G	2 COLOR COPY : CMY	OFF	Setting of YES/NO of applying the soft filter to C/M/Y	OFF	0	1 (ON)
		ON	images of the 2-color copy mode	ON	1	
Н	2 COLOR COPY : K	OFF	Setting of YES/NO of applying the soft filter to K images of	OFF	0	1 (ON)
		ON	the 2-color copy mode	ON	1	
Ι	B/W COPY	OFF	Soft filter applying setting in monochrome copy mode	OFF	0	1 (ON)
		ON		ON	1	
J	COLOR PUSH : RGB	OFF	Soft filter applying setting to image in push scan color	OFF	0	1 (ON)
		ON	mode	ON	1	
К	B/W PUSH	OFF	Soft filter applying setting to image in push scan	OFF	0	1 (ON)
		ON	monochrome mode	ON	1	
L	COLOR PRINT: CMY	OFF	Setting of ON/OFF of soft filter application to color print C,	OFF	0	0 (OFF)
		ON	M, Y images	ON	1	
Μ	COLOR PRINT: K	OFF	Setting of ON/OFF of soft filter application to color print K	OFF	0	0 (OFF)
		ON	images	ON	1	
Ν	B/W PRINT	OFF	Setting of ON/OFF of soft filter application to monochrome	OFF	0	0 (OFF)
		ON	print images	ON	1	

# 46-61 Purpose

Adjustment/Setup

Function (Purpose)

 Used to adjust the area separation recognition level.

### Section

#### **Operation/Procedure**

- 1) Select an adjustment mode.
- 2) Select a target adjustment item with scroll key on the touch panel.
- 3) Enter the adjustment value using the 10-key.
- 4) Press [OK] key.

# Important

This must be set to the default unless any change is specially required.

When the adjustment value is set to a value greatly different from the default value, image quality trouble may occur for some documents.

Item/Display		Content
COLOR	AUTO	[Color/Gray] Auto
TPP		[Color/Gray] Manual (Text print)
COPY(TPP)		[Color/Gray] Copy document (Text print)
MONO	AUTO	[Monochrome] Auto
	TPP	[Monochrome] Manual (Text print)
COPY(TPP)		[Monochrome] Copy document (Text print)

	Item/Display	Content	Setting range	Default value
A	SEGMENT: SWITCH [TXT ON SCR]	Detection ON/OFF: Text on dot	0 - 1	0
В	SEGMENT: SWITCH [LINE SCR]	Detection ON/OFF: line screen	0 - 1	0
С	SEGMENT: SWITCH [SMALL SCR]	Detection ON/OFF: Dot in a small area	0 - 1	0
D	SEGMENT: SWITCH [HIGH LPI]	Detection ON/OFF: High line number judgment select	0 - 1	0
E	SEGMENT: SWITCH [TXT ON SCR IMAGE SEND]	Detection ON/OFF: Text on image send dots	0 - 1	0
F	SEGMENT: ADJUST [BK TXT 1]	Detection level adjustment: Black text 1	1 - 99	50
G	SEGMENT: ADJUST [CL TXT 1]	Detection level adjustment: Color text 1	1 - 99	50
Н	SEGMENT: ADJUST [BK TXT 2, CL TXT 2]	Detection level adjustment: Black text 2, Color text 2	1 - 49	25
Ι	SEGMENT: ADJUST [TXT ON SCR 1]	Detection level adjustment: Text 1 on dots	1 - 99	50
J	SEGMENT: ADJUST [TXT ON SCR 2]	Detection level adjustment: Text 2 on dots	1 - 99	50
К	SEGMENT: ADJUST [TXT ON SCR AREA]	Detection level adjustment: Detection area of text on dots	1 - 15	8
L	SEGMENT: ADJUST [HIGH LPI]	Detection level adjustment: High line number judgment	1 - 49	25
М	SEGMENT: ADJUST [BK]	Detection level adjustment: No chrome judgment	1 - 99	50
N	SEGMENT: ADJUST [CL]	Detection level adjustment: Chrome judgment	1 - 99	50
0	SEGMENT: ADJUST [TXT ON BG]	Detection level adjustment: Text on background	1 - 99	50

	Item/Display	Content	Setting range	Default value
Ρ	SEGMENT: ADJUST [SCR 1 HIGH]	Detection level adjustment: High density dots	1 - 49	25
Q	SEGMENT: ADJUST [SCR 1 MIDDLE]	Detection level adjustment: Medium density dots	1 - 49	25
R	SEGMENT: ADJUST [SCR 1 LOW]	Detection level adjustment: Low density dots	1 - 49	25
S	SEGMENT: ADJUST [SCR 2]	Detection level adjustment: Dot 2	1 - 15	8
Т	SEGMENT: ADJUST [SCR 3]	Detection level adjustment: Dot 3	1 - 15	8
U	SEGMENT: ADJUST [LINE HALFTONE]	Detection level adjustment: line screen	1 - 49	25

46-62	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the operating conditions of the ACS, the area separation, the background image process, and the auto exposure mode.

# Section

### **Operation/Procedure**

- 1) Select a target adjustment item with scroll key on the touch panel.
- 2) Enter the adjustment value using the 10-key.
- 3) Press [OK] key.

### Important

This must be set to the default unless any change is specially required.

When the adjustment value is set to a value greatly different from the default value, image quality trouble may occur for some documents.

	Item/Display	Content	Setting range	Default value
A	SW_ACS	ACS judgment reference area select	0 - 1	1
В	TEXT_IMAGE	Text/Image judgment priority level adjustment	0 - 6	3
С	TEXT_BLANK	Text/Blank judgment priority level adjustment	0 - 6	4
D	HT_LV	Dot area judgment threshold value adjustment	0 - 6	1
E	AE_AREA_LV	Color AE judgment target area adjustment	0 - 6	3
F	AE_LV_CC	AE background detection division result adjustment: For color copy	0 - 8	4
G	AE_LV_MC	AE background detection division result adjustment: For monochrome copy	0 - 8	4
Н	AE_LV_CS	AE background detection division result adjustment: For color scan	0 - 8	4
I	AE_LV_MS	AE background detection division result adjustment: For monochrome scan	0 - 8	4
J	AE_JUDGE _LV_L_U	Color AE background density threshold value adjustment (lower limit)	0 - 4	0

Item/Display		Content		Sett	ing	Default		
		,			ran	ge	value	
к	AE_JUDG	iΕ	Color AE backgro	und	0 - 1	10	0	
	LV_L_O		density threshold					
			adjustment (uppe	r limit)				
L	AE_JUDG	iE_	Color AE backgro	und	0 - 1	10	5	
	LV_C		detection level					
			adjustment (chror	na)		1		
М	AE	ON	AE mode ON/	ON	0 - 1	0	0 (ON)	
	_ONOFF	OFF	OFF switch:	OFF		1		
	_CC		For color copy					
Ν	AE	ON	AE mode ON/	ON	0 - 1	0	0 (ON)	
	_ONOFF OFF		OFF switch:	OFF		1		
	_MC		For mono-					
			chrome copy					
0	AE	ON	AE mode ON/	ON	0 - 1	0	0 (ON)	
	_ONOFF	OFF	OFF switch :	OFF		1		
	_CS		For color scan					
Р	AE	ON	AE mode ON/	ON	0 - 1	0	0 (ON)	
	_ONOFF	OFF	OFF switch :	OFF		1		
	_MS		For mono-					
			chrome copy					
Q	BLANK_JUDGE		Blank judgment level		0 - 10		0	
	_LV_L		adjustment (value	e)				
R	BLANK_J	UDGE	Blank judgment le	evel	0 - 1	10	0	
	_LV_C		adjustment (chror	na)				
S	MODE0_U	JNDE	Mode 0 developir	eveloping		6	0	
	R		paper mode selec	t		_		
Т	MODE1_U	JNDE	Mode 1 developin	ig	0 -	6	0	
<u></u>	R		paper mode selec	t				
U	MODE5_U	JNDE	Mode 5 developin	ig	0 -	6	0	
<u> </u>	R		paper mode selec	t	-			
V	MODE6_U	JNDE	Mode 6 developir	ig	0 - 6		0	
L	K		paper mode selec	л				
W	SW_CHAI	NGE_	Mode 0: Mode judgment		0 - 6		0	
	MODE0		select					
X	SW_CHAI	NGE_	Mode 1: Mode jud	Igment	0 -	6	1	
	MODE1		select					
Y	SW_CHANGE_		Mode 2: Mode jud	Igment	0 -	6	2	
<u> </u>	MODE2		select		<u> </u>			
Z	SW_CHAI	NGE_	Mode 3: Mode judgment		0 -	6	3	
			select		-	0	4	
AA	SW_CHAI	NGE_	Mode 4: Mode jud	agment	0 -	6	4	
	NUDE4		select				_	
AB	SW_CHAI	NGE_	Mode 5: Mode jud	gment	0 -	6	5	
<u> </u>	MODE5		select			_		
A	SW_CHAI	NGE_	Mode 6: Mode jud	lgment	0 -	6	6	
I C	MODE6		select		1		1	

46-63	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the density in the copy low density section.

### Section Operation/Procedure

- 1) Select a target adjustment item with scroll key on the touch panel.
- 2) Enter the adjustment value using the 10-key.
- 3) Press [OK] key.

When the adjustment value is increased, reproducibility of the background and the low density image is increased. When the adjustment value is decreased, reproducibility of the background and the low density image is decreased.

	ltem/Display	Content	Setting range	Default value
А	COLOR COPY :	Text print	1 - 9	3
	<b>TEXT/PRINTED PHOTO</b>	(color copy)		
В	COLOR COPY : TEXT	Text (color copy)	1 - 9	3
С	COLOR COPY :	Printed photo	1 - 9	5
	PRINTED PHOTO	(color copy)		

	Item/Display	Content	Setting	Default value
D	COLOR COPY : PHOTOGRAPH	Photograph (color copy)	1 - 9	5
Е	COLOR COPY : TEXT/PHOTO	Text/Photograph (color copy)	1 - 9	3
F	COLOR COPY : MAP	Map (color copy)	1 - 9	5
G	COLOR COPY : LIGHT	Light document (color density)	1 - 9	6
Н	COLOR COPY : TEXT/PRINTED PHOTO (COPY TO COPY)	Copy document, Character print (color copy)	1 - 9	5
I	COLOR COPY : TEXT (COPY TO COPY)	Copy document, Character (color copy)	1 - 9	5
J	COLOR COPY : PRINTED PHOTO (COPY TO COPY)	Copy document, Printed photo (color copy)	1 - 9	5
К	COLOR PUSH : TEXT/PRINTED PHOTO	Text print (color PUSH)	1 - 9	3
L	COLOR PUSH : TEXT	Text (color PUSH)	1 - 9	3
М	COLOR PUSH : PRINTED PHOTO	Printed photo (color PUSH)	1 - 9	5
N	COLOR PUSH : PHOTOGRAPH	Photograph (color PUSH)	1 - 9	5
0	COLOR PUSH : TEXT/PHOTO	Text/Photograph (color PUSH)	1 - 9	3
Ρ	COLOR PUSH : MAP	Map (color PUSH)	1 - 9	5

46-65	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the color correction table.
Section	

### **Operation/Procedure**

1) Select an adjustment mode.

- 2) Select an item (mode) to be set with the scroll key.
- 3) Enter the adjustment value using the 10-key.
- 4) Press [OK] key.

When the setting is changed, the color tone is changed. This function is used to make copies of different color tone for each copy mode.

The initial value must be set unless any special change is required.

Mode	Item/Display		Content	Setting range	Default value
COPY	A	[MANUAL] TEXT PRT	Text print	0 - 8	0
	В	[MANUAL] TEXT	Text	0 - 8	0
	С	[MANUAL] PRINTED PHOTO	Printed Photo	0 - 8	0
	D	[MANUAL] PHOTO	Photograph	0 - 8	1
	E	[MANUAL] TEXT PHOTO	Text photograph	0 - 8	1
	F	[MANUAL] MAP	Мар	0 - 8	0
	G	[MANUAL] LIGHT	Pencil	0 - 8	0
	Н	[MANUAL] CPT TO CPT/TXT PRT	Copy document/ Text print	0 - 8	0
	Ι	[MANUAL] CPT TO CPT/TEXT	Copy document/ Text	0 - 8	0
	J	[MANUAL] CPY TO CPY/PHOTO	Copy document/ Printed Photo	0 - 8	0
	K	AUTO0	Automatic mode judgment 0	0 - 8	2

Mode		Item/Display Conten		Setting range	Default value
COPY	L	AUTO1	Automatic	0 - 8	2
			mode		
	N/			0.8	2
	IVI	A0102	mode	0-0	3
			judgment 2		
	Ν	AUTO3	Automatic	0 - 8	3
			mode		
	0		Judgment 3	0.8	2
	Ŭ	A0104	mode	0-0	2
			judgment 4		
	Ρ	AUTO5	Automatic	0 - 8	2
			mode		
	0		Judgment 5	0.8	2
	Q	A0100	mode	0-0	2
			judgment 6		
PREVIEW	А	[MANUAL] TEXT	Text print	0 - 4	0
(Preview	_	PRT	<b>-</b>		<u> </u>
screen)	B		lext Brinted	0-4	0
	C		Photo	0-4	0
	D	[MANUAL]	Photograph	0 - 4	1
		PHOTO	<b>U</b> .		
	Е	[MANUAL] TEXT	Text	0 - 4	1
	_	PHOTO	photograph		
	F		Nap	0-4	0
	н		Copy	0-4	0
		TO CPT/TXT PRT	document/	Ŭ.	Ũ
			Text print		
	Т	[MANUAL] CPT	Сору	0 - 4	0
		TO CPI/TEXT	document/		
	J	[MANUAL] CPY	Copy	0 - 4	0
		TO CPY/PHOTO	document/		
			Printed		
	K		Photo	0.4	2
	n	A0100	mode	0-4	2
			judgment 0		
	L	AUTO1	Automatic	0 - 4	2
			mode		
	N/			0.4	2
	101	//0102	mode	0-4	5
			judgment 2		
	Ν	AUTO3	Automatic	0 - 4	3
			mode		
	0	AUTO4	Automatic	0-4	2
			mode		-
			judgment 4		
	Р	AUTO5	Automatic	0 - 4	2
			mode		
	0	AUTO6	Automatic	0 - 4	2
	-		mode		
			judgment 6		

46-66	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the reproduction capability of watermarks in the copy/printer mode.
Section	

This is to adjust the reproduction capability of watermarks in the copy/printer mode.

1) Select the adjustment mode.

- 2) Select an adjustment item according to the necessity.
- 3) Enter the adjustment value with 10-key and press [OK] key.
- 4) Make a copy, and check the adjustment result.

Category	egory Item/Display		Content	Setting	Default	NOTE
DATTERN	•			range	value	
PATTERN	A	WOVEN DEN BK LOW	Watermark density level (Black LOW)	0 - 255	15	I ne adjustment value is
	В	WOVEN DEN BK MIDDLE	Watermark density level (Black MIDDLE)	0 - 255	19	changed to increase of
	С	WOVEN DEN BK HIGH	Watermark density level (Black HIGH)	0 - 255	23	watermark of background
	D	WOVEN DEN C LOW	Watermark density level (Cyan LOW)	0 - 255	19	documents (primary output)
	Е	WOVEN DEN C MIDDLE	Watermark density level (Cyan MIDDLE)	0 - 255	23	To increase the watermark
	F	WOVEN DEN C HIGH	Watermark density level (Cyan HIGH)	0 - 255	27	density increase the
	G	WOVEN DEN M LOW	Watermark density level (Magenta LOW)	0 - 255	15	adjustment value.
	Н	WOVEN DEN M MIDDLE	Watermark density level (Magenta MIDDLE)	0 - 255	18	To decrease the watermark
	1	WOVEN DEN M HIGH	Watermark density level (Magenta HIGH)	0 - 255	21	density, decrease the
						adjustment value.
						NOTE:
						When the adjustment value
						is increased, the watermark
						area which is originally not
						reproduced becomes
						difficult to disappear.
						When the adjustment value
						is decreased, the watermark
						area which is originally
						reproduced becomes easy
				0.055	-	
	J	CONTRAST	Contrast adjustment	0 - 255	2	I his is used to adjust the
						density when the adjustment
						value of the watermark print/
						contrast adjustment in the
						system setting is changed
						by 1
						When this value is
						increased, the variation is
						also increased. When the
						value is decreased, the
						variation is also decreased.
						When the adjustment value
						is 0, the result of the
						contrast adjustment is not
						reflected. (* The adjustment
						value must be set to 1 or
						greater.)
	К	HT TYPE (POSI)	For halftone index watermark type positive	42 - 43	42	To reproduce the containing
	L	HT TYPE (NEGA)	For halftone index watermark type negative	42 - 43	42	characters of watermark
						copy (secondary output)
						more clearly, set to 43.
						In that case, however, the
						containing characters of the
						watermark document
						(primary output) can be
	1	1		1		easily reproduced.

Category Item/Display		Cont	Content		Setting range		NOTE	
COPY MODE	Α	TEXT/PRINTED PHOTO	Text/Printed Photo mode	OFF	0 - 1	0	1	Normally set to the default.
			select Enable/Disable	ON		1		No need to change in the
	В	TEXT	Text mode select Enable/	OFF	0 - 1	0	1	market.
			Disable	ON		1		
	С	PRINTED PHOTO	Printed Photo mode	OFF	0 - 1	0	1	
			select Enable/Disable	ON		1		
	D	PHOTOGRAPH	Photograph mode select	OFF	0 - 1	0	1	
			Enable/Disable	ON		1		
	E	TEXT/PHOTO	Text/Photograph mode	OFF	0 - 1	0	1	
	-	MAD	Select Enable/Disable	ON	0.1	1		
	F	MAP	Niap mode select Enable/	OFF	0 - 1	0	1	
	G		Light density decument		0 1	0	1	
	G	LIGHT	mode select Enable/		0-1	1		
			Disable					
	н	TEXT/PRINTED PHOTO	Copy document: Enable/	OFF	0 - 1	0	1	
		(CPY TO CPY)	Disable of selection of the	ON		1		
			text print mode					
	Т	TEXT (CPY TO CPY)	Copy document: Enable/	OFF	0 - 1	0	1	
			Disable of selection of the text mode	ON		1		
	J	PRINTED PHOTO (CPY	Copy document: Enable/	OFF	0 - 1	0	1	
		TO CPY)	Disable of selection of the printed photo mode	ON	1	1		
	κ	AUTO	Automatic mode select	OFF	0 - 1	0	1	
			Enable/Disable	ON	1	1		
	L	DEFAULT MODE	When the default	TEXT/	0 - 5	0	0	
			exposure mode	PRINTED PHOTO				
			background is ON, the	TEXT	1	1		
			exposure mode to be set	PRINTED PHOTO		2		
			is specified.	PHOTOGRAPH		3		
				TEXT/PHOTO	1	4		
				MAP		5		
POSITION	A	LINE SPACE 1	Line space in the waterma (24P - 36P)	0 - 20	00	50		
	В	LINE SPACE 2	Line space in the waterma (37P - 48P)	0 - 20	00	60		
	С	LINE SPACE 3	Line space in the waterma (49P - 64P)	rk print box	0 - 200 70 0 - 200 80		70	
	D	LINE SPACE 4	Line space in the waterma (65P - 80P)	rk print box			80	
	E	BLANK H/B 1	Upper margin/Lower marg box (24P - 36P)	in in the watermark print	0 - 20	00	25	
	F	BLANK H/B 2	Upper margin/Lower marg box (37P - 48P)	in in the watermark print	0 - 20	00	30	
	G	BLANK H/B 3	Upper margin/Lower marg box (49P - 64P)	in in the watermark print	0 - 200 35		35	
	Н	BLANK H/B 4	Upper margin/Lower marg	in in the watermark print	0 - 20	00	40	
	I	BLANK L/R 1	Left margin/Right margin ir (24P - 36P)	the watermark print box	0 - 200		60	
	J	BLANK L/R 2	Left margin/Right margin in (37P - 48P)	the watermark print box	0 - 20	00	90	
	К	BLANK L/R 3	Left margin/Right margin in (49P - 64P)	the watermark print box	0 - 20	00	120	
	L	BLANK L/R 4	Left margin/Right margin in (65P - 80P)	the watermark print box	0 - 20	00	150	

46-74	
Purpose	Adjustment

**Function (Purpose)** Copy color balance adjustment (Auto adjustment)/Printer color balance adjustment (Auto adjustment)

# Section

### **Operation/Procedure**

This simulation is used to perform SIM46-24 and SIM67-24 continuously.

To perform both the copy color balance adjustment (Automatic adjustment) and the printer color balance adjustment (Automatic adjustment), use this simulation for efficient adjustment operations.

- Press [EXECUTE] key, and the high density process control is performed. Then, the copy color balance adjustment pattern is printed.
- 2) Place the printed adjustment pattern on the document table, select [FACTORY] or [SERVICE] mode.
- 3) Press [EXECUTE] key, and the copy color balance adjustment is performed and the adjustment result pattern is printed.
- 4) Press [EXECUTE] key, and the printer color balance adjustment pattern is printed.
- 5) Place the printed adjustment pattern on the document table, select [FACTORY] or [SERVICE] mode.
- Press [EXECUTE] key, and the printer color balance adjustment (automatic adjustment) is performed and the adjustment result pattern is printed.
- 7) Press [OK] key, and the halftone correction target is registered.
- 8) When [EXECUTE] key is displayed, press it.

When "COMPLETED THIS PROCEDURE" is displayed, the adjustment is completed.

### Important

The adjustment result becomes effective only when the adjustment procedure for both copy and print mode have completed successfully. For example, when the copy color balance adjustment (automatic adjustment) is performed and the simulation is canceled, the adjustment result is not effective.

# 46-90 Purpose Adjustment

**Function (Purpose)** Used to set the process operation of highcompression PDF images.

Section

### **Operation/Procedure**

- 1) Select a target adjustment mode.
- 2) Select an adjustment target item with the scroll key.
- 3) Enter the set value with 10-key.
- 4) Press [OK] key. The set value is saved.

Mode	Item / Display		Content	Setting value	Default value
TEXT	А	GLYPH SENSITIVITY	Text handling selection	0 - 2	0
	В	BG SW FOR FINDLINES	Line handling selection	0 - 1	0
	С	HOR FINDLINES SW	Line detection SW(H)	0 - 2	0
	D	VERT FINDLINES SW	Line detection SW (V)	0 - 2	0
	E	FGCOLOR INDEXING SEL	Text color number adjustment SW	0 - 3	0
	F	FGCOLOR INDEXING ADJ	Text color adjustment	0 - 4	2
COLO R	А	LUMINANCE ADJUSTMENT	Luminance adjustment	0 - 4	2
	В	CHROMA INTENT	Chroma selection	0 - 2	1
	С	NEUTRAL ADJUSTMENT	Neutral adjustment	0 - 2	0
	D	R-RATIO ADJUSTMENT	Gray scale adjustment ®	0 - 1000	299
	Е	G-RATIO ADJUSTMENT	Gray scale adjustment (G)	0 - 1000	587
BG LAYER	А	BG LAYER INTENT 1	Speed priority setting	0 - 2	1
	В	BG LAYER INTENT 2	Image quality priority setting	0 - 2	1
46-91					
--------------------	-----------------------------------------------------------				
Purpose	Adjustment				
Function (Purpose)	Used to adjust the reproduction capability of black text.				
	·				

#### Section Operation/Procedure

- 1) Select an item to be set with the scroll key.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key. The adjustment value is set.

When COLOR key or MONO key is pressed, the adjustment value is set and a copy is made simultaneously.

Item	Display		Content	Description	Setting range	Default value
A	SEGMENT PARAM	COMMON SPECIAL	Area separation setting select	<ol> <li>Other than image send mode black text emphasis (simple, high compression)</li> <li>Image send mode black text emphasis (simple, high compression)</li> </ol>	0 - 1	0
В	B BG: JPEG QUALITY LV [COL: COMPACT]		JPEG recompression level adjustment [Color: High compression mode]	The JPEG compression ratio of the background layer is selected.	0 - 2	1
С	BG: JPEG QUALITY LV [COL: ULTRA FINE]		JPEG recompression level adjustment [Color: Ultra fine mode]	0: Low 1: Middle	0 - 2	1
D	BG: JPEG QUALITY LV [GRY: COMPACT]		JPEG recompression level adjustment [Gray: High compression mode]	2: High	0 - 2	1
E	BG: JPEG QUALITY LV [GRY: ULTRA FINE]		JPEG recompression level adjustment [Gray: Ultra fine mode]		0 - 2	1
F	FG: TARGET AREA	TYPE0	Front ground extraction area select	0: type0	0 - 2	0
		TYPE1		1: type1		
		TYPE2		2: type2		
G	G FG: TEXT DENSITY [COL]		Front ground black text density adjustment [Color]	The black text density in the front ground layer is changed.	0 - 10	5
Н	FG: TEXT DENSITY [GRY]		Front ground black text density adjustment [Gray]	0: Dark - 5: Default - 10: Light	0 - 10	5
I	ULTRA FINE MODE	OFF	High compression/Ultra Fine mode select	0: High compression mode 1: Ultra fine mode	0 - 1	0

NOTE: This must be set to the default unless any change is specially required.

When the adjustment value is changed greatly from the initial value, an image quality trouble may occur.

# 48

48-1	
Purpose	Adjustment
Function (Purpose)	Used to adjust the scan image magnifica-
	tion ratio (in the main scanning direction

and the sub scanning direction).

### Section

#### **Operation/Procedure**

- 1) Select a target adjustment item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.
  - The set value is saved.

When the adjustment value is increased, the image magnification ratio is increased.

A change of "1" in the adjustment value of item A, C, or E corresponds to a change of about 0.02% in the copy magnification ratio. A change of "1" in the adjustment value of item B, D, or F corresponds to a change of about 0.1% in the copy magnification ratio.

#### [RSPF]

I	tem/Display	Content	Setting range	Default value
A	CCD (MAIN)	SCAN main scanning magnification ratio adjustment (CCD)	1 - 99	50
В	CCD (SUB)	SCAN sub scanning magnification ratio adjustment (CCD)	1 - 99	50
С	SPF (MAIN)	RSPF document front surface magnification ratio adjustment (Main scan)	1 - 99	50
D	SPF (SUB)	RSPF document front surface magnification ratio adjustment (Sub scan)	1 - 99	50
E	SPFB (MAIN)	RSPF document back surface magnification ratio adjustment (Main scan)	1 - 99	50
F	SPFB (SUB)	RSPF document back surface magnification ratio adjustment (Sub scan)	1 - 99	50



48-5	
Purpose	Adjustment
Eurotion (Burnasa)	Llood to correction the co

 Function (Purpose)
 Used to correction the scan image magnification ratio (in the sub scanning direction).

Section

Operation/Procedure

1) Select a target adjustment item with scroll key on the touch panel.

Scanner section

- 2) Enter the set value with 10-key.
- 3) Press [OK] key.
- The set value is saved.

When the image magnification ratio in the sub scanning direction is adjusted with SIM48-1, and a different magnification ratio is specified, and the image magnification ratio is not satisfactory, perform this adjustment.

When there is an error in the image magnification ratio in reduction, change the adjustment value in the high speed mode. When there is an error in the image magnification ratio in enlargement, change the adjustment value in the low speed mode.

Item/Display		Content	Setting range	Default value
А	MR (HI)	Scanner motor (High speed)	1 - 99	50
В	MR(MID)	Scanner motor (Reference speed)	1 - 99	50
С	MR(LO)	Scanner motor (Low speed)	1 - 99	50
D	SPF(HI)	Document feed (SPF) motor (High speed)	1 - 99	50
E	SPF(MID)	Document feed (SPF) motor (Reference speed)	1 - 99	50

48-6	
Purpose	Adjustment
Function (Purpose)	Used to adjust the rotation speed of each
	motor.

#### Section

#### **Operation/Procedure**

- 1) Select an adjustment target mode with [COLOR] [MONO] [HEAVY] keys on the touch panel.
- 2) Select a target adjustment item with scroll key on the touch panel.
- 3) Enter the set value with 10-key.
- 4) Press [OK] key.
- The set value is saved.

When the adjustment value is increased, the speed is increased, and vice versa. A change of 1 in the adjustment value corresponds to a change of about 0.1% in the speed.

Mode Select	lte	em/Display	Content	Setting range	Default value
COLOR	А	RRM	Registration motor	1 - 99	51
MONO			correction value		
HEAVY					
COLOR	В	BTM	Belt motor correction	1 - 99	47
MONO			value		
HEAVY					
COLOR	С	DVM_K	Developing K motor	1 - 99	45
MONO			correction value		
HEAVY					
COLOR**	D	FSM	Fusing motor correction value	1 - 99	26/ 31cpm 41 36cpm 40
HEAVY					41
COLOR	Е	DVM_CL	Developing CL motor	1 - 99	45
HEAVY			correction value		

Mode Select	lte	em/Display	Content	Setting range	Default value
COLOR*	F	PFM	Paper transport motor correction value	1 - 99	48
COLOR*	G	POM	Paper exit motor correction value	1 - 99	50
HEAVY	Н	FUSER SETTING	Fusing speed select timing	1 - 99	60
HEAVY	I	RRM START	Registration motor speed increasing start timing	0 - 255	109
HEAVY	J	RRM END	Registration motor speed increasing end timing	0 - 255	210

* Common items for color, monochrome, and heavy paper

** Common items for color and monochrome

The greater the correction value is, the higher the speed is, and vice versa. Change by +/-1 corresponds to 0.1%.

# 49

49-1	
Purpose	
Function (Purpose)	Used to perform the firmware update.
Section	
Operation/Breadure	

#### Operation/Procedure

- 1) Save the firmware to the USB memory.
- 2) Insert the USB memory into the main unit. (Use USB I/F of the operation panel section.)
- 3) Select a target firmware file for update with the touch panel.
- Select a target firmware.
   Press [A] [1] key to select all the
  - Press [ALL] key to select all the Firmware collectively.
- 5) Press [EXECUTE] key.
- 6) Press [YES] key.

The selected firmware is updated. When the operation is normally completed, "COMPLETE" is displayed. When terminated abnormally, "ERROR" is displayed.

Item/Display	Content	Error display in case or
		abnormality
ICUM(MAIN)	ICUM main section	ICUMM
ICUM(SUB)	ICUM sub section	ICUMS
ICUM(OS)	ICUM OS	ICUMO
ICUM(CN)	ICUM CN	ICUMC
ICUM(BOOT)	ICUM boot section	ICUMT
ICUM(BIOS)	ICUM BIOS	ICUMB
ICU (MAIN)	ICU main section	ICUM
ICU(BOOTM)	ICU boot section main	ICUB
ICU(SUB)	ICU sub section(ARM9)	ICUS
LANGUAGE	Language support data program	LANG
SLIST	SLIST data for L-LCD	SLIST
EOSA	embedded OSA	EOSA
PCL(PROFILE)	PCL color profile	PCLP
PCU(BOOT)	PCU boot section	PCUB
PCU(MAIN)	PCU main section	PCUM
DESK(BOOT)	Desk unit boot section	DESKB
DESK(MAIN)	Desk unit main section	DESKM
A4LCC(BOOT)	LCC boot	LCC4B
A4LCC(MAIN)	LCC main	LCC4M
FIN(BOOT)	Inner finisher boot section	FINB
FIN(MAIN)	Inner finisher main section	FINM
1KFIN(BOOT)	Saddle stitch finisher boot	FIN1B
1KFIN(MAIN)	Saddle stitch finisher main	FIN1M
1KPUNCH(BOOT)	Saddle punch unit boot	1PUNB

ltem/Display	Content	Error display in case or abnormality
1KPUNCH(MAIN)	Saddle punch unit main	1PUNM
SCU(BOOT)	SCU boot section	SCUB
SCU(MAIN)	SCU main section	SCUM
FAX(BOOT)	FAX1 boot section	FAXB
FAX(MAIN)	FAX1 main section	FAXM
FAXOPT1(BOOT)	FAX2 boot section	FX01B
FAXOPT1(MAIN)	FAX2 main section	FX01M
FAXOPT2(BOOT)	FAX3 boot section	FX02B
FAXOPT2(MAIN)	FAX3 main section	FX02M
ACRE(BOOT)	Enhanced compression kit boot section	ACREB
ACRE(MAIN)	Enhanced compression kit main section	ACREM
ACRE_DATA	Enhanced compression kit table	ACRED

### 49-3

# Purpose

Function (Purpose) Used to update the operation manual in the HDD.

#### Section

#### **Operation/Procedure**

- 1) Insert the USB memory into the main unit.
  - * When the USB is not inserted, "INSERT A STORANGE E-MANUAL STORED ON" is displayed. When [OK] key is pressed, the display is shifted to the folder select menu 1.
- 2) Press the folder button of the operation manual data. (The display is shifted to the operation manual update menu.) The current version and the update version are displayed.
- 3) Press [EXECUTE] key. [EXECUTE] key is highlighted, and [YES] [NO] keys becomes active from gray out.
- When [YES] key is pressed, the selected operation manual is 4) updated.

When update is completed normally, "COMPLETE" is displayed. When terminated abnormally, "ERROR" is displayed.

49-5	
Purpose	
Function (Purpose)	Used to perform the watermark update.
Section	
<b>Operation/Procedure</b>	

- 1) Insert the USB memory into the main unit.
- 2) Select the button of the folder to perform the watermark update.
- 3) The current version and the update version are displayed.
- 4) Press [EXECUTE] key.
- 5) Press [YES] key.

The selected watermark is updated.

### 49-10

Purpose	
Function (Purpose)	Used to perform the ACU firmware update.
Section	

#### **Operation/Procedure**

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.



50-1						
Purpose	Adjus	tment				
Function (Purpose)	Copy ment	image	position,	image	loss	adjust-
Section						

#### **Operation/Procedure**

- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key. Set the items other than RRCA, LEAD, and SIDE to the default.

RRCA: Image lead edge reference position adjustment LEAD: Lead edge image loss adjustment SIDE: Side image loss adjustment

3) Press [OK] key. (The set value is saved.)

	Item/Dis	splay	Cor	ntent	Setting range	Default value
A	Lead edge adjust-	RRCA	Documen edge refe position (	it lead rence OC)	0 - 99	50
В	ment value	RRCB-CS1	Regis- tration	Standard Tray	1 - 99	60
С		RRCB-DSK	motor	Desk	1 - 99	60
D		RRCB-LCC	ON	LCC	1 - 99	60
E		RRCB-MFT	timing adjust- ment	Manual paper feed	1 - 99	60
F		RRCB-ADU		ADU	1 - 99	60
G	Image loss area	LEAD	Lead edg loss area	e image setting	0 - 99	40
Н	setting value	SIDE	Side imaç area adju	ge loss stment	0 - 99	20
Ι	Void area adjust-	DENA	Lead edg area adju	e void stment	1 - 99	40
J	ment	DENB	Rear edg area adju	e void stment	1 - 99	30
к		FRONT/ REAR	FRONT/F area adju	REAR void stment	1 - 99	20
L	Off-center adjust- ment	OFFSET_ OC	OC docur center ad	ment off- justment	1 - 99	50
М	Magnificat ion ratio correc- tion	SCAN_ SPEED_ OC	SCAN sul magnifica adjustme	o scanning ition ratio nt (CCD)	1 - 99	50
N	Sub scanning	DENB-MFT	Manual fe correction	ed value	1 - 99	50
0	direction print area	DENB-CS1	Tray 1 co value	rrection	1 - 99	50
Ρ	correction value	DENB-CS2	Tray 2 co value	rrection	1 - 99	50
Q		DENB-CS3	Tray 3 correction value		1 - 99	50
R		DENB-CS4	Tray 4 correction value		1 - 99	50
S		DENB-LCC	LCC correction value		1 - 99	50
Т		DENB-ADU	ADU corr value	ection	1 - 99	50
U		DENB-HV	Heavy pa correction	per value	1 - 99	50

A. (RRC-A) Timing from starting document scanning to specifying the image lead edge reference is adjusted. (01.mm/step)

* When the value is decreased, the timing is advanced. When the value is increased, the timing is delayed.

- B F. (RRC-B) Timing of paper (registration roller ON) for the image position on the transfer belt is adjusted. (0.1mm/step)
  - * When the value is decreased, the timing is delayed. When the value is increased, the timing is advanced.
- G. (LEAD) The lead edge image loss amount is adjusted. (0.1mm/ step)
- * When the value is increased, the image loss is increased.
- H. (SIDE) The side image loss amount is adjusted.
- * When the value is increased, the image loss is increased. (0.1mm/step)
- I. (DEN-A) The paper lead edge void amount is adjusted. (0.1mm/ step)
- * When the value is increased, the void is increased.
- J. (DEN-B) The paper rear edge void amount is adjusted. (0.1mm/ step)
  - * When the value is increased, the void is increased.
- K. (FRONT/REAR) The void amount on the right and left edges of paper is adjusted. (0.1mm/step)

50-5	
Purpose	Adjustment
Function (Purpose)	Used to adjust the print lead edge image
	position. (PRINTER MODE)

### Section

#### **Operation/Procedure**

- 1) Select a target adjustment item (DEN-C) with scroll key on the touch panel.
- 2) Enter the adjustment value using the 10-key.
- 3) Press [EXECUTE] key.

The set value is saved, and the adjustment check pattern is printed.

 Measure the distance from the paper lead edge the adjustment pattern to the image lead edge, and check to confirm that it is in the standard adjustment value range.

Standard reference value: 4.0±2.0mm

When the adjustment value is increased, the distance from the paper lead edge to the image lead edge is increased. When the adjustment value is decreased, the distanced is decreased.

When the set value is changed by 1, the distance is changed by about  $0.1 \,\mathrm{mm}$ .

Item/Display		ay	Content		Settin range	ig e	Default value	NOTE
A	DEN-C		Used to adjust the print lead edge image position. (PRINTER MODE)		1 - 99	9	30	Adjustment value too align the print lead edge for the printer. When the adjustment value of this item is decreased by 1, the printer print start position in the paper transport direction is shifted to the lead edge by 0.1mm.
В	DEN-B	Rear edge void area adjustment		Rear edge void area adjustment		9	30	Void amount generated at the paper rear edge. When the adjustment value of item B (DEN-B) is decreased by 1, the print area adjustment value in the sub scanning direction for the paper transport direction is decreased by 0.1mm.
С	C FRONT/REAR FRONT/REAR void area adjustment		a adjustment	1 - 99		20	Adjustment of the void amount generated on the left and right edges of paper. When the adjustment value is increased, the void amount is increased.	
D	DENB-MF1	Г	Manual feed rear edge correction value	void area adjustment	1 - 99	9	50	Fine adjustment value of each paper feed source for the adjustment value of DEN-B
Е	E DENB-CS1 Tray 1 rear edge void area adjustr correction value		rea adjustment	1 - 99	Э	50		
F	DENB-CS2 Tray 2 rear edge void area adjustment correction value		1 - 99	Э	50			
G	DENB-CS3	CS3 Tray 3 rear edge void area adjustment correction value		1 - 99	Э	50		
н	DENB-CS4 Tray 4 rear edge void area adjustment correction value		1 - 99	Э	50			
I	DENB-LCC LCC rear edge void aria adjustment correction value		a adjustment	1 - 99	9	50		
J	DENB-ADU	J	ADU rear edge void aria correction value	a adjustment	1 - 99	9	55	
К	DENB-HV		Heavy paper correction	n value	1 - 99	9	50	
L	MULTI CO	UNT	Number of print		1 - 99	9	1	Adjustment pattern print conditions setting
М	PAPER	MFT	Tray selection	Manual paper feed	1 - 6	1	2 (CS1)	
		CS1		Tray 1		2		
		CS2		Tray 2		3		
		CS3		Tray 3		4		
		CS4		Tray 4		5		
		LCC	Dualau ariat a da "	LCC	0.4	6	4 (NO)	
IN	DUPLEX	IES NO	Duplex print selection	No	0 - 1	1	1 (NU)	

When the adjustment value is increased, the distance from the paper lead edge to the image lead edge is increased. When the adjustment value is decreased, the distance from the paper lead edge to the image lead edge is decreased.

When the set value is changed by 1, the distance is changed by about 0.1mm.

50-6	
Purpose	Adjustment
Function (Purpose)	Used to adjust the copy image position and the image loss. (RSPF mode)
Section	RSPF

- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key. (The set value is saved.)

### [RSPF]

Item/Display			Content	Setting	Default
Δ	SIDE1		Front surface	1 _ 00	50
~	0.521		document scan	1 00	00
			position		
			adjustment (CCD)		
В	SIDE2		Back surface	1 - 99	50
			document scan		
			position		
		r	adjustment (CCD)		
С	Image	LEAD_EDGE	Front surface lead	0 - 99	20
	loss (SIDE1)		edge image loss		
	amount		amount setting		
	setting				
5	SIDET		Frank surface side	0 00	00
U	Image	(SIDE1)	image loss amount	0 - 99	20
	amount	(SIDE I)	setting		
F	setting	TRAIL EDGE	Front surface rear	0 - 99	40
-	SIDE1	(SIDE1)	edge image loss	0 00	10
	(0.22.)		amount setting		
F	Image	LEAD_EDGE	Back surface lead	0 - 99	20
	loss	(SIDE2)	edge image loss		
	amount		amount setting		
G	setting	FRONT_REAR	Back surface side	0 - 99	20
	SIDE2	(SIDE2)	image loss amount		
			setting		
н		TRAIL_EDGE	Back surface rear	0 - 99	40
		(SIDE2)	edge image loss		
	OFOFT		amount setting	4 00	50
1	UFSET_	5771	document off	1 - 99	50
			center adjustment		
J	OESET 3	SPF2	SPE back surface	1 - 99	50
0	01021_	0112	document off-	1 00	00
			center adjustment		
Κ	SCAN_SPEED_SPF1		RSPF document	1 - 99	50
			front surface		
			magnification ratio		
			(Sub scan)		
L	SCAN_S	PEED_SPF2	RSPF document	1 - 99	50
			back surface		
			magnification ratio		
			(Sub scan)		

Item A, B: When the adjustment value is increased, the scan timing is delayed.

Item C - H: When the adjustment value is increased, the image loss is increased.

Item E - H: When a shadow image appears on the rear edge, increase the adjustment value to delete the shadow.

All adjustment items: 1 step = 0.1mm change

50-10	
Purpose	Adjustment
Function (Purpose)	Used to adjust the black print image magni- fication ratio and the off-center position. (The adjustment is made separately for each paper feed section.)
Section	

#### Section Operation/Procedure

1) Select an adjustment target item with scroll key on the touch panel.

- 2) Enter the set value with 10-key.
- 3) Press [EXECUTE] key. (The set value is saved.)

	Item/Dis	play	Content		Setting r	ange	Default value	NOTE
Α	BK-MAG		Main scan print magnification ratio Bl	<	60 - 14	40	110	Adjustment Item List
В	MAIN-MFT		Print off center adjustment value (Ma	nual paper feed)	1 - 9	9	50	
С	MAIN-CS1		Print off center adjustment value (Tra	y 1)	1 - 99		52	
D	MAIN-CS2		Print off center adjustment value (Tra	Print off center adjustment value (Tray 2)		9	52	
Е	MAIN-CS3		Print off center adjustment value (Tra	y 3)	1 - 9	9	52	
F	MAIN-CS4		Print off center adjustment value (Tra	y 4)	1 - 9	9	52	
G	MAIN-LCC		Print off center adjustment value (Lar	ge capacity tray)	1 - 9	9	52	
Н	H MAIN-ADU Print off center adjustment value (Duplex)		1 - 9	9	42	Adjustment Item List		
	Important		Important					
		If the adjustment items A G are not preparly adjusted, this						
			adjustment cannot be executed property adjusted, this					
1	SUB-MET		Registration motor ON timing	Manual paper feed	1 - 99		60	
	SUB-CS1		adjustment	Standard cassette	1 - 99		60	-
ĸ	SUB-DSK			DESK	1 - 9	9	60	
L	SUB-LCC			LCC	1 - 9	9	60	
M	SUB-ADU			ADU	1 - 9	9	60	
Ν	MULTI COU	INT	Number of print		1 - 99	9	1	Adjustment pattern print
0	PAPER	MFT	Tray selection	Manual paper feed	1 - 6	1	2 (CS1)	conditions setting
		CS1		Tray 1		2		
		CS2		Tray 2		3		
		CS3		Tray 3		4		
		CS4	]	Tray 4		5	]	
		LCC	]	LCC		6		
Ρ	DUPLEX	YES	Duplex print selection	Yes	0 - 1	0	1 (NO)	
		NO	]	No	]	1		

Item A: When the set value is increased, the BK image magnification ratio in the main scanning direction is increased. When the set value is decreased, the image magnification ratio is decreased.

Item B - H: When the adjustment value is increased, it is shifted to the front frame side. When the adjustment value is decreased, it is shifted to the rear frame side.

All adjustment items: 1 step = 0.1mm change

50-12	
Purpose	Adjustment
Function (Purpose)	Used to perform the scan image off-center
	position adjustment. (The adjustment is
	made separately for each scan mode.)

#### Section

#### **Operation/Procedure**

- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key. (The set value is saved.)

When the adjustment value is increased, the image position is shifted to the rear frame side. When the adjustment value is decreased, it is shifted to the front frame side.

1step = 0.1mm

Item/Display		Content	Setting range	Default value
A	OC	Document table image off- center adjustment	1 - 99	50
В	SPF (SIDE1)	SPF front surface image off- center adjustment	1 - 99	50
С	SPF (SIDE2)	SPF back surface image off- center adjustment	1 - 99	50

50-20	
Purpose	Adjustment
Function (Purpose)	Image registration adjustment (Main scan- ning direction)
Section	

- **Operation/Procedure**
- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [EXECUTE] key. (The set value is saved.)

Item/Display			Content			ng je	Default value
Α	CYAN(FROM	NT)	Registration adjustment value main scanning direction CYAN F s	side	1 - 1	99	100
В	CYAN(REAF	R)	Registration adjustment value main scanning direction CYAN R s	side	1 - 1	99	100
С	MAGENTA(FRONT) Registration adjustment value main scanning direction MAGENTA F side						100
D	MAGENTA(F	REAR)	Registration adjustment value main scanning direction MAGENT	A R side	1 - 1	99	100
Е	YELLOW(FF	RONT)	Registration adjustment value main scanning direction YELLOW	F side	1 - 1	99	100
F	YELLOW(RE	EAR)	Registration adjustment value main scanning direction YELLOW	R side	1 - 1	99	100
G	CYAN(SUB)		Registration adjustment value sub scanning direction CYAN (Bla	ck drum reference)	1 - 1	99	100
н	MAGENTA(S	SUB)	Registration adjustment value sub scanning direction MAGENTA	(Black drum reference)	1 - 1	99	100
Ι	YELLOW(SU	JB)	Registration adjustment value sub scanning direction YELLOW (	Black drum reference)	1 - 1	99	100
J	OFFSET_C	F	Registration adjustment value main scanning direction offset value	ue CYAN (FRONT)	1 - 9	99	50
К	OFFSET_C	R	Registration adjustment value main scanning direction offset value CYAN (REAR)			99	50
L	OFFSET_M	_F	Registration adjustment value main scanning direction offset value MAGENTA (FRONT)			99	50
М	OFFSET_M	_R	Registration adjustment value main scanning direction offset value MAGENTA (REAR)			99	50
Ν	OFFSET_Y_	F	Registration adjustment value main scanning direction offset value YELLOW (FRONT)			99	50
0	OFFSET_Y_	R	Registration adjustment value main scanning direction offset value YELLOW (REAR)			99	50
Ρ	OFFSET_C	S	Registration adjustment value sub scanning direction offset value CYAN			99	50
Q	OFFSET_M	_S	Registration adjustment value sub scanning direction offset value MAGENTA		1 - 99		47
R	OFFSET_Y_	S	Registration adjustment value sub scanning direction offset value	lue sub scanning direction offset value YELLOW		99	48
S	MULTICOUN	NT	Number of print		1 - 9	99	1
Т	PAPER	MFT	Tray selection	Manual paper feed	1 - 6	1	2 (CS1)
		CS1	· · · · · · · · · · · · · · · · · · ·	Tray 1		2	
		CS2	· · · · · · · · · · · · · · · · · · ·	Tray 2		3	
		CS3	· · · · · · · · · · · · · · · · · · ·	Tray 3		4	
		CS4		Tray 4		5	
		LCC		LCC		6	
U	DUPLEX	YES	Duplex print selection	Yes	0 - 1	0	1 (NO)
		NO		No		1	

50-22	
Purpose	Adjustmen

Function (Purpose)

Used to adjust the image registration. (Main scan direction, sub scan direction) (Auto adjustment)/OPC drum phase adjustment (Auto adjustment)

#### Section

### Operation/Procedure

- 1) Press [EXECUTE] key.
  - The adjustment is automatically performed, and the adjustment data are displayed.

## Note

The contents of the following list are mainly used by the technical division, and are not necessary for the market.

Item/Display			Content	Setting range (unit)	Color/ History	Default value	NOTE	
MAIN F	-	REG_M_F (VALUE)	Registration adjustment correction amount main scanning direction F	1.0 - 199.0 (±0.1)	CMY/-	100		
	()	REG_M_F (DIF)	Registration value correction amount from the previous one, main scanning F	-199.0 - 199.0 (±0.1)	CMY/-	0		
MAIN R	-	REG_M_R (VALUE)	Registration adjustment correction value, main scanning direction R	1.0 - 199.0 (±0.1)	CMY/-	100		
	()	REG_M_R (DIF)	Registration value correction amount from the previous one, main scanning R	-199.0 - 199.0 (±0.1)	CMY/-	0		
SUB	-	REG_SUB (VALUE)	Registration adjustment correction value, sub scanning direction	1.0 - 199.0 (±0.1)	CMY/-	100		
	()	REG_SUB (DIF)	Registration value correction amount from the previous one, sub scanning	-199.0 - 199.0 (±0.1)	CMY/-	0		
SKEW	СМҮ	SKEW_CLC	SKEW adjustment rotating direction and the number of clicks (CMY)	L99.9 - R99.9 (±0.1)	KCMY/-	0	If the value is plus, L is displayed to left side of numerical value. If the value is minus, R is displayed to left side of numerical value. When the value is -2.1 - +2.1, "(OK)" is place at the back of the value. For the other cases, "(NG)" is displayed. *1	
	ALL_ ROTATE		SKEW adjustment rotating direction and the number of clicks (K)				If the value is plus, L is displayed to left side of numerical value. If the value is minus, R is displayed to left side of numerical value. When the value is -1.6 - +1.6, "(OK)" is place at the back of the value. For the other cases, "(NG)" is displayed. *2	
PHASE		PHASE_ADJ	Phase adjustment value (1: Value of this time, 2: Value of the previous time) Angle step 0° (1) $\rightarrow$ 45° (2) $\rightarrow$ 90° (3) $\rightarrow$ 135° (4) $\rightarrow$ 180° (5) $\rightarrow$ 225° (6) $\rightarrow$ 270° (7) $\rightarrow$ 315° (8)	1 - 8 (±1)	-/2	1	-	

*1: The color image skew adjustment is performed according to this display value.

When "R" is displayed in front of the value, turn and click the skew adjustment screw (LSU) clockwise by the value.

When "L" is displayed in front of the value, turn and click the skew adjustment screw (LSU) counterclockwise by the value.

*2: The color image skew adjustment is performed according to this display value.

When "R" is displayed at the head of the value, turn the skew adjustment screw (LSU) clockwise by the number of the value.

When "L" is displayed at the head of the value, turn the skew adjustment screw (LSU) counterclockwise by the number of the value.

At that time, the values under the decimal point are rounded.

#### Error displays in case of abnormal end

	Error code	Error display	Error content	Description
Forcible end error	e end error - SUSPENDED		Door open end	Door open during operation
	-	SUSPENDED	CA end	CA button pressed during operation
	-	-	OFF end	Unconfirmed operation during operation (Power OFF)

	Error code	Error display	Error content	Description
Basic error	1	TONNER EMPTY	Toner Empty	BK or ALL Color toner EMPTY detection
	2	BEFOR BEHAVIOR	Other condition	Other condition
	4	SENSOR CALIBLATION F	Calibration error F	The target is not reached by 3 times of retry of F or R
	5	SENSOR CALIBLATION R	Calibration error R	
	6	SENSOR CALIBLATION FR	Calibration error FR	
	7	TIME OVER	Time error	No data are obtained for 90sec from data acquisition
	8	PROCESS CONTROL	Process control error	Process control error detection
Sub scanning	10 - 47	SUB XXX XXXX XXX		
adjustment error				
Main scanning	50 - 88	MAIN XXX XXXX XXX		
adjustment error				
Others	99	OTHER 99	Other errors	Other errors

50-24	
Purpose	(This simulation is normally not used in the
	market.)
Function (Purpose)	Used to display the detail data of SIM 44-2,
	50-20 and 22.

Section

**Operation/Procedure** 

### Note

This simulation is mainly used by the technical division, and is not necessary for the market.

50-27	
Purpose	Adjustment
Function (Purpose)	Used to perform the image loss adjustment of scanned images in the FAX or image send mode.
Section	

### Operation/Procedure

- 1) Select a target adjustment mode with [FAX] or [SCANNER] key.
- 2) Select an adjustment target item with scroll key on the touch panel.
- 3) Enter the set value with 10-key.
- 4) Press [OK] key. (The set value is saved.)

#### [RSPF]

		Item/Display	,	Content	Setting range	Default value
FAX send	A Image loss		LEAD_EDGE (OC)	OC lead edge image loss amount setting	0 - 100	30 (3mm)
	В	amount setting OC	FRONT_REAR (OC)	OC side image loss amount setting	0 - 100	20 (2mm)
	С		TRAIL_EDGE (OC)	OC rear edge image loss amount setting	0 - 100	20 (2mm)
[		Image loss amount setting	LEAD_EDGE (SPF_SIDE1)	Front surface lead edge image loss amount setting	0 - 100	20 (2mm)
	Е	SPF SIDE1	FRONT_REAR (SPF_SIDE1)	Front surface side image loss amount setting	0 - 100	20 (2mm)
	F		TRAIL_EDGE (SPF_SIDE1)	Front surface rear edge image loss amount setting	0 - 100	30 (3mm)
	G	Image loss amount setting	LEAD_EDGE (SPF_SIDE2)	Back surface lead edge image loss amount setting	0 - 100	20 (2mm)
	Н	SPF SIDE2	FRONT_REAR (SPF_SIDE2)	Back surface side image loss amount setting	0 - 100	20 (2mm)
	Ι		TRAIL_EDGE (SPF_SIDE2)	Back surface rear edge image loss amount setting	0 - 100	30 (3mm)

		Item/Display	,	Content	Setting range	Default value
When image send	Α	Image loss	LEAD_EDGE (OC)	OC lead edge image loss amount setting	0 - 100	0 (0mm)
mode (Except for	В	amount setting OC	FRONT_REAR(OC)	OC side image loss amount setting	0 - 100	0 (0mm)
FAX and copy)	С		TRAIL_EDGE(OC)	OC rear edge image loss amount setting	0 - 100	0 (0mm)
	D	Image loss amount setting	LEAD_EDGE (SPF_SIDE1)	Front surface lead edge image loss amount setting	0 - 100	0 (0mm)
	Е	SPF SIDE1	FRONT_REAR (SPF_SIDE1)	Front surface side image loss amount setting	0 - 100	0 (0mm)
	F		TRAIL_EDGE(SPF_SIDE1)	Front surface rear edge image loss amount setting	0 - 100	0 (0mm)
	G	Image loss amount setting	LEAD_EDGE (SPF_SIDE2)	Back surface lead edge image loss amount setting	0 - 100	0 (0mm)
ł		SPF SIDE2	FRONT_REAR (SPF_SIDE2)	Back surface side image loss amount setting	0 - 100	0 (0mm)
	I		TRAIL_EDGE(SPF_SIDE2)	Back surface rear edge image loss amount setting	0 - 100	0 (0mm)

A-I: When the adjustment value is increased, the image loss is increased.

1step = 0.1mm

50-28	
Purpose	Adjustment
Function (Purpose)	Used to automatically adjust the image
	loss, void area, image off-center, and image magnification ratio.

### Section

#### **Operation/Procedure**

The following adjustment items can be executed automatically with SIM50-28.

- * ADJ16 Print image position, image magnification ratio, void area, off-center adjustments (Manual adjustments)
- * ADJ 17 Scan image magnification ratio adjustment (Manual adjustment)
- * ADJ 18 Scan image off-center adjustment (Manual adjustment)
- * ADJ 19 Used to adjust the copy image position and the image loss (Manual adjustments)
- 1) Select an adjustment item with the menu button.
- 2) Press [EXECUTE] key, and the adjustment pattern is printed.
- 3) Set the adjustment pattern on the document table.
- 4) Press [EXECUTE] key, and the adjustment pattern is scanned.

#### 5) Press [OK] key.

Item/Dis	splay	Con	Section	
OC ADJ	MFT	Document lead	Image loss off-	Scanner
	CS1	edge	center sub scanning	
	CS2		direction image	
	ADU	Document off-	magnification ratio	
	CS3	center	adjustment	
	CS4	Sub scanning	(Document table	
	LCC	magnification ratio	mode)	

	ltem/I	Display		Con	tent	Section
SPF ADJ (RSPF)	ALL	SIDE1 (Front surface) SIDE2 (Back surface)	MFT CS1 CS2 ADU CS3 CS4 LCC	Document lead edge Document off-center Sub scanning magnifica- tion ratio Document lead edge Document off-center Sub scanning magnifica- tion ratio	Image loss off-center sub scanning direction image magnifica- tion ratio adjustment (RSPF mode)	Scanner

	ltem/l	Display		Co	ontent	Section
SETUP/	ALL	LEAD	MFT	Print off	Print lead	Engine
PRINT			CS1	center	edge	
ADJ			CS2	Print lead	adjustment,	
		OFFSET	ADU	edge	image off-	
			CS3		center	
			CS4		(each paper	
			LCC		dupley	
					mode)	
					adjustment	

Item/Display		Cor	itent	Section
BK-MAG	MFT	BK main scanning	Main scanning	Engine
ADJ	CS1	magnification ratio	direction image	
	CS2		magnification ratio	
	ADU		adjustment	
	CS3			
	CS4			
	LCC			

RESULT	Adjustment result display
DATA	Adjustment operation data display

# 51

51-1	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the ON/OFF timing of the
	secondary transport voltage.

### Section

#### **Operation/Procedure**

- 1) Select an adjustment target item with scroll key on the touch panel.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key. (The set value is saved.)

When the adjustment value is decreased, the transfer ON/OFF timing for the paper is advanced. When the adjustment value is increased, the timing is delayed.

When the adjustment value is changed by 1, the timing is changed by about 10ms. The setting range is -490 - +490ms.

	Item/Display	Content	Default value
A	TC2 ON TIMING	Secondary transfer voltage ON timing setting	50
В	TC2 OFF TIMING	Secondary transfer voltage OFF timing setting	60



51-2	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the contact pressure (deflec-
	tion amount) on paper by the main unit and
	the RSPF registration roller. (This adjust-
	ment is performed when there is a consid-
	erable variation in the print image position
	on the paper or when paper jams frequently

#### Section

**Operation/Procedure** 

1) (When RSPF model)

Select a target adjustment mode with [SIDE1] or [SIDE2] or [ENGINE] keys.

2) Select a target item to be adjusted with scroll keys.

occur.)

- 3) Enter the set value with 10-key.
- 4) Press [OK] key. (The set value is saved.)

#### [RSPF]

Mode		Display/Ite	Content		Setting range	26cpm/ 31cpm	36cpm
SIDE1	A	NORMAL_PLAIN_HIGH	RSPF front surface document deflection amount adjustment value (Normal/Plain paper/HIGH)	-	1 - 99	50	50
	В	NORMAL_PLAIN_LOW	RSPF front surface document deflection amount adjustment value (Normal/Plain paper/LOW)	-	1 - 99	50	50
	С	NORMAL_THIN _HIGH	RSPF front surface document deflection amount adjustment value (Normal/Thin paper/HIGH)	-	1 - 99	50	50
	D	NORMAL_THIN _LOW	RSPF front surface document deflection amount adjustment value (Normal/Thin paper/LOW)	-	1 - 99	50	50
	Е	RANDOM_PLAIN_HIGH	RSPF front surface document deflection amount adjustment value (Random/Plain paper/HIGH)	-	1 - 99	50	50
	F	RANDOM_PLAIN _LOW	RSPF front surface document deflection amount adjustment value (Random/Plain paper/LOW)	-	1 - 99	50	50
	G	RANDOM_THIN_HIGH	RSPF front surface document deflection amount adjustment value (Random/Thin paper/HIGH)	-	1 - 99	50	50
	н	RANDOM_THIN_LOW	RSPF front surface document deflection amount adjustment value (Random/Thin paper/LOW)	-	1 - 99	50	50
SIDE2	A	NORMAL_PLAIN_ HIGH_1	RSPF back surface document deflection amount adjustment value 1 (Normal/Plain paper/HIGH)	-	1 - 99	50	50
	В	NORMAL_PLAIN_ LOW_1	RSPF back surface document deflection amount adjustment value 1 (Normal/Plain paper/LOW)	-	1 - 99	50	50
ENGINE	A	TRAY1(S)	Main unit cassette 1 (Upper stage)/deflection adjustment value (Plain paper/Small size)	LT size (216mm) or less	1 - 99	20	20
	В	TRAY1(L)	Main unit cassette 1 (Upper stage)/deflection adjustment value (Plain paper/Large size)	LT size (216mm) or above	1 - 99	20	20
	С	TRAY1 HEAVY PAPER (S)	Main unit cassette 1 (Upper stage)/deflection adjustment value (Heavy paper/Small size)	LT size (216mm) or less	1 - 99	10	2
	D	TRAY1 HEAVY PAPER (L)	Main unit cassette 1 (Upper stage)/deflection adjustment value (Heavy paper/Large size)	LT size (216mm) or above	1 - 99	10	2
	Е	TRAY2(S)	Main unit cassette 2 (Lower stage)/deflection adjustment value (Plain paper/Small size)	LT size (216mm) or less	1 - 99	20	20
	F	TRAY2(L)	Main unit cassette 2 (Lower stage)/deflection adjustment value (Plain paper/Large size)	LT size (216mm) or above	1 - 99	20	20
	G	TRAY2 HEAVY PAPER (S)	Main unit cassette 2 (Upper stage)/deflection adjustment value (Heavy paper/Small size)	LT size (216mm) or less	1 - 99	10	2
	н	TRAY2 HEAVY PAPER (L)	Main unit cassette 2 (Upper stage)/deflection adjustment value (Heavy paper/Large size)	LT size (216mm) or above	1 - 99	10	2
	I	MANUAL PLAIN PAPER (S)	Manual feed tray/deflection adjustment value (Plain paper/Small size)	LT size (216mm) or less	1 - 99	20	20
	J	MANUAL PLAIN PAPER (L)	Manual feed tray/deflection adjustment value (Plain paper/Large size)	LT size (216mm) or above	1 - 99	20	20
	К	MANUAL HEAVY PAPER (S)	Manual feed tray/deflection adjustment value (Heavy paper/Small size)	LT size (216mm) or less	1 - 99	10	2



:	'14/Jun	

Mode		Display/Ite	Content		Setting range	26cpm/ 31cpm	36cpm
ENGINE	L	MANUAL HEAVY PAPER	Manual feed tray/deflection adjustment value	LT size (216mm)	1 - 99	10	2
		(L)	(Heavy paper/Large size)	or above			
	Μ	MANUAL HEAVY B	Manual feed tray/deflection adjustment value	LT size (216mm)	1 - 99	10	2
		PAPER(S)	(Heavy paperB/Small size)	or less			
	Ν	MANUAL HEAVY B	Manual feed tray/deflection adjustment value	LT size (216mm)	1 - 99	10	2
		PAPER (L)	(Heavy paperN/Large size)	or above			
	0	MANUAL OHP	Manual feed tray/deflection adjustment value (OHP)	-	1 - 99	10	2
	Р	MANUAL ENV	Manual feed tray/deflection adjustment value	-	1 - 99	10	2
			(Envelop)				
	Q	ADU PLAIN PAPER (S)	ADU/deflection adjustment value	LT size (216mm)	1 - 99	20	20
			(Plain paper/Small size)	or less			
	R	ADU HEAVY PAPER (L)	ADU/deflection adjustment value	LT size (216mm)	1 - 99	20	20
			(Heavy paper/Large size)	or above			
	S	ADU HEAVY A PAPER	ADU/deflection adjustment value	LT size (216mm)	1 - 99	10	2
		(S)	(Heavy paper A/Small size)	or less			
	Т	ADU HEAVY A PAPER	ADU/deflection adjustment value	LT size (216mm)	1 - 99	10	2
		(L)	(Heavy paper A/Large size)	or above			
	U	DESK (S)	DESK/deflection adjustment value	LT size (216mm)	1 - 99	20	20
			(Plain paper/Small size)	or less			
	V	DESK (L)	DESK/deflection adjustment value	LT size (216mm)	1 - 99	20	20
			(Plain paper/Large size)	or above			
	W	DESK HEAVY PAPER	DESK/deflection adjustment value	LT size (216mm)	1 - 99	10	2
		(S)	(Heavy paper/Small size)	or less			
	Х	DESK HEAVY PAPER	DESK/deflection adjustment value	LT size (216mm)	1 - 99	10	2
		(L)	(Heavy paper/Large size)	or above			
	Y	A4LCC	A4LCC/deflection adjustment value	-	1 - 99	20	20

#### Note on "Large size" and "Small size"

Small size: The paper length in the transport direction is shorter than the LT size (216mm).

Large size: The paper length in the transport direction is longer than the LT size (216mm).

#### Adjustment value

When the adjustment value is increased, the warp amount is increased. When the adjustment value is decreased, the warp amount is decreased.

(When the adjustment value is changed by 1, the stop timing is changed by 0.1mm.)



53-6	
Purpose	Adjustment
Function (Purpose)	Used to adjust the detection level of the
	RSPF document width.

### Section

#### **Operation/Procedure**

- 1) Open the RSPF paper feed guide to the maximum width.
- 2) Press [EXECUTE] key. The maximum width detection level is recognized.
- 3) Open the RSPF paper feed guide to the A4R width.
- 4) Press [EXECUTE] key. The A4R width detection level is recognized.
- 5) Open the RSPF paper feed guide to the A5R width.
- 6) Press [EXECUTE] key.
- The A5R width detection level is recognized.
- 7) Open the RSPF paper feed guide to the minimum width.
- 8) Press [EXECUTE] key.
  - The minimum width detection level is recognized.

When the above operation is nor performed normally, "ERROR" is displayed and. When the above operation is completed normally, "COMPLETE" is displayed.

1	TRAYVOLMAX	Tray size volume maximum value
2	TRAYVOLA4R	Tray volume A4R size adjustment value
3	TRAYVOLA5R	Tray volume A5R size adjustment value
4	TRAYVOLMIN	Tray size volume minimum value

53-7	
Purpose	Adjustment/Setup
Function (Purpose)	Used to adjust the RSPF document size
	width sensor.

#### Section **Operation/Procedure**

- 1) Select an adjustment target item with scroll key on the touch
  - panel.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key. (The set value is saved.)

#### [RSPF]

Item/Display			Setting range	Default value
А	AD_MAX	Max. width position	0 - 1023	84
В	AD_P1	A4R width position	0 - 1023	509
С	AD_P2	A5R width position	0 - 1023	808
D	AD_MIN	Min. width position	0 - 1023	961

#### 53-8

Purpose	Adjustment
	,

Function (Purpose) Use

Used to adjust the document lead edge reference and the RSPF mode document scan position.

# Section

**Operation/Procedure** Select an adjustment item with [AUTO] [MANUAL] key.

<AUTO: Document lead edge reference (RRCA) adjustment>(Auto adjustment)

- 1) Set a sheet of black paper of A4 or 11"x 8.5" on the document table.
- 2) Press [EXECUTE] key. (The adjustment is performed and the adjustment value is saved.)

Item/Display	Content	Setting range	Default value
MEASUREMENT	Document lead edge	0-255	-
DISTANCE	measurement distance	(0.1mm unit)	
RRCA	Document lead edge reference position	0 - 99	50

<MANUAL: RSPF mode document scan position adjustment>

- 1) Enter the set value with 10-key.
- 2) Press [OK] key. (The set value is saved.)

lt	em/Display	Content	Setting range	Default value
А	ADJUST	RSPF mode document scan	1 - 99	5
	VALUE	position adjustment (Scanner		
		stop position adjustment)		

- When the adjustment value is increased, the scanner stop position in the RSPF mode is shifted to the right.
- When the adjustment value is changed by 1, the position is shifted by 0.1mm.

53-9	
Purpose	Adjustment
Function (Purpose)	Used to set dirt detection for RSPF scan- ning position.
Section	

- 1) Select an items to be set with scroll key.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key. (The set value is saved.)

	Item/Display		Content		Settin rang	ig e	Default value
Α	SIDEA_SCAN_POSITION_SET_START	OFF	RSPF front surface optimum scan position detection	OFF	0 to 1	0	1
		ON	setting (When starting)	ON		1	(ON)
В	SIDEA_SCAN_POSITION_SET_JOB	OFF	RSPF front surface optimum scan position detection	OFF	0 to 1	0	1
		ON	setting (After a job)	ON		1	(ON)
С	SIDEA_SCAN_POSITION_LV	WEAK	RSPF front surface optimum scan position detection	Low	0 to 2	0	1
		MIDDLE	level setting	Medium		1	(MIDDLE)
		STRONG		High		2	
D	OC_DIRT_LV	WEAK	OC dirt level setting	Low	0 to 2	0	1
		MIDDLE		Medium		1	(MIDDLE)
		STRONG		High		2	
Е	SIDEA_DIRT_ALARM_LV	WEAK	RSPF front surface dirt alarm level setting	Low	0 to 2	0	1
		MIDDLE		Medium		1	(MIDDLE)
		STRONG		High		2	
F	SIDEA_DIRT_SHADING_SET	OFF	RSPF front surface streak delete shading setting	OFF	0 to 1	0	1
		ON		ON		1	(ON)
G	SCAN_POSITION_PRIORITY_SET	MVIEW	SPF front surface MVIEW/SCU priority setting (Optimum	MVIEW	0 - 1	0	0
		SCU	scan position)	SCU		1	(MVIEW)
н	DIRT_ALARM_PRIORITY_SET	MVIEW	RSPF MVIEW/SCU prioity.	MVIEW	0 - 1	0	0
		SCU		SCU		1	(MVIEW)

### 53-10

00.0	
Purpose	Adjustment/Setup
Function (Purpose)	RSPF dirt detection execution.
Section	

#### **Operation/Procedure**

1) Press [EXECUTE] key.

Item	Content
SPF SIDEA	RSPF front surface dirt detection position (main scan position 1 to 8) "-": No dirt, A"*": Dirt
OC	OC surface dirt detection position (main scan position 1 to 8) "-": No dirt, "*": Dirt

# 55

55-1	
Purpose	(Do not use this function unless specially required.)
Function (Purpose)	Used to set the specifications of the engine control operations. (SOFT SW)
Section	
<b>Operation/Procedure</b>	

55-2	
Purpose	(Do not use this function unless specially required.)
Function (Purpose)	Used to set the specifications of the scan- ner control operation. (SOFT SW)
Section	
Operation/Procedure	

55-3	
Purpose	(Do not use this function unless specially required.)
Function (Purpose)	Used to set the specifications of the control- ler operation. (SOFT SW)
Section	

**Operation/Procedure** 

55-10	
Purpose	Adjustment/Setting
Function (Purpose)	Used to set the special stamp text. (Taiwan
	only)
Section	

#### **Operation/Procedure**

- 1) Select an item to be set (digit, color, type) with the scroll key.
- 2) Enter the value corresponding to the setting item with 10-key.
- 3) Press [OK] key.

	ltem/Di	splay	Co	ntent	Setting range	Default value
А	1ST DIGIT		First digit	(left edge)	1 - 90	1
В	2ND DIG	IT	Second d	igit		
С	3RD DIG	IT	Third digi	t	32 [blank: 20H]	
D	D 4TH DIGIT		Fourth dig	git	65 - 90 [Alphabet: 41H("A) - 5AH("Z")]	
E	5TH DIG	5TH DIGIT		Fifth digit		
F	6TH DIG	IT	Sixth digit (right edge)			
G	COLOR	К	Color spe	cification	0	0
		С	input		1	
		М			2	
		Y			3	
		R			4	
		G			5	
		В			6	
Н	TYPE	PATTERN	Print	Edging	0	1
		1	com-	type		
		PATTERN	posing	OR	1	
		2	method	process		
				type		
		PATTERN		No-	2	
		3		delete-		
				compo-		
1				shon type		

#### Input value

Print	Blank	А	В	С	Ш	F	G
Input value	32	65	66	67	69	70	71
Print	Н	I	J	К	L	М	Ν
Input value	72	73	74	75	76	77	78
Print	0	Р	Q	R	Т	U	V
Input value	79	80	81	82	84	85	86
Print	W	Х	Y	Z	0	1	2
Input value	87	88	89	90	48	49	50
Print	3	5	6	7	8	9	
Input value	51	53	54	55	56	57	

56	

56-1	
Purpose	Backup
Function (Purpose)	Used to transport data between HDD - MFP PWB SRAM/EEPROM. (Used to repair the PWB.)
Section	
Operation/Procedure	1

- 1) Select a target content of data transfer.
- 2) Press [EXECUTE] key and press [YES] key.

Data transfer of the item selected in procedure 1) is executed. When the operation is completed normally, "COMPLETE" is displayed. In case of an abnormal end, "ERROR" is displayed.

$EEPROM \to HDD$	Transfer from EEPROM to HDD
$HDD \rightarrow EEPROM$	Transfer from HDD to EEPROM

56-2	
Purpose	Data backup
Function (Purpose)	Used to backup the d

Used to backup the data in the EEPROM. SD Card, and HDD (including user authentication data and address data) to the USB memory. (Corresponding to the device cloning and the storage backup.)

#### Section

#### **Operation/Procedure**

- 1) Insert the USB memory into the main unit.
- Select a target transfer item with the touch panel.
   <IMPORT>

From USB MEMORY DEVICE To EEPROM, SD Card HDD <EXPORT>

From EEPROM, SD Card, HDD To USB MEMORY

Press [EXECUTE] key, and press [YES] key.
 Data transfer selected in the procedure 2) is performed
 When the operation is completed normally, "COMPLETE" is displayed. In case of an abnormal end, "ERROR" is displayed.

(Machine with the DSK installed)

- 1) Insert the USB memory into the main unit.
- 2) Select a target transfer item with the touch panel. <IMPORT>

From USB MEMORY DEVICE to EEPROM, SD Card HDD <EXPORT>

From EEPROM, SD Card, HDD to USB MEMORY DEVICE

- 3) Enter the password with 10-key.
- 4) Press [SET] key.
- Press [EXECUTE] key, and press [YES] key.
   Data transfer selected in the procedure 2) is performed.
   When the operation is completed normally, "COMPLETE" is displayed. In case of an abnormal end, "ERROR" is displayed.

# <Data list outside the backup targets>

(EEPK	0101/50	Card)	

PWB Type	Content	NOTE
Controller	Machine serial No.	
	Product key information	
	Various counter	Copy counter/FAX
		send counter etc.
	Trouble history	
PCU	Machine serial No.	
	Various counter	Maintenance counter
	Machine adjustment execute	
	history	
	Trouble history	
SCU	Various counter	Maintenance counter
	Trouble history	

(HDD)

Classifi- cation	Content	NOTE
Japanese FEP	User dictionary	
Job end list	Job end list display data (The image send series include the preserved job list.)	
Log	Job log	Read from WEB is enable.
New N/A	<ul> <li>Print history information</li> <li>JAM history information</li> <li>Trouble history information</li> <li>Same position continuous jam count value</li> <li>Charging information</li> <li>Life information</li> </ul>	
Operation manual	E-manual	

56-3	
Purpose	Data backup
Function (Purpose)	Used to backup the document filing data to the USB memory.

#### Section Operation/Procedure

- 1) Insert the USB memory into the main unit.
- Select a target transfer item with the touch panel.
   <IMPORT>

From USB MEMORY DEVICE to EEPROM, SD Card, HDD <EXPORT>

From EEPROM, SD Card, HDD to USB MEMORY DEVICE 3) Press [EXECUTE] key, and press [YES] key.

Data transfer selected in the procedure 2) is performed. When the operation is completed normally, "COMPLETE" is displayed. In case of an abnormal end, "ERROR" is displayed.

## 56-4

Purpose	Data backup
Function (Purpose)	Used to backup the JOB log data to the USB memory.

### Section

### **Operation/Procedure**

- 1) Insert the USB memory into the main unit.
- 2) Press [JOB LOG EXPORT] key.
- Press [EXECUTE] key, and press [YES] key.
   Data transfer selected in the procedure 2) is performed.
   When the operation is completed normally, "COMPLETE" is displayed. In case of an abnormal end, "ERROR" is displayed.

56-5	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to import the SIM22-6 data to a USB memory in the TEXT format.

# Section Operation/Procedure

- 1) Insert the USB memory into the main unit.
- 2) Select a kind of data to be imported.
- Press [EXECUTE] key, and press [YES] key.
   Procedure 2) The selected data are imported.
   When the operation is completed normally, "COMPLETE" is

displayed. In case of an abnormal end, "ERROR" is displayed.

56-6	
Purpose	Operation data check
Function (Purpose)	Used to import the SIM23-2 data to a USB memory in the TEXT format.
Section	
O	

- 1) Insert the USB memory into the main unit.
- 2) Select a kind of data to be imported.
- 3) Press [EXECUTE] key, and press [YES] key.

56-7	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to import the syslog data to a USB
	memory.
Section	

- 1) Insert the USB memory into the main unit.
- 2) Select SYSLOG EXPORT to be imported.
- 3) Press [EXECUTE] key, and press [YES] key.

# 60

60-1				
Purpose	Operation test/check			
Function (Purpose)	Used to check the memory operations			
	(read/write) of the MFP PWB.			

### Section

#### **Operation/Procedure**

1) Press [EXECUTE] key.

Start the test.

Result display	Description
OK	Success
NG	Fail
NONE	DIMM trouble
INVALID	Execution disable

# 61

61-1	
Purpose	Operation test/check
Function (Purpose)	Used to check the LSU polygon motor rota tion and laser detection.
Section	LSU

### **Operation/Procedure**

1) Press [EXECUTE] key.

When the operation is completed normally, [OK] is displayed. In case of an abnormal end, [NG] is displayed.

Display	Content
LSU TESTRESULT NG: PG	Polygon mirror rotation abnormality
LSU TESTRESULT NG: K	Laser abnormality (K)
LSU TESTRESULT NG: CL	Laser light emitting abnormality (C,M,Y)

61-3	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the laser power
Section	

- 1) Select a target mode for adjustment with [COPY], [PR600/ FAX] on the touch panel.
- 2) Select an adjustment target item with scroll key on the touch panel.
- 3) Enter the adjustment value using the 10-key.
- Press [OK] key. (The set value is saved.)
   When the laser power and the DUTY adjustment value are increased, the print density is increased and the line width of line images are increased.

Mode		Item / Display	Content	Setting	Default	t value	Destinatio
				range	26/31cpm machine	36cpm machine	n linkage
	Α	LASER POWER MIDDLE(K1)	Laser power setting middle speed/K1	0 - 255	128	151	х
	В	LASER POWER MIDDLE(K2)	Laser power setting middle speed/K2	0 - 255	128	151	х
	С	LASER POWER MIDDLE(C1)	Laser power setting middle speed/C1	0 - 255	128	151	х
	D	LASER POWER MIDDLE(C2)	Laser power setting middle speed/C2	0 - 255	128	151	х
	E	LASER POWER MIDDLE(M1)	Laser power setting middle speed/M1	0 - 255	128	151	х
	F	LASER POWER MIDDLE(M2)	Laser power setting middle speed/M2	0 - 255	128	151	х
	G	LASER POWER MIDDLE(Y1)	Laser power setting middle speed/Y1	0 - 255	128	151	х
	Н	LASER POWER MIDDLE(Y2)	Laser power setting middle speed/Y2	0 - 255	128	151	х
	I	LASER POWER LOW(K1)	Laser power setting low speed/K1	0 - 255	128	151	х
	J	LASER POWER LOW(K2)	Laser power setting low speed/K2	0 - 255	128	151	х
	К	LASER POWER LOW(C1)	Laser power setting low speed/C1	0 - 255	128	151	х
	L	LASER POWER LOW(C2)	Laser power setting low speed/C2	0 - 255	128	151	х
	М	LASER POWER LOW(M1)	Laser power setting low speed/M1	0 - 255	128	151	х
	N	LASER POWER LOW(M2)	Laser power setting low speed/M2	0 - 255	128	151	х
	0	LASER POWER LOW(Y1)	Laser power setting low speed/Y1	0 - 255	128	151	х
COPY	P	LASER POWER LOW(Y2)	Laser power setting low speed/Y2	0 - 255	128	151	x
	Q	LASER POWER MIDDLE(BW1)	Laser power setting middle speed/BW1	0 - 255	128	151	x
	R	LASER POWER MIDDLE(BW2)	Laser power setting middle speed/BW2	0 - 255	128	151	x
	S	LASER POWER LOW(BW1)	Laser power setting low speed/BW1	0 - 255	128	151	x
	Т	LASER POWER LOW(BW2)	Laser power setting low speed/BW2	0 - 255	128	151	x
	U		Laser power setting middle speed/K	0 - 255	0	0	0
	V		Laser duty select middle speed/C	0 - 255	0	0	0
	Ŵ		Laser duty select middle speed/M	0 - 255	0	0	0
	X		Laser duty select middle speed/Y	0 - 255	0	0	0
	Y		Laser duty select low speed/K	0 - 255	0	0	0
	7		Laser duty select low speed/C	0 - 255	0	0	0
			Laser duty select low speed/0	0 - 255	0	0	0
	AB		Laser duty select low speed/V	0 - 255	0	0	0
			Laser duty select middle speed/RW/	0 - 255	0	0	0
			Laser duty select low speed/BW	0 - 255	0	0	0
			Laser power setting middle speed/K1	0 - 255	129	151	v
	R		Laser power setting middle speed/K1	0 - 255	120	151	×
	Б С		Laser power setting middle speed/R2	0 - 255	120	151	x
			Laser power setting middle speed/C1	0 - 255	120	151	~
			Laser power setting middle speed/C2	0 - 255	120	151	X
			Laser power setting middle speed/M1	0 - 255	128	151	X
	F		Laser power setting middle speed/M2	0 - 255	128	151	X
	G		Laser power setting middle speed/ f 1	0 - 255	128	151	X
	н		Laser power setting middle speed/ Y2	0 - 255	128	151	X
		LASER POWER LOW(K1)	Laser power setting low speed/K1	0 - 255	128	151	X
PR600/	J	LASER POWER LOW(K2)	Laser power setting low speed/K2	0 - 255	128	151	X
FAX	ĸ	LASER POWER LOW(C1)	Laser power setting low speed/C1	0 - 255	128	151	X
		LASER POWER LOW(C2)	Laser power setting low speed/C2	0 - 255	128	151	x
	M	LASER POWER LOW(M1)	Laser power setting low speed/M1	0 - 255	128	151	x
	N	LASER POWER LOW(M2)	Laser power setting low speed/M2	0 - 255	128	151	x
	0	LASER POWER LOW(Y1)	Laser power setting low speed/Y1	0 - 255	128	151	x
	P	LASER POWER LOW(Y2)	Laser power setting low speed/Y2	0 - 255	128	151	х
	Q	LASER POWER MIDDLE(BW1)	Laser power setting middle speed/BW1	0 - 255	128	151	x
	R	LASER POWER MIDDLE(BW2)	Laser power setting middle speed/BW2	0 - 255	128	151	x
	S	LASER POWER LOW(BW1)	Laser power setting low speed/BW1	0 - 255	128	151	x
1	Т	LASER POWER LOW(BW2)	Laser power setting low speed/BW2	0 - 255	128	151	х

Mode		Item / Display	Content	Setting	Default	value	Destinatio
				range	26/31cpm machine	36cpm machine	n linkage
PR600/	U	LASER DUTY MIDDLE(K)	Laser duty select middle speed/K	0 - 255	0	0	0
FAX	V	LASER DUTY MIDDLE(C)	Laser duty select middle speed/C	0 - 255	0	0	0
	W	LASER DUTY MIDDLE(M)	Laser duty select middle speed/M	0 - 255	0	0	0
	Х	LASER DUTY MIDDLE(Y)	Laser duty select middle speed/Y	0 - 255	0	0	0
	Y	LASER DUTY LOW(K)	Laser duty select low speed/K	0 - 255	0	0	0
	Z	LASER DUTY LOW(C)	Laser duty select low speed/C	0 - 255	0	0	0
	AA	LASER DUTY LOW(M)	Laser duty select low speed/M	0 - 255	0	0	0
	AB	LASER DUTY LOW(Y)	Laser duty select low speed/Y	0 - 255	0	0	0
	AC	LASER DUTY MIDDLE(BW)	Laser duty select middle speed/BW	0 - 255	0	0	0
	AD	LASER DUTY LOW(BW)	Laser duty select low speed/BW	0 - 255	0	0	0
	AE	LASER DUTY MIDDLE(K 1BIT)	Laser duty select middle speed/K	0 - 255	0	0	0
	AF	LASER DUTY MIDDLE(C 1BIT)	Laser duty select middle speed/C	0 - 255	0	0	0
	AG	LASER DUTY MIDDLE(M 1BIT)	Laser duty select middle speed/M	0 - 255	0	0	0
	AH	LASER DUTY MIDDLE(Y 1BIT)	Laser duty select middle speed/Y	0 - 255	0	0	0
	AI	LASER DUTY LOW(K 1BIT)	Laser duty select low speed/K	0 - 255	0	0	0
	AJ	LASER DUTY LOW(C 1BIT)	Laser duty select low speed/C	0 - 255	0	0	0
	AK	LASER DUTY LOW(M 1BIT)	Laser duty select low speed/M	0 - 255	0	0	0
	AL	LASER DUTY LOW(Y 1BIT)	Laser duty select low speed/Y	0 - 255	0	0	0
	AM	LASER DUTY MIDDLE(BW 1BIT)	Laser duty select middle speed/BW	0 - 255	0	0	0
	AN	LASER DUTY LOW(BW 1BIT)	Laser duty select low speed/BW	0 - 255	0	0	0
	Α	LASER POWER MIDDLE(K1)	Laser power setting middle speed/K1	0 - 255	128	151	х
	В	LASER POWER MIDDLE(K2)	Laser power setting middle speed/K2	0 - 255	128	151	x
	С	LASER POWER MIDDLE(C1)	Laser power setting middle speed/C1	0 - 255	128	151	х
	D	LASER POWER MIDDLE(C2	Laser power setting middle speed/C2	0 - 255	128	151	х
	E	LASER POWER MIDDLE(M1)	Laser power setting middle speed/M1	0 - 255	128	151	x
	F	LASER POWER MIDDLE(M2)	Laser power setting middle speed/M2	0 - 255	128	151	x
	G	LASER POWER MIDDLE(Y1)	Laser power setting middle speed/Y1	0 - 255	128	151	x
	Н	LASER POWER MIDDLE(Y2)	Laser power setting middle speed/Y2	0 - 255	128	151	x
	1	LASER POWER LOW(K1)	Laser power setting low speed/K1	0 - 255	128	151	x
	J	LASER POWER LOW(K2)	Laser power setting low speed/K2	0 - 255	128	151	х
	K	LASER POWER LOW(C1)	Laser power setting low speed/C1	0 - 255	128	151	x
	L	LASER POWER LOW(C2)	Laser power setting low speed/C2	0 - 255	128	151	х
	М	LASER POWER LOW(M1)	Laser power setting low speed/M1	0 - 255	128	151	х
	N	LASER POWER LOW(M2)	Laser power setting low speed/M2	0 - 255	128	151	х
PR1200	0	LASER POWER LOW(Y1)	Laser power setting low speed/Y1	0 - 255	128	151	х
11(1200	Р	LASER POWER LOW(Y2)	Laser power setting low speed/Y2	0 - 255	128	151	х
	Q	LASER POWER MIDDLE(BW1)	Laser power setting middle speed/BW1	0 - 255	128	151	х
	R	LASER POWER MIDDLE(BW2)	Laser power setting middlespeed/BW2	0 - 255	128	151	х
	S	LASER POWER LOWÅi(BW1)	Laser power setting low speed/BW1	0 - 255	128	151	х
	Т	LASER POWER LOW(BW2)	Laser power setting low speed/BW2	0 - 255	128	151	х
	U	LASER DUTY MIDDLE(K)	Laser duty select middle speed/K	0 - 255	0	0	х
	V	LASER DUTY MIDDLE(C)	Laser duty select middle speed/C	0 - 255	0	0	х
	W	LASER DUTY MIDDLE(M)	Laser duty select middle speed/M	0 - 255	0	0	х
	Х	LASER DUTY MIDDLE(Y)	Laser duty select middle speed/Y	0 - 255	0	0	х
	Y	LASER DUTY LOW(K)	Laser duty select low speed/K	0 - 255	0	0	х
	Z	LASER DUTY LOW(C)	Laser duty select low speed/C	0 - 255	0	0	x
	AA	LASER DUTY LOW(M)	Laser duty select low speed/M	0 - 255	0	0	х
	AB	LASER DUTY LOW(Y)	Laser duty select low speed/Y	0 - 255	0	0	x
	AC	LASER DUTY MIDDLE(BW)	Laser duty select middle speed/BW	0 - 255	0	0	х
	AD	LASER DUTY LOW(BW)	Laser duty select low speed/BW	0 - 255	0	0	х

## 61-4

011	
Purpose	Adjustment
Function (Purpose)	Used to print the print image skew adjust-
	ment pattern. (LSU unit)

### Section

### **Operation/Procedure**

- 1) Select a target item with scroll key on the touch panel.
- 2) Enter the print conditions setting value with 10-key.
- 3) Press [EXECUTE] key.

The print image skew adjustment pattern is printed.

Item/Display		Content	Default value	
A	MULTICOUNT	Print quantity (1-999)	1	

Item/Display			Co	ontent	Default value	
В	PAPER	MFT	Tray	1	Manual paper feed	2
		CS1	selection	2	Paper feed tray 1	(Paper
		CS2		3	Paper feed tray 2	feed tray
		CS3		4	Paper feed tray 3	1)
		CS4		5	Paper feed tray 4	
		LCC		6	LCC	

### 61-11 Purpose

Adjustment

Function (Purpose)

Used to correct the laser power automatically.

#### Section

#### **Operation/Procedure**

- 1) Press [AUTO CORRECTION] key.
- Select a density to be corrected. 2)
- 3) Press [EXECUTE] key.
- 4) Place the printed sample for scanning on the OC in the A4R(LTR) direction.



#### Press [EXECUTE] key. 5)

61-12	
Purpose	Adjustment
Function (Purpose)	Laser power manual correction
Section	LSU

**Operation/Procedure** 

Press an item button to be adjusted.

When [MEASURING INSTRUMENT] is pressed:

- 1) Select the adjustment density pattern.
- 2) Press [EXECUTE] key.
- 3) The adjustment pattern is printed out.
- 4) Enter the adjustment value by the density meter.
- 5) Press [EXECUTE] key.

Execute the manual correction of the laser power. Then the adjustment result pattern is outputted and the data are displayed.

#### When [VISUAL INSPECTION] is pressed:

- 1) Select the adjustment density pattern.
- 2) Press [EXECUTE] key.
- 3) The adjustment pattern is printed out.
- 4) Press [4POINT CORRECTION] or [31POINT CORRECTION].
- 5) Enter an adjustment value.
- 6) Press [EXECUTE] key.

Execute the manual correction of the laser power. Then the adjustment result pattern is outputted and the data are displayed.

### 61-13 Adjustment

value.

Purpose Used to clear the laser power correction

Function (Purpose)

#### Section

#### **Operation/Procedure**

1) Press [EXECUTE] key.

2) Press [YES] key.

Reference value reset item		
Laser power automatic correction amount (K) 32 data (point)		
Laser power automatic correction amount (C) 32 data (point)		
Laser power automatic correction amount (M) 32 data (point)		
Laser power automatic correction amount (Y) 32 data (point)		
Laser power manual correction amount (K) 32 data (point)		
Laser power manual correction amount (C) 32 data (point)		
Laser power manual correction amount (M) 32 data (point)		
Laser power manual correction amount (Y) 32 data (point)		



62-1	
Purpose	Data clear
Function (Purpose)	Used to format the hard disk/SD Card. (HDD: Excluding the Operation manual and the watermark data) (SD Card: User data)
Section	

### **Operation/Procedure**

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

Used to execute the HDD/SD Card format.

When the operation is completed, [EXECUTE] key returns to the normal display.

62-2	
Purpose	Operation test/check
Function (Purpose)	Used to check read/write of the hard disk
Section	

### **Operation/Procedure**

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

62-3		
Purpose	Operation test/check	
Function (Purpose)	Used to check read/write of the hard disk (all areas).	
Section		

- 1) Press [EXECUTE] key.
- Press [YES] key. 2) Read/write operations are performed.

### 62-6 Purpose

Operation test/check

Function (Purpose)

Used to perform the self diagnostics of the hard disk.

#### Section

- **Operation/Procedure**
- 1) Select the self diag area.
- 2) Press [EXECUTE] key.

The self diag operation is performed.

### Note

E7-03 error occurs. If there may be a trouble in the HDD, use this simulation to cheek the HDD.

SHORT S.T	Partial area diag
EXTENDED S.T	All area diag

When the operation is completed, [EXECUTE] key returns to the normal display.

Normal completion  $\rightarrow$  "OK (RESULT:0)" is displayed.

Abnormal end  $\rightarrow$  "NG (RESULT: Other than 0)" is displayed.

 If the simulation cannot be executed or terminated abnormally for some reason, "ERROR" is displayed on the corresponding section.

62-7	
Purpose	Operation test/check
Function (Purpose)	Used to print the hard disk self diagnostics
	error log.
Section	

#### **Operation/Procedure**

1) Press [EXECUTE] key.

ERROR LOG SECTOR of the SMART function is executed, and the result is printed.

When the operation is completed, [EXECUTE] key returns to the normal display.

62-8	
Purpose	Data clear
Function (Purpose)	Used to format the hard disk/SD Card. (HDD: Excluding the Operation Manual, the watermark data, and the system area) (SD
	Card: User data)

#### Section Operation/Procedure

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

Used to execute the hard disk format.

When the operation is completed, [EXECUTE] key returns to the normal display.

* When the HDD formatting (except for the system area) is not completed normally, "HDD FORMAT (EXCEPT SYSTEM AREA) NG" is displayed.

62-10	
Purpose	Data clear
Function (Purpose)	Used to clear the job completion list data.
Section	

#### **Operation/Procedure**

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.
  - Used to delete the job log data.

When the operation is completed, [EXECUTE] key returns to the normal display.

62-11	
Purpose	Data clear
Function (Purpose)	Used to delete the document filing data.
Section	

#### **Operation/Procedure**

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

Used to delete the document filing data.

When the operation is completed, [EXECUTE] key returns to the normal display.

62-12	
Purpose	Setting
Function (Purpose)	Used to set Enable/Disable of auto format in a hard disk trouble.
Section	
Operation/Procedure	
1) Entor the set value	o with 10 kov

- Enter the set value with 10-key.
- 2) Press [OK] key.
  - The set value is saved.

When it is set to Enable, if a read error of HDD occurs in the system data storage area (FAX/device cloning data, etc.), only the system data storage area is cleared.

А	0	Enable
	1	Disable (Default)

62-13	
Purpose	Data clear
Function (Purpose)	Used to format the hard disk. (Operation
	Manual, watermark data only)

### Section

#### **Operation/Procedure**

- 1) Press [EXECUTE] key.
- Press [YES] key.
  - The operation manual data are deleted.

When the operation is completed, [EXECUTE] key returns to the normal display.

62-14	
Purpose	Data clear
Function (Purpose)	Used to delete the document filing management data.
Section	HDD

#### Section Operation/Procedure

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

The document filing management data are cleared. At the same time, the job log data are also cleared.

- This simulation is executed in the following trouble cases.
- * The document filing function does not work normally.
- * The job log is not recorded normally.

### Note

This simulation may not function with some firmware versions. In such a case, the firmware must be upgraded to the latest version.

62-20	
Purpose	Operation test/check
Function (Purpose)	Used to check the operation of the mirror- ing hard disk.
Section	Mirroring hard disk

### **Operation/Procedure**

Enter the simulation mode, and the operation status of the HDD is displayed.

The status display is renewed in every second.

Display	Content description
ОК	Normal operation
NONE	Not connected
REBUILDING	Data rebuilding
ERROR	Error occurrence
TROUBLE	Trouble

# 63

63-1						
Purpose	Adjust	tme	nt/Setting	g/Op	eration da	ta check
Function (Purpose)	Used	to	display	the	shading	correction
	result.					
Section	Scanr	ner				

#### **Operation/Procedure**

1) Select a target color to display with [R] [G] [B] on the touch panel.

#### [RSPF]

Display item	Description	Remarks
ANALOG	Analog gain adjustment	
GAIN ODD	value (odd number)	
ANALOG	Analog gain adjustment	
GAIN EVEN	value (even number)	
DIGITAL	Digital gain adjustment	
GAIN ODD	value (odd number)	
DIGITAL	Digital gain adjustment	
GAIN EVEN	value (even number)	
SMP AVE	Reference plate	
ODD	sampling average value	
	(ODD)	

Display item	Description		Remarks
SMP AVE	Reference plate		
EVEN	sampling average value		
	(EVEN)		
TARGET	Target value		
BLACK	Black output level		
LEVEL			
ERROR	Error code (0, 1 - 14)	0:	No error
CODE		1:	Loop number over
		2:	The target value is
			under the speci-
			fied value
		3:	The gain set value is
			negative.
		4:	END is not asserted.
			(Gain adjustment)
		5:	Reserve
		6:	Underflow
		7:	Black shading error
		8:	Other error
		9:	END is not asserted.
			(White shading)
		10:	END is not asserted.
			(Black shading)
		11:	END is not asserted.
			(Light quantity
			correction)
		12:	END is not asserted.
		13:	Register check error
			(White booting/Before
			gain)
		14:	Register check error
			(Before light quantity
			correction)
	FIISL SCAN KOPF DACK		
RSPE BACK	Second scan RSPE back		
WHITE	surface white reference		
LEVEL 2ND	level		

63-2	
Purpose	Adjustment
Function (Purpose)	Used to perform shading.
Section	

#### **Operation/Procedure**

 (When RSPF model) Press [EXECUTE] key. Used to perform shading.

When the operation is completed, [EXECUTE] key returns to the normal display.

63-3	
Purpose	Adjustment
Function (Purpose)	Used to perform scanner (CCD) color bal- ance and gamma auto adjustment.
Section	Scanner

- Place the SIT chart (UKOG-0280FCZZ or UKOG-0280FCZ1) on the reference position of the left rear frame side of the document table.
- 2) Press [EXECUTE] key.

The scanner (CCD) color balance automatic adjustment is performed.

When the operation is completed, [EXECUTE] key returns to the normal display.

After completion of the operation, press [RESULT] key, and the adjustment data are displayed. At that time, the target color of data display can be selected with [R] [G] [B] key.

63-4	63-4	
------	------	--

00 +	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to display the SIT chart patch density.
Section	

#### **Operation/Procedure**

- Set the SIT chart (UKOG-0280FCZZ or UKOG-0280FCZ1) to the reference position on the left rear frame side of the document table.
- 2) Press [EXECUTE] key.

The patch of the SIT chart is scanned.

When the operation is completed, [EXECUTE] key returns to the normal display.

3) Select a data display mode.

THROUGH GAMMA	SIT chart scan data	
COPY GAMMA	Copy mode gamma process data of the SIT chart	
	scan data	
SCANNER GAMMA	Image send mode gamma process data of the SIT	
	chart scan data	
SIT CHECK	SIT chart scan data/Check result	

Select an target display color with [R] [G] [B] keys.

63-5	
Purpose	Adjustment/Setup
Function (Purpose)	Used to perform the scanner (CCD) color balance and gamma default setting.
Section	

### Operation/Procedure

- 1) Press [EXECUTE] key, and press [YES] key
- 2) The scanner (CCD) color balance and gamma are set to the default.

63-6	
Purpose	Adjustment/Setting/Operation data check
Function (Purpose)	Used to display the scan level and the den- sity level of the copy color balance adjust- ment patch.

# Section

### **Operation/Procedure**

- Set the color balance adjustment pattern sheet printed with SIM46-21 on the document table.
- 2) Press [EXECUTE] key.

The patch image of the adjustment pattern sheet is scanned. Select a target color with [C] [M] [Y] [K] key.

63-7	
Purpose	Adjustment/Setup
Function (Purpose)	Used to register the service target of the
	copy mode auto color balance adjustment.

#### Section

#### **Operation/Procedure**

- 1) Press [SETUP] key on the touch panel.
- 2) Set the color balance adjustment pattern sheet printed with SIM46-21 on the document table.
- 3) Press [EXECUTE] key.

The patch image of the adjustment pattern sheet is scanned.

4) Press [OK] key.

The service target of the copy mode automatic color balance adjustment is registered according to the patch image of the scanned adjustment pattern sheet.

The registered color balance and the density are displayed.

Select a target color with [C] [M] [Y] [K] key.

#### Important

This simulation is executed only when the copy color balance is manually adjusted.

В	Point B target value
С	Point C target value
D	Point D target value
E	Point E target value
F	Point F target value
G	Point G target value
Н	Point H target value
Ι	Point I target value
J	Point J target value
K	Point K target value
L	Point L target value
М	Point M target value
Ν	Point N target value
0	Point O target value
BASE	Background sampling value

63-8	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the default of the service target of the copy mode auto color balance adjust- ment.
Section	

### Operation/Procedure

- 1) Press [EXECUTE] key.
- 2) Press [YES] key.

The service target of the copy mode automatic color balance adjustment is set to the default.

The service color balance target and the color balance target for the user color balance adjustment are set to the same color balance as the factory color balance target.

63-11	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the target color balance of the copy mode auto color balance adjustment.
Section	

#### **Operation/Procedure**

1) Select the target color balance with the touch panel.

Item/Display		Content	Default value
Target color balance	DEF1	The engine color balance adjustment target in the automatic color balance operation is slightly shifted to Magenta. When this target is selected, the color balance is converted into natural gray color balance by the color table in an actual copy mode and print is made.	DEF 1
	DEF2	The engine color balance adjustment target in the automatic color balance operation is slightly shifted to natural gray color balance. When this target is selected, the color balance is slightly shifted to Cyan by the color table in an actual copy mode and print is made.	
	DEF3	The engine color balance adjustment target in the automatic color balance operation is slightly shifted to Cyan. When this target is selected, the color balance is converted into the color balance with enhanced Cyan by the color table in an actual copy mode and print is made.	



64-1	
Purpose	Operation test/check
Function (Purpose)	Test print. (Self print) (Color mode)
Section	

- Set the print conditions.
   Select an item to be print condition with scroll keys.
   Set the print conditions with 10-key.
   Select a target print color with [K] [C] [M] [Y] key.
- 2) Press [EXECUTE] key. The test print (self print) is performed.

A         PRINT PATTERN (1, 2, 9 - 11, 17 - 19, 21, 22, 29)         Specification of the print pattern (* For details, refer to the description below.)         1 - 58 (Printable only 1, 2, 9 - 11, 17 - 19, 21, 22, 29)         I         I         Specification of the print pattern (* For details, refer to the description below.)         1 - 58 (Printable only 1, 2, 9 - 11, 17 - 19, 21, 22, 29)         I         I         Specification of the print pattern (* For details, refer to the description below.)         1 - 58 (Printable only 1, 2, 9 - 11, 17 - 19, 21, 22, 29)         I         I         Specification of the print pattern (* For details, refer to the description below.)         1 - 255         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I         I	efault value
(1, 2, 9 - 11, 17 - 19, 21, 22, 29)       (* For details, refer to the description below.)       22, 29)         B       DOT1 (DOT1>=2 IF A: 2,11)       Setting of print dot number (M parameter) (Self print pattern: m by n)       1-255 (Pattern 2, 11: 2-255 except above: 1-255)         C       DOT2 (DOT2>=2 IF A: 2,11)       Setting of blank dot number (N parameter) (Self print pattern: m by n)       0-255 (Pattern 2, 11: 2-255 except above: 0-255)         D       DENSITY (FIXED "255" IF A: 9)       Used to specify the print gradation.       1-255 (Pattern 9: 255 Fixed except above: 1-255)         E       MULTI COUNT       Number of print       1 - 999         F       EXPOSURE (2 - 8 IF A: 17 - 19)       THROUGH       Exposure mode specification       No process (through)         Text/ Photograph       Text/ Photograph       except above:1-8)       3         PRINT PAPER       PRINT PAPER       Photograph       5         Photograph       7	1
B       DOT1 (DOT1>=2 IF A: 2,11)       Setting of print dot number (M parameter) (Self print pattern: m by n)       1-255 (Pattern 2, 11: 2-255 except above: 1-255)         C       DOT2 (DOT2>=2 IF A: 2,11)       Setting of blank dot number (N parameter) (Self print pattern: m by n)       0-255 (Pattern 2, 11: 2-255 except above: 0-255)         D       DENSITY (FIXED "255" IF A: 9)       Used to specify the print gradation.       1-255 (Pattern 9: 255 Fixed except above: 0-255)         E       MULTI COUNT       Number of print       1 - 999         F       EXPOSURE (2 - 8 IF A: 17 - 19)       THROUGH       Exposure mode specification       No process (through)         GHAR/PRPIC CHAR       CHAR/PRPIC CHAR       Text/Printed Photo       (Pattern 17-19: 2-8 except above:1-8)       2 3         PRINT PIC PRINT PAPER       PRINT PAPER       Photograph       5 Photograph       5 Photograph	
C       Setting of blank dot number (N parameter) (Self print pattern: m by n)       (Pattern 2, 11: 2-255 except above: 1-255)         D       DT2 (DOT2>=2 IF A: 2,11)       Setting of blank dot number (N parameter) (Self print pattern: m by n)       0-255 (Pattern2, 11: 2-255 except above: 0-255)         D       DENSITY (FIXED "255" IF A: 9)       Used to specify the print gradation.       1-255 (Pattern 9: 255 Fixed except above: 1-255)         E       MULTI COUNT       Number of print       1 - 999         F       EXPOSURE (2 - 8 IF A: 17 - 19)       THROUGH       Exposure mode specification       No process (through)         Text/Printed Photo       (Pattern 17-19: 2-8 except above:1-8)       2 3       (ST Text/ Photograph         PRINT PIC PRINT PAPER       PRINT PAPER       Photograph       5 Photograph       5 Photograph	1
C       DOT2 (DOT2>=2 IF A: 2,11)       Setting of blank dot number (N parameter) (Self print pattern: m by n)       0-255 (Pattern2, 11: 2-255 except above: 0-255)         D       DENSITY (FIXED "255" IF A: 9)       Used to specify the print gradation.       1-255 (Pattern 9: 255 Fixed except above: 1-255)         E       MULTI COUNT       Number of print       1 - 999         F       EXPOSURE (2 - 8 IF A: 17 - 19)       THROUGH       Exposure mode specification       No process (through)       1-8 (Pattern 17-19: 2-8 (Pattern 17-19: 2-8 (Pattern 17-19: 2-8)       1 (Pattern 17-19: 2-8 (Pattern 17-19: 2-8)       2 (ST (Pattern 17-19: 2-8)       (ST (Pattern 17-19: 2-8)       2 (ST (Pattern 17-19: 2-8)       (ST (Pattern 17-19: 2-8)       2 (ST (Pattern 17-19: 2-8)       (ST (Pattern 17-19: 2-8)       3 (ST (Pattern 17-19: 2-8)       3 (ST (ST (Pattern 17-19: 2-8)       3 (ST (ST (ST (ST (ST (ST (ST (ST (ST (ST	
Image: Constraint of the part of th	254
D     DENSITY (FIXED "255" IF A: 9)     Used to specify the print gradation.     1-255 (Pattern 9: 255 Fixed except above:1-255)       E     MULTI COUNT     1 - 999       F     EXPOSURE (2 - 8 IF A: 17 - 19)     THROUGH CHAR/PRPIC CHAR     Exposure mode specification     No process (through) Text/Printed Photo     1-8     1       CHAR/PRPIC CHAR     CHAR/PRPIC CHAR     Text     4       PRINT PIC PRINT PAPER     Printed Photo     5       PRINT PAPER     Map     Map	
E       MULTI COUNT       Number of print       1 - 999         F       EXPOSURE (2 - 8 IF A: 17 - 19)       THROUGH       Exposure mode specification       No process (through)       1-8       1         CHAR/PRIC CHAR       CHAR/PRIC       Specification       Text/Printed Photo       (Pattern 17-19: 2-8       2       (S [*] )         PRINT PIC       CHAR       Text       4       4         PRINT PAPER       Photograph       5       5         Map       Map       Map       7	255
E     MULTI COUNT     Number of print     1 - 999       F     EXPOSURE (2 - 8 IF A: 17 - 19)     THROUGH     Exposure mode specification     No process (through)     1-8     1       CHAR/PRIC     CHAR/PRPIC     Text/Printed Photo     Text/Photograph     except above:1-8)     3     1       PRINT PIC     PRINT PAPER     Photograph     Text     6       Map     Map     Map     Map	
F       EXPOSURE       THROUGH       Exposure mode       No process (through)       1-8       1         (2 - 8 IF A: 17 - 19)       CHAR/PIC       specification       Text/Printed Photo       (Pattern 17-19: 2-8       2       (S)         CHAR/PRPIC       CHAR       Text/ Photograph       except above:1-8)       3       1         PRINT PIC       Printed Photo       Fext       4       5         PRINT PAPER       Mon       Mon       5	1
(2 - 8 IF A: 17 - 19)       CHAR/PIC       specification       Text/Printed Photo       (Pattern 17-19: 2-8 except above:1-8)       2       (S'         CHAR/PRPIC       Text       4         CHAR       Text       4         PRINT PIC       Printed Photo       5         PRINT PAPER       Photograph       6	8
CHAR/PRPIC     Text/ Photograph     except above:1-8)     3     I       CHAR     Text     4       PRINT PIC     Printed Photo     5       PRINT PAPER     Photograph     6	STANDARD
CHARText4PRINT PICPrinted Photo5PRINT PAPERPhotograph6MARMax7	DITHER)
PRINT PIC     Printed Photo     5       PRINT PAPER     Photograph     6       MAD     Map     7	
PRINT PAPER Photograph 6	
MAR Non	
STANDARD DITHER Dither without correction 8	
G PAPER MFT Tray selection Manual paper feed 1-6 1	2
CS1 Tray 1 2	(CS1)
CS2 Tray 2 3	
CS3 Tray 3 4	
CS4 Tray 4 5	
LCC LCC 6	
H DUPLEX YES Duplex print Yes 0-1 0	1
NO selection No 1	(NO)
I PAPER TYPE PLAIN Paper type Standard paper 1-6 1	1
HEAVY Heavy paper 2	(PLAIN)
OHP OHP 3	
ENVELOPE Envelope 4	
HEAVY2 Heavy paper 2 5	
GLOSSY Glossy paper 6	
HEAVY3 Heavy paper 3 7	

Pattern No.	Content	Pattern generating section	NOTE
1	Grid pattern	LSU-ASIC	<ul> <li>When the print width is 100 or more and all colors are selected, print is made in the three colors (CMY).</li> <li>Print is started at 4mm from the paper lead edge.</li> <li>Writing regardless of pound. The first one is fixed to LD1.</li> </ul>
2	Dot print		-
9	Each color 10% area (A4/ A4R) density print		<ul> <li>Each interval is 41.86mm (989dot).</li> <li>If m is not in the range of 1 - 13%, it is rounded.</li> <li>K print is started at 17mm from the paper lead edge.</li> </ul>
10	8-color belt print		
11	4-color dot print (sub scan)		<ul> <li>For every 1/4 of the sub scanning direction paper size, print is made for each color.</li> <li>When N=0, print of all the background is made in 4 colors.</li> </ul>
17	All background (halftone)	Halftone	When all colors are selected, print is made in CMY.
18	256 gradations pattern (Other dither)	(IMG-ASIC rear process)	<ul> <li>When all colors are selected, print is made in CMY.</li> <li>16 gradations are printed in the main scanning direction, and feedback is made, and the next 16 gradations are printed. (16 x 16 patch print)</li> <li>Print is started at 5mm from the paper lead edge.</li> <li>Print is made from 255 gradations, and 0-254 gradations are printed.</li> </ul>
19	256 gradations pattern (For text dither)		Print is made from 255 gradations, and 0-254 gradations are printed.
21	4-point dot print (main scan)	LSU-ASIC	<ul> <li>For every 1/4 of the main scanning direction paper size, print is made for each color.</li> <li>When N=0, print of all the background is made in 4 colors.</li> </ul>
22	Slant line	LSU-ASIC	
29	Dot print 1200dpi	LSU-ASIC	M=1(Fixed), N=1or3

64-2	
Purpose	Operation test/check
Function (Purpose)	Test print. (Self print) (Monochrome mode)
Section	
Operation/Procedure	•

#### Operation/Procedure

1) Set the print conditions. Select an item to be print condition with scroll keys. Set the print conditions with 10-key.

2) Press [EXECUTE] key.

The test print (self print) is performed.

	Item/Dis	splay		Content	Setting range		Default value
А	PRINT PATTERN		Print pattern specif	ication	1 - 58		1
	(1, 2, 9 - 11, 17 - 19,	21, 22, 29)	(* For details, refer to the description below.)		(Printable only 1, 2, 9 - 11, 17 - 19, 21,	, 22,	
					29)		
В	DOT1 (DOT1>=2 IF	A: 2,11)	Setting of print dot	number (M parameter)	1-255		1
			(Self print pattern:	m by n)	(Pattern 2, 11: 2-255 except above: 1-2	255)	
С	DOT2 (DOT2>=2 IF	A: 2,11)	Setting of blank do	t number	0-255		254
			(N parameter) (Sel	f print pattern: m by n)	(Pattern2, 11: 2-255 except above: 0-2	255)	
D	DENSITY (FIXED "2	55" IF A: 9)	Used to specify the	e print gradation.	1-255		255
_					(Pattern 9: 255 Fixed except above:1-2	255)	
E	MULTI COUNT	t	Number of print		1 - 999	1	1
F	EXPOSURE	THROUGH	Exposure mode	No process (through)	1-8	1	8
	(2 - 8 IF A: 17 - 19)	CHAR/PIC	specification	Text/Printed Photo	(Pattern 17-19: 2-8	2	(STANDARD
		CHAR/PRPIC		Text/ Photograph	except above: 1-8)	3	DITHER)
		CHAR		Text		4	
		PRINT PIC		Printed Photo		5	
		PRINT PAPER		Photograph		6	
		MAP		Мар		7	
		STANDARD DITHER		Dither without correction		8	
G	PAPER	MFT	Tray selection	Manual paper feed	1 - 6	1	2
		CS1		Tray 1		2	(CS1)
		CS2		Tray 2		3	
		CS3		Tray 3		4	
		CS4		Tray 4		5	
		LCC		LCC		6	
н	DUPLEX	YES	Duplex print	Yes	0 - 1	0	1
		NO	selection	No		1	(NO)

Item/Display		Content		Setting range		Default value	
1	PAPER TYPE	PLAIN	Paper type	Standard paper	1 - 6	1	1
		HEAVY		Heavy paper		2	(PLAIN)
		OHP		OHP		3	
		ENVELOPE		Envelope		4	
		HEAVY2		Heavy paper 2		5	
		GLOSSY		Glossy paper		6	
		HEAVY3		Heavy paper 3		7	

Pattern No.	Content	Pattern generating section	NOTE
1	Grid pattern	LSU-ASIC	<ul> <li>When the print width is 100 or more and all colors are selected, print is made in the three colors (CMY).</li> <li>Print is started at 4mm from the paper lead edge</li> </ul>
			<ul> <li>Writing regardless of pound. The first one is fixed to LD1.</li> </ul>
2	Dot print		-
9	Each color 10% area (A4/		Each interval is 41.86mm (989dot).
	A4R) density print		<ul> <li>If m is not in the range of 1 - 13%, it is rounded.</li> </ul>
			<ul> <li>K print is started at 17mm from the paper lead edge.</li> </ul>
10	8-color belt print		
11	4-color dot print (sub scan)		<ul> <li>For every 1/4 of the sub scanning direction paper size, print is made for each color.</li> <li>When N=0, print of all the background is made in 4 colors.</li> </ul>
17	All background (halftone)	Halftone (IMG-ASIC	-
18	256 gradations pattern (Other dither)	rear process)	_
19	256 gradations pattern (For text dither)		_
21	4-point dot print (main scan)	LSU-ASIC	<ul> <li>For every 1/4 of the main scanning direction paper size, print is made for each color.</li> <li>When N=0, print of all the background is made in 4 colors.</li> </ul>
22	Slant line	LSU-ASIC	
29	Dot print 1200dpi	LSU-ASIC	M=1(Fixed), N=1or3

64-4					
Purpose	Operation test/check				
Function (Purpose)	Printer test print. (Self print)				
Section					

### **Operation/Procedure**

Set the print conditions.
 Select an item to be print condition with scroll keys.
 Set the print conditions with 10-key.
 Select a target print color with [K] [C] [M] [Y] key.

- 2) Press [EXECUTE] key.
- 3) The test print (self print) is performed.

Item/Display			Content		Setting range	Default value
Α	A PRINT PATTERN		Specification of the print pattern		1 - 6	6
			(* For details, refer to the d	escription below.)		
В	DENSITY		Used to specify the print gr	adation.	1 - 255	128
С	MULTI COUNT		Number of print		1 - 999	1
D	PAPER	MFT	Paper feed tray selection	Manual paper feed	1	3
		CS1		Tray 1	2	(CS2)
		CS2		Tray 2	3	
		CS3		Tray 3	4	
		CS4		Tray 4	5	
		LCC		LCC	6	
Е	HALFTONE	LOW	Halftone	Low line number	0	0
		HIGH		High line number	1	(LOW)
		GLOSSY		Glossy paper	2	
F	QUALITY	STANDARD	Image quality setting	Standard	0	1
		HIGHQUALITY		High quality	1	(HIGHQUALITY)
		FINE		Fine	2	
				(26cpm/36cpm/31cpm(A)		
				machine)		
G	DITHER	STRAIGHT	Specification of dither	Straight	0	1
		CALIB	correction	Calibration	1	(CALIB)

Item/Display		Content		Setting range	Default value	
Н	PAPER TYPE	PLAIN	Paper type	Standard paper	0	0
		HEAVY		Heavy paper	1	
		HEAVY2		Heavy paper 2	2	
		GLOSSY		Glossy paper	3	
		HEAVY3		Heavy paper 3	4	

Pattern No.	Content
1	256 gradations pattern (COLOR)
2	256 gradations pattern (B/W)
3	256 gradations pattern (COLOR) (Y-M-C-K continuous)
4	Halftone pattern (COLOR)
5	Halftone pattern (B/W)
6	Background dot print

64-5				
Purpose	Operation test/check			
Function (Purpose)	Printer test print. (Self print) (PCL)			
Section				

### **Operation/Procedure**

 Set the print conditions. Select an item to be print condition with scroll keys.

Set the print conditions with 10-key.

- Select a target print color with [K] [C] [M] [Y] key.
- 2) Press [EXECUTE] key.

The test print (self print) is performed.

	Item/Disp	lay	Content		Setting range	Default value
Α	PRINT PATTERN		Print pattern specification		1 - 5	3
В	DENSITY		Print gradation specification		1 - 255	255
С	MULTI COUNT		Number of print		1 - 999	1
D	PAPER	MFT	Paper feed tray	Manual paper feed	1	2
		CS1	selection	Tray 1	2	(CS1)
		CS2		Tray 2	3	
		CS3		Tray 3	4	
		CS4		Tray 4	5	
		LCC		LCC	6	
Е	HALFTONE	LOW(IMAGE)	Halftone	For Photo	0	3
		HIGH(TEXT)		For text	1	(AUTO)
		GLOSSY		For glossy paper	2	
		AUTO		Auto (for photo/text)	3	
F	QUALITY	STANDARD	Image quality setting	Standard (600dpi, 1bit)	0	1
		HIGHQUALITY		High quality (600dpi, 4bit)	1	(HIGHQUALITY)
		FINE		Fine (1200dpi, 1bit)	2	
				(26cpm/36cpm/31cpm(A)		
				machine)		
G	DITHER	STRAIGHT	Specification of dither	0: Straight	0	1
		CALIB	correction	1: Calibration	1	
н	PAPER TYPE	PLAIN	Paper type	Standard paper	0	0
		HEAVY	_	Heavy paper	1	(PLAIN)
		HEAVY2		Heavy paper 2	2	
		GLOSSY	_	Glossy paper	3	
		HEAVY3		Heavy paper 3	4	
I	INTENT	PERCEPTUAL	Rendering indent	Perceptual	0	0
		COLORIMETRIC	_	Color metric	1	(PERCEPTUAL)
		SATURATION		Saturation	2	
J	OUTPUT PROFILE	SHARP	Output profile	Standard	0	0
		STANDARD		Photo image	1	(SHARP)
		GRAPHICS		Graphics	2	
к	RGB SOURCE	SRGB	RGB source profile	SRGB	0	0
	PROFILE	GAMMA1.6		Gamma 1.6	1	(SRGB)
		GAMMA1.8		Gamma 1.8	2	
		GAMMA2.0		Gamma 2.0	3	
		GAMMA2.6		Gamma 2.6	4	
		GAMMA3.0		Gamma 3.0	5	
		TONER SAVE		For TONER SAVE	6	
L	GRAY COMPENSATION	К	Gray print method	Print method K	0	0
1		KCMY		KCMY	1	(K)

Item/Display			Content		Setting range	Default value
Μ	PURE BLACK PRINT	ON	Black monochrome	set.	0	0
		OFF	print	not set.	1	(ON)
Ν	TONER SAVE MODE	OFF	Monochrome toner	not set.	0	0
		ON	save	set.	1	(OFF)

Pattern No.	Content	
1	COLOR	
2	B/W	
3	Continuous COLOR,B/W	
4	4 Service chart (COLOR)	
5	Service chart (B/W)	

64-6				
Purpose	Operation test/check			
Function (Purpose)	Printer test print. (Self print) (PS)			
Section				
Operation/Procedure				

Set the print conditions.
 Select an item to be print condition with scroll keys.
 Set the print conditions with 10-key.
 Select a print color with [K] [C] [M] [Y] key.

 Press [EXECUTE] key. The test print (self print) is performed.

Item/Display			Content	Setting range	Default value	
Α	PRINT PATTERN		Print pattern specification		1 - 2	1
В	DENSITY		Print gradation specifica	tion	1 - 255	255
С	MULTI COUNT		Number of print		1 - 999	1
D	PAPER	MFT	Paper feed tray	Manual paper feed	1	2
		CS1	selection	Tray 1	2	(CS1)
		CS2		Tray 2	3	
		CS3		Tray 3	4	
		CS4		Tray 4	5	
		LCC		LCC	6	
Е	HALFTONE	LOW(IMAGE)	Halftone	For Photo	0	3
		HIGH(TEXT)		For text	1	(AUTO)
		GLOSSY		For glossy paper	2	
		AUTO		Auto (for photo/text)	3	
F	QUALITY	STANDARD	Image quality setting	Standard (600dpi, 1bit)	0	1
		HIGHQUALITY		High quality (600dpi, 4bit)	1	(HIGHQUALITY)
		FINE		Fine (1200dpi, 1bit)	2	
				(26cpm/36cpm/31cpm(A)		
				machine)		
G	DITHER	STRAIGHT	Specification of dither	0: Straight	0	1
		CALIB	correction	1: Calibration	1	(CALIB)
н	PAPER TYPE	PLAIN	Paper type	Standard paper	0	0
		HEAVY		Heavy paper	1	(PLAIN)
		HEAVY2		Heavy paper 2	2	
		GLOSSY		Glossy paper	3	
		HEAVY3		Heavy paper 3	4	
1	INTENT	PERCEPTUAL	Rendering indent	Perceptual	0	0
		COLORIMETRIC		Color metric	1	(PERCEPTUAL)
		SATURATION		Saturation	2	
J	OUTPUT PROFILE	SHARP	Output profile	Standard	0	0
		STANDARD		Photo image	1	(SHARP)
		GRAPHICS		Graphics	2	
к	RGB SOURCE	SRGB	RGB source profile	SRGB	0	0
	PROFILE	GAMMA1.6		Gamma 1.6	1	(SRGB)
		GAMMA1.8		Gamma 1.8	2	
		GAMMA2.0		Gamma 2.0	3	
		GAMMA2.6		Gamma 2.6	4	
		GAMMA3.0		Gamma 3.0	5	]
		TONER SAVE		For TONER SAVE	6	

Item/Display			Content	Setting range	Default value	
L	GRAY COMPENSATION	К	Gray print method	Print method K only	0	0
		KCMY		KCMY	1	(K)
Μ	PURE BLACK PRINT	ON	Black monochrome	set.	0	0
		OFF	print	not set.	1	(ON)
Ν	TONER SAVE MODE	OFF	Monochrome toner	not set.	0	0
		ON	save	set.	1	(OFF)
0	CMY SIMULATION	OFF	CMYK simulation	OFF	0	0
		SWOP		SWOP	1	(OFF)
		EURO		EURO	2	
		JAPAN COLOR		JAPAN COLOR	3	
		TONER SAVE		For TONER SAVE	4	

Pattern No.	Content
1	COLOR
2	B/W

64-7	
Purpose	Operation test/check
Function (Purpose)	Used to print the adjustment pattern of the test print. (Self print). (The adjustment pattern of SIM46-21 is printed.)

### Section

#### **Operation/Procedure**

Set the print conditions.
 Select an item to be print condition with scroll keys.
 Set the print conditions with 10-key.

#### 2) Press [EXECUTE] key.

The adjustment pattern of SIM46-21 is printed.

ŀ	Item/Display			Content	Setting range	Default value	Writing
А	COPIES	6	Nu	mber of print	1 - 999	1	No
В	PROC ADJ	YES	0	The halftone process control correction value is reflected.	0 - 1	1	Yes
		NO	1	The halftone process control correction value is not reflected.			

# 65

65-1	
Purpose	Adjustment
Function (Purpose)	Used to adjust the touch panel (LCD display section) detection coordinates.

### Section Operation panel section

#### **Operation/Procedure**

Touch the center of the cross mark at the four corners of the screen.

When the adjustment is completed normally, the screen shifts to the simulation sub number entry menu.

In case of an error, the screen returns to the adjustment menu.



65-2	
Purpose	Operation check/test
Function (Purpose)	Used to display the touch panel (LCD dis-
	play section) detection coordinates.

#### Section

#### **Operation/Procedure**

Touch the touch panel.

The coordinates X (horizontal direction) and Y (vertical direction) of the touched position is displayed in real time.

۰	٠	٠	*	٠	- 20	٠	•	٠	٠	٠
	₩ ₩120			11: 12:	0 T1: 0 T2:	0			947 120	
۰	*	٠	٠	٠	<b>\$</b> 160	٠	*	٠	*	٠
20	120 P	220	3 <u>20</u>	¥	520 <b>4</b> 300	<b>600</b>	720	*** •	9 <b>2</b> 0	1004
۰	;; ∳*00	٠	٠	٠	<b>\$</b> 440	*	÷	٠	۰ هُ	÷
•	*	*	*	•	<b>\$</b> 580	٠	*	٠	*	•

65-5							
Purpose	Opera	tior	n check	/test			
Function (Purpose)	Used input.	to	check	the	operation	panel	key
Section							

Press the keys sequentially according to the guidance displayed on the screen.

If the key entry is effective, the guidance for pressing the next key is displayed. When all the key entries are completed, "COMPLETE" is displayed.

#### <Check target key>

	10 Inch LCD model	
HOME		



66-1	
Purpose	Setting
Function (Purpose)	Used to display the FAX-related soft SW (2
	- 150) on the LCD to allow changing the
	soft SW while checking with the LCD.

Section

#### **Operation/Procedure**

1) Enter the [SW NO] with 10-key.

FAX

- $^{\ast}\,$  When [C] key is pressed, the entered value of [SW NO] is cleared.
- 2) Press [DATA] button.

The soft SW data entered in procedure 1) is displayed.

- * When [SW NO] button is pressed, the display returns to the initial screen.
- Enter the number corresponding to the bit to be changed with 10-key.
  - * [1] → [0]

 $[0] \rightarrow [1]$ 

 When [EXECUTE] button is pressed, it is highlighted and the setting is saved.

After saving the setting, [EXECUTE] button returns to the normal display.

66-2	
Purpose	Setting
Function (Purpose)	Used to enter a country code and set the
	default value for the country code.

FAX

## Section

**Operation/Procedure** 

- 1) When the machine enters Simulation 66-02, the following screen is displayed.
  - * When [DEST CODE] button is pressed, the display is shifted to the country code list screen.
  - * The currently set country code is displayed in the column of "PRESENT:".
- Enter the country code (8 digits) with 10-key([0]/[1]). The entered country code is displayed in the column of "NEW:" and [SET] key becomes active.
  - * When [C] key is pressed, the column of "NEW:" is cleared.

- When [SET] button is pressed after entering the country code, [EXECUTE] button becomes active. The country code is displayed in the column of "PRESENT:", and the column of "NEW:" is cleared.
- 4) When [EXECUTE] button is pressed, it is highlighted and [YES] and [NO] buttons become active. The country name is displayed on the tile line.
- 5) When [YES] button is pressed, it is highlighted and the soft SW corresponding to the country code is initialized.
- After completion of initialization of the soft SW, [EXECUTE], [YES], and [NO] buttons become inactive.

#### Operation/Procedure (Shifting to the country page)

* When [DEST CODE] button is pressed on the initial screen, the display is shifted to the country code list screen.

Use scroll keys to select the country select page.

#### <Country code list>

JAPAN	0000000
U.S.A.	10110101
AUSTRALIA	00001001
U.K.	10110100
FRANCE	00111101
GERMANY	00000100
SWEDEN	10100101
NEWZEALAND	0111110
CHINA	00100110
SINGAPORE	10011100
TW	1111110
MIDDLEANDNEAREAST	1111101
SLOVAKIA	11111100
OTHER3	11111011
FINLAND	00111100
NORWAY	10000010
DENMARK	00110001
NETHERLANDS	01111011
ITALY	01011001
SWITZERLAND	10100110
AUSTRIA	00001010
INDONESIA	01010100
THAILAND	10101001
MALAYSIA	01101100
INDIA	01010011
PHILIPPINES	10001001
HONGKONG	01010000
RUSSIA	10111000
SOUTHAFRICA	10011111
SPAIN	10100000
PORTUGUESE	10001011
LUXEMBURG	01101001
BELGIUM	00001111
CZECH	00101110
HUNGARY	01010001
GREECE	01000110
POLAND	10001010
BRAZIL	00010110

66-3	
Purpose	Operation test/Check
Function (Purpose)	Used to check read/write of the EEPROM and the SDRAM on the MODEM controller and display the result.
Section	FAX

- 1) When the machine enters Simulation 66-03, the following screen is displayed.
  - * Select the page of memory check item with the scroll key.
- 2) When the memory check item button is selected, the display is shifted to the memory check screen.
- 3) When [EXECUTE] button is pressed, it is highlighted and the memory check of the selected item is started.
- After completion of memory check, [EXECUTE] button returns to the normal display and the result of memory check is displayed.

#### Memory check status

NO CHECK	No check	
CHECKING	During checking	
OK	Check complete OK	
NG A##	Check complete NG	Error occurring address or data line is displayed for each item.

#### Check item

	Check memory item	Remark	
1	All Memory Device Check (once)	All the items are checked	
		once.	
2	MODEM EEPROM <1> (once)	Check only once in LINE1	
3	MODEM EEPROM <1> (repeat)	Repeat check in LINE1	
4	MODEM SDRAM <1> (once)	Check only once in LINE1	
5	MODEM SDRAM<1>(repeat)	Repeat check in LINE1	

The number in < > indicates the line.

66-4		
Purpose	Operation test/Check	
Function (Purpose)	Used to send the selected signals to the line and the main unit speaker. (Send level: max.)	
Section	FAX	

#### **Operation/Procedure**

- 1) When the machine enters Simulation 66-04, the screen on the right is displayed. (Default, left upper selected.)
  - * Use scroll keys to switch the send mode select page.
- When a button of a signal to be sent is selected, it is highlighted and the previously set button is shifted to the normal display.
- When [EXECUTE] button is pressed, it is highlighted and signals are sent.
- 4) To end signal send:

When [EXECUTE] button is pressed, it is highlighted and signal send is interrupted.

#### <Signal send table>

33.6 V34	31.2 V34	28.8 V34
24.0 V34	21.6 V34	19.2 V34
14.4 V34	12.0 V34	9.6 V34
4.8 V34	2.4 V34	14.4 V33
14.4 V17	12.0 V17	9.6 V17
9.6 V29	7.2 V29	4.8 V27t
0.3 FLG	CED 2100	CNG 1100
ANSam	RINGER	No RBT
	33.6 V34 24.0 V34 14.4 V34 4.8 V34 14.4 V17 9.6 V29 0.3 FLG ANSam	33.6 V34         31.2 V34           24.0 V34         21.6 V34           14.4 V34         12.0 V34           4.8 V34         2.4 V34           14.4 V17         12.0 V17           9.6 V29         7.2 V29           0.3 FLG         CED 2100           ANSam         RINGER

#### DP MAKE DP BRK NO MSG

66-5	
Purpose	Operation test/Check
Function (Purpose)	Used to send the selected signal to the line and the main unit speaker. (Send level: Soft SW setting) (For the kinds of send signals, refer to SIM66-04.)
Section	FAX

#### **Operation/Procedure**

- 1) When the machine enters Simulation 66-05, the following screen is displayed.
  - * Use scroll keys to switch the send mode select page.
- When a button of a signal to be sent is selected, it is highlighted and the previously set button is shifted to the normal display.
- 3) When [EXECUTE] button is pressed, it is highlighted and signals are sent.
- 4) To end signal send:
  - * When [EXECUTE] button is pressed, it is highlighted and signal send is interrupted.

66-6	
Purpose	Data output/Check
Function (Purpose)	Used to print the confidential registration check table (BOX NO., BOX name, pass- code. (If there is no confidential registra- tion, no print is made.)
Section	FAX

#### **Operation/Procedure**

- 1) When [EXECUTE] button is pressed, it is highlighted and the confidential checkable is printed.
  - If there is no confidential registration, no print is made even though [EXECUTE] key is pressed.
- 2) After completion of printing, [EXECUTE] button returns to the normal display.

66-7	
Purpose	Data output/Check
Function (Purpose)	Used to output all image data saved in the image memory. (Confidential data are also outputted.)
Section	FAX

- 1) When [EXECUTE] button is pressed, it is highlighted and all image data saved in the image memory are outputted.
- 2) After completion of printing, [EXECUTE] button returns to the normal display.

66-8	
Purpose	Operation test/Check
Function (Purpose) Used to send the selected sour sages to the line and the speake level: Max.)	
Section	FAX

- 1) When the machine enters Simulation 66-08, the following screen is displayed.
- When the sound message button to be sent is selected, it is 2) highlighted and the previously set button returns to the normal display.

#### <Sound message table>

NONE (Mute)	PAUSE (Pause	MESSAGE1	MESSAGE2
	melody)	(Message 1)	(Message 2)
MESSAGE3	MESSAGE4	MESSAGE5	MESSAGE6
(Message 3)	(Message 4)	(Massage 5)	(Message 6)
ALARM (Alarm)	RINGER	EXT.TEL.RING	
	(Ringing sound	ER (External	
	(Speaker))	telephone call)	

66-9	
Purpose	Operation test/Check
Function (Purpose)         Used to send the selected sound me to the line and the speaker. (Send Soft SW setting)           * For details of sound messages, r           the sound message table of SIM66-0	
Section	FAX

#### **Operation/Procedure**

- 1) When the machine enters Simulation 66-09, the following screen is displayed.
- 2) When a button of a sound message to be sent is selected, it is highlighted and the previously set button returns to the normal display.
- When [EXECUTE] button is pressed, it is highlighted and a 3) sound message is sent.
- To end signal send: 4)

When [EXECUTE] button is pressed, it is highlighted and signal send is interrupted.

66-10	
Purpose	Data clear
Function (Purpose)	Used to clear the FAX and image send image data. (The confidential data are also cleared.)
Section	FAX

### **Operation/Procedure**

- 1) Press [EXECUTE] button.
- 2) Press [YES] button.
- 3) After completion of clearing, press [CA] key to reboot the machine.

66-11		
Purpose	Operation test/Check	
Function (Purpose)	Used to send the selected signal at 300bps	
	to the line and the speaker. (Send level: Max.)	
Section	FAX	
Operation/Procedure		

#### Operation/Procedure

- 1) When the machine enters Simulation 66-11, the following screen is displayed.
- When a button of a sound message to be sent is selected, it is 2) highlighted and the previously set button returns to the normal display.
- 3) When [EXECUTE] button is pressed, it is highlighted and a sound message is sent.
- To end signal send: 4)

When [EXECUTE] button is pressed, it is highlighted and signal send is interrupted.

#### <300bps send signal table>

NO SIGNAL	11111	11110	00000
010101	00001		

66-12	
Purpose	Operation test/Check
Function (Purpose)	Used to send the selected signal at 300bps to the line and the speaker. (Send level: Soft SW setting) * For the kings of send signals at 300bps, refer to SIM66-11, 300bps send signal table.
Section	FAX

#### **Operation/Procedure**

- 1) When the machine enters Simulation 66-12, the following screen is displayed.
- When a button of a sound message to be sent is selected, it is 2) highlighted and the previously set button returns to the normal display.
- When [EXECUTE] button is pressed, it is highlighted and a 3) sound message is sent.
- 4) To end signal send: When [EXECUTE] button is pressed, it is highlighted and signal send is interrupted.

66-13	
Purpose	Setting
Function (Purpose)	Used to register dial numbers for SIM66-14/15/16, Dial test. (Up to 20 digits can be registered.)
Section	FAX
Operation/Procedure	

- 1) When the machine enters Simulation 66-13, the following screen is displayed.
  - * The number saved in the memory is displayed in the column of [PRESENT:]. (If there is no data, [------] is displayed.)
- 2) Enter a number with 10-key.

The entered number is displayed in the column of [NEW:]. After entering 20 digits, 10-key is disabled (no response). Only [C] key is enabled. (10-key [0] to [9], [*], [#], [C] key (back by one digit))

3) When [SET] key is pressed after completion of entry, the entered number is displayed (registered) in the column of [PRESENT:]. The column of [NEW:] becomes blank.

66-14	
Purpose	Adjustment
Function (Purpose)	Used to execute the dial pulse (10PPS) send test and to adjust the make time.
Section	FAX

- 1) When the machine enters Simulation 66-14, the following screen is displayed.
- 2) When [EXECUTE] button is pressed, it is highlighted and the dial pulse is sent from the line in the set make time.
- To end the dial test, press [EXECUTE] button again. The button returns to the normal display and the test is terminated.

66-15	
Purpose	Adjustment
Function (Purpose)	Used to execute the dial pulse (20PPS) send test and to adjust the make time.
Section	FAX

#### **Operation/Procedure**

- 1) When the machine enters Simulation 66-15, the following screen is displayed.
- 2) When [EXECUTE] button is pressed, it is highlighted and the dial pulse is sent from the line in the set make time.
  - * The dial pulse in this example is up to 20 digits registered with SIM66-13.
- To end the dial test, press [EXECUTE] button again. The button returns to the normal display and the test is terminated.

66-16	
Purpose	Adjustment
Function (Purpose)	Used to execute the DTFM signal send test and to adjust the send level.
Section	FAX

## Section

- Operation/Procedure
- 1) When the machine enters Simulation 66-16, the following screen is displayed.
- 2) When [EXECUTE] button is pressed, it is highlighted and the dial pulse signal is sent from the line by the setting of high/low group of the signal send level.
- 3) To terminate the dial test, press [EXECUTE] button. The button returns to the normal display and the test is terminated.

### 66-17

Purpose	Operation test/Check
Function (Purpose)	Used to send the DTMF signal to the line
	and the speaker. (Send level: Max.)

FAX

Section

### **Operation/Procedure**

- 1) When the machine enters Simulation 66-17, the following screen is displayed.
- 2) When a button of a send signal is selected, it is highlighted and the previously set button returns to the normal display.
- 3) When [EXECUTE] button is pressed, it is highlighted and signals are sent.
- 4) To stop signal sending:

When [EXECUTE] button is pressed, it returns to the normal display and signal sending is interrupted.

66-18	
Purpose	Operation test/Check
Function (Purpose)	Used to send the DTMF signal to the line and the speaker. (Send level: Soft SW set- ting)
Section	FAX

#### **Operation/Procedure**

- 1) When the machine enters Simulation 66-18, the following screen is displayed.
- 2) When a button of a send signal is selected, it is highlighted and the previously set button returns to the normal display.
- When [EXECUTE] button is pressed, it is highlighted and signals are sent.
- 4) To stop signal sending:

When [EXECUTE] button is pressed, it returns to the normal display and signal sending is interrupted.

66-21	
Purpose	Check
Function (Purpose)	Used to print the selected items (system
	error, protocol monitor).
Section	FAX

#### **Operation/Procedure**

- 1) When an item button to be printed is selected, it is highlighted and the previously set button returns to the normal display.
- Press [EXECUTE] button.
   [EXECUTE] button is highlighted and printing is started.
- 3) After completion of printing, [EXECUTE] button returns to the normal display.

#### <FAX information print content table>

PROTOCOL LINE 1 SYSTEM ERROR LINE 1

66-22	
Purpose	Setting
Function (Purpose)	Used to set the handset sound volume. (This simulation can be executed even though the handset setting is set to NO. When, however, the handset is not installed, the sound volume cannot be checked.) (Japan model only)
Section	FAX

- When the machine enters the simulation, the number of the set sound volume is displayed. (In this example, MIDDLE is set as the default sound volume.)
- 2) Use 10-key to set the handset sound volume. (0: MIN 1:MID-DLE 2:MAX)
- Press [EXECUTE] button to deliver the selected on-hold tone.
   * If, however, the handset is not installed, the sound volume cannot be checked. Execution is possible.
- When [EXECUTE] button is pressed, it is highlighted and delivery of the on-hold tone is stopped.

#### 66-24

Purpose	Data clear
Function (Purpose)	Used to clear the FAST save data.
Section	FAX

#### Operation/Procedure

- 1) Press [EXECUTE] button.
- 2) Press [YES] button.
- The FAST save data are cleared.
- 3) After completion of memory clear, [EXECUTE] button returns to the normal display and [YES] and [NO] buttons gray out.

66-29	
Purpose	Clear
Function (Purpose)	Used to initialize the telephone book data (the one-touch registration table, the FTP/ Desktop expansion table, the group expan- sion table, the program registration table, the interface memory box table, the meta data, InboundRouting, and the Documen- tAdmin table).
Section	FAX

#### Operation/Procedure

1) Press [EXECUTE] button.

2) Press [YES] button.

The telephone book data area cleared.

 After completion of memory clear, [EXECUTE] button returns to the normal display and [YES] and [NO] buttons gray out.

66-30		
Purpose Operation test/Check		
Function (Purpose)	Used to display the TEL/LIU status change, The display is highlighted by status change.	
Section	FAX	

#### Operation/Procedure

- 1) When the machine enters Simulation 66-30, the following screen is displayed.
- HS1, HS2, RHS, and EXHS are highlighted when the signal is detected, and displayed normally when the signal is not detected.

#### <TEL/LIU status change item description>

HS1	Polarity inversion signal
HS2	Polarity inversion signal
RHS	Handset hook SW
EXHS	External telephone hook SW

66-31	
Purpose	Setting
Function (Purpose)	Used to set ON/OFF the port for output to TEL/LIU.
Section	FAX

#### **Operation/Procedure**

- 1) When the machine enters Simulation 66-31, the following screen is displayed.
- 2) Change the port setting.
  - When a port is set to ON, the port display is highlighted.
- When [EXECUTE] button is pressed, the changed setting is reflected to the port which outputs to TEL/LIU.
- To terminate the process, press [EXECUTE] button again. [EXECUTE] button returns to the normal display.

#### <Port which outputs to TEL/LIU>

CION	MR	EC	S.

66-32		
Purpose	Operation test/Check	
Function (Purpose)	Used to check the fixed data received from	
	the line and to display the result.	

### Section FAX

#### **Operation/Procedure**

- 1) Press [EXECUTE] button to check the fixed data received from the line. At that time, [EXECUTE] button is highlighted.
  - * Fixed data check procedure
  - The data received from the line is checked of the following fixed data status for minutes, then if they are in accord with "OK" is displayed on LCD, if not "NG" is displayed.
  - The judgment is made in 2 minutes. Receive speed: 300BPS Receive data: 00H Judgment data: 100byte
- 2) After completion of check, [EXECUTE] button returns to the normal display. The result is displayed as "OK" or "NG."

66-33			
Purpose	Operation test/Check		
Function (Purpose)	Used to execute detection of various sig-		
	nals with the line connected and to display		
	the detection result. When a signal is		
	detected, the display is highlighted.		
Section	FAX		

#### Operation/Procedure

- 1) When the machine enters Simulation 66-33, the following screen is displayed.
- The signal to be checked can be selected from the two options: "FNET" and "BT/CNG/CED/DTMF."
- When a signal is detected, "FNET" and "BUSY TONE CNG CED DTMF" are highlighted. When a signal is not detected, they are normally displayed.

#### <Signal used for signal detection check>

#### FNET

#### (When "BT/CNG/CED/DTMF" is selected)

ſ	BUSY TONE	CNG	CED	DTME
	BUSTIONE	CING	OLD	DTIVI

66-34	
Purpose	Operation test/Check
Function (Purpose)	Used to execute the send test and display
	the time required for sending image data in
	the test. Used to execute send test and dis-

play. (Unit: ms)

#### Section Operation/Procedure

FAX send is performed.

2) Enter the SIM 66-34 mode.

The send time in procedure 1) is displayed.

FAX

66-36	
Purpose	Operation test/Check
Function (Purpose)	Used to check send and receive data from the MODEM controller to the MFP control- ler or the data line or the command line individually.

### Section

#### **Operation/Procedure**

- 1) When the machine enters Simulation 66-36, the following screen is displayed.
- 2) Operation check

Select an item to be checked on the screen.

FAX

#### <MFP controller I/F check item table>

MFP ← MDMC (DATA once)	MFP $\rightarrow$ MDMC (DATA once)
Data line Once	Data line Once
MFP ← MDMC (DATA repeat)	MFP $\rightarrow$ MDMC (DATA repeat)
Data line Repeat	Data line Repeat
MFP $\leftarrow$ MDMC (CMD once)	MFP $\rightarrow$ MDMC (CMD once)
Command line Once	Command line Once
MFP ← MDMC (CMD repeat)	MFP $\rightarrow$ MDMC (CMD repeat)
Command line Repeat	Command line Repeat

66-39	
Purpose	Setting
Function (Purpose)	Used to check and change the destination setting saved in EEPROM of the FAX BOX.
Section	FAX

Operation/Procedure

- When the machine enters the simulation, the currently set destination button is highlighted. (In the default state, JAPAN is set as the destination.)
- Select a destination button to set the destination. (In this example, USA/CANADA is selected.) The selected button is highlighted and the previously selected button returns to the normal display.
  - * When the destination button is changed, the new destination setting is saved to EEPROM of the FAX BOX.

#### <Destination setting table>

JAPAN	U.S.A/CANADA	EUROPE	AUSTRALIA
CHINA	ASIA&OTHERS		

66-42	
Purpose	Setting
Function (Purpose)	Used to rewrite the program to power con- trol installed in the FAX BOX.
Section	FAX

#### Operation/Procedure

- 1) Press [EXECUTE] button.[EXECUTE] button is highlighted and YES] and [NO] buttons become active.
- 2) Press [YES] button.

The power control program is rewritten.

 When rewriting of the power control program is normally completed, "OK" is displayed and [EXECUTE] button returns to the normal display, and [YES] and [NO] buttons gray out.

66-43	
Purpose	Setting
Function (Purpose)	Used to write the adjustment value into the power control installed in the FAX BOX.
Section	FAX

#### Operation/Procedure

- 1) When the machine enters Simulation 66-43, the following screen is displayed.
  - * Use scroll keys to select the select item of the power control adjustment value.
- When [EXECUTE] key is pressed, it is highlighted and writing to the power control is executed. When writing is normally completed, "OK" is displayed. When it is failed, "NG" is displayed.
- After completion of writing, [EXECUTE] key returns to the normal display.

#### <Set range and default value of each set value>

	Item	Set range	Default value
Α	CI_LEVEL_JUDGE	2 to 15	6
В	CI_CYCLE_MIN	1 to 254	10
С	CI_CYCLE_MAX	2 to 255	142
D	CI_COUNT	2 to 15	3
Е	RES_3.3V_LEVEL_JUDGE	2 to 15	15
F	EXHS_LEVEL_JUDGE	2 to 225	240
G	RHS_LEVEL_JUDGE	2 to 15	2
Н	SON_TIMEOUT	1 to 127	20

66-61	
Purpose	Setting
Function (Purpose)	Used to display the FAX-related soft SW (151 - 250) on the LCD to allow changing the soft SW while checking with the LCD.
Section	FAX

#### **Operation/Procedure**

- 1) Enter the [SW NO] with 10-key.
- 2) Press [DATA] button.
  - The soft SW data entered in procedure 1) is displayed.
- Enter the number corresponding to the bit to be changed with 10-key.
  - *  $[1] \rightarrow [0]$

 $[0] \rightarrow [1]$ 

4) When [EXECUTE] button is pressed, it is highlighted and the setting is saved.

66-62	
Purpose	Backup
Function (Purpose)	Used to import the FAX receive data into a
	USB memory in PDF file type.

Section

#### **Operation/Procedure**

1) Insert the USB memory into the main unit.

FAX

- Select data to be imported. 2)
- 3) Press [EXECUTE] key.

Execute import of data selected in procedure 2).

When the operation is completed normally, [COMPLETE] is displayed. In case of an abnormal end, [ERROR] is displayed.

Error display	Content
ERROR: NO USB MEMORY DEVICE	No USB memory installed
ERROR: NO IMAGE DATA	No image data
ERROR	Other errors

# 67

67-17		
Purpose	Reset	
Function (Purpose)	Printer reset	
Section	Printer	
<b>Operation/Procedure</b>	•	

1) Press [EXECUTE] key.

- Press [YES] key. 2)
  - The set data related to the printer are initialized. (Including the NIC setting.)

When the operation is completed, [EXECUTE] key returns to the normal display.

67-24					
Purpose	Adjustm	nent/Se	etup		
Function (Purpose)	Printer	color	balance	adjustment	(Auto
	adjustm	nent)			
Section	Printer				

**Operation/Procedure** 

1) Press [EXECUTE] key.

The color patch image (adjustment pattern) is printed out.

- 2) Plate the printed adjustment pattern on the document table, select [FACTORY] or [SERVICE] mode.
- Press [EXECUTE] key. 3)

The printer color balance auto adjustment is performed, and the adjustment result is printed.

Press [OK] key. 4)

The halftone correction target registration is processed.

67-25	
Purpose	Adjustment/Setup
Function (Purpose)	Printer color balance adjustment (Manual adjustment)
Section	Printer

#### **Operation/Procedure**

- 1) Select an adjustment target color with [K][C][M][Y] keys on the touch panel.
- 2) Select a target adjustment density level with scroll key on the touch panel.
- Enter the set value with 10-key. 3)
  - * When the  $\triangle \bigtriangledown$  key is pressed, the setting value of each item can be changed with 1up (1down) collectively.
- 4) Press [OK] key. (The set value is saved.)

When the adjustment value is increased, the image density is increased, and vice versa.

When [EXECUTE] key is pressed, the check pattern in printed in the color balance and density corresponding to the adjustment value.

Item/Display		Setting range	Default value
Α	POINT1	1 - 999	500
В	POINT2	1 - 999	500
С	POINT3	1 - 999	500
D	POINT4	1 - 999	500
ш	POINT5	1 - 999	500
F	POINT6	1 - 999	500
G	POINT7	1 - 999	500
Н	POINT8	1 - 999	500
-	POINT9	1 - 999	500
J	POINT10	1 - 999	500
К	POINT11	1 - 999	500
L	POINT12	1 - 999	500
Μ	POINT13	1 - 999	500
Ν	POINT14	1 - 999	500
0	POINT15	1 - 999	500
Ρ	POINT16	1 - 999	500
Q	POINT17	1 - 999	500

67-26			
Purpose	Adjustment/Setup		
Function (Purpose)	Used to set the target color balance of the printer mode auto color balance adjustment.		
Section	Printer		
Operation/Procedure			

Operation/Procedure

1) Select the target color balance with the touch panel.
| Item/Display                       |      | Content                                                                                                                                                                                                                                                                                                | Default<br>value |
|------------------------------------|------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------|
| Target<br>value<br>table<br>select | DEF1 | The engine color balance adjustment<br>target in the automatic color balance<br>operation is slightly shifted to Magenta.<br>When this target is selected, the color<br>balance is converted into natural gray<br>color balance by the color table in an<br>actual printer mode and print is made.     | DEF 1            |
|                                    | DEF2 | The engine color balance adjustment<br>target in the automatic color balance<br>operation is slightly shifted to natural gray<br>color balance. When this target is<br>selected, the color balance is slightly<br>shifted to Cyan by the color table in an<br>actual copy mode and print is made.      |                  |
|                                    | DEF3 | The engine color balance adjustment<br>target in the automatic color balance<br>operation is slightly shifted to Cyan. When<br>this target is selected, the color balance is<br>converted into the color balance with<br>enhanced Cyan by the color table in an<br>actual copy mode and print is made. |                  |

67-27	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the service target of the printer
	mode auto color balance adjustment.

#### Section Printer

**Operation/Procedure** 

- 1) Press [SETUP] key on the touch panel.
- 2) Place the printed color balance adjustment pattern sheet printed in SIM 67-25 on the document table.
- 3) Press [EXECUTE] key.

The patch image of the adjustment pattern sheet is scanned.

4) Press [OK] key.

The service target of the printer mode auto color balance adjustment is set according to the scanned adjustment pattern sheet patch images.

The registered color balance and the density are displayed. Select a target color with [C] [M] [Y] [K] key.

#### Important

This simulation is executed only when the printer color balance is manually adjusted.

В	Point B target value
С	Point C target value
D	Point D target value
ш	Point E target value
F	Point F target value
G	Point G target value
Н	Point H target value
-	Point I target value
J	Point J target value
К	Point K target value
L	Point L target value
М	Point M target value
Ν	Point N target value
0	Point O target value
BASE	Background sampling value

67-28		
Purpose	Adjustment/Setup	
Function (Purpose)	Used to set the default of the service target	
	of the printer mode auto color balance adjustment.	
Section	Printer	
Operation/Procedure		
1) Press [EXECUTE	E] key.	
2) Press [YES] key.		
The service target of the printer mode auto color balance		

adjustment is set to the default.

The service color balance target and the color balance target for the user color balance adjustment are set to the same color balance as the factory color balance target.

67-31	
Purpose	Data clear
Function (Purpose)	Used to clear the printer calibration value.
Section	Printer

#### **Operation/Procedure**

1) Press [EXECUTE] key.

2) Press [YES] key.

The printer calibration data (Halftone correction data) are cleared.

(The printer color balance correction is canceled.)

67-33	
Purpose	Adjustment/Setup
Function (Purpose)	Used to change the gamma of the printer
	screen.
Section	Printer

#### **Operation/Procedure**

- 1) Select a target change color with [K] [C] [M] [Y] key on the touch panel.
- 2) Select a target screen with [SCREEN] key.
- 3) Select a target adjustment density level with scroll key.
- 4) Enter the set value with 10-key.
- 5) Press [OK] key. (The set value is saved.)

When [EXECUTE] key is pressed, the check pattern in printed in the color balance and density corresponding to the adjustment value.

Item/Display		Content	Setting range	Default value
Α	POINT1	Point 1	0 - 255	128
В	POINT2	Point 2	0 - 255	128
С	POINT3	Point 3	0 - 255	128
D	POINT4	Point 4	0 - 255	128
Е	POINT5	Point 5	0 - 255	128
F	POINT6	Point 6	0 - 255	128
G	POINT7	Point 7	0 - 255	128
Н	POINT8	Point 8	0 - 255	128
Ι	POINT9	Point 9	0 - 255	128
J	POINT10	Point 10	0 - 255	128
K	POINT11	Point 11	0 - 255	128
L	POINT12	Point 12	0 - 255	128
М	POINT13	Point 13	0 - 255	128
Ν	POINT14	Point 14	0 - 255	128
0	POINT15	Point 15	0 - 255	128
Р	POINT16	Point 16	0 - 255	128
Q	POINT17	Point 17	0 - 255	128

#### PCL/PS printer

Display	Content
SCREEN1	600dpi 1bit Photo
SCREEN2	600dpi 1 bit Graphics
SCREEN3	600dpi 4 bit Photo
SCREEN4	600dpi 4 bit Graphics
SCREEN7	B/W 600dpi 1 bit
SCREEN8	B/W 600dpi 4 bit
SCREEN10	Gloss 600dpi 4bit
HEAVY PAPER	Printer paper kind manual gamma correction
	(Heavy paper)

67-34	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the density correction in the
	printer high density section. (Support for the high density section tone gap)

Section

Printer

#### **Operation/Procedure**

1) Enter the set value with 10-key.

0	Enable
1	Disable

2) Press [OK] key. (The set value is saved.)

Item/Display		Content		Setting range	Default value
A	CMY (0: ENABLE 1: DISABLE)	0	CMY engine highest density correction mode: Enable	0 - 1	0
		1	CMY engine highest density correction mode: Disable		
В	K (0: ENABLE 1: DISABLE)	0	K engine highest density correction mode: Enable	0 - 1	1
		1	K engine highest density correction mode: Disable		
С	CYAN MAX TARGET	Sca CYA corr	nner target value for N maximum density ection	0 - 999	500
D	MAGENTA MAX TARGET	Sca MAC corr	nner target value for GENTA maximum density ection	0 - 999	500
E	YELLOW MAX TARGET	Scanner target value for YELLOW maximum density correction		0 - 999	500
F	BLACK MAX TARGET	Scanner target value for BLACK maximum density correction		0 - 999	500

• When tone gap is generated in the high density section, set items A and B to "0."

The density in the high density section is decreased, but tone gap is reduced.

• To increase the density in the high density section further, set items A and B to "1.

The tone gap may occur in high density part.

#### Important

Do not change the values of items C, D, E, and F. If these values are changed, the density in the high density area is changed.

67-36				
Purpose	Adjustment/Setup			
Function (Purpose)	Used to adjust the density in the low den- sity section.			
Section	Printer			

#### **Operation/Procedure**

- 1) Enter the adjustment value using the 10-key.
- 2) Press [OK] key.

When the adjustment value is increased, the low density images are strongly reduced. When the adjustment value is decreased, the low density are images are weakly reproduced.

When tone gap is generated in the low density section (highlight section), changing this adjustment value may improve the trouble.

Item/Display		Content	Setting range	Default value
A	A PATCH INPUT	A patch input value	0 - 13	1

67-41	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the threshold for judging the selected color printing or the black color printing in the black and white mode.
Section	Printer
Operation/Presedure	

#### Operation/Procedure

- 1) Select a set value with the scroll key.
- 2) Enter the set value with 10-key.
- 3) Press [OK] key.

Item/Display		Content	Setting range	Default value
Α	C1	Mode1 : Threshold of Saturation	0 - 255	5
В	V1	Mode1 : Threshold of Brightness	0 - 255	0
С	C2	Mode2 : Threshold of Saturation	0 - 255	5
D	V2	Mode2 : Threshold of Brightness	0 - 255	0

67-42	
Purpose	Adjustment
Function (Purpose)	Used to adjust the gradation by increasing / decreasing the selected color componet amount or the black color component amount in the black and white mode.
Section	Printer

#### **Operation/Procedure**

- 1) Select Mode1 or Mode2.
- 2) Select an item to be set.

Mode	Item/Display		Content	Default value
	Black	F1	Black : Light	F2
	(Achromatic	F2	Black : Normal	
MODE	color)	F3	Black : Dark	
1	COLOR	G1	Selected color : Light	G2
	(Selected	G2	Selected color : Normal	
	color)	G3	Selected color : Dark	
	Black	F1	Black : Light	F2
	(Achromatic	F2	Black : Normal	
MODE	color)	F3	Black : Dark	
2	COLOR	G1	Selected color : Light	G2
	(Selected	G2	Selected color : Normal	
	color)	G3	Selected color : Dark	

#### 67-43

Purpose

Se Adjustment

Function (Purpose) 2 Color mode balance adjustment

Section Printer

**Operation/Procedure** 

- 1) Select an adjustment item with the scroll key.
- 2) Enter the set value with 10-keys.
- 3) Press [OK] key.

				Setting	Def	ault va	lue
lt	em/Display	Content	Color	range	С	М	Y
A	RED	R output color	CMY	0 - 255	0	235	224
В	GREEN	G output color	CMY	0 - 255	180	0	241
С	BLUE	B output color	CMY	0 - 255	235	159	0
D	CYAN	C output color	CMY	0 - 255	182	0	25
E	MAGENTA	M output color	CMY	0 - 255	0	271	0
F	YELLOW	Y output color	CMY	0 - 255	0	0	234

67-45						
Purpose	Adjustment/Setup					
Function (Purpose)	Used to adjust the printer image filter and trapping.					
Section	Printer					

**Operation/Procedure** 

- 1) Select an adjustment item with the scroll key.
- 2) Enter the set value.
- 3) Press [OK] key.

Item/Display		Content	Setting range	Default value	NOTE
A	SHARPNESS: COLOR PRINT	Color print	0 - 4	2	The greater the set value
В	SHARPNESS: B/W PRINT	Monochrome print	0 - 4	2	is, the stronger the filer enhancement is. The smaller the set value is, the stronger the filter smoothness is. (0: Soft High, 1: Soft Low, 2: Center, 3: Sharp Low, 4: Sharp High)

	Item/Display	Content	Setting range	Default value	NOTE
С	TRAPPING: CMY (PCL & DIRECTPRINT)	CMY (PCL, Direct Print)	0 - 5	3	The greater the set value is, the
D	TRAPPING: K (PCL & DIRECTPRINT)	K (PCL, Direct Print)	0 - 5	3	stronger the trapping is. (0: OFF, (Low)
Е	TRAPPING: CMY (PS)	CMY (PS)	0 - 5	3	1 < 2 < 3 < 4 < 5)
F	TRAPPING: K (PS)	K (PS)	0 - 5	0	(The target is vector images.
G	TRAPPING: CMY (XPS)	CMY (XPS)	0 - 5	0	I here is no effect for the
Н	TRAPPING: K (XPS)	K (XPS)	0 - 5	0	images.) However, the sharpness also varies.

67-52	
Purpose	Adjustment/Setup
Function (Purpose)	Used to set the default of the gamma of the printer screen.
Section	Printer

#### **Operation/Procedure**

- Select a target default setting mode with the touch panel. Press [ALL] key to select all the modes.
- 2) Press [EXECUTE] key and press [YES] key.

When the printer screen gamma was changed by SIM 67-33, SIM67-54, it is reset to the default.

#### PCL/PS printer

lte	m/Display	Content
Screen HEAVYPAPER		Heavy paper screen
		Printer heavy paper automatic density
		correction amount
	1200DPI_1BIT	SCREEN5 (1200dpi 1bit Photo)
		SCREEN6 (1200dpi 1bit Graphics)
600DPI_1BIT		SCREEN1 (600dpi 1bit Photo)
		SCREEN2 (600dpi 1bit Graphics)
Screen	B/W	SCREEN7 (600dpi 1bit Graphics)
		SCREEN8 (600dpi 4bit Graphics)
		SCREEN9 (120dpi 1bit Graphics)
		Printer B/W toner save automatic density
		correction amount
	GLOSSPAPER	SCREEN10 (Glossy paper screen)
	4BIT_GRAPHIC S	SCREEN4 (600dpi 4bit Graphics)

67-54	
Purpose	Adjustment
Function (Purpose)	Printer color balance adjustment

Section Printer

#### **Operation/Procedure**

This simulation is used to adjust the color balance, the density, and the gradation in the monochrome mode, the heavy paper mode, the 1200dpi mode, and the 600dpi 1bit mode.

This simulation is used to improve image quality in these modes and images.

1) Press [EXECUTE] key. (A3 or 11" x 17" paper is automatically selected.)

The color patch image (adjustment pattern) is printed out.

- 2) Set the color patch image (adjustment pattern) printed in the procedure 1) on the document table so that the thin lines on the printed color patch image (adjustment pattern) are on the left side. Place 5 sheets of white paper on the printed color patch image (adjustment pattern).
- 3) Press [EXECUTE] key.

The color balance adjustment is automatically performed. The adjustment pattern is printed out. Check it for any abnormality.

4) Press [OK] key.

The list of the adjustment items (for each dither) is displayed.

5) Select an adjustment item (for each dither).

Select item (Mode)	Content
Heavy Paper	Adjustment item to improve the color balance in the heavy paper mode
B/W	Adjustment item to improve the density and gradation in the monochrome mode
Glossy	Adjustment item to improve the color balance in glossy paper mode
1200dpi 1bit	Adjustment item to improve the color balance in 1200dpi mode
4BIT_GRAPHI CS	Adjustment item to improve the color balance in 600dpi, 4bit Graphic mode

6) Press [EXECUTE] key. (A3 or 11" x 17" paper is automatically selected.)

The color patch image (adjustment pattern) is printed out.

- 7) Set the color patch image (adjustment pattern) printed in the procedure 6) on the document table so that the thin lines on the printed color patch image (adjustment pattern) are on the left side. Place 5 sheets of white paper on the printed color patch image (adjustment pattern).
- 8) Press [EXECUTE] key.

The color balance adjustment is automatically performed, and the color balance check patch image is printed out.

9) When [OK] key is pressed, the adjustment result is registered and the adjustment mode is terminated. When [EXECUTE] key is pressed, the adjustment result is registered and the screen is shifted to the other item (Mode/Image) select menu.

To execute the adjustment of the other item (Mode/Image), press [EXECUTE] key.

After completion of all the adjustments of the items (Mode/ Image), press [OK] key, and the adjustment results are registered.

10) Make a print, and check the print image quality.

#### Note

Use SIM67-52 to reset the adjustment values to the default values.

## [7] TROUBLESHOOTING

#### 1. Error code and troubleshooting

#### A. General

When a trouble occurs in the machine or when the life of a consumable part is nearly expired or when the life is expired, the machine detects and displays it on the display section. This allows the user and the serviceman to take the suitable action. In case of a trouble, this feature notifies the occurrence of a trouble and stops the machine to minimize the damage.

#### B. Function and purpose

- 1) Securing safety. (The machine is stopped on detection of a trouble.)
- 2) The damage to the machine is minimized. (The machine is stopped on detection of a trouble.)
- By displaying the trouble content, the trouble position can be quickly identified. (This allows to perform an accurate repair, improving the repair efficiency.)
- Preliminary warning of running out of consumable parts allows to arrange for new parts in advance of running out. (This avoids stopping of the machine due to running out the a consumable part.)

#### C. Self diag message kinds

The self diag messages are classified as shown in the table below.

Class 1	User	Warning of troubles which can be recovered by the user. (Paper jam, consumable part life expiration, etc.)
	Service	Warning of troubles which can be recovered only by a serviceman. (Motor trouble, maintenance, etc.)
	Others	-
Class 2	Warning	Warning to the user, not a machine trouble (Preliminary warning of life expiration of a consumable part, etc.)
	Trouble	Warning of a machine trouble. The machine is stopped.
	Others	-

#### D. Self diag operation

The machine always monitors its own state.

When the machine recognizes a trouble, it stops the operation and displays the trouble message.

A warning message is displayed when a consumable part life is nearly expired or is expired.

When a warning message is displayed, the machine may be or may not be stopped.

The trouble messages and the warning messages are displayed by the LCD and lamp.

Some trouble messages are automatically cleared when the trouble is repaired. Some other troubles must be cleared by a simulation.

Some warning messages of consumable parts are automatically cleared when the trouble is repaired. Some other warning messages must be cleared by a simulation.



#### E. Breakdown sequence

#### (1) Error code and operatable mode

				Operatable mode								
Troub	le content	Judg- ment block	Trouble code	Copy scan (including interrup- tion)	Scan (Push)	Scan (Pull)	Scan- To HDD	Print	List print	FAX Send	FAX print	FAST Notifi- cation to host
FAX board trouble	<ul> <li>FAX board breakdown</li> </ul>	MFP	F6 (00, 01, 04, 21, 30, 97, 98)	0	0	0	0	0	0	-	-	-
HDD trouble	<ul> <li>SD card breakdown</li> </ul>		E7 (07)	×	×	×	×	×	×	×	×	×
	HDD breakdown		E7 (03, 05, A5)	×	×	×	×	×	×	×	×	×
	HDD-ASIC breakdown		E7 (04)	×	×	×	×	×	×	×	×	×
Scanner communication trouble	SCU communication error		A0 (02) E7 (80)	×	×	×	×	0	0	×	0	0
Engine communication trouble	PCU communication error		A0 (01) E7 (90)	×	×	×	×	×	×	×	×	0
Option communication trouble	ACU communication trouble		A0 (04)	×	×	×	×	×	×	×	×	0
Backup battery voltage fall trouble	Backup battery voltage fall		U1 (01)	×	×	×	×	×	×	×	×	0
Operation disable trouble 1	Controller fan trouble		L4 (30)	×	×	×	×	×	×	×	×	×
Operation disable trouble 2	External serial I/F communication error (RIC)		U7 (50, 51)	×	×	×	×	×	×	×	×	0
	Memory error (included not installed the expansion RAM)		U2 (00, 11, 40, 41, 42)	×	×	×	×	×	×	×	×	△15
	Connection trouble (Model data discrepancy) (MFPC detection)		A0 (10, 11, 14 15, 16, 17, 20) E7 (60, 61, 65, 89)	×	×	×	×	×	×	×	×	×
	<ul> <li>Serial number data error</li> </ul>		U2 (30)	×	×	×	×	×	×	×	×	×
	HDD registration data check sum error		U2 (50)	×	×	×	×	×	×	×	×	0
Operation disable trouble 3	Memory check     error when     booting		E7 (96)	×	×	×	×	×	×	×	×	0
	Image memory trouble, decode error		E7 (01, 49, 91, 92, 93, 94)	×	×	×	×	×	×	×	×	0
	<ul> <li>Image memory trouble, decode error (Image high compression)</li> </ul>		E7(42,46,47,4 8)	×	△17	×	×	×	0	0	0	0
Operation disable trouble 4	Personal counter connection trouble		PC (00)	×	×	×	×	×	×	×	×	0
Power controller trouble	Power controller error		L8 (20)	×	×	×	×	×	×	×	×	0
Special function trouble	Watermark data     error		U2 (60) P1 (00, 01, 02)	0	0	0	0	0	0	0	0	0

Operatable							atable mode							
Troub	le content	Judg- ment block	Trouble code	Copy scan (including interrup- tion)	Scan (Push)	Scan (Pull)	Scan- To HDD	Print	List print	FAX Send	FAX print	FAST Notifi- cation to host		
Laser trouble	LSU breakdown	PCU	E7 (20, 24, 28, 29, A0) L6 (10)	×	×	×	×	×	×	×	× *10	0		
Engine trouble 1	Connection trouble (Model data discrepancy) (PCU detection)		A0 (21) E7 (50, 55) F1 (50)	×	×	×	×	×	×	×	×	×		
Engine trouble 2	PCU troubles (motor, fusing, etc.)		$\begin{array}{c} C1 \ (10, \ 14) \\ C4 \ (00) \\ F2 \ (22, \ 40, \ 64, \\ 70, \ 74, \ 91) \\ H2 \ (00, \ 01, \\ 02, \ 03) \\ H3 \ (00, \ 01, \\ 02) \\ H4 \ (00, \ 01, \\ 02) \\ H4 \ (00, \ 01, \\ 02) \\ H5 \ (01) \\ H7 \ (10, \ 11) \\ L4 \ (02, \ 03, \ 04, \\ 05, \ 06, \ 07, \ 11, \\ 12, \ 16, \ 31, \ 32, \\ 34, \ 35, \ 43, \ 50, \\ 51) \\ L8 \ (01, \ 02) \\ U2 \ (90, \ 91) \end{array}$	×	×	×	×	×	×	×	× *10	0		
Process system trouble	<ul> <li>LSU/Process system breakdown</li> </ul>		$ \begin{array}{c} {\sf E7} (21,22,\\ 23,25,26,27,\\ {\sf A1},{\sf A2},{\sf A3})\\ {\sf F2} (23,24,25,\\ 41,42,43,65,\\ 66,67,71,72,\\ 73,75,76,77,\\ 92,93,94) \end{array} $	× *19	× *19	× *19	× *19	× *19	× *19	× *19	× *10 *19	0		
Paper feed tray 1 trouble	<ul> <li>Paper feed tray 1 breakdown</li> </ul>		F3 (12)	∆3	0	0	0	∆3	∆3	0	∆3 *10	0		
Paper feed tray 2 trouble	<ul> <li>Paper feed tray 2 breakdown</li> </ul>		F3 (22)	∆3	0	0	0	∆3	∆3	0	∆3 *10	0		
Paper feed tray 3 trouble	Paper feed tray 3     breakdown		U6 (01)	∆3	0	0	0	∆3	∆3	0	∆3 *10	0		
Paper feed tray 4 trouble	<ul> <li>Paper feed tray 4 breakdown</li> </ul>		U6 (02)	∆3	0	0	0	∆3	∆3	0	∆3 *10	0		
Paper feed tray 5 trouble	Paper feed tray 5     breakdown		U6 (03, 09, 20, 21, 22, 51, 52)	∆3	0	0	0	∆3	∆3 *10	0	∆3	0		
Paper feed tray other troubles	<ul> <li>Paper feed tray other breakdown</li> </ul>		U6 (00, 10, 50, 52)	∆11	0	0	0	∆11	∆11	0	∆11 *10	0		
Staple trouble	Staple breakdown		F1 (08, 10)	△4	∆4	∆4	∆4	∆4	∆4	∆4	∆4 *10	0		
Saddle stitch section trouble	<ul> <li>Saddle stitch section breakdown</li> </ul>		F1(31, 41, 43, 45, 47)	∆4	∆4	∆4	∆4	∆4	∆4 *10	∆4	∆4	0		
Finisher trouble	After-process     breakdown		F1 (00, 03, 11, 15, 19, 20, 21, 32, 33, 34, 36, 37, 38, 39)	△4	△4	∆4	△4	∆4	∆4	∆4	∆4 *10	0		
Other troubles	Other troubles		EE (EC, EL, EU)	0	0	0	0	0	0	0	0	0		
Process control trouble	<ul> <li>Process control breakdown (PCU detection)</li> </ul>		F2 (39, 49, 50, 51, 58, 78)	0 *12	0	0	0	0	0	0	0	0		

							Operat	able mo	ode			
Troub	le content	Judg- ment block	Trouble code	Copy scan (including interrup- tion)	Scan (Push)	Scan (Pull)	Scan- To HDD	Print	List print	FAX Send	FAX print	FAST Notifi- cation to host
Operation disable trouble	Connection trouble (Model data discrepancy) (SCU detection)	SCU	A0 (22)	×	×	×	×	×	×	×	×	×
SCU CPT ASIC trouble	SCU CPT ASIC     error		UC (02)	∆9	∆9	∆9	∆9	0	0	∆9	0	0
SCU ASIC trouble (SCU detection)	SCU ASIC error (SCU detection)		UC (20)	×	×	×	×	0	0	×	0	0
Scanner trouble	<ul> <li>SCU EEPROM error</li> </ul>		U2 (80, 81)	×	×	×	×	0	0	×	0	0
Scanner trouble 2	<ul> <li>Touch panel breakdown</li> </ul>		U9 (01)	×	×	×	×	0	0	×	0	0
	<ul> <li>Scanner section breakdown (mirror motor, lens, copy lamp)</li> </ul>		L1 (00) L3 (00)	×	×	×	×	0	0	×	0	0
CCD trouble	<ul> <li>CCD breakdown (shading, etc.)</li> </ul>		E7 (10, 11, 14)	×	×	×	×	0	0	×	0	0

#### Error where only history data are saved

						Operata	ble moo	le			
Trouble content	Judg- ment block	Trouble code	Copy scan (including interrup- tion)	Scan (Push)	Scan (Pull)	Scan- To HDD	Print	List print	FAX Send	FAX print	FAST Notifi- cation to host
Error history	PCU	F2 (45)	0	0	0	0	0	0	0	0	0
	MFP	E7(02), U2(05)	0	0	0	0	0	0	0	0	0

O: Operation enabled X: Operation disabled

riangle1: The operation is enabled in a line other than the trouble line.

riangle 3: When detected during other than a job, the operation is enabled with a tray other than the trouble tray.

 $\triangle$ 4: When detected during other than a job, the operation is enabled in a section other than the trouble paper exit section. * However, it is valid only when the escape tray setting has been made.

 $\triangle$ 9: When detected during other than a job, the operation is enabled in the black and white mode.

*10: Since communication is enabled, reception can be transferred.

riangle11: When detected during other than a job, the operation is enabled in other than the DESK and the LCC.

*12: A trouble message is displayed. (Example: Ready to copy. F2 trouble)

 $\triangle$ 15: FAST notification function (When in U2-22, trouble notification cannot be made. If there is no abnormality in the FAX software or the FAST data in U2-23, trouble notification can be made.)

 $\triangle$ 17: Job execution enable only in a format other high compression PDF.

*19: When the color mode is set to disable in the "Color mode disable setting" of the system setting, the operation is enabled in the black and white mode.

#### (2) Trouble detection sequence and trouble cancel sequence when turning on the power



#### The process has priority when the power is turned ON with the MFP.

When booting, two or more troubles in the list below may be detected. In this case, the trouble code of higher priority is displayed.

Process sequence	Error	code	Content
	U2	60	Watermark check error
		50	HDD user authentication data check sum error
		30	MFPC PWB and PCU PWB manufacturing No. data inconsistency
		24	User authentication counter check sum error
First		10	User authentication index check sum error
(Low priority)	A0	15	Incompatible DSK BOOT and program firmware
*		20	Conflict firmware and EEPROM data version (MFP)
	U2	11	MFPC PWB EEPROM counter check sum error
.L		00	MFP EEPROM read/write error
¥	E7	48	Scanner expansion PWB ASIC memory error
Last		42	Image data trouble (Scanner expansion PWB (ACRE) ASIC)
(High priority)		96	MFPC PWB DRAM memory check error (MFPC PWB)
		95	SoC DRAM memory check error (PRINTER section)
	U1	01	Battery trouble
	E7	60	Combination error between PWB and firmware (MFPC PWB detection)
	A0	04	Scanner expansion PWB (ACU) ROM error



### F. Error code list

Troubl	e code							
Main code	Sub code	Trouble content	detection	Mechanism	Option	Electricity	FAX	Supply
A0	01	PCU PWB ROM error	MFP			0		
	02	SCU PWB ROM error	MFP			0		
	04	Scanner expansion PWB (ACU) (ACRE) ROM error	MFP			0		
	10	Color profile error	MFP			0		
	11	Firmware version inconsistency (MFP - PCU)	MFP			0		
	14	Inconsistency between the MFP and the CPU firmware version	MFP			0		
	15	Incompatible DSK BOOT and program firmware	MFP			0		
	16	Data error of the energy-saving NIC controller firmware in the SD card	MFP			0		
	17	Inconsistency between the UI data and the CPU firmware version	MFP			0		
	20	Conflict firmware and EEPROM data version (MEP)	MEP			0		
	20	Conflict firmware and EEPPOM data version (MIT)	PCU			0		
	21	Conflict firmware and EEPPOM data version (FCO)	SCU			0		
C1	10	Main charger traukle (Manachrome)	PCU			0		
U1	10	Main charger trouble (Monochrome)	PCU			0		
04	14		PCU			0		
64	00	PTC trouble (TC high voltage trouble)	PCU			0		
E/	01	MFP image data error	MFP		-	0		
	02	HDD trouble when the mirroring kit is installed	MFP		0			
	03	HDD trouble / Mirroring kit error	MFP			0		
	04	HDD-ASIC error	MFP			0		
	07	SD card error	MFP			0		
	10	Shading error (Black correction)	SCU			0		
	11	Shading error (White correction)	SCU			0		
	14	CCD-ASIC error	SCU			0		
	20	LSU laser detection error (K)	PCU			0		
	21	LSU laser detection error (C)	PCU			0		
	22	LSU laser detection error (M)	PCU			0		
	23	LSU laser detection error (Y)	PCU			0		
	24	LSU LD driver trouble (K)	PCU			0		
	25	LSU LD driver trouble (C)	PCU			0		
	26	LSU LD driver trouble (M)	PCU			0		
	27	I SULD driver trouble (Y)	PCU			0		
	28	I SUL PCI connection error	PCU			0		
	29		PCU			0		
	42	Image data trouble (Scapper expansion PWB (ACRE) ASIC)	MED			0		
	42	Image data trouble (Scanner expansion 1 WB (ACRE) ASIC)	MED			0		
	40	Intrage data decode entit (Scanner expansion P WB (ACRE) ASIC)	MED			0		
	47					0		
	40	Scanner expansion PWB (ACRE) ASIC memory enor				0		
	49	water Mark data error	MFP			0		
	50	Combination error between PWB and firmware (PCU PWB detection)	PCU			0		
	55	PCU PWB information sum error	PCU			0		
	60	Combination error between PWB and firmware (MFPC PWB detection)	MFP			0		
	61	Combination error between the MFPC PWB and the PCU PWB	MFP			0		
	65	(MEP C PWB delection)	MED					
	00		MED			0		
	89	Communication error between MFPC PWB CPU and energy-saving NIC	MFP			0		
		controller	MER					
	90	MEP - PCU PWB communication error	MFP			0	_	
	91	FAX reception image data error	MFP			_	0	
	92	Copy image data error	MFP			0		
	93	Copy, image send, FAX, filing, print image data process error	MFP			0		
	94	Image file data process error (when importing file data)	MFP			0		
	96	MFPC PWB memory check error	MFP			0		
	A0	LSU EEPROM/LD driver read/write error (K)	PCU			0		
E7	A1	LSU EEPROM/LD driver read/write error (C)	PCU			0		
	A2	LSU EEPROM/LD driver read/write error (M)	PCU			0		
	A3	LSU EEPROM/LD driver read/write error (Y)	PCU			0		
	A5	Installation error of HDD which was used in the mirroring kit	MFP		0			
EE	EC	Automatic toner density adjustment error	PCU			0		
	EL	Automatic toner density adjustment error (Over toner)	PCU			0		
	EU	Automatic toner density adjustment error (Under toner)	PCU			0		

Troubl	e code		Trouble					
Main code	Sub code	Trouble content	detection	Mechanism	Option	Electricity	FAX	Supply
F1	00	Finisher - PCU PWB communication error	PCU		0			
	03	Finisher paper exit roller lifting operation trouble	PCU		0			
	08	Stapler shift trouble	PCU		0			
	10	Staple operation trouble	PCU		0			
	11	Finisher grip motor trouble	PCU		0			
	15	Finisher paper exit tray lift operation trouble	PCU		0			
	19	Finisher alignment operation trouble F	PCU		0			
	20	Finisher alignment operation trouble R	PCU		0			
	21	Finisher fan trouble	PCU		0			
	31	Finisher saddle motor trouble (Saddle stitch finisher) (FSFOM)	PCU		0			
	32	Communication error between the finisher and the punch unit (Saddle stitch finisher)	PCU		0			
	33	Punch unit shift operation trouble	PCU		0			
	34	Punch operation trouble	PCU		0			
	36	Punch paper edge detection error	PCU		0			
	37	Finisher data backup RAM error	PCU		0			
	38	Punch data backup RAM error	PCU		0			
	39	Punch paper dust sensor error	PCU		0			
	41	Saddle paper positioning operation trouble	PCU		0			
	43	Saddle alignment operation trouble	PCU		0			
	45	Saddle staple trouble	PCU		0			
	47	Saddle paper transport motor trouble	PCU		0			
	50	Main unit - Finisher combination error	PCU		0			
F2	22	Discharge lamp trouble (K)	PCU		-			0
	23	Discharge lamp trouble (C)	PCU					0
	24	Discharge lamp trouble (M)	PCU					0
	25	Discharge Jamp trouble (Y)	PCU					0
	39	Process thermistor trouble	PCU					0
	40	Toper density sensor trouble (K)	PCU					0
	41	Toner density sensor trouble (C)	PCU					0
	42	Toner density sensor trouble (M)	PCU					0
	43	Toner density sensor trouble (N)	PCU					0
	45	Color image density sensor trouble	PCU					0
	49		PCU					0
	50	K drum phase sensor trouble	PCU					0
	51	CL drum phase sensor trouble	PCU					0
	58	Temperature/humidity sensor trouble (HLID_M/TH_M)	PCU					0
	64	Toper supply operation trouble (K)	PCU					0
	65	Topor supply operation trouble (C)	PCU					0
	66	Toner supply operation trouble (0)	PCU					0
	67	Toner supply operation trouble (N)	PCU					0
	70	Improper topor cartridge detection (K)	PCU					
	70	Improper toner cartridge detection (N)	PCU					0
	72	Improper toner cartridge detection (C)	PCU				<u> </u>	0
	72		PCU					0
	13	Improper toner cartriage detection (Y)	PCU					0
	74		PCU					
	75	Ioner cartridge CRUM error (C)	PCU					
	76	Ioner cartridge CRUM error (M)	PCU					0
	11	Ioner cartridge CRUM error (Y)	PCU				<u> </u>	0
	78	Registration image density sensor trouble	PCU					0
	Q1	High density process control high voltage error (K)	PCU					0
	92	High density process control high voltage error (C)	PCU					0
	02	High density process control high voltage error (M)	PCU					0
F2	93 Q/	High density process control high voltage error (V)	PCU					0
F3	12	Paper feed tray 1 lift operation trouble	PCU	0				
13	22	Paper feed tray 1 lift operation travible	PCU	0				
	22	Paper reeu tray 2 lift operation trouble	PCU	U				

Trouble	e code		Tasakla					
Main	Sub	Trouble content	detection	Mechanism	Option	Electricity	FAX	Supply
code	code		MED					
F6	00	MFPC PWB - FAX communication trouble	MFP				0	
	01	FAX control PWB EEPROM read/write error	FAX				0	
	04	FAX MODEM operation trouble	FAX				0	
	21	Improper combination of TEL/LIU PWB and FAX soft switch	MFP				0	
	30	FAX 1-chip microprocessor access error (FAX detection)	MFP				0	
	97	Incompatibility between FAX control PWB and the main machine	MFP				0	
	98	Incompatibility between the FAX control PWB destination and the main	MFP				0	
		machine destination						
H2	00	Thermistor open trouble (TH_UM_AD2)	PCU	0				
	01	Thermistor open trouble (TH_LM)	PCU	0				
	02	Thermistor open trouble (TH_US)	PCU	0				
	03	Thermistor open trouble (TH_UM_AD1)	PCU	0				
H3	00	Fusing section high temperature trouble (TH_UM)	PCU	0				
	01	Fusing section high temperature trouble (TH_LM)	PCU	0				
	02	Fusing section high temperature trouble (TH_US)	PCU	0				
H4	00	Fusing section low temperature trouble (TH_UM_AD2)	PCU	0				
	01	Fusing section low temperature trouble (TH_LM)	PCU	0				
	02	Fusing section low temperature trouble (TH_US)	PCU	0				
H5	01	5 times continuous POD1 not-reach jam	PCU	0				
H7	10	Recovery error from low fuser temp. (TH_UM_AD2)	PCU	0				
	11	Recovery error from low fuser temp. (TH_LM)	PCU	0				
11	00	Scanner feed trouble	SCU	0				
1.3	00	Scanner return trouble	SCU	0				
14	02	Paper food motor trouble	PCU	0		0		
L-7	02	Fusing motor trouble	PCU			0		
	03	Pasing motor trouble	PCU			0		
	04	Developing motor trouble (BLACK)	PCU			0		
	05		FCU			0		
	06		PCU			0		
	07	Iranster belt motor trouble	PCU			0		
	11	Shift motor trouble	PCU			0		
	12	Secondary transfer separation trouble	PCU	0				
	16	Fusing pressure release trouble	PCU			0		
	30	MFP fan motor trouble	MPF			0		
	31	Paper exit cooling fan trouble	PCU			0		
	32	Power source cooling fan trouble	PCU			0		
	35	Fusing cooling fan trouble	PCU			0		
	43	Paper exit cooling fan 2 trouble	PCU			0		
	50	Process fan trouble	PCU			0		
	51	Process fan 2 trouble	PCU			0		
L6	10	Polygon motor trouble	PCU			0		
L8	01	Full wave signal detection error	PCU			0		
	02	Full wave signal error	PCU			0		
	20	Communication error of MFPC PWB/LSU mother board	MFP			0		
P1	00	PCI communication error	MFP		0			
	01	PCI fan error	MFP		0			
	02	Plasma generating device error	MFP		0			
PC	-	Personal counter not detected	MFP	0				
U1	01	Battery trouble	MFP			0		
112	00	MEP FEPROM read/write error	MFP			0		
	05	Erroneous detection of account management data / HDD internal	MFP			0		
		authentication DB table error				Ŭ		
	11	MFPC PWB EEPROM counter check sum error	MFP			0		
	30	MFPC PWB and PCU PWB manufacturing No. data inconsistency	MFP		1	0		1
	40	SD card system storage data area error	MFP			0		
	41	HDD system storage data area error	MFP	1		0		
	42	Machine adjustment data (system storage data area) error	MFP			0		
	50	HDD user authentication data check sum error	MEP			0		
	60	Watermark check error	MEP			0		
	80		SCU			0		
	00		SCU					
	01		BCU			0		
	90					0		
1	91	PCU PWB EEPROM check sum error	PCU	1	1	0		1

Trouble	e code		Trouble					
Main	Sub	Trouble content	detection	Mechanism	Option	Electricity	FAX	Supply
code	code							
U6	00	PCU PWB - Paper feed desk (paper feed tray 3, 4) communication trouble	PCU			0		
	01	Desk paper feed tray 1 lift trouble	PCU		0			
	02	Desk paper feed tray 2 lift trouble	PCU		0			
	03	Desk paper feed tray 3 lift trouble	PCU		0			
	09	LCC lift motor trouble	PCU		0			
	10	Desk paper feed unit paper transport motor trouble	PCU		0			
	20	LCC control PWB - PCU PWB communication error	PCU		0			
	21	LCC transport motor trouble	PCU		0			
	22	LCC 24V power abnormality	PCU		0			
	50	Desk - Main unit combination trouble	PCU		0			
	51	LCC - Main unit combination trouble	PCU		0			
	52	PCU PWB - Paper feed desk (paper feed tray 2) communication trouble	PCU			0		
U7	50	MFPC PWB - Vendor machine communication error	MFP			0		
	51	Vendor machine error	MFP			0		
U9	01	Touch panel trouble	SCU			0		
UC	02	CPT - ASIC error	SCU			0		
	20	DOCC ASIC error	SCU			0		

#### A0-01 PCU PWB ROM error

Detail	MFP
Cause	The firmware version-up is not completed properly by interruption of the power during the version-up operation, etc. PCU PWB trouble.
Check & Remedy	Use SIM49-1 to perform the firmware version-up procedure again. Replace the PCU PWB.

#### A0-02 SCU PWB ROM error

Detail	MFP
Cause	The firmware version-up is not completed properly by interruption of the power during the version-up operation, etc. SCU PWB trouble.
Check & Remedy	Use SIM49-1 to perform the firmware version-up procedure again. Replace the SCU PWB.

#### A0-04 Scanner expansion PWB (ACU) (ACRE) ROM error

Trouble content	Scanner expansion PWB ROM error
Detail	MFP
Cause	Scanner expansion PWB (ACU) (ACRE) ROM data error. An error occurs during firmware upgrading for some reasons.
Check & Remedy	Perform firmware upgrading again.

#### A0-10 Color profile error

Trouble content	Color profile error
Detail	MFP
Cause	The content of the color profile is abnormal. Combination error between the MFPC PWB firmware and the color profile
Check & Remedy	Upgrade the firmware collectively. Replace the MFPC PWB.

#### A0-11 Firmware version inconsistency (MFP - PCU)

Detail	MFP
Cause	Firmware combination error between the MFP and the PCU.
Check & Remedy	Install the firmware in the all-firmware version-up mode.

# A0-14 Inconsistency between the MFP and the CPU firmware version

Trouble content	Inconsistency between the MFP and the CPU
	firmware version
Detail	MFP
Cause	Combination error between the MFP and the CPU UI
	firmware version.
Check & Remedy	Install the firmware in the all-firmware version-up
	mode.

# A0-15 Incompatible DSK BOOT and program firmware

Detail	MFP
Cause	Installation of the normal firmware was performed with a security kit enable.
Check & Remedy	Stop installation of the normal firmware.

## A0-16 Data error of the energy-saving NIC controller firmware in the SD card

Trouble content	Data error of the energy-saving NIC controller
	firmware in the SD card.
Detail	MFP
Cause	SD card trouble.
	MFPC PWB trouble.
Check & Remedy	Reinstall the firmware.
	Replace the SD card.
	Replace the MFPC PWB.

# A0-17 Inconsistency between the UI data and the CPU firmware version

Trouble content	Inconsistency between the UI data and the CPU firmware version
Detail	MFP
Cause	Combination error between the UI contents data and the CPU UI firmware version.
Check & Remedy	Install the firmware in the all-firmware version-up mode.

# A0-20 Conflict firmware and EEPROM data version (MFP)

Detail	MFP
Cause	Inconsistency between the MFP firmware version and the EEPROM data version.
Check & Remedy	Check the combination of the firmware.

# A0-21 Conflict firmware and EEPROM data version (PCU)

Detail	PCU
Cause	Inconsistency between the PCU firmware version and the EEPROM data version.
Check & Remedy	Check the combination of the firmware.

# A0-22 Conflict firmware and EEPROM data version (SCU)

Trouble content	
Detail	SCU
Cause	Inconsistency between the SCU firmware version and the EEPROM data version.
Check & Remedy	Check the combination of the firmware.



#### **C1-10** Main charger trouble (Monochrome)

Detail	PCU
Cause	The main charger unit (BK) is not installed properly. There is an abnormality in the main charger unit (BK). The developer unit (KCMY) is not installed properly. There is an abnormality in the developer unit (KCMY). Disconnection of the high voltage MC PWB connector. Breakage of the high voltage harness. High voltage MC PWB trouble. PCU PWB trouble.
Check & Remedy	Check the output of the main charger with SIM8-2. Check the output of the developing bias with SIM8-1. Check disconnection of the main charger./Replace. Check disconnection of the developer unit./Replace. Check disconnection of the high voltage MC PWB connector./Replace. Replace the high voltage MC PWB. Replace the PCU PWB.

#### C1-14 Main charger trouble (Color)

Detail	PCU
Cause	The main charger unit (CMY) is not installed properly. There is an abnormality in the main charger unit (CMY). Disconnection of the high voltage MC PWB connector. Breakage of the high voltage harness. High voltage MC PWB trouble. PCU PWB trouble.
Check & Remedy	Check the output of the main charger with SIM8-2. Check disconnection of the main charger./Replace. Check disconnection of the high voltage MC PWB connector./Replace. Replace the high voltage MC PWB Replace the PCU PWB.

#### C4-00 PTC trouble (TC high voltage trouble)

Detail	PCU
Cause	The PTC unit is not installed properly./Trouble.
	The primary transfer unit is not installed properly./
	Trouble.
	The secondary transfer unit is not installed properly./
	Trouble.
	High voltage TC PWB trouble.
	PCU PWB trouble.
	Connection trouble of the connector and the harness.
Check & Remedy	Replace the PTC unit.
	Replace the primary transfer unit.
	Replace the secondary transfer unit.
	Check disconnection of the high voltage TC PWB
	connector./Replace.
	Replace the high voltage TC PWB.
	Replace the PCU PWB.

#### E7-01 MFP image data error

Detail	MFP
Cause	Image data transfer error in the MFPC PWB. MFPC PWB trouble.
Check & Remedy	Check connection of the connector and the harness of the MFPC PWB. Check or replace the MFPC PWB.

# E7-02 HDD trouble when the mirroring kit is installed

Travella contant	
I rouble content	HDD trouble
Detail	MFP
Cause	When installing the mirroring kit, the HDD of the machine or the HDD of the mirroring kit breaks down or connection fails. Defective installation of the mirroring kit Breakdown of the HDD of the mirroring kit Breakdown of the HDD of the machine Defective connection between the HDD and the mirroring kit harness MFP PWB trouble
Check & Remedy	Use SIM62-20 to check the troouble Check installation of the mirroring kit (connector and harness) and replace if necessary Replace the broken HDD Replace the mirroring kit Replace the MFP PWB

### E7-03 HDD trouble / Mirroring kit error

Detail	MFP
Cause	Connector, harness connection trouble in the MFPC PWB and HDD. HDD (error file management area) data abnormality (FAT breakage). MFPC PWB trouble.
	(When the mirroring kit is installed) RAID PWB trouble. A HDD which has been used for mirroring is installed. Both HDD's go into trouble under the use environment of mirroring.
Check & Remedy	Check connection of the connector and the harness of the MFPC PWB and HDD. Use SIM62-2, 3 to check read/write operations of the HDD. Replace the HDD. Check or replace the MFPC PWB. (When the mirroring kit is installed) Check the RAID PWB, and replace if necessary. Replace the HDD. (For details, refer to the HDD and RAID PWB replacement procedures under mirroring

A

### E7-04 HDD-ASIC error

Detail	MFP
Cause	HDD-ASIC trouble. (MFPC PWB trouble.) An error occurs in the HDD-ASIC self test when booting.
Check & Remedy	Check or replace the MFPC PWB.

### E7-07 SD card error

Detail	MFP
Cause	SD card trouble or contact error MFPC PWB trouble.
Check & Remedy	Replace the SD card. Check the SD card socket. Replace the MFPC PWB.

#### E7-10 Shading error (Black correction)

Trouble content	
Detail	SCU
Cause	Abnormality in the CCD black scan level when the scanner lamp is turned OFF. Improper installation of the harness to the CCD unit. CCD unit abnormality. SCU PWB abnormality.
Check & Remedy	Check connection of the harness to the CCD unit. Check the CCD unit. Check the SCU PWB.

#### **E7-11** Shading error (White correction)

Trouble content	
Detail	SCU
Cause	Abnormality in the CCD white reference plate scan level when the scanner lamp is turned ON. Improper installation of the harness to the CCD unit. Dirt on the mirror, lens, and the reference white plate. Scanner lamp lighting trouble. Scanner lamp drive PWB trouble CCD unit abnormality. SCU PWB abnormality.
Check & Remedy	Check connection of the harness to the CCD unit. Check connection of the harness to the scanner lamp unit. Check or replace the scanner lamp drive PWB. Clean or replace the mirror, the lens, and the reference white board. Check or replace the CCD unit. Check or replace the SCU PWB.

#### E7-14 CCD-ASIC error

Trouble content	
Detail	SCU
Cause	SCU PWB trouble.
	CCD unit trouble.
	Improper Installation of the harness to the CCD unit.
Check & Remedy	Check the SCU PWB.
	Replace the SCU PWB.
	Check the CCD unit.
	Replace the CCD unit.
	Check connection of the harness to the CCD unit.

#### E7-20 LSU laser detection error (K)

Trouble content	
Detail	PCU
Cause	Laser optical axis misalignment Reduced laser power, lighting error, laser diode trouble. LSU harness, connector trouble LSU trouble
Check & Remedy	Use SIM61-1 to check the operation of the LSU. Check or replace the LSU control PWB. Check connection of the LSU harness. Replace the LSU.

#### E7-21 LSU laser detection error (C)

Trouble content	
Detail	PCU
Cause	Laser optical axis misalignment
	Reduced laser power, lighting error, laser diode
	trouble.
	LSU harness, connector trouble
	LSU trouble
Check & Remedy	Use SIM61-1 to check the operation of the LSU.
	Check or replace the LSU control PWB.
	Check connection of the LSU harness.
	Replace the LSU.

#### E7-22 LSU laser detection error (M)

Trouble content	
Detail	PCU
Cause	Laser optical axis misalignment Reduced laser power, lighting error, laser diode trouble. LSU harness, connector trouble LSU trouble
Check & Remedy	Use SIM61-1 to check the operation of the LSU. Check or replace the LSU control PWB. Check connection of the LSU harness. Replace the LSU.

### E7-23 LSU laser detection error (Y)

Trouble content	
Detail	PCU
Cause	Laser optical axis misalignment Reduced laser power, lighting error, laser diode trouble. LSU harness, connector trouble LSU trouble
Check & Remedy	Use SIM61-1 to check the operation of the LSU. Check or replace the LSU control PWB. Check connection of the LSU harness. Replace the LSU.

### E7-24 LSU LD driver error (K)

Trouble content	LSU LD driver error
Detail	PCU
Cause	When lighting the LSU LD, initialization of the LD driver is not performed normally. Harness/connector trouble between the LD PWB and the LSU mother PWB. LD PWB trouble. LSU mother PWB trouble.
Check & Remedy	Use SIM61-1 to check the operation of the LSU. Check the LSU, and replace if necessary. Check the LSU mother PWB, and replace if necessary. Check connection of the harness/connector between the LD PWB and the LSU mother PWB.

#### E7-25 LSU LD driver error (C)

Trouble content	LSU LD driver error
Detail	PCU
Cause	When lighting the LSU LD, initialization of the LD driver is not performed normally. Harness/connector trouble between the LD PWB and the LSU mother PWB. LD PWB trouble. LSU mother PWB trouble.
Check & Remedy	Use SIM61-1 to check the operation of the LSU. Check the LSU, and replace if necessary. Check the LSU mother PWB, and replace if necessary. Check connection of the harness/connector between the LD PWB and the LSU mother PWB.

#### E7-26 LSU LD driver error (M)

Trouble content	LSU LD driver error
Detail	PCU
Cause	When lighting the LSU LD, initialization of the LD driver is not performed normally. Harness/connector trouble between the LD PWB and the LSU mother PWB. LD PWB trouble. LSU mother PWB trouble.
Check & Remedy	Use SIM61-1 to check the operation of the LSU. Check the LSU, and replace if necessary. Check the LSU mother PWB, and replace if necessary. Check connection of the harness/connector between the LD PWB and the LSU mother PWB.

### E7-27 LSU LD driver error (Y)

Trouble content	LSU LD driver error
Detail	PCU
Cause	When lighting the LSU LD, initialization of the LD driver is not performed normally. Harness/connector trouble between the LD PWB and
	the LSU mother PWB.
	LSU mother PWB trouble.
Check & Remedy	Use SIM61-1 to check the operation of the LSU. Check the LSU, and replace if necessary. Check the LSU mother PWB, and replace if necessary.
	the LD PWB and the LSU mother PWB.

#### E7-28 LSU - PCU connection error

PCU
Communication error between the CPU in the PCU PWB and the LSU control ASIC.
Improper connection of the communication connector between the PCU PWB and the LSU control PWB (interface PWB).
Harness trouble between the PCU PWB and the LSU control PWB (interface PWB)
PCU PWB trouble.
L SU trouble
LSU mother PWB trouble.
Check connection of the connector and the harness between the PCU PWB and the LSU control PWB (interface PWB). Replace the LSU mother PWB. Replace the PCU PWB. Replace the LSU. Replace the LSU.

#### E7-29 LSU ASIC frequency error

Trouble content	
Detail	PCU
Cause	Oscillation abnormality of the external oscillator and the internal oscillating circuit used in the LSU ASIC. LSU ASIC abnormality on the LSU ASIC PWB.
Check & Remedy	Replace the LSU control PWB.

# E7-42 Image data trouble (Scanner expansion PWB (ACRE) ASIC)

Trouble content	Image data trouble
Detail	MFP
Cause	An image data error occurs. An image data send error occurs. Scanner expansion PWB (ACRE) connection trouble. Scanner expansion PWB (ACRE) trouble. MFPC PWB trouble.
Check & Remedy	Check connection of the scanner expansion PWB (ACRE). Check the scanner expansion PWB (ACRE), and replace if necessary. Check the MFPC PWB, and replace if necessary.

# E7-46 Image data decode error (Scanner expansion PWB (ACRE) ASIC)

Trouble content	Image data decode error
Detail	MFP
Cause	A decode error occurs while high compression PDF images are made. (garbled data) Scanner expansion PWB (ACRE) connection trouble. Scanner expansion PWB (ACRE) trouble. MFPC PWB trouble.
Check & Remedy	Check connection of the scanner expansion PWB (ACRE). Check the scanner expansion PWB (ACRE), and replace if necessary. Check the MFPC PWB, and replace if necessary.

E7-47 Combination of firmware error between the MFP and the ACRE ASIC

Trouble content	Combination of firmware error
Detail	MFP
Cause	Written ACRE board of the firmware that a model did not support MFP was connected.
Check & Remedy	Use SIM49-1 or SIM49-10 to execute firmware ver- sion-up

#### E7-48 Scanner expansion PWB (ACRE) ASIC memory error

Trouble content	DDR calibration error
	<ul> <li>DIMM insertion trouble, etc.</li> </ul>
Detail	MFP
Cause	Scanner expansion PWB (ACRE) DIMM trouble, memory slot trouble. Scanner expansion PWB (ACRE) DIMM insertion trouble.
	Scanner expansion PWB (ACRE) connection trouble. Scanner expansion PWB (ACRE) trouble. MFPC PWB trouble.
Check & Remedy	Check insertion of the scanner expansion PWB (ACRE) DIMM memory. Check the scanner expansion PWB (ACRE) DIMM memory, and replace if necessary. Check connection of the scanner expansion PWB (ACRE). Check the scanner expansion PWB (ACRE), and replace if necessary. Check the MEPC PWB, and replace if necessary.

#### E7-49 Water Mark data error

Trouble content	
Detail	MFP
Cause	Watermark data trouble. HDD trouble.
Check & Remedy	Use SIM49-5 to upload the watermark data. Replace the HDD.

#### E7-50 Combination error between PWB and firmware (PCU PWB detection)

Trouble content	
Detail	PCU
Cause	A PWB/firmware/LSU which is not compatible with the machine specifications is detected. PCU PWB trouble LSU trouble
Check & Remedy	Check the kind and the version of the firmware. Check or replace the LSU. Check or replace the PCU PWB.

#### E7-55 PCU PWB information sum error

Trouble content	PCU EEPROM PWB information sum error
Detail	PCU
Cause	PCU EEPROM sum check error.
	PCU EEPROM trouble.
	PCU EEPROM contact trouble.
Check & Remedy	Replace the PCU PWB.
	Replace the PCU EEPROM.

#### E7-60 Combination error between PWB and firmware (MFPC PWB detection)

Trouble content	
Detail	MFP
Cause	A PWB/firmware which is not compatible with the machine specifications is detected in the MFPC PWB. MFPC PWB trouble.
Check & Remedy	Check the kind and the version of the firmware. Check or replace the MFPC PWB.

#### E7-61 Combination error between the MFPC PWB and the PCU PWB (MFPC PWB detection)

Trouble content	
Detail	MFP
Cause	Combination error between the MFPC PWB and the PCU PWB. MFPC PWB trouble. PCU PWB trouble.
Check & Remedy	Check the combination between the MFPC PWB and the PCU PWB. Replace the MFPC PWB. Replace the PCU PWB.

### E7-65 MFP EEPROM sum check error

Trouble content	
Detail	MFP
Cause	MFPC PWB EEPROM trouble.
	MFPC PWB EEPROM contact trouble.
Check & Remedy	Replace the MFPC PWB.
	Replace the MFPC PWB EEPROM.

### **E7-80** MFP - SCU PWB communication error

Trouble content	
Detail	MFP
Cause	SCU PWB - MFPC PWB connection trouble.
	SCU PWB trouble.
	MFPC PWB trouble.
Check & Remedy	Check connection of the SCU PWB and the MFPC
	PWB.
	Check the ground.
	Replace the SCU PWB.
	Replace the MFPC PWB.

#### Communication error between MFPC E7-89 PWB CPU and energy-saving NIC controller

Trouble content	No response can be obtained from the energy-saving NIC controller.
Detail	MFP
Cause	MFPC PWB trouble.
Check & Remedy	Replace the MFPC PWB.

#### E7-90 MFP - PCU PWB communication error

Trouble content	
Detail	MFP
Cause	PCU PWB - MFPC PWB connection trouble. PCU PWB trouble. MFPC PWB trouble.
Check & Remedy	Check connection of the PCU PWB and the MFPC PWB. Check the ground. Replace the PCU PWB. Replace the MFPC PWB.

#### E7-91 FAX reception image data error

Trouble content	An error of FAX reception image data process occurs.
Detail	MFP
Cause	Image data process abnormality HDD trouble SD card trouble or contact error Image compression data corruption MFPC PWB trouble FAX control PWB trouble
Check & Remedy	Use SIM60-01 to check the read/write operations of the memory. Replace the HDD. Replace or check installation of the SD card. Replace the MFPC PWB. Replace the FAX control PWB.

#### E7-92 Copy image data error

Trouble content	An error of copy image data process occurs. (In Non ERDH)
Detail	MFP
Cause	Image data process abnormality HDD trouble Image compression data corruption MFPC PWB trouble DRAM memory trouble or contact error
Check & Remedy	Use SIM60-01 to check the read/write operations of the memory. Replace the HDD. Replace the MFPC PWB.

# E7-93 Copy, image send, FAX, filing, print image data process error

Trouble content	An image data process error occurs in the following operation mode: • Copy (in ERDH) • Copy composing system function (Water mark) • When in image send • When filing documents • When displaying the preview • When printing with the GDI/PCL printer • Copy composing system function (Water mark)
Detail	MFP
Cause	Image data process abnormality HDD trouble Image compression data corruption MFPC PWB trouble DIMM memory trouble or contact error
Check & Remedy	Use SIM60-01 to check the read/write operations of the memory. Replace the HDD. Replace the MFPC PWB. Replace or check installation of the DIMM memory.

# E7-94 Image file data process error (when importing file data)

Trouble content	File image process error (backup restore error) when importing filing data
Detail	MFP
Cause	Image data process abnormality HDD trouble Image compression data corruption MFPC PWB trouble DIMM memory trouble or contact error
Check & Remedy	Use SIM60-01 to check the read/write operations of the memory. Replace the HDD. Replace the MFPC PWB. Replace or check installation of the DIMM memory.

#### E7-96 MFPC PWB memory check error

Trouble content	MFPC PWB memory access trouble
Detail	MFP
Cause	Memory data curruption occure Memory device trouble or contact error
Check & Remedy	Use SIM60-1 to check the read/write operations of the memory. Replace MFP PWB

#### E7-A0 LSU LD PWB EEPROM read/write error (K)

Trouble content	Write error in the EEPROM write sequence
Detail	PCU
Cause	LD PWB EEPROM trouble.
	LSU mother PWB trouble.
	Connector/harness trouble between the LD PWB and
	the LSU mother PWB.
	Connector/harness trouble between the PCU PWB
	and the LSU mother PWB.
	DC POWER PWB trouible.
Check & Remedy	Check the LSU, and replace if necessary.
	Check the LSU mother PWB, and replace if
	necessary.
	Check the connector/harness between the LD PWB
	and the LSU mother PWB, and replace if necessary.
	Check the connector/harness between the PCU PWB
	and the LSU mother PWB, and replace if necessary.
	Replace the LSU.
	Measure the voltage between the C101 on the LSU-
	cnt PWB and the C80/C61 on the LD PWB and the
	check whether the voltage is 5V. If the voltage is not
	5V, replace DC POWER PWB.

#### E7-A1 LSU LD PWB EEPROM read/write error (C)

Trouble content	Write error in the EEPROM write sequence
Detail	PCU
Cause	LD PWB EEPROM trouble. LSU mother PWB trouble. Connector/harness trouble between the LD PWB and the LSU mother PWB. Connector/harness trouble between the PCU PWB and the LSU mother PWB.
Check & Remedy	Check the LSU, and replace if necessary. Check the LSU mother PWB, and replace if necessary. Check the connector/harness between the LD PWB and the LSU mother PWB, and replace if necessary. Check the connector/harness between the PCU PWB and the LSU mother PWB, and replace if necessary. Replace the LSU.

#### E7-A2 LSU LD PWB EEPROM read/write error (M)

Trouble content	Write error in the EEPROM write sequence
Detail	PCU
Cause	LD PWB EEPROM trouble. LSU mother PWB trouble. Connector/harness trouble between the LD PWB and
	Connector/harness trouble between the PCU PWB and the LSU mother PWB.
Check & Remedy	Check the LSU, and replace if necessary. Check the LSU mother PWB, and replace if necessary. Check the connector/harness between the LD PWB and the LSU mother PWB, and replace if necessary. Check the connector/harness between the PCU PWB and the LSU mother PWB, and replace if necessary. Replace the LSU.

#### E7-A3 LSU LD PWB EEPROM read/write error (Y)

Trouble content	Write error in the EEPROM write sequence
Detail	PCU
Cause	LD PWB EEPROM trouble. LSU mother PWB trouble. Connector/harness trouble between the LD PWB and the LSU mother PWB. Connector/harness trouble between the PCU PWB and the LSU mother PWB.
Check & Remedy	Check the LSU, and replace if necessary. Check the LSU mother PWB, and replace if necessary. Check the connector/harness between the LD PWB and the LSU mother PWB, and replace if necessary. Check the connector/harness between the PCU PWB and the LSU mother PWB, and replace if necessary. Replace the LSU.

# E7-A5 Installation error of HDD which was used in the mirroring kit

Trouble content	When a HDD which was used in the mirroring kit is installed to the MFP without the mirroring kit, its operation is restricted in order to prevent against malfunction.
Detail	MFP
Cause	A HDD which was used in the mirroring kit is installed to the MFP without the mirroring kit.
Check & Remedy	Replace the HDD with one which has not been used in the mirroring kit.

### E7-A6 Compact flash memory trouble

Trouble content	A read/write access error in the compact flash
	memory occurs.
Detail	
Cause	Compact flash memory trouble.
	MFPC PWB trouble.
	File system control area data trouble.
Check & Remedy	Replace the compact flash memory.
	Replace the MFPC PWB.

# **EE-EC** Automatic toner density adjustment error

Trouble content	The sampling level in the automatic toner density adjustment is outside of $128 \pm 10$ .
Detail	PCU
Cause	Toner density sensor trouble. Developing unit trouble. PCU PWB trouble.
Check & Remedy	Replace the toner density sensor. Replace the developing unit. Replace the PCU PWB.

# **EE-EL** Automatic toner density adjustment error (Over toner)

Trouble content	The sampling level in the automatic toner density adjustment is 76 or less or the control voltage is 208 or above.
Detail	PCU
Cause	Toner density sensor trouble. Developing unit trouble. PCU PWB trouble.
Check & Remedy	Replace the toner density sensor. Replace the developing unit. Replace the PCU PWB.

# **EE-EU** Automatic toner density adjustment error (Under toner)

Trouble content	The sampling level in the automatic toner density adjustment is 178 or above or the control voltage is 51 or less.
Detail	PCU
Cause	Toner density sensor trouble.
	Developing unit trouble.
	PCU PWB trouble.
Check & Remedy	Replace the toner density sensor.
	Replace the developing unit.
	Replace the PCU PWB.

# F1-00 Finisher - PCU PWB communication error

Trouble content	
Detail	PCU
Cause	Connection trouble of the connector and the harness between the finisher and the PCU PWB. Finisher control PWB trouble. PCU PWB trouble.
Check & Remedy	Check the connector and the harness between the finisher and the PCU PWB. Replace the finisher control PWB. Replace the PCU PWB.

#### F1-03 Finisher paper exit roller lifting operation trouble

Trouble content	
Detail	PCU
Cause	Finisher paper exit roller lift motor trouble Harness and connector connection trouble
	Home position sensor trouble
	Finisher control PWB trouble
Check & Remedy	Use SIM3-3 to check the operation of the paper exit roller lift motor. Use SIM3-2 to check the operation of the home
	position sensor.
	Replace the paper exit roller lift motor.
	Check connection of the connector and the harness.
	Replace the home position sensor.
	Replace the finisher control PWB.

#### F1-08 Stapler shift trouble

Trouble content	
Detail	PCU
Cause	Stapler shift motor trouble.
	Finisher control PWB trouble.
	Home position sensor trouble.
Check & Remedy	Use SIM3-3 to check the operation of the stapler shift
	motor.
	Use SIM3-2 to check the operation of the home
	position sensor.
	Replace the stapler shift motor.
	Check connection of the connector and the harness.
	Replace the home position sensor.
	Replace the finisher control PWB.

### F1-10 Staple operation trouble

Trouble content	
Detail	PCU
Cause	Staple motor trouble.
	Finisher control PWB trouble.
	Home position sensor trouble.
Check & Remedy	Use SIM3-3 to check the operation of the staple
	motor.
	Use SIM3-2 to check the operation of the home
	position sensor.
	Replace the staple motor.
	Check connection of the connector and the harness.
	Replace the home position sensor.
	Replace the finisher control PWB.

### F1-11 Finisher grip motor trouble

Trouble content	
Detail	PCU
Cause	Paper exit operation trouble caused by the gripper. Gripper motor lock or trouble. Gripper home position sensor trouble. Finisher control PWB trouble. Connection trouble of the harness and the connector of the finisher control PWB and the gripper motor.
Check & Remedy	Use SIM3-3 to check the operation of the gripper motor. Check the connection of the harness and the connector of the finisher control PWB and the gripper motor, and replace if necessary. Check the gripper motor, and replace if necessary. Check the gripper home position sensor, and replace if necessary. Check the finisher control PWB, and replace if necessary.

#### F1-15 Finisher paper exit tray lift operation trouble

Trouble content	Lift motor trouble.
Detail	PCU
Cause	Paper exit tray lift motor trouble. Finisher control PWB trouble. Home position sensor trouble.
Check & Remedy	Use SIM3-3 to check the operation of the paper exit tray lift motor. Use SIM3-2 to check the operation of the home position sensor. Replace the finisher control PWB. Replace the paper exit tray lift motor. Replace the home position sensor.

### F1-19 Finisher alignment operation trouble F

Trouble content	
Detail	PCU
Cause	Finisher paper alignment motor lock. Motor speed abnormality. Over-current to the motor. Finisher control PWB trouble. Home position sensor trouble.
Check & Remedy	Use SIM3-3 to check the operation of the paper alignment motor F. Use SIM3-2 to check the operation of the home position sensor. Replace the finisher control PWB. Replace the paper alignment motor F. Replace the home position sensor.

#### F1-20 Finisher alignment operation trouble R

Trouble content	
Detail	PCU
Cause	Finisher paper alignment motor lock.
	Motor speed abnormality.
	Over-current to the motor.
	Finisher control PWB trouble.
	Home position sensor trouble.
Check & Remedy	Use SIM3-3 to check the operation of the paper
	alignment motor R.
	Use SIM3-2 to check the operation of the home
	position sensor.
	Replace the finisher control PWB.
	Replace the paper alignment motor R.
	Replace the home position sensor.

## F1-21 Finisher fan trouble

Trouble content	
Detail	PCU
Cause	Motor lock, motor harness short-circuit/open, finisher control PWB trouble, connection harness/connector trouble. Fan motor lock, short-circuit, open circuit. Finisher fan trouble. Finisher control PWB trouble. Connector/harness trouble
Check & Remedy	Use SIM3-3 to check the operation of the fan. Check the finisher fan, and replace if necessary. Check the finisher control PWB, and replace if necessary. Check the connector/harness, and replace if necessary.

#### F1-31 Finisher saddle motor trouble (Saddle stitch finisher)

Trouble content	
Detail	PCU
Cause	Saddle paper folding motor trouble.
	Saddle paper folding mechanism trouble.
	Finisher control PWB trouble.
	Folding plate home position sensor trouble.
	Saddle paper folding motor rotation sensor trouble.
	Harness/connector connection trouble.
	PCU PWB trouble.
Check & Remedy	Use SIM3-3 to check the operation of the saddle
	motor.
	Check the saddle paper folding mechanism.
	Check the finisher control PWB, and replace if
	necessary.
	Check the folding plate home position sensor, and replace if necessary.
	Check the saddle paper folding motor rotation sensor, and replace if necessary.
	Check connection of the harness/connector, and replace if necessary.
	Check the PCU PWB, and replace if necessary.

#### F1-32 Communication error between the finisher and the punch unit (Saddle stitch finisher)

Trouble content	
Detail	PCU
Cause	Connector/harness trouble between the finisher and the punch unit. Finisher control PWB trouble. PCU PWB trouble. Malfunction due to noises.
Check & Remedy	Check the connector/harness between the finisher and the punch unit, and replace if necessary. Check the finisher control PWB, and replace if necessary. Check the PCU PWB, and replace if necessary.

#### F1-33 Punch unit shift operation trouble

Trouble content	
Detail	PCU
Cause	Punch shift motor trouble.
	Finisher control PWB trouble.
	Home position sensor trouble.
	Harness and connector connection trouble.
Check & Remedy	Use SIM3-3 to check the operation of the punch
	shifting.
	Use SIM3-2 to check the operation of the home
	position sensor.
	Replace the punch shift motor.
	Replace the finisher control PWB.
	Replace the home position sensor.
	Check connection of the connectors and the harness.

#### F1-34 Punch operation trouble

Trouble content	
Detail	PCU
Cause	Punch motor trouble.
	Finisher control PWB trouble.
	Home position sensor trouble.
	Harness and connector connection trouble.
Check & Remedy	Use SIM3-2 to check the operation of the home
	position sensor.
	Use SIM3-3 to check the operation of the punch.
	Replace the punch motor.
	Replace the finisher control PWB.
	Replace the home position sensor.
	Check connection of the connectors and the harness.

#### F1-36 Punch paper edge detection error

Travela a sectored	
I rouble content	
Detail	PCU
Cause	Punch paper edge sensor trouble.
	Harness disconnection.
	Finisher control PWB trouble.
	Punch control PWB trouble.
Check & Remedy	Use SIM3-2 to check the operation of the sensor.
	Replace the punch paper edge sensor.
	Replace the finisher control PWB.
	Replace the punch control PWB.

#### Finisher data backup RAM error F1-37

Trouble content	
Detail	PCU
Cause	Finisher control PWB trouble.
	Malfunction due to noises
Check & Remedy	Replace the finisher control PWB.
	Readjust the finisher. (Use SIM3-10, Finisher control
	PWB DIP SW adjustment.)

#### F1-38 Punch data backup RAM error

Trouble content	
Detail	PCU
Cause	Punch control PWB trouble.
	Malfunction due to noises
Check & Remedy	Replace the punch control PWB.
	Set the punch unit specifications, and adjust the
	sensor. (Punch unit control PWB DIP SW
	adjustment.)

#### F1-39 Punch paper dust sensor error

Trouble content	
Detail	PCU
Cause	Punch dust sensor trouble.
	Harness and connector connection trouble.
	Finisher control PWB trouble.
	Punch unit control PWB trouble.
Check & Remedy	Use SIM3-2 to check the operation of the sensor.
	Check connection of the connectors and the harness.
	Replace the punch dust sensor.
	Replace the finisher control PWB.
	Replace the punch unit control PWB.

# F1-41 Saddle paper positioning operation trouble

Trouble content	Abnormality in the folding positioning guide motor in
	the saddle section.
Detail	PCU
Cause	Saddle paper positioning guide drive motor trouble.
	Finisher control PWB trouble.
	Home position sensor trouble.
	Harness and connector connection trouble.
Check & Remedy	Use SIM3-3 to check the operation of the saddle
	paper positioning motor.
	Check connection from the control PWB to the motor.
	Turn OFF/ON the power.
	Replace the control PWB.
	Replace the sensor.

#### F1-43 Saddle alignment operation trouble

Trouble content	
Detail	PCU
Cause	Saddle alignment motor trouble.
	Finisher control PWB trouble.
	Home position sensor trouble.
	Harness and connector connection trouble.
Check & Remedy	Use SIM3-3 to check the operation of the Saddle alignment motor (FSPAM).
	Check connection from the control PWB to the motor.
	Turn OFF/ON the power.
	Replace the control PWB.
	Replace the sensor.

#### F1-45 Saddle staple trouble

Trouble content	Abnormality of the staple unit drive motor in the
	saddle section.
Detail	PCU
Cause	Saddle staple motor trouble.
	Finisher control PWB trouble.
	Home position sensor trouble.
	Harness and connector connection trouble.
Check & Remedy	Use SIM3-3 to check the operation of the saddle
	staple motor.
	Check connection from the control PWB to the motor.
	Turn OFF/ON the power.
	Replace the control PWB.
	Replace the sensor.



Trouble content	Abnormality in the drive roller oscillation motor in the finisher saddle transport section.
Detail	PCU
Cause	Saddle paper transport motor trouble. Finisher control PWB trouble. Harness and connector connection trouble. Fuse blown (24V line).
Check & Remedy	Use SIM3-3 to check the operation of the saddle paper transport motor. Check connection from the control PWB to the motor. Replace the control PWB. Replace the sensor.

#### F1-50 Main unit - Finisher combination error

Trouble content	
Detail	PCU
Cause	The finisher which is not supported by the main unit model is installed. Finisher control PWB trouble.
Check & Remedy	Install a proper finisher. Replace the finisher control PWB.

### F2-22 Discharge lamp trouble (K)

Trouble content	The lamp is kept open for 1 sec from turning on the
	discharge lamp.
Detail	PCU
Cause	Contact trouble between the discharge lamp PWB (K)
	and the PCU PWB.
	Discharge lamp PWB (K) trouble.
	PCU PWB trouble.
Check & Remedy	Replace the discharge lamp PWB (K).
	Check the harness and the connector.
	Replace the PCU PWB.

#### F2-23 Discharge lamp trouble (C)

Trouble content	The lamp is kept open for 1 sec from turning on the discharge lamp.
Detail	PCU
Cause	Contact trouble between the discharge lamp PWB (C) and the PCU PWB. Discharge lamp PWB (C) trouble. PCU PWB trouble.
Check & Remedy	Replace the discharge lamp PWB (C). Check the harness and the connector. Replace the PCU PWB.

### F2-24 Discharge lamp trouble (M)

Trouble content	The lamp is kept open for 1 sec from turning on the discharge lamp.
Detail	PCU
Cause	Contact trouble between the discharge lamp PWB (M) and the PCU PWB. Discharge lamp PWB (M) trouble. PCU PWB trouble.
Check & Remedy	Replace the discharge lamp PWB (M). Check the harness and the connector. Replace the PCU PWB.

### F2-25 Discharge lamp trouble (Y)

Trouble content	The lamp is kept open for 1 sec from turning on the discharge lamp.
Detail	PCU
Cause	Contact trouble between the discharge lamp PWB (Y) and the PCU PWB. Discharge lamp PWB (Y) trouble. PCU PWB trouble.
Check & Remedy	Replace the discharge lamp PWB (Y). Check the harness and the connector. Replace the PCU PWB.

#### F2-39 Process thermistor trouble

Trouble content	
Detail	PCU
Cause	Process thermistor trouble.
	Process thermistor harness connection trouble.
	PCU PWB trouble.
Check & Remedy	Replace the process thermistor.
	Check connection of the process thermistor harness
	and the connector.
	Replace the PCU PWB.

#### F2-40 Toner density sensor trouble (K)

Trouble content	
Detail	PCU
Cause	Toner density sensor output abnormality.
	Sensor connector and harness connection trouble.
	Developing unit trouble.
	PCU PWB trouble.
Check & Remedy	Replace the toner density sensor.
	Check connection of the sensor connector and the
	harness.
	Replace the developing unit.
	Replace the PCU PWB.

F2-41

#### **1** Toner density sensor trouble (C)

Trouble content	
Detail	PCU
Cause	Toner density sensor output abnormality.
	Sensor connector and harness connection trouble.
	Developing unit trouble.
	PCU PWB trouble.
Check & Remedy	Replace the toner density sensor.
	Check connection of the sensor connector and the
	harness.
	Replace the developing unit.
	Replace the PCU PWB.

#### F2-42 Toner density sensor trouble (M)

Trouble content	
Detail	PCU
Cause	Toner density sensor output abnormality. Sensor connector and harness connection trouble. Developing unit trouble. PCU PWB trouble.
Check & Remedy	Replace the toner density sensor. Check connection of the sensor connector and the harness. Replace the developing unit. Replace the PCU PWB.

#### F2-43 Toner density sensor trouble (Y)

Trouble content	
Detail	PCU
Cause	Toner density sensor output abnormality. Sensor connector and harness connection trouble. Developing unit trouble. PCU PWB trouble.
Check & Remedy	Replace the toner density sensor. Check connection of the sensor connector and the harness. Replace the developing unit. Replace the PCU PWB.

#### F2-45 Color image density sensor trouble

Trouble content	
Detail	PCU
Cause	Color image density sensor sensitivity adjustment trouble. Color image density sensor trouble. Sensor harness and connector connection trouble. Image density sensor dirt. Transfer unit lift operation trouble PCU PWB trouble.
Check & Remedy	Replace the color image density sensor. Check connection of the sensor harness and the connector. Clean the image density sensor. Repair the transfer unit lift mechanism. Replace the PCU PWB. Use SIM44-2 to perform the sensitivity adjustment of the process control sensor.

### F2-49 LSU thermistor trouble

Trouble content	
Detail	PCU
Cause	The LSU temperature is outside of -28°C - 78°C.
	LSU thermistor harness and connector connection
	PCU PWB trouble.
	LSU control PWB trouble.
Check & Remedy	Replace the PCU PWB.
	Replace the LSU control PWB.
	Replace the LSU.

#### F2-50 K drum phase sensor trouble

Trouble content	
Detail	PCU
Cause	Drum phase sensor trouble. Drum phase sensor harness and connector connection trouble Drum drive section trouble. PCU PWB trouble.
Check & Remedy	Use SIM30-1 to check the operation of "DHPD_K". Replace the drum phase sensor. Check connection of the drum phase sensor harness and the connector. Repair the drum drive section. Replace the PCU PWB.

#### F2-51 CL drum phase sensor trouble

Trouble content	
Detail	PCU
Cause	Drum phase sensor trouble. Drum phase sensor harness and connector connection trouble Drum drive section trouble. PCU PWB trouble.
Check & Remedy	Use SIM30-1 to check the operation of "DHPD_CL". Replace the drum phase sensor. Check connection of the drum phase sensor harness and the connector. Repair the drum drive section. Replace the PCU PWB.

#### F2-58 Temperature/humidity sensor trouble (HUD_M/TH_M)

Trouble content	
Detail	PCU
Cause	Temperature/humidity sensor trouble.
	Process humidity sensor harness and connector
	connection trouble
	PCU PWB trouble.
Check & Remedy	Replace the temperature/humidity sensor.
	Check connection of the temperature/humidity sensor
	harness and the connector.
	Replace the PCU PWB.

#### F2-64 Toner supply operation trouble (K)

Trouble content	
Detail	PCU
Cause	Toner motor trouble.
	Toner density sensor trouble.
	Connector/harness trouble.
	PCU PWB trouble.
	Toner cartridge trouble.
	Developing unit trouble.
	Toner transport pipe section trouble
Check & Remedy	Replace the toner motor.
	Replace the toner density sensor.
	Connector and harness check.
	Replace the PCU PWB.
	Replace the toner cartridge.
	Replace the developing unit.
	Check the toner transport pipe section.

#### F2-65 Toner supply operation trouble (C)

Trouble content	
Detail	PCU
Cause	Toner motor trouble.
	Toner density sensor trouble.
	Connector/harness trouble.
	PCU PWB trouble.
	Toner cartridge trouble.
	Developing unit trouble.
	Toner transport pipe section trouble
Check & Remedy	Replace the toner motor.
	Replace the toner density sensor.
	Connector and harness check.
	Replace the PCU PWB.
	Replace the toner cartridge.
	Replace the developing unit.
	Check the toner transport pipe section.



#### F2-66 Toner supply operation trouble (M)

Trouble content	
Detail	PCU
Cause	Toner motor trouble.
	Toner density sensor trouble.
	Connector/harness trouble.
	PCU PWB trouble.
	Toner cartridge trouble.
	Developing unit trouble.
	Toner transport pipe section trouble
Check & Remedy	Replace the toner motor.
	Replace the toner density sensor.
	Connector and harness check.
	Replace the PCU PWB.
	Replace the toner cartridge.
	Replace the developing unit.
	Check the toner transport pipe section.

#### **F2-67** Toner supply operation trouble (Y)

Trouble content	
Detail	PCU
Cause	Toner motor trouble.
	Toner density sensor trouble.
	Connector/harness trouble.
	PCU PWB trouble.
	Toner cartridge trouble.
	Developing unit trouble.
	Toner transport pipe section trouble
Check & Remedy	Replace the toner motor.
	Replace the toner density sensor.
	Connector and harness check.
	Replace the PCU PWB.
	Replace the toner cartridge.
	Replace the developing unit.
	Check the toner transport pipe section.

#### F2-70 Improper toner cartridge detection (K)

Trouble content	
Detail	PCU
Cause	An improper toner cartridge is inserted. (The main unit detects a toner cartridge of a different specification.) Toner cartridge trouble. PCU PWB trouble.
Check & Remedy	Replace the toner cartridge. Replace the PCU PWB.

#### Improper toner cartridge detection (C) F2-71

Trouble content	
Detail	PCU
Cause	An improper toner cartridge is inserted. (The main unit detects a toner cartridge of a different specification.) Toner cartridge trouble. PCU PWB trouble.
Check & Remedy	Replace the toner cartridge. Replace the PCU PWB.

### F2-72 Improper toner cartridge detection (M)

Trouble content	
Detail	PCU
Cause	An improper toner cartridge is inserted. (The main unit detects a toner cartridge of a different specification.) Toner cartridge trouble. PCU PWB trouble.
Check & Remedy	Replace the toner cartridge. Replace the PCU PWB.

### **F2-73** Improper toner cartridge detection (Y)

Trouble content	
Detail	PCU
Cause	An improper toner cartridge is inserted. (The main unit detects a toner cartridge of a different specification.) Toner cartridge trouble. PCU PWB trouble.
Check & Remedy	Replace the toner cartridge. Replace the PCU PWB.

Trouble content	
Detail	PCU
Cause	Toner cartridge (CRUM) trouble. PCU PWB trouble. Connector and harness trouble between PCU PWB and toner cartridge
Check & Remedy	Replace the toner cartridge. Replace the PCU PWB. Check the connector and the harness between the PCU PWB and the toner cartridge.

### F2-75 Toner cartridge CRUM error (C)

Trouble content	
Detail	PCU
Cause	Toner cartridge (CRUM) trouble. PCU PWB trouble. Connector and harness trouble between PCU PWB and toner cartridge
Check & Remedy	Replace the toner cartridge. Replace the PCU PWB. Check the connector and the harness between the PCU PWB and the toner cartridge.

### F2-76 Toner cartridge CRUM error (M)

Trouble content	
Detail	PCU
Cause	Toner cartridge (CRUM) trouble.
	PCU PWB trouble.
	Connector and harness trouble between PCU PWB
	and toner cartridge
Check & Remedy	Replace the toner cartridge.
	Replace the PCU PWB.
	Check the connector and the harness between the
	PCU PWB and the toner cartridge.

### F2-77 Toner cartridge CRUM error (Y)

Trouble content	
Detail	PCU
Cause	Toner cartridge (CRUM) trouble.
	PCU PWB trouble.
	Connector and harness trouble between PCU PWB
	and toner cartridge
Check & Remedy	Replace the toner cartridge.
	Replace the PCU PWB.
	Check the connector and the harness between the
	PCU PWB and the toner cartridge.



#### F2-78 Registration image density sensor trouble (Transfer belt substrate reflection rate abnormality)

Trouble content	
Detail	PCU
Cause	Image density (registration) sensor trouble (Sensor sensitivity adjustment trouble). PCU PWB trouble. Image density (resist) sensor connector and harness connection trouble Image density (registration) sensor dirt. Transfer belt dirt, scratch.
Check & Remedy	Replace the image density (registration) sensor. Replace the PCU PWB. Check connection of the connector and the harness of the image density (resist) sensor. Clean the image density (registration) sensor. Clean or replace the transfer belt. Use SIM44-2 to perform the sensibility adjustment of the process control sensor.

# F2-91 High density process control high voltage error (K)

Trouble content	For the production process (Not occur in the market.)
Detail	PCU
Cause	—
Check & Remedy	_

# F2-92 High density process control high voltage error (C)

Trouble content	For the production process (Not occur in the market.)
Detail	PCU
Cause	—
Check & Remedy	—

# F2-93 High density process control high voltage error (M)

Trouble content	For the production process (Not occur in the market.)
Detail	PCU
Cause	—
Check & Remedy	—

# F2-94 High density process control high voltage error (Y)

Trouble content	For the production process (Not occur in the market.)	
Detail	PCU	
Cause	—	
Check & Remedy	1	

#### F3-12 Paper feed tray 1 lift operation trouble

Trouble content	CLUD1 does not turn ON within the specified time.
Detail	PCU
Cause	CLUD1 is not turned ON within the specified time. CLUD1 sensor trouble. Paper feed tray 1 lift unit trouble. PCU PWB trouble. Sensor harness and connector connection trouble
Check & Remedy	Check connection of the harness and the connector of CLUD1. Replace the lift-up unit. Replace the PCU PWB.

#### F3-22 Paper feed tray 2 lift operation trouble

Trouble content	CLUD2 does not turn ON within the specified time.
Detail	PCU
Cause	CLUD2 does not turn ON within the specified time.
	CLUD2 sensor trouble.
	Paper feed tray 2 lift unit trouble.
	PCU PWB trouble.
	Sensor harness and connector connection trouble
Check & Remedy	Check the harness and the connector of CLUD2.
	Replace the lift-up unit.
	Replace the PCU PWB.

#### F6-00 MFPC PWB - FAX communication trouble

-		
Trouble content		MFP - FAX communication establishment error /
		Framing / Parity / Protocol error
Section		MFP
Case 1	Cause	FAX control PWB trouble.
	Check and Remedy	Replace the FAX control PWB.
Case 2	Cause	FAX control PWB - MFPC PWB connector and harness trouble
	Check and Remedy	Check the connector and the harness between the FAX control PWB and the MFPC PWB.
Case 3	Cause	FAX control PWB - Mother board connector and harness trouble
	Check and Remedy	Check the connector and the harness between the FAX control PWB and the mother board.
Case 4	Cause	FAX control PWB ROM trouble / ROM pin breakage
	Check and Remedy	Check the ROM of the FAX control PWB.

#### F6-01 FAX control PWB EEPROM read/write error

Trouble content		FAX control PWB EEPROM access error (Read and
		write)
Section		FAX
Case 1	Cause	FAX control PWB EEPROM trouble
	Check	Check that no trouble occurs after replacement of
	and	EEPROM. Execute the memory check of SIM66-3 to
	Remedy	insure that EEPROM can be accessed.
Case 2	Cause	FAX control PWB EEPROM access circuit trouble
	Check	Replace the FAX control PWB.
	and	
	Remedy	

#### F6-04 FAX MODEM operation trouble

Trouble content		FAX control PWB MODEM chip operation trouble	
Section		FAX	
Case 1	Cause	FAX MODEM chip operation trouble.	
	Check and remedy	Replace the FAX control PWB.	
Case 2	Cause	The FAX MODEM chip cannot be accessed.	
	Check and Remedy	Replace the FAX control PWB.	

#### F6-21 Improper combination of TEL/LIU PWB and FAX soft switch

Trouble	content	Incompatibility between the TEL/LIU PWB and the FAX control PWB information (soft switch)
Section		MFP
Case 1	Cause	The destination of the TEL/LIU PWB installed is improper.
	Check and Remedy	Check the destination of the TEL/LIU PWB.
Case 2	Cause	TEL/LIU PWB trouble.
	Check and Remedy	Replace the TEL/LIU PWB.

#### F6-30 FAX 1-chip microprocessor access error (FAX detection)

Trouble	content	FAX 1-chip microprocessor access error (Read and write)
Section		MFP
Case 1	Cause	Program writing trouble to the 1-chip microprocessor, or no program data written.
	Check and Remedy	Use SIM66-42 to rewrite the 1-chip microprocessor program.
Case 2	Cause	FAX 1-chip microprocessor circuit trouble.
	Check and Remedy	Replace the FAX control PWB.

#### F6-97 Incompatibility between FAX control PWB and the main machine

Trouble	content	Incompatibility between FAX control PWB and the main machine
Section		MFP
Case 1	Cause	The FAX control PWB installed is improper. FAX control PWB trouble.
	Check and Remedy	Install a proper FAX control PWB. Replace the FAX control PWB.

#### F6-98 Incompatibility between the FAX control PWB destination and the main machine destination

Trouble content		Incompatibility between the FAX control PWB destination and the main machine destination
Section		MFP
Case 1	Cause	Incompatibility between the destination information written into the FAX control PWB EEPROM and that in the main machine (set with SIM26-6)
	Check and Remedy	<ol> <li>Check the destination of the FAX control PWB.</li> <li>Check the destination of the machine. (SIM26-6)</li> </ol>

#### H2-00 Thermistor open trouble (TH_UM_AD2)

Trouble content	
Detail	PCU
Cause	Thermistor trouble PCU PWB trouble Thermistor connector and harness connection trouble Fusing section connector connection trouble Fusing unit not installed
Check & Remedy	Use SIM44-14 to check the state of the thermistor. Replace the thermistor. Replace the PCU PWB. Check connection of the thermistor connector and the harness. Check the connector in the fusing section.

### H2-01 Thermistor open trouble (TH_LM)

Trouble content	
Detail	PCU
Cause	Thermistor trouble
	PCU PWB trouble
	Thermistor connector and harness connection trouble
	Fusing section connector connection trouble
	Fusing unit not installed
Check & Remedy	Use SIM44-14 to check the state of the thermistor.
	Replace the thermistor.
	Replace the PCU PWB.
	Check connection of the thermistor connector and the
	harness.
	Check the connector in the fusing section.

### H2-02 Thermistor open trouble (TH_US)

Trouble content	
Detail	PCU
Cause	Thermistor trouble
	PCU PWB trouble
	Thermistor connector and harness connection trouble
	Fusing section connector connection trouble
	Fusing unit not installed
Check & Remedy	Use SIM44-14 to check the state of the thermistor.
	Replace the thermistor.
	Replace the PCU PWB.
	Check connection of the thermistor connector and the
	harness.
	Check the connector in the fusing section.

## H2-03 Thermistor open trouble

(TH_UM_AD1)

Trouble content	
Detail	PCU
Cause	Thermistor trouble
	PCU PWB trouble
	Thermistor connector and harness connection trouble
	Fusing section connector connection trouble
	Fusing unit not installed
Check & Remedy	Use SIM44-14 to check the state of the thermistor.
	Replace the thermistor.
	Replace the PCU PWB.
	Check connection of the thermistor connector and the
	harness.
	Check the connector in the fusing section.

#### H3-00 Fusing section high temperature trouble (TH_UM)

Trouble content	
Detail	PCU
Cause	The fusing temperature exceeds the specified level. Thermistor trouble PCU PWB trouble Thermistor connector and harness connection trouble HL control PWB trouble
Check & Remedy	Use SIM44-14 to check the state of the thermistor. Use SIM5-2 to check the flashing operation of the heater lamp. Use SIM14 to cancel the trouble. Replace the thermistor. Replace the PCU PWB. Check connection of the thermistor connector and the harness. Replace the HL control PWB.

#### H3-01 Fusing section high temperature trouble (TH_LM)

Trouble content	
Detail	PCU
Cause	The fusing temperature exceeds the specified level. Thermistor trouble PCU PWB trouble Thermistor connector and harness connection trouble
	HL control PWB trouble
Check & Remedy	Use SIM44-14 to check the state of the thermistor. Use SIM5-2 to check the flashing operation of the heater lamp. Use SIM14 to cancel the trouble. Replace the thermistor. Replace the PCU PWB. Check connection of the thermistor connector and the harness. Replace the HL control PWB.

# H3-02 Fusing section high temperature trouble (TH_US)

Trouble content	
Detail	PCU
Cause	The fusing temperature exceeds the specified level.
	Thermistor trouble
	PCU PWB trouble
	Thermistor connector and harness connection trouble
	HL control PWB trouble
Check & Remedy	Use SIM44-14 to check the state of the thermistor.
	Use SIM5-2 to check the flashing operation of the
	heater lamp.
	Use SIM14 to cancel the trouble.
	Replace the thermistor.
	Replace the PCU PWB.
	Check connection of the thermistor connector and the
	harness.
	Replace the HL control PWB.

# H4-00 Fusing section low temperature trouble (TH_UM_AD2)

Trouble content	The fusing temperature does not reach the specified level within the specified time from turning ON the power relay.
Detail	PCU
Cause	Thermistor trouble. Heater lamp trouble. PCU PWB trouble. Thermostat trouble. Connector, harness connection trouble. HL control PWB trouble.
	Power unit trouble.
Check & Remedy	Use SIM14 to cancel the trouble. Use SIM44-14 to check the state of the thermistor. Use SIM5-2 to check the flashing operation of the heater lamp. Replace the thermistor. Replace the heater lamp. Replace the PCU PWB. Replace the thermostat. Check connection of the connector and the harness. Replace the HL control PWB. Replace the power unit.

# H4-01 Fusing section low temperature trouble (TH_LM)

Trouble content	The fusing temperature does not reach the specified
	level within the specified time from turning ON the
	power relay.
Detail	PCU
Cause	Thermistor trouble.
	Heater lamp trouble.
	PCU PWB trouble.
	Thermostat trouble.
	Connector, harness connection trouble.
	HL control PWB trouble.
	Power unit trouble.
Check & Remedy	Use SIM14 to cancel the trouble.
	Use SIM44-14 to check the state of the thermistor.
	Use SIM5-2 to check the flashing operation of the
	heater lamp.
	Replace the thermistor.
	Replace the heater lamp.
	Replace the PCU PWB.
	Replace the thermostat.
	Check connection of the connector and the harness.
	Replace the HL control PWB.
	Replace the power unit.

# H4-02 Fusing section low temperature trouble (TH_US)

#### Trouble content The fusing temperature does not reach the specified level within the specified time from turning ON the power relay. Detail PCU Thermistor trouble. Cause Heater lamp trouble. PCU PWB trouble. Thermostat trouble. Connector, harness connection trouble. HL control PWB trouble. Power unit trouble. Check & Remedy Use SIM14 to cancel the trouble. Use SIM44-14 to check the state of the thermistor. Use SIM5-2 to check the flashing operation of the heater lamp. Replace the thermistor. Replace the heater lamp. Replace the PCU PWB. Replace the thermostat. Check connection of the connector and the harness. Replace the HL control PWB. Replace the power unit.

## H5-01 5 times continuous POD1 not-reach jam

Trouble content	
Detail	PCU
Cause	A fusing jam is not canceled completely. (A jam paper remains.) POD1 sensor trouble Fusing unit installation trouble POD1 sensor connector and harness connection trouble PCU PWB trouble Fusing unit drive section trouble
Check & Domody	Pushig unit, drive section trouble
Check & Remedy	Replace the POD1 sensor. Check installation of the fusing unit. Replace the fusing unit. Check or repair the fusing drive section. Check connection of the POD1 sensor connector and the harness. Replace the PCU PWB. Use SIM14 to cancel the trouble.

#### H7-10 Recovery error from low fuser temp. (TH_UM_AD2)

Trouble content	The fusing temperature does not reach the specified level within the specified time from stopping a job due to fall in the fusing temperature.
Detail	PCU
Cause	Thermistor trouble. Heater lamp trouble.
	PCU PWB trouble.
	Thermostat trouble.
	Connector, harness connection trouble.
	HL control PWB trouble.
	Power unit trouble.
Check & Remedy	Replace the thermistor.
	Replace the heater lamp.
	Replace the PCU PWB.
	Replace the thermostat.
	Check connection of the connector and the harness.
	Replace the HL control PWB.
	Replace the power unit.
	Use SIM5-2 to check the flashing operation of the
	heater lamp.

#### H7-11 Recovery error from low fuser temp. (TH_LM)

Trouble content	The fusing temperature does not reach the specified level within the specified time from stopping a job due to fall in the fusing temperature.
Detail	PCU
Cause	Thermistor trouble. Heater lamp trouble. PCU PWB trouble. Thermostat trouble. Connector, harness connection trouble. HL control PWB trouble. Power unit trouble.
Check & Remedy	Replace the thermistor. Replace the heater lamp. Replace the PCU PWB. Replace the thermostat. Check connection of the connector and the harness. Replace the HL control PWB. Replace the power unit. Use SIM5-2 to check the flashing operation of the heater lamp.

#### L1-00 Scanner feed trouble

Trouble content	Scanner feed is not completed within the specified time.
Detail	SCU
Cause	Scanner unit trouble. SCU PWB trouble. Scanner control PWB trouble. Harness and connector connection trouble. Scanner home position sensor trouble. Scanner motor trouble.
Check & Remedy	Use SIM1-1 to check the scan operation. Replace the scanner unit. Replace the SCU PWB. Check connection of the connectors and the harness. Replace the scanner home position sensor. Replace the scanner motor.

#### L3-00 Scanner return trouble

Trouble content	Scanner return is not completed within the specified
	time.
Detail	SCU
Cause	Scanner unit trouble
	SCU PWB trouble
	Scanner control PWB trouble
	Harness and connector connection trouble
	Scanner home position sensor trouble
	Scanner motor trouble
Check & Remedy	Use SIM1-1 to check the scan operation.
	Replace the scanner unit.
	Replace the SCU PWB.
	Check connection of the connectors and the harness.
	Replace the scanner home position sensor.
	Replace the scanner motor.

#### L4-02 Paper feed motor trouble

Trouble content	A lock signal is not detected within the specified time in ON operation of the paper feed motor after warming-up or canceling a jam.
Detail	PCU
Cause	Paper feed motor trouble Paper feed motor harness and connector connection trouble PCU PWB trouble
Check & Remedy	Use SIM6-1 to check the operation of the paper feed motor. Replace the paper feed motor. Check connection of the paper feed motor harness and the connector. Replace the PCU PWB.

### L4-03 Fusing motor trouble

Trouble content	The motor lock signal is detected during rotation of the fusing motor.
Detail	PCU
Cause	Fusing motor trouble Fusing motor harness and connector connection trouble PCU PWB trouble
Check & Remedy	Use SIM6-1 to check the operation of the fusing motor. Replace the Fusing motor. Check connection of the fusing motor harness and the connection. Replace the PCU PWB.

### L4-04 Developing motor trouble (BLACK)

Trouble content	The motor lock signal is detected during rotation of the developing motor.
Detail	PCU
Cause	Developing motor trouble Developing motor harness and connector connection trouble PCU PWB trouble Developing unit trouble
Check & Remedy	Use SIM25-1 to check the operation of the developing motor. Replace the developing motor. Check connection of the developing motor harness and the connection. Replace the PCU PWB. Replace the developing motor. Replace the developing unit.

#### L4-05 Developing motor trouble (COLOR)

Trouble content	The motor lock signal is detected during rotation of
	the developing motor.
Detail	PCU
Cause	Developing motor trouble
	Developing motor harness and connector connection
	trouble
	PCU PWB trouble
	Developing unit trouble
Check & Remedy	Use SIM25-1 to check the operation of the
	developing motor.
	Replace the developing motor.
	Check connection of the developing motor harness
	and the connection.
	Replace the PCU PWB.
	Replace the developing motor.
	Replace the developing unit.

#### L4-06 Transfer unit lift trouble

Trouble content	A change in the primary transfer position sensor cannot be detected within the specified time in lifting operation of the primary transfer unit.
Detail	PCU
Cause	Transfer unit position sensor trouble
	Dirt on the transfer unit position sensor.
	PCU PWB trouble
	Connection trouble of the connector and the harness.
	Transfer unit lift mechanism trouble
	Primary transfer belt unit is not installed.
Check & Remedy	Use SIM6-3 to check the separating operation of the transfer unit.
	Install the primary transfer belt unit.
	Replace the transfer unit position sensor.
	Clean the transfer unit position sensor.
	Replace the PCU PWB.
	Check connection of the connector and the harness.
	Repair the transfer unit lift mechanism.

#### L4-07 Transfer belt motor trouble

Trouble content	
Detail	PCU
Cause	The motor lock signal is detected during rotation of the transfer belt motor. Transfer belt motor trouble Transfer belt motor harness and connector connection trouble PCU PWB trouble
Check & Remedy	Use SIM25-1 to check the operation of the transfer belt motor. Check the transfer belt motor, and replace if necessary. Check connection of the harness and connectors of the transfer belt motor, and replace if necessary. Check the PCU PWB, and replace if necessary.

#### L4-11 Shift motor trouble

Trouble content	No change in the shifter home position sensor signal
	is detected in the operation of the shifter initializing.
Detail	PCU
Cause	Shift motor trouble.
	PCU PWB trouble.
	Connection trouble of the connector and the harness.
	Shifter home position sensor trouble.
Check & Remedy	Use SIM6-1 to check the shift operation.
	Use SIM30-1 to check the operation of the shifter
	home position sensor.
	Replace the shift motor.
	Replace the PCU PWB.
	Check connection of the connector and the harness.
	Replace the shifter home position sensor.

### L4-12 Secondary transfer separation trouble

Trouble content	A change in the separation sensor status cannot be detected within the specified time in separation operation of the secondary transfer.
Detail	PCU
Cause	Secondary transfer separation mechanism trouble. Secondary transfer separation clutch trouble. Secondary transfer separation sensor trouble. Connection trouble of the connector and the harness. PCU PWB trouble.
Check & Remedy	Check or repair the secondary transfer separation mechanism. Replace the secondary transfer separation clutch. Replace the secondary transfer separation sensor. Replace the PCU PWB. Check connection of the connector and the harness.

#### L4-16 Fusing pressure release trouble

	-
Trouble content	A change in the fusing pressure release sensor signal cannot be detected within the specified time after outputting the fusing pressure release motor.
Detail	PCU
Cause	Fusing pressure release sensor trouble. Fusing pressure release motor trouble. Pressure release drive gear and pressure release idle gear trouble.
	PCU PWB trouble. Connection trouble of the connector and the harness.
Check & Remedy	Replace the fusing pressure release sensor. Replace the fusing pressure release motor. Replace the pressure release drive gear and the pressure release idle gear. Replace the PCU PWB. Check connection of the connector and the harness.

#### L4-30 MPF FAN Motor trouble

Trouble content	Fan operation signal is not detected.
Detail	MPF
Cause	Fan motor trouble MFP PWB trouble harness and connector connection trouble PCU PWB trouble
Check & Remedy	Use Sim6-2 to check the operation of the fan motor Replace the fan motor Replace the MFP PWB Check connection of the connector and the harness Replace the PCU PWB

#### L4-31 Paper exit cooling fan trouble

Trouble content	The fan operation signal is not detected.
Detail	PCU
Cause	Paper exit cooling fan trouble.
	PCU PWB trouble
	Connection trouble of the connector and the harness.
Check & Remedy	Check connection of the connectors and the harness.
	Use SIM6-2 to check the rotating operation of the fan.
	Replace the paper exit cooling fan.
	Replace the PCU PWB.

#### L4-32 Power source cooling fan trouble

Trouble content	The fan operation signal is not detected.
Detail	PCU
Cause	Power cooling fan trouble.
	PCU PWB trouble.
	Connection trouble of the connector and the harness.
Check & Remedy	Use SIM6-2 to check that the fan is actually rotating.
	Replace the power cooling fan.
	Replace the PCU PWB.
	Check connection of the connectors and the harness.

#### L4-35 Fusing cooling fan trouble

Trouble content	The fan operation signal is not detected.
Detail	PCU
Cause	Fusing cooling fan trouble.
	PCU PWB trouble.
	Connection trouble of the connector and the harness.
Check & Remedy	Use SIM6-2 to check that the fan is actually rotating.
	Replace the fusing cooling fan.
	Replace the PCU PWB.
	Check connection of the connector and the harness.

#### L4-43 Paper exit cooling fan 2 trouble

Trouble content	The fan operation signal is not detected.
Detail	PCU
Cause	Paper exit cooling fan trouble.
	PCU PWB trouble.
	Connection trouble of the connector and the harness.
Check & Remedy	Replace the fan.
	Replace the PCU PWB.
	Check the connector and the harness.
	Use SIM6-2 to check that the fan is actually rotating.

#### L4-50 Process fan trouble

Trouble content	The fan operation signal is not detected.
Detail	PCU
Cause	Process fan trouble.
	PCU PWB trouble.
	Connection trouble of the connector and the harness.
Check & Remedy	Check that the fan is rotating after turning ON the
	power.
	Replace the process fan.
	Replace the PCU PWB.
	Check connection of the connector and the harness.

#### L4-51 Process fan 2 trouble

Trouble content	The fan operation signal is not detected.
Detail	PCU
Cause	Fan trouble.
	PCU PWB trouble.
	Connection trouble of the connector and the harness.
Check & Remedy	Replace the fan.
	Replace the PCU PWB.
	Check the connector and the harness.
	Check that the fan is rotating after turning ON the
	power.

#### L6-10 Polygon motor trouble

Trouble content	The polygon motor does not reach the specified RPM within the specified time after starting rotation of the polygon motor.
Detail	PCU
Cause	Polygon motor trouble. LSU mother PWB trouble. Connection trouble of the connector and the harness.
Check & Remedy	Use SIM61-1 to check the operation of the polygon motor. Check connection of the connector and the harness. Replace the LSU. Replace the LSU mother PWB.

#### L8-01 Full wave signal detection error

Trouble content	The full wave signal is not detected.
Detail	PCU
Cause	PCU PWB trouble.
	Power unit trouble.
	Connection trouble of the connector and the harness.
Check & Remedy	Replace the PCU PWB.
	Replace the power unit.
	Check connection of the connector and the harness.

#### L8-02 Full wave signal error

Trouble content	The full wave signal is not detected.
Detail	PCU
Cause	An abnormality in the full wave signal frequency is detected (The frequency is detected as 65Hz or above, or 45Hz or less) PCU PWB trouble. Power unit trouble Connection trouble of the connector and the harness Power frequency wave form abnormality
Check & Remedy	Replace the PCU PWB Replace the power unit Check connection of the connector and the harness Check the power wave form

#### L8-20 Communication error of MFPC PWB/ LSU mother board

Trouble content	
Detail	MFP
Cause	LSU mother board PWB - MFPC PWB connection trouble. MFPC PWB trouble. LSU mother board trouble.
Check & Remedy	Check connection between the LSU mother board PWB and the MFPC PWB. Check the ground of the main unit. Replace the MFPC PWB. Replace the LSU mother board.

#### P1-00 PCI communication error

Trouble content	
Detail	MFP
Cause	Communication error between the MFPC PWB and the PCI. Connection failure of connectors and harness between the MFPC PWB and the PCI. MFPC PWB trouble. PCI control PWB trouble.
Check & Remedy	Check connection of the harness and connectors between the MFPC PWB and the PCI. Check the MFPC PWB, and replace if necessary. (Refer to the necessary procedures after replacement of the MFPC PWB in the Service Manual, and perform the procedures.) Check the PCI control PWB, and replace if necessary.

#### P1-01 PCI fan error

Trouble content	
Detail	MFP
Cause	The PCI fan operation signal is not detected.
	PCI fan trouble.
	PCI control PWB trouble.
Check & Remedy	Check connection of the connectors and harness
	between the PCI fan and the PCI control PWB.
	Check the PCI control PWB, and replace if
	necessary.
	Check the PCI fan, and replace if necessary.



#### P1-02 Plasma generating device error

Trouble content	
Detail	MFP
Cause	Connection failure of connectors and harness between the plasma generating device and the PCI control PWB. Plasma generating device trouble. PCI control PWB trouble.
Check & Remedy	Check connection of the connectors and harness between the plasma generating device and the PCI control PWB. Replace the plasma generating device. Check the PCI control PWB, and replace if necessary.

#### Personal counter not detected PC--

Trouble content	
Detail	MFP
Cause	The personal counter is not installed. The personal counter is not detected. SCU PWB trouble.
Check & Remedy	Check connection of the connectors and the harness. Replace the SCU PWB.

#### U1-01 Battery trouble

Trouble	e content	RTC backup battery voltage fall
De	etail	MFP
Case 1	Cause	1) Battery life
		2) Battery circuit abnormality
	Check	Check to confirm that the battery voltage is about
	and	2.5V or above.
	Remedy	Replace the battery.

#### U2-00 MFP EEPROM read/write error

Trouble content	
Detail	MFP
Cause	MFPC PWB EEPROM trouble
	EEPROM socket contact trouble
	MFPC PWB trouble
	Strong external noises.
Check & Remedy	Replace the MFPC PWB EEPROM.
	Replace the MFPC PWB.
	(Refer to the pages on the necessary works after
	replacing the MFPC PWB in the Service Manual, and
	perform the works.)
	Check the power environment.

#### U2-05 HDD/MFPC PWB SRAM contents inconsistency

	-
Trouble content	The HDD or the MFPC PWB installed is improper.
	(Erroneous detection of account management data)
Detail	MFP
Cause	The HDD was replaced.
	The MFPC PWB was replaced.
	HDD trouble
	MFPC PWB trouble
Check & Remedy	(Refer to the pages on the necessary works after
	replacing the HDD and the MFPC PWB in the Service
	Manual, and perform the works.)
	Use SIM16 to cancel the error.

#### U2-11 MFPC PWB EEPROM counter check sum error

Trouble content	
Detail	MFP
Cause	MFPC PWB EEPROM trouble
	EEPROM socket contact trouble
	MFPC PWB trouble
	Strong external noises.
Check & Remedy	Use SIM16 to cancel the error. (The previous writing data (about the latest 8 sheets) are written into the EEPROM.) Replace the MFPC PWB. (Refer to the pages on the necessary works after replacing the MFPC PWB in the Service Manual, and perform the works.)

#### U2-30 MFPC PWB and PCU PWB manufacturing No. data inconsistency

Trouble content	Inconsistency between the manufacturing No. saved in the PCU PWB and that in the MFPC PWB.
Detail	MFP
Cause	When replacing the PCU PWB or the MFPC PWB, the EEPROM which was mounted on the PWB before replacement is not mounted on the new PWB. MFPC PWB trouble PCU PWB trouble
Check & Remedy	Check that the EEPROM is properly set. Check to confirm that the EEPROM which was mounted on the PWB before replacement is mounted on the new PWB. Replace the MFPC PWB. (Refer to the pages on the necessary works after replacing the MFPC PWB in the Service Manual, and perform the works.) Replace the PCU PWB.

#### **U2-40** SD card system storage data area error

Trouble content	
Detail	MFP
Cause	A file error occurs in the SD card system storage data partition. SD card trouble MFPC PWB trouble
Check & Remedy	Turn OFF/ON the power, and the backup data in the HDD are written into the SD card and the machine is automatically booted. Check the MFPC PWB, and replace if necessary. Check the SD card, and replace if necessary.

#### U2-41 HDD system storage data area error

Trouble content	
Detail	MFP
Cause	A file error occurs in the HDD system saved data area, disabling backup of the saved file of the machine adjustment values in the SD card. HDD trouble MFPC PWB trouble
Check & Remedy	Check the HDD, and replace if necessary. Check the MFPC PWB, and replace if necessary. When replacing the HDD and the MFPC PWB, refer to the chapter of "Necessary works and procedures of HDD and MFPC PWB replacement."

#### U2-42 Machine adjustment data (system storage data area) error

Trouble content	
Detail	MFP
Cause	The saved file of the machine adjustment values in the SD card and the HDD cannot be found or is broken. Both of the SD card set data and the HDD system saved data area are broken. HDD trouble MFPC PWB trouble SD card trouble
Check & Remedy	Check the HDD, and replace if necessary. Check the MFPC PWB, and replace if necessary. Check the SD card, and replace if necessary. When replacing the HDD, the MFPC PWB, and the SD card, refer to the chapter of "Necessary works and procedures of HDD, MFPC PWB, and SD card replacement." Use SIM to adjust the machine again and set the adjustment values.

#### U2-50 HDD*1 user authentication data check sum error

Trouble content	
Detail	MFP
Cause	HDD trouble*1
	MFPC PWB trouble
	Strong external noises.
Check & Remedy	Check the data related to the check sum error
	(address book, image send system registration data
	(senders record, meta data)) and register again.
	Use SIM16 to cancel the U2 trouble.
	Replace the HDD*1.
	Replace the MFPC PWB.
	(Refer to the pages on the necessary works after
	replacing the HDD and the MFPC PWB in the Service
	Manual, and perform the works.)*1

*1: SD card when no HDD is installed.

### U2-60 Watermark check error

Trouble content	
Detail	MFP
Cause	Watermark data trouble
	HDD trouble
	MFPC PWB trouble
Check & Remedy	Use SIM16 to cancel the U2 trouble.
	Use SIM49-5 to install the watermark data.
	Replace the HDD.
	Replace the MFPC PWB.
	(Refer to the pages on the necessary works after
	replacing the HDD and the MFPC PWB in the Service
	Manual, and perform the works.)

#### U2-80 SCU PWB EEPROM read/write error

Trouble content	
Detail	SCU
Cause	SCU PWB EEPROM trouble SCU PWB trouble
	SCU PWB EEPROM socket connection trouble
Check & Remedy	Replace the SCU PWB EEPROM. Replace the SCU PWB. Check connection of the SCU PWB EEPROM socket. Check the SIM adjustment value of the following items, and adjust again if they are improper. • Scanner-related adjustments • Touch panel-related adjustments
	Use SIM16 to cancel the trouble.

### U2-81 SCU PWB EEPROM check sum error

Trouble content	
Detail	SCU
Cause	SCU PWB EEPROM trouble.
	Installation of non-initialized EEPROM.
	SCU PWB trouble.
	EEPROM socket contact trouble.
Check & Remedy	Replace the SCU PWB EEPROM.
	Replace the SCU PWB.
	Check contact of the EEPROM socket.
	Use SIM16 to cancel the trouble. (The check sum
	error detection data are calculated again to reset the
	proper check sum data.)

#### U2-90 PCU PWB EEPROM read/write error

Trouble content	
Detail	PCU
Cause	PCU PWB EEPROM trouble
	PCU PWB trouble
	EEPROM socket contact trouble
Check & Remedy	Replace the PCU PWB EEPROM.
	Check the SIM adjustment values of the engine, and
	adjust again if they are improper.
	Replace the PCU PWB.
	Check contact of the EEPROM socket.
	Use SIM16 to cancel the trouble.

#### U2-91 PCU PWB EEPROM check sum error

Trouble content	
Detail	PCU
Cause	PCU PWB EEPROM trouble
	PCU PWB trouble
	EEPROM socket contact trouble
Check & Remedy	Replace the PCU PWB EEPROM.
	Replace the PCU PWB.
	Check contact of the EEPROM socket.
	Use SIM16 to cancel the trouble. (The check sum
	error detection data are calculated again to reset the
	proper check sum data.)

# U6-00 PCU PWB - Paper feed desk (paper feed tray 3, 4) communication trouble

Trouble content	
Detail	PCU
Cause	Connection trouble of the connector and the harness. Paper feed desk control PWB trouble PCU PWB trouble
Check & Remedy	Check connection of the connector and the harness. Replace the paper feed desk control PWB. Replace the PCU PWB.

#### U6-01 Paper feed tray 2 lift trouble

Trouble content	D1ULD does not turn ON within the specified time
Detail	PCU
Cause	CLUD2 sensor trouble.
	Desk control PWB trouble.
	Lift unit trouble.
	Connection trouble of the connector and the harness.
	PCU PWB trouble.
Check & Remedy	Replace the CLUD2 sensor.
	Replace the desk control PWB.
	Replace the lift unit.
	Check connection of the connector and the harness.
	Replace the PCU PWB.

#### U6-02 Paper feed tray 3 lift trouble

Trouble content	D2ULD does not turn ON within the specified time when lift-up operation.
Detail	PCU
Cause	D1ULD sensor trouble Desk control PWB trouble Lift unit trouble Connection trouble of the connector and the harness. PCU PWB trouble
Check & Remedy	Replace the D1ULD sensor. Replace the desk control PWB. Replace the lift unit. Check connection of the connector and the harness. Replace the PCU PWB.

#### U6-03 Paper feed tray 4 lift trouble

Trouble content	D2ULD does not turn ON within the specified time when lift-up operation.
Detail	PCU
Cause	D2ULD sensor trouble Desk control PWB trouble Lift unit trouble Connection trouble of the connector and the harness. PCU PWB trouble
Check & Remedy	Replace the D2ULD sensor. Replace the desk control PWB. Replace the lift unit. Check connection of the connector and the harness. Replace the PCU PWB.

### U6-09 LCC lift motor trouble

Trouble content	No variation in the motor rotation sensor signal (encoder sign) is detected within the specified time after booting or stopping the LCC lift motor.
Detail	PCU
Cause	LCC lift motor rotation sensor trouble
	LCC control PWB trouble
	LCC lift mechanism trouble
	LCC lift motor trouble
Check & Remedy	Use SIM4-2 and 4-3 to check the operation of the LCC
	sensor and the lift motor.
	Check the LCC lift motor rotation sensor, and replace
	if necessary.
	Check the LCC control PWB, and replace if
	necessary.
	Check the LCC lift mechanism, and repair if
	necessary.
	Check the LCC lift motor, and replace if necessary.
	Use SIM15 to cancel the trouble.

# U6-10 Desk paper feed unit paper transport motor trouble

Trouble content	
Detail	PCU
Cause	Desk paper feed motor trouble (motor lock, motor rpm
	abnormality, over-current to the motor).
	Desk control PWB trouble
	Connection trouble of the connector and the harness.
Check & Remedy	Use SIM4-3 to check the operation of the desk
	transport motor.
	Replace the desk control PWB.
	Replace the desk paper feed motor.
	Check connection of the connector and the harness.

#### U6-20 LCC control PWB - PCU PWB communication error

Trouble content	
Detail	PCU
Cause	Communication error between the LCC control PWB and the PCU PWB. Connection trouble of the harness and the connector between the machine and the LCC and those of the LCC control PWB. LCC control PWB trouble PCU PWB trouble Malfunction due to noises.
Check & Remedy	Check to confirm the LCC model. Check the connection of the harness and the connector between the machine and the LCC and those of the LCC control PWB, and replace if necessary. Check the LCC control PWB, and replace if necessary. Check the PCU PWB, and replace if necessary.

#### U6-21 LCC transport motor trouble

Trouble content	No variation in the motor rotation sensor signal (encoder sign) is detected within the specified time after booting or stopping the LCC transport motor.
Detail	PCU
Cause	LCC transport motor rotation sensor trouble LCC control PWB trouble LCC paper transport mechanism trouble LCC paper transport motor trouble
Check & Remedy	Use SIM4-3 to check the operation of the LCC transport motor. Check the LCC transport motor rotation sensor, and replace if necessary. Check the LCC control PWB, and replace if necessary. Check the LCC paper transport mechanism, and replace if necessary. Check the LCC transport motor, and replace if necessary.

#### U6-22 LCC 24V power trouble

Trouble content	The power voltage of DC24V is not supplied to the
	LCC unit.
Detail	PCU
Cause	Connection trouble of the harness and the connector between the machine and the LCC and those of the LCC control PWB. LCC control PWB trouble Machine power unit trouble
Check & Remedy	Check the connection of the harness and the connector between the machine and the LCC and those of the LCC control PWB, and replace if necessary. Check the LCC control PWB, and replace if necessary. Check the machine power unit, and replace if necessary.

#### U6-50 Desk - Main unit combination trouble

Trouble content	
Detail	PCU
Cause	Improper combination between the main unit and the
	desk.
	Desk control PWB trouble.
Check & Remedy	Install a desk which is proper for the main unit mode.
	Replace the desk control PWB.

### U6-51 LCC - Main unit combination trouble

Trouble content	An LCC of a different model which is not supported by
	the machine is installed. (Improper combination of the
	machine and the LCC model code.)
Detail	PCU
Cause	LCC control PWB trouble
	PCU PWB trouble
Check & Remedy	Check to confirm the LCC model.
	Check the LCC control PWB, and replace if necessary.
	Check the PCU PWB, and replace if necessary.

#### U6-52 PCU PWB - Paper feed desk (paper feed tray 2) communication trouble

Trouble content	Paper feed tray 2 (desk unit) is not recognized.
Detail	PCU
Cause	Connection failure between the machine and paper feed tray 2 (desk unit) PCU PWB trouble.
Check & Remedy	Check connection of the connector and the harness. Replace the PCU PWB.

#### U7-50 MFPC PWB - Vendor machine communication error

Trouble content	Communication error between the MFP and the serial vendor.
Detail	MFP
Cause	Improper setting of the vendor machine specifications (SIM26-3). Vendor machine trouble. MFPC PWB trouble. Connector, harness connection trouble. Strong external noises.
Check & Remedy	Cancel the error by turning OFF/ON the power. Check the connector and the harness in the communication line. Change the specifications of the vendor machine (SIM26-3). Replace the MFPC PWB.

## U7-51 Vendor machine error

Trouble content	
Detail	MFP (Notification of a trouble from the serial vendor)
Cause	Serial vendor machine trouble.
	Connector, harness connection trouble.
Check & Remedy	Err.XX is displayed on the operation panel of the vendor. (XX is the detail code.) Repair the vendor machine referring to the detail code. Check the connector and the harness in the communication line.

## U9-01 Touch panel trouble

Trouble content	
Detail	SCU
Cause	SCU PWB trouble
Check & Remedy	Check connection signal between the SCU CPU and the touch panel controller.
# UC-02 CPT - ASIC error

Trouble content	
Detail	SCU
Cause	SCU PWB trouble. (CPT-ASIC trouble.)
Check & Remedy	Replace the SCU PWB.

### (1) Descriptions on E7-91 - 94 errors

Two-digit numbers with double parentheses are added to E7-91 - 94 error codes recorded in SIM22-6 indicate the detailed contents of the errors.

The number in each digit has its own meaning.

(Example) E7-91(**)

The upper digit of the added code indicates the job kind at the occurrence of the error.

Error	The upper digit of	Image	Job kind at the occurrence	
E7 01		Othor	of the error	*1
L7-31	1*	IPEG	• EAX (Internet EAX)	*1
	2*	IRIG	<ul> <li>FAA (IIIteIIIet FAA)</li> <li>recention print (Other than</li> </ul>	*1
	3*	Myv1ch	long size images)	-
		Mxx4ch	g 0.20	
	5*	Other		*1
	6*		• EAX (Internet EAX)	*1
	7*	JBIG	reception print	*1
	8*	Mxx1ch	(Long size images)	<u> </u>
	9*	Mxx4ch		
	A* - F*	Not Used		*1
E7-92	0*	Other		*1
	1*	JPEG		
	2*	JBIG	<ul> <li>OC copy (in Non ERDH)</li> </ul>	*1
	3*	Mxx1ch		*1
	4*	Mxx4ch		
	5* - F*	Not Used		*1
E7-93	0*	Other		*1
	1*	JPEG	Copy print (in ERDH)     Copy companing system	
	2*	JBIG	Copy composing system     function (Custom Stomp	
	3*	Mxx1ch	Water mark)	*1
	4*	Mxx4ch	Water many	
	5*	Other		*1
	6*	JPEG	Image send	
	7*	JBIG	Document filing	
	8*	Mxx1ch	<ul> <li>Preview display</li> </ul>	
	9*	Mxx4ch		
	A*	Other	• CDI/PCI printer print	*1
	B*	JPEG	Conv composing system	
	C*	JBIG	function (Custom Stamp	L
	D*	Mxx1ch	Water mark)	*1
	E*	Mxx4ch	,	
	F*	Not Used		*1
E7-94	0*	Other		*1
	1*	JPEG	Backup restore	
	2*	JBIG	(Filing data import)	*1
	3*	Mxx1ch	(g colo import)	*1
	4*	Mxx4ch		*1
	5* - F*	Not Used		*1

*1: Added code without generating

The lower digit of the added code indicates the kind and the content of the abnormality or the result of the automatic memory check executed when the abnormality is detected.

				Lower digit of the added code $\rightarrow$ Kind/Content of the error						
			*1	*9	*A	*В	*C	*D	*E	*F
		Memory		Huffman	Restart	Improper	Head decoding	Head decoding	Other	
			verify	—	code	marker	marker	error detection	error detection	abnormal
			NG		error	error	error	(ASIC detection)	(CPU detection)	termination
The upper digit of the	1*, 6*, B*	JPEG	•		0	0	0	0		0
added code	2*, 7*, C*	JBIG	•			Ι	0	0		0
$\downarrow$	3*, 8*, D*	Mxx1ch	•		-		—	_	_	0
Error detection circuit	4*, 9*, E*	Mxx4ch	•	_	_	_	_	_	_	0

•: Added code indicating that the memory and its peripheral must be focused for check in case of an error.

# UC-20 DOCC ASIC error

Trouble content	
Detail	SCU
Cause	SCU PWB trouble. (DOCC-ASIC trouble.)
Check & Remedy	Replace the SCU PWB.

O: Added code indicating that doubtful sections are in a wider range such as the memory, PWB's, HDD, etc.

-: Added code without generating

# (2) Countermeasures in case of E7-91 - 94 In case of E7-9x (11), E7-9x (21), E7-9x (31), E7-9x (41)

Cause	In case of E7-91 - 94, the DIMM memory (DRAM) is automatically read/written to perform a simplified check. If an abnormality is detected in that case, the added code becomes (*1). Therefore, there is a strong possibility that an abnormality lies around the memory.
Check and remedy	<ul> <li>Check the installing state of the DIMM memory and the MFPC PWB to insure that there is no abnormality. (Disconnect and connect the DIMM memory and the MFPC PWB to check to insure that there is no error occurring again.)</li> <li>Use SIM60-01 (Memory read/write check) to check to insure that no error occurs.</li> <li>Replace the DIMM memory.</li> <li>Replace the MFPC PWB.</li> </ul>

# Note

Since the automatic memory check executed when E7-91 - 94 occurs is a simplified check, it cannot detect an abnormality with absolute certainty.

If the added code is (*1), there may be a memory abnormality. Even if it is not (*1), however, it cannot be said that there is no abnormality around the memory.

#### Other added codes

Cause	Mostly because the data inputted to the ASIC for decoding are broken for some reasons. There is an abnormality in the process of read/write of the process data in the memory or the hard disk. A great noise unexpectedly generated may be the cause. For the cases of FAX or Internet FAX reception data, when broken data are saved, printing is performed every time when the machine is booted, generating an error repeatedly. (E7-91) (To clear the received data, execute SIM66-10.)
Check and remedy	<ul> <li>Check the DIMM memory, the MFPC PWB, and the HDD to insure that there is no abnormality.</li> <li>When the job at occurrence of an error is FAX (E7-91), check the installing state of the FAX control PWB and the SC CARD PWB.</li> <li>Perform SIM60-01 (Memory read/write check) to insure that there is no NG.</li> <li>Perform SIM62-02 and SIM62-03 (HDD read/write check) to insure that there is no NG.</li> <li>Perform SIM62-02 and SIM62-03 (HDD read/write check) to insure that there is no NG. (It is not required, however, when the job at occurrence of an error is FAX.)</li> <li>Check the installing state of the DIMM memory and the MFPC PWB to insure that there is no abnormality. (Disconnect and connect the DIMM memory and the MFPC PWB to check to insure that there is no error occurring again.)</li> <li>Replace the HDD.</li> <li>Replace the DIMM memory.</li> <li>Replace the MFPC PWB.</li> <li>Replace the SD card.</li> </ul>

# Note

When there is an abnormality around the HDD, E7-03 may occur. If error E7-91 - 94 as well as E7-03 occurs, there is a high possibility that the error can be removed by replacing the HDD and the MFPC PWB.

# (3) Countermeasures against the case where nothing is displayed when the machine is booted

#### [Trouble content]

If nothing is displayed when the machine is booted, the error code cannot be checked and the cause is hard to identify.

One of the causes may be an abnormality in the boot program of the SD card. To check that, the following method is used.

#### [Check method]

Check to confirm that the LED (red) under the CPU heat sink on the MFPC PWB shown in the figure below is lighted when the power is supplied.

If the LED is lighted, it is judged as an abnormality of the SD card.



#### [Countermeasures]

- 1) Replace the SD card with a new one. (Be sure to use a service part.)
- 2) Upgrade the firmware to the latest version.
- 3) Use SIIM66-62 to backup the FAX reception data from the HDD to a USB memory device. (If there is no FAX reception data, this procedure is not required.) (The FAX reception data are backed up in the PDF format. Supply the date to the user.)
- Use SIM66-10 to clear the FAX and image send memory. (Ensure consistency between the HDD data and the image related memory.)

# (4) Relation between the MFPC PWB LED status and errors

When the machine cannot be booted, check the LED status of the MFPC PWB to presume the error content and its cause.

<process co<="" th=""><th>ntent and</th><th>LED dis</th><th>play&gt;</th></process>	ntent and	LED dis	play>
-------------------------------------------------------------------------------------	-----------	---------	-------

LED status (Lighting)	Process operation content	Cause for halt during operation
0000	CPU initial setting	Reus ASIC trouble
000●	Memory adjustment	Memory and its
		peripheral circuit trouble
0000	Memory check	Memory and its
		peripheral circuit trouble
00 • •	_	_
0000	Program memory development	Memory-related trouble
$\circ \bullet \circ \bullet$	Interruption-related initialization	Reus ASIC trouble
$0 \bullet \bullet 0$	PCIe initialization	PCIe and its peripheral
		circuit trouble (SoC, etc.)
$\bigcirc \bullet \bullet \bullet$	Basic device initialization	Reus ASIC trouble
•000	SD card initialization	Reus ASIC trouble
	SATA initialization	SD card trouble
		HDD trouble
●00●	OS initialization (1)	Reus ASIC trouble
$\bullet \circ \bullet \circ$	Timer enabling	Reus ASIC trouble
$\bullet \circ \bullet \bullet$	Serial driver enabling	Reus ASIC trouble
	I2C driver enabling	
••00	LCD initialization	Reus ASIC trouble
$\bullet \bullet \bullet \circ$	Image process IP initialization	Reus ASIC trouble
$\bullet \bullet \bullet \circ$	OS initialization (2)	Reus ASIC trouble
	Main process	Reus ASIC trouble

* •: LED ON / O: LED OFF

#### <When an error occurs>

LED status (Flashing)	Error content	Cause
000●	Nonsupport memory	Memory trouble
0000	Nonsupport memory (access speed)	Memory trouble
00 • •	Nonsupport memory controller	Memory trouble
0000	DDR-PHY setting error	Reus ASIC trouble
0.00	Interruption handler process error	Reus ASIC trouble
•000	Memory check error	Memory trouble
	Memory combination error	Memory trouble

* In case of an error, the LED's flash as shown in the above table.

* •: LED ON / O: LED OFF

0000 •

LED No D25/D24/D23/D22 3 / 2 / 1 / 0

# 2. JAM and troubleshooting

# A. JAM code list

		JAM detection method				JAM	
JAM code	JAM content	JAM detection start trigger	JAM judgment condition	Basic distance(A) [mm]	JAM margin distance (B) [mm]	detection distance (A+B) [mm]	
TRAY1	Main cassette paper feed JAM (CPFD1 not-reached JAM)	CPUC1 ON	CPFD1 ON	103.4	65.0	168.4	
CPFD1_N2	CPFD1 not-reached JAM (Main cassette 2 feed paper)	CPFD2 ON	CPFD1 ON	99.1	65.0	164.1	
CPFD1_N3	CPFD1 not-reached JAM (Desk upper stage feed paper)	CPFD2 ON	CPFD1 ON	107.0	65.0	172.0	
CPFD1_N4	CPFD1 not-reached JAM (Desk lower stage feed paper)	CPFD2 ON	CPFD1 ON	107.0	65.0	172.0	
TRAY2	CPFD2 not-reached JAM (Main cassette 2 feed paper)	CPUC2 ON	CPFD2 ON	103.4	65.0	168.4	
CPFD2_N3	CPFD2 not-reached JAM (Desk upper stage feed paper)	Reception of the paper feed start command from DESK (At position 45mm from the final roller of the DESK.)	CPFD2 ON	35.5	65.0	100.5	
CPFD2_N4	CPFD2 not-reached JAM (Desk lower stage feed paper)	Reception of the paper feed start command from DESK (At position 45mm from the final roller of the DESK.)	CPFD2 ON	35.5	65.0	100.5	
MFT	Manual feed tray paper feed JAM (PPD1 not-reached)	MPFS ON	PPD1 ON	83.2	65.0	148.2	
PPD1_N1	PPD1 not-reached JAM (Cassette 1 feed paper)	CPFD1 ON	PPD1 ON	151.9	65.0	216.9	
PPD1_N2	PPD1 not-reached JAM (Main cassette 2 feed paper)	CPFD1 ON	PPD1 ON	149.6	65.0	214.6	
PPD1_N3	PPD1 not-reached JAM (Desk upper stage feed paper)	CPFD1 ON	PPD1 ON	149.6	65.0	214.6	
PPD1_N4	PPD1 not-reached JAM (Desk lower stage feed paper)	CPFD1 ON	PPD1 ON	149.6	65.0	214.6	
PPD1_NA	PPD1 not-reached JAM (ADU refeed paper)	APPD2 ON	PPD1 ON	135.7	65.0	200.7	
PPD1_NL	PPD1 not-reached JAM (LCC feed paper)	Reception of the paper feed start command from LCC (Extension amount 19mm position)	PPD1 ON	141.7	65.0	206.7	
PPD2_N1	PPD2 not-reached JAM (Main cassette feed paper)	CPFD1 ON	PPD2 ON	71.9	65.0	136.9	
PPD2_N2	PPD2 not-reached JAM (Main cassette 2 feed paper)	CPFD1 ON	PPD2 ON	71.9	65.0	136.9	
PPD2_N3	PPD2 not-reached JAM (Desk upper stage feed paper)	CPFD1 ON	PPD2 ON	71.9	65.0	136.9	
PPD2_N4	PPD2 not-reached JAM (Desk lower stage feed paper)	CPFD1 ON	PPD2 ON	71.9	65.0	136.9	
PPD2_NM	PPD2 not-reached JAM (Manual feed tray feed paper)	PPD1 ON	PPD2 ON	70.4	65.0	135.4	
PPD2_NA	PPD2 not-reached JAM (ADU refeed paper)	PPD1 ON	PPD2 ON	70.4	65.0	135.4	
PPD2_NL	PPD2 not-reached JAM (LCC feed paper)	PPD1 ON	PPD2 ON	71.9	65.0	136.9	
POD1_N	POD1 not-reached JAM	RRM ON	POD1 ON	242.4	50.0	292.4	
POD2_N	POD2 not-reached JAM	POD1 ON	POD2 ON	92.2	65.0	157.2	
POD3_N	POD3 not-reached JAM	Reversing start	POD3 ON	53.7	65.0	118.7	
APPD1_N	APPD1 not-reached JAM	Reversing start	APPD1 ON	39.3	65.0	104.3	
APPD2_N	APPD2 not-reached JAM	APPD1 ON	APPD2 ON	226.3	65.0	291.3	
CPFD1_S1	CPFD1 remaining JAM (Main cassette paper)	CPUC1 OFF	CPFD1 OFF	144.4	65.0	209.4	
CPFD1_S2	CPFD1 remaining JAM (Main cassette 2 feed paper)	CPFD2 OFF	CPFD1 OFF	96.8	65.0	161.8	
CPFD1_S3	CPFD1 remaining JAM (Desk upper stage feed paper)	CPFD2 OFF	CPFD1 OFF	107.0	65.0	172.0	
CPFD1_S4	CPFD1 remaining JAM (Desk lower stage feed paper)	CPFD2 OFF	CPFD1 OFF	107.0	65.0	172.0	
CPFD2_S2	CPFD2 remaining JAM (Main cassette 2 feed paper)	CPUC2 OFF	CPFD2 OFF	144.4	65.0	209.4	
CPFD2_S3	CPFD2 remaining JAM (Desk upper stage feed paper)	Reception of the paper feed end command from DESK (The final roller position of DSEK)	CPFD2 OFF	89.2	65.0	154.2	

		JAM detect	ion method	Basic	JAMmargin	JAM
JAM code	JAM content	JAM detection start trigger	JAM judgment condition	distance (A) [mm]	distance (B) [mm]	detection distance (A+B) [mm]
CPFD2_S4	CPFD2 remaining JAM (Desk lower stage feed paper)	Reception of the paper feed end command from DESK (The final roller position of DSEK)	CPFD2 OFF	89.2	65.0	154.2
PPD1_S1	PPD1 remaining JAM (Main cassette paper)	CPFD1 OFF	PPD1 OFF	149.9	65.0	214.9
PPD1_S2	PPD1 remaining JAM (Main cassette 2 feed paper)	CPFD1 OFF	PPD1 OFF	149.9	65.0	214.9
PPD1_S3	PPD1 remaining JAM (Desk upper stage feed paper)	CPFD1 OFF	PPD1 OFF	149.9	65.0	214.9
PPD1_S4	PPD1 remaining JAM (Desk lower stage feed paper)	CPFD1 OFF	PPD1 OFF	149.9	65.0	214.9
PPD1_SM	PPD1 remaining JAM (Manual feed tray feed paper)	PPD1 ON	PPD1 OFF	Sub scan size –9	65.0	Sub scan size –9 + 65
PPD1_SA	PPD1 remaining JAM (ADU refeed paper)	APPD2 OFF	PPD1 OFF	131.1	65.0	196.1
PPD1_SL	PPD1 remaining JAM (LCC refeed paper)	Reception of the paper feed end command from LCC (LPFD OFF)	PPD1 OFF	179.1	65.0	244.1
PPD2_S1	PPD2 remaining JAM (Main cassette feed paper)	PPD1 OFF	PPD2 OFF	62.9	65.0	127.9
PPD2_S2	PPD2 remaining JAM (Main cassette 2 feed paper)	PPD1 OFF	PPD2 OFF	62.9	65.0	127.9
PPD2_S3	PPD2 remaining JAM (Desk upper stage feed paper)	PPD1 OFF	PPD2 OFF	62.9	65.0	127.9
PPD2_S4	PPD2 remaining JAM (Desk lower stage feed paper)	PPD1 OFF	PPD2 OFF	62.9	65.0	127.9
PPD2_SM	PPD2 remaining JAM (Manual feed tray feed paper)	PPD1 OFF	PPD2 OFF	61.4	65.0	126.4
PPD2_SA	PPD2 remaining JAM (ADU refeed paper)	PPD1 OFF	PPD2 OFF	61.4	65.0	126.4
PPD2_SL	PPD2 remaining JAM (LCC feed paper)	PPD1 OFF	PPD2 OFF	62.9	65.0	127.9
POD1_S	POD1 remaining JAM	PPD2 OFF	POD1 OFF	297.6	65.0	362.6
POD2_S	POD2 remaining JAM (When left paper exit)	POD1 OFF	POD2 OFF	90.2	65.0	155.2
	POD2 remaining JAM (When ADU reversing)	Reversing start	POD2 OFF after starting reversing	Sub scan size –60.6	65.0	Sub scan size –60.6 + 65
POD3_S	POD3 remaining JAM	POD2 OFF after starting reversing	POD3 OFF	68.9	65.0	133.9
APPD1_S	APPD1 remaining JAM	POD2 OFF after starting reversing	APPD1 OFF	111.0	65.0	176.0
APPD2_S	APPD2 remaining JAM	APPD1 OFF	APPD2 OFF	228.8	65.0	293.8
PPD2_PRI	PPD2 JAM (Image preparation wait time-	Transmission of the IMAGE_PREPARE command	Reception time-out of the END_IMAGE_PREPARE	—	—	Ι
CPFD2	CPED2 JAM	Transmission of the	Reception time-out of the	_	_	_
DESK	(Desk communication abnormality detection)	preliminary paper feed request command to DESK	preliminary paper feed start command from DESK (30 sec)			
		Reception of the preliminary paper feed start command from DESK	Reception time-out of the preliminary paper feed end command from DESK (30 sec)	_	—	_
		Transmission of the paper feed request command to DESK	Reception time-out of the paper feed start command from DESK (30 sec)	_	_	_
		Reception of the paper feed start command from DESK	Reception time-out of the paper feed end command from DESK (30 sec)	—	_	_
PPD1_LCC	PPD1 JAM (LCC communication abnormality detection)	Transmission of the preliminary paper feed request command to LCC	Reception time-out of the preliminary paper feed start command from LCC (30 sec)	—	_	_
		Reception of the preliminary paper feed start command from LCC	Reception time-out of the preliminary paper feed end command from LCC (30 sec)	—	—	—
		Transmission of the paper feed request command to LCC	Reception time-out of the paper feed start command from LCC (30 sec)	_	_	—
		Reception of the paper feed start command from LCC	Reception time-out of the paper feed end command from LCC (30 sec)	_	_	

	JAM content	JAM detect	Basic	IAM morgin	JAM	
JAM code		JAM detection start trigger	JAM judgment condition	distance(A) [mm]	distance (B) [mm]	detection distance (A+B) [mm]
PPD2_FIN	PPD2 JAM	Transmission of the paper	Reception time-out of the	—	_	_
	(Finisher communication	attribute data command to	paper interval data command			
	abnormality detection)	FINISHER	from FINISHER (30 sec)			

# (1) RSPF

		JAM detect	tion method	Rasic distance	JAM margin	JAM detection
JAM code	JAM content	JAM detection start trigger	JAM judgment condition	(A) [mm]	distance (B) [mm]	distance (A+B) [mm]
SPPD1_N	SPPD1 not-reached JAM	Paper feed start (When the document width is more than B5 size.)	SPPD1 ON	51.5	450.0	501.5
SPPD2_N	SPPD2 not-reached JAM	Paper feed start (When the document width is less than B5 size.)	SPPD2 ON	90.2	450.0	540.2
		SPPD1 ON (When the document width is more than B5 size.)	SPPD2 ON	38.7	50.0	88.7
SPPD3_N	SPPD3 not-reached JAM	Restart at the temporal stop position	SPPD3 ON	23.7	50.0	73.7
SPPD4_N	SPPD4 not-reached JAM	SPPD3 ON	SPPD4 ON	149.1	50.0	199.1
SPPD2_NR	SPPD2 reverse not- reached JAM	Reversing start	SPPD2 ON	85.5	50.0	135.5
SPPD1_S	SPPD1 remaining JAM	SPPD1 ON (When the document width is more than B5 size.)	SPPD1 OFF	Normal mode: 431.8mm Long size mode: 1000mm/ 800mm	50.0	Normal mode: 481.8mm Long size mode: 1050mm/ 850mm
SPPD2_S	SPPD2 remaining JAM	SPPD2 ON (When the document width is less than B5 size.)	SPPD2 OFF	Normal mode: 431.8mm Long size mode: 1000mm/ 800mm	50.0	Normal mode: 481.8mm Long size mode: 1050mm/ 850mm
		SPPD1 OFF (When the document width is more than B5 size.)	SPPD2 OFF	37.8	50.0	87.8
SPPD3_S	SPPD3 remaining JAM	SPPD2 OFF	SPPD3 OFF	68.8	50.0	118.8
SPPD4_S	SPPD4 remaining JAM	SPPD3 OFF	SPPD4 OFF	153.3	50.0	203.3
SPPD2_SR	SPPD2 reverse remaining JAM	SPPD4 OFF	SPPD2 OFF	100.9	50.0	150.9
SPSD_SCN	Exposure start notification timer end	Arrival at temporal stop position	Exposure start command from ICU to SCU no reception time- out (120 sec)	—	—	—
P_SHORT	Short size JAM	SPPD3 ON	When the document length is less than 120.0mm.	—	—	—
SDFS_S	Paper JAM	Start of the light quantity correction between papers	When canceling of the light quantity correction between papers does not make it in time.	_	—	_
ICU_REQ	ICU factor stop JAM	_	Stop by a job stop request commend from ICU to SCU	—	—	—
STOP_JAM	Emergency stop JAM	—	Trouble mode transition request from ICU to SCU Emergency stop by a command	_	_	_

# (2) Desk

JAM code	IAM content	JAM detection method		
	SAM content	JAM detection start trigger	JAM judgment condition	
TRAY3	Casette 3 (Desk 1) paper feed JAM	D1PFC ON (Paper feed start)	D1PPD does not turn ON within the specified time.	
DPFD1_N4	DPFD1 not-reached JAM (Desk 2 feed paper)	D2PPD ON	D1PPD does not turn ON within the specified time.	
DPFD1_S3	DPFD1 remaining JAM (Desk 1 feed paper)	D1PPD ON	D1PPD does not turn OFF within the specified time.	
DPFD1_S4	DPFD1 remaining JAM (Desk 2 feed paper)	D2PPD OFF	D1PPD does not turn OFF within the specified time.	
DPFD2_S4	DPFD2 remaining JAM (Desk 2 feed paper)	D2PPD ON	D2PPD does not turn OFF within the specified time.	
TRAY4	Casette 4 (Desk 2) paper feed JAM	D2PFC ON (Paper feed start)	D2PPD does not turn ON within the specified time.	

# (3) LCC

JAM code	IAM content	JAM detection method	
	JAW content	JAM detection start trigger	JAM judgment condition
LCC	Side LCC paper feed JAM (LPFD not-reached)	LPFC ON (paper feed start)	LPFD does not turn ON within the specified time.
LPFD_SL	LPFD remaining JAM (Side LCC feed paper)	LPFD ON	LPFD does not turn OFF within the specified time.

# (4) Saddle finisher

		JAM detection method		Decie distance	JAM margin	JAM detection
JAM code	JAM content	JAM detection start trigger	JAM judgment condition	(A) [mm]	distance (B) [mm]	distance (A+B) [mm]
PDPPD1_N	Interface inlet port not- reached JAM	Machine paper exit command reception	PDPPD1 does not turn ON within the specified time.	79.6 [mm]	238.8 [mm]	318.4 [mm]
PDPPD1_S	Interface inlet port remaining JAM	PDPPD1 ON	PDPPD1 does not turn OFF within the specified time.	(Paper length + 11.3) [mm]	(Paper length + 11.3) [mm]	(Paper length + 11.3) x 2 [mm]
PDPPD2_N	Interface outlet port not- reached JAM	PDPPD1 ON	PDPPD2 does not turn ON within the specified time.	318.7 [mm]	318.7 [mm]	637.4 [mm]
PDPPD2_S	Interface outlet port remaining JAM	PDPPD2 ON	PDPPD2 does not turn OFF within the specified time.	(Paper length + 11.3) [mm]	(Paper length + 11.3) [mm]	(Paper length + 11.3) x 2 [mm]
FPPD1_N	Finisher inlet port not- reached JAM	PDPPD2 ON	FPPD1 does not turn ON within the specified time.	180.3 [mm]	180.3 [mm]	360.6 [mm]
FPPD1_S	Finisher inlet port remaining JAM	Paper reaches the finisher speed change position.	FPPD1 does not turn OFF within the specified time.	108.4 [mm]	216.8 [mm]	325.2 [mm]
FPPD2_N	Saddle section not- reached JAM	The lead edge of paper reaches the position of 20mm past the saddle No. 1 transport roller.	FPPD2 does not turn ON within the specified time.	110.4 [mm]	110.4 [mm]	220.8 [mm]
FPPD2_S	Saddle section remaining JAM	The rear edge of paper reaches the position of 20mm past the process roller.	FPPD2 does not turn OFF within the specified time.	220.4 [mm]	220.4 [mm]	440.8 [mm]
FPDD_S	Bundle exit remaining JAM	Gripper discharging is started.	FATPD does not turn OFF within the specified time.	437 [msec]	437 [msec]	874 [msec]
		Gripper discharging is completed.	FPDD does not turn ON when gripper discharging is completed.			FPDD OFF
FSTPLJ	Staple JAM	Driving the staple motor is started.	FSHS ON is not detected within the specified time after detection of FSHS OFF during stapling operation, and FSHS ON is detected by reverse rotation of the staple motor after stapling operation is stopped.	400 [msec]	200 [msec]	600 [msec]
		Staple extending operation is started.	Staple extending cannot be executed by execution of staple feeding by the specified number of times (9 times) during staple extending operation.			9 times
		Driving the saddle staple motor is started.	FSSHS ON is not detected within the specified time after detection of FSSHS OFF during stapling operation, and FSSHS ON is detected by reverse rotation of the staple motor after stapling operation is stopped.	480 [msec]	240 [msec]	720 [msec]
		Saddle staple extending operation is started.	Staple extending cannot be executed by execution of staple feeding by the specified number of times (14 times) during staple extending operation.			14 times

# MX-3640N TROUBLESHOOTING 7-39

		JAM	JAM detection method		JAM margin	JAM detection
JAM code	JAM content	JAM detection start trigger	JAM judgment condition	(A) [mm]	distance (B) [mm]	distance (A+B) [mm]
FPNCHJ	Punch JAM	Punch motor stop	FPCHPS does not turn ON after punching operation.			FPCHPS OFF
FIN_TIME	Finisher paper early reaching JAM	Paper exit command of the preceding paper	The paper exit command of the next paper is received at the timing earlier than the specified paper interval.	Specified paper interval time	150 [msec]	(Specified paper interval time) - 150) [msec]
FIN_PAOF	Paper attribute data reception overflow	Paper information data command is received.	Paper information data of more than allowable buffer (16 sheets) are received.			16 sheets
FPATPD_S	Saddle transport remaining JAM	Transport operation is started after folding operation.	FSATPD does not turn OFF within the specified time.	(Paper length/ 2 – 26.2) [mm]	(Paper length/ 2 – 26.2) [mm]	(Paper length/ 2 – 26.2) x 2 [mm]
FPPD3_N	Saddle paper exit not- reached JAM	Thrusting operation is started.	FPPD3 does not turn ON within the specified time.	66.9 [mm]	66.9 [mm]	133.8 [mm]
FPPD3_S	Saddle paper exit remaining JAM	Transport operation is started after folding operation.	FPPD3 does not turn OFF within the specified time.	(Paper length/ 2 – 26.2) [mm]	(Paper length/ 2 – 26.2) [mm]	(Paper length/ 2 – 26.2) x 2 [mm]
FSSMJ	Stapler shift motor JAM	Driving the stapler shift motor is started.	Change from FSSHPS ON to OFF is not detected within the specified time during the stapler shift operation.	1434 [msec]	1434 [msec]	2868 [msec]
			Change from FSSHPS OFF to ON is not detected within the specified time during the stapler shift operation.	2085 [msec]	2085 [msec]	4170 [msec]
			Change from FSSSHPS ON to OFF is not detected within the specified time during the stapler shift operation.	401 [msec]	401 [msec]	802 [msec]
			Change from FSSSHPS OFF to ON is not detected within the specified time during the stapler shift operation.	3179 [msec]	3179 [msec]	6358 [msec]
			Change from FSSSW2 ON to OFF is not detected within the specified time during the stapler shift operation.	138 - 503 [msec]	138 - 503 [msec]	276 - 1006 [msec]
			Change from FSSSW2 OFF to ON is not detected within the specified time during the stapler shift operation.	291 - 803 [msec]	291 - 803 [msec]	582 - 1606 [msec]
FDRLMJ	Paper exit roller lift motor JAM	Driving the finisher paper exit roller lift motor is started.	Change from FDRHS ON to OFF is not detected within the specified time during the paper exit roller lift operation.	176 [msec]	176 [msec]	352 [msec]
50000			Change from FDRHS OFF to ON is not detected within the specified time during the paper exit roller lift operation.	235 [msec]	235 [msec]	470 [msec]
FGMJ	Gripper motor JAM	Driving the gripper motor is started.	Change from FGHPS ON to OFF is not detected within the specified	187 [msec]	187 [msec]	374 [msec]
			Change from FGHPS OFF to ON is not detected within the specified time during the gripper operation.	535 [msec]	535 [msec]	1070 [msec]
FSPTMJ	Saddle paper transport motor JAM	Driving the saddle paper transport motor is started.	Change from FSRHS ON to OFF is not detected within the specified time during the paper transport roller lift operation in the saddle section.	37 [msec]	37 [msec]	74 [msec]
			Change from FSRHS OFF to ON is not detected within the specified time during the paper transport roller lift operation in the saddle section.	24 [msec]	24 [msec]	48 [msec]

# (5) Inner finisher

JAM code		JAM	detection method	Pasia distance	JAM margin distance (B) [mm]	JAM detection
	JAM content	JAM detection start trigger	JAM judgment condition	(A) [mm]		distance (A+B) [mm]
FPPD1_N	Finisher inlet port not-reached JAM	Machine paper exit command reception	FPPD1 does not turn ON within the specified time.	134.602 [mm]	400 [mm]	534.602 [mm]
FPPD1_S	Finisher inlet port remaining JAM (When Long-size paper support OFF)	FPPD1 ON	FPPD1 does not turn OFF within the specified time.	464.803 [mm]	50 [mm]	514.803 [mm]
	Finisher inlet port remaining JAM (When Long-size paper support ON)	FPPD1 ON	FPPD1 does not turn OFF within the specified time.	1207.803 [mm]	50 [mm]	1257.803 [mm]
FPDD_S	Bundle exit remaining JAM	Driving the bundle exit roller is started.	FSTPD does not turn OFF within the specified time.	133.1 [mm]	13.66 [mm]	146.76 [mm]
FIN_TIME	Finisher paper early reaching JAM	FPPD1 ON by the prior paper detection	FPPD1 of the next paper turns ON at the timing earlier than the specified paper interval.	Specified paper interval time	30 [mm]	(Paper interval time) - (Paper transport time of 30 [mm]) [msec]
FSTPD_S	Finisher paper exit remaining JAM	Driving the paper exit roller in the straight mode is started.	FSTPD does not turn OFF within the specified time.	96.76 [mm]	50 [mm]	146.76 [mm]
FSTPLJ	Staple JAM	FSHPS OFF after FSM ON	FSHPS does not turn ON within the specified time.	350 [msec]	250 [msec]	600 [msec]

# 3. Image send communication report code

### A. Outline and code system descriptions

After completion of communication, the communication report table, the communication management table, and the protocol are described on the communication report column.

The communication report code is composed as follows:

Communication report: XX (XXXX)

The upper 2 digits of the communication report code:

Communication report code of 00 - 99 (Refer to communication report main code.)

The lower 4 digits of the communication report code: Used by the serviceman.

The upper 2 digits: Communication report sub code 1 (Refer to communication report sub code 1.)

The lower 2 digits: Communication report sub code 2 (Refer to communication report sub code 2.)

#### Important

The communication report sub code 1 and sub code 2 are in hexadecimal notation. (The others are in decimal notation.)

#### Important

The communication report sub code 1 is not used in the these models.

# **B.** Details

#### (1) Communication report main code

Report code	Final receive signal (Send side)	Final receive signal (Receive side)
0	Abnormal signal	Abnormal signal
1	NSF, DIS	(SID), (SUB), NSS, DCS
2	CFR	(PWD), (SEP), NSC, DTC
3	FTT	EOP
4	MCF	EOM
5	PIP, PIN	MPS
6	RTN, RTP	PRI-Q
7	No signal, DCN	DCN
8	PPR	PPS-EOP
9		PPS-EOM
10		PPS-MPS, PPS-NULL
11	RNR	RR
12	CTR	CTC
13	ERR	EOR-Q
14		PPS-PRI-Q
16	Abnormal signal	Abnormal signal
17	NSF, DIS	SID, SUB, NSS, DCS
18	CFR	PWD, SEP, NSC, DTC
19	FTT	PPS-EOP
20	MCF	PPS-EOM
21	PIP, PIN	PPS-MPS, PPS-NULL
22	RTN, RTP	PRI-Q
23	No signal, DCN	DCN
24	PPR	
25	RNR	RR
26	CTR	CTC
27	ERR	EOR-Q
28		PPS-PRI-Q
29	V.8 Phase-1	V.8 Phase-1
30	V.8 Phase-2	V.8 Phase-2
31	V.8 Phase-3	V.8 Phase-3

#### Important

For report codes 16 - 31, V.34 MODE COMMUNICATION.

Report code (Communication result)	Display in the column of result	Content of communication interruption
0 – 31	Refer to "previous table".	Depends on the point of communication interruption. For 16 or later, V.34 mode communication.
33	BUSY	The calling side cannot establish connection with the remote party.
34	CANCEL	A communication interruption command is made during sending/receiving. The interruption key is pressed for interruption of input. <send board="" bulletin="" polling="" receive=""></send>
35	NG35 XXXX	Power is failed during sending/receiving. <send board="" bulletin="" polling="" receive=""></send>
36	(No record paper)	
37	(Record paper jam)	
38	MEM. FULL	Memory over during reception. <receive polling=""> Print is not made during reception in acting reception inhibit. <receive polling=""></receive></receive>
39	(Number of paper unmatched)	
40	(Relay not received)	
41	LENGTH OVER	The send data length of one page exceeds the limit (2m) in sending. <send board="" bulletin=""></send>
42	LENGTH OVER	The receive data length of one page exceeds the limit. <receive polling=""></receive>
43	(Communication) (OK)	Speaking before data transmission
44	ORIGINAL ERROR	A document jam occurs in direct sending. <send></send>
45	(Picture quality error)	
46	NO RESPONSE	The FAX signal from the remote party is not detected within T1 time. <send polling=""> (When in recall, however, the recall setting in case of a communication error is valid.)</send>
47	TX DECODE ERROR	A decode error occurs in the FAX board. <send board="" bulletin=""></send>
48	ОК	Normal end of communication
	OK REPLY RECEIVE	OK in Internet FAX send with reception confirmation.
49	NO RX POLL	The called side does not have polling function in polling reception. <polling> The called side has no data to send. <polling></polling></polling>
50	RX POLL FAIL	In polling reception, DCN is received for DTC. <polling> In polling sending, there is no send data. <bulletin board=""></bulletin></polling>

Report code (Communication	Display in the column of result	Content of communication interruption
51	PASS # NG	In poling sending, the allow number is not matched. <bulletin board=""></bulletin>
52	(No confidential function in	In confidential sending, the remote party does not have confidential function. <send></send>
	remote party)	(Including other company's machines)
		<ul><li>2) The NSF is not a Sharp machine.</li></ul>
53	(Confidential not received)	1) In confidential sending, DCN is received for NSS. <send></send>
54	(Confidential BOX NO NG)	In confidential reception, a confidential box number which is not registered is specified.     In relay command sending, the remote machine has no relay function, <sends< td=""></sends<>
	remote party)	(Including other company's machine)
		<ol> <li>The NSF signal has not "Confidential function" bit.</li> <li>The NSE is not a Sharp machine</li> </ol>
56	NO REL RX	<ol> <li>In relay command sending, DCN is received for NSS. <send></send></li> </ol>
		<ol> <li>In relay command reception, a remote station number which is not registered is specified. <receive></receive></li> <li>In F and relay broadcasting an E code relay command is received </li> </ol>
57	(Relay ID unmatched)	<ul> <li>In relay command reception, the relay ID does not match. <receive></receive></li> </ul>
58	REJECTED	In reception, data are sent from a remote machine of receive inhibit number. <receive></receive>
59	RX NO E-CODE POLL	(Not rejected in the bulletin board send or the F code bulletin board send.)
		In F code polling (calling), the called side has no send data. (DIS bit 9 is 0.) <polling></polling>
60	NO F-CODE POLL	In F code polling (calling), DCN is received for SEP. <polling></polling>
61	RX POLL # NG	In bulletin board, the sub address (bulletin board number (SEP)) is not matched. <bulletin board=""></bulletin>
62	F POLL PASS # NG	In bulleting board, the pass code (PWD) is not matched. <bulletin board=""></bulletin>
63	NO F FUNC	In F code sending, the remote machine has no DIS bit 49 (sub address function). <send></send>
64	NO F-CODE	In F code sending : <send></send>
		1) DCN is received for SUB Check the box number.
		2) DCN is received for SID Check the box number and pass code.
		In F code receiving : <receive></receive>
67	E PASS # NG	"F code relay broadcasting" or "F code confidential reception" is "Inhibited with soft SW."
68	BOX NO. NG	In F code reception, a box number which is not registered is specified. (SUB is not matched.) <receive></receive>
69	MEMORY OVER	Memory over in quick online sending <send></send>
70	(JOB MEMORY OVER)	In PC-FAX reservation, the number of remote parties is exceeded. <send></send>
71	NG71 XXXX *1	In PC-FAX reservation, data sent from PC includes some errors. <send></send>
12		<ul> <li>In reservation from PC-FAX or PC-Internet FAX, a department number which is not registered on the</li> </ul>
		machine side is specified. <send></send>
73	NG73 XXXX *1	<ul> <li>In reservation from PC-FAX or PC-Internet FAX, the department number is not specified. <send></send></li> <li>In reservation from PC-FAX or PC-Internet FAX, the use quantity limit is exceeded. <send></send></li> </ul>
74	NG74 XXXX *1	When reserving specified filing in document filing in PC-FAX or PC-Internet FAX;
		The pass-code for the folder is set on the machine side and the pass-code from PC-XXX does not match     with it a souther than the pass-code for the folder is set on the machine side and the pass-code form PC-XXX does not match
		<ul> <li>The pass-code for the folder is set on the machine side and no pass-code is specified by PC-XXX. <send></send></li> </ul>
75	NG75 XXXX *1	Reservation cannot be made due to machine busy. (Reservation of PC-FAX cannot be accepted.)
76	NG76 XXXX *1	When "PC-FAX or PC-Internet FAX send inhibit" is set on the machine side. Reserved with receive confirmation request in PC-Internet FAX, but the Internet FAX sender is not registered.
		on the machine side. <send></send>
77	NG77 XXXX *1	In reserving specified filing in PC-FAX or PC-Internet FAX, the machine has no filing function.
78		Ine filing function is inhibited on the machine side when filing specification is reserved by PC-FAX or PC- Internet FAX.
79	NG79 XXXX *1	An authentication error occurs when PC-FAX or PC-Internet FAX is reserved.
80	NG80 XXXX *1	NIC connect failure (network abnormality)
		<ul> <li>A network trouble (CE-XX) occurs.</li> </ul>
		The port is set to DISABLE.
		<ul> <li>Autoentication of the POP server is failed when POP before SMTP is enabled.</li> <li>When an error other than the communication result code 93 or 94 in D-SMTP send (including error</li> </ul>
		response of 5XX)
81	NG REPORT	In Internet FAX send, reply of receive confirmation of the remote machine is not normal. (Including PC-Internet
		Error of the disposition-modifier.
		• The disposition modifier is not in an error, and the disposition type is other than displayed, dispatched, or
82	NO REPORT	In Internet FAX send, time-out occurs in waiting for receive confirmation from the remote machine. (Including
		PC-Internet FAX).
		<ul> <li>In a case where send confirmation wait time-out time is other than 0, when send confirmation reply from an Internet FAX destination is not received.</li> </ul>
		Recalls of the set number of recalls are performed, but send confirmation reply from an internet FAX
83		destination is not received. In E-mail/ETP Internet FAX send, the send data size exceeds the upper limit of send data
50		$\dots = \dots =$

Report code (Communication result)	Display in the column of result	Content of communication interruption
84	REJECTED	In e-mail receive, a sender is registered in receive reject address/domain. <receive></receive>
85	NG85 XXXX *1	In e-mail receive, an error occurs in communication with POP3 server.
		Header acquisition error.
		Time-out during mail receive
86	RECEIVED	In e-mail receive, an unsupported attached file is received.
		Only the TIFF-F type is supported for attached files.
		The TIFF-F type of the attached file cannot be recognized.
		There is no attached file.
87	NG87 XXXX *1	In e-mail receive, an attached file cannot be stored in memory.
		Memory over
88	NG88 XXXX *1	In SMTP e-mail receive, an attached file cannot be stored in memory.
		Cannot be stored in memory.
		The number of items of acting receive data is the maximum, and an additional data cannot be stored.
89	NG89 XXXX *1	In SMTP e-mail receive, an error occurs in communication with the mail server.
		Time-out occurs during e-mail receive.
90	NG90 XXXX *1	After reservation by re-operation of document filing, conversion for image send cannot be made.
91	NG91 XXXX ^{*1 *2}	Data cannot be written to the memory device when Scan To USB is executed.
		The memory device is disconnected during writing to the memory device.
		An error occurs due to a memory device trouble.
92	NG92 XXXX *1 *2	The USB device memory overflows during writing data into the memory device when "Scan to USB" is
		executed.
93	NG93 XXXX *1	When error in D-SMTP send (with recall)
		An error response of 4XX occurs during communication with the SMTP server.
		Time out occurs after establishment of connection with the SMTP server.
94	NG94 XXXX ^{*1}	When busy in D-SMTP send
		Time out occurs during establishment of connection with the SMTP server.
95	NG95 XXXX ^{*1}	When the path is too long in execution of Scan To USB.
96	NG96 XXXX ^{*1}	When the normal process is not executed in the secure mail sending.
98	NG98 XXXX *1	The copy inhibit pattern is detected when scanning a document.
99	NG99 XXXX *1	A document which is inhibited to be copied such as a banknote is scanned.

*1: For a job status result in "Display in the column of result," "NG  $\triangle \triangle$  XXXX" is displayed. " $\triangle \triangle$ " is the code number.

For a communication result, "Communication error  $\triangle \triangle$  (XXXX)" is displayed.

*2: The error code of Scan To USB is specified only in the job log.

• When the communication result is OK, the communication sub code 1 and the communication sub code 2 are "0000."

• Errors in ( ) are not used.

#### (2) Communication report sub code 1

The communication report sub code 1 (upper 2 digits) are always indicated as "00."

### (3) Communication report sub code 2

Report code 2	Content of communication interruption	Send/Receive
00	When the conditions after 01 do not apply.	Send/Receive
01	Send length over	Send
02	EOL time up	Receive
03	Carrier detection time up	Receive
04	Time up of the communication start command from the machine side	Receive
05	Time up in phase C (8 min)	Send
06	Memory image decode error	Receive
07	Memory image decode error	Send
08	Time up between frames in phase C (Report code is 0 or 16.)	Send/Receive
09	Not used	_
10	Not used	_
11	Polarity reversion detection	Receive
12	Invalid command reception	Receive
13	Time up (1-minute timer/6-second time)	Receive
14	PUT error	Receive
15	In V.34 mode, time up is generated when shifting from Primary to Control.	Receive
16	In V.34 mode, time up is generated when shifting from Control to Primary.	Receive
17	Command receive time-up from MFP controller	Receive
18	Not used	_
19	Not used	_
20	Polarity reversion detection	Send
21	Invalid command reception	Send
22	Fallback retry number over	Send
23	Command retry number resend over	Send
24	Time up (T5 timer)	Send
25	Time up (T5 timer) in V.34 mode	Send
26	In V.34 mode, time up is generated when shifting from Primary to Control.	Send

Report code 2	Content of communication interruption	Send/Receive
27	In V.34 mode, time up is generated when shifting from Control to Primary.	Send
28	When sending the FSK signal, no response of send completion is sent back from the MODEM chip within a certain time. (V.34, other than V.34)	Send
29	Not used	—
30	A communication error is generated between MFP controller and Modem controller. (Report code is 0 or 16.)	—
31	DC current not detected (busy)	Send
32	Dial tone not detected (busy)	Send
33	Busy tone detection (busy)	Send
34	T0 time up (Remote machine not responding)	Send
35	T1 time up (Remote machine not responding)	Send
36	In dialing, polarity reversion detection (Remote machine not responding)	Send
37	Calling is not made (busy) <collision (including="" cng="" detected="" detection)=""></collision>	Send
38	Not used	—
60	In resend of document filed data, an error occurs in decoding or coding.	Resend
61	In resend of document filed data, setting to inhibit resolution conversion is made. (The resolution after resend is set to be Enlarged.)	Resend
62	In resend of document filed data, rotation setting is made for data which cannot be rotated.	Resend
63	In resend of document filed data, data cannot be stored in HD after conversion of resolution for resend.	Resend
64	In resending data of document file, during conversion for resending, the number of IMS management pages exceeds the	Resend
	upper limit (999). (IT occurs in OSA Scan to FTP also, resulting in memory over.)	OSAScanToFTP
70	E-mail header acquisition error	E-mail receive
71	Time out occurs during e-mail receive.	E-mail receive
72	Receive reject occurs during e-mail receive.	E-mail receive
73	Network communication cannot be made due to port disable.	Network send
74	An authentication of the POP server is failed when POP before SMTP is enabled.	Network send
75	In the setting of SSL communication, when SSL communication is tried but the server side does not support SSL.	Network send
76	There is no image in network communication (transfer).	Network send
80	There is no attached file in received e-mail.	E-mail receive
81	The attached file of received e-mail is not of TIFF type which is supported.	E-mail receive
82	The TIFF type of the attached file in received e-mail cannot be recognized. ID error	E-mail receive
83	The TIFF type of the attached file in received e-mail cannot be recognized. Endian error	E-mail receive
84	The TIFF type of the attached file in received e-mail cannot be recognized.	E-mail receive
85	The TIFF type of the attached file in received e-mail cannot be recognized.	E-mail receive
86	The TIFF type of the attached file in received e-mail cannot be recognized.	E-mail receive
87	The TIFF type of the attached file in received e-mail cannot be recognized.	E-mail receive
80	The TIFE type of the attached file in received e-mail cannot be recognized	E-mail receive
00	Data error	E-mail receive
90	In e-mail receive, an attached file cannot be stored in memory.	E-mail receive
	Memory over.	
01	Carrinor be stored in memory.	
91	In e-mail receive, an allached file cannot be stored in memory.	E-mail receive
02	In SMTP e-mail receive an attached file cannot be stored in memory	E-mail receivo
JZ	Cannot be stored in memory.	

When the sub code 2 is "08" or "30" and the communication report is "OK," the report code is "00" or "16."

# 4. Dial tone

When shipping from the factory, the dial tone detection when sending is set to Enable (changed from OFF to ON). When installing this machine, be sure to check and confirm that the dial tone is properly detected and the auto dial sending is enabled.

Check to confirm that the continuous buzzer sound is heard when the on-hook key is pressed. (Press the on-hook key again to cancel the buzzer sound.)

If facsimile communication cannot be executed normally through the IP telephone line, try the general telephone line.

# [8] FIRMWARE UPDATE

# 1. Outline

### A. Cases where update is required

ROM update is required in the following cases:

- 1) When there is a necessity to upgrade the performance.
- When installing a new spare part ROM for repair to the machine.
- When installing a new spare parts PWB unit (with ROM) for repair to the machine.
- 4) When there is a trouble in the ROM program and it must be repaired.

### B. Notes for update

### (1) Relationship between each ROM and update

Before execution of ROM update, check combinations with ROM's installed in the other PWB's including options. Some combinations of each ROM's versions may cause malfunctions of the machine.

### C. Update procedures and kinds of firmware

There are following methods of update of the firmware.

- 1) Update method using SIM 49-1
- 2) Update method using FTP
- 3) Update method using the Web page
- 4) Update method using the CN update function (There are three methods.)

Normally, one of 1) - 3) is used to update the firmware.

When any one of 1) - 3) is interrupted by an error such as power-off during updating, etc., and when retries of these methods are failed, the method 4) is employed.

#### **Firmware types**

The firmware type can be displayed by SIM22-5.

Use SIM22-5 to check the firmware type.

# 2. Update procedure

# A. Update method using SIM 49-1

For the update, connect the media or USB memory to the USB port that exists in the main body, and select the firmware data in the media or USB memory by simulation screen in the main unit.



*1:

- Store the firmware data (xxx .sfu) to the media or USB memory beforehand.
- The media used for the update must have an enouch capacity for storing the firmware data.
- The USB memory equipped with the security (secure) function cannot be used.

#### Execution of the firmware by SIM49-01

- Insert the media or USB memory which stores the firmware into the main unit. (Be sure to use the USB I/F on the operation panel.)
- 2) Enter the SIM49-01.

Press the key of the file to be updated. The screen transfers to the update screen.



- * The number of key changes according to the number of the sfu file in the media or USB memory inserted.
- * If the media or USB memory was not inserted when entry to the SIM49-01 screen, "INSERT A USB MEMORY DEVICE CONTAINING MFP FIRMWARE [OK]" is displayed on the screen. Insert the media or USB memory and push the [OK] key to open the file. If the media have not been inserted and [OK] key is pushed, the next screen does not appear and the screen waits the entry. Conversely, if the media or USB memory is pulled out on the file list screen, the error is detected by the [FILE] key pressing, and the first screen appears.
- Current version number and the version number to be updated will be shown for each firmware respectively.

									C	0
TEST SINULATION	NO. 49-01								CLO	SE )
FIRMWARE UPDATE [	/usbbd:1/	/******	****/******	**** ]						
CONFIG	: CUI	RRENT	01000000	UPDATED :	ю	01010000				
ICU (MAIN)	: CUI	RRENT	01000000	UPDATED :	TO	01010000				
ICU (BOOTN)	: CUI	RRENT	09000000	UPDATED 3	10	01000000				
ICU (BOOTCN)	: CUI	RRENT	01010000	UPDATED 3	TO .	09000000				
ICU (SUB)	: CUI	RRENT	01000000	UPDATED 3	ΓO	01010000				
LANGUAGE	: CUI	RRENT	01000000	UPDATED 3	10	01010000				全
GRAPHIC	: CUI	RRENT	09000000	UPDATED 3	ю	01000000				_
SLIST	: CUI	RRENT	01010000	UPDATED 3	ΓO	09000000				Ŧ
PCL (BOOT)	: CUI	RRENT	01000000	UPDATED 3	10	01010000				
PCL (MAIN)	: CUI	RRENT	01000000	UPDATED 3	ΓO	01010000				
PCL (CONFIG)	: CUI	RRENT	01010000	UPDATED :	ю	09000000				
PCL (PROFILE)	: CUI	RRENT	01010000	UPDATED 3	10	09000000				
ALL	[	ARE YOU	SURE?	'ES 📔 🛛		NO	←	EXECUTE		1/3

#### 4) Press [ALL] key.

All the firmware programs are selected.

		© 0
TEST SIMULATION NO.	. 49-01	CLOSE
FIRMWARE UPDATE [ /us	sbbd:1/************************	
CONFIG :	CURRENT 01000000 UPDATED TO 01010000	
ICU (MAIN) ,	CURRENT 01000000 UPDATED TO 01010000	
ICU (BOOTM)	CURRENT 09000000 UPDATED TO 01000000	
ICU (BOOTCN) :	CURRENT 01010000 UPDATED TO 09000000	
ICU(SUB) ;	CURRENT 01000000 UPDATED TO 01010000	
LANGUAGE	CURRENT 01000000 UPDATED TO 01010000	
GRAPHIC .	CURRENT 09000000 UPDATED TO 01000000	
SLIST ;	CURRENT 01010000 UPDATED TO 09000000	
PCL (BOOT)	CURRENT 01000000 UPDATED TO 01010000	
PCL (MAIN)	CURRENT 01000000 UPDATED TO 01010000	
PCL (CONFIG) ;	CURRENT 01010000 UPDATED TO 09000000	
PCL (PROFILE) ;	CURRENT 01010000 UPDATED TO 09000000	
ALL	ARE YOU SURE? YES NO + E	XECUTE 1/3

- * Normally select all the firmwares and execute updating.
- * In this case, firmwares which do not exist on the machine side are ignored.

To update a certain firmware only, select the firmware with the firmware display key.

* If firmware's key is not selected, [EXECUTE] key is gray out and cannot be pressed.

5) Press [EXECUTE] key. "ARE YOU SURE? [YES] [NO]" becomes clear. Press [YES] key to start the update of selected firemware.

							q	2 (	5
TEST SIMULATION	NO, 4	9-01					[	CLOSE	D
FIRMWARE UPDATE [	/usbb	d:1/*****	*****/*****	***** ]					
CONFIG	1	CURRENT	01000000	UPDATED TO	01010000				
ICU (MAIN)	).	CURRENT	01000000	UPDATED TO	01010000				
ICU (BOOTM)		CURRENT	09000000	UPDATED TO	01000000				
ICU (BOOTCN)	].	CURRENT	01010000	UPDATED TO	09000000				
ICU (SUB)	].	CURRENT	01000000	UPDATED TO	01010000				
LANGUAGE	Į.	CURRENT	01000000	UPDATED TO	01010000			1	٦Ì
GRAPHIC	J.	CURRENT	09000000	UPDATED TO	01000000				
SLIST	Į.	CURRENT	01010000	UPDATED TO	09000000			6	L
PCL (B00T)	Į.	CURRENT	01000000	UPDATED TO	01010000				
PCL (MAIN)	Į.	CURRENT	01000000	UPDATED TO	01010000				
PCL (CONFIG)	Į.	CURRENT	01010000	UPDATED TO	09000000				
PCL (PROFILE)	J .	CURRENT	01010000	UPDATED TO	09000000				
ALL		ARE YO	U SURE?	YES	NO	- 🗕 🛛	EXECUTE		1/3

The progress is displayed on right side of "FIRMWARE UPDATE" title by 20 steps.

	Ð	0
TEST SIMULATION NO. 49-01	CLO	SE
FIRMWARE UPDATE		_
S***** E		
REMAINS FOR ** MINUTES.		
CAUTION DO NOT POWER OFF THE MFP! FIRMWARE UPDATE IN PROGRESS!		

At this time, only the progress gauge is displayed on the screen, and the version and the firmware selection key are not displayed.

 If the update is normal completion, following screen is displayed.

	<b>©</b> 0
TEST SIMULATION NO. 49-01	CLOSE
FIRMWARE UPDATE	
COMPLETE: PLEASE TOUCH [OK] TO FINISH.	
	OK

Press [OK] key. (The machine is rebooted.)

Go to SIM22-05 and confirm the firmware has upgraded successfully.

 If the update is not normal completion, following screen is displayed.

	C	0
TEST SIMULATION NO. 49-01		CLOSE
FIRMWARE UPDATE		
ERROR :PLEASE TOUCH [OK] TO FINISH. ICUM, PCUM, SCUB		
		OK

## B. Firmware update using FTP

FTP software is used to transfer the firmware data (extension ".sfu") from the PC to the machine. The controller recognizes the firmware identifier and the machine automatically switches to firmware write mode. After the firmware is updated, the machine automatically resets.



### C. Firmware update using the Web page

An Web browser (service technician's Web page) is used to update the firmware.

- Start the Web browser on a PC and enter the specified URL. A special firmware upgrade page appears.
- 2) Click the "Update of Firmware" key in the Web page. Click the [Browse] key and select the firmware for the update.



 After selecting the file, click the [Submit] key to send the firmware to the machine. Update processing begins. While processing takes place, "Firmware Update, now processing..." appears.

Update of Firmware	
Firmmare Update, now processing	
	]

4) When the firmware update is finished, "Firmware Update completed. Please reboot the MFP." appears. Pressing the [Reboot] key, the machine will restart to complete the update. The browser will shift to the following screen.

Update of Firmware	
Close the browser and open again to display latest information.	

"Close the browser and open again to display latest information." will be displayed.

5) Check the firmware version of machine again.

# D. Firmware update using the CN update function (There are three methods.)

### (1) Outline

The update method using the DIP SW of the MFP  $\ensuremath{\mathsf{PWB}}$  is called the CN update.

#### a. Function

There are the following three functions in the CN update mode.

• Firmware update function

This function is used to update the firmware by transferring data from the PC which is connected to the MFP PWB, the SCU PWB, the PCU PWB, the FAX PWB, and various options by means of a USB memory or USB cable.

This is basically the same as SIM49-01, but differs in the following points:

When the power is shut down or an abnormality occurs in a section other than the boot program for some reasons during firmware update operation of other method than the CN update, this method can be used to update the firmware.

If, however, an abnormality occurs in the boot program, the SD card and CompactFlash must be replaced with a new one having the normal boot program.

If the boot animation is not displayed, there is an abnormality in the boot program.

If the boot animation is displayed but "Copying is enabled" is not displayed on the copier basic menu, there is an abnormality in the main program.

Firmware version check function

(The method to check the firmware version by using SIM22-5 is easier than this method. Therefore, it is not described in this manual.)

### b. Purpose

This function is used in the following cases:

- When an error occurs during firmware update operation other than the CN update.
- When the power is shut down or an error occurs in a section other than the boot program for some reasons during firmware update operation of other method than the CN update, this method can be used to update the firmware.

If an error occurs in the boot program, this method cannot be used. In such a case, the SD card and CompactFlash must be replaced with a new one having the normal boot program.

#### c. DIP-SW used in the CN update mode

To enter the CN update mode, turn ON the UPDATE DIP-SW on the MFP PWB and boot the machine.

When terminating the CN update mode, reset UPDATE DIP-SW to OFF (normal mode).



#### d. Keys used in the CN update mode

The following two keys are used for operations in the CN update mode. Be careful that the functions of the keys differ those in the normal mode.



[DOWN] [MENU] [OK]

Key name	Functions in the CN update mode
[OK] key	Executes the selected function or item.
[MENU] key	Selects a menu.
[BACK] key	Selects a menu.
	(Serves as a cancel key in the execution check screen.)
[UP] key	Selects an item.
[DOWN] key	Selects an item.

#### (2) Operating procedures

#### a. Firmware update function

This function is used to revise the firmware by using the USB memory for the MFP PWB, the SCU PWB, the PCU PWB, the FAX PWB, and each option.

It is basically same as SIM 49-01, but differs in the following points.

- · The update target ROM is automatically selected.
- When the power is shut down or an abnormality occurs in a section other than the boot program for some reasons during firmware update operation of other method than the CN update.

If, however, an abnormality occurs in the boot program, this method cannot be used. On that case, the SD card and CompactFlash must be replaced with a new one having the normal boot program. When the boot animation is displayed but "Copying is enabled" is not displayed on the copier basic menu, there is an abnormality in

#### a-1. Necessary items

- 1) Insert the SD card and CompactFlash to the MFP PWB of the machine.
- 2) USB memory with the firmware file (SFU) saved in it.
- NOTE: Save the firmware file in the main directory or in a one-level lower directory.

#### a-2. Procedures

- 1) Turn OFF the power, and remove the cabinet and the MFP PWB cover.
- 2) Turn ON the DIP SW of the MFP PWB UP DATE.
- Install the USB memory into the USB port.
   USB memory installing position

the main program (SD card or CompactFlash).



4) Turn ON the power.

 Check to confirm that the machine starts booting. (It takes more than ten seconds to display the menu.)
 Display when booting is completed



Display when booting is completed

6) Select the firmware update mode.

Select the update mode with [MENU] key and [BACK] key. Display of the firmware update mode

# Firm Update From USB Memory

Display of the firmware update mode

7) Press [OK] key.

The firmware file saved in the USB memory is retrieved, and the file selection menu is displayed.

Display of file selection

# Firm Update > F 0100xx00.sfu

Display of file selection

Select the firmware file (SFU).

Select the target firmware file (SFU) with [UP] key and [DOWN] key.

When [OK] key is pressed with a directory name (the head: "> D") displayed, the menu goes to the one-stage lower directory. When [BACK] key is pressed in the lower-stage directory, the menu returns to the original upper directory.

9) Press [OK] key.

8)

The selected firmware file (SFU) is read. It takes about one minute.

Display of file reading



Display of file reading

10) After completion of reading, the firmware update process is continued.

Display of the firmware update process

Firm Update IcuM Writing Data

Display of the firmware update process

- * The abbreviated name of the firmware which is under update process is indicated on the right upper corner of the display.
- * During the update process, the display may flash instantaneously. It is a normal operation.

11) Check the update result.

Use [UP] key and [DOWN] key to display the results of all the firmware programs.

#### Display of the firmware update result

Firm Update	lcuM	Firm Update IcuM	Firm Update IcuM
Result : OK		Result : Not Update	Result : NG
	<u> </u>	<i></i>	

- Display of the firmware update result - OK: Update is completed successfully.
- NG: Update is failed.
- Not Update: Update is not executed.
- 12) Turn OFF the power.
- 13) Turn OFF the DIP SW of the MFP PWB UP DATE. (Set the DIP-SW to the normal mode.)
- 14) Turn ON the power, and check to confirm that the machine boots up normally.

Check to confirm that the boot animation is displayed.

Check to confirm that "Copying is enabled" is displayed on the copier basic menu.

- 15) Check to confirm the version of each firmware with SIM22-5.
- 16) Attach the MFP PWB cover and the cabinet.

# [9] MAINTENANCE

# 1. Works necessary when executing the maintenance

## A. Counter check

Before execution of the maintenance, execute SIM22 to check the counter values of the following counters to confirm consuming states of each section.

- 1) Each consumable part counter
- 2) Each unit counter
- 3) Trouble counter, JAM counter

### **B.** Counter reset

When a part or consumable part is replaced with new one in the maintenance, execute SIM24 to reset the following counters.

- 1) Maintenance counter
- 2) Each consumable part counter
- 3) Each unit counter
- 4) Trouble counter, JAM counter

## C. Firmware version check and upgrading

Execute SIM22-5 to check the firmware version, and upgrade it as needed. (SIM49-1)  $\,$ 

# D. Confirmation, adjustment

After completion of part replacement and cleaning, etc, execute the following procedures.

### Items necessary to execute

		ltem		SIM to be used
ADJ 5	Print engine image distortion adjustment /	ADJ5A	Print engine image distortion adjustment (Manual adjustment) /	50-22
	OPC drum phase adjustment /		OPC drum phase adjustment (Automatic adjustment) /	
	Color registration adjustment		Color registration adjustment (Automatic adjustment)	
	(Print engine section)			
ADJ10/SET1	Image quality adjustment		Copy image quality adjustment	
			Printer image quality adjustment	
		ADJ10B	Printer, copy color balance, density adjustments (Automatic adjustments) (Basic adjustments)	46-74

#### Items to execute as needed

		ltem		SIM to be used
ADJ 2	High voltage adjustment	ADJ2A	Main charger grid voltage adjustments	8-2
		ADJ2B	Developing bias voltage adjustments	8-1
		ADJ2C	Transfer current/voltage adjustment	8-6
ADJ4	Image lead edge position, image loss, void area, image off-center, image magnification	ADJ4A	Print image main scanning direction automatic magnification ratio adjustment (Print engine)	50-28
	ratio adjustments (Automatic adjustments)	ADJ4B	Print image off-center automatic adjustment (Print engine) (Each paper feed tray)	50-28
		ADJ4C	Copy mode image lead edge position, image loss, void area, image off-center, sub scanning direction image magnification ratio automatic adjustment (Scanner) (Document table mode)	50-28
		ADJ4D	Copy mode image lead edge position, image loss, void area, image off-center, sub scanning direction image magnification ratio automatic adjustment (Scanner) (RSPF mode)	50-28
ADJ10/SET1	Image quality adjustment	ADJ10A	Scanner calibration (CCD calibration)	63-3 (63-5)

# 2. Display of maintenance execution timing

The message of maintenance execution timing is displayed when each counter reaches the set value. The relations between the messages and the counters are shown below.

## A. Maintenance counter

	Display condition									
Display content	SIM26-38-A set value	Counter name	Counter value	Enable/ Disable						
Maintenance required. Code: TA	0 (Print continue)	Maintenance counter (Total)	When the SIM21-1 set value is reached.	Enable						
	1 (Print stop)		When 90% of the SIM21-1 set value is reached.							
Maintenance required. Code: TA	1 (Print stop)		When the SIM21-1 set value is reached.	Disable						
Maintenance required. Code: CA	0 (Print continue)	Maintenance counter (Color)	When the SIM21-1 set value is reached.	Enable						
	1 (Print stop)		When 90% of the SIM21-1 set value is reached.							
Maintenance required. Code: CA	1 (Print stop)		When the SIM21-1 set value is reached.	Disable						
Maintenance required. Code: AA	0 (Print continue)	Both of total and color	When the SIM21-1 set value is reached.	Enable						
	1 (Print stop)		When 90% of the SIM21-1 set value is reached.							
Maintenance required. Code: AA	1 (Print stop)		When the SIM21-1 set value is reached.	Disable						

* After execution of maintenance, be sure to execute SIM24-4 to clear the maintenance counter (Total) and the maintenance counter (Color).

## B. Primary transfer unit

	Display condition								
Display content	SIM26-38-A set value	Counter name	Counter value	Enable/ Disable					
Maintenance required .: TK1	0 (Print continue)	Primary transfer unit print counter	26/31 cpm : When 200K is reached.	Enable					
	1 (Print stop)		36 cpm : When 240K is reached.						

* After execution of the maintenance, execute SIM24-4 to clear the primary transfer unit print counter, the accumulated number of rotations counter, and the use day counter.

## C. Secondary transfer unit

	Display condition								
Display content	SIM26-38-A	Counter name	Counter value	Enable/					
	set value			Disable					
Maintenance required.: TK2	0 (Print continue)	Secondary transfer unit print counter	26/31 cpm : When 300K is reached.	Enable					
	1 (Print stop)		36 cpm : When 360K is reached.						

* After execution of the maintenance, execute SIM24-4 to clear the secondary transfer print counter, the accumulated number of rotations counter, and the use day counter.

## D. Fusing unit

	Display condition									
Display content	SIM26-38-A set value	SIM26-38-B set value	Counter name	Counter value	Enable/ Disable					
Maintenance required.: FK1	0 (Print continue)	-	Fusing belt print counter	26/31 cpm : When 200K is reached.	Enable					
	1 (Print stop)	-		36 cpm : When 240K is reached.						
Maintenance required.: FK2	0 (Print continue)	-	Pressure roller print counter	26/31 cpm : When 200K is reached.	Enable					
	1 (Print stop)	-		36 cpm : When 240K is reached.						
Maintenance required.: FK3	-	0 (Print continue)	Fusing web print counter	When 200K is reached.	Enable					
	-	1 (Print stop)								
Maintenance required.: FK3 (Pop-up)	-	0 (Print continue)	Fusing web print counter	When Web end detection is ON.	Enable					
	-	1 (Print stop)			Disable					

* After execution of the maintenance, execute SIM24-4 to clear the fusing roller counter, the fusing belt counter, the fusing web print counter, the accumulated rotation number counter, and the use day counter.

# E. OPC drum

	Display condition									
Display content	SIM26-38-A set value	Counter name	Counter value	Enable/Disable						
Maintenance required.: DK	0 (Print continue) 1 (Print stop)	OPC drum print counter (K) or OPC drum accumulated rotation number counter (K)	When 840K rotation is reached 26cpm machine : When 140K is reached. 31cpm machine : When 155K is reached 36cpm machine when 170K is reached.	Enable						
Maintenance required.: D (C/M/Y)	0 (Print continue) 1 (Print stop)	OPC drum print counter (C/M/Y) or OPC drum accumulated rotation number counter (C/M/Y)	When 840K rotation is reached 26/31/36cpm machine : When 140K is reached.							

* After execution of the maintenance, execute SIM24-4 to clear the OPC drum print counter, the accumulated number of rotations counter, and the use day counter.

## F. Developer

	Display condition									
Display content	SIM26-38-A set value	Counter name	Counter value	Enable/Disable						
Maintenance required.: DK	0 (Print continue) 1 (Print stop)	OPC drum print counter (K) or OPC drum accumulated rotation number counter (K)	When 840K rotation is reached 26cpm machine : When 140K is reached. 31cpm machine : When 155K is reached 36cpm machine when 170K is reached.	Enable						
Maintenance required.: D (C/M/Y)	0 (Print continue) 1 (Print stop)	OPC drum print counter (C/M/Y) or OPC drum accumulated rotation number counter (C/M/Y)	When 840K rotation is reached 26/31/36cpm machine : When 140K is reached.							

* After execution of the maintenance, execute SIM24-4 to clear the developer print counter, the accumulated number of rotations counter, and the use day counter.

### G. Waste toner box

Display content	Display o	Print JOB					
Display content	Counter name	Counter value	Enable/Disable				
Check the waste toner box.	After detection of near end, pixel cour	After detection of near end, pixel count 104K					
	(equivalent to color 1K, monochrome	4K print)	End: Disable				

* When the waste toner box is replaced with an empty one, the message disappears.

# H. Toner

		Display condition		Brint IOP
Display content	SIM26-38-A set value	Counter name	Counter value	Enable/Disable
(K/C/M/Y) Prepare a toner (Near near end)	No relation	Toner motor rotation time	Specified time of rotations	Enable
(K/C/M/Y) Toner supply is low (Near end)	No relation	Toner supply amount is decreasing.	ATC sensor output variation	Enable
Replace the toner cartridge. (K) (End)	0 (Print continue) 1 (Print stop)	The pixel count from near end reaches the specified value.	Specified pixel count	(Disable for a JOB which requires K toner)
Replace the toner cartridge. (C/M/Y) (End)	0 (Print continue) 1 (Print stop)	The pixel count from near end reaches the specified value.	Specified pixel count	Enable for monochrome, Disable for color

# 3. Maintenance list

### Main unit

X: Check (Clean, replace, or adjust according to necessity.) O: Clean ▲: Replace △: Adjust ☆: Lubricate

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	840 K rotation	840 K rotation	840 K rotation	Remark
1	Developing	Developing unit	1	Developer	Х	<b></b>	<b></b>	<b></b>	maximum printed
	section	(monochrome)	2	DV seal/DV seal B	Х	Х	Х	Х	number 26cpm 140K
			3	DV side seals F/R	Х	Х	Х	Х	26cpm 140K
			4	Toner filter	Х	Х	Х	Х	36cpm 170K
			5	Bias pin	Х	Х	Х	Х	
			6	Connector	Х	Х	Х	Х	
		Developing unit	1	Developer	Х		<b></b>	<b></b>	maximum printable
		(color)	2	DV seal/DV seal B	Х	Х	Х	Х	number 140K
			3	DV side seals F/R	Х	Х	Х	Х	
			4	Toner filter	Х	Х	Х	Х	
			5	Bias pin	Х	Х	Х	Х	
			6	Connector	Х	Х	Х	Х	
2	OPC drum	OPC drum unit	1	Drum	Х	<b></b>		<b></b>	840K rotation or
	section	(monochrome)	2	MC unit	Х	<b></b>		<b></b>	an and an one of the st
			3	Cleaning blade	Х	<b></b>		<b></b>	number
			4	Toner reception blade	Х	х	Х	Х	26cpm 140K 31cpm 155K
			5	Side seals F/R	Х	х	Х	Х	36cpm 170K
			6	Charger cleaner	Х	<b></b>	<b></b>	<b></b>	
		OPC drum unit	1	Drum	Х			<b></b>	840K rotation or
		(color)	2	MC unit	Х	<b></b>	<b></b>	<b></b>	maximum printable
			3	Cleaning blade	Х	<b></b>	<b></b>	<b></b>	number 140K
			4	Toner reception blade	Х	х	Х	Х	
			5	Side seals F/R	Х	х	Х	Х	
			6	Charger cleaner	Х	▲			

### 26 cpm/31cpm machine

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
1	RSPF section	RSPF unit	1	Document pickup roller	0	0	-	0	0	0	-	0	0	Replace at 100K of the SPF paper feed counter
			2	Paper feed roller	0	0	-	0	0	0	-	0	0	or 1 year of use. When replacing the
	3 Separation O O - O O O roller	-	0	0	paper feed roller, apply grease to the paper feed shaft. GP-501MR									
			4	Torque limiter SPF	Х	х	-	х	Х	х	-	Х	Х	Replace at 400K of the SPF paper feed counter
			5	Take-up torque limiter	Х	Х	-	Х	Х	Х	-	Х	х	or 2 years of use.
			6	Discharge brush	Х	Х	-	Х	Х	Х	-	Х	Х	
			7	Registration roller	0	0	-	0	0	0	-	0	0	
			8	Transport roller 2	0	0	-	0	0	0	-	0	0	
			9	Transport roller 3	0	0	-	0	0	0	-	0	0	
			10	Paper exit roller	0	0	-	0	0	0	-	0	0	
			11	Sensors	Х	Х	-	Х	Х	Х	-	Х	Х	
			12	Scan plate	0	0	-	0	0	0	-	0	0	
			13	Gears	Х	Х	-	Х	Х	Х	-	Х	X	
			14	Belts	Х	Х	-	Х	Х	Х	-	Х	Х	
			15	OC mat	0	0	-	0	0	0	-	0	0	

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
2	Scanner	Scanner unit	1	Drive belt	Х	Х	-	Х	Х	Х	-	Х	Х	
	section		2	Drive wire	Х	Х	-	Х	Х	Х	-	Х	Х	
			3	Sensors	Х	Х	-	Х	Х	Х	-	Х	Х	
			4	Rails	☆	☆	-	☆	☆	☆	-	☆	☆	
			5	Mirror	0	0	-	0	0	0	-	0	0	
			6	Reflector	0	0	-	0	0	0	-	0	0	
			7	Scanner	0	0	-	0	0	0	-	0	0	
				lamp		_			_				_	
			8	Lens	0	0	-	0	0	0	-	0	0	
			9	CCD	0	0	-	0	0	0	-	0	0	
			10	Table glass	0	0	-	0	0	0	-	0	0	
-	<b>.</b> .	D :	11	SPF glass	0	0	-	0	0	0	-	0	0	<b>D</b>
3	section	Primary transfer unit	1	Separation pawl	-	X	-	X	X	X	-	X	X	Replace as needed.
			2	Primary transfer belt	-		-		•		-	•	•	When replacing, apply KYNAR powder.
			3	Secondary drive transmission gear	-	0	-	0	0	0	-	0	0	
			4	Primary transfer belt drive roller	-	0	-	0	0	0	-	0	0	
			5	Primary transfer belt follower roller	-	0	-	0	0	0	-	0	0	
			6	Primary transfer belt tension roller	-	0	-	0	0	0	-	0	0	
			7	Registration backup roller	-	0	-	0	0	0	-	0	0	
			8	Y auxiliary roller	-	0	-	0	0	0	-	0	0	
			9	PTC backup roller	-	0	-	0	0	0	-	0	0	
			10	Primary transfer roller	-	Х	-	Х	Х	Х	-	х	Х	Replace as needed.
			11	Transfer cleaner seals F/R	-	Х	-	Х	Х	Х	-	х	х	
			12	Primary transfer belt cleaner blade	-		-			•	-		•	
			13	Primary transfer toner reception blade	-	X	-	Х	Х	Х	-	X	Х	Replace as needed.
			14	Primary transfer operation mode detector	-	0	-	0	0	0	-	0	0	

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 К	1200 K	Remark
3	Transfer section	Secondary transfer unit	1	Secondary transfer belt follower roller	-	-	0	-	0	-	0	-	0	
			2	Secondary transfer belt	-	-		-	•	-		-	<b></b>	Never use alcohol or solvents for cleaning. Replace at every 300K.
			3	Secondary transfer belt drive roller	-	-	0	-	0	-	0	-	0	
			4	Secondary transfer backup roller	-	-	0	-	0	-	0	-	0	
			5	Secondary transfer belt tension roller	-	-	0	-	0	-	0	-	0	
			6	Secondary transfer roller	-	-	х	-	х	-	х	-	х	Replace as needed.
			7	Secondary transfer drive gear	-	-	Х	-	х	-	Х	-	Х	
			8	Separation cam	-	-		-	☆	-		-	☆	When replacing, apply HANARL FL-955R to
			9	Secondary transfer frame	-	-	☆	-	☆	-	☆	-	☆	the shaft section.
4	Other	Other	1	PTC unit	Х	•	-	<b></b>		<b></b>	-	<b></b>		Replace. Reciprocate the PTC cleaning rod back and forth 3 times.
			2	Image density sensor/ Registration sensor	Х	0	-	0	0	0	-	0	0	Remove dirt from the light emitting/receiving sections (transparent plastic sections) of the sensor (gray plastic section) with dry waste cloth. *1
5	LSU section	LSU	1	Dust-proof glass	0	0	-	0	0	0	-	0	0	Use the LSU cleaning rod.
		Other	2	Cleaning base	X	F	Replac	e ever	y time t repla	the wa aced.	ste tor	ner box	is	Attached to the waste toner box. (2 pcs.) / Replace when the waste toner box is replaced, or at 100K, or 2 years of use.
6	Manual paper feed	Manual paper feed unit	1	Paper feed roller	Х	0	-	0	0	0	-	0	0	Replace at 100K of the manual paper feed
	section		2	Separation roller	Х	0	-	0	0	0	-	0	0	counter or 1 year of use.
			3	Torque limiter	Х	Х	-	Х	X	Х	-	X	Х	
			4	Transport roller 9	X	0	-	0	0	0	-	0	0	
			5	Transport roller 10	X	0	-	0	0	0	-	0	0	
			-	Sensors Paper guides	х О	х О	-	0 0	0 X	0 0	-	0 X	<u>х</u> О	Clean with alcohol.

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 К	1000 К	1200 K	Remark
7	Tray paper	Tray paper	1	Paper pickup roller	х	0	-	0	0	0	-	0	0	Replace at 100K of the
			2	Paper feed roller	х	0	-	0	0	0	-	0	0	or 1 year of use.
			3	Separation roller	х	0	-	0	0	0	-	0	0	
			4	Transport roller 4	Х	0	-	0	0	0	-	0	0	
			5	Transport roller 2	х	0	-	0	0	0	-	0	0	
			6	Torque limiter	х	х	-	Х	х	х	-	Х	х	
			7	Sensors	Х	Х	-	Х	Х	Х	-	Х	Х	
			-	Paper quides	0	0	-	0	0	0	-	0	0	Clean with alcohol.
8	Paper registration	PS unit	1	Registration roller (idle)	х	0	-	0	0	0	-	0	0	
	section (paper		2	Registration roller (drive)	х	0	-	0	0	0	-	0	0	
	transport section)/		3	Transport roller 5	х	0	-	0	0	0	-	0	0	
	Paper exit		4	Sensors	Х	Х	-	Х	Х	Х	-	Х	Х	
	section/ADU section	Right door unit	5	Transport roller 7	х	0	-	0	0	0	-	0	0	
			6	Transport	х	0	-	0	0	0	-	0	0	
			7	Paper exit	х	0	-	0	0	0	-	0	0	
			8	Paper exit	х	0	-	0	0	0	-	0	0	
			9	Discharge	х	х	-	х	х	х	-	х	х	
			10	Sensors	Х	Х	-	Х	Х	Х	-	Х	Х	
		Fusing rear unit	11	Transport roller 6	х	0	-	0	0	0	-	0	0	
		Paper exit unit	12	Paper exit roller 1	х	0	-	0	0	0	-	0	0	
			13	Discharge brush	х	х	-	х	х	х	-	Х	Х	
			14	Sensors	-	Х	-	Х	Х	Х	-	Х	Х	
		Other	15	Paper dust removing unit	0	0	-	0	0	0	-	0	0	
			-	Paper guides	0	0	-	0	0	0	-	0	0	Clean with alcohol.
9	Drive section	Main drive unit Belt drive unit	1	Gears (grease)	х	х	-	х	х	х	-	Х	Х	Apply to the specified position when checking.
			2	Shafts (grease)	х	х	-	х	х	х	-	Х	Х	FLOIL G-313S
			3	Shaft earth sections (conduction grease)	х	х	-	х	X	x	-	х	X	Apply to the specified position when checking. FLOIL GE-676
			4	Belts	x	x	-	x	x	x	-	x	x	
			5	Sensors	Х	Х	-	Х	X	X	-	Х	X	
		Transport	6	Belts	Х	Х	-	Х	Х	Х	-	Х	Х	
		drive unit	7	Connection arm	Х	Х	-	Х	х	Х	-	х	х	Apply to the specified position when checking.
		Fusing drive unit	8	Shafts (grease)	Х	Х	-	Х	х	Х	-	Х	Х	HANARL FL-955R
		Paper exit drive unit	9	Shafts (grease)	Х	Х	-	Х	х	Х	-	Х	Х	
			10	Belts	Х	Х	-	Х	Х	Х	-	Х	Х	

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
10	Fusing section	Fusing unit	1	Lower separation pawl	X	Х	-	Х	Х	х	-	Х	Х	
			2	Lower separation pawl spring	Х	Х	-	Х	Х	Х	-	Х	Х	
			3	Separation plate	х	х	-	Х	Х	Х	-	Х	Х	
			4	Web guide shaft	х		-	<b></b>	•	•	-	<b></b>	<b></b>	
			5	Web pressure roller bearing	х	•	-	<b>A</b>	•	•	-			
			6	Web pressure roller	х		-	•	•	•	-	<b></b>	<b></b>	
			7	Web roller	Х		-				-			
			8	Lower thermistor	х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
			9	Pressure roller gear	х	х	-	Х	Х	Х	-	Х	Х	
			10	Pressure roller bearing	х	Х	-	х	х	х	-	Х	Х	
			11	Pressure roller	X		-				-			Apply grease to the shaft section when replacing. (JEF552) / After completion of replacement, clean the new pressure roller surface with alcohol. / Integrated with the fusing roller as a maintenance kit. Replace at every 200K.
			12	Sub thermistor	х	Х	-	Х	Х	х	-	Х	Х	Replace as needed.
			13	Fusing roller bearing	Х	Х	-	Х	Х	Х	-	Х	Х	
			14	Heat- insulating bush	X	Х	-	Х	X	Х	-	x	x	Replace as needed. / When replacing, apply grease to the inner ring section and the outer ring section. (JEF552)
			15	Heating roller bearing	х	х	-	х	х	х	-	Х	Х	Replace as needed.
			16	Fuser belt guide collar	Х		-				-			Integrated with the fusing belt as a maintenance kit. Replace at every 200K.
			17	Fusing roller	X		-				-			Apply grease to the shaft section when replacing. (JEF552) / Integrated with the pressure roller as a maintenance kit. Replace at every 200K.
			18	Heating roller	х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
			19	Fusing belt	Х	•	-	•	•	•	-			Integrated with the fuser belt guide collar as a maintenance kit. Replace at every 200K.
			20	Main thermistor	Х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
			21	Paper guides	0	0	-	0	0	0	-	0	0	
			22	Gears	Х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
			23	Pressure	Х	Х	-	х	Х	х	-	Х	Х	
			24	spring Washer	-	х	-	х	Х	х	-	Х	Х	

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
11	Other		1	Ozone filter	-	-		-		-		-		
			2	Toner cartridge BK		Use	r repla	cemen	t for ev	ery tor	ner em	pty.		
			3	Toner cartridge C										
			4	Toner cartridge M										
			5	Toner cartridge Y	<u>.</u>									
	6 Waste toner box					Repla	ced by	/ the u	ser whe	en full	is dete	cted.		Replacement reference: 50K

# 36cpm machine

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
1	RSPF	RSPF unit	1	Document	0	0	-	-	0	-	0	-	0	Replace at 100K of the
	section			pickup roller										SPF paper feed counter
			2	Paper feed roller	0	0	-	-	0	-	0	-	0	or 1 year of use. When replacing the
			3	Separation roller	0	0	-	-	0	-	0	-	0	paper feed roller, apply grease to the paper feed shaft. GP-501MR
			4	Torque limiter SPF	х	х	-	-	Х	-	х	-	х	Replace at 400K of the SPF paper feed counter
			5	Take-up torque limiter	Х	Х	-	-	х	-	Х	-	х	or 2 years of use.
			6	Discharge brush	х	Х	-	-	Х	-	Х	-	Х	
			7	Registration roller	0	0	-	-	0	-	0	-	0	
			8	Transport roller 2	0	0	-	-	0	-	0	-	0	
			9	Transport roller 3	0	0	-	-	0	-	0	-	0	
			10	Paper exit roller	0	0	-	-	0	-	0	-	0	
			11	Sensors	Х	Х	-	-	Х	-	Х	-	Х	
			12	Scan plate	0	0	-	-	0	-	0	-	0	
			13	Gears	Х	Х	-	-	Х	-	Х	-	Х	
			14	Belts	Х	Х	-	-	Х	-	Х	-	Х	
			15	OC mat	0	0	-	-	0	-	0	-	0	
2	Scanner	Scanner unit	1	Drive belt	Х	Х	-	-	Х	-	Х	-	Х	
	section		2	Drive wire	Х	Х	-	-	Х	-	Х	-	Х	
			3	Sensors	Х	Х	-	-	Х	-	Х	-	Х	
			4	Rails	☆	☆	-	-	☆	-	☆	-	☆	
			5	Mirror	0	0	-	-	0	-	0	-	0	
			6	Reflector	0	0	-	-	0	-	0	-	0	
			7	Scanner Iamp	0	0	-	-	0	-	0	-	0	
			8	Lens	0	0	-	-	0	-	0	-	0	
			9	CCD	0	0	-	-	0	-	0	-	0	
			10	Table glass	0	0	-	-	0	-	0	-	0	
			11	SPF glass	0	0	-	-	0	-	0	-	0	

Section/ Unit work	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
3	Transfer section	Primary transfer unit	1	Separation pawl	-	-	Х	-	-	Х	-	х	-	Replace as needed.
			2	Primary transfer belt	-	-	<b></b>	-	-	<b></b>	-	<b></b>	-	When replacing, apply KYNAR powder.
			3	Secondary drive transmission gear	-	-	0	-	-	0	-	0	-	
			4	Primary transfer belt drive roller	-	-	0	-	-	0	-	0	-	
			5	Primary transfer belt follower roller	-	-	0	-	-	0	-	0	-	
			6	Primary transfer belt tension roller	-	-	0	-	-	0	-	0	-	
			7	Registration backup roller	-	-	0	-	-	0	-	0	-	
			8	Y auxiliary roller	-	-	0	-	-	0	-	0	-	
			9	PTC backup roller	-	-	0	-	-	0	-	0	-	
			10	Primary transfer roller	-	-	Х	-	-	Х	-	х	-	Replace as needed.
			11	Transfer cleaner seals F/R	-	-	Х	-	-	Х	-	х	-	
			12	Primary transfer belt cleaner blade	-	-		-	-		-		-	
			13	Primary transfer toner reception blade	-	-	Х	-	-	Х	-	×	-	Replace as needed.
			14	Primary transfer operation mode detector	-	-	0	-	-	0	-	0	-	

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
3	Transfer section	Secondary transfer unit	1	Secondary transfer belt follower roller	-	-	-	0	-	-	-	0	-	
			2	Secondary transfer belt	-	-	-	•	-	-	-		-	Never use alcohol or solvents for cleaning. Replace at every 360
			3	Secondary transfer belt drive roller	-	-	-	0	-	-	-	0	-	
			4	Secondary transfer backup roller	-	-	-	0	-	-	-	0	-	
			5	Secondary transfer belt tension roller	-	-	-	0	-	-	-	0	-	
			6	Secondary transfer roller	-	-	-	х	-	-	-	х	-	Replace as needed.
			7	Secondary transfer drive gear	-	-	-	Х	-	-	-	х	-	
			8	Separation cam	-	-	-		-	-	-		-	When replacing, appl HANARL FL-955R to
			9	Secondary transfer frame	-	-	-		-	-	-		-	the shaft section.
4	Other	Other	1	PTC unit	Х	•	-	-	<b></b>	-	<b></b>	-	<b></b>	Replace. Reciprocate the PTC cleaning rod back and forth 3 time
			2	Image density sensor/ Registration sensor/ Standard reflection plate	x	0	-	-	0	-	0	-	0	Remove dirt from the light emitting/receiving sections (transparent plastic sections) of th sensor and the standa reflection plate (gray plastic section) with d waste cloth. *1
5	LSU section	LSU	1	Dust-proof glass	0	0	-	-	0	-	0	-	0	Use the LSU cleaning rod.
		Other	2	Cleaning base	X	F	Replac	e ever	y time trepl	the wa aced.	ste tor	ier box	is	Attached to the waste toner box. (2 pcs.) / Replace when the waste toner box is replaced, or at 100K, 2 years of use.
6	Manual paper feed	Manual paper feed unit	1	Paper feed roller	Х	0	-	-	0	-	0	-	0	Replace at 100K of th manual paper feed
	section		2	Separation roller	X	0	-	-	0	-	0	-	0	counter or 1 year of u
			3	Torque limiter	X	X	-	-	X	-	X	-	X	
			4	Transport roller 9	X	0	-	-	0	-	0	-	0	
			5	I ransport roller 10	X	0	-	-	0	-	0	-	0	
		1	b	Sensors	~	X	-	-	X		Ă	-	X	

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
7	Tray paper	Tray paper	1	Paper pickup roller	х	0	-	-	0	-	0	-	0	Replace at 100K of the
			2	Paper feed roller	х	0	-	-	0	-	0	-	0	or 1 year of use.
			3	Separation roller	х	0	-	-	0	-	0	-	0	
			4	Transport roller 4	Х	0	-	-	0	-	0	-	0	
			5	Transport roller 2	х	0	-	-	0	-	0	-	0	
			6	Torque limiter	х	Х	-	-	х	-	х	-	Х	
			7	Sensors	х	Х	-	-	Х	-	Х	-	Х	
			-	Paper quides	0	0	-	-	0	-	0	-	0	Clean with alcohol.
8	Paper registration	PS unit	1	Registration roller (idle)	х	0	-	-	0	-	0	-	0	
	section (paper		2	Registration roller (drive)	х	0	-	-	0	-	0	-	0	
	transport section)/		3	Transport roller 5	х	0	-	-	0	-	0	-	0	
	Paper exit		4	Sensors	Х	Х	-	-	Х	-	Х	-	Х	
	section/ADU section	Right door unit	5	Transport roller 7	х	0	-	-	0	-	0	-	0	
			6	Transport	х	0	-	-	0	-	0	-	0	
			7	Paper exit roller 3	х	0	-	-	0	-	0	-	0	
			8	Paper exit	х	0	-	-	0	-	0	-	0	
			9	Discharge	х	Х	-	-	х	-	х	-	х	
			10	Sensors	Х	Х	-	-	Х	-	Х	-	Х	
		Fusing rear unit	11	Transport roller 6	х	0	-	-	0	-	0	-	0	
		Paper exit unit	12	Paper exit roller 1	х	0	-	-	0	-	0	-	0	
			13	Discharge brush	х	Х	-	-	х	-	х	-	х	
			14	Sensors	-	Х	-	-	Х	-	Х	-	Х	
		Other	15	Paper dust removing unit	0	0	-	-	0	-	0	-	0	
			-	Paper guides	0	0	-	-	0	-	0	-	0	Clean with alcohol.
9	Drive section	Main drive unit Belt drive unit	1	Gears (grease)	х	х	-	-	х	-	х	-	Х	Apply to the specified position when checking.
			2	Shafts (grease)	х	х	-	-	х	-	х	-	Х	FLOIL G-313S
			3	Shaft earth sections (conduction grease)	х	х	-	-	х	-	х	-	Х	Apply to the specified position when checking. FLOIL GE-676
			4	Belts	x	x	-	-	x	-	x	-	x	
			5	Sensors	Х	X	-	-	X	-	X	-	Х	
		Transport	6	Belts	Х	Х	-	-	Х	-	Х	-	Х	
		drive unit	7	Connection arm	Х	Х	-	-	х	-	Х	-	х	Apply to the specified position when checking.
		Fusing drive unit	8	Shafts (grease)	Х	Х	-	-	х	-	Х	-	х	HANARL FL-955R
		Paper exit drive unit	9	Shafts (grease)	Х	Х	-	-	X	-	Х	-	X	
1			10	Belts	Х	Х	- 1	- 1	Х	- 1	Х	-	Х	

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
10	Fusing section	Fusing unit	1	Lower separation pawl	х	-	Х	-	-	Х	-	Х	-	
			2	Lower separation pawl spring	Х	-	Х	-	-	Х	-	х	-	
			3	Separation plate	Х	-	х	-	-	х	-	Х	-	
			4	Web guide shaft	Х		-	-		-		-	<b></b>	
			5	Web pressure roller bearing	Х		-	-	<b></b>	-	•	-	<b>A</b>	
			6	Web pressure roller	х	•	-	-	•	-	•	-	•	
			7	Web roller	Х		-	-		-		-		
			8	Lower thermistor	х	-	х	-	-	х	-	Х	-	Replace as needed.
			9	Pressure roller gear	х	-	х	-	-	х	-	х	-	
			10	Pressure roller bearing	Х	-	Х	-	-	Х	-	х	-	
			11	Pressure roller	x	-		-	-		-		-	Apply grease to the shaft section when replacing. (JEF552) / After completion of replacement, clean the new pressure roller surface with alcohol. / Integrated with the fusing roller as a maintenance kit. Replace at every 240K.
			12	Sub thermistor	Х	-	Х	-	-	Х	-	Х	-	Replace as needed.
			13	Fusing roller	Х	-	х	-	-	х	-	Х	-	
			14	Heat- insulating bush	Х	-	Х	-	-	Х	-	Х	-	Replace as needed. / When replacing, apply grease to the inner ring section and the outer ring section. (JEF552)
			15	Heating roller bearing	х	-	х	-	-	х	-	Х	-	Replace as needed.
			16	Fuser belt guide collar	Х	-	•	-	-	•	-	•	-	Integrated with the fusing belt as a maintenance kit. Replace at every 240K.
			17	Fusing roller	X	-		-	-		-		-	Apply grease to the shaft section when replacing. (JEF552) / Integrated with the pressure roller as a maintenance kit. Replace at every 240K.
			18	Heating roller	х	-	х	-	-	х	-	Х	-	Replace as needed.
			19	Fusing belt	X	-		-	-		-		-	Integrated with the fuser belt guide collar as a maintenance kit. / When replacing, clean the fusing belt surface with alcohol. Replace at every 240K.
			20	Main	Х	-	х	-	-	х	-	Х	-	Replace as needed.
			21	Paper	0	-	0	-	-	0	-	0	-	
			22	Gears	Х	-	х	-	-	х	-	х	-	Replace as needed.

Section/ Unit work sequence	Section name	Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
10	Fusing section	Fusing unit	23	Pressure spring	х	-	Х	-	-	х	-	Х	-	
			24	Washer	-	-	Х	-	-	Х	-	Х	-	
11	Other	•	1	Ozone filter	-	-	-		-	-	-		-	
			2	Toner cartridge BK		Use	r repla	cemen	t for ev	ery tor	ner em	pty.		
			3	Toner cartridge C										
			4	Toner cartridge M										
			5	Toner cartridge Y										
			6	Waste toner box		Repla	ced by	/ the u	ser whe	en full	is dete	cted.		Replacement reference: 50K

* 1: *1 Note for cleaning the image registration/density sensor.

When in maintenance or in case a service call, refer to "Criteria for necessity of cleaning" below to judge the necessity of cleaning the image registration/density sensor. If it is judged that cleaning is necessary, then perform cleaning.

#### Criteria for necessity of cleaning

- The SIM44-2 item D/E/F value is increased by aging or dirt of the image density sensor.
- When the image density is decreased, execute SIM44-2. and execute SIM46-74 Copy color balance adjustment.



#### Greasing

Greasing is not always required for every maintenance. In the following cases, check and grease.

- When there are some noises.
- When a lot of jams occur frequently. (Check the jam history.)

For the part code of grease to be used, refer to "[15] TOOL LIST."

# Note

# Cleaning of sensors and detectors in the paper feed/transport system

Cleaning of sensors and detectors in the paper feed/transport system is not always required for every maintenance. In the following cases, check and clean.

• When a trouble or a jam occurs due to a sensor or a detector. (Check the jam history.)

## Note

#### Torque limiter check and replacement

Torque limiter check and replacement is not always required for every maintenance. In the following cases, check and replace.

- When there are some noises.
- When a lot of jams occur frequently. (Check the jam history.)

# Note

#### Alcohol for cleaning

Be sure to use ethanol for cleaning.

# Note

#### Cleaning of the primary transfer mode detector (CL/BK)

- When replacing the OPC drum, remove the primary transfer unit and the developing unit, and clean them.
- Blow air to the light emitting section and light receiving section to remove the attached toner.
- Blow air also when the sensor is wiped and cleaned with waste cloth.

# Option

X: Check (Clean, replace, or adjust according to necessity.) O: Clean ▲: Replace △: Adjust ☆: Lubricate

Option name	Unit work sequence	Unit name	Parts work sequence	Part name	When calling	At the machine cycle	Remark
Stand/	1	Tray 2 paper feed unit	1	Paper pickup roller	×	0	Replace at 100K of each tray paper
500 sheet			2	Paper feed roller	×	0	feed counter or 1 year of use.
paper			3	Separation roller	×	0	
drawer			4	Transport roller 1	×	0	
			5	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
			6	Sensors	×	×	
			-	Paper guides	0	0	Clean with alcohol.
	2	1CS drive unit	7	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
			8	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S
Stand/	1	Tray 2 paper feed unit	1	Paper pickup roller	×	0	Replace at 100K of each tray paper
2x500 sheet			2	Paper feed roller	×	0	feed counter or 1 year of use.
paper			3	Separation roller	×	0	
drawer			4	Transport roller 1	×	0	
			5	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
			6	Sensors	×	×	
			-	Paper guides	0	0	Clean with alcohol.
	2	Tray 3 paper feed unit	7	Paper pickup roller	×	0	Replace at 100K of each tray paper
			8	Paper feed roller	×	0	feed counter or 1 year of use.
			9	Separation roller	×	0	
			10	Vertical transport roller 1	×	0	
			11	Transport roller 3	×	0	
			12	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
			13	Sensors	×	×	
			-	Paper guides	0	0	Clean with alcohol.
	3	1CS drive unit	14	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
			15	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S
	4	2CS drive unit	16	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
			17	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S

Option name	Unit work sequence	Unit name	Parts work sequence	Part name	When calling	At the machine cycle	Remark
Stand/	1	Tray 2 paper feed unit	1	Paper pickup roller	×	0	Replace at 100K of each tray paper
3x500 sheet			2	Paper feed roller	×	0	feed counter or 1 year of use.
paper			3	Separation roller	×	0	
drawer			4	Transport roller 1	×	0	
			5	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
			6	Sensors	×	×	
			-	Paper guides	0	0	Clean with alcohol.
	2	Tray 3 paper feed unit	7	Paper pickup roller	×	0	Replace at 100K of each tray paper
			8	Paper feed roller	×	0	feed counter or 1 year of use.
			9	Separation roller	×	0	
			10	Vertical transport roller 1	×	0	
			11	Transport roller 3	×	0	
			12	Iorque limiter	×	×	Replace at 100K of each tray paper feed counter.
			13	Sensors	X	×	
	-		-	Paper guides	0	0	Clean with alcohol.
	3	Tray 4 paper feed unit	14	Paper pickup roller	X	0	Replace at 100K of each tray paper
			15	Paper feed roller	×	0	feed counter or 1 year of use.
			16	Separation roller	X	0	
			17	Vertical transport roller 2	X	0	
			18	Transport roller 5	X	0	Deplete at 100K of each traverse
			19		×	×	feed counter.
			20	Sensors	×	×	
			_	Paper guides	0	0	Clean with alcohol.
	4	1CS drive unit	21	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
			22	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S
	5	2CS drive unit	23	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
			24	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S
	6	3CS drive unit	25	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S
Stand/	1	Tray 2 paper feed unit	1	Paper pickup roller	×	0	As a rough guide, these rollers
500&2000			2	Paper feed roller	×	0	should be replaced when each tray
sneet paper drawer			3	Separation roller	×	0	paper feed counter reaches a value of 100K or when one year has elansed since the start of use
			4	Transport roller 1	×	0	
			5	Torque limiter	×	×	As a rough guide, the torque limiter should be replaced when each tray paper feed counter reaches a value of 100K.
			6	Each sensor	×	×	
				Each paper guide	0	0	Clean with alcohol.
	2	1CS drive unit	7	Each gear (grease)	×	×	When checking, apply to the specified positions.
			8	Each shaft (grease)	×	×	When checking, apply to the specified positions. FLOIL G-313S
	3	Tray 3 paper feed unit	9	Paper pickup roller	×	0	As a rough guide, these rollers
			10	Paper feed roller	×	0	should be replaced when each tray
			11	Separation roller	×	0	paper feed counter reaches a value of 100K or when one year has elapsed since the start of use.
			12	Torque limiter	×	×	As a rough guide, the torque limiter should be replaced when each tray paper feed counter reaches a value of 100K.
				Each sensor	×	×	
				Each paper guide	0	0	Clean with alcohol.

Option name	Unit work sequence	Unit name	Parts work sequence	Part name	When calling	At the machine cycle	Remark
Stand/	4	Tray 4 paper feed unit	13	Paper pickup roller	×	0	As a rough guide, these rollers
500&2000			14	Paper feed roller	×	0	should be replaced when each tray
sheet paper drawer			15	Separation roller	×	0	paper feed counter reaches a value of 100K or when one year has elapsed since the start of use.
			16	Torque limiter	×	×	As a rough guide, the torque limiter should be replaced when each tray paper feed counter reaches a value of 100K.
				Each sensor	×	×	
				Each paper guide	0	0	Clean with alcohol.
	5	Level transport unit	17	Level transport roller R	×	0	
			18	Level transport roller L	×	0	
	6	Desk transport unit	19	Transport roller 2	×	0	
			20	Transport roller 3	×	0	
Large	1	Paper feed unit	1	Paper pickup roller	×	0	As a rough guide, these rollers
capacity tray			2	Paper feed roller	×	0	should be replaced when each tray
capacity tray			3	Separation roller	×	0	paper feed counter reaches a value of 100K or when one year has elapsed since the start of use.
			4	Torque limiter	×	×	As a rough guide, the torque limiter should be replaced when each tray paper feed counter reaches a value of 800K.
			5	Transport roller	×	0	
			6	Each gear (grease)	×	×	When checking, apply to the specified positions. HANARL FL-955R
			7	Each sensor	×	×	
			-	Each paper guide	0	0	Clean with alcohol.
	2	Drive unit	8	Each gear (grease)	×	×	When checking, apply to the specified positions. MOLYKOTE X5-6020 MOLYKOTE BR-2 Plus
			9	Each belt	×	×	
			10	Each sensor	×	×	
	3	Other	11	Each gear (grease)	×	×	When checking, apply to the specified positions. MOLYKOTE X5-6020
			12	Each sensor	×	×	

Option name	Parts work sequence	Part name	When calling	At the machine cycle	Remark
Finisher	1	Staple cartridge	×	×	Replacement is made by the user at every 5,000 pcs.
	2	Staple unit	×	×	Replacement reference: Replace the unit at every 200K staple.
	3	Paddle	×	0	
	4	Inlet port paper transport roller	×	0	
	5	Inlet port paper transport roller B	×	0	
	6	Discharge brush	×	×	
	7	Paper exit roller B	×	0	
	8	Paper exit roller	×	0	
	9	Bundle exit paper transport roller	×	0	
	10	Bundle exit paper exit transport roller B	×	0	
	11	Scraping roller	×	0	Replacement reference: Replace at every 1000K of the finisher paper exit count value.
	12	Sensors	×	×	
	-	Paper guides	×	0	Clean with alcohol.
Punch unit	1	Punch unit	×	×	Replacement reference: Replace the unit at every 1000K.
	2	Sensors	×	×	
Paper pass unit	1	Inlet port roller	0	0	
	2	Inlet port rear roller	0	0	
	3	Paper exit front roller	0	0	
	4	Paper exit roller	0	0	
	5	Sensors	×	×	
	-	Paper guides	×	0	Clean with alcohol.

Option	Parts work	Part name	When	At the	Remark
	sequence	Transact cellers	canny		
Sadde stitch finisher	1	Transport rollers	0	0	
	2	Knurling belt	×	0	
	3	Discharge brush	×	×	
	4	Sensors	×	×	
	5	Staple unit	×	×	Replacement reference: Replace the unit at every 200K staple.
	6	Staple unit (for saddle)	×	×	Replacement reference: Replace the unit at every 100K staple.
	7	Staple unit	×	×	Replacement reference: Replacement is made by the user at every 5,000 pcs.
	8	Staple unit (for saddle)	×	×	Replacement reference: Replacement is made by the user at every 2,000 pcs.
	-	Gears	×	×	
	-	Belts	×	×	
	_	Paper guides	×	0	Clean with alcohol.
Punch unit	1	Punch unit	×	×	Replacement reference: Replace the unit at every 1000K.
	2	Sensors	×	×	

# Note

#### Greasing

Greasing is not always required for every maintenance. In the following cases, check and grease.

• When there are some noises.

• When a lot of jams occur frequently. (Check the jam history.)

For the part code of grease to be used, refer to "[15] TOOL LIST."

# Note

#### Cleaning of sensors and detectors in the paper feed/transport system

Cleaning of sensors and detectors in the paper feed/transport system is not always required for every maintenance. In the following cases, check and clean.

• When a trouble or a jam occurs due to a sensor or a detector. (Check the jam history.)

# Note

#### Torque limiter check and replacement

Torque limiter check and replacement is not always required for every maintenance. In the following cases, check and replace.

- · When there are some noises.
- When a lot of jams occur frequently. (Check the jam history.)

## Note

# Alcohol for cleaning

Be sure to use ethanol for cleaning.
### A. RSPF section

 $\times/$   $\swarrow$  : Check (Clean, replace, or adjust according to necessity.)

▲/ 🜔 : Replace

 $\triangle / \overleftarrow{\leftarrow \bullet \rightarrow}$  : Adjust





O/ 🏹 🛃 🎬 😴 🚺 🧹 : Clean

26 cpm/31 cpm machine

Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
RSPF unit	1	Document pickup roller	0	0	-	0	0	0	-	0	0	Replace at 100K of the SPF
	2	Paper feed roller	0	0	-	0	0	0	-	0	0	paper feed counter or 1
	3	Separation roller	0	0	_	0	0	0	_	0	0	year of use. When replacing the paper feed roller, apply grease to the paper feed shaft. GP-501MR
	4	Torque limiter SPF	×	$\times$	-	×	X	×	-	×	×	Replace at 400K of the SPF
	5	Take-up torque limiter	×	×	-	×	×	×	-	×	×	paper feed counter or 2 years of use.
	6	Discharge brush	×	Х	-	×	X	×	-	×	×	
	7	Registration roller	0	0	-	0	0	0	-	0	0	
	8	Transport roller 2	0	0	-	0	0	0	-	0	0	
	9	Transport roller 3	0	0	-	0	0	0	-	0	0	
	10	Paper exit roller	0	0	-	0	0	0	-	0	0	
	11	Sensors	×	×	-	×	×	×	-	×	×	
	12	Scan plate	0	0	-	0	0	0	-	0	0	
-	13	Gears	×	×	-	X	×	×	-	×	×	
	14	Belts	×	X	-	×	X	×	-	×	×	
	15	OC mat	0	0	-	0	0	0	-	0	0	

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
RSPF unit	1	Document pickup roller	0	0	-	_	0	-	0	-	0	Replace at 100K of the SPF
	2	Paper feed roller	0	0	-	-	0	-	0	-	0	paper feed counter or 1
	3	Separation roller	0	0	_	I	0	_	0	_	0	year of use. When replacing the paper feed roller, apply grease to the paper feed shaft. GP-501MR
	4	Torque limiter SPF	×	×	-	1	×	-	×	-	×	Replace at 400K of the SPF
	5	Take-up torque limiter	×	×	-	I	×	-	×	-	×	paper feed counter or 2 years of use.
	6	Discharge brush	×	×	-	-	×	-	×	-	×	
	7	Registration roller	0	0	-	١	0	-	0	-	0	
	8	Transport roller 2	0	0	-	1	0	-	0	-	0	
	9	Transport roller 3	0	0	-	1	0	-	0	-	0	
	10	Paper exit roller	0	0	-	1	0	-	0	-	0	
	11	Sensors	×	×	-	-	×	-	×	-	×	
-	12	Scan plate	0	0	-	-	0	-	0	-	0	
	13	Gears	×	X	-	-	×	-	×	-	×	
	14	Belts	×	×	-	-	×	-	×	-	×	
	15	OC mat	0	0	-	_	0	-	0	-	0	



### **B.** Scanner section



▲/ 🚺 : Replace

 $\triangle / \overleftarrow{\leftarrow \bullet \rightarrow}$  : Adjust

O/ 🎦 🎽 🎬 🍞 🌈 < : Clean ☆/ OIL GREASE

### 26 cpm/31 cpm machine

Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
Scanner	1	Drive belt	×	×	-	×	×	×	-	×	×	
unit	2	Drive wire	×	×	-	×	×	×	-	×	×	
	3	Sensors	×	×	-	×	×	×	-	×	×	
	4	Rails	☆	X4	-	X4	\$	\$	-	\$2	☆	
	5	Mirror	0	0	-	0	0	0	-	0	0	
	6	Reflector	0	0	-	0	0	0	-	0	0	
	7	Scanner lamp	0	0	-	0	0	0	-	0	0	
	8	Lens	0	0	-	0	0	0	-	0	0	
	9	CCD	0	0	-	0	0	0	-	0	0	
	10	Table glass	0	0	-	0	0	0	-	0	0	
	11	SPF glass	0	0	_	0	0	0	-	0	0	

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
Scanner	1	Drive belt	×	×	-	-	×	-	Х	-	×	
unit	2	Drive wire	×	×	-	-	×	-	Х	-	×	
	3	Sensors	×	×	-	-	×	-	Х	-	×	
	4	Rails	☆	X4	1	-	X4	-	☆	-	42	
	5	Mirror	0	0	I	I	0	-	0	1	0	
	6	Reflector	0	0	-	-	0	-	0	-	0	
	7	Scanner lamp	0	0	1	-	0	-	0	-	0	
	8	Lens	0	0	-	-	0	-	0	-	0	
	9	CCD	0	0	-	-	0	-	0	-	0	
	10	Table glass	0	0	1	-	0	-	0	-	0	
	11	SPF glass	0	0	_	_	0	-	0	_	0	



### C. Developing section



Unit name	Parts work	Part name	When calling	840 K rotation	840 K rotation	840 K rotation	Remark
	sequence						
Developing unit	1	Developer	×		<b>A</b>		maximum printed
(monochrome)	2	DV seal/DV seal B	×	×	×	×	number
	3	DV side seals F/R	×	×	×	×	26cpm 140K
	4	Toner filter	×	×	×	×	31cpm 155K 36cpm 170K
	5	Bias pin	×	×	×	×	
	6	Connector	×	×	×	×	
Developing unit (color)	1	Developer	×	<b>A</b>	<b></b>	<b>A</b>	maximum printable
	2	DV seal/DV seal B	×	×	×	×	number 140K
	3	DV side seals F/R	×	×	×	×	
	4	Toner filter	×	×	×	×	
	5	Bias pin	×	×	×	×	
	6	Connector	×	×	×	×	



### D. OPC drum section



Unit name	Parts work sequence	Part name	When calling	840 K rotation	840 K rotation	840 K rotation	Remark
OPC drum unit	1	Drum	×	<b></b>	<b></b>	<b></b>	840K rotation or
(monochrome)	2	MC unit	×	<b></b>	<b></b>	<b></b>	
	3	Cleaning blade	×	<b></b>	<b></b>	<b></b>	maximum printed
	4	Toner reception blade	×	×	×	×	26cpm 140K 31cpm 155K
	5	Side seals F/R	×	×	×	×	36cpm 170K
	6	Charger cleaner	×	<b>A</b>	<b>A</b>	<b>A</b>	
OPC drum unit (color)	1	Drum	×	<b>A</b>		<b></b>	840K rotation or
	2	MC unit	×	<b></b>	<b></b>	<b></b>	maximum printable
	3	Cleaning blade	×	<b></b>	<b></b>	<b></b>	
	4	Toner reception blade	×	×	×	×	
	5	Side seals F/R	×	×	×	×	]
	6	Charger cleaner	×	<b>A</b>		•	



### E. Transfer section

### (1) Primary transfer unit

 $\times/\sim$  : Check (Clean, replace, or adjust according to necessity.)





### 26 cpm/31 cpm machine

Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
Primary	1	Separation pawl	×	Х	-	×	×	Х	I	×	×	Replace as needed.
transfer unit	2	Primary transfer belt	×	<b></b>	_	<b></b>	<b></b>	<b></b>	I	•	<b></b>	When replacing, apply KYNAR powder.
	3	Secondary drive transmission gear	×	0	-	0	0	0	1	0	0	
	4	Primary transfer belt drive roller	×	0	-	0	0	0	I	0	0	
	5	Primary transfer belt follower roller	×	0	-	0	0	0	I	0	0	
	6	Primary transfer belt tension roller	×	0	-	0	0	0	1	0	0	
	7	Registration backup roller	×	0	-	0	0	0	I	0	0	
	8	Y auxiliary roller	×	0	-	0	0	0	I	0	0	
	9	PTC backup roller	×	0	-	0	0	0	-	0	0	
	10	Primary transfer roller	×	Х	-	×	×	Х	I	×	×	Replace as needed.
	11	Transfer cleaner seals F/R	×	×	-	×	×	×	I	×	×	
	12	Primary transfer belt cleaner blade	×		-				-			
	13	Primary transfer toner reception blade	×	×	-	×	×	×	I	×	×	Replace as needed.
	14	Primary transfer operation mode detector	×	0	_	0	0	0	-	0	0	

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
Primary	1	Separation pawl	-	-	×	-	-	×	-	×	1	Replace as needed.
transfer unit	2	Primary transfer belt	_	_	<b></b>	_	-	<b></b>	1		I	When replacing, apply KYNAR powder.
	3	Secondary drive transmission gear	-	-	0	-	-	0	I	0	I	
	4	Primary transfer belt drive roller	-	-	0	-	-	0	Ι	0	١	
	5	Primary transfer belt follower roller	-	-	0	-	-	0	1	0	I	
	6	Primary transfer belt tension roller	-	-	0	-	-	0	-	0	-	
	7	Registration backup roller	-	-	0	-	-	0	-	0	-	
	8	Y auxiliary roller	-	-	0	-	-	0	Ι	0	-	
	9	PTC backup roller	-	-	0	-	-	0	-	0	-	
	10	Primary transfer roller	-	-	×	-	-	Х	-	×	-	Replace as needed.
	11	Transfer cleaner seals F/R	-	-	×	-	-	×	Ι	×	-	
	12	Primary transfer belt cleaner blade	-	-		-	-		-		-	
	13 Primary transfer toner rec blade		-	-	×	-	-	×	-	×	I	Replace as needed.
	14	Primary transfer operation mode detector	-	_	0	_	_	0	-	0	-	



### (2) Secondary transfer unit







### 26 cpm/31 cpm machine

Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
Secondary transfer unit	1	Secondary transfer belt follower roller	×	I	0	I	0	I	0	I	0	
	2	Secondary transfer belt	×	1	<b></b>	I		I		I		Never use alcohol or solvents for cleaning. Replace at every 300K.
	3	Secondary transfer belt drive roller	×	-	0	-	0	-	0	-	0	
	4	Secondary transfer backup roller	×	-	0	-	0	-	0	-	0	
	5	Secondary transfer belt tension roller	×	1	0	-	0	-	0	-	0	
	6	Secondary transfer roller	×	I	×	1	×	I	×	-	×	Replace as needed.
	7	Secondary transfer drive gear	×	I	×	I	×	I	×	1	×	
	8	Separation cam	×	Ι	\$	-	\$	-	\$	-	\$	When replacing, apply
	9	Secondary transfer frame	×	-	\$	1	\$	1	\$3	1	42	HANARL FL-955R to the shaft section.

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
Secondary transfer unit	1	Secondary transfer belt follower roller	-	-	-	0	-	-	-	0	-	
	2	Secondary transfer belt	-	-	-	•	-	-	-	•	-	Never use alcohol or solvents for cleaning. Replace at every 360K.
	3	Secondary transfer belt drive roller	-	-	-	0	-	-	-	0	-	
	4	Secondary transfer backup roller	-	-	-	0	-	-	-	0	-	
	5	Secondary transfer belt tension roller	-	-	-	0	-	-	-	0	-	
	6	Secondary transfer roller	-	I	I	Х	-	-	-	×	-	Replace as needed.
	7	Secondary transfer drive gear	-	I	I	×	-	I	-	×	-	
	8	Separation cam	-	I	I	纹	-	I	-	43	-	When replacing, apply
	9	Secondary transfer frame	-	-	-	\$2	_	-	-	\$	-	HANARL FL-955R to the shaft section.



#### (3) Other





▲/ 🚺 : Replace

△/ ← → : Adjust

GREASE C Lubricate

#### 26 cpm/31 cpm machine

Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
Other	1	PTC unit	×	•	-				-	•		Replace. Reciprocate the PTC cleaning rod back and forth 3 times.
	2	Image density sensor/ Registration sensor/ Standard reflection plate	×	0	_	0	0	0	-	0	0	Remove dirt from the light emitting/ receiving sections (transparent plastic sections) of the sensor and the standard reflection plate (gray plastic section) with dry waste cloth. *1

#### 36 cpm machine

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
Other	1	PTC unit	×		-	-		-		Ι		Replace. Reciprocate the PTC cleaning rod back and forth 3 times.
	2	Image density sensor/ Registration sensor/ Standard reflection plate	×	0	_	0	0	0	-	0	0	Remove dirt from the light emitting/ receiving sections (transparent plastic sections) of the sensor and the standard reflection plate (gray plastic section) with dry waste cloth. *1

*1 : Note for cleaning the image registration/density sensor.

When in maintenance or in case a service call, refer to "Criteria for necessity of cleaning" below to judge the necessity of cleaning the image registration/density sensor. If it is judged that cleaning is necessary, then perform cleaning

### Criteria for necessity of cleaning

- The SIM44-2 item D/E/F value is increased by aging or dirt of the image density sensor.
- When the image density is decreased, execute SIM44-2 and execute SIM46-74 Copy color balance adjustment.



### F. LSU section

×/ 🔄 : Check (Clean, replace, or adjust according to necessity.) O/ 🎦 🎽 🌠 🌄 Clean









Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
LSU	1	Dust-proof glass	0	0	-	0	0	0	-	0	0	Use the LSU cleaning rod.
Other	2	Cleaning base	×	Rep	lace ev	ery time	e the wa	aste tor	ier box	is repla	ced.	Attached to the waste toner box. (2 pcs.) / Replace when the waste toner box is replaced, or at 100K, or 2 years of use.

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
LSU	1	Dust-proof glass	0	0	-	-	0	-	0	-	0	Use the LSU cleaning rod.
Other	2	Cleaning base	×	Rep	lace ev	ery tim	e the wa	aste tor	ner box	is repla	iced.	Attached to the waste toner box. (2 pcs.) / Replace when the waste toner box is replaced, or at 100K, or 2 years of use.



### G. Manual paper feed section

×/ 🔄 : Check (Clean, replace, or adjust according to necessity.) O/ 🎦 🎽 🌠 🌄 IClean

▲/ () : Replace

△/ ← → : Adjust



☆/ CIL GREASE



Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
Manual paper	1	Paper feed roller	×	0	-	0	0	0	-	0	0	Replace at 100K of the manual
feed unit	2	Separation roller	×	0	-	0	0	0	-	0	0	paper feed counter or 1 year of use.
	3	Torque limiter	×	×	-	×	×	×	-	×	×	
	4	Transport roller 9	×	0	-	0	0	0	-	0	0	
	5	Transport roller 10	×	0	-	0	0	0	-	0	0	
	6	Sensors	×	×	-	×	×	×	-	×	×	
	-	Paper guides	0	0	-	0	0	0	_	0	0	Clean with alcohol.

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
Manual paper	1	Paper feed roller	×	0	-	-	0	-	0	-	0	Replace at 100K of the manual
feed unit	2	Separation roller	×	0	-	-	0	-	0	-	0	paper feed counter or 1 year of use.
	3	Torque limiter	×	X	-	-	Х	-	Х	-	×	
	4	Transport roller 9	×	0	-	-	0	-	0	-	0	
	5	Transport roller 10	×	0	-	-	0	-	0	-	0	
	6	Sensors	×	X	-	-	X	-	Х	-	×	
	_	Paper guides	0	0	-	-	0	-	0	-	0	Clean with alcohol.



### H. Tray paper feed section

×/ 🔄 : Check (Clean, replace, or adjust according to necessity.) O/ 🎦 🎽 🌠 🌄 IClean

▲/ 🜔 : Replace

 $\triangle / \overleftarrow{\leftarrow \bullet \rightarrow}$  : Adjust



☆/ OIL GREASE



Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
Tray paper	1	Paper pickup roller	×	0	I	0	0	0	1	0	0	Replace at 100K of the tray
feed unit	2	Paper feed roller	×	0	-	0	0	0	-	0	0	paper feed counter or 1 year of
	3	Separation roller	×	0	-	0	0	0	-	0	0	use.
	4	Transport roller 4	×	0	-	0	0	0	-	0	0	
	5	Transport roller 2	×	0	1	0	0	0	-	0	0	
	6	Torque limiter	×	×	-	×	×	×	-	×	×	
	7	Sensors	×	×	-	×	×	×	-	×	×	
	_	Paper guides	0	0	-	0	0	0	-	0	0	Clean with alcohol.

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
Tray paper	1	Paper pickup roller	×	0	-	-	0	-	0	-	0	Replace at 100K of the tray
feed unit	2	Paper feed roller	×	0	1	-	0	-	0	-	0	paper feed counter or 1 year of
	3	Separation roller	×	0	-	-	0	-	0	-	0	use.
	4	Transport roller 4	×	0	-	-	0	-	0	-	0	
	5	Transport roller 2	×	0	-	-	0	-	0	-	0	
	6	Torque limiter	×	×	-	-	×	-	×	1	×	
	7	Sensors	×	×	_	-	×	-	×	-	×	
	_	Paper guides	0	0	-	-	0	-	0	-	0	Clean with alcohol.



### I. Paper registration section (paper transport section)/Paper exit section/ADU section

 $\times$  Check (Clean, replace, or adjust according to necessity.)

▲/ () : Replace

26 cpm/31 cpm machine

 $\triangle / \leftarrow \bullet \rightarrow$  : Adjust



O/

☆/



When Parts work 200 300 400 600 800 900 1000 1200 Unit name Part name Remark sequence calling κ κ κ κ κ κ κ κ PS unit 0 0 0 1 Registration roller (idle)  $\times$ Ο _ 0 0 _ 0 0 0 0 2 Registration roller (drive) × 0 0 _ _ × 0 0 0 0 0 3 Transport roller 5 _ 0 _ 4 Sensors Х х _ Х Х Х _ Х Х Right door unit 5 Transport roller 7 × 0 _ 0 0 0 _ 0 0 6 Transport roller 8 Х 0 0 0 0 0 -0 -0 0 7 Paper exit roller 3 × 0 0 0 0 --8 Paper exit roller 2 X 0 0 0 0 0 0 --9 Discharge brush × × × × × × × --Х Х Х 10 Sensors х _ х ×  $\times$ _ 0 0 11 Х 0 0 0 Fusing rear unit Transport roller 6 0 _ _ 12 X 0 0 0 0 0 0 Paper exit unit Paper exit roller 1 _ _ 13 Discharge brush Х х _ Х х Х -Х Х 14 Sensors × ×  $\times$ ×  $\times$ _ ×  $\times$ _ Other 15 0 0 0 0 0 0 0 Paper dust removing unit --0 0 0 0 0 0 Clean with alcohol. 0 Paper guides _ _

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
PS unit	1	Registration roller (idle)	×	0	1	I	0	I	0	-	0	
	2	Registration roller (drive)	×	0	-	-	0	١	0	١	0	
	3	Transport roller 5	×	0	-	Ι	0	I	0	١	0	
	4	Sensors	×	×	-	١	×	I	×	Ι	×	
Right door unit	5	Transport roller 7	×	0	-	-	0	١	0	١	0	
	6	Transport roller 8	×	0	-	Ι	0	I	0	١	0	
	7	Paper exit roller 3	×	0	-	١	0	I	0	Ι	0	
	8	Paper exit roller 2	×	0	-	-	0	١	0	١	0	
	9	Discharge brush	×	×	-	-	$\times$	-	×	-	×	
	10	Sensors	×	×	-	١	×	I	×	Ι	×	
Fusing rear unit	11	Transport roller 6	×	0	-	-	0	١	0	١	0	
Paper exit unit	12	Paper exit roller 1	×	0	-	Ι	0	I	0	١	0	
	13	Discharge brush	×	×	-	-	×	-	×	-	×	
	14	Sensors	-	Х	-	-	×	I	×	-	×	
Other	15	Paper dust removing unit	0	0	-	Ι	0	I	0	I	0	
	-	Paper guides	0	0	-	-	0	-	0	-	0	Clean with alcohol.



### J. Drive section



#### 26 cpm/31 cpm machine

Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
Main drive unit	1	Gears (grease)	×	×	-	×	×	×	-	×	×	Apply to the specified
Belt drive unit	2	Shafts (grease)	×	×	-	×	×	×	-	×	×	position when checking. FLOIL G-313S
	3	Shaft earth sections (conduction grease)	×	×	_	×	×	×	_	×	×	Apply to the specified position when checking. FLOIL GE-676
	4	Belts	×	×	-	×	Х	×	-	×	×	
	5	Sensors	×	×	-	×	×	×	-	×	×	
Transport drive unit	6	Belts	×	X	-	×	Х	×	-	×	×	
	7	Connection arm	×	×	-	×	Х	×	-	×	×	Apply to the specified
Fusing drive unit	8	Shafts (grease)	×	×	-	×	×	×	-	×	×	position when checking.
Paper exit drive unit	9	Shafts (grease)	×	X	-	×	Х	×	-	×	×	HANARL FL-955R
	10	Belts	×	×	-	×	×	×	-	×	×	

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
Main drive unit	1	Gears (grease)	×	×	-	-	×	-	×	-	×	Apply to the specified
Belt drive unit	2	Shafts (grease)	×	×	-	-	×	-	×	-	×	position when checking. FLOIL G-313S
	3	Shaft earth sections (conduction grease)	×	×	-	-	×	-	×	-	×	Apply to the specified position when checking. FLOIL GE-676
	4	Belts	×	×	-	-	×	-	Х	-	×	
	5	Sensors	×	Х	-	-	Х	-	×	-	×	
Transport drive unit	6	Belts	×	×	-	-	×	-	Х	-	×	
	7	Connection arm	×	Х	-	_	Х	-	×	_	×	Apply to the specified
Fusing drive unit	8	Shafts (grease)	×	×	-	-	×	-	×	-	×	position when checking.
Paper exit drive unit	9	Shafts (grease)	×	Х	-	_	Х	_	×	-	×	HANARL FL-955R
	10	Belts	×	Х	-	-	Х	-	×	-	×	





# K. Fusing section



▲/ 🚺 : Replace

4

△/ 
ADJUST
: Adjust

ity.) O/ 🚺 🛃 🌠 🎜 🚺 🥪 : Clean

#### 26 cpm/31 cpm machine

Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
Fusing unit	1	Lower separation pawl	Х	Х	-	Х	Х	Х	-	Х	Х	
	2	Lower separation pawl spring	Х	Х	-	Х	Х	Х	-	Х	Х	
	3	Separation plate	Х	Х	-	Х	Х	Х	-	Х	Х	
	4	Web guide shaft	Х		-				-			
	5	Web pressure roller bearing	Х		-				-			
	6	Web pressure roller	Х		-				-			
	7	Web roller	Х		-				-			
	8	Lower thermistor	Х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
	9	Pressure roller gear	Х	Х	-	Х	Х	Х	-	Х	Х	
	10	Pressure roller bearing	Х	Х	-	Х	Х	Х	-	Х	Х	
	11	Pressure roller	X		-				-			Apply grease to the shaft section when replacing. (JEF552) / After completion of replacement, clean the new pressure roller surface with alcohol. / Integrated with the fusing roller as a maintenance kit. Replace at every 200K.
	12	Sub thermistor	Х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
	13	Fusing roller bearing	Х	Х	-	Х	Х	Х	-	Х	Х	
	14	Heat-insulating bush	X	X	-	X	X	X	-	X	X	Replace as needed. / When replacing, apply grease to the inner ring section and the outer ring section. (JEF552)
	15	Heating roller bearing	Х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
	16	Fuser belt guide collar	X		-				-			Integrated with the fusing belt as a maintenance kit. Replace at every 200K.
	17	Fusing roller	X		-				-			Apply grease to the shaft section when replacing. (JEF552) / Integrated with the pressure roller as a maintenance kit. Replace at every 200K.
	18	Heating roller	Х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
	19	Fusing belt	х		-				-			Integrated with the fuser belt guide collar as a maintenance kit. Replace at every 200K.
	20	Main thermistor	Х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
	21	Paper guides	0	0	-	0	0	0	-	0	0	
	22	Gears	Х	Х	-	Х	Х	Х	-	Х	Х	Replace as needed.
	23	Pressure spring	Х	Х	-	Х	Х	Х	-	Х	Х	
	24	Washer	Х	Х	-	Х	Х	Х	-	Х	Х	



Δ

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
Fusing unit	1	Lower separation pawl	Х	-	Х	-	-	Х	-	Х	-	
-	2	Lower separation pawl spring	Х	-	Х	-	-	Х	-	Х	-	
	3	Separation plate	Х	-	Х	-	-	Х	-	Х	-	
	4	Web guide shaft	Х		-	-		-		-		
	5	Web pressure roller bearing	Х		-	-		-		-		
	6	Web pressure roller	Х		-	-		-		-		
	7	Web roller	Х		-	-		-		-		
	8	Lower thermistor	Х	-	Х	-	-	Х	-	Х	-	Replace as needed.
	9	Pressure roller gear	Х	-	Х	-	-	Х	-	Х	-	
	10	Pressure roller bearing	Х	-	Х	-	-	Х	-	Х	-	
	11	Pressure roller	X	-		-	-		-		-	Apply grease to the shaft section when replacing. (JEF552) / After completion of replacement, clean the new pressure roller surface with alcohol. / Integrated with the fusing roller as a maintenance kit. Replace at every 240K.
	12	Sub thermistor	Х	-	Х	-	-	Х	-	Х	-	Replace as needed.
	13	Fusing roller bearing	Х	-	Х	-	-	Х	-	Х	-	
	14	Heat-insulating bush	Х	-	х	-	-	х	-	Х	-	Replace as needed. / When replacing, apply grease to the inner ring section and the outer ring section. (JEF552)
	15	Heating roller bearing	Х	-	Х	-	-	Х	-	Х	-	Replace as needed.
	16	Fuser belt guide collar	х	-	•	-	-	•	-		-	Integrated with the fusing belt as a maintenance kit. Replace at every 240K.
	17	Fusing roller	X	-		-	-		-		-	Apply grease to the shaft section when replacing. (JEF552) / Integrated with the pressure roller as a maintenance kit. Replace at every 240K.
	18	Heating roller	Х	-	Х	-	-	Х	-	Х	-	Replace as needed.
	19	Fusing belt	X	-		-	-		-		-	Integrated with the fuser belt guide collar as a maintenance kit. / When replacing, clean the fusing belt surface with alcohol. Replace at every 240K.
	20	Main thermistor	Х	-	Х	-	-	Х	-	Х	-	Replace as needed.
	21	Paper guides	0	-	0	-	-	0	-	0	-	
	22	Gears	Х	-	Х	-	-	Х	-	Х	-	Replace as needed.
	23	Pressure spring	Х	-	Х	-	-	Х	-	Х	-	
	24	Washer	Х	-	Х	-	-	Х	-	Х	-	



### L. Other











Unit name	Parts work sequence	Part name	When calling	200 K	300 K	400 K	600 K	800 K	900 K	1000 K	1200 K	Remark
	1	Ozone filter	-	-		-		-		-		
	2	Toner cartridge BK		Use	er repla	cement	for eve	ery tone	r empty			
	3	Toner cartridge C										
	4	Toner cartridge M										
	5	Toner cartridge Y										
	6	Waste toner box	Replaced by the user when full is detected.									Replacement reference: 50K

Unit name	Parts work sequence	Part name	When calling	200 K	240 K	360 K	400 K	480 K	600 K	720 K	800 K	Remark
	1	Ozone filter	-	-	-		-	-	-		-	
	2	Toner cartridge BK	User replacement for every toner empty.									
	3	Toner cartridge C										
	4	Toner cartridge M										
	5	Toner cartridge Y										
	6	Waste toner box	Replaced by the user when full is detected.						Replacement reference: 50K			



# M. Option

### (1) Stand/500 sheet paper drawer

 $\times/\swarrow$ : Check (Clean, replace, or adjust according to necessity.)  $\bigcirc/\checkmark$ 

Unit work sequence	Unit name	Parts work sequence	Part name	When calling	At the machine cycle	Remark
1	Tray 2 paper feed	1	Paper pickup roller	×	0	Replace at 100K of each tray paper feed counter
	unit	2	Paper feed roller	×	0	or 1 year of use.
		3	Separation roller	×	0	
		4	Transport roller 1	×	0	
		5	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
		6	Sensors	×	×	
		-	Paper guides	0	0	Clean with alcohol.
2	1CS drive unit	7	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
		8	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S





### (2) Stand/2x500 sheet paper drawer

 $\times/\swarrow$ : Check (Clean, replace, or adjust according to necessity.)  $\bigcirc/\checkmark$ 

Unit work sequence	Unit name	Parts work sequence	Part name	When calling	At the machine cycle	Remark
1	Tray 2 paper feed unit	1	Paper pickup roller	×	0	Replace at 100K of each tray paper feed
		2	Paper feed roller	×	0	counter or 1 year of use.
		3	Separation roller	×	0	
		4	Transport roller 1	×	0	
		5	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
		6	Sensors	×	×	
		-	Paper guides	0	0	Clean with alcohol.
2	Tray 3 paper feed unit	7	Paper pickup roller	×	0	Replace at 100K of each tray paper feed
		8	Paper feed roller	×	0	counter or 1 year of use.
		9	Separation roller	×	0	
		10	Vertical transport roller 1	×	0	
		11	Transport roller 3	×	0	
		12	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
		13	Sensors	×	×	
		-	Paper guides	0	0	Clean with alcohol.
3	1CS drive unit	14	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
		15	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S
4	2CS drive unit	16	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
		17	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S



### (3) Stand/3x500 sheet paper drawer

Unit work sequence	Unit name	Parts work sequence	Part name	When calling	At the machine cycle	Remark
1	Tray 2 paper feed unit	1	Paper pickup roller	×	0	Replace at 100K of each tray paper feed
		2	Paper feed roller	×	0	counter or 1 year of use.
		3	Separation roller	×	0	
		4	Transport roller 1	×	0	
		5	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
		6	Sensors	×	×	
		-	Paper guides	0	0	Clean with alcohol.
2	Tray 3 paper feed unit	7	Paper pickup roller	×	0	Replace at 100K of each tray paper feed
		8	Paper feed roller	×	0	counter or 1 year of use.
		9	Separation roller	×	0	
		10	Vertical transport roller 1	×	0	
		11	Transport roller 3	×	0	
		12	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
		13	Sensors	×	×	
		-	Paper guides	0	0	Clean with alcohol.
3	Tray 4 paper feed unit	14	Paper pickup roller	×	0	Replace at 100K of each tray paper feed
		15	Paper feed roller	×	0	counter or 1 year of use.
		16	Separation roller	×	0	
		17	Vertical transport roller 2	×	0	
		18	Transport roller 5	×	0	
		19	Torque limiter	×	×	Replace at 100K of each tray paper feed counter.
		20	Sensors	×	×	
		-	Paper guides	0	0	Clean with alcohol.
4	1CS drive unit	21	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
		22	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S
5	2CS drive unit	23	Gears (grease)	×	×	Apply to the specified position when checking. HANARL FL-955R
		24	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S
6	3CS drive unit	25	Shafts (grease)	×	×	Apply to the specified position when checking. FLOIL G-313S



#### (4) Stand/500&2000 sheet paper drawer



Unit work sequence	Unit name	Parts work sequence	Part name	When calling	When machine cycle	Remarks
1	Tray 2 paper feed unit	1	Paper pickup roller	×	0	As a rough guide, these rollers should be replaced when
		2	Paper feed roller	×	0	each tray paper feed counter reaches a value of 100K or
		3	Separation roller	×	0	when one year has elapsed since the start of use.
		4	Transport roller 1	×	0	
		5	Torque limiter	×	×	As a rough guide, the torque limiter should be replaced when each tray paper feed counter reaches a value of 100K.
		6	Each sensor	×	×	
			Each paper guide	0	0	Clean with alcohol.
2	1CS drive unit	7	Each gear (grease)	×	×	When checking, apply to the specified positions. HANARL FL-955R
	8 Each shaft (grease)		×	×	When checking, apply to the specified positions. FLOIL G-313S	
3	Tray 3 paper feed unit	9	Paper pickup roller	×	0	As a rough guide, these rollers should be replaced when
		10	Paper feed roller	×	0	each tray paper feed counter reaches a value of 100K or
		11	Separation roller	×	0	when one year has elapsed since the start of use.
		12	Torque limiter	×	×	As a rough guide, the torque limiter should be replaced when each tray paper feed counter reaches a value of 100K.
			Each sensor	×	×	
			Each paper guide	0	0	Clean with alcohol.
4	Tray 4 paper feed unit	13	Paper pickup roller	×	0	As a rough guide, these rollers should be replaced when
		14	Paper feed roller	×	0	each tray paper feed counter reaches a value of 100K or
		15	Separation roller	×	0	when one year has elapsed since the start of use.
		16	Torque limiter	×	×	As a rough guide, the torque limiter should be replaced when each tray paper feed counter reaches a value of 100K.
			Each sensor	×	×	
			Each paper guide	0	0	Clean with alcohol.
5	Level transport unit	17	Level transport roller R	×	0	
		18	Level transport roller L	×	0	
6	Desk transport unit	19	Transport roller 2	×	0	
		20	Transport roller 3	×	0	

### Note

#### On greasing

Greasing is not always necessary for every maintenance. In the following cases, check and grease.

• There are some noises.

• Many jams occur frequently. (Check the jam history.)

For the part code of grease to be used, refer to [15] "Tool List" in service manual (00ZMX3640/S1E).

# Note

#### Cleaning of the paper feed and paper transport system sensors and detectors

Cleaning of the paper feed and paper transport system sensors and detectors is not always necessary for every maintenance. In the following case, check and clean.

· A trouble or jam is generated because of the sensors or detectors. (Check the jam history.)

# Note

#### Torque limiter check and replacement

Torque limiter check or replacement is not always necessary for every maintenance. In the following cases, check and replace.

- There are some noises.
- Many jams occur frequently. (Check the jam history.)

### Note

#### Alcohol used for cleaning

Be sure to use ethanol for cleaning.



### (5) Large capacity tray



Unit work sequence	Unit name	Parts work sequence	Part name	When calling	At the machine cycle	Remark
1	Paper feed unit	ed unit 1 Paper pickup roller		×	0	As a rough guide, these rollers should be replaced when
		2	Paper feed roller	×	0	each tray paper feed counter reaches a value of 100K or
		3	Separation roller	×	0	when one year has elapsed since the start of use.
		4	Torque limiter	×	×	As a rough guide, the torque limiter should be replaced when each tray paper feed counter reaches a value of 800K.
		5	Transport roller	×	0	
		6	Each gear (grease)	×	×	When checking, apply to the specified positions. HANARL FL-955R
		7	Each sensor	×	×	
		-	Each paper guide	0	0	Clean with alcohol.
2	Drive unit	8	Each gear (grease)	×	×	When checking, apply to the specified positions. MOLYKOTE X5-6020 MOLYKOTE BR-2 Plus
		9	Each belt	×	×	
		10	Each sensor	×	×	
3	Other	11	Each gear (grease)	×	×	When checking, apply to the specified positions. MOLYKOTE X5-6020
		12	Each sensor	×	×	



### (6) Finisher



 $\blacktriangle / \bigcirc : \mathsf{Replace} \qquad \bigtriangleup / \xleftarrow{\mathsf{ADJUST}} : \mathsf{Adjust} \qquad \And / \bigcirc \textcircled{\mathsf{GREASE}} \bigcirc \textcircled{\mathsf{GREASE}} : \mathsf{Lubricate}$ 

Parts work sequence	Part name	When calling	At the machine cycle	Remark
1	Staple cartridge	×	×	Replacement is made by the user at every 5,000 pcs.
2	Staple unit	×	×	Replacement reference: Replace the unit at every 200K staple.
3	Paddle	×	0	
4	Inlet port paper transport roller	×	0	
5	Inlet port paper transport roller B	×	0	
6	Discharge brush	×	×	
7	Paper exit roller B	×	0	
8	Paper exit roller	×	0	
9	Bundle exit paper transport roller	×	0	
10	Bundle exit paper exit transport roller B	×	0	
11	Scraping roller	×	0	Replacement reference: Replace at every 1000K of the finisher paper exit count value.
12	Sensors	×	×	
-	Paper guides	×	0	Clean with alcohol.



# (7) Punch unit

×/ 🛃 :	Check (Clear	n, replace, or adjust ac	ccording to necessity.)	0/ 🎦 📩	No.	: Clean	
<b>▲</b> / () :	Replace	$\triangle / \xleftarrow{\bullet \bullet \bullet}$ : Adjust		: Lubricate			

Parts work sequence	Part name	When calling	At the machine cycle	Remark
1	Punch unit	×	×	Replacement reference: Replace the unit at every 1000K.
2	Sensors	×	×	



#### (8) Paper pass unit

Inlet port rear roller

Paper exit roller

Paper exit front roller

2

3

4

O/ 🎦 🛃 🎬 😴 🚺 춛 : Clean  $\times/$   $\swarrow$  : Check (Clean, replace, or adjust according to necessity.) ▲/ ( : Replace  $\triangle / \leftarrow \bullet \rightarrow$ : Adjust ☆/ 0 💓 : Lubricate Parts work When At the Part name Remark calling machine cycle sequence Inlet port roller 0 0 1 0

0

0

0

0

0



### (9) Saddle stitch finisher



Parts work sequence	Part name	When calling	At the machine cycle	Remark
1	Transport rollers	0	0	
2	Knurling belt	×	0	
3	Discharge brush	×	×	
4	Sensors	×	×	
5	Staple unit	×	×	Replacement reference: Replace the unit at every 200K staple.
6	Staple unit (for saddle)	×	×	Replacement reference: Replace the unit at every 100K staple.
7	Staple unit	×	×	Replacement reference: Replacement is made by the user at every 5,000 pcs.
8	Staple unit (for saddle)	×	×	Replacement reference: Replacement is made by the user at every 2,000 pcs.
-	Gears	×	×	
-	Belts	×	×	
-	Paper guides	×	0	Clean with alcohol.





# (10) Punch unit

$\times/$ $\checkmark$ : Check (Clean, replace, or adjust a	according to necessity.)	0/ 🔼 🛃 🧳	: Clean
$\blacktriangle/$ : Replace $\bigtriangleup/$ $\longleftrightarrow$ : Adjust		: Lubricate	
Parts work	Whon At the		

Parts work	Part name	When	At the	Remark	
sequence		canny	machine cycle		
1	Punch unit	×	×	Replacement reference: Replace the unit at every 1000K.	
2	Sensors	×	×		



### (10) Punch unit

$\times/$ $\checkmark$ : Check (Clean, replace, or adjust a	ccording to necessity.)	O/ 🏹 🛃 🎬 豦 🌈 🥪 : Clean
$\blacktriangle/$ : Replace $\bigtriangleup/$ : Adjust		: Lubricate
Parts work	When At the	

Parts work sequence	Part name	When calling	At the machine cycle	Remark
1	Punch unit	×	×	Replacement reference: Replace the unit at every 1000K.
2	Sensors	×	×	



# [10] DISASSEMBLY AND ASSEMBLY

# 1. Disassembly of Units

### A. External view

No.	Name
1	Front cabinet upper
2	Rear upper cabinet
3	Rear cabinet
4	Left cabinet
5	Shield plate
6	Paper exit cover
7	Left cabinet upper
8	Paper exit tray
9	Upper cabinet left
10	Upper cabinet right
11	ROM cover
12	Ozone filter cover



### (1) Front cabinet upper

1) Remove the front cabinet upper.



### (2) Rear upper cabinet

1) Remove the rear upper cabinet.



### (3) Rear cabinet

1) Remove the rear cabinet.


#### (4) Rear cabinet, Shield plate

1) Remove the left cabinet.



2) Remove the shield plate.



- (5) Paper exit cover, Left cabinet upper, Paper exit tray
- 1) Remove the front cabinet upper.
- 2) Remove the paper exit cover.



3) Remove the left cabinet upper.



4) Remove the paper exit tray.



- (6) Left cabinet lower
- 1) Remove the left cabinet lower.



#### (7) Upper cabinet left, Upper cabinet right

- 1) Remove the rear cabinet upper.
- 2) Remove the RSPF unit.
- 3) Remove the table glass and the SPF glass.
- 4) Remove the paper exit cover.
- 5) Remove the upper cabinet left.



6) Remove the upper cabinet right.



#### (8) ROM cover

- 1) Remove the rear cabinet.
- 2) Open the right door, and remove the ROM cover.



#### (9) Ozone filter cover

1) Remove the ozone filter cover.



#### B. Operation panel section

 No.
 Name

 1
 Operation panel unit)



- (1) Operation panel unit
- 1) Remove the operation panel cover.



2) Remove the operation panel upper cover.



3) Slide the operation panel unit to the left, and put it down. Remove the operation panel cover.



4) Remove the operation panel lower cover.



5) Turn over the operation panel unit.



Important

Fit the flat cable edges with section s A of the Mylar, and remove slack in sections B of the flat cables.



6) Remove the clamp. Peel off the mylar and disconnect the connector.



#### Important

Fit the flat cable edges with sections A of the Mylar, and remove slack in sections B of the flat cables.



#### C. RSPF section

No.	Name
1	RSPF unit
2	RSPF paper feed tray unit
3	RSPF transport unit



#### (1) RSPF unit

- 1) Remove the two screws and remove the rear cabinet.
- 2) Loosen the screw fixing the earth cable and remove the earth cable. Then, disconnect the connector.



3) Remove the RSPF unit from the machine.



- (2) RSPF paper feed tray unit
- 1) Turn over the left upper corner of the OC mat.



2) Remove the front cabinet.





4) Disconnect the connector from the RSPF driver PWB. Remove the holder, and remove the RSPF paper feed tray unit.



# 3) Remove the RSPF transport unit.

## 

#### (3) RSPF transport unit

- 1) Remove the paper feed tray unit.
- 2) Remove the earth wire. Disconnect the connector from the RSPF driver PWB.



#### **D. Scanner section**





#### (1) Scanner unit

- 1) Remove the RSPF unit.
- 2) Remove the operation panel unit.
- 3) Remove the table glass and the SPF glass.
- 4) Remove the upper cabinet left, and the upper cabinet right.
- 5) Remove the scanner unit.



#### E. Waste toner collection section

 No.
 Name

 1
 Waste toner box



#### (1) Waste toner box

1) Open the front cabinet. Slide the lock to release it, and remove the waste toner box.



#### F. Developing section



#### (1) Developing unit

- 1) Remove the waste toner box.
- 2) Turn the lock to release, and open the drum positioning cover.



 While pressing the lever, pull out the developing unit to remove.

#### Important

When pulling out and pushing in the developing unit, put your hand beneath the unit and slide it horizontally along the guide. At the time, be careful not to touch the developing roller surface.



#### G. OPC drum section

 No.
 Name

 1
 OPC drum unit



#### (1) OPC drum unit

- 1) Remove the waste toner box.
- 2) Remove the developing unit.
- 3) While pressing the lever, pull out the OPC drum to remove.

#### Important

When pulling out and pushing in the OP C drum unit, put you r hand beneath the unit and slide it hor izontally along the guide on the right side.

At the time, be careful not to touch the OPC drum surface.



#### H. Transfer section

No.	Name
1	Primary transfer unit
2	Primary transfer cleaner unit
3	Secondary transfer unit
4	PTC unit



#### (1) Primary transfer unit

- 1) Remove the waste toner box.
- 2) Turn the lock to release, and open the drum positioning cover.



Important

Before opening the drum positioning cover, check to confirm that the transfer cam knob is at the free position.



3) Open the right door. Turn the lock to release, and pull out the primary transfer unit to remove.



When removing the primary transfer unit, be sure to open the right door in advance.

#### Important

Be careful not to put foreign materials on the primary transfer belt.



#### (2) Primary transfer cleaner unit

- 1) Remove the primary transfer unit.
- Rotate the primary transfer cleaner unit 45 degrees downward to remove.



#### (3) Secondary transfer unit

 Rotate the secondar y transfer unit a half turn upward to remove. Disconnect the connector from the right door unit.

Important

Be careful not to put foreign materials on the secondary transfer belt.

#### Important

When installing the secondary transfer unit, check to confirm that the frame projections are securely in the pressure springs on the front and the rear side.



#### (4) PTC unit

- 1) Remove the waste toner box.
- 2) Remove the PTC unit.



#### I. LSU section





#### (1) LSU

- 1) Remove the left cabinet, and the shield plate.
- 2) Remove the MFP control PWB unit.

#### Important

Since the MFP cont rol PWB and the LSU mother PWB are connected together (board to board), use care when removing and attaching them.



3) Remove the LSU mother PWB unit, and the HDD unit.



- 4) Remove the waste toner box.
- 5) Lift the LSU mother PWB unit, and remove the LSU.

#### Important

Do not touch the LSU PWB and the upper cover glass section.



Put the LSU on a flat surface. (Do not turn it over.)



#### J. Manual paper feed section

No.	Name
1	Manual paper feed tray
2	Manual paper feed unit



#### (1) Manual paper feed tray

1) Open the right door, and remove the cover.



2) Remove the cover.



3) Remove the cover.



4) Remove the cover.



5) Remove the shaft.



6) Slide the tray and remove the arm.



7) Remove the cover, and remove the manual paper feed tray.



- (2) Manual paper feed unit
- 1) Remove the manual paper feed tray.
- 2) Remove the manual paper feed unit.



#### K. Tray paper feed section

No.	Name
1	Paper feed tray
2	Tray paper feed unit



#### (1) Paper feed tray

1) Pull out the paper feed tray, and lift and remove it.



#### (2) Tray paper feed unit

- 1) Remove the paper feed tray.
- 2) Remove the right door lower.



3) Remove the paper guide.



4) Remove the tray paper feed unit.



#### L. Paper transport/Paper exit/ADU section

No.	Name
1	Paper dust removing unit
2	PS unit
3	Right door unit
4	Fusing rear unit
5	Paper exit unit



#### (1) Paper dust removing unit

- 1) Remove the waste toner box.
- 2) Remove the paper dust cleaner unit.



- (2) PS unit
- 1) Remove the waste toner box.
- 2) Remove the paper dust cleaner unit.
- 3) Remove the paper feed tray.
- 4) Remove the tray paper feed unit.
- 5) Remove the PS unit.



#### (3) Right door unit

1) Open the right door. Remove the gear, and remove the right door.



- (4) Fusing rear unit
- 1) Remove the fusing unit.
- 2) Remove the fusing rear unit.



- (5) Paper exit unit
- 1) Remove the front cabinet upper.
- 2) Remove the paper exit tray.
- 3) Remove the paper exit unit.





When connecting the paper exit unit connector, rotate the harness one turn clockwise as shown in the figure below so that the harness faces toward the arrow A, and connect the connector.

This procedure is necessary for preventing the paper exit sensor from disconnecting by contact with the harness.











#### M. Drive section

No.	Name
1	Main drive unit
2	Transport drive unit
3	Fusing drive unit
4	Paper exit drive unit



#### (1) Main drive unit

- 1) Remove the waste toner box.
- 2) Remove the developing unit.
- 3) Remove the OPC drum unit.
- 4) Remove the primary transfer unit.
- 5) Remove the rear cabinet.
- 6) Remove the main drive unit.





When the drive section is disa ssembled, apply screw lock to the following sections:

#### Front side

Apply screw lock (0.1g: about two rice grains) between the bearing and the drive frame. (4 positions)

#### Important

Be careful not to ap ply screw lock between the bearing and each DV drive shaft.



#### Rear side

Apply screw lock (0.04g: about one rice grain). (6 positions)

#### Important

Be careful not to apply screw lock to the head of the screw.



#### (2) Transport drive unit

- 1) Remove the rear cabinet.
- 2) Open the right door.
- 3) Remove the ozone filter cover.
- 4) Remove the duct.



5) Remove the transport drive unit.





When the drive section is disa ssembled, apply screw lock to the following sections:

#### Front side

Apply screw lock (0. 1g: about two rice grains) between the bearing and the transport drive frame. (4 positions)

#### Important

Be careful not to apply screw lock between the bearing and the drive shaft.



#### Rear side

Apply screw lock (0.1g: about two rice grains) between the bearing and the transport drive frame. (2 positions)

#### Important

Be careful not to apply screw lock between the bearing and the drive shaft.



#### (3) Fusing drive unit

- 1) Remove the rear cabinet upper.
- 2) Remove the rear cabinet.
- 3) Remove the ROM cover.
- 4) Remove the FAX unit.
- 5) Remove the fusing drive unit.



#### (4) Paper exit drive unit

- 1) Remove the rear cabinet upper.
- 2) Remove the rear cabinet.
- 3) Remove the ROM cover.
- 4) Remove the FAX unit.
- 5) Remove the paper exit drive unit.



#### N. Fusing section

 No.
 Name

 1
 Fusing unit



#### (1) Fusing unit

1) Open the right door. Release lock, and remove the fusing unit.



Important

When carrying the fusing unit, be sure to hold the both levers on the F and R sides of the fusing unit. If only one lever is held to carry the unit, it may be broken.

#### O. Toner supply section





#### (1) Toner cartridge

1) Open the front cabinet, and remove the toner cartridge.

#### Important

Do not install a toner cartridge of a different color. Be sure to install a toner cartridge of the same color.

#### Important

When installing, do not insert with great force.

When inserting, put your hand on it to the end until it locks securely.

#### Important

When the machine is moved with the developing unit removed, be sure to remove the toner cartridge. (If not, toner may clog.)



#### P. PWB section

No.	Name
1	SCU PWB
2	LD PWB
3	DC POWER PWB
4	High voltage PWB (TC PWB)
5	HL control PWB
6	PCU PWB
7	High voltage PWB (MC/DV PWB)
8	AC POWER PWB
9	MFP control PWB
10	LSU mother PWB
11	Driver PWB
12	Right door PWB



#### (1) SCU PWB

- 1) Remove the rear cabinet upper.
- 2) Remove the SCU PWB.



#### (2) DC POWER PWB

- 1) Remove the rear cabinet upper.
- 2) Remove the rear cabinet.
- 3) Remove the DC POWER PWB.



#### (3) High voltage PWB (TC PWB)

- 1) Remove the rear cabinet upper.
- 2) Remove the rear cabinet.
- 3) Remove the left cabinet upper.
- 4) Remove the DC POWER PWB unit.



5) Remove the high voltage PWB (TC PWB).



#### (4) HL control PWB

- 1) Remove the rear cabinet upper.
- 2) Remove the rear cabinet.
- 3) Remove the ROM cover.
- 4) Remove the DC POWER PWB unit.



5) Remove the HL control PWB.



#### (5) PCU PWB, High voltage PWB (MC/DV PWB)

- 1) Remove the rear cabinet.
- 2) Remove the PCU PWB.



- 3) Remove the left cabinet lower.
- 4) Remove the PCU PWB mounting plate.



5) Remove the high voltage PWB (MC/DV PWB).



#### Important

Section A

Install so that the left edge of the MC PWB is fitted with the rib of ozone duct cover B.





#### Section B

Be careful not to bring the back surface of the PWB into contact with the left guide which is one of the three guides in the lower side of the machine frame.



#### (6) AC POWER PWB

- 1) Remove the rear cabinet.
- 2) Remove the left cabinet lower.
- 3) Remove the AC connector plate.



4) Remove the AC POWER PWB.



#### (7) MFP control PWB

- 1) Remove the left cabinet, and the shield plate.
- 2) Remove the MFP control PWB unit.

#### Important

Since the MFP control PWB and the LSU mother PWB are connected together (board to board), use enough care when removing and attaching them.



3) Remove the MFP control PWB.



#### (8) LSU mother PWB

- 1) Remove the left cabinet, and the shield plate.
- 2) Remove the MFP control PWB unit.

#### Important

Since the MFP cont rol PWB and the LSU mother PWB are connected together (board to board), use enough care when removing and attaching them.



3) Remove the LSU mother PWB.



#### Q. Filter section



#### (1) Ozone filter

- 1) Remove the ozone filter cover.
- 2) Remove the ozone filter.



### 2. Disassembly and assembly of each unit

#### A. Operation panel section

(1) Operation panel unit

No.	Name
1	USB I/F PWB
2	LVDS PWB
3	KEY PWB
4	LCD PWB
5	Touch panel
6	HOME KEY PWB



- a. USB I/F PWB
- 1) Remove the USB I/F PWB.



- b. LVDS PWB
- 1) Disconnect the connector, and remove the LVDS PWB.



#### c. HOME KEY PWB, LCD, Touch panel

1) Disconnect the connector, and remove the HOME KEY PWB.



2) Remove the LCD holder.



3) Remove the holder, and remove the LCD.

#### Important

Use enough care not to put finger prints on the LCD surface.



4) Remove the touch panel.

#### Important

Use enough care not to put finger pr ints on the touch panel surface.



#### B. RSPF section

(1) RSPF unit

No.	Name
1	Document pickup roller
2	Paper feed roller
3	Separation roller
4	Torque limiter SPF
5	Take-up torque limiter
6	Discharge brush
7	Registration roller
8	OC mat



- a. Document pickup roller, Paper feed roller
- 1) Open the paper feed unit, and remove the cover.



2) Remove the holder, and remove the document pickup roller, and the paper feed roller.



#### b. Separation roller, Torque limiter SPF

1) Open the paper feed unit, and remove the cover.



2) Remove the holder, and remove the separation roller.



3) Remove the torque limiter SPF.



#### c. Take-up torque limiter

 Remove the one-way coup ling, the belt, and the pulley. Remove the E-ring. Pull out the shaft, and remove the bearing, the holder, and the take-up torque limiter.



#### d. Discharge brush

1) Open the document tray, and remove the discharge brush.

#### Important

When replacing the discharge brush, attach a new brush to the reference.



#### e. Registration roller

1) Open the paper feed unit, and clean the registration roller.



#### f. OC mat

1) Open the RSPF unit, and clean the OC mat.



#### (2) RSPF transport unit

No.	Name
1	Transport roller 2
2	Transport roller 3
3	Paper exit roller
4	Scan plate



#### a. Transport roller 2, Transport roller 3, Paper exit roller

1) Clean the transport roller 2, the transport roller 3, and the paper exit roller



#### b. Scan plate

1) Clean the scan plate.



#### C. Scanner section

#### (1) Scanner unit

No.	Name
1	Drive belt
2	Drive wire
3	Rails
4	Mirror
5	Reflector
6	Scanner lamp
7	Lens
8	CCD
9	Table glass
10	SPF glass
11	LED PWB
12	LED driver PWB



#### a. Drive belt, Drive wire

- 1) Remove the table glass.
- Check the tension of the drive belt and the drive wire. Check to confirm that the drive wire in the winding pulley is wound without clearance.



3) Clean the reflector, the scanner lamp, and the No. 2 mirror.



Wind the drive wire in the sequence of 1 to 7 as shown in the figure below and fix it.

When winding the drive wire around the pulley, shift the mirror unit to the vicinity of the home position, and wind 7 turns as shown in the figure, and fix the 8th turn with a screw. Then wind two turns furthermore around the pulley.



#### b. Rails

- 1) Remove the table glass.
- 2) Grease each rail.

#### Important

Be careful not to allow gre ase to come in contact with drive wires.

If grease contacts drive wires, clean wires thoroughly.



#### c. Mirror, Reflector, Scanner lamp

- 1) Remove the table glass.
- 2) Clean the No. 2 mirror, and the No. 3 mirror.





#### d. Lens, CCD

- 1) Remove the table glass.
- 2) Remove the dark box, and the cover.



3) Clean the lens, and the CCD.



#### e. Table glass, SPF glass

1) Remove the glass holder. and the table glass. Remove the table glass, and the SPF glass.



2) Clean the both surfaces of the table glass, and the SPF glass.



- f. LED PWB, LED driver PWB
- 1) Remove the table glass.
- 2) Shift the lamp unit to the notch section of the scanner base plate.



3) Turn over the sheet.

#### Important

When attaching the sheet to the origin al position, insert the Lshape sections into the inside of the metal plate and attach the center portion to the metal plate with double-stick tape.



4) Remove the lamp guid e. Disconnect the connector fr om the LED driver PWB.



5) Remove the scanner lamp, and the LED PWB. Disconnect the connector from the LED PWB.



6) Remove the harness holder, and remove the flat cable fr om the LED driver PWB. Remove the LED driver PWB.



#### **D.** Developing section

#### (1) Developing unit

No.	Name
1	Developer
2	DV seal
3	DV side seals F/R
4	Toner filter



#### a. Developer

1) Open the cover, and remove the developing unit.



2) While rotating the gear, dispose of developer.





Thoroughly clean developer unit so that no developer remains in the unit. Be careful not to scratch the MG roller.



Shutter section

3) Loading developer to the developing units.

#### Important

Be sure to shake the bag of developer thoroughly before pouring into the developing unit.

#### Important

When pouring the developer into the unit, use care to not get developer in to the drive section.



4) Install the cover.



5) Shake the developing unit se veral times horizont ally and strongly.



 Open the toner shutter of the developing unit and check to confirm that there is proper amount of developer. If not, perform procedure 5) again.



• Check that there is proper amount of developer. (The stirring screw can be partly seen.)



• There is no developer in the shutter position.



• There is too much developer. (The stirring screw cannot be seen.)





Be sure to keep the developing unit level while supplying the developer.

 Insert the developing unit so as not to give a str ong shock to the main unit.

#### Important

Slide the developing unit horizontally into the machine, in the direction of the arrow, until developing unit locks into. place. Do not push the unit diagon ally, as contact with the drum may occur causing damage.

#### Important

When removing or installing the developing unit, put your hand from below the unit and slide it in parallel along the guide. At that time, be careful not to touch the roller surface.



#### Important

When performing the above operation, there is no need to uninstall or install the OPC drum unit. If it must be uninstalled or installed for any reason, follow the procedures below. When uninstalling or installing the OPC drum unit, put your hand from below the unit and slide it in p arallel along the guide on the right side.

At that time, be careful not to touch the OPC drum surface.

- 8) Set the ADJ 1C toner density control reference value.
- b. DV seal
- 1) Remove the DV seal.

#### Important

Remove the cover with a screwdriver (-) from the rear side. At that time, be careful not to break the boss on the front side.

#### Important

When attaching the DV seal to the cover, use care and do not wrinkle the seal.



#### c. DV side seals F/R

1) Remove the DV side seals F/R.

#### Important

When replacing the toner DV side seals  $\mathsf{F}/\mathsf{R},$  attach a new one to the reference.

Important

Before attaching a new seal, be sure to remove foreign materials or remained adhesive completely from the attachment surface.



#### d. Toner filter

1) Remove the toner filter.

#### Important

When attaching the toner filter, be su re filter is completely seated.



#### E. OPC drum section

#### (1) OPC drum unit

Name
Drum
MC unit
Cleaning blade
Toner reception blade
Side seals F/R



#### a. Drum

1) Rotate the OPC drum drive gear in the arrow direction (clockwise) to release the drum shaft lock.

#### Note

When locking or releasing the lock of the drum shaft, check the direction of rotating the drum drive gear indicated on the drum holder on the rear frame side.



2) Insert a small screwdriver or a hex wrench into the hole in the shaft cover on the opposite side of the OPC drum drive gear, and push it in the arrow direction to pull out the drum shaft.



#### Note

In order to improve the image qualit y, the backlash between the OPC drum shaft and the OPC dr um is minimized in this machine. To pull out the OPC drum shaft, therefore, follow the above procedure.

#### Important

Note that conduction grease is applied to the shaft on the OPC drum drive gear side. Be careful not to att ach conduction grease to the OPC drum surface.

3) Remove the drum.



#### Important

When assembling the drum shaft, set the project ion with an opening for the drum drive gear to the position shown in the figure, and push the drum shaft inside. Then, rotate the drum drive gear in the arrow direction (counterclockwise) to lock it. Check to confirm that the projection of the drum drive gear is securely in the drum holder.



#### Important

#### Note for servicing the OPC drums

#### 1. Prevent contamination

#### Note

- Be careful not to leave fingerprints or oily dirt on the OPC drum surface. (Keep the unit away from oils and dust.)
- When replacing the OPC drum, cover the OPC drum with the protection sheet and hold the protection sheet.

If it is required to hold the OPC dr um directly, use enough care not to touch the clean ing blade are a, 5mm inside from both edges of the OPC drum. (If a fingerprint or oily dirt is attached to the cleaning blad e area of the OPC drum, the cleaning blade may flip.)

#### Countermeasures

If a fingerprint is attached to the OPC drum surface erroneously, perform the following countermeasures.

- 1) Use dry cloth to clean and remove the dirt.
- 2) Apply stearic acid powder to prevent blade flip.

#### Check method

Check to confirm that the OPC drum is free from fingerprints or oily dirt and that the cleaning blade is completely cleaned by the following method.

• Make a print of a half tone image on all the surface of A4 (11" x 8.5") paper, and check the printed paper for any abnormality in the image.

#### 2. Prior exposure prevention

#### Note

- · Avoid servicing in a place where there is strong light.
- Do not expose the unit to light for a long time.
- Cover the OPC drum with light-blocking material. (When using paper, use about 10 sheets of paper to block light.)

#### Countermeasures

If the OPC drum is erroneously exposed to light too much (prior exposure), perform the following countermeasures.

- Print half tone images on the whole surface of A4 (11" x 8.5") paper, and check to con firm that there is no irre gular density area in the previously exposed section.
- If the OPC dru m is subject to stress by being exposed to strong light, it may be recovered by leaving it in a dark and cool place.

If it may not be recovered, replace it with a new one.

#### b. MC unit

1) Remove the cover, and slide the MC unit to the rear side to remove.

Important

When replacing the MC unit, do not touch the MC grid surface.

Important

When attaching the cover, check to confirm that the seat attached to the cover is not in contact with the MC grid.

#### Important

Check to confirm that the MC grid of the MC unit is not in contact with the lens and that it is not deformed.



#### c. Cleaning blade

1) Remove the lens. Remove the cleaning blade.

#### Important

When toner is attached to the lens, wipe with dry cloth or cloth immersed in alcohol.

#### Important

Do not touch the tip of the cleaning blade.



#### d. Toner reception blade

1) Remove the toner reception blade.



When replacing the toner reception blade, attach a new one to the reference.



#### e. Side seals F/R

1) Remove the side seals F/R.

#### Important

When replacing the side seals F/R, attach the cleaning blade in advance, then attach a new seal to the reference.

#### Important

Thoroughly clean the fr ame surface of any old glue residue before attaching the new seals.



#### Important

When the OPC drum is removed, perform the following procedures.

 After removing the OPC drum, apply stea ric acid powder (UKOG-0312FCZZ) to the whole surface of the OPC drum.



2) After attaching the OPC drum to the OPC drum frame, use the black protect sheet or copy p aper, and manually r otate the OPC drum two turns in the forward direction to remove stearic acid powder applied to the OPC drum surface.



- Do not touch the OPC drum surface except for the both ends (5mm) of the OPC drum.
- Any section of the OPC drum may be touched from above the black protect sheet, but do not touch too strongly.

#### (2) MC cleaning rod



- a. Charger cleaner
- 1) Open the front cabinet, and remove the MC cleaning rod.



2) Remove the charger cleaner at the lead edge of the MC cleaning rod, and attach a new charger cleaner.



#### F. Transfer section

#### (1) Primary transfer unit

No.	Name
1	Separation pawl
2	Primary transfer belt
3	Secondary transfer drive transmission gear
4	Primary transfer belt drive roller
5	Primary transfer belt follower roller
6	Primary transfer belt tension roller
7	Registration backup roller
8	Y auxiliary roller
9	PTC backup roller
10	Primary transfer roller



#### a. Separation pawl, Primary transfer belt

1) Remove the paper guide.



After removing the paper guide, place it so that the separation pawl faces upward in order to protect the separation pawl tip from damages.

In addition, when attaching the paper guide, be careful not to damage the transfer belt by the separation pawl.



2) Remove the separation pawl from the paper guide.



- 3) Remove the primary transfer unit.
- 4) Fold the primary transfer unit, and remove the primary transfer belt.



The length of the mounting screw on the front side differs from that on the rear side. The screw on the rear side is longer than that on the front side.



- b. Secondary transfer drive transmission gear
- 1) Clean the secondary transfer driver transmission gear.



- c. Primary transfer belt drive roller, Primary transfer belt follower roller
- 1) Clean the primary transfer belt drive roller, and the primary transfer belt follower roller.



- d. Primary transfer belt tension roller, Registration backup roller
- 1) Clean the primary transfer belt tension roller, registration backup roller.



- e. Y auxiliary roller, PTC backup roller
- 1) Clean the Y auxiliary roller, and the PTC backup roller.



#### f. Primary transfer roller

 With the front section of the primary transfer unit slightly lifted, rotate the transfer lock cam knob counterclockwise so that it is at the angle shown in the figure.

With the above procedure, the primary transfer roller may be removed.



Be sure to slightly lift the front section of the primary transfer unit when rotating the transfer lock cam knob. If not, a stress is applied to the standard reflection plate lever, causing a trouble.



2) Release the lock of the bearing, and remove the bearing and the primary transfer roller.



3) With the front section of the primary transfer unit slightly lifted, return the transfer lock cam knob to the neutral angle.

#### (2) Primary transfer cleaner unit

No.	Name
1	Transfer cleaner seal F/R
2	Primary transfer belt cleaner blade
3	Primary transfer toner reception blade



#### a. Transfer cleaner seal F/R

1) Remove the transfer cleaner seal F/R.

#### Important

When replacing the transfer cleaner seals R/F, attach a new seal to the reference.

Thoroughly clean the frame surface of any old glue residue before attaching the new seals.



#### b. Primary transfer belt cleaner blade

1) Remove the primary transfer belt cleaner blade.



#### c. Primary transfer toner reception blade

1) Remove the primary transfer toner reception blade.

#### Important

When replacing the primary transfer toner reception blade, attach a new one to the reference.

Thoroughly clean the fr ame surface of any old glue residue before attaching the new seals.



#### Important

After replacement of the primary transfer belt, perform the following procedures.

 With the primary transfer cleaner unit removed, apply starting powder (UKOG-0123FCZZ) to the whole surface of the primary transfer belt.



- 2) Attach the primary transfer cleaner unit.
- 3) Manually rotate the transfer belt drive gear to remove starting powder from the primary transfer belt clearly.



#### (3) Secondary transfer unit

No.	Name
1	Secondary transfer belt follower roller
2	Secondary transfer belt
3	Secondary transfer belt drive roller
4	Secondary transfer backup roller
5	Secondary transfer belt tension roller
6	Secondary transfer roller
7	Secondary transfer drive gear



- a. Secondary transfer belt follower roller, Secondary transfer belt
- 1) Remove the spring, and separate the secondary tran sfer belt unit and the secondary transfer base unit.



#### Important

Before assembling the secondary transfer belt unit and the secondary transfer base unit, apply grease (HANAL FL-955R) to the cam and the frame of the secondary transfer base unit.

* Use care not to apply grease to the secondary transfer belt.



 Remove the holder, and remove the secondary transfer belt follower roller. Clean the secondary transfer belt follower roller.



3) Remove the secondary transfer belt.



- b. Secondary transfer belt drive roller, Secondary transfer backup roller, Secondary transfer belt tension roller
- Clean the secondary transfer belt drive roller, the secondary transfer backup roller, and the secondary transfer belt tension roller.


### c. Secondary transfer roller

1) Remove the bearing, and r emove the secondary transfer roller.



### d. Secondary transfer drive gear

 Remove the E-ring and the bearing. Slide the secondary transfer belt drive roller, and remove the parallel pin and the secondary transfer drive gear.



### (4) PTC unit

No.	Name					
1	PTC cleaner					
2	PTC wire					
3	PTC cleaner holder					



- a. PTC cleaner, PTC wire, PTC cleaner holder
- 1) Remove the PTC cleaner.

Important

Check to confirm that the P TC wire is located at the center between the PTC cleaner holder and the PTC cleaner.



2) Remove the electrode plate, and r emove the spring. Remove the electrode plate and the spring from the PTC wire.



Do not touch the wire section of the PTC wire with bare hands.



3) Remove the holder, and remove the PTC cleaner holder.



### G. LSU section

(1) LSU





- a. Dust-proof glass
- 1) Remove the waste toner box.
- 2) Remove the LSU cleaning rod from the front cabinet.



 Insert the LSU cleaning rod with the felt side dow nward, and move it back and forth several times to clean the LSU dustproof glass.



### (2) LSU cleaning rod



### a. Cleaning base

- 1) Remove the waste toner box.
- 2) Remove the LSU cleaning rod from the front cabinet.



3) Remove the cleaning base from the waste toner box, and attach it to the LSU cleaning rod.



### H. Manual paper feed section

### (1) Manual paper feed unit

No.	Name					
1	Paper feed roller					
2	Separation roller					
3	Torque limiter					
4	Transport roller 9					
5	Transport roller 10 (36cpm machine)					



- a. Paper feed roller, Separation roller, Torque limiter
- 1) Remove the cover.



2) Slide the stopper and the collar, and remove the paper feed roller.



3) Remove the separation roller, and the torque limiter.



- b. Transport roller 9
- 1) Clean the transport roller 9.



### c. Transport roller 10

1) Remove the paper guide, and clean the transport roller 10.



I. Tray paper feed section

### (1) Tray paper feed unit

No.	Name						
1	Paper pickup roller						
2	Paper feed roller						
3	Separation roller						
4	Transport roller 4						
5	Transport roller 2						
6	Torque limiter						



- a. Paper pickup roller, Paper feed roller, Separation roller
- 1) Remove the paper feed tray.
- 2) Remove the paper guide.



3) Remove the paper pickup roller, and the paper feed roller.



4) Remove the separation roller.



b. Transport roller 4

1) Clean the transport roller 4.



### c. Transport roller 2

1) Remove the E-ring and the bearing, and remove the paper feed lower PG unit.



2) Clean the transport roller 2.



- d. Torque limiter
- 1) Remove the E-ring and the bearing, and remove the paper feed lower PG unit.



 Remove the spring, and remove the reinforcement plate. Remove the spring, and the separation pressure release plate.



3) Remove the sep aration roller. Remove the E-ring, and the shaft, and remove the torque limiter.



### J. Paper transport/Paper exit/ADU section

### (1) PS unit

No.	Name					
1	Registration roller (Idle)					
2	Registration roller (Drive)					
3	Transport roller 5					



- a. Registration roller (Idle), Registration roller (Drive), Transport roller 5
- 1) Clean the registration roller (Idle), the registration roller (Drive), and the transport roller 5.



### (2) Right door unit

No.	Name					
1	Transport roller 7					
2	Transport roller 8					
3	Paper exit roller 3					
4	Paper exit roller 2					



### a. Transport roller 7, Transport roller 8

 Open the ADU open/close door, and clean the transport roller 7, and the transport roller 8.

![](_page_401_Picture_12.jpeg)

### b. Paper exit roller 3

1) Open the right door unit, and clean the paper exit roller 3.

![](_page_401_Figure_15.jpeg)

### c. Paper exit roller 2

1) Open the right door unit, and remove the cover.

![](_page_402_Figure_2.jpeg)

2) Remove the cover.

![](_page_402_Figure_4.jpeg)

3) Remove the cover, and clean the paper exit roller 2.

![](_page_402_Figure_6.jpeg)

(3) Fusing rear unit

![](_page_402_Figure_8.jpeg)

- a. Transport roller 6
- 1) Clean the transport roller 6.

![](_page_402_Figure_11.jpeg)

### (4) Paper exit unit

No.	Name					
1	Paper exit roller 1					
2	Discharge brush					

![](_page_403_Figure_2.jpeg)

- a. Paper exit roller 1
- 1) Clean the paper exit roller 1.

![](_page_403_Figure_5.jpeg)

### b. Discharge brush

1) Remove the holder.

![](_page_403_Figure_8.jpeg)

2) Remove the earth plate. Remove the discharge brush.

### Important

When replacing the discharge brush, attach a new brush to the reference.

### Important

Thoroughly clean the fr ame surface of any old glue residue before attaching the new seals.

![](_page_403_Picture_14.jpeg)

### K. Fusing section

### (1) Fusing unit

No.	Name						
1	Lower separation pawl						
2	Lower separation pawl spring						
3	Separation plate						
4	Web guide shaft						
5	Web pressure roller bearing						
6	Web pressure roller						
7	Web roller						
8	Lower thermistor						
9	Pressure roller gear						
10	Pressure roller gear bearing						
11	Pressure roller						
12	Sub thermistor						
13	Fusing roller bearing						
14	Insulation bush						
15	Heating roller bearing						
16	Meandering suppress collar						
17	Fusing roller						
18	Heating roller						
19	Fusing belt						
20	Washer						

![](_page_404_Figure_3.jpeg)

### a. Lower separation pawl, Lower separation pawl spring

1) Open the fusing rear lower PG unit, and remove the fusing cover.

### Important

When removing the fusing cover, lift the pawl section with a screwdriver (-) and remove.

![](_page_404_Picture_8.jpeg)

2) Remove the fusing rear lower PG unit.

### Important

When removing, be careful not to lose the spring.

### Important

When attaching, check to confirm that  $t \;$  he spring hook is engaged.

![](_page_404_Picture_14.jpeg)

3) Remove the fusing cover.

![](_page_405_Picture_1.jpeg)

4) Remove the lower separation pawl and the lower separation pawl spring from the paper guide.

### Important

When assembling, check to confirm that the hook of the lower separation pawl spring is engaged.

![](_page_405_Figure_5.jpeg)

### b. Separation plate

1) Remove the paper guide.

![](_page_405_Picture_8.jpeg)

![](_page_405_Picture_9.jpeg)

After installing the separation plate and the paper guide, manually move the separation plate to check the operation.

![](_page_405_Picture_11.jpeg)

2) Remove the spring, and slide it to the front side, and remove the separation plate.

### Important

Be careful not to damage or scratch the separation plate surface.

![](_page_405_Picture_15.jpeg)

3) Remove the holder, from the separation plate.

![](_page_405_Picture_17.jpeg)

- c. Web guide shaft, Web pressure roller bearing, Web pressure roller, Web roller
- 1) Disconnect the connector and remove the harness. Remove the web unit.

![](_page_406_Picture_2.jpeg)

2) Remove the holder.

### Important

When assembling, place the actuator tip on the outside of the web sheet.

![](_page_406_Picture_6.jpeg)

3) Remove the web guide shaft.

![](_page_406_Picture_8.jpeg)

4) Remove the web roller (on the winding side).

![](_page_406_Figure_10.jpeg)

5) Remove the spring and the web pressure roller bearing, and remove the web pressure roller.

![](_page_406_Picture_12.jpeg)

6) Remove the web guide shaft.

![](_page_406_Figure_14.jpeg)

7) Remove the web roller (on the feeding side).

![](_page_407_Picture_1.jpeg)

Important

After assembling the web unit, rotate the drive gear until the end position of the start mark on the web sheet comes to the pressure roller.

![](_page_407_Figure_4.jpeg)

![](_page_407_Picture_5.jpeg)

- d. Lower thermistor
- 1) Remove the paper guide.

![](_page_407_Picture_8.jpeg)

2) Disconnect the connector, and remove the mounting plate. Remove the lower thermistor from the mounting plate.

![](_page_407_Picture_10.jpeg)

- e. Pressure roller gear, Pressure roller gear bearing, Pressure roller
- 1) Remove the drive plate, and remove the gear.

![](_page_407_Picture_13.jpeg)

2) Disconnect the connector of the heater lamp. Remo ve the holder, and remove the heater lamp.

![](_page_408_Figure_1.jpeg)

3) Remove the C-ring, the pressure roller gear, and the pressure roller gear bearing.

![](_page_408_Picture_3.jpeg)

4) Remove the pressure roller.

![](_page_408_Picture_5.jpeg)

When attaching the pressure roller, attach it with the protection sheet on it. After completion of assembly, remove the protection sheet.

Important

When replacing the pressure roller, apply grease (JFE552). In addition, wipe the pressure roller surface with alcohol.

### Important

For removal of the pressure roller, remove the lower thermistor then remove the roller.

![](_page_408_Picture_11.jpeg)

### f. Sub thermistor

1) Disconnect the connector, and remove the sub thermistor.

![](_page_408_Picture_14.jpeg)

- g. Fusing roller bearing, heat-insulating bush, heating roller bearing, meandering suppress collar, fusing roller, heating roller, fusing belt
- 1) Remove the paper guide. Disconnect the connector.

![](_page_409_Picture_2.jpeg)

2) Remove the spr ing. Remove the holder, and remo ve the heater lamp.

![](_page_409_Figure_4.jpeg)

 Remove the E-ring, the gear, the fusing roller bearing, and the support plate.

![](_page_409_Figure_6.jpeg)

4) Remove the fulcrum plate, and remove the fusing belt unit.

![](_page_409_Picture_8.jpeg)

5) Remove the C-ring, the insulation bush, the washers and the heating roller bearing.

### Important

When replacing the insulation bush, apply grease (JFE552) to the inner race and the outer race.

![](_page_409_Figure_12.jpeg)

 Remove the heating roller from the frame. Remove the washer and the meandering suppress collar from the heating roller. Remove the heating roller and the fusing roller from the fusing belt.

### Important

When attaching the fusing belt, attach it with the protection sheet on it. After attaching the fusing roller bearing, remove the protection sheet.

### Important

After attaching the fusing belt, wipe the belt surface with alcohol.

![](_page_409_Figure_18.jpeg)

![](_page_410_Picture_0.jpeg)

When replacing the fusing roller, apply grease (JFE552) to the shaft section.

![](_page_410_Figure_2.jpeg)

### Important

When attaching the fusing pressure spring, perform the following procedures.

1) Slide the fusing belt unit to the front side, then to the rear side.

![](_page_410_Picture_6.jpeg)

- 2) Attach the pressure spring, and connect the fusing heater lamp connector.
- 3) Shine a light through the clearance between the rear side of the fusing unit and the frame to confirm that there is a clearance between the fusing belt and the belt guide collar.

If there is a clea rance between the fusing be It and the belt guide collar, black color on the surface of the fusing roller (F1) can be seen. It serves as a criterion of the judgment for presence of a clearance.

![](_page_410_Figure_10.jpeg)

![](_page_410_Picture_11.jpeg)

When processing the fusing unit harness, note the following. If the harness is improperly processed, short-circuit may occur. Harness A should be passed over the earth terminal.

![](_page_410_Picture_13.jpeg)

![](_page_410_Picture_14.jpeg)

### Important

For connection of the power switch connector, follow the procedures below.

Be sure to identify the colors and connecting directions of the connector and the wire.

![](_page_410_Figure_18.jpeg)

## [11] VARIOUS STORAGE DATA HANDLING

### 1. HDD/SD card memory map

### A. HDD partition

HDD size = 320GB (Actual size 289GB)

![](_page_411_Figure_4.jpeg)

### B. HDD data contents

No	File system	Stored data	NOTE
L-1	Not available		
S-1	Universal	e-manual Watermark	
I-1	Image data	Image data (ERDH/Document filing)	3000 documents,ÅA20000 images
I-2	Image data	Image data (Temporary storageÅj	1000 documentsÅA10000 images
I-3	Image data	User watermark/Stamp	1000 documentsÅA10000 images
I-4	Image data	FAX/Internet FAX receive images	3000 documentsÅA5000 images
L-2	Not available	Syatem storage data	
S-2	Universal	System storage data (for backup)	
S-3	Universal	Download font User profile User macro strage data System setting data	
S-4	Universal	System log	
S-5	Universal	Document filing (Database) Job log ÅiDatabaseÅj Job completion list	
S-6	Universal	Address book ÅiDatabaseÅj Account information ÅiDatabaseÅj Direct WEB browsing setting information OSA application cookie file	
S-7	Universal	Database file	
S-8	Universal	Spool area for printer	

![](_page_412_Picture_0.jpeg)

No	File system	Stored data	NOTE
S-9	Universal	Application work area (User file used in SMB direct print	
S-10	Universal	eOSA application file	
S-11	Universal	User file saved in the SMB server	
S-12	Universal	Data backup when installing DSK ÅiAddress bookÅAAccount informationÅj	
L-3	Not available	RAID system information	

### C. CF card partition

CF card size = 8GB (Actual size 7.8GB)

	0	100	200	300	400	500	600	700	800	900	[MB
0	[L-201] 708	OMB									
1											
2											
3											
4											
5											
6											
7	[S-201] 512	MB				[S-203] 200	MB				-
[GB]								•			

### D. CF card data contents

No.	File system	Stored data	NOTE
L-201	Universal	ICU firmware (Boot/Main)	
		Log data	
		Snapshot	
		Swap area	
	Universal	font	
6 201		web help	
5-201		spdl	
		Option FontROM	
S-203	Universal	System setting value data file	

### E. SD card partition

SD card size = 4GB (Actual size 3.6GB)

	0	100	200	300	400	500	600	700	800	900	[MB]
0	0 [L-101] 500MB					[I-101] 1GB					
1						Δ					-

[GB]

### F. SD card data contents

No.	File system	Stored data	NOTE
L-101	Not availablr	ICU (Reus) firmware (Boot/Main)	
I-101	Image data	FAX/Intermet FAX receive images ÅibackupÅj	

### 2. Necessary steps when replacing the PWB, HDD, SD Card and the CF Card

### A. MFP substrate replacement procedure (work flow)

### Important

Registered user information will not be recovered if the MFP PWB is affected by U2-05 trouble. (*1)

1) Attach the flash ROM, the memory, the EEPROM, the SD card etc. of the MFP PWB on the service parts MFP PWB and install it to the main unit.

### Important

Ground your body with grounding band during the work.

- 2) When U2 trouble occurs, use SIM16 to cancel it.
- 3) Set as follows after restarting the main unit.

At this timing, F6-21 may occur. Whether it may occur or not, go to execute procedure 1.

(1) Set the appropriate country code by Sim66-02 (clear the software switches related to FAX).

Important

Make sure to execute even if the fax option is not installed on the machine.

### B. Procedures necessary for HDD replacement

### Note for HDD replacement

- Data of the following list are saved in the HDD of the complex machine. If the HDD operates normally and data backup is possible before replacement, perform data backup and then replace the HDD.
- If the HDD does not operate normally, data cannot be backed up.
- The HDD replacement procedures with a broken HDD differs from that with a normal HDD.

### Contents of this chapter

- HDD storage data and backup
- Replacement procedures when HDD storage data can be backed up
- Replacement procedures when HDD storage data cannot be backed up due to breakdown of HDD
- Reinstall and update procedures of Operation Manual data saved in HDD
- Reinstall and update procedures of watermark data.

### (1) HDD storage data and backup

Some HDD storage data can be backed up, and some other data cannot. Some HDD storage data can be reinstalled, and some other storage data cannot.

If the HDD operates normally before replacement and data can be backed up, back up the data before replacement of the HDD referring to the HDD storage data list. Then reinstall the data after replacement of the HDD.

### a. HDD storage data list

No	Data kind	Before installation	After installation	Enable/ Disable of	Backup means	Enable/ Disable of	Data reinstall	Reinstall
	Bata Anta	from the factory)	users)	data backup	Duonup mouno	data reinstall	procedures	operator
1	e-Manual	Available	Available	Disable	*1	Enable	Sim49-3	Service
2	Address book	Not available	Available	Enable	Sim56-2 / Device cloning / Storage backup	Enable	Sim56-2 / Device cloning / Storage backup	Service
3	Image send series registration data (Sender's information, meta data, etc.)	Not available	Available	Enable	Sim56-2 / Device cloning / Storage backup	Enable	Sim56-2 / Device cloning / Storage backup	Service
4	User authentication Account management	Not available	Available	Enable	Sim56-2	Enable	Sim56-2	Service
5	Japanese FEP dictionary (Learning)	Not available	Available	Disable	Not available	Disable		-
6	Chinese FEP dictionary (Learning)	Not available	Available	Disable	Not available	Disable		-
7	JOB LOG	Not available	Available	Enable	Perform with WEB PAGE.	Disable		-
8	JOB completion list	Not available	Available	Disable	Not available	Disable		-
9	New N/A (FSS) information	Not available	Available	Disable	Not available	Disable		-
10	User font (Added)	Not available	Available	Disable	Not available	Enable	Perform with WEB PAGE.	Service or User
11	User macro	Not available	Available	Disable	Not available	Enable	Perform with WEB PAGE.	
12	Document filing	Not available	Available	Enable	Perform with WEB PAGE.	Enable	Perform with WEB PAGE.	
13	Some of system setting data	Not available	Available	Enable	Sim56-2 / Device cloning / Storage backup	Enable	Sim56-2 / Device cloning / Storage backup	Service
14	Watermark	Available	Available	Disable	*2	Enable	Sim49-5	Service
15	User color profile	Not available	Available	Disable	Not available	Enable	Perform with WEB PAGE.	Service
16	Mirroring information (When the mirroring kit is installed, the mirroring information is written.)	Not available	Available (After installation of the mirroring kit)	Disable	Not available	Enable	The mirroring information is erased by forcible build or RIB BUSTER.	Service
17	Individual setting information for direct WEB browsing	Not available	Available	Disable		Disable		Service
18	Cookie file for OSA application	Not available	Available	Disable		Disable		Service
19	eOSA application file	Not available	Installation of application	Disable		Enable	Reinstallation of application	Service
20	User file saved in the SMB server (NAS)	Not available	Available	Disable		Disable		Service

*1: The e-Manual cannot be backed up, but can be reinstalled by using Sim49-3 and USB memory.

*2: Watermark data cannot be backed up, but can be reinstalled by using Sim49-5 and USB memory.

# (2) Replacement procedures when HDD data can be backed up

### a. Work contents and procedures

	When a new HDD (blank HDD, service part) is When a used HDD					
Procedures	used, or when a HDD which	(used in the same				
1 rootaaroo	is normal but a program	model) is used *				
	error occurs in it is used.					
Step 1	Back up the HDD storage data b	efore replacement.				
	(Servicing)					
	Use SIM56-2 or the device clonin function to backup the data. (Bac	ng, or the storage backup or the data to the USB				
	memory.)					
	(Backup enable data: HDD stora	ge data list No. 2, 3, 4				
	(Address book, Image send serie	es registration data, User				
Sten 2	Back up the HDD storage data before replacement. (User					
Otop 2	or servicing)					
	Back up the data to PC with Web	page.				
	(Backup enable data: HDD stora	ge data list No. 7, 10, 14				
	(Document filing data, JOB LOG	data))				
Step 3	SIM66-62 to backup the image d	ernet Fax data, use				
	the USB memory. (The backup in	nage data are of PDF file				
	type, and cannot be restored to the machine. The backup					
	data are given to the user.)					
Step 4	Replace the HDD.					
Step 5	Boot the complex machine.	Boot the complex				
	performed.	machine.				
Step 6		The trouble code, U2-05,				
		is displayed. → Cancel				
<u> </u>		with SIM16.				
Step 7	Since a blank HDD is	Use SIM62-1 to format				
	is no need to perform					
	formatting procedure with SIM.					
Step 8	Use SIM66-10 to clear the FAX i	mage memory. The				
	memory is cleared in order to ke	ep compliance between				
	prevent malfunctions (The mem	ory must be cleared not				
	only in the FAX model but in the	scanner and the Internet				
	Fax models.)					
Step 9	Use SIM49-3 to install the manua	al data to the HDD.				
Step 10	The trouble code, U2-60, is displ	ayed. → Use SIM49-5 to				
	Install the watermark data to the	HDD. $\rightarrow$ After booting the				
Step 11	Import the data backed up in Ste	p 1.				
otop 11	Use SIM56-2, or the device cloni	ng, or the storage backup				
	to import.					
	(Import enable data: HDD storag	e data list No. 2, 3, 4				
	authentication data))	es registration data, Oser				
Step 12	Import the data backed up with the	ne Web page function in				
.	Step 2.					
	Import enable data: Document fil	ing data, User font, Use				
	Macro	ed up but cannot bo				
	imported)	ted up but carmot be				

# (3) Replacement procedures when the HDD storage data cannot be backed up due to breakdown

### a. Display when HDD breakdown

When a trouble occurs in the HDD, the error code display of E7-03 is popped up.

In this case, the main power must be turned OFF and the HDD must be replaced.

### b. Work contents and procedures

Procedures	When a new HDD (blank HDD, service part) is used, or when a HDD which is normal but a program error occurs in it is used.	When a used HDD (used in the same model) is used *		
Step 1	Install a HDD to the machine, and boot the complex machine. → Formatting is automatically performed.	Install a HDD to the machine, and boot the complex machine.		
Step 2		The trouble code, U2-05, is displayed. $\rightarrow$ Cancel with SIM16.		
Step 3	Since a blank HDD is automatically formatted, there is no need to perform formatting procedure with SIM.	Use Sim62-1 to format the HDD.		
Step 4	When there are some FAX or Int SIM66-62 to backup the image d the USB memory. (The backup in type, and cannot be restored to t data are given to the user.)	ernet Fax data, use lata from the SD card to mage data are of PDF file he machine. The backup		
Step 5	Use SIM66-10 to clear the FAX image memory. The memory is cleared in order to keep compliance between the HDD data and the image related memory and to prevent malfunctions. (The memory must be cleared not only in the FAX model but in the scanner and the Internet Fax models.)			
Step 6	Use SIM49-3 to install the manua	al data to the HDD.		
Step 7	The trouble code, U2-60, is displ install the watermark data to the machine, use SIM16 to cancel th	ayed. → Use SIM49-5 to HDD. →After booting the e "U2-60" trouble.		

With the above procedures, the HDD is reset to the state of factory shipping.

- (4) Reinstall and update procedures of the HDD storage Operation Manual data
- Obtain the Operation Manual data.
   Download the Operation Manual data (**.uar) from the utility menu on the web site (Tech-DS home page).
   Copy the downloaded file to the USB device without changing the file hierarchy.
- 2) Enter the SIM49-3 mode.

# Image: Status of the state of the state

- 3) Insert the USB memory into the machine.
  - When the USB memory is not inserted, "INSERT A STORAN-GEE-MANUAL STORED ON" is displayed. When [OK] button is pressed, the screen shifts to the folder select menu 1.
- Select the file of the Operation Manual data. (The screen shifts to the Operation Manual data install menu.)

The current version and the update version are displayed.

5) Press [EXECUTE] button.

[EXECUTE] button is highlighted, and [YES] and [NO] buttons are changed from gray-out to active display.

6) When [YES] button is pressed, the selected Operation Manual is installed.

When install is completed, "COMPLETE" is displayed. In case of an abnormality, "ERROR" is displayed.

### (5) Watermark data reinstall and update procedures

1) Obtain the watermark data.

Download the watermark data from the utility menu on the web site (Tech-DS home page).

Copy the downloaded files to the USB device without changing the file hierarchy.

### Note

When data are uploaded from the USB memory to the HDD, if there are some data in the HDD, the files in the memory are compared with the files in the HDD and only the files which satisfy the following conditions are written into the HDD.

- The file size is different.
- The time stamp is different.
- The file exists only in the USB memory.
- 2) Enter the SIM49-5 mode.

EST	N NU. 49-05			CL05
ATER MARK UPD	ATE [ /usbbd:1/ ]		 	
	<dir> FOLDERI</dir>		FILEI	
	FILE2		<dir> FOLDER2</dir>	
[	<dir> WM1</dir>	)		
				[
				I
				I

- 3) Insert the USB memory into the machine.
  - When the USB memory is not inserted, "INSERT A STORAN-GEE-MANUAL STORED ON" is displayed. When [OK] button is pressed, the screen shifts to the folder select menu 1.
- 4) Select the folder of the watermark data. (The screen shifts to the watermark data install menu.)

The current version and the update version are displayed.

- Press [EXECUTE] button.
   [EXECUTE] button is highlighted, and [YES] and [NO] buttons are changed from gray-out to active display.
- When [YES] button is pressed, the selected watermark data are installed.

When install is completed, "COMPLETE" is displayed. In case of an abnormality, "ERROR" is displayed.

![](_page_417_Picture_0.jpeg)

### C. Procedures necessary for SD card replacement

### (1) SD card data and backup

Some SD card storage data can be backed up, and some other cannot. Some SD card storage data can be reinstalled, and some other cannot. If the SD card operates normally before replacement and data can be backed up, back up the data before replacement of the SD card referring to the storage data list. Then reinstall the data after replacement of the SD card.

The SD card includes the following data.

### SD card backup

Partition number	Stored data		Enable/Disable of data backup	Backup means	Enable/Disable of data reinstall	Data reinstall procedures
L-101	ICU firmware data	ICU firmware (Boot/Main) ARM9 firmware	Disable		Enable	SIM49-1 (BOOT cannot be installed again.)
I-101	FAX reception data	FAX/Internet Fax reception image data	Enable	SIM66-62	Disable	

- 1) Use SIM56-02 to backup the SD card data to the USB memory.
- 2) When the operation panel home screen has been customized, backup the SD card data by using the device cloning function.
- 3) When there are some FAX/Internet Fax data received, use SIM66-62 to backup the image data to the USB memory in the PDF file type, and give the PDF file to the user. (The data cannot be restored to the machine.)
- 4) Replace the SD card with a new one.
- 5) Upgrade the firmware to the latest version.
- Use SIM66-10 to clear the image send memory. (This is in order to obtain consistency between the HDD data and the image related memory.)
- 7) Use SIM56-02 to restore the data backed up in procedure 1).
- 8) Restore the data backed up in procedure 2) by using the device cloning function.

![](_page_417_Picture_15.jpeg)

When replacing the SD card, be sure to use only the specified SD card supplied as a service part.

The firmware required for booting must be included in the SD card used in this machine. The commercially available SD cards have no such data.

![](_page_417_Picture_18.jpeg)

When U2-40 error occurs, if the error cannot be canceled by SIM16, or when E7-07 error occurs, there may be some trouble in the SD card.

Important

The data backed up with SIM56-2 must not be installed to another machine. If installed, the adjustment data will be overwritten and a trouble may be generated.

### A

### D. Procedures necessary for CF card replacement

Some CF card storage data can be backed up, and some other cannot. Some CF card storage data can be reinstalled, and some other cannot. If the CF card operates normally before replacement and data can be backed up, back up the data before replacement of the CF card referring to the storage data list. Then reinstall the data after replacement of the CF card.

### CF card backup

No.	File	Stored data	NOTE
	system		
L-201	Universal	ICU firmware (Boot/Main) Log data Snapshot Swap area	
S-201	Universal	font web help spdl Option FontROM	
S-203	Universal	System setting value data file	

 Use SIM56-2 to back up the CF card data to the USB flash drive.

- 2) Back up the CF card data by the device cloning function when the operation panel screen is customized..
- 3) Replace the CF card with a new one.
- 4) Upgrade the firmware to the latest version.
- 5) Use SIM56-02 to restore the data backed up in procedure 1).
- Restore the data backed up in procedure 2) by using the device cloning function.

![](_page_418_Picture_0.jpeg)

### 3. Necessary procedure and notes for replacement of the mirroring kit HDD

### NOTE:

### Terminology and contents

Mirroring information: When the mirroring kit is installed and the power is turned ON, the mirroring information is written into the L-2 partition of the both HDD's.

Rebuilding: Copying operation of the whole contents of one HDD to the other HDD.

Forcible rebuilding: Erasing the mirroring information in the HDD and rewriting new information.

When the mirroring kit is installed, the two HDD's are named HDD1 and HDD2.

HDD1: Mirroring kit HDD

HDD2: Standard HDD for the machine

The status of each HDD can be checked with SIM62-20.

### **Outline / Description Items**

Kinds of errors and remedies	A. Causes and remedies when the icon of HDD trouble is displayed
	B. Causes and remedies when the E7-03 error display is popped up
Specified remedies for each error	C. Replacement procedures of the HDD of the mirroring kit or that of the machine
(Details of remedies and procedures)	D. Replacement procedures of both of the HDD of the mirroring kit and that of the machine
	E. Note for reuse of HDD

### Mirroring kit status and status icons

When the mirroring kit is installed, one of the following icons is displayed on the operation panel.

lcon	Mirroring kit status
	Mirroring kit installed
	Mirroring kit/HDD trouble
	Mirroring kit/Rebuilding

### A. Causes and remedies when the icon of HDD trouble is displayed

(When the icon shown below is displayed)

![](_page_418_Figure_18.jpeg)

1) When one HDD goes into trouble, the UI icon which indicates HDD trouble of the mirroring kit is displayed.

 Use SIM62-20 to check the HDD status, and refer to the table below to confirm the relation between the HDD status and the remedy. SIM62-20 status and causes of troubles (When the icon of HDD trouble is displayed)

			HDD2					
		OK	NONE	REBUILDING	ERROR	TROUBLE		
HDD1	OK	-	A	-	A	A		
	NONE	A	-	-	-	-		
	REBUILDING	-	-	-	-	-		
	ERROR	A	-	-	-	-		
	TROUBLE	А	-	-	-	-		

3) Refer to the table below and check to confirm the remedy.

Table: Causes of troubles and remedies when the icon of HDD trouble is displayed

Case	State	Cause	Remedy
A	One HDD status is OK. The other HDD status is other than OK.	<ul> <li>The HDD which indicates the status other than OK is in trouble.</li> <li>Connection failure of the connectors and harness of the mirroring kit</li> </ul>	<ul> <li>Replace the HDD. (Perform "C. Replacement procedures of the HDD of the mirroring kit or that of the machine")</li> <li>Replace the mirroring kit. (Perform "C. Replacement procedures of the HDD of the mirroring kit or that of the machine")</li> </ul>

4) Refer to the details of the remedy and perform the necessary procedures.

# **1**: '14/Jun

![](_page_419_Picture_1.jpeg)

### **B**. Causes and remedies when the E7-03 error display is displayed

 Use SIM62-20 to check the HDD status, and refer to the table below to confirm the relation between the HDD status and the remedy. Refer to the table of "Causes of troubles and remedies when the E7-03 error occurs" and perform the necessary procedures. Backup the data from the HDD without trouble first.

### SIM62-20 status and causes of troubles

				HDD2		
		OK	NONE	REBUILDING	ERROR	TROUBLE
HDD1	OK	В	B or C	В	В	В
	NONE	B or C	С	С	С	С
	REBUILDING	В	С	F	F	F
	ERROR	В	С	F	F	F
	TROUBLE	В	С	F	F	D or E

2) Refer to the table below, and check to confirm the remedy.

### Causes of troubles and remedies when the E7-03 error occurs

Case	State	Cause	Remedy
В	When at least one HDD is OK.	<ul> <li>Communication trouble through the SATA harness of HDD.</li> <li>Trouble of HDD which indicates the status other than OK.</li> <li>Broken data in HDD</li> <li>The mirroring side HDD is normal. The machine side HDD is in trouble or rebuild operation is not completed.</li> <li>RAID PWB trouble</li> </ul>	<ul> <li>Replace the cable. Remove and connect.</li> <li>Replace the HDD which indicates other than OK. (Perform procedures of "C. Replacement procedures of the HDD of the mirroring kit or that of the machine.")</li> <li>Replace both of the HDD's of the mirroring kit and that of the machine. (Perform procedures of "D. Replacement procedures of both of the HDD of the mirroring kit and that of the machine.")</li> </ul>
С	When at least one HDD is NONE.	<ul> <li>Communication trouble through the SATA harness of HDD.</li> <li>Connection failure between the RAID PWB and the HDD.</li> <li>HDD trouble</li> <li>HDD SATA harness and connector trouble</li> <li>Both the mirroring side HDD and the machine side HDD are in trouble.</li> <li>RAID PWB trouble</li> </ul>	<ul> <li>Replace the cable. Remove and connect.</li> <li>Check connection between the mirroring kit and the HDD.</li> <li>Replace the HDD which indicates NONE. (Perform procedures of "C. Replacement procedures of the HDD of the mirroring kit or that of the machine.")</li> <li>Replace the mirroring kit. (Perform procedures of "C. Replacement procedures of the HDD of the mirroring kit or that of the machine.")</li> <li>Replace both of the HDD's of the mirroring kit and that of the machine. (Perform procedures of "D. Replacement procedures of both of the HDD of the mirroring kit and that of the machine. (Perform procedures of "D. Replacement procedures of both of the HDD of the mirroring kit and that of the machine.")</li> </ul>
D	When in TROUBLE- TROUBLE.	<ul> <li>RAID PWB trouble</li> <li>(Both or one) HDD trouble</li> <li>Raid PWB is in trouble. The mirroring side HDD is normal. The machine side HDD is other than OK.</li> </ul>	<ul> <li>Replace the mirroring kit. (Perform procedures of "C. Replacement procedures of the HDD of the mirroring kit or that of the machine.")</li> <li>Replace both of the HDD's of the mirroring kit and that of the machine. (Perform procedures of "D. Replacement procedures of both of the HDD of the mirroring kit and that of the machine.")</li> </ul>
E	When in TROUBLE- TROUBLE. (Occurring when replacing the HDD)	<ul> <li>The mirroring kit is composed of HDD's which have different mirroring information each other.</li> <li>(A HDD which has been used in the mirroring kit of another machine is used.)</li> </ul>	<ul> <li>Replace both of the HDD's of the mirroring kit and that of the machine. (Perform procedures of "D. Replacement procedures of both of the HDD of the mirroring kit and that of the machine.")</li> </ul>

Refer to the details of the remedy and perform the necessary procedures.
 Causes and remedies when cases B, C, D, and E are not applicable

Case	State	Cause	Remedy
F	Other than cases B, C, D,	<ul> <li>RAID PWB trouble</li> </ul>	- Replace the mirroring kit. (Perform procedures of
	and E	- Both HDD's trouble	<ul> <li>"C. Replacement procedures of the HDD of the mirroring kit or that of the machine.")</li> <li>Replace both of the HDD's of the mirroring kit and that of the machine. (Perform procedures of "D. Replacement procedures of both of the HDD of the mirroring kit and that of the machine.")</li> </ul>

### 14/Jun

### C. Replacement procedures of the HDD of the mirroring kit or that of the machine (Details of the remedies and the procedures)

- When replacing the mirroring kit, follow the replacement procedures of the HDD of the mirroring kit only.

### (1) Work contents and procedures

### Data backup

### NOTE:

When E7-03 error code is displayed, procedures of Step 1 and Step 2 are nor required.

Step 1	Back up the data in the HDD before replacement. (By servicing) Use SIM56-2, the device cloning, or the storage backup function to save the data. (Back up the data to the PC or a USB memory.) (Data which can be backed up: Address book data, image send registration data, user authentication data)
Step 2	Back up the data in the HDD before replacement. (By the user or by servicing) Back up the data to the PC by Web page. (Data which can be backed up: Document filing data, JOB log data)
Step 3	When there is some received data of FAX and Inter- net FAX, use SIM66-62 to back up the image data from the SD card to a USB memory. (The backed up image data are in the PDF file type and cannot be returned to the machine.) Give the backed up data to the use.

### HDD replacement procedures

Proce-	Procedure
aure	
Condition	When a new HDD (blank)(*1) (service part) is used.
Step 4	If HDD1 is in trouble, replace the HDD of the mirror-
	ing kit. If HDD2 is in trouble, replace the HDD of the
	machine. (*2)
Step 5	Boot the machine.
	→Rebuilding is automatically executed.
	→Check to confirm that E7-03 error (HDD trouble)
	does not occur, and that the UI icon which indicates
	rebuilding of the mirroring kit is displayed. Use SIM
	62-20 to confirm that the status of the replaced HDD
	is displayed as REBUILDING.
Step 6	It takes about one hour to complete rebuilding.
Step 7	Check to confirm that the UI icon which indicated
	installation of the mirroring unit is displayed. Use
	SIM62-20 to confirm that the HDD status is dis-
	played as HDD1/HDD2=OK/OK.

 Replacement procedures of both of the HDD of the mirroring kit and that of the machine (Details of the remedies and the procedures)

### (1) Work contents and procedures

Data backup

Step 1	When there is some received data of FAX and Internet FAX, use SIM66-62 to back up the image data from
	the SD card to a USB memory. (The backed up image
	data are in the PDF file type and cannot be returned to
	the machine.) Give the backed up data to the use.

HDD replac	ement procedures
Proce- dure	Procedure
Condition	When two new HDD's (blank)(*1) (service part) are used for the both.
Step 2	Replace the both HDD's (as well as the RAID PWB if necessary). (*2)
Step 3	Set DIPSW2 of the mirror- ing kit to ON, and turn on the main power of the machine. → Forcible rebuilding is executed. → Check to confirm that the E7-03 error (HDD trouble) does not occur and that the UI icon which indicates installation of the mirroring kit is displayed. Use SIM62-20 to confirm that the HDD status is displayed as HDD1/HDD2=OK/OK.
Step 4	Turn OFF the main power of the machine, and setONDIPSW2 to OFF. Then, turn ON the main power of the machine again.OFF
Step 5	Use SIM66-10 to clear the FAX image memory. The memory is cleared in order to ensure consistency between the HDD data and the image memory and to prevent against malfunctions. (Not only the FAX model, but also the scanner and the Internet FAX models require memory clearing.)
Step 6	Use SIM49-3 to install the e-Operation Manual data to the HDD.
Step 7	The trouble code "U2-60" is displayed. → Use SIM49-5 to install the watermark data to the HDD. → Use SIM16 to cancel the U2-60 error.

### E. Note for reuse of HDD

When replacing the HDD for the mirroring kit, be sure to use a new HDD.

If a HDD which has been used in a mirroring kit is used for replacing the HDD, the operations and the data cannot be assured.

If a HDD which has been used in a mirroring kit is installed, the original data may be erased.

If, however, the mirroring information of the HDD is erased by RIB Buster as described later, it can be used. (*1) In addition, if the both HDD's are replaced with HDD's which have been used, SIIM62-1 must be executed to format HDD's in addition to erasing the mirroring information.

When removing the HDD after installing the mirroring kit, be sure to remove the both HDD's together.

If only one HDD is removed then it is reinstalled, the data of both HDD's may not be identical, causing an error.

When removing the HDD and performing some work, first disconnect the HDD SATA connector of the MFP PWB and perform the work.

With the above procedure, the both HDD's are brought into the status disconnected from the machine.

Put mark on the mirroring kit HDD and the machine HDD to indicate that they have been used. (*2)

- *1: Refer to "5-C. Deleting the HDD mirroring information."
- *2: Refer to "5-B. How to check the usage history of a HDD in a mirroring kit."

### 4. Note for installing and repairing the mirroring kit

When installing or repairing the mirroring kit, fully understand the following descriptions to avoid erroneous handling and procedures. When a HDD which has once been used for the mirroring kit is reused without proper preparation, it may cause an error and destruction of user data, or other troubles.

The following three cases must be strictly avoided.

*When newly installing a mirroring kit, do not use one which has been once used.

*When replacing the HDD because of a HDD trouble, do not replace it with a HDD which has been once used in a mirroring kit.

*When replacing the HDD because of a HDD trouble in the machine, do not replace it with a HDD which has been once used in a mirroring kit.

### Note

When a HDD is once used in a mirroring kit, the mirroring information is written into the HDD. This causes a trouble by erroneous using.

The details of inhibited items, results of erroneous procedures, and precautions for avoiding those errors are described below.

### A. Details of inhibited items

### (1) When newly installing a mirroring kit, do not use one which has been once used.

### **Trouble contents**

If HDD1 which has been once used is used for new installation of a mirroring kit, the data in HDD1 will be written into HDD2. This causes erasion of the original user data, freeze of the machine, or other troubles. The "HDD which has been once used" includes a HDD which was just installed and conducted only.

![](_page_421_Figure_13.jpeg)

### Countermeasures

Use a new mirroring kit for installation.

If there is no choice but to use a mirroring kit which has been once used, be sure to erase the mirroring information in the HDD before installation. (For details, refer to "5-C. Deleting the HDD mirroring information.")

# (2) When replacing the HDD in case of a trouble in the HDD, do not use a HDD which has been used in another mirroring kit of another machine.

### **Trouble contents**

If a HDD which has been used in another mirroring kit, the RAID controller cannot recognize the HDD, causing E7-03 error, and the necessary data may be destructed in some cases.

![](_page_422_Figure_3.jpeg)

### Countermeasures

Use a new mirroring kit for installation.

If there is no choice but to use a mirroring kit which has been once used, be sure to erase the mirroring information in the HDD before installation. (For details, refer to "5-C. Deleting the HDD mirroring information.")

# (3) When the HDD is replaced because of a HDD trouble, do not use a HDD which has been used in a mirroring kit of another machine.

### **Trouble contents**

E7-A5 error occurs. If a HDD which has been used in a mirroring kit is used as the machine HDD, the machine does not operate normally. In this case, the trouble of erasing the original data is avoided.

![](_page_423_Figure_3.jpeg)

### Countermeasures

Use a new mirroring kit for installation.

If there is no choice but to use a mirroring kit which has been once used, be sure to erase the mirroring information in the HDD before installation. (For details, refer to "5-C. Deleting the HDD mirroring information.")

When a HDD is used without any other HDD, the mirroring information must be erased before executing SIM62-1 to format.

This procedure allows the HDD being treated as a new HDD.

When removing the HDD after installation of the mirroring kit, remove both HDD's simultaneously. If only one HDD is removed and then installed again, the data of both HDD's may not match, causing a trouble.

[Simultaneous removal of both HDD's] Disconnect the HDD SATA connector of the MFP PWB, and both HDD's are brought into disconnected state from the machine.

# B. How to check the usage history of a HDD in a mirroring kit

As stated before, when installing a mirroring kit or replacing a HDD, be sure to check the usage history of a HDD or a mirroring kit which is to be used.

For convenience of checking the usage history, put a mark on the mirroring kit HDD and the machine HDD when installing them to indicate that they have been used.

![](_page_424_Picture_3.jpeg)

### C. Deleting the HDD mirroring information

Be deleting the HDD mirroring information, the HDD can be used under the mirroring kit environment.

### (1) Necessary tools

- RIB Buster software
  - The software is composed of the following two files. (They can be downloaded from Tech DS Web site.)
  - RIB Buster{YYYYMMDD}.exe
  - Setup.ini
- Commercially aD case unitvailable USB HD (SATA support)

![](_page_424_Picture_12.jpeg)

- USB cable
- Windows PC

(Support OS: Windows XP, Windows VISTA, Windows 7 (32/ 64bit)

### (2) Procedures

 Assemble the HDD (the mirroring information of which is to be deleted) to the USB HDD case unit (SATA support), and connect the USB cable.

![](_page_424_Picture_18.jpeg)

### Important

When removing or attaching a HDD to the HDD case, be sure to disconnect the USB cable from the PC in advance.

If this precaution is ignored, the HDD may be damaged.

- Copy the RIB Buster software files (RIB Buster {YYYYM-MDD}.exe and Setup.ini) to a same directory of the PC.
  - RIB Buster{YYYYMMDD}.exe
  - Setup.ini
- Connect the PC and the USB HDD case unit assembled in procedure 1) with the USB cable.

![](_page_424_Picture_26.jpeg)

4) Double-click RIB Buster {YYYYMMDD}.exe to boot the RIB Buster software.

If the user account control is ON in VISTA or Windows 7 setting, the user account control menu is displayed. Click [Allow] on this menu.

Main Pr	ogram	
	Result:	

5) Select the target HDD to delete the mirroring information.

![](_page_424_Picture_31.jpeg)

### 6) Click [Clear RIB in HDD] button.

![](_page_425_Picture_1.jpeg)

7) Click [OK] button. (The mirroring information is deleted.)

RIB Clear	×
ОК.	
RIB was cleared.	
ОК	

 After completion of deleting the mirroring information, "OK" is displayed.

![](_page_425_Picture_5.jpeg)

# (3) Kinds of errors, causes and remedies Phenomenon 1

An error indicating an abnormality in the Setup.ini file when booting the RIB Buster software.

Cause	Setup.ini file does not exists, or there is any abnormality in the file.
Countermeasures	Check to confirm that there is Setup.ini file in the proper directory and that there is no abnormality in the descriptions.

![](_page_425_Picture_9.jpeg)

### Phenomenon 2

The mirroring information has not been deleted normally.

Cause	Temporary communication trouble, cable or other device trouble, HDD trouble
Countermeasures	<ol> <li>Click [Clear RIB in HDD] button again.</li> <li>If the trouble is not solved by procedure 1., disconnect and connect the cable, change the devices, and reboot the RIB Buster. Then execute procedure 1</li> </ol>

RIB Clear Error	X
ERROR!	
RIB was not cleared!	
ОК	

Main Pr	ogram	
	Clear RIB in HDD!	
	Result: NG	

×

### Phenomenon 3

RIB Bust

Though the target HDD is connected, it is not displayed.

Cause	The target HDD is not registered in the Setup.ini file. Cable or other device trouble, HDD trouble
Countermeasures	<ol> <li>Reboot RIB Buster, and click the frame section.</li> <li>If the trouble is not solved by procedure 1., replace the Setup. ini file and the RIB Buster {YYYYMMDD} with the latest version, and execute procedure 1</li> <li>If the trouble is not solved by procedure 2., disconnect and connect the cable, change the devices, and reboot the RIB Buster. Then execute procedure 1</li> </ol>

Main P	rogram		
	Clear RIB if	(HDD)	
	Result:		

# [12] SERVICE WEB PAGE

### 1. General

The following functions are available on the Hidden Web Page exclusively used for the serviceman.

	Menu/Item	Function and content			
Output of Te	est Page	Used to print out the test page (system setting contents).			
Font/Form	Download	Used to download Font/Form.			
		Font/Form of PCL and PostScript, macro, and other resources are downloaded to the HDD and controlled. (PS, PCL5 only)			
Device Cloning		Used to import/export the system setting information in XML format. By importing the export file to the other device, the setting values and setting contents of the device can be copied to another device. This function is useful to set the same setting to two or more machines efficiently.			
Filing Data Backup		Used to import/export the document filing data in the unit of folder.			
User Control		Used to shift to the user mode. After log in, the screen is shifted to the setting screen of user management.			
User Control 2		Used to set the Pages Limit Group and the Favorite Operation Group by authority of the serviceman.			
		(Select among preset items.)			
Job Log	Save Job Log	Used to save the Job Log.			
	View Job Log	Used to display the Job Log.			
Update of F	irmware	Used to update the firmware version.			
Syslog*1	Administration Settings	Used to set the Log Type. (Set to the default.)			
	Storage/Send Settings	Keep all the items selected.			
	Save/ Delete Syslog	Used to save or delete the log data.			
	View Syslog	Used to display the log data.			

*1: This may be useful for troubleshooting when a trouble occurs. When submission of the log data file is requested in order to troubleshoot, use the log file save mode to export the log data file to the client PC.

### 2. Details and operation procedures

# A. Procedures to enter the Hidden Web page exclusively used for the serviceman

- 1) Boot a browser program.
- 2) Enter the specified

URL (http://xxx.xxx.xxx/service_login.html) and enter the servicing page menu.

Default password: "service"

![](_page_426_Picture_11.jpeg)

### B. Output of Test Page

Comparisonal	Nobill-4-1-1 EWedan EWedan Reis	Ervers Companya-tu-t . 614	
SHARP MX-XXXX	Output of Test Page		tion Name Series 199
Dated of Sold Page	Educt a bult page to be potted		
Family and Deserved	System Settings > Data List Print		
Dated Posts Datings			
Denie Chines	All Custom Setting Last	Post(C)	
Pang Date Derive	Frank Test Page	No fermiliarity of	
Pattern Salting		(Pred)	
Use Certe		775.1.1.1	
Ine Central 2	Darsting Address List	Companying Lines	
Dell Leg		(Predits)	
Lipitete at Parenare	Decompet Eliza Sublection	CHICKNEY .	
Dreng .	contract and the first	(1990)	
	Syntom Lettings + List + Report Print		
	Announce Setup Lie	Curr M FreeD	
	Image Sanding Activity Report	Image Sanding Actualy Report (Scan)	
	Ties Parametrowed Lat	Decoret Addres Lat 18	
	tion Sattings Ltd	(Posts)	
	Brings strangers in an		

 Click "Print" button of an item or report to be printed. When there is a list of items for selection, select one of the items in the pull-down menu list, and click "Print" button. The list is printed out.

### C. Font/Form Download

C 1999 1470148	1)118-07-7 @wedae	C Wednes Badle CT	VORA Come Solfiets-Pu-1		
SHARP MX-XXXX	Fant/Farm Down	foad			tion Name Series (Input))
	( Darrett   Uption)	<u>u,</u>			
Total of Text Page Tangit and Download	Resource List		(Dooth M		
Senia Cherry Reg Dan Bartury	-	( Agrie	10 A		
National Salary Rel Cartol 2	Rans	1214	Researce Type Restaurce Application Profilespitester Restaurce Researce		
nd Log Spillel of Pyroneth Looky					
	Resource Download	0			
	Reserve Type Safert File Desrive(M)			(MC)(4 to 200 (hearthest	
	[54-824] (\$56-9	0			Back to the Tap on The Page 1

### (1) Download of Font, Form, and Macro

- Select "Resource Type" from the pull-down menu list. (Example: PCL/PostScript Font/Form or Macro)
- 2) Click "Refer" button to select a target file.
- 3) Click "Download" button.
- 4) Click "Submit" (registration) button.
  - The file is downloaded to the HDD.

The list of the downloaded files and the use percentage of the HDD are displayed.

### (2) Delete of downloaded font (Procedures to delete a file separately)

- Select a file to be deleted from the list of the downloaded files, and click "Delete" button.
- Check that the confirmation message is displayed, and press Yes key.
- Click "Submit" (registration) button. The file in the HDD is deleted.
- (3) Procedures to delete all the files at a time
- 1) Click "Initialize" button.
- 2) Check that the confirmation message is displayed, and press OK key.
- 3) Click "Submit" (registration) button.

### Note

By the Write-Protect Setting function, the downloaded files can be set to write protect.

### **D. Device Cloning**

PECOLOGIA AD Mary COUNTS A REA	having during choice html			Q /71 m
SHARE HATKOVAR	()+58-44-9 🜒 Wednes 🌒 Wednes Neda 🌒 10-500KK 🗉	ENAR 電子証明書ホームページ	* 9	
SHARP				User Name: Service Lopout(L)
MX-XXXX	Device Cloning			
Output of Text Page	Funant Sattions			
Ford Farm Download				
Colored Double Colorest	System Settings			
Contra a contra de	Default Settings			
Cance Crewel	Tray Settings			
Filing Data Backup	Printer Condition Settings			
Passward Setting	User Control			
User Control	Energy Save			
User Control 2	Coperation Settings			
395 LAg	Device Control			
United of Farmers	Copy Sattings			
for the second se	Printer Settings			
al tool	Image send Setting > Operation Setting			
	Scan Sattings			
	Document Filing Settings			
	Security Settings			
	Web Settings			
	Network Settings			
	Application Gettings (Excluding Pre-Get Text/Forward Tabl	H)		
	C-mail Alert and Status			
	Port Control/ Filter Settings			
	Custom Link Setting			
	Select AI(S) Clear Checked(Z)			
	Password	10.00 (mile)		
	Executa(J)	for its indext		
	Stere Current Configuration:	Execute(J)		
	Import Settings			
	Import settings from tile:	-	The to 200 characteral	
	Password.	IS IS don't	Comments - 100 Contents	
	Execute (C)			
				Back to the Top on This Dans &

### (1) Export

- 1) Select an item to be backed up.
- 2) Click "Execute" button.
  - Specify the save position of the file, and save the file. (File name: *****.bin)

When the password is set, the set password must be entered when importing.

### (2) Import

- Import from a file: Click "Refer" button to select the back-up file. (File name: *****.bin)
- Click "Execute" button to execute import. If the password is set when exporting, the password must be entered.
- 3) Reboot the machine.

### E. Filing Data Backup

	Article Comme Contra and	Cronts Com fellafte-Pe->		
SHARP MX-XXXX	Filing Data Backup			User Name Serica (Lingmill)
Did of Sect Page	Export Settings			
eff yn Doelloel gal Feide Satrope Rie Openg	Indee Display land	All Fallers		
ng Data Bachup Ideated Satting at Classed	Folder Rase: 4 7 CMain Folder Elboox Fair Folder Tata Folder 2	Nor Name & T		n. 11
itag Site offerences	1/1 Seet AKS [ Dee Overlek]] Encode(3)			
	Import Sattings			
	Import settings from the Energiable		(897 Cont 20 (tester)	
	[ thready ]			Back to the Top on The Page

### (1) Export

1) Select the folder to be backed up.

The list display conditions can be specified by changing the index and the number of display items on the pull-down menu.

2) Click "Execute" button.

Specify the save position of the file, and save the file. (File name: *****.bin)

3) Click "Update" button.

### (2) Import

- 1) Click "Refer" button to select a target file. (File name: *****.bin)
- 2) Click "Execute" button.
- The target file is imported.
- 3) Click "Update" button.

### F. User Control 1

![](_page_428_Picture_1.jpeg)

1) Enter the password to log in.

Default Password: admin

The screen is shifted to the setting menu of user management.

G. User Control 2

# 

 Select the Pages Limit Group and the Favorite Operation Group. (The Pages Limit Group and the Favorite Operation Group must be set in advance.)

### (Example of use)

The use sets the conditions for servicing work by using the Pages Limit Group and the Favorite Operation Group functions in advance, and the serviceman selects the set conditions in this mode for servicing work.

### H. Job Log

### (1) Save Job Log

![](_page_428_Picture_12.jpeg)

 Click "Save" button, and specify the save position of the Job Log to save it. (2) View Job Log

AD THE AD A DIA OF A DIA DE	server about precident	
Gianna hezioleath-	(2+38-2/C-2) el Windows el Windows Med	er Chinaith Cheve Attender-Pic-h A.
CHADD	1	Iber Nove Series Linevilla
SHARP	Manu Jab Law	
MX-XXXX	view Job Log	
Iput of Test Page	Select Rem	
#Form Download		
put Profile Settings	El Anti D	
nce Claning	- Jub Mode	
ng Data Backup	Computer Name	
savered Setting	El User Name	
er Control	C Login Name	
er Centrol 2	Date	Starting Date & Time/Completing Date & Time Starts & Makes Time/Completing Date & Time
Log	[2] Total Court	Tetal Court
Save Jub Log	Count according to size	
tate of Fernware	Number of sheets according to size	
all the second se	E Invalid Paper Count	Elack & White Invald Paper Colour Invald Paper
	El Danas	Number of Reserved Corrolated Pages
	PRess	
	Enter Cause	
	Print Job Related Itern:	E Ovtput
		E Staple
		Staple Count
		Plunch Count
		EFeld
		EProid Court
		E Prister land
	Image Send Related Item:	E Address
		Sander Name
		Sterder Address
		Transmission Type
		E Administrative Senai Number
		P Fetry order
		EFfe Type
		Compression Mode/Compression Ratio
		Communication Time
		ET at No.
	Document Filing Related Item:	EDocument Filing
		EStoring Mode
		E ror name
	Annual	
	Common Functionality.	Cooperating
		E Special modes
	Datalled Bases	The second s
	and a second second	Colonal Type
		E Paper Sca
		⊡Paper Type
		Paper Property Disable Duplex
		Paper Property Fixed Paper Side
		Paper Property Sisable Staple
		Paper Property: Disable Punch
		E Duplies Service
	10.000 B	
	PARTICULE REVIL	Et Moost Name
		ENarra
		EMachine Location
	Select AI(S) Clear Checked(2)	
	[Show(6)]	
		Burlets the Top on This Date
		Deck to the report this Page

- Select a Jog Log item to be displayed. (In the default setting, all the items are selected. Remove check marks of the items which are not to be displayed.)
- Click "Show" (display) button. The Jog Log is displayed.

### I. Update of Firmware

![](_page_428_Picture_19.jpeg)

- 1) Click "Refer" button to select a firmware file.
- After selecting a firmware file, click "Execute" button. The firmware data are sent to the machine, and update of the firmware is processed.

During the process, the message of "Firmware Update, now processing..." is displayed.

### J. Syslog

There are following functions in the Syslog mode.

This function is provided to acquire the detailed Syslog to troubleshoot when a trouble occurs.

When submission of the log data file is requested for troubleshooting, use the log file save mode to export the log data file to the client PC.

Syslog	Administration Settings	Log Type Setting (Set to the default.)
	Storage/Send Settings	Set all the items selected.
	Save/ Delete Syslog	Log data save, delete
	View Syslog	Log data display

SHARP	Administration Settings			inar Nation Tarrito Linguidi 1
IIIA AAAAA	Subretta Unionalla			
Dated of Text Page	Broka	tran .		
Family and Document	Log Type Setting		_	
Danta Dorng	Automation Type	4 samply sufferenties manager (security)	-	
FingDateMarke	Decarty .	12 security/suffernation messages (security?)		
Partness Satisfy	Notine	15 book use 8 books		
the Course	Module 7.	117 band one 5 decatts	-	
User Control 2	Module2	10 key al ann 2 (sec al.)		
and I am	Mukaki	19 local area 3 docality		
per per	Municipal	20 bits of some & Decision	-	
Course of Fernane	Manual .	(2) hand see 6 handlik		
Parent .	Module.	22 bit of some if (balanti)		
A Barage Gard Settings	the second secon	(2) hered unit 7 (hered?)	-	
a Sami Paleta Synta	Typhate	3 spring damage builting		
a vise Systep	Report.	A system damage (builders)		
				duct in the Tay or Dis Page &
	Subvit() [ \size(h) ]			

(1) Administration Settings/ Log Type Setting Set to the default.

SHARP	an a			and the second s
	Administration Gettings			Con Name Dance (
	Sameta ( Updaw/9 )			
Mail of Fact Page 1	ring	them at		
off and Danisland				
and Posts Latings	ing Type Setting			
and Illowing A	athentication Type	I security/automation messages chemeted)		
ing Data fining D	anadip	10 secult/addrespator messager (seculty?)		
anneed listing and	tanal .	10. Annual annu 11 (Annual 12	1	
at Control Man	hodowitt .	117 Innui suo 1 decelta		
ai Coluit 1	hand.	Int local and 2 (local)		
A Log	Palate	(10 local use 3 (local))		
and offerent in	topped .	20 Terrar una 4 (terraril)		
-	have -	21 Incat your & (Incatt)		
+ Administration Defengs	had a second	32 total use 8 (hcall)		
Allowated beings M	laker"	(23 incutions ? (seal?)		
a Line Dente System 12	August .	(3 system disenses (system)		
	atouth /	3 system diamons (system)	-	
				Back to the Top on The Pape A
	Superity United St			

### (2) Storage/Send Settings

Keep all the items selected.

TAXABLE IN COLUMN AND A	states and a self-rate of	and the second se		
	0498-14-7 @B	an Chantan Court Court Court	* 41+	
				anone at a
SHARP				Discharge Tanks   Linguistic
MX-XXXX	Storage/Ser	vd GefBregs		
	[ tacents ]			
and a second address of the	- Automation	Laine and L		
Contrast of Taxa Prope	They read	Construction (		
Concer Design Concerns	LAud 8			
Dance Linna	Stars Latting			
PROJEKS BATHA				
Entropy Saltry	(here) in Streets	Roate 10		
(the Casho	Store Tape			
She Care 2	-			
244 g		CC And marriage Barries		
Caldes of Terrowe		The set of the set of the set		
Serve .		The second barrant lines of		
A Researched Internet		Es securit/hattorization messages (security?)		
a Dated Genere During		The manager generated storesty by systept byring		
a your home		Eff ine preter sussymme (preter)		
		22 odpeck seve subsystem (retrans)		
		218 VVCP extrement (avenue)		
		EP des damas plants		
		1011 FTF damme Rei		
		C II NT adaptes (s)		
		(ETT ing multi (multi)		
		(Child big shet (shel)		
		27 H dail damas (Hck/)		
		The search of th		
		[[Wheel on 2 heal)		
		(Climites ) (mail)		
		Ell hard used (head)		
		E21 biol and 5 decall)		
		1222 hour use 5 docards 1223 hour use 7 docards		
	100			
	Downey .	ER Company		
		177 Calud		
		173 fee		
		IT4 Warms		
		Et Notes		
		Et storation		
	(Texter)	Der Dertert		
	CELEVIC			
	Contract 1			
				Back to the Tax on Two Page

### (3) Save/ Delete Syslog

Constanting	and the second second second	Econs Erneternet	
SHARP MX-XXXX	Bavel Delete Syslog		ine targ Grove Legethic
NAME OF TAXABLE	Eping	1949	
Fault on Derivat	Sara Spileg		
Denie Ulerag	(1+1)		
Frequenci Satrag	Delete Spling		
Une Corput	[ Intereff ]		
Add Log			Back to the Tap on This Pape
Charles of Parrows			
A Administration Serving - Same Conste Syring - Your Spring			
C-IPARINALE			C/7-8+F

When saving the Syslog, click "Save" button and specify the save position and save it.

When deleting, click "Delete" button.

Check to confirm that the confirmation message is displayed, and press  $\ensuremath{\mathsf{OK}}$  key.

### (4) View Syslog

![](_page_429_Picture_17.jpeg)

- 1) Select a Syslog item to be displayed.
- Click "Show" button. The Syslog is displayed.

### K. Output Profile Settings

77イル(E) 編集(E) 表示(化	り お気に入り④ ツール①	ヘルプ(H)				
3 戻る • 🔿  🖹 👔 (	🏠 🔎 検索 🌟 お気に入り	🐵 🔊 · 🚴 🖻 · 🗔 🛍 🍮				
FL.2 (1) 🗃 http://10.36.100.2	26/service_output_profile.html		»			
	2	11	f (J)tuc			
SHARP	User Name: Service Cogodi(c)					
MY-YYYY	Output Profil	Output Profile Settings				
MYY-VWV						
	Update(R)					
Output of Text Powe	low to the	C and a second				
East/Form Description	Output A Profile	Output A Profile Settings				
Convronni Download	File Name	Default				
output Profile Settings	Standard	1.				
Device Cloning	Delete(0)					
Filing Data Backup						
Password Setting	Add Profile:	参照… (Up				
User Control		Lo 200 characters)				
User Control 2		Can(1)				
Job Log	Output B Profile	Settings				
Update of Firmwore	1 - a par o ritome					
Svelog	File Name	Default				
~1910Å	Standard					
	sharp.icm	·				
	Delete(C)					
	Add Dusfile					
	Photo Provide:	参照… (Up to 200 characters)				
		Add(M)				
		Constitution of the Second				
	Output C Profile Settings					
	Leader					
	File Name	Default				
	Standard					
	Delete(N)					
	Add Profile	E av 07				
	and a colline.	to 200 characters)				
		Add(Q)				
	Output D Profile Setting					
	<b>F</b> 11. <b>H</b>	P. (2016				
	File Name Standard	Default *				
	Deleterte					
	Add Profile					
		to 200 characters)				
		Add(Q)				
	_		_			
	Spotcolor Table	Setting				
	File Name	Default				
	Not Set	Delaun				
	Delete(S) Add Table:	[李聪_]ala				
	Delete(S) Add Table:	委题…)(Up to 200 characters)				
	Delete(S) Add Table:	して すなして (Up の の の の の の の の の の の の の				
	Delete(5) Add Table:	to 200 characters)				
	Defere(5) Add Table:	to 200 characters) Add(U) Back to the Top on This	Page 🛦			

### (1) Download procedures of custom output profile

- 1) Click "Refer" button to select the output profile.
- 2) Click "Add" button to add the output profile.
- 3) Click "Add" button to add the output profile.

The added profile is displayed on the list. For the output A profile and the output B profile, the newly added profile becomes valid.

When no profile is added, the default output profile in the firmware of the machine set when shipping from the factory is valid.

Output A profile / Output B profile / Output D profile: Selectively used.

Output C profile: PS mode, for CMYK simulation (Custom) Spot Color Table: For PS mode

- (2) Procedures to delete the custom output profile and return to the default output profile
- 1) Clock "Delete" button of the output profile to be deleted.
- 2) Click "Update" button.

The custom output profile is deleted and the default output profile in the firmware of the machine becomes valid.

### L. Machine ID Setting

SHARP MX-XXXX	Machine ID Sett	User Name: Senice Logood), L
Output of Test Page Fort/Form Download	Machine ID:	0123456789 (Up to 30 Characters)
Output Profile Settings		
Device Cloning	[	Back to the Top on This Pag
Filing Data Backup	Submit(U)	
Password Setting		
Machine ID Setting		
User Control		
User Control 2		
Job Log		
Update of Firmware		
Sysleg		
Administration Settings		

- Enter the machine ID. Max. 30 digits of numeral figures and characters can be entered.
- 2) Press the registration button.

### Note

The machine ID can be set with SIM26-7 as well as this function.

### M. Administration Settings (Menu display setting)

This setting is to select whether to display all the menus of Web Page on the machine display or to display only the restricted system setting menu of the default.

Setting must be executed according to the user request.

1) Press the setting execution button corresponding to the display mode.

. # hetp://10.36.	164.209/service_admin.html	• 4 X Live Search P
Administration	Settings - MX-2610N	() • □ • ⊕ • □ * ->(2) • 0 × ->(0)
SHARP MX-XXXX	Administration Se	User Name Service Logand(L)
Output of Test Page	Job Log to be Displaye	d
Fort/Form Download	2 au	
Output Profile Settings	All	Execute(J)
Device Cloning	Only System Setting	Execute(C)
Filing Data Backup		Back to the Top on This Page A
Password Setting		and the second
Machine ID Setting		
User Control		
User Control 2		
Job Log		
Update of Firmware		
Syslog		
Administration Settings		

# i '14/Jun[13] OPERATIONAL DESCRIPTIONS

- 1. Operation panel section
- A. Electrical and mechanism relation diagram

![](_page_431_Figure_3.jpeg)


Signal name	Name	Function/Operation
OCSW	Paper size detection trigger sensor	Generates the document size detection trigger signal.

	No.	Name Function/Operation	
	1	HW-KEY PWB	Outputs the key operation signal.
	2	PW-KEY PWB Turns ON/OFF the power on the secondary side.	
	3	LVDS PWB Converts the display data signal to the LCD display signal. / Controls the touch panel.	
	4	Document size detection PWB (Light emitting)	Drives the LED for the document size detection.
	5	Document size detection PWB (Light receiving)	Outputs the document size detection signal.
	6	USB I/F PWB	USB Interface
4	7	USB CONV PWB	Converts to the USB connection
	8	Wireless LAN PWB	Connects the network with the wireless LAN

Signal name	Name	Function/Operation
OCSW	Paper size detection trigger sensor	Generates the document size detection trigger signal.
PWRSW	Operation panel power switch	Turns ON/OFF the power on the secondary side.

No.	Name	Function/Operation
1	KEY PWB	Outputs the key operation signal.
2	LVDS PWB	Converts the display data signal to the LCD display signal. / Controls the touch panel.
3	Document size detection PWB (Light emitting)	Drives the LED for the document size detection.
4	Document size detection PWB (Light receiving)	Outputs the document size detection signal.
5	USB I/F PWB	USB Interface

# 2. Scanner section

# A. Electrical and mechanism relation diagram



Signal name	Name	Function/Operation
CL_ON	Scanner lamp	Radiates light onto a document for the CCD to scan the document image.
MHPS	Scanner home position sensor	Detects the scanner home position.
MIM	Scan motor	Drives the scanner unit. (scan, return operations)

No.	Name	Function/Operation
1	CCD PWB	Scans document images and performs A/D conversion of the scanning signal.
2	SCU PWB	Controls the scanner and the operation section.
3	Scanner lamp drive PWB	Drives the scanner lamp
4	Lens	Reduces a document image (light) and project it to the CCD.
5	1st mirror	Leads a document image to the lens.
6	2nd mirror	
7	3rd mirror	
8	Reflector	Converges the scanner lamp lights and radiates onto the document.

#### (1) General

This section performs the following operations.

- Light is radiated onto the document by the scanner lamp and the reflected image is scanned by the 3-line (RGB) CCD elements to be converted into analog image signals.
- 2) The analog image signals are converted into 10-bit digital signals by the A/D converter.
- The digital image signals are sent to the scanner control PWB for image processing.

### (2) Detailed descriptions

#### a. Optical section drive

The optical section is driven as follows: The drive power is transmitted from the scanner motor (MIM) through the belt to the drive pulley/wire, and the copy lamp unit and the mirror base which are attached to the wire are driven.

The scanner motor (MIM) is controlled with the signals sent from the scanner control  $\ensuremath{\mathsf{PWB}}.$ 

#### b. Scanner lamp drive

The scanner lamp is driven by the scanner lamp drive voltage which is generated by the scanner lamp drive PWB with the control signals sent from the scanner control PWB.

#### c. Image scan and color separation

Light is radiated onto the document by the scanner lamp and the reflected image is scanned by the 3-line (RGB) CCD elements to be converted into analog image signals.

The color components are extracted into R, G, and B by the three kinds of CCD elements (R, G, and B).

The red CCD extracts the red component of an image, the green CCD extracts the green component, and the blue CCD extracts the blue component. This operation is called color separation.

The CCD element is apparently seen as one unit, but it includes the three kinds of elements (R, G, and B).

The CCD element scans the document in the main scanning direction. Scanning in the sub scanning direction is made by shifting the scanner unit with the scanner motor.

The document images are optically reduced by the lens and reflected to the CCD.

**3 LINES CCD UNIT** 

The scanning direction is 600dpi.





Image data of one line



#### d. Image signal A/D conversion

- Each image signal (analog) of R, G, and B is converted into a 10bit digital signal by the A/D converter in the CCD PWB.
   Each color pixel has 10bit information.
- 2) Each 10bit digital image signal of R, G, and B is outputted from the CCD PWB and sent to the SCU PWB, where it is converted into an 8bit signal and sent to the MFP PWB.



#### e. Zooming operation

Zooming in the sub scanning direction is performed by changing the scanning speed in the sub scanning direction.

Zooming in the main scanning direction is not made optically, but performed by the image process technology (software).

# 3. Manual paper feed section

# A. Electrical and mechanical relation diagram



Signal name	Name	Function/Operation
CPFM	Paper feed motor	Drives the paper feed section.
HUD_M/TH_M	Temperature/humidity sensor	Detects the temperature and the humidity. (For the process control)
MPED	Paper empty sensor (Manual paper feed tray)	Detects presence of paper. (Manual paper feed tray)
MPFS	Paper feed solenoid (Manual paper feed)	Controls the paper feed roller. (Manual paper feed)
MPLD	Paper length detector (Manual paper feed tray)	Detects the paper length. (Manual paper feed tray)
MPWS	Paper width detector (Manual paper feed tray)	Detects the paper width. (Manual paper feed tray)
PFM	Transport motor	Drives the transport rollers 5 and 9.

No.	Name	Function/Operation
1	Paper feed roller (Manual paper feed tray)	Feeds paper to the paper transport section.
2	Separation roller (Manual paper feed tray)	Separates paper to prevent double-feeding.
3	Transport roller 9 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.
4	Transport roller 9 (Drive)	Transports paper transported from the transport roller 5 to the transport roller 9.
5	Transport roller 10 (Drive)	Transports paper from manual paper feed section to the transport roller 9.
6	Transport roller 10 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.

### (1) Paper feed operation

The pickup roller moves up and down to press the paper surface, separating the paper on the top of the paper bundle and sending it to the paper feed roller section.

The paper feed roller feeds paper to the transport section to prevent against double feed with the separation roller. The manual paper feed clutch controls ON/OFF of the pickup roller and the paper feed roller. Paper is sent to the registration roller by the manual transport roller.

#### (2) Paper size detection

The paper size is detected by the combination of the following detectors on the manual paper feed tray.

#### Paper size detection table

Parias	Paper size	Bapar langth datastar (MBLD)	Paper width detector (MPWS)
Series	Paper size	Paper length detector (MPLD)	Detection width (mm)
	A3W	ON	301 - 310.4
	A3	ON	291 - 301
	11" x 17"	ON	273.4 - 285.4
	B4	ON	251 - 263
	8.5" x 14"	ON	209.9 - 221.9
	8.5" x 13"	ON	209.9 - 221.9
AB series	A4	-	291 - 305
	8.5" x 11"	-	273.4 - 285.4
	B5	-	251 - 263
	A4R	-	204 - 216
	B5R	-	176 - 188
	A5R	-	142.5 - 154
	Postcard	-	96 - 106
	12" x 18"	ON	301 - 310.4
	A3	ON	291 - 301
	11" x 17"	ON	273.4 - 285.4
	B4	ON	251 - 263
	8.5" x 14"	ON	209.9 - 221.9
INCH parios	8.5" x 13"	ON	209.9 - 221.9
INCH Selles	A4	-	291 - 305
	8.5" x 11"	-	273.4 - 285.4
	B5	-	251 - 263
	8.5" x 11"R	-	209.9 - 221.9
	7.25" x 10.5"R	-	178.1 - 190.1
	5.5" x 8.5"R	-	133.7 - 145.7

# 4. Tray paper feed section

# A. Electrical and mechanical relation diagram



Signal name	Name	Function/Operation	
CLUD1	Paper feed tray upper limit sensor	Detects the upper limit of the paper lift up. (Paper feed tray 1)	
	(Paper feed tray 1)		
CLUM1	Paper tray lift motor (Paper feed tray 1)	Lifts the lift plate of the paper feed tray. (Paper feed tray 1)	
CPED1	Paper empty sensor (Paper feed tray 1)	Detects paper empty. (Paper feed tray 1)	
CPFC1	Tray vertical transport clutch 1	Controls the transport roller of the paper feed tray 1 section.	
CPFD1	Paper transport detector (Paper feed tray 1)	Detects paper pass in the paper transport section of the paper feed tray 1.	
CPFM	Paper feed motor	Drives the paper feed section.	
CPUC1	Paper feed clutch (Paper feed tray 1)	Controls ON/OFF of the paper feed roller in the paper feed tray 1 section. (Paper feed tray 1)	
CSPD1	Paper remaining quantity sensor	Detects the paper remaining quantity. (Paper feed tray 1)	
	(Paper feed tray 1)		
CSS11	Paper feed tray size detector	Detects closing of the paper feed tray. (Paper feed tray 1)	
	(Paper feed tray 1)		
CSS11 - 14	Paper feed tray size detector	Detects the paper size. (Paper size detection is only for 36cpm machine.)	
	(Paper feed tray 1)	Detects closing of the paper feed tray. (Paper feed tray 1)	
DSW_C1	Transport cover open/close detector	Detects open/close of the transport section cover. (Paper feed tray 1)	
	(Paper feed tray 1)		
PFC_HPFC	Transport roller clutch	Controls the transport roller 4.	

No.	Name	Function/Operation
1	Transport roller 1 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.
2	Transport roller 1 (Drive)	Transports paper fed from the paper feed desk tray to the transport roller 4.
3	Paper pickup roller (No. 1 paper feed tray)	Feeds paper to the paper feed roller.
4	Separation roller (No. 1 paper feed tray)	Separates paper to prevent double-feeding.
5	Paper feed roller (No. 1 paper feed tray )	Feeds paper to the paper transport section.
6	Transport roller 2 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.
7	Transport roller 2 (Drive)	Transports paper fed from the paper feed tray 1 to the transport roller 3.
8	Transport roller 3	Transports paper from the transport roller 2 to the transport roller 4.

### (1) Paper feed front operation

- Set paper and insert the paper feed tray, and the pickup roller falls to turn ON the paper feed tray sensor.
- The lift-up motor drives the rotating plate to move it up.
- The paper upper limit sensor turns ON, and the rotation plate stops at the specified position.

#### (2) Paper feed operation

- When copy/print operation is started, the motor and the clutch are turned ON to rotate the pickup roller in the paper pickup timing, feeding paper.
- At the same time, the paper feed roller rotates to transport paper to the transport section. At that time, the separation roller rotates to prevent against double feed of paper.

#### (3) Paper remaining detection

The notifying levels of paper remaining quantity are 4 steps in total; 3 steps of paper remaining quantity and 1 step of paper empty. The result is displayed.

#### (4) Paper remaining quantity detection method

• The paper remaining quantity is judged from the number of rotations of the remaining quantity sensor from starting the lift-up operation of the paper feed tray to turning ON the upper limit sensor.

# (Figure showing state transition of the remaining paper detection sensor during tray elevation and changes in status according to the number of remaining sheets)



- 5. Paper registration section (Paper transport section)
- A. Electrical and mechanical relation diagram



Name	Function/Operation
Transport motor	Drives the transport rollers 5 and 9.
Paper transport detector 1	Detects paper pass in front of the transport roller 5.
Paper transport detector 2	Detects paper pass in the transport roller 5 in front of the registration roller.
Registration motor	Drives the registration roller. (Controls the timing of the transfer image for the paper.)
	NameTransport motorPaper transport detector 1Paper transport detector 2Registration motor

No.	Name	Function/Operation
1	Transport roller 5 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.
2	Transport roller 5 (Drive)	Transports paper to the registration roller. / Paper is warped between the registration roller and this roller to correct the paper skew and the relation between images and paper.
3	Registration roller (Drive)	Transports paper to the transfer section. / Controls the transport timing of paper and adjusts relative relations between the image and paper.
4	Registration roller (Idle)	Apply a pressure to paper and the registration roller to provide the transport power of the transport roller to paper.

Paper is fed from each paper feed section and transported to the registration roller by the transport rollers. ON/OFF control of each transport roller is made by the paper transport clutch. The registration roller controls the relative positions of transported paper and the transfer image. The registration roller is driven by the transport motor. The relative positions of paper and the transfer image are determined by the ON timing of the transport motor.

# 6. Paper exit section

# A. Electrical and mechanical relation diagram



Signal name	Name	Function/Operation
ADUM	ADU motor	Drives the ADU and the transport roller in the right paper exit section.
FUM	Fusing motor	Drives the fusing section.

Signal name	Name	Function/Operation
OSM	Offset motor	Offsets (shifts) paper.
POD1	Paper exit detector 1	Detects paper transport from the fusing section.
POD2	Paper exit detector 2	Detects paper transport to the face-down paper exit tray.
POD3	Paper exit detector 3	Detects paper transport to the right paper exit tray.
POFM	Paper exit cooling fan	Cools the fusing section and the paper exit section.
POFM2	Paper exit cooling fan	Cools the fusing section and the paper exit section.
POM	Paper exit motor	Drives the roller in the paper exit section.
PRTPD	Paper exit tray paper detector (Right paper exit tray)	Detects paper empty in the paper exit tray (Right paper exit tray).
SHPOS	Shifter home positions sensor	Detects the shifter home position.
TFD2	Paper exit tray full detector (Face-down tray)	Detects paper full in the face-down paper exit tray.
TFD3	Paper exit tray full detector (Right paper exit tray)	Detects paper full in the right paper exit tray.

No.	Name	Function/Operation		
1	Transport roller 6 (Drive)	Transports paper transported from the fusing section to the paper exit section and the switchback section.		
2	Transport roller 6 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller to paper.		
3	Paper exit roller 1 (Idle)	Apply a pressure to paper and the paper exit roller to provide the transport power of the paper exit roller to paper.		
4	Paper exit roller 1 (Drive)	Transports paper to the left paper exit section.		
5	Paper exit roller 2 (Idle)	Apply a pressure to paper and the paper exit roller to provide the transport power of the paper exit roller to paper.		
6	Paper exit roller 2 (Drive)	Discharges paper to the right paper exit tray.		
7	Paper exit gate	Selects the paper path: to transport paper to the back surface print transport section or to the right tray.		
8	Switchback gate	Switchbacks paper to transport it to the back surface print section.		
9	Paper exit roller 3 (Drive)	Discharges paper to the right paper exit tray.		
10	Paper exit roller 3 (Idle)	Apply a pressure to paper and the paper exit roller to provide the transport power of the paper exit roller to paper.		

- The paper transported from the fusing section is sent from transport roller 6 (which is driven by the ADU motor) to paper exit roller 1, and then discharged to the inner tray.
- When the paper is discharged to the right tray: The paper is transported to paper exit roller 1, and the paper exit motor is reversed. Then the paper is passed over the right paper exit gate through paper exit roller 2 to the right tray.

# 7. ADU section

# A. Electrical and mechanical relation diagram



Signal name	Name	Function/Operation
ADUM	ADU motor	Drives the transport roller in the ADU right paper exit section.
APPD1	ADU paper transport detector 1	Detects paper entry and paper pass in the ADU.
APPD2	ADU paper transport detector 2	Detects paper pass in the ADU transport roller 8.
DSW_ADU	ADU paper guide open/close detector	Detects open/close of the ADU paper guide.
PFM	Transport motor	Drives the transport rollers 5 and 9.
POD3	Paper exit detector 3	Detects paper transport to the right paper exit tray.

No.	Name	Function/Operation		
1	Transport roller 7 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller		
		to paper.		
2	Transport roller 7 (Drive)	Transports paper transported from the switchback section to the transport roller 8.		
3	Transport roller 8 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller		
		to paper.		
4	Transport roller 8 (Drive)	Transports paper transported from the transport roller 7 to the transport roller 9.		
5	Transport roller 9 (Idle)	Apply a pressure to paper and the transport roller to provide the transport power of the transport roller		
		to paper.		
6	Transport roller 9 (Drive)	Transports paper transported from the transport roller 8 to the transport roller 5.		
7	Paper exit roller 3 (Drive)	Discharges paper to the right paper exit tray.		
8	Paper exit roller 3 (Idle)	Apply a pressure to paper and the paper exit roller to provide the transport power of the paper exit roller		
		to paper.		

- The paper transported from the fusing section is sent from transport roller 6 (which is driven by the ADU motor) to paper exit roller 1. At that time, the paper passed under the gate.
- When POD1 detects the paper lead edge, the paper exit drive motor reverses.
- By reversion of the paper exit motor, the paper is sent to the ADU section. At that time, the paper passes over the ADU guide which fell by its own weight.
- Transport rollers 7 and 8 are driven the ADU motor, and transport roller 9 by the transport motor. The paper is transported to the duplex paper feed position.
- The paper is once stopped at the duplex paper feed position, and transported again to the inside of the machine.

# 8. LSU section

# A. Electrical and mechanical relation diagram



Signal name Name Function/C		Function/Operation
BD	Laser beam detector	Detects (monitors) the laser bean scan timing.
PGM	Polygon motor	Scans laser beams.
TH1_LSU	LSU temperature sensor	Detects the temperature in the LSU. (For correction of the LSU distortion)

No.	Name	Function/Operation		
1	LD PWB	Drives the laser diode and controls the power.		
2	Colimeter lens	Forms laser beams.		
3	f 0 lens 1	Equalizes the laser beam dot intervals in the main scanning direction. (Corrects the laser dot		
4	f 0 lens 2	intervals on the OPC drum.)		
5	f 0 lens 3			
6	1st mirror	Reflects laser beams to the OPC drum.		
7	2nd mirror	Reflects laser beams to the OPC drum.		
8	3rd mirror	Reflects laser beams to the OPC drum.		
9	4th mirror	Reflects laser beams to the OPC drum.		
10	Cylindrical lens	Leads laser beams to the polygon mirror.		
11	Conversion lens for BD	Converges laser beams and leads to the BD (Bean Detector).		
12	Filter glass	Prevents dust, toner, and foreign materials from entering the LSU.		
13	LSU shutter	Closes the exposure opening port in conjunction with opening of the waste toner box, preventing		
		dust, toner, and foreign materials from attaching.		
14	Shutter ring cam	Shutter closes the exposure opening port in conjunction with opening of the waste toner box.		
15	BD mirror	Leads laser beams to the BD (Beam Detector).		
16	Skew adjustment screw (C, M, Y, K)	Adjusts the radiating angle of laser beams for the OPC drum. By turning this adjustment screw,		
		image skew can be adjusted.		

#### (1) General

Image data sent from the LSU Mother PWB are converted into laser beams and radiated onto the OPC drum surface. The LSU unit is composed of : (1) the optical elements from the laser to the polygon mirror, (2) the primary system including the mirror which secures the optical path, (3) the optical elements including the polygon mirror, and (4) the scanning system including the mirror which secure the optical path.

#### (2) Composition

Primary system



Scanning system



#### Main scanning direction



Writing position on paper





4

# 14/Jun

# (3) Outline of LSU specifications

26cpm/31cpm machine				
Process speed	140mm/sec			
Resolution	1200dpi			
Laser beam	2 beams			
Polygon motor rotation speed	33070.9rpm			
Laser power	0.110mW			
Bearing type	Oil bearing			
Number of mirrors	6			
Laser beam diameter	50 - 85 x 50 - 80μm			
Effective scan length	310mm			
Laser wave length	790 +/-10nm			

### 36cpm machine

Process speed	165mm/sec
Resolution	1200dpi
Laser beam	2 beams
Polygon motor rotation speed	38976.4rpm
Laser power	0.130mW
Bearing type	Oil bearing
Number of mirrors	6
Laser beam diameter	50 - 85 x 50 - 80μm
Effective scan length	310mm
Laser wave length	790 +/-10nm

# 9. Process section

### A. General

The process section is composed of the following major devices.

Laser beams generated by the LSU are converted into visible toner images via the OPC drum, the developing unit, and the transfer unit, and transferred on paper.

The process operations are performed in the following sequence:

Charging - Exposure - Developing - Primary transfer - Secondary transfer



In addition, the process control system is employed to maintain stable print image qualities.

## B. Major units and functions



Name	Content	
OPC drum unit	Generates electrostatic latent images with the main charger and the image laser beams.	
Toner cartridge	Supplies toner to the developing unit with the toner motor.	
Developing unit	Converts electrostatic latent images on the OPC drum into visible toner images.	
Primary transfer unit	Transfers toner images on the OPC drum to the primary transfer belt.	
Secondary transfer unit	Transfers toner images from the primary transfer belt to paper.	
Waste toner collection section	Collects waste toner generated in the OPC drum section and the transfer section.	
Image density sensor (Registration sensor)	Detects the toner patch density on the primary transfer belt during operation of the process control	
	system. Detects the color shift amount.	
MC/DV PWB	Generates the main charger voltage and the DV bias voltage.	
TC PWB	Generates the transfer voltage.	
Before-transfer charging unit (PTC)	Charges toner so as to be easily transferred on paper.	

# C. Process section equivalent circuit diagram



# **D. Process control**

### (1) General

The process control system is provided to maintain stable print image qualities under changes in the environmental conditions and in characteristics of supply parts.

The major operation of the process control is to detect a change in the print density with the image density sensor and change the DV bias, the MC grid voltage and the dither pattern according to the detection result, maintaining the stable color balance and the print density.

### (2) Block diagram

The process control system is composed as shown in the block diagram below.



# (3) Process control items and contents

The table below shows the correction item, the change item, the purpose/effect, and the operation timing for each process control item.

Item No.	Correction item		Change item	Purpose/Effect	Operation timing/ Operation condition
1	Color image density sensor sensitivity adjustment (Image registration sensor F)	Color image density sensor (Image registration sensor F) LED current adjustment	Color image density sensor LED current adjustment value	A change in the sensitivity due to dirt on the sensor or a change in the temperature is corrected to enable always correct detection of the image patch density.	SIM44-2 / Before high density process control operation
	Monochrome image density sensor sensitivity adjustment (Image registration sensor R)	Monochrome image density sensor (Image registration sensor R) LED current adjustment	Monochrome image density sensor amp gain and sensor LED current adjustment value	A change in the sensitivity due to dirt on the sensor or a change in the temperature is corrected to enable always correct detection of the image patch density.	SIM44-2 / Before high density process control operation
2	High density process control	Developing bias voltage correction	Developing bias voltage	A change in the density due to a change in characteristics of the image generating section and overlap copy are prevented to maintain the density in the high density image section at the proper level.	SIM44-6 (Compulsory execution) When warming up after resetting the OPC drum counter, the developing counter, and the transfer counter (SIM25- 2/24-4/24-5/24-7). When warming up after resetting the OPC drum counter, the developing counter, and the transfer counter (SIM25- 2/24-4/24-5/24-7). When warming up after replacement of the toner cartridge.
				<b></b>	For the other operation timing, conform to the setting of SIM44-28.
		Main charger grid voltage correction	Main charger grid voltage 3	The developing bias voltage correction (change) is corrected to maintain the relation between the developing bias voltage and the main charger grid voltage difference to a constant one. (Prevention of overlap copy and developer drop)	After the developing bias voltage changes by the high density process control.
3	Half-tone process control	Half-tone process control (Copy mode)	Dither pattern (LUT)	The color balance (gamma) adjusted by the serviceman color balance adjustment is maintained.	<ol> <li>SIM44-26 (Compulsory execution)</li> <li>After the high density process control (However, depending on the conditions)</li> <li>For the other operation timing, conform to the setting of SIM44-28</li> </ol>
		Half-tone process control (Printer mode)	Dither pattern (LUT)	The result of the half-tone correction executed in the copy mode is applied to the printer mode.	After the copy mode half-tone density image correction
4	Toner density correction / Toner density control	Correction for the environmental toner supply quantity (Toner density correction) (Temperature and humidity change)	Toner supply quantity (Toner supply time)	By changing the toner motor rotation level, the toner supply is corrected to maintain the toner density at a proper level.	When the temperature and the humidity change
		quantity correction for the result of the high density process control	quantity (Toner supply time)	when the developing bias voltage is changed by the high density process control, if the toner density is judged to be low, the toner supply quantity is corrected to maintain the proper density for print.	After the developing bias voltage is changed to the higher level than the specified level by the high density process control.
		Correction of the toner supply quantity for the toner cartridge counter	Toner motor rotation number Toner supply quantity (Toner supply time)	The toner supply quantity to the developing unit for the certain number of rotations of the toner motor differs depending on the remaining toner quantity in the toner cartridge. Therefore, the toner motor RPM is changed according to the remaining toner quantity (toner motor counter) to maintain the proper toner supply operation.	When the toner motor counter changes
		Correction of the toner supply quantity for the output image density (number of pixels)	Toner supply quantity (Toner supply time (duty))	The toner supply quantity is maintained properly for the area (pixel count) of output images (for the actual toner consumption quantity), keeping the toner density at the proper level.	During output operation (for every page)

### a. Image density sensor sensitivity adjustment operation





A

# 14/Jun : '14/Jun

#### Sensitivity adjustment of the color sensor light receiving elements (Photo transistors)

Purpose: To maintain the sensitivity of the light receiving elements even if the environmental conditions (temperature and humidity) vary.

Execution timing: This adjustment is executed in the process control when the temperature or the humidity varies.

Method: Use the patch written on the primary transfer to adjust the

Light emitting current of the sensor LED (Light emitting diode)

Purpose: To maintain the light emitting quantity of the sensor even if the sensor LED is aged or the environmental conditions vary. Execution timing: Every time when the process control is made. Method: Reflection on the surface of the primary transfer belt is used to adjust the sensor sensitivity.



#### b. High density process control operation (Toner patch generation and density correction operations)

- When the machine enters the high density process control mode, the secondary transfer unit enters the free state. 1)
- While changing the DV bias voltage step by step, a number of toner patches in different densities are generated on the F side and the R 2) side of the primary transfer belt.

F side: The color toner patch is generated. R side: The black toner patch is generated.



Each toner patch density is detected by the image density sensor, and the DV bias correction voltage is calculated in the PCU PWB so that 3) the proper density is obtained from the relation between the DV bias voltage at the time when each toner patch is made and the toner patch density.



- (1) Toner patch electrostatic latent images are formed on the OPC drum.
- (2) The toner patch electrostatic latent images are developed and transferred on the primary transfer belt.
- (3) Each toner patch density is detected by the toner density sensor.
- (4) The DV bias correction value is calculated.
- (5) The DV bias correction value is applied to the actual operation mode.
- (6) The calculated DV bias voltage is applied to the actual operation mode.

#### c. Half-tone process control operation (Toner patch generation and half-tone correction operation)

- 1) When the machine enters the half-tone process control mode, the secondary transfer unit enters the free state.
- 2) While changing the dither pattern step by step by the MFP PWB, a number of toner patches in different densities are generated on the F side and the R side of the primary transfer belt.

F side: The color toner patch is generated. R side: The black toner patch is generated.



- 3) Each toner patch density is detected by the image density sensor, and each toner patch density are compared with the reference gamma to calculate the correction amount.
- 4) The dither pattern in the actual operation mode is generated in the MFP PWB with the reference gamma and the correction amount.



- (1) Toner patch electrostatic latent images are formed on the OPC drum.
- (2) The toner patch electrostatic latent images are developed and transferred on the primary transfer belt.
- (3) Each toner patch density is detected by the toner density sensor.
- (4) By comparing with the reference gamma, the correction value is calculated.
- (5) The dither data in the actual operation mode are formed in the MFP PWB according to the correction value, and applied to the actual operation mode.

#### d. Toner density correction / Toner density control

Different from the conventional models, this machine does not control the toner density in the developing unit according to the toner density detected by the toner density sensor.

The toner supply operation from the toner cartridge to the developing unit is controlled according to the following data so that the optimum developing is performed.

- The print pixel number for every page is counted and the toner consumption is calculated by the LSU mother PWB.
- The toner density is checked to be proper or not according to the result of the high density process control.
- The remaining toner quantity is presumed with the toner cartridge counter, and the toner supply quantity to the developing unit for the number of rotations of the toner motor is corrected. (This is because the toner supply quantity to the developing unit for the number of rotation of the toner motor differs depending on the remaining toner quantity in the toner cartridge.)
- · Correction for the temperature and the humidity

The toner density sensor in this machine performs the following functions.

- · Judges whether toner is supplied from the toner cartridge to the developing unit or not during rotation of the toner motor.
- · Judges whether the toner density is abnormal or not.



- (1) The basic information of the toner density control is acquired.
- · Temperature and humidity
- · Print pixel number for every page
- · High density process control data
- Toner cartridge counter
- · Toner density sensor data

- (2) The necessary toner supply quantity (toner motor rotation number) is calculated according to the basic information of the toner density control. (PCU PWB)
- (3) The toner motor is rotated for the time corresponding to the calculated toner motor rotation number.
- (4) Toner is supplied from the toner cartridge to the developing unit.

#### (5) Setting of process control execution conditions

#### a. General

The SIM44-62 function facilitates changing the process control execution conditions.

The SIM44-62 function also allows collective change of the set contents of SIM44-4 and SIM44-28 easily.

This is used to assure stable image qualities by executing proper operations of the process control according to the machine use status.

#### b. SIM44-62 function and use

- 1) Changes the image density in the high density area.
- 2) Changes the execution frequency of the process control.

#### c. Setting method

1) Enter the SIM44-62 mode, and select the set item.

To change the image density in the high density area, select PROCON TARGET.

To change the frequency of the process control operations, select PROCON MODE.



# (When PROCON TARGET is selected.)

2A) Select the density level.



(Relation between the selected density level and the output image density)

CL ID DOWN	The densities of C, M, and Y decrease. (The C/M/Y high density process control target values decrease.)
CL ID UP	The densities of C, M, and Y increase. (The C/M/Y high density process control target values increase.)
BK ID DOWN	The density of K decreases. (The high density process control target value decreases.)
BK ID UP	The density of K increases. (The high density process control target value increases.)
ALL ID DOWN	The densities of C, M, Y and K decrease. (The C/M/Y/K high density process control target values decrease.)
ALL ID UP	The densities of C, M, Y and K increase. (The C/M/Y/K high density process control target values increase.)
NORMAL	The standard density of C, M, Y and K. (The C/M/Y/K high density process control target values are the standard values.)

(Relation between the selected density level and the SIM44-4 set values)

			SIM44-62 PROCON TARGET (Selected density level)						
			Low		Normal	High			
	Item (SIM44-4)	CL ID Down	BK ID Down	ALL ID Down	Normal (Default)	CL ID Up	BK ID Up	ALL ID Up	
Α	PCS_CL TARGET	98	98	98	98	98	98	98	SIM44-4 set value
В	PCS_K TARGET	208	208	208	208	208	208	208	
С	LED_CL OUTPUT	21	21	21	21	21	21	21	
D	LED_K OUTPUT	21	21	21	21	21	21	21	
Е	PCS ADJSTMENT LIMIT	4	4	4	4	4	4	4	
F	BELT GROUND DIF	1	1	1	1	1	1	1	
G	BIAS_CL STANDARD DIF	60	60	60	60	60	60	60	
Н	BIAS_BK STANDARD DIF	0	0	0	0	0	0	0	
-	<b>BIAS PATCH INTERVAL</b>	60	60	60	60	60	60	60	
J	Y_PAT TARGET ID	101	111	101	111	126	111	126	
К	M_PAT TARGET ID	125	135	125	135	150	135	150	
Ц	C_PAT TARGET ID	118	128	118	128	143	128	143	
М	K_PAT TARGET ID	45	40	40	45	45	55	55	
Ν	HV BK_GROUND LIMIT	60	60	60	60	60	60	60	

3A) Press [EXECUTE] key.

4A) Press [YES] key.

The SIM44-4 set value varies according to the selected density level.

5A) Execute SIM46-74 to adjust the copy and printer color balance.

#### (When PROCON MODE is selected.)

2B) Select the execution frequency level of the process control.



(Setting level and application)

HighQuality2:

The execution frequency of the process control is highest.

It is set when the color image quality is given priority.

Every time the power is turned ON, the process control is executed.

The execution frequency of the process control is about 3 times greater than the normal setting.

For a user who's main jobs are color jobs of more than 100 sheets/day with priority on the color image quality.

(Relation between the selected mode and the SIM44-28 set values)

HighQuality1:

The execution frequency of the process control is high.

It is set when the color image quality is given priority.

Every time the power is turned ON, the process control is executed.

For a user of about 100 sheets/day with priority on the color image quality.

Normal (Default):

The process control is executed in the normal frequency.

BW Mode:

The process control is executed in the normal frequency.

It is set when there are little color jobs and many monochrome jobs.

The black process control is executed.

The color process control is occasionally executed according to the color toner consumption.

The color toner consumption is suppressed.

Print Performance:

The execution frequency of the process control is low.

It is set when the job speed is given priority.

The process control is executed in about 50% of the normal frequency during jobs.

For jobs of 100 or less, the process control is executed after completion of the jobs.

SIM44-62 and PROCON MODE (process control execution				l execution frequenc	y level)		
		Highest	High	Nor	mal	Low	
	Item (SIM44-28)	HighQuality2	HighQuality1	Normal (Default)	BW Mode	Print Performance	
Α	INITIAL	0	0	0	0	0	SIM44-28 set value
В	SW ON	0	0	3	3	3	
С	TIME	0	0	3	3	3	
D	HUM_LIMIT	0	0	0	2	0	
Е	HUM	0	0	0	2	0	
F	REV1	0	0	0	1	1	
G	REV2_BK	0	0	0	0	0	
Н	REV2_CL	0	0	0	0	0	
1	REFRESH MODE	1	1	1	1	1	
J	DAY	1	1	1	0	1	
Κ	HI-COV	0	0	0	0	1	
L	LO-COV	0	0	0	0	1	
М	TonerCA-END	1	1	1	1	1	
0	AVERAGE-PAGE	3	3	3	3	3	
Р	LIMIT PAGE	5	5	10	10	10	
Q	PIX_RATIO_BK	10	10	10	10	10	
R	PIX_RATIO_CL	10	10	10	50	10	
S	INTERVAL TIME	3	3	3	3	3	
Т	HUM HOUR	2	2	2	2	2	
U	HUM_DIF	2	2	2	2	4	
V	BK_RATIO	5	10	15	30	30	
W	M_RATIO	5	10	15	30	30	
Х	COLOR BORDER	20	20	20	100	20	
Y	BK ONLY	5	5	5	6	5	
Ζ	HT_DIF	1	20	40	40	40	
AA	RG_ON_SYNC	0	0	0	0	0	
AB	RG_TEMP_TIMER	0	0	0	0	0	
AC	RG_PERM_TIMER	0	1	1	1	1	
AC	RG_HOUR_TIMER	3	5	5	11	11	
AD	RG_BW_SYNC	1	1	1	1	1	

Items out of application: 2TRAN_CLEAN_TIME1/2TRAN_CLEAN_TIME2/2TRAN_CLEAN_TIME3

3B) Press [EXECUTE] key.

4B) Press [YES] key.

The SIM44-28 set value varies according to the selected execution frequency level of the process control.

### Note

This simulation may not function with some firmware versions. In such a case, the firmware must be upgraded to the latest version

# E. Other correction items and contents

The table below shows the correction item, the change item, the purpose/effect, and the operation timing for the other correction items.

ltem No.	Correct	tion item	Change item	Purpose/Effect	Operation timing/ Operation condition
1	OPC drum deterioration correction	Main charger grid voltage correction	Main charger grid voltage 1	The surface dark potential fall due to the OPC drum OPC layer membrane decrease and electric and optical stress is corrected to maintain the proper density for print and prevent overlap copy.	When executing the high density process control.
			Main charger grid voltage 2	The surface dark potential fall due to the temperature and the humidity is corrected to maintain the proper density for print and prevent overlap copy.	
		Discharge lamp light quantity correction	Discharge lamp light quantity (ON DUTY 1)	A change (an increase in the surface dark potential) in a change in the OPC drum sensitivity (a change in the discharge efficiency) due to the OPC drum OPC layer membrane decrease and electrical and optical stress is corrected to maintain the proper density for print.	
			Discharge lamp light quantity (ON DUTY 2)	A change in the OPC drum sensitivity (a change in the discharge efficiency) (a change in the surface dark potential) due to the temperature and the humidity is corrected to maintain the proper density for print.	
		Laser power correction	Laser power 1	A fall in the OPC drum photo sensitivity due to the OPC drum OPC layer membrane decrease and electrical and optical stress is corrected to maintain the proper density for print.	



Item No.	Correct	tion item	Change item	Purpose/Effect	Operation timing/ Operation condition
2	Transfer capability correction (Primary transfer)	Correction of the transfer current for the environment (A change in the temperature and the humidity)	Primary transfer current 1	A change in the transfer characteristics (transfer efficiency) due to a change in the temperature and the humidity is corrected by changing the transfer current.	A change in the environmental area (temperature and humidity) / Before the high density process control operation (AND condition)
		Correction of the transfer current for the high density process control (MC grid voltage)	Primary transfer current 2	A change in the transfer characteristics (transfer efficiency / memory) according to the surface potential of the OPC drum is corrected by changing the transfer current value.	After the OPC drum surface potential is changed by the high density process control



ltem No.	Correct	tion item	Change item	Purpose/Effect	Operation timing/ Operation condition
3	Transfer capability correction (Secondary transfer)	Correction of the transfer current for the environment (A change in the temperature and the humidity)	Secondary transfer current 1	A change in the transfer characteristics for a change in the paper state due to a change in the temperature and the humidity is corrected by changing the transfer current.	Environmental area (temperature and humidity) change
		Transfer current correction for back surface print	Secondary transfer current 2	A change in the transfer efficiency for a change in the paper state is corrected to maintain the proper density for print.	When printing the back surface
		Correction of the transfer current for the paper kind (thickness and material) for transfer and the size	Secondary transfer current 3	A difference in the flow of the transfer current due to the paper kind and size is corrected.	For every change in the paper kind or size



ItemNo.	Correction item	Change item	Purpose/Effect	Operation timing/Operation condition
4	Automatic image	LSU exposure timing	An image registration generated by a variation	After execution of SIM50-22 / User image
	registration adjustment		in the LSU unit, a position shift and rotations of	registration adjustment / After high density
			the transfer belt is automatically adjusted.	process control operation



ItemNo.	Correction item	Change item	Purpose/Effect	<b>Operation timing/Operation condition</b>
5	LSU heat distortion	LSU exposure timing	An image registration and distortion generated by	Laser ON timing
	correction		the optical axis shift due to the LSU heat distortion	
			are automatically corrected.	



# F. OPC drum section

# (1) Electrical and mechanism relation diagram



Signal name	Name	Function/Operation
DHPD_CL	OPC drum rotation sensor (CL)	Detects rotation and the phase of the OPC drum (CL).
DHPD_K	OPC drum rotation sensor (BK)	Detects rotation and the phase of the OPC drum (BK).
DL_BK	Discharge lamp (K)	Discharges electric charges on the OPC drum (K).
DL_C	Discharge lamp (C)	Discharges electric charges on the OPC drum (C).
DL_M	Discharge lamp (M)	Discharges electric charges on the OPC drum (M).
DL_Y	Discharge lamp (Y)	Discharges electric charges on the OPC drum (Y).
DVM_CL	Developing motor (CL)	Drives the developing/OPC drum section (CL).
DVM_K	Developing motor (K)	Drives the developing/black OPC drum (BK)/transfer section.
GB (Y, M, C, K)	Grid (Y, M, C, K)	The OPC drum surface potential is controlled.
GB (K, M, C, Y)	Main charger grid voltage (K, M, C, Y)	The OPC drum surface charging voltage is controlled.
MC (Y, M, C, K)	Main charger (Y, M, C, K)	The OPC drum surface is negatively charged.
MC-CL	Main charger applying voltage (CL)	The main charger is charged to generate negative electric charges.
MC-K	Main charger applying voltage (K)	

No.	Name	Function/Operation
1	OPC drum unit (Y, M, C, K)	Latent electrostatic images are formed.
2	Cleaning blade (Y, M, C, K)	Remaining toner on the OPC drum surface is cleaned.
3	Waste toner transport screw	Waste toner in the OPC drum unit is transported to the waste toner collection section.
4	High voltage PWB (MC/DV PWB)	Generates the main charger voltage and the DV bias voltage.

The OPC drum surface is negatively charged by the main charger, then laser image beams are radiated to the OPC drum surface by the laser (writing) unit to form electrostatic latent images.

1) The OPC drum surface is negatively charged by the main charger.



The main charger grid is provided with the screen grid. The OPC drum is charged at a voltage virtually same as the voltage applied to the screen grid.

2) Laser beams are radiated to the OPC drum surface by the laser (writing) unit to form electrostatic latent images.



When laser beams are radiated onto the CGL of the OPC drum, positive and negative charges are generated.

Positive charges generated in CGL are attracted to the negative charges on the OPC drum surface. On the other hand, negative charges are attracted to positive charges in the aluminum layer of the OPC drum.

Therefore, positive charges and negative charges are balanced out on the OPC drum and in the aluminum layer, reducing positive and negative charges to decrease the OPC drum surface voltage.

Electric charges remain at a position where laser beam are not radiated.

As a result, latent electrostatic images are formed on the OPC drum surface.

3) After transfer operation, remaining toner is removed by the cleaning blade.

Toner removed from the OPC drum surface is transported to the waste toner section by the waste toner transport screw.



#### **OPC drum rotation control**

The OPC drum (K) is driven by the DV motor (DVM_K), and the rotation speed is monitored by the OPC drum rotation sensor (DHPD_K).

The color OPC drums (C, M, and Y) are driven by the DV motor (DVM_CL), and the rotation speed is monitored by the OPC drum rotation sensor (DHPD_CL).

Based on the signals monitored by the two sensors, the rotation speeds of K OPC drum and the color OPC drums and the rotation phase are controlled. 4) The whole surface of the OPC drum is discharged.



By radiating the discharge lamp light to the discharge lens, light is radiated through the lens to the OPC drum surface.

When the discharge lamp light is radiated to the OPC drum CGL, positive and negative charges are generated.

Positive charges generated in CGL are attracted to the negative charges on the OPC drum surface. On the other hand, negative charges are attracted to positive charges in the aluminum layer of the OPC drum.

Therefore, positive and negative charges are balanced out on the OPC drum surface and in the aluminum layer, reducing positive and negative charged to decrease the surface voltage of the OPC drum.


## G. Toner supply section

## (1) Electrical and mechanism relation diagram



Signal name	Name	Function/Operation
CRUM	CRUM (Y, M, C, K)	Saves various data of the toner cartridge.
TNM_C	Toner motor (C)	Supplies toner from the toner cartridge (C) to the developing unit.
TNM_K	Toner motor (K)	Supplies toner from the toner cartridge (K) to the developing unit.
TNM_M	Toner motor (M)	Supplies toner from the toner cartridge (M) to the developing unit.
TNM_Y	Toner motor (Y)	Supplies toner from the toner cartridge (Y) to the developing unit.

No.	Name	Function/Operation
1	Toner transport screw	Transports toner from the toner cartridge to the developing unit.
2	Toner stirring plate	Moves the toner stirring plate and toner to the toner transport screw to assist the toner transport operation.

## (2) Operational descriptions

Based on the print pixel count and the process control information, Yes/No of toner supply is judged.

When it is judged that the toner density is decreasing, the toner motor is rotated to supply toner in the toner cartridge through the toner transport screw and the toner duct to the developing unit.

## H. Developing section

## (1) Electrical and mechanism relation diagram



Signal name	Name	Function/Operation
1TURC_1	Primary transfer separation clutch 1	Controls separation of the primary transfer unit.
BS (K, M, C, Y)	Developing bias voltage (K, M, C, Y)	Voltage to form toner images on the OPC drum. Controls the developing density.
DVM_CL	Developing motor (CL)	Drives the developing/OPC drum section (CL).
DVM_K	Developing motor (K)	Drives the developing/black OPC drum (BK)/transfer section.
TCS_C	Toner sensor (C)	Detects toner supply from the toner cartridge. Detects the toner density (C).
TCS_K	Toner sensor (K)	Detects toner supply from the toner cartridge. Detects the toner density (K).
TCS_M	Toner sensor (M)	Detects toner supply from the toner cartridge. Detects the toner density (M).
TCS_Y	Toner sensor (Y)	Detects toner supply from the toner cartridge. Detects the toner density (Y).

No.	Name	Function/Operation
1	Developing roller	Attaches toner to electrostatic latent images on the OPC drum and forms toner images.
2	Stirring roller	Stirs developer and toner to negatively charge toner.
3	Doctor	Maintains the quantities of toner and developer on the DV roller at a constant levels.
4	Toner filter (K, M, C, Y)	Prevents toner splash.
5	High voltage PWB (MC/DV PWB)	Generates the main charger voltage and the DV bias voltage.

### (2) Operational descriptions

Toner is attached to electrostatic latent images formed on the OPC drum surface by laser image beams to form toner images.



Toner and carrier in the developing unit are agitated and transported by the mixing roller.

By stirring, toner and carrier are negatively charged by mechanical friction.

The developing bias voltage (AC component and negative DC component) is applied to the developing roller.

Negatively charged toner is attracted to the exposed section on the OPC drum where the negative potential falls due to the developing bias.

If the OPC drum is not exposed, the negative potential is higher than the developing bias voltage, and toner is not attracted.

The toner sensor detects the toner supply state from the toner car-tridge.

In this machine, the toner density is detected by the toner sensor, but the toner supply operation is not controlled only by the toner density detection result. The toner density control is performed according to the process control data.



4

- I. Transfer section
- (1) Electrical and mechanism relation diagram
- a. Transfer section
- a-1 26cpm/31cpm machine







Signal name	Name	Function/Operation
1TC (CMY)	Primary transfer voltage (CMY)	Flows the transfer current to the primary transfer belt, and transfers toner images from the OPC drum to the transfer belt.
1TC (K)	Primary transfer voltage (K)	Flows the transfer current to the primary transfer belt, and transfers toner images from the OPC drum to the transfer belt.
1TUD_CL	Transfer mode detector (CL)	Detects separation of the transfer belt and the transfer mode. (Detection is made by combination of 1TUD_CL/1TUD_K signals.)
1TUD_K	Transfer mode detector (BK)	Detects separation of the transfer belt and the transfer mode. (Detection is made by combination of 1TUD_CL/1TUD_K signals.)
1TURC_1	Primary transfer separation clutch 1	Controls separation of the primary transfer unit.
1TURC_2	Primary transfer separation clutch 2	Controls separation of the primary transfer unit.
2TC	Secondary transfer belt voltage	Flows the transfer current to the secondary transfer belt, and transfers toner images from the primary transfer belt to paper.
2TUD	Secondary transfer position detector	Detects the position (separation) of the secondary transfer unit.
2TURC	Secondary transfer separation clutch	Controls separation of the secondary transfer unit.
BTM	Transfer belt drive motor	Drives the transfer belt. (For 36 cpm machine)
DVM_K	Developing motor (K)	Drives the developing/black OPC drum (BK)/transfer section.
PTC	PTC voltage	High voltage for PTC

No.	Name	Function/Operation
1	High voltage PWB (TC PWB)	Generates the transfer voltage.
2	Cleaning blade	Cleans residual toner on the primary transfer belt.
3	Primary transfer belt	Transfers toner images of the OPC drum onto the transfer belt.
4	Primary transfer roller (K, C, M, Y)	Applies a high positive voltage to the primary transfer belt.
5	Primary transfer belt drive roller	Drives the transfer belt. A negative voltage is applied when in the transfer operation, and an alternate high voltage (positive and negative) is applied when cleaning.
6	Primary transfer belt follower roller	Transfer belt follower drive
7	Primary transfer belt tension roller	Applies a tension to the transfer belt.
8	PTC opposed roller	Flows the PTC current to the GND.
9	Secondary transfer belt	Transfers toner images on the primary transfer belt to paper.
10	Secondary transfer roller	Connects the secondary transfer belt to the GND, and flows the transfer current.
11	Secondary transfer belt drive roller	Drives the transfer belt.
12	Secondary transfer belt follower roller	Transfer belt follower drive
13	PTC unit	Reduces positive charges on the primary transfer belt, and improves the transfer efficiency.
14	Primary transfer waste toner transport screw	Transports waste toner in the primary transfer cleaning unit to the waste toner collection section.
15	PTC cleaner	Clean the PTC wire.
16	Separation pawl	Separates paper after transfer.
17	Discharge brush	Discharges the secondary transfer belt surface after transfer to neutralize it.



Signal name	Name	Function/Operation
REGS_F/IMGDS	Registration sensor F (Inmate density sensor)	Detects color shift. (F side) / Detects the toner patch density.
REGS_R	Registration sensor R (Inmate density sensor)	Detects color shift. (R side) / Detects the toner patch density.

### (2) Operational descriptions

#### a. Transfer

### a-1. Transfer, cleaning operation

### Transfer operation



A high positive voltage is applied to the primary transfer roller to transfer toner images from the OPC drum to the primary transfer belt.

Negative electronic charges are generated by the PTC unit, supplying negative charges to toner.

This operation improves the transfer efficiency in the secondary transfer.

Then a high negative voltage is applied to the primary transfer drive roller, to transfer toner images from the primary transfer belt to paper.

#### Primary transfer cleaning operation

The primary transfer belt is cleaned mechanically by the cleaning blade.



Remaining toner removed from the primary transfer belt is transported to the waste toner collection section by the waste toner transport screw.

#### Secondary transfer cleaning

A high positive voltage is applied to the primary transfer belt to attach unnecessary toner to the primary transfer belt, and it is cleaned by the primary transfer belt cleaning.



#### Primary transfer belt mode select

There are three kinds of modes of the transfer belt: the free position, the color print mode, and the monochrome print mode.

Mode select is made with the developing motor, the mode select clutches 1TURC1 and 1TURC2.

When the roller separation clutch is turned ON, the transfer cam rotates, and the primary transfer link in conjunction with the cam is shifted in the arrow direction, separating the transfer roller.

The color transfer rollers (C, M, and Y) and the black transfer roller (K) perform an independent separation operation, and the mode state is detected by the combination of the transfer mode detector 1TUD_CL and 1TUD_K signals.

To select the rotating direction of the mode select cam, two mode select clutches 1TURC1 and 1TURC2 are used.

The two mode select clutches are used to select the mode in the shortest time.

Mada	Transfer mode detector	
Mode	1TUD_CL	1TUD_K
Monochrome print mode	ON	ON
Color print mode	OFF	ON
Free position	ON	OFF





# b. Image density detection and registration detection operation

The image density detection and the image registration detection are performed the sensors which are provided separately on the front frame side and the rear frame side.

#### b-1. Functions and operations of the color image density sensor and the image registration sensor F (REGS F) provided on the front frame side

When the process control is performed with one sensor, the color toner patch density is detected. When the image registration adjustment is performed, the image registration shift on the front frame side is detected.

A shutter plate is provided on the sensor. Before execution of the process control and the automatic registration adjustment, the standard reflection plate is closed and the sensor sensitivity adjustment is performed by using the standard reflection plate.



#### b-2. Functions and operations of the black image density sensor and the image registration sensor R (REGS R) provided on the rear frame side

When the process control is performed with one sensor, the black toner patch density is detected. When the image registration adjustment is performed, the image registration shift on the rear frame side is detected.

The sensor sensitivity adjustment is performed by using the standard reflection plate before execution of the process control and the automatic registration adjustment.



- J. Waste toner collection section
- (1) Electrical and mechanism relation diagram



Signal name	Name	Function/Operation
CPFM	Paper feed motor	Drives the paper feed section.
PFC_HPFC	Transport roller clutch	Controls the transport roller 4. / Drives the waste toner transport section.
TNFD	Waste toner full detector	Detects full of waste toner.
INFD	waste toner full detector	Detects full of waste toner.

No.	Name	Function/Operation
1	Waste toner transport screw	Transports waste toner to the waste toner box.
2	Waste toner box	Collects waste toner.

## (2) Operational descriptions

### a. Waste toner full detection operation

Waste toner generated in the OPC drum and the primary transfer cleaning section is transported to the waste toner box by the waste toner transport screw which is driven by the paper feed motor.

The toner collection box section is provided with the waste toner full detection mechanism. When the waste toner quantity in the toner collection box becomes full, the rotation load of the waste toner transport screw increases and the waste toner transport screw drive coupler is stranded to turn ON the waste toner full detector (TNFD).

When the waste toner full detector is turned ON continuously for 1 sec, it is judged as near end, and the message is display to indicate that the replacement of the toner collection box is approaching.





## 10. Fusing section

## A. Electrical and mechanism relation diagram



Signal name	Name	Function/Operation
FUFM	Fusing cooling fan	Cools the fusing section and the paper exit section.
FUM	Fusing motor	Drives the fusing section.

Signal name	Name	Function/Operation
HL_LM	Heater lamp (HL_LM)	Heats the fusing roller (B).
HL_UM/US	Heater lamp (HL_UM/US)	Heats the fusing roller (F1), and fusing belt.
HLPCD	Fusing pressure detector	Detects the fusing pressure state.
PRM	Fusing pressure control motor	Controls ON/OFF of the fusing roller pressure.
TH_LM_IN	Fusing temperature sensor	Detects the surface temperature of the fusing roller (B).
TH_UM_IN	Fusing temperature sensor (Main)	Detects the surface temperature at the center of the fusing belt.
TH_US_IN	Fusing temperature sensor (Sub)	Detects the suffered temperature at the edge section of the fusing belt.
TS LM	Thermostat LM	Shuts down the heater lamp (HL_LM) circuit when the fusing section is overheated.
TS UM	Thermostat UM	Shuts down the heater lamp (HL_UM) circuit when the fusing section is overheated. (Center section)
TS US	Thermostat US	Shuts down the heater lamp (HL_US) circuit when the fusing section is overheated. (Edge section)
WEBEND	Web end detector	Detects web end of the fusing unit.

No.	Name	Function/Operation
1	Fusing roller (F1)	Heats the fusing belt.
2	Fusing roller (F2)	The cushion layer of the roller forms a wide nip between the fusing belt and fusing roller (B).
3	Fusing roller (B)	Heats the back surface of paper to fuse toner on the paper.
4	Fusing web roller	Cleans the fusing roller (B) and the fusing belt.
5	HL control PWB	Drives the heater lamp.
6	Discharge brush	Discharges static electricity generated in the fusing section to the ground.
7	Separation plate	Separates the whole surface of paper. (non-contact)
8	Separation pawl	Separates fusing roller (B) when it is attached.
9	Fusing belt	Heats the front surface of paper to fuse toner on the paper.

## B. Outline of operations

This machine employs the fusing system by the belt.

The features of the belt-type fusing system are as follows:

- 1) Short warm-up time
- 2) Low power consumption
- 3) Wide nip providing high fusing capability

### C. Heater lamp driving

The surface temperature of the heat roller and the fusing belt detected by the fusing temperature sensor is sent to the PCU. If the temperature is lower than the specified temperature, the heater lamp lighting signal is sent from the PCU to the heater lamp drive circuit in the HL PWB.

When the power triac in the heater lamp drive circuit is turned ON, the AC power is supplied to the heater lamp to light the lamp and heat the fusing belt.

A thermostat is provided as a safety device against an abnormally high temperature in the heat roller and the fusing belt.

When the thermostat is opened, the AC power supply to the heater lamp is cut off.

The heater lamp is arranged to fusing roller (F1) and fusing roller (B).

In heater lamp (HL_UM/US), two lamps are integrated into one.

### Heater lamp operations

Heater lamp	Operation			
Heater lamp (HL_UM)	Heats fusing roller (F1) and the fusing belt.			
Heater lamp	Heats fusing roller (F1) and the fusing belt.			
(HL_US)	Turns ON continuously when in warming up.			
Heater lamp	Heats fusing roller (B). Does not turn ON while heater			
(HL_LM)	lamp (HL_UM) and heater lamp (HL_US) light up.			

## **D.** Fusing operation

Color toner (Y, M, C, and K) on paper is heated and pressed by the fusing belt, fusing roller (F2), and fusing roller (B) to be fused on paper.

Toner in the four layers on the paper is fused by heating from up and down and both sides.

The fusing belt, fusing roller (F2) which is provided with the cushion layer, and fusing roller (B) realize the following operations.

- 1) The nip amount is increased and the heat capacity to paper is increased.
- By pressing with the flexible roller, toner of many layers can be fused without being deformed.
- An even pressure is applied to rough surface of toner (due to the multi-layer composition).



## E. Automatic pressure release system

Normally the upper and lower heat rollers are pressed. When, however, the following conditions are satisfied, the pressure is released.

- When the machine shifts to the preheat mode.
- When the machine shifts to the auto power shut off mode.
- When the power switch of the operation panel is turned OFF.
- When the machine is left for 90 sec under the ready state.
- When in the envelope mode.
- When a jam occurs.

#### (1) Pressure release operation

The fusing pressure control motor (PRM) rotates to turn ON the fusing pressure detector (HLPCD) (H level). When the specified time passes after turning ON the fusing pressure detector (HLPCD) (H level) by rotation of the fusing pressure control roller (PRM), the pressure release motor stops to complete the pressure release operation.



#### (2) Pressure release operation

When the end user makes some operations or when the machine receives the Job signal, the fusing pressure control motor (PRM) rotates reversely to drive the pressure release lever to the pressing state.

When the specified time passes from turning OFF the fusing pressure detector (HLPCD), the pressure release motor stops to complete the pressing operation.





When turning OFF the main power switch of the machine, be sure to turn OFF the power switch of the operation panel and check to confirm that the LCD display goes off before turning OFF the main power switch.

If the main power switch is turned OFF with the LCD lighted, the power is cut off before completion of the pressure release operation. If this state is kept for a long time, the fusing roller may be deformed.

## F. Fusing section cleaning

In this machine, the fusing roller (B) is cleaned by the web.

The cleaning unit is composed of the web feed roller, the winding roller, and the backup roller which presses the web onto the fusing roller (B) with the proper pressure.

Residual toner on the fusing roller (B) is cleaned by the web which contains silicon oil.



Fusing roller (B)

## G. Web life end detection

The web life near end is detected by the web print counter. When the life reaches 200K prints, the following message is displayed to notify that the replacement timing is approaching. (Maintenance required a  $\Sigma(2)$ )

(Maintenance required.: FK3)

The web life end is detected by the web end detector. When the life end is detected, a job is forcibly interrupted even the job is being performed.

After replacing the web with a new one, reset the web life counter and the web send counter to clear the life end state.



## 11. RSPF section

- A. Electrical and mechanical relation diagram
- (1) Paper feed section



Signal name	Name	Function/Operation
SPED	Document sensor	Detects document empty in the RSPF paper feed tray.
SPLS1	Paper size detector 1	Detects the document length in the RSPF paper feed tray.
SPLS2	Paper size detector 2	Detects the document length in the RSPF paper feed tray.
SPM (SPUM)	RSPF paper feed motor	Feeds a document.
SPPD1	Document transport sensor 1	Detects paper feed and the document size in random paper feed.
SPWS	Document size detector	Detects the document width.

No.	Name	Function/Operation
1	Document pickup roller (RSPF)	Feeds a document to the paper feed roller.
2	Paper feed roller (RSPF)	Feeds a document to the transport section. Makes a warp on paper between the registration roller and
		this roller to correct the start position of document skew and document image scan.
3	Separation roller (RSPF)	Separates a document to prevent double-feeding.



Signal name	Name	Function/Operation
SCOV	RSPF cover open/close detector	Detects open/close of the RSPF cover.
SOCD	RSPF open/close sensor	Detects open/close of the RSPF unit.
SPFM	RSPF transport motor	Transports a document.
SPPD2	Document transport sensor 2	Detects paper pass.
SPPD3	Document transport sensor 3	Detects paper pass.
SPPD4	Document transport sensor 4	Detects paper exit and switchback.
SPRS	Paper exit roller pressure control solenoid	Controls ON/OFF of the transport power of the paper exit roller. (Releases the paper exit roller
	(RSPF)	pressure when reversing paper.)
SRRC	Registration roller clutch (RSPF)	Controls the registration roller. (Controls the timing of document transport.)
STMPS	Stamp solenoid	Drives the finish stamp.

No.	Name	Function/Operation
1	Transport auxiliary roller (RSPF)	Reduces friction between a document and the paper guide to transport the document smoothly to the registration roller.
2	Registration roller (Drive) (RSPF)	Transports a document to the transport roller 2. / Controls the transport timing of the document and adjusts the document scanning timing.
3	Registration roller (Idle) (RSPF)	Apply a pressure to a document and the registration roller to provide the transport power of the transport roller to the document.
4	Transport roller 3 (Idle) (RSPF)	Apply a pressure to a document and the transport roller to provide the transport power of the transport roller to the document.
5	Transport roller 3 (Drive) (RSPF)	Transports a document transported from the document scanning section to the paper exit roller.
6	Transport roller 2 (Idle) (RSPF)	Apply a pressure to a document and the transport roller to provide the transport power of the transport roller to the document.
7	Transport roller 2 (Drive) (RSPF)	Transports a document transported from the registration roller to the document scanning section.
8	Paper exit roller (Idle) (RSPF)	Apply a pressure to a document and the paper exit roller to provide the transport power of the paper exit roller to the document.
9	Paper exit roller (Drive) (RSPF)	Discharges a document. Switchbacks the document and transports it to the registration roller when scanning the back surface.
10	Document reverse gate	Reverses a document when scanning images on the back surface.
11	RSPF driver PWB	Drives the motor, the solenoid, and the clutch in the RSPF section.

## **B.** Operational descriptions

### (1) Document size detection

#### Size detection on the document tray

The document width is detected with the RSPF document width sensor (SPWS), and the document length is detected with the RSPF document length sensors (SPLS1, SPLS2). The document size is judged from the document width and the document length according to the table below. When documents of different sizes are mixed and set on the document tray, the largest document size is detected.

	Decument size	Document length sensor			
	Document size	SPLS1	SPLS2		
AB series	A5	OFF	OFF		
	B5	OFF	OFF		
	11" x 8.5"	OFF	OFF		
	A4	OFF	OFF		
	B5R	ON	OFF		
	A4R	ON	OFF		
	8.5" x 13"	ON	ON		
	B4	ON	ON		
	A3	ON	ON		
	11" x 17"	ON	ON		
	8.5" x 14"	ON	ON		
	8.5" x 13.4"	ON	ON		
	8.5" x 13.5"	ON	ON		
Inch series	8.5" x 5.5"	OFF	OFF		
	11" x 8.5"	OFF	OFF		
	A4	OFF	OFF		
	11" x 8.5"R	ON	OFF		
	8.5" x 13"	ON	ON		
	8.5" x 14"	ON	ON		
	A3	ON	ON		
	11" x 17"	ON	ON		
	8.5" x 13.4"	ON	ON		

### RSPF unit



#### (2) Document scanning

The document scanning mode is available in 400dpi and 600dpi.

Resolution	Document transport speed
400dpi	259mm/sec
600dpi	173mm/sec

### (3) RSPF paper feed and transport operations

#### a. Paper feed operation

The paper feed motor is turned ON and the power of the paper feed motor is transmitted to the pickup roller and the paper feed roller.

The pickup roller descends to pickup the top document and feed it to the paper feed roller.

The paper feed roller feeds a document to the transport section.

At that time, the document is separated by the separation roller to prevent double-feeding.

#### b. Single face scanning

The lead edge of the fed document is aligned (registration) by the registration roller, and passed through transport roller 1 to the document scanning section, where images are scanned.

Then the document is passed through transport roller 2 to the paper exit roller.

The rollers (the registration roller, transport rollers 1 and 2, the paper exit roller) in the transport section are driven by the transport motor.

The paper exit roller (drive pulley) is separated by the paper exit roller pressure control solenoid.

When the read edge of the document passes the scanning section, the both rollers are brought into close contact to supply the power for paper exit.

1) Document set (Document empty sensor ON)



2) Paper feed start (1st sheet)

The pick-up roller descends. (The paper feed motor is booted.) (The transport motor is booted simultaneously.)



#### Registration operation (1st sheet) (Registration clutch ON)

(When a certain time passes after turning ON the registration clutch, the paper feed motor is turned OFF.)



4) Scanning start (1st sheet)



5) Paper feed start (2nd sheet)



6) Scanning complete (1st sheet)/Registration operation (2nd sheet)

(When a certain time passes after turning ON the registration clutch, the paper feed motor is turned OFF.)



7) Scanning start (2nd sheet)



8) Paper exit complete (1st sheet)



9) Scanning complete (2nd sheet)



10) Paper exit complete (2nd sheet)



11) Pick-up roller lifting up

(After completion of a job, the paper feed motor is rotated reversely at a low speed for a certain time to lift the pickup roller.)



#### c. Duplex scanning

Images on the document surface are scanned, and detection of the rear edge of the document by sensor SPPD3 triggers the following. That is, when the rear edge of the document passes the reverse gate, the transport motor is reversed.

Due to the above operation, the paper exit roller is reversed to switchback the document, returning it to the registration roller section and aligning (registration) the document.

Then the transport motor is rotated normally to transport the document to the scanning section, scanning images on the back surface.

To reset the page order of the documents, the following operations are made which are triggered by the detection of the rear edge of the document. That is, when the rear edge of the document passes the reverse gate, the transport motor is reversed.

Due to the above operation, the paper exit roller is reversed to switchback the document, returning it to the registration roller section and aligning (registration) the document.

Then the transport motor is rotated normally to transport the document to the paper exit section and discharge it.

When a duplex document is scanned, the document lead edge section and the rear edge section intersect. At that timing, the paper exit roller pressure release solenoid is turned ON to make a gap between the paper exit roller (drive) and the paper exit roller (idle).

During the time from when the document rear edge passes the scanning section to when it is switch backed and send to the registration roller section, the paper exit roller pressure release solenoid is turned OFF to keep the paper exit roller (drive) and the paper exit roller (idle) in contact.

1) Document set (Document empty sensor ON)



2) Paper feed start (1st sheet) Pick-up roller descending



3) Registration operation (1st sheet, front surface)



4) Scanning start (1st sheet, front surface)



5) After completion of scanning, the reverse follower roller is pressed. (Solenoid ON)



6) After stopping the operation, reversing is started.



7) After reversing, registration operation is executed.



 After turning ON the PS clutch, the reverse follower roller pressure is released.



9) Scanning start (First sheet, back surface)



10) After completion of scanning, the reverse follower roller is pressed.



11) After stopping the operation, reversing is started.



12) After reversing, registration operation is executed.



 After turning ON the PS clutch, the reverse follower roller pressure is released.



14) Scanning start (Second sheet)



15) After passing the scanning section, the reverse follower roller is pressed.



16) After discharge (First sheet), the reverse follower roller pressure is released.



### d. Stamp operation

1) Document set (Document empty sensor ON)



2) Paper feed start (1st sheet)

Pick-up roller descending (The paper feed motor is booted.) (The transport motor is booted simultaneously.)



3) Registration operation (1st sheet)

(Registration clutch ON)

(When a certain time passes after turning ON the registration clutch, the paper feed motor is turned  $\ensuremath{\mathsf{OFF.}}\xspace$ )



4) Scanning start (1st sheet)



5) Scanning complete (1st sheet)



 Stop at the stamp position/Stamp operation (1st sheet) (Stamp solenoid ON)



7) Paper exit start (1st sheet)/Preliminary paper feed start (2nd sheet)



8) Paper exit complete (1st sheet)



 Stop at the stamp position/Stamp operation (2nd sheet) (Stamp solenoid ON)



10) Paper exit start (2nd sheet)



11) Paper exit complete (2nd sheet)



12) Pick-up roller lifting up

(After completion of a job, the paper feed motor is rotated reversely at a low speed for a certain time to lift the pickup roller.)



## 12. Fan and filter

The machine is provided with the following fan to discharge air from the process section and cool the fusing section and the power unit.

Signal name	Name	Function/Operation
FUFM	Fusing cooling fan	Prevents heat generated in the fusing section from lowing into the toner cartridge and the paper exit section.
POFM	Paper exit cooling fan	Cools the fusing section and the paper exit section.
POFM2	Paper exit cooling fan	Cools the fusing section and the paper exit section.
PROFM	Process fan motor 1	Blows air to the main charger and the PTC unit to promote discharging of ozone generated.
PROFM2	Process fan motor 2	Discharges ozone generated in the main charger and the PTC unit, and cools the developing unit.
PSFM	Power cooling fan motor	Cools the power unit.

The flow of air is as shown in the figure below.



The machine is provided with the following filter to remove ozone generated in the process section.

Filter process fan motor 1 produces an air flow to generate a difference in the air pressure between inside outside of the developing unit, preventing toner from splashing from the open port of the developing unit.

The toner filter prevents toner from leaking from the slit caused by this difference in air pressure.

No.	Name	Function/Operation			
1	Toner filter	Prevents toner splash.			
2	Ozone filter	Absorbs ozone generated in the image process section.			

## 13. Operations and specifications of counters

## A. Counters and count conditions

		Counter					
						Job lo	g
Condition		Print image	Total counter	User counter	Pixel count	Valid paper counter	Invalid paper counter
Normal disch	arge paper	Valid image	Counted	Counted	Counted as a corresponding job.	Counted	Not counted
Simplex surfation the duplex jol	ace white paper in	White paper	Not counted	Not counted	Not counted	Not counted	Not counted
White paper of insert paper	of cover paper,	White paper	Select with the setting of SIM26-52.	Select with the setting of SIM26-52.	Not counted	Select with the setting of SIM26-52.	Not counted
Size illegal	Transfer completed	Valid image for some paper sizes	Counted	Counted	Counted as a corresponding job.	Counted	Not counted
	Transfer not completed	White paper	Not counted	Not counted	Not counted	Not counted	Counted
Document jar the RSPF pul	n involvement in lling mode	White paper	Not counted	Not counted	Not counted	Not counted	Counted
Anti copy	Paper for transfer OFF	Invalid image	Counted	Counted	Counted as a corresponding job.	Counted	Not counted
	Following paper	White paper	Not counted	Not counted	Not counted	Not counted	Counted
White paper at CA cancel		White paper	Not counted	Not counted	Not counted	Not counted	Counted
Remaining paper at a paper jam		Not discharged	Not counted	Not counted	Counted as the other.	Not counted	Not counted
Amount of pri paper feed sl	int cancel for ip or paper empty	-	-	-	Counted as the other.	-	-

## B. Maintenance system counters (Print counter)

				Count-up number					
				Simplex pr	surface		Duplex su	rface print	
Counter name	Count-up timing	Display SIM	Reset SIM	Paper feed tray - Paper exit		Paper feed tray - ADU paper entry		ADU paper feed - Paper exit	
				com	oleted	comp	oleted	comp	oleted
				Small	Large	Small	Large	Small	Large
				size	size	size	size	size	size
Maintenance counter (Total)	All paper exit operations completed	SIM22-13	SIM24-4	1	2(1)*1	1	2(1)*1	1	2(1)*1
Maintenance counter (Color)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
Fusing belt print counter	All paper exit operations completed	SIM22-13	SIM24-4	1	2(1)*1	1	2(1)*1	1	2(1)*1
Fusing roller print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
Pressure roller print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
Separation pawl print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
Separation plate print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
Fusing web print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
Primary transfer unit print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
Transfer blade print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
PTC print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
Secondary transfer unit print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
PS paper dust cleaner print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1
Developer cartridge print counter (K)	All paper exit operations completed	SIM22-13	SIM24-5 SIM25-2	1	2(1)*3	1	2(1)*3	1	2(1)*3
Developer cartridge print counter (C)	Color paper exit operations completed			1	2(1)*3	1	2(1)*3	1	2(1)*3
Developer cartridge print counter (M)	Color paper exit operations completed			1	2(1)*3	1	2(1)*3	1	2(1)*3
Developer cartridge print counter (Y)	Color paper exit operations completed			1	2(1)*3	1	2(1)*3	1	2(1)*3

						Count-up number				
	Simplex surfac print		surface	Duplex surface print						
Counter name	Count-up timing	Display SIM	Reset SIM	Paper feed tray - Paper exit completed		Paper feed tray - ADU paper entry completed		ADU paper feed - Paper exit completed		
				Small size	Large size	Small size	Large size	Small size	Large size	
Drum cartridge print counter (K)	All paper exit operations completed	SIM22-13	SIM24-4	1	2(1)*1	1	2(1)*1	1	2(1)*1	
Drum cartridge print counter (C)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Drum cartridge print counter (M)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Drum cartridge print counter (Y)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Main charger print counter (K)	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Main charger print counter (C)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Main charger print counter (M)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Main charger print counter (Y)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Drum blade print counter (K)	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Drum blade print counter (C)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Drum blade print counter (M)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Drum blade print counter (Y)	Color paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Ozone filter print counter	All paper exit operations completed			1	2(1)*1	1	2(1)*1	1	2(1)*1	
Toner cartridge print counter (K)	All paper exit operations completed	SIM22-13	-	1	2(1)*4	1	2(1)*4	1	2(1)*4	
Toner cartridge print counter (C)	Color paper exit operations completed			1	2(1)*4	1	2(1)*4	1	2(1)*4	
Toner cartridge print counter (M)	Color paper exit operations completed			1	2(1)*4	1	2(1)*4	1	2(1)*4	
Toner cartridge print counter (Y)	Color paper exit operations completed			1	2(1)*4	1	2(1)*4	1	2(1)*4	

*1: The number in () is the count-up number when the large-size count-up setting is changed to the single count-up with SIM26-5 (Maintenance count (B/W, COL)).

*3: The number in () is the count-up number when the large-size count-up setting is changed to the single count-up with SIM26-5 (Developer count (B/W, COL)).

*4: The number in () is the count-up number when the large-size count-up setting is changed to the single count-up with SIM26-5 (Total count (B/W, COL)).

## C. Maintenance system counters (Number of rotations)

				Count-up number						
				Simplex surface print Paper feed tray - Paper exit		Duplex surface print				
Counter name	Count-up timing	Display SIM	Reset SIM			Paper fe ADU par	Paper feed tray - ADU paper entry		er feed - r exit	
				com	pleted	comp	leted	comp	leted	
				Small	Large	Small size	Large size	Small	Large size	
Fusing belt accumulated rotation time	While the fusing motor is driven.	SIM22-13	SIM24-4	0120	* Calcul	RPM (I ated from th	Unit: 1) e traveling	distance.	0120	
Fusing roller accumulated	While the fusing motor is						Ū			
rotation time	driven.									
rotation time	driven.									
Separation pawl accumulated	While the fusing motor is									
rotation time	driven.	_								
separation plate accumulated	driven.									
Primary transfer unit	While the primary transfer unit									
accumulated rotation time	is driven.									
Transfer blade accumulated	While the drum (K) is driven.									
PTC accumulated rotation time	While the drum (K) is driven.	-								
Secondary transfer unit	While the secondary transfer									
accumulated rotation time	unit is driven	011400 40		-						
accumulated rotation time (K)	vvnile the drum (K) is driven.	SIM22-13	SIM24-5 SIM25-2							
Developer cartridge accumulated rotation time (C)	While the drum (C) is driven.									
Developer cartridge accumulated rotation time (M)	While the drum (M) is driven.									
Developer cartridge accumulated rotation time (Y)	While the drum (Y) is driven.									
Drum cartridge accumulated rotation time (K)	While the drum (K) is driven.	SIM22-13	SIM24-4							
Drum cartridge accumulated rotation time (C)	While the drum (C) is driven.									
Drum cartridge accumulated rotation time (M)	While the drum (M) is driven.									
Drum cartridge accumulated rotation time (Y)	While the drum (Y) is driven.									
Main charger accumulated rotation time (K)	While the drum (K) is driven.									
Main charger accumulated rotation time (C)	While the drum (C) is driven.									
Main charger accumulated rotation time (M)	While the drum (M) is driven.									
Main charger accumulated rotation time (Y)	While the drum (Y) is driven.									
Drum blade accumulated rotation time (K)	While the drum (K) is driven.									
Drum blade accumulated rotation time (C)	While the drum (C) is driven.									
Drum blade accumulated rotation time (M)	While the drum (M) is driven.									
Drum blade accumulated rotation time (Y)	While the drum (Y) is driven.									
Toner motor accumulated rotation time (K)	While the toner motor (K) is driven.	SIM22-13	-		* Calc	RPM (I culated from	Unit: 1) the rotating	g time.		
Toner motor accumulated	While the toner motor (C) is									
Toper motor accumulated	ariven. While the toner motor (M) is	-								
rotation time (M)	driven.	-								
rotation time (Y)	driven.									

## D. Maintenance system counters (Number of use days)

						Count-u	o number		
		Display SIM	Reset SIM	Simplex surface print Paper feed tray - Paper exit completed		Duplex surface print			
Counter name	Count-up timing					Paper feed tray - ADU paper entry completed		ADU paper feed - Paper exit completed	
				Small size	Large size	Small size	Large size	Small size	Large size
Number of day that used maintenance counter (Total)	Date change	SIM22-13	SIM24-4			1 (Uni	t: day)		
Number of day that used maintenance counter (Color)									
Number of day that used fusing belt (Excluding the 18cpm/20cpm machine)	Date change	SIM22-13	SIM24-4	-					
Number of day that used fusing roller									
Number of day that used pressure roller									
Number of day that used separation pawl									
Number of day that used separation plate									
Number of day that used fusing web									
Number of day that used primary transfer unit									
Number of day that used transfer blade									
Number of day that used PTC									
Number of day that used secondary transfer unit									
Number of day that used PS paper dust cleaner									
Number of day that used developer cartridge (K)	Date change	SIM22-13	SIM24-5						
Number of day that used developer cartridge (C)			SIM25-2						
Number of day that used developer cartridge (M)									
Number of day that used developer cartridge (Y)									
Number of day that used drum cartridge (K)	Date change	SIM22-13	SIM24-4						
Number of day that used drum cartridge (C)									
Number of day that used drum cartridge (M)									
Number of day that used drum cartridge (Y)									
Number of day that used main charger (K)									
Number of day that used main charger (C)									
Number of day that used main charger (M)									
Number of day that used main charger (Y)									
Number of day that used drum blade (K)									
Number of day that used drum blade (C)									
Number of day that used drum blade (M)									
Number of day that used drum blade (Y)	-								
Number of day that used ozone filter				1					
Number of day that used toner cartridge (K)	Date change	SIM22-13	-						
Number of day that used toner cartridge (C)	4								
Number of day that used toner cartridge (M)	4								
Number of day that used toner cartridge (Y)									

## E. Maintenance system counters (Other)

				Count-up number					
				Simplex surface print Paper feed tray - Paper exit completed			Duplex su	rface print	
Counter name	Count-up timing	Display SIM	Reset SIM			Paper feed tray - Paper feed tray   Paper exit ADU paper end   completed completed		ADU paper feed - Paper exit completed	
				Small	Large	Small	Large	Small	Large
Staple counter	When requesting for staple	SIM22-8	SIM24-3	size	size	Number	of stanles	size	size
Punch counter	When requesting for supple	0111122 0	0111124 0						
Manual paper feed counter (Total)	When manual paper feed is started	SIM22-9	SIM24-2	1					
Manual paper feed counter (Heavy paper)	When manual paper feed of heavy paper is started (without distinction between heavy paper 1 and 2)								
Manual paper feed counter (OHP)	When manual paper feed of OHP sheet is started								
Manual paper feed counter (Envelope)	When manual paper feed of envelopes is started								
Tray 1 counter	When tray 1 paper feed is started								
Tray 2 counter	When tray 2 paper feed is started (request)								
Tray 3 counter	When tray 3 paper feed is started (request)								
Tray 4 counter	When tray 4 paper feed is started (request)								
LCC counter	When LCC paper feed is started (request)								
ADU counter	When ADU paper feed is started	SIM22-9	SIM24-2				1		
Fusing web cleaning feed counter (36cpm machine only)	When the fusing web cleaning roller is rotated	SIM22-13	SIM24-4			Number	of pulses		
Toner use number counter (K)	When toner near end is	SIM22-14	SIM24-35				1		
Toner use number counter (C)	detected (*2)								
Toner use number counter (M)									
Toner use number counter (Y)									
Toner near end number counter (K)	When toner near near end								
Toner near end number counter (C)	is detection								
Toner near end number counter (M)									
Toner near end number counter (Y)									

## F. RSPF/Scanner counter

Counter name	Display SIM	Reset SIM	Count-up timing	NOTE
RSPF counter	SIM22-8	SIM24-3	When SPF document discharge is completed. The front surface in duplex scan is counted when the reverse operation is stopped.	Number of discharge of document from the SPF
Scan counter	SIM22-8	SIM24-3	When the scanner carriage feed is completed.	Number of times of scan
Finish stamp counter	SIM22-8	SIM24-3	When the stamp is ON.	Number of use of the finish stamp
Cover open/close counter	SIM22-8	SIM24-3	When the document cover close is detected.	Number of open/close of the cover
Home detection counter	SIM22-8	SIM24-3	When the home sensor ON is detected.	Number of detection of the home position
Scanner lamp lighting time counter	SIM22-8	SIM24-3	When the scanner lamp is lighted.	Scanner lamp lighting time

# [14] ELECTRICAL SECTION

## 1. Block diagram

## A. System block diagram













With secure locking device BM30B-SHLDS MFP IF Connector <+24V +5V +33V +5V2 RES_FAX 3.3V FAX_RXD(D)+ FAX_RXD(D)-FAX_TXD(CS)+ FAX_TXD(CS)-FAX_RTS(CS)-FAX_TXD(D)+ FAX_TXD(D)-FAX_CTS(D)-FAX_RTS(D)-FAX_RXD(CS) FAX_RXD(CS) FAX_CTS(CS) CNCT_FAX-Crystal Resonator 14.7456MHz FLVPP VE.6+~ BD45285G STATUS LED_0 STATUS LED_0 STATUS LED_1 (Not mount) ₽ŝ  $\mathbf{b}$ 1.3V Filter MDM3.3V Filter Voltage Regulator R1173S001B Spred Spectrum CY25811SXCT voltage level +5VA 26 +24V PROGRAM FLASH ROM 16Mb VHIM29LV16 B-1Q WORK MEMORY SDRAM 64Mbit A3V 64S40ETP-G6 FAX IMAGE MEMORY (Not mount) FLASH ROM 16Mbit +24V Detection CPU SH7706 FAX WUP AUART MON_24V-16bit 16bit 16bit 16bit FAX MAIN PWB JTAG Connector 14pin (Not mount) Log Connector (Not mount) 16bit 16bit VDM3.3V UART FAX ASIC MB87F4930 MODEM MMD5020 CID-Nownload EN_SPKON-SEN_BZON-1.8V VOLB VOLD VOLD +24V +12V J ₽ BZ Voltage Regulator NJU7772F 18 +12 Crystal Resonator 24.576MHz Volume Change BU4066 NJM3414 PIC PIC16F690 3.3V . AV5 Power Amplifier LM4819 CI Filter Speaker Connector S02B-PASK Speaker ASPCLK ABITCLK ARXD ATXD BSPCLK BBITCLK BRXD BTXD RGDT-(Cl detection) HDMUTE-RHS-SI3_RES-CI2-TEL/LIU Connector AFE_CLK AFE_RES-MSGMUTE TELID2 SPK(analog) EXHS-MRON 150VON TELID SON2 HS2-CION ECON SON1 HS1ö voltage level voltage level Si3056 Cl Detection Polarity inversion Detection (Ndt mount) Silicon DAA Si3056 CHIP SET Operation in 1W/7W energy-save mode Т LIU EX PWB Si3019  $\downarrow$ S relay +5V2 OFF fock detection MJ1 (INE) MJ2 (TEL)

# G. FAX section

(1) MX-FX11



## 2. Power line diagram

## A. AC power line diagram

(1) AC power line diagram (120V)








# 3. Actual wiring chart

A. MFPC, LSU







### D. CSS1, Paper feed, Transport, Main drive, RESI







## F. Paper exit, Frame fusing, DRV PWB





#### G. CRUM, Motor





## H. Process, DV, High voltage











# 4. Signal list

Circul nome	Neme [Trine]	Eurotian/Operation	Connec	tor level	Connector	Pin	PWB	NOTE
	Name [Type]		L	н	No.	No.	name	NOTE
110D_CL	detection	separation CL.	-	_	CN18	1	PCU	
1TUD_K	Transfer belt separation BK detection	Detects the transfer belt separation BK.	-	-	CN18	2	PCU	
1TURC_1	Primary transfer separation clutch	Controls the primary transfer separation mode. [Electromagnetic clutch]	Separation select	-	CN16	7	PCU	
1TURC_2	Primary transfer separation clutch [Electromagnetic clutch]	Controls the primary transfer separation mode.	Separation select	-	CN16	8	PCU	
2TCCRU	Secondary transfer unit initial detection	Detects the initial state of the secondary transfer unit.	-	-	CN10	9	PCU	
2TUD	Secondary transfer position detection	Detects the position of the secondary transfer.	Separate	Contact	CN10	5	PCU	
2TURC	Secondary transfer separation clutch [Electromagnetic clutch]	Controls the secondary transfer separation mode.	Separation select	-	CN10	7	PCU	
ADUGS	ADU gate solenoid	Controls the ADU gate solenoid.	ON	OFF	CN10	18	PCU	
ADUM	ADU motor		-	-	CN11	23, 25, 26	PCU	
ADUM_CNT	ADU motor current select	ADU motor lower current select	Current Large	Current Small	CN11	24	PCU	
APPD1	ADU transport path detection 1	Detects paper pass in the ADU upper stream section.	Pass	-	CN10	14	PCU	
APPD2	ADU transport path detection 2	ADU midstream paper pass detection	Pass	-	CN10	11	PCU	
CCFT	LCD backlight [CCFT cool cathode ray tube]	LCD backlight	ON	OFF	CN4	21	SCNcnt	
CL_ON	Scanner lamp	Radiates light onto a document for the CCD to scan the document image.	ON	OFF	CN8	3	SCNcnt	
CLUD1	Tray 1 upper limit detection (Lift HP detection) [Transmission type]	Detects the tray 1 upper limit.	_	Upper limit	CN9	23	PCU	
CLUD2	Tray 2 upper limit detection (Lift HP detection) [Transmission type]	Detects the tray 2 upper limit.	-	Upper limit	CN8	11	PCU	
CLUM1	Paper tray lift-up motor (Paper feed tray 1) [DC brush motor]	Drives the paper tray lift plate.	Stop	Drive	CN9	20	PCU	
CLUM2	Paper tray lift-up motor (Paper feed tray 2) [DC brush motor]	Drives the paper tray lift plate.	Stop	Drive	CN8	8	PCU	
CPED1	Tray 1 paper empty detection [Transmission type]	Detects paper empty in the tray 1.	YES	NO	CN9	25	PCU	
CPED2	Tray 2 paper empty detection [Transmission type]	Detects paper empty in the tray 2.	YES	NO	CN8	13	PCU	
CPFC1	Tray vertical transport clutch 1 [Electromagnetic clutch]	Controls ON/OFF of the paper transport roller in the paper feed tray section.	ON	OFF	CN11	17	PCU	
CPFC2	Tray vertical transport clutch 2 [Electromagnetic clutch]	Controls ON/OFF of the paper transport roller in the paper feed tray section.	ON	OFF	CN8	2	PCU	
CPFD1	Tray 1 transport detection (Paper entry detection) [Transmission type]	Detects paper pass in the tray 1.	Pass	-	CN9	27	PCU	
CPFD2	Tray 2 transport detection (Paper entry detection) [Transmission type]	Detects paper pass in the tray 2.	Pass	-	CN8	15	PCU	
CPFM_D	Paper feed motor [Brushless motor]	Drives the paper feed section.	Drive	Stop	CN12	24	PCU	
CPFM_LD	Paper feed motor lock detection	Detects the paper feed motor lock.	-	Lock detection	CN12	28	PCU	
CPUC1	Paper feed clutch (Paper feed tray 1) [Electromagnetic clutch]	Controls ON/OFF of the roller in the paper feed trav section	ON	OFF	CN11	18	PCU	
CPUC2	Paper feed clutch (Paper feed tray 2) [Electromagnetic clutch]	Controls ON/OFF of the roller in the paper feed trav section.	ON	OFF	CN8	1	PCU	
CPUS1	Paper feed pickup solenoid (Paper feed tray 2) [Solenoid]	Controls the paper pickup solenoid.	ON	OFF	CN9	17	PCU	
CPUS2	Paper feed pickup solenoid (Paper feed tray 2) [Solenoid]	Controls the paper pickup solenoid.	ON	OFF	CN8	5	PCU	

0:	Name (Terral)	Europhian (Oropertient	Connec	tor level	Connector	Pin	PWB	NOTE
Signal name	Name [Type]	Function/Operation	L	н	No.	No.	name	NOTE
CSPD1	Tray 1 remaining paper quantity detection	Detects the remaining paper quantity in the tray 1.	Remaining quantity	_	CN9	32	PCU	Detects during lifting
CSPD2	Tray 2 remaining paper quantity detection	Detects the remaining paper quantity in the tray 2.	Remaining quantity	-	CN8	20	PCU	Detects during lifting up.
CSS11	Tray 1 detection	Detects the tray 1.	YES	NO	CN9	24	PCU	
CSS21	Tray 2 detection	Detects the tray 2.	YES	NO	CN8	12	PCU	
CSS2SET	Cassette 2 unit detection	Detects the cassette 2 unit.	YES	NO	CN8	22	PCU	
DHPD CL	CL phase detection	Detects the CL phase.	Reference	_	CN16	2	PCU	
DHPD K	BK phase detection	Detects the BK phase.	Reference	_	CN16	1	PCU	
DL_BK	Discharge lamp BK [LED]	Discharges electric charges on	OFF	ON	CN14	8	PCU	
DL_C	Discharge lamp C [LED]	Discharges electric charges on the OPC drum.	OFF	ON	CN14	4	PCU	
DL_M	Discharge lamp M [LED]	Discharges electric charges on	OFF	ON	CN14	7	PCU	
DL_Y	Discharge lamp Y [LED]	Discharges electric charges on the OPC drum	OFF	ON	CN14	3	PCU	
DSW_ADU	ADU transport open/close detection [Transmission type]	Detects ADU cover open/ close.	Open	Close	CN10	12	PCU	
DSW_C1	Tray 1 transport cover open/	Detects tray 1 transport cover	Open	Close	CN9	31	PCU	
DSW_C2	Tray 2 transport cover open/	Detects tray 2 transport cover	Open	Close	CN8	19	PCU	
DSW_F	Front door open/close switch [Micro switch]	Detects open/close of the front door, and fusing, motor, LSU laser power line.	Open	Close	CN11	12	PCU	
DSW_R	Right door open/close switch [Micro switch]	Detects open/close of the right door unit, and fusing, motor, LSU laser power line.	Open	Close	CN11	10	PCU	
DVM_CL_D	Development drive motor (CL) [Brushless motor]	Drives the development section, the color OPC drum, and the transfer section.	Drive	Stop	CN16	14	PCU	
DVM_CL_LD	Development drive motor (CL) lock detection	Detects the development drive motor (CL) lock.	-	Lock detection	CN16	16	PCU	
DVM_K_D	Development drive motor (K) [Brushless motor]	Drives the development section, the black OPC drum, and the transfer section.	Drive	Stop	CN16	13	PCU	
DVM_K_LD	Development drive motor (K) lock detection	Detects the development drive motor (K) lock.	-	Lock detection	CN16	15	PCU	
FUFM_LD	Fusing fan motor lock detection	Detects the fusing fan motor lock.	-	Lock detection	CN12	25	PCU	
FUFM_V	Fusing fan motor	Cools the motor related to the fusing and the paper exit sections.	OFF	ON	CN12	19	PCU	
FUM_D	Fusing drive motor [Brushless motor]	Drives the fusing unit.	Drive	Stop	CN13	17	PCU	
FUM_LD	Fusing drive motor lock detection	Detects the fusing drive motor lock.	-	Lock detection	CN13	19	PCU	
HL_LM_out	Lower heater lamp	Turns ON/OFF the lower heater lamp.	OFF	ON	CN13	13	PCU	
HL_PR	Heater lamp power relay	Heater lamp power line ON/ OFF	OFF (Open)	ON (Close)	CN19	26	PCU	
HL_UM_out	Heater lamp main	Turns ON/OFF the heater lamp main.	OFF	ON	CN13	9	PCU	
HL_US_out	Heater lamp sub	Turns ON/OFF the heater lamp sub.	OFF	ON	CN13	11	PCU	
HLPCD	Fusing pressure detection sensor [Transmission sensor]	Detects a change in the fusing pressure.	Pressure release	Pressure applying	CN13	3	PCU	
HPOS (SHPOS)	Shifter home position sensor	Detects the shifter home position.	-	Home position	CN13	22	PCU	
HUD_M	Humidity detection	Detects the humidity.	-	-	CN10	4	PCU	Analog detection
INT_CNT	Interlock control	ON/OFF control of INT24V1,V2	ON	OFF	CN11	14	PCU	
MHPS	Scanner home position sensor [Transmission type]	Detects the scanner home position.	-	Home	CN10	1	SCNcnt	
MIM_*	Scanner motor [Stepping motor]	Scanner (reading) section	-	-	CN7	1, 2, 3, 4	SCNcnt	
MPED	Manual feed paper empty	Detects paper empty in the	YES	NO	CN10	1	PCU	
	detection [Transmission type]	manual paper feed tray.						

Signal name	Name [Type]	Function/Operation	Connector level		Connector	Pin	PWB	NOTE
Signal name		Function/Operation	L	н	No.	No.	name	NOTE
MPFS	Paper pickup solenoid (Manual paper feed) [Electromagnetic solenoid]	Paper pickup solenoid (Manual paper feed) [Electromagnetic solenoid]	Pickup	-	CN10	3	PCU	
MPLD	Manual feed paper length	Detects the paper length in the manual paper feed tray	-	Detection	CN10	10	PCU	
MPWS	Manual feed tray paper width	Detects the paper width in the manual feed tray	-	-	CN10	8	PCU	
OCSW	Light emitting unit open/close	Detects the light emitting unit	Close	Open	CN17	3	SCNcnt	
OSM	Shifter motor [Stepping motor]	Offsets the paper.	-	_	CN12	7, 8, 9, 10	PCU	Drives with the 4-phase
PFC HPFC	PS front clutch	Controls the PS front clutch.	ON	OFF	CN11	22	PCU	Signal.
PFM	Transport motor		-	-	CN11	30, 32, 34	PCU	
PFM_CNT	Transport motor current select	Selects the transport motor current.	Current Large	Current Small	CN11	28	PCU	
POD1	Fusing rear detection	Detects the paper exit from fusing.	Pass	-	CN13	4	PCU	
POD2	Paper exit detection	Detects the discharged paper.	Pass	-	CN13	10	PCU	
	[Transmission type]							
POD3	Right tray paper exit detection	Detects paper exit to the right tray.	Pass	-	CN10	16	PCU	
POFM_CNT	Paper exit cooling fan motor speed control	Controls the speed of the paper exit cooling fan motor.	-	-	CN12	13, 14	PCU	Pulse (Duty) drive
POFM_LD1	POFM lock detection	Detects the POFM lock.	-	Lock detection	CN12	17	PCU	
POFM_LD2	POFM lock detection	Detects the POFM lock.	-	Lock detection	CN12	18	PCU	
POFM_V	Paper exit cooling fan motor	Cools the fusing unit.	Stop	Drive	CN12	11,12	PCU	
РОМ	Paper exit drive motor	Drives the paper exit roller.	-	-	CN11	5, 7, 9, 11	PCU	
POM_CNT	Paper exit drive motor current select	Selects the paper exit drive motor current.	Current Large	Current Small	CN11	13	PCU	
PPD1	Registration front detection [Transmission type]	Detects paper in front of the registration roller.	Pass	-	CN9	14	PCU	
PPD2	Registration detection	Detects paper at the rear of the registration roller.	Pass	-	CN9	16	PCU	
PRM	Fusing pressure release motor [Stepping motor]	Changes the fusing voltage.	-	-	CN12	1, 2, 3, 4	PCU	Drives with the 4-phase signal.
PROFM1_CNT	Process fan motor 2 speed control	Controls the speed of the process fan motor.	-	-	CN19	29	PCU	
PROFM1_LD	Process fan motor 2 lock detection	Process fan motor lock detection	-	Lock detection	CN19	22	PCU	
PROFM1_V	Process fan motor 2	Cools the process.	OFF	ON	CN19	33	PCU	
PROFM2_CNT	Process fan motor 2 speed control	Controls the speed of the process fan motor 2.	_	-	CN9	4	PCU	Pulse (Duty) drive
PROFM2_LD	Process fan motor 2 lock detection	Detects process fan motor 2 lock.	-	Lock detection	CN9	8	PCU	
PROFM2_V	Process fan motor 2	Cools the process.	OFF	ON	CN9	2	PCU	
PRTPD	Right paper exit tray paper empty detection	Detects paper empty in the right paper exit tray.	NO	YES	CN10	15	PCU	
PSFM_LD	Power cooling fan motor lock detection	Detects the power cooling fan motor lock.	-	Lock detection	CN19	30	PCU	
PSFM_V	Power cooling fan motor	Cools the power unit.	Stop	Drive	CN19	28	PCU	
REGS_F	Registration sensor (Front) [Reflection type]	Registration shift detection	_	-	CN17	A-2	PCU	Analog detection
REGS_F_LED	Registration sensor LED (Front) [LED]	Registration sensor LED light emitting	_	-	CN17	A-3	PCU	Analog output
REGS_R	Registration sensor (Rear) [Reflection type]	Registration shift detection	-	-	CN17	A-6	PCU	Analog detection
REGS_R_LED	Registration sensor LED (Rear) [LED]	Registration sensor LED light emitting	-	-	CN17	A-7	PCU	Analog output
RRM	Registration motor		-	-	CN11	31, 33	PCU	
RRM_CNT	Registration motor current select	Selects the registration motor current.	Current Large	Current Small	CN11	27	PCU	
SOCD	SPF open/close sensor	Detects open/close of the SPF.	Close	-	CN14	28	SCNcnt	
SPED	Document empty sensor	Detects document empty.	Detection	-	CN14	27	SCNcnt	
SPFM*	SPF transport motor	Drives the SPF transport motor.	-	-	CN14	3, 4, 5, 6, 7	SCNcnt	
SPM*	SPF paper feed motor	Drives the SPF paper feed motor.	-	-	CN14	8, 9, 10, 11, 12	SCNcnt	

0.		E suite (Descrition	Connec	Connector level		Pin	PWB	NOTE
Signal name	Name [Iype]	Function/Operation	L	Н	No.	No.	name	NOTE
SPPD1	SPF transport sensor 1	Detects paper pass.	Detection	_	CN14	1	SCNcnt	
SPPD2	SPF transport sensor 2	Detects paper pass.	Detection	-	CN14	2	SCNcnt	
SPPD3	SPF transport sensor 3	Detects paper pass.	Detection	-	CN14	24	SCNcnt	
SPPD4	SPF transport sensor 4	Detects paper pass.	Detection	-	CN14	22	SCNcnt	
SPRS	Pressure release solenoid	Controls the pressure release solenoid.	OFF	ON	CN14	13	SCNcnt	
SPWS	Document width sensor	Detects document width.	_		CN14	17	SCNcnt	
SRRC	PS clutch	Controls the PS clutch.	OFF	ON	CN14	15	SCNcnt	
STMPS	Stamp solenoid	Controls the stamp solenoid.	-	Stamp	CN14	14	SCNcnt	
TCS_C	Toner density sensor [Magnetic sensor]	Detects the toner density (C)	-	-	CN15	B-7	PCU	Analog detection
TCS_K	Toner density sensor [Magnetic sensor]	Detects the toner density (K)	-	-	CN15	B-16	PCU	Analog detection
TCS_M	Toner density sensor [Magnetic sensor]	Detects the toner density (M)	-	-	CN15	A-7	PCU	Analog detection
TCS_Y	Toner density sensor [Magnetic sensor]	Detects the toner density (Y)	-	-	CN15	A-16	PCU	Analog detection
TFD2	Paper exit full detection [Transmission type]	Detects the face-down paper exit tray full.	Full	-	CN13	16	PCU	
TFD3	Right tray paper exit full detection	Detects paper exit full in the right tray.	Full	-	CN10	13	PCU	
TH_LM_IN	Lower thermistor	Detects the temperature.	-	_	CN17	B-11	PCU	Analog detection
TH_M	Temperature detection	Detects the temperature.	-	-	CN10	6	PCU	Analog detection
TH_UM_CS_ IN	Main thermistor	Detects the temperature.	-	-	CN17	B-7	PCU	Analog detection
TH_UM_IN	Main thermistor	Detects the temperature.	-	-	CN17	B-6	PCU	Analog detection
TH_US_IN	Sub thermistor	Detects the temperature.	-	-	CN17	B-9	PCU	Analog detection
TH1_LSU	LSU unit thermistor	Detects the temperature.	-	-	CN2	A-2	PCU	Analog detection
TNFD	Waste toner full detection switch [Mechanical switch]	Detects waste toner full.	Empty	Full	CN9	10	PCU	
TNM_C	Toner motor C [Stepping motor]	Transports toner from the toner cartridge to the developing unit.	-	-	CN16	17, 18, 19, 20	PCU	Drives with the 4-phase signal.
TNM_K	Toner motor K [Stepping motor]	Transports toner from the toner cartridge to the developing unit.		-	CN16	25, 26, 27, 28	PCU	Drives with the 4-phase signal.
TNM_M	Toner motor M [Stepping motor]	Transports toner from the toner cartridge to the developing unit.	-	_	CN19	17, 19, 25, 27	PCU	Drives with the 4-phase signal.
TNM_Y	Toner motor Y [Stepping motor]	Transports toner from the toner cartridge to the developing unit.	-	-	CN19	5, 7, 13, 15	PCU	Drives with the 4-phase signal.
WEBEND	Web end detection	Detects the fusing web end.	-	End	CN17	B-2	PCU	
WEBS	Web drive solenoid	Drives the web.	ON	OFF	CN17	B-4	PCU	

# [15] TOOL LIST

Name	Part code	Note
Color copy test chart	UKOG-0326FCZZ/UKOG-0326FC11	
SIT chart	UKOG-0280FCZZ/UKOG-0280FCZ1	
Gray test chart	UKOG-0162FCZZ	
Kynar powder	UKOG-0123FCZZ	For transfer belt
Grease (HANARL FL-955R)	UKOG-0299FCZZ	
Conduction grease (FLOIL GE-676)	UKOG-0012QSZZ	Other shaft
Grease (FLOIL G-313S)	UKOG-0307FCZZ	
Grease (JFE552)	UKOG-0235FCZZ	
Stearic acid powder	UKOG-0312FCZZ	OPC drum
Grease (FLOIL GP-501MR)	UKOG-0013QSZZ	RSPF paper feed roller shaft
Grease (MOLYKOTE X5-6020)	UKOG-0158FCZZ	
Grease (MOLYKOTE BR-2 Plus)	UKOG-0097FCZZ	

## LEAD-FREE SOLDER

The PWB's of this model employs lead-free solder. The "LF" marks indicated on the PWB's and the Service Manual mean "Lead-Free" solder. The alphabet following the LF mark shows the kind of lead-free solder.

#### Example:



Solder	com	position	code	of	lead-free	solder>
001001		poontion	0040	۰.	1000 1100	001001

<

Solder composition	Solder composition code
Sn- <u>A</u> g-Cu	а
Sn-Ag- <u>B</u> i Sn-Ag- <u>B</u> i-Cu	b
Sn- <u>Z</u> n-Bi	Z
Sn- <u>I</u> n-Ag-Bi	i
Sn-Cu- <u>N</u> i	n
Sn-Ag-Sb	S
Bi-Sn-Ag- <u>P</u> Bi-Sn-Ag	р

#### (1) NOTE FOR THE USE OF LEAD-FREE SOLDER THREAD

When repairing a lead-free solder PWB, use lead-free solder thread.

Never use conventional lead solder thread, which may cause a breakdown or an accident.

Since the melting-point of lead-free solder thread is about 40°C higher than that of conventional lead solder thread, the use of the exclusive-use soldering iron is recommended.

#### (2) NOTE FOR SOLDERING WORK

Since the melting-point of lead-free solder is about 220°C, which is about 40°C higher than that of conventional lead solder, and its soldering capacity is inferior to conventional one, it is apt to keep the soldering iron in contact with the PWB for longer time. This may cause land separation or may exceed the heat-resistive temperature of components. Use enough care to separate the soldering iron from the PWB when completion of soldering is confirmed.

Since lead-free solder includes a greater quantity of tin, the iron tip may corrode easily. Turn ON/OFF the soldering iron power frequently. If different-kind solder remains on the soldering iron tip, it is melted together with lead-free solder. To avoid this, clean the soldering iron tip after completion of soldering work.

If the soldering iron tip is discolored black during soldering work, clean and file the tip with steel wool or a fine filer.

(Danish) ADVARSEL ! Lithiumbatteri – Eksplosionsfare ved fejlagtig håndtering. Udskiftning må kun ske med batteri af samme fabrikat og type. Levér det brugte batteri tilbage til leverandoren.	
(English) Caution !	
Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.	
	•.
(Finnish) VAROITUS Paristo voi räjähtää, jos se on virheellisesti asennettu. Vaihda paristo ainoastaan laitevalmistajan suosittelemaan tyyppiin. Hävitä käytetty paristo valmistajan ohjeiden mukaisesti.	
(French) ATTENTION	
Il y a danger d'explosion s' il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur. Mettre au rebut les batteries usagées conformément aux	
(Swedich) //ADNINC	
(Swedish) VARINING Explosionsfara vid felaktigt batteribyte. Använd samma batterityp eller en ekvivalent typ som rekommenderas av apparattillverkaren. Kassera använt batteri enligt fabrikantens instruktion.	
<ul> <li>(German) Achtung</li> <li>Explosionsgefahr bei Verwendung inkorrekter Batterien.</li> <li>Als Ersatzbatterien dürfen nur Batterien vom gleichen Typ oder vom Hersteller empfohlene Batterien verwendet werden.</li> <li>Entsorgung der gebrauchten Batterien nur nach den vom Hersteller angegebenen Anweisungen.</li> </ul>	

#### - CAUTION FOR BATTERY DISPOSAL -

#### (For USA, CANADA)

"BATTERY DISPOSAL" THIS PRODUCT CONTAINS A LITHIUM PRIMARY (MANGANESS DIOXIDE) MEMORY BACK-UP BATTERY THAT MUST BE DISPOSED OF PROPERLY. REMOVE THE BATTERY FROM THE PRODUCT AND CONTACT YOUR LOCAL ENVIRONMENTAL AGENCIES FOR INFORMATION ON RECYCLING AND DISPOSAL OPTIONS.

"TRAITEMENT DES PILES USAGÉES" CE PRODUIT CONTIENT UNE PILE DE SAUVEGARDE DE MÉMOIRE LITHIUM PRIMAIRE (DIOXYDE DE MANGANÈSE) QUI DOIT ÊTRE TRAITÉE CORRECTEMENT. ENLEVEZ LA PILE DU PRODUIT ET PRENEZ CONTACT AVEC VOTRE AGENCE ENVIRONNEMENTALE LOCALE POUR DES INFORMATIONS SUR LES MÉTHODES DE RECYCLAGE ET DE TRAITEMENT.



#### **COPYRIGHT © 2013 BY SHARP CORPORATION**

All rights reserved. Produced in Japan for electronic Distribution No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic; mechanical; photocopying; recording or otherwise without prior written permission of the publisher.

#### Trademark acknowledgements

- Microsoft[®], Windows[®], Windows[®] 98, Windows[®] Me, Windows NT[®] 4.0, Windows[®] 2000, Windows[®] XP, Windows[®] Vista, Windows[®] 7, Windows[®] Server 2003, Windows[®] Server 2008 and Internet Explorer[®] are registered trademarks or trademarks of Microsoft Corporation in the U.S.A. and other countries.
- PostScript is a registered trademark of Adobe Systems Incorporated.
- Macintosh, Mac OS, AppleTalk, EtherTalk, Laser Writer, and Safari are registered trademarks or trademarks of Apple Computer, Inc.
- IBM, PC/AT, and Power PC are trademarks of International Business Machines Corporation.
- Acrobat[®] Reader Copyright[®] 1987- 2002 Adobe Systems Incorporated. All rights reserved. Adobe, the Adobe logo, Acrobat, and the Acrobat logo are trademarks of Adobe Systems Incorporated.
- PCL is a registered trademark of the Hewlett-Packard Company.
- Sharpdesk is a trademark of Sharp Corporation.
- All other trademarks and copyrights are the property of their respective owners.

SHARP CORPORATION Business Solutions CS Promotion Center II Yamatokoriyama, Nara 639-1186, Japan First Edition 2012 October Latest Edition 2014 June