


SHARP SERVICE MANUAL

CODE: 00ZAR455N/A1E



DIGITAL MULTIFUNCTIONAL SYSTEM

AR-M355N
MODEL AR-M455N

CONTENTS

[1] GENERAL	1-1
[2] CONFIGURATION	2-1
[3] SPECIFICATIONS	3-1
[4] CONSUMABLE PARTS	4-1
[5] EXTERNAL VIEWS AND INTERNAL STRUCTURES	5-1
[6] UNPACKING AND INSTALLATION	6-1
[7] DISASSEMBLY AND ASSEMBLY, MAINTENANCE	7-1
[8] ADJUSTMENTS	8-1
[9] SIMULATIONS	9-1
[10] TROUBLE CODES	11-1
[11] MACHINE OPERATION	10-1
[12] ROM VERSION-UP METHOD	12-1
[13] ELECTRICAL SECTION	13-1

Parts marked with “△” are important for maintaining the safety of the set. Be sure to replace these parts with specified ones for maintaining the safety and performance of the set.

CAUTION

This product is a class 1 laser product that complies with 21CFR 1040.10 and 1040.11 of the CDRH standard and IEC825. This means that this machine does not produce hazardous laser radiation. The use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

This laser radiation is not a danger to the skin, but when an exact focusing of the laser beam is achieved on the eye's retina, there is the danger of spot damage to the retina.

The following cautions must be observed to avoid exposure of the laser beam to your eyes at the time of servicing.

- 1) When a problem in the laser optical unit has occurred, the whole optical unit must be exchanged as a unit, not as individual parts.
- 2) Do not look into the machine with the main switch turned on after removing the developer unit, toner cartridge, and drum cartridge.
- 3) Do not look into the laser beam exposure slit of the laser optical unit with the connector connected when removing and installing the optical system.
- 4) The middle frame contains the safety interlock switch.
Do not defeat the safety interlock by inserting wedges or other items into the switch slot.

Cautions on laser

Wave length	785 nm +10 nm -15 nm	At the production line, the output power of the scanner unit is adjusted to 0.4 MILLIWATT PLUS 8 % and is maintained constant by the operation of the Automatic Power Control (APC).
Pulse times	North America: 35 cpm model: (4.1 μ s \pm 4.1 ns)/7 mm 45 cpm model: (5.7 μ s \pm 5.7 ns)/7 mm Europe: 35 cpm model: (3.8 μ s \pm 3.8 ns)/7 mm 45 cpm model: (4.4 μ s \pm 4.4 ns)/7 mm	
Output power	0.2 mW - 0.4 mW	Caution This product contains a low power laser device. To ensure safety do not remove any cover or attempt to gain access to the inside of the product. Refer all servicing to qualified personnel.

For North America:

SAFETY PRECAUTIONS

This Digital Equipment is rated Class 1 and complies with 21 CFR 1040.10 and 1040.11 of the CDRH standards. This means that the equipment does not produce hazardous laser radiation. For your safety, observe the precautions below.

- Do not remove the cabinet, operation panel or any other covers.
- The equipment's exterior covers contain several safety interlock switches. Do not bypass any safety interlock by inserting wedges or other items into switch slots.

Caution

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

For Europe:

CLASS 1 LASER PRODUCT

LASER KLASSE 1

LUOKAN 1 LASERLAITE

KLASS 1 LASERAPPARAT

CAUTION

INVISIBLE LASER RADIATION WHEN OPEN INTERLOCKS DEFEATED. AVOID EXPOSURE TO BEAM.

VORSICHT

UNSICHTBARE LASERSTRAHLUNG WENN ABDECKUNG GEÖFFNET UND SICHERHEITSVERRIEGELUNG ÜBERBRÜCKT. NICHT DEM STRAHL AUSSETZEN.

ADVARSEL


USYNLIG LASERSTRÅLNING VED ÅBNING, NÅR SIKKERHEDSBRYDERE ER UDE AF FUNKTION. UNDGA UDSÆTTELSE FOR STRÅLNING.

VAROITUS!

LAITTEEN KÄYTTÄMINEN MUULLA KUIN TÄSSÄ KÄYTTÖOHJEESSA MAINITULLA TAVALLA SAATTAA ALTISTAA KÄYTTÄJÄN TURVALLISUUSLUOKAN 1 YLITTÄVÄLLE NÄKYMÄTTÖMÄLLE LASERSÄTEILYLLE.

VARNING

OM APPARATEN ANVÄNDS PÅ ANNAT SÄTT ÄN I DENNA BRUKSANVISNING SPECIFICERATS, KAN ANVÄNDAREN UTSÄTTAS FÖR OSYNLIG LASERSTRÅLNING, SOM ÖVERSKRIDER GRÄNSEN FÖR LASERKLASS 1.



**CLASS 1
LASER PRODUCT**

LASER KLASSE 1



Laserstrahl

CAUTION INVISIBLE LASER RADIATION WHEN OPEN INTERLOCKS DEFEATED. AVOID EXPOSURE TO BEAM.
VORSICHT UNSICHTBARE LASERSTRAHLUNG WENN ABDECKUNG GEÖFFNET UND SICHERHEITSVERRIEGELUNG ÜBERBRÜCKT. NICHT DEM STRAHL AUSSETZEN.
ADVARSEL USYNLIG LASERSTRÅLNING VED ÅBNING, NÅR SIKKERHEDSBRYDERE ER UDE AF FUNKTION. UNDGA UDSÆTTELSE FOR STRÅLNING.
VARNING OSYNLIG LASERSTRÅLNING NÄR DENNA DEL ÄR ÖPPNAD OCH SPRÄKKAR ÄR ÖPPEN. STRÅLEN ÄR FÄRLIG. RESTRÄCKA SÄ STRÅLEN.
VARO! AVATTAESSA JA SUOJALUKITUS OHTETTÄESSA OLET ALLITTINA NÄKYMÄTÖN LASERSÄTEILYLLE. ÄLÄ KATSO SÄTEESEEN.

△ 注意 (サービスマン用)

カバーを開けてかつインターロックを無効にした場合にはレーザー光にさらされないようにしてください。

[1] GENERAL

1. Note for servicing

Pictogram


This Service Manual uses some pictographs to assure safe operation.

Please understand the meanings of pictographs before servicing.

CAUTION: If this CAUTION is ignored, an injury or damage to property could occur.


A. Cautions for servicing

- 1) Do not touch the photoconductive drum. Scratches or smudges on the drum will cause dirty printouts.
- 2) The fusing unit is extremely hot. Exercise care in this area.



Fusing unit

- 3) Do not look directly at the light source of the scanner module. Doing so may damage your eyes.
- 4) Five adjusters are provided on all optional stand/paper drawer units. These adjusters should be lowered until they contact the floor.




- 5) Do not make any modifications to this machine. Doing so may result in personal injury or damage to the machine.
- 6) Since this machine is heavy, it is recommended that it be moved by more than one person to prevent injury.
- 7) When connecting this machine to a computer, be sure to first turn both the computer and the machine off.
- 8) Do not print anything which is prohibited from printing by law. The following items are normally prohibited from printing by national law. Other items may be prohibited by local law.
 - Money
 - Stamps
 - Bonds
 - Stocks
 - Bank drafts
 - Checks
 - Passports
 - Driver's licenses
- 9) Do not throw toner or a toner cartridge into fire. Toner may be spattered, causing a burn.
- 10) Store toner or toner cartridges in a hard-to-reach place for children.

[2] CONFIGURATION

1. System configuration


A. Basic system

<p>AR-M355N/M455N (Copier/Network printer model)</p>

<p>Necessary options</p> <ul style="list-style-type: none">• B/W scanner module/DSPF (AR-EF3)• Scanner Rack (AR-RK2)• Any one of the stand/MPD & 2000 sheet paper drawer (AR-D28), the stand/3 x 500 sheet paper drawer (AR-D27), or the multi purpose drawer (AR-MU2)• Any one of the upper exit tray extension (AR-TE4), the finisher (AR-FN6), the mail-bin stacker (AR-MS1), or the cover option at right side (AR-TE5)

B. Option lineup

For combinations of options, refer to "C. List of combination of peripheral devices" described later.

(1) Major options



No.	Option name		Installing conditions
1	B/W scanner module/DSPF	AR-EF3	<ul style="list-style-type: none"> The scanner rack (AR-RK2) is required. Either of the stand/3 x 500 sheet paper drawer (AR-D27) or the stand/MPD & 2000 sheet paper drawer (AR-D28) is required.
2	Stand/MPD & 2000 sheet paper drawer	AR-D28	<ul style="list-style-type: none"> Simultaneous installation with the large capacity paper feed desk (AR-D28) or the 3-stage paper feed desk (AR-D27) is inhibited.
3	Stand/3 x 500 sheet paper drawer	AR-D27	
4	Multi purpose drawer	AR-MU2	
5	Upper exit tray extension	AR-TE4	<ul style="list-style-type: none"> Required when the finisher (AR-FN6) or the mail-bin stacker (AR-MS1) is not installed.
6	Cover option at right side	AR-TE5	
7	Exit tray	AR-TE3	<ul style="list-style-type: none"> Required when the duplex module (AR-DU3) is installed and the saddle stitch finisher (AR-FN7) is not installed.
8	Duplex module/bypass tray	AR-DU4	<ul style="list-style-type: none"> Any one of the multi purpose drawer (AR-MU2), the stand/3 x 500 sheet paper drawer (AR-D27), or the stand/MPD & 2000 sheet paper drawer (AR-D28) is required. The duplex module/bypass tray (AR-DU4) cannot be installed with the exit tray (AR-TE3) or the saddle stitch finisher (AR-FN7). When the duplex module (AR-DU3) is installed, the exit tray (AR-TE3) or the saddle stitch finisher (AR-FN7) is required.
9	Duplex module	AR-DU3	
10	Saddle stitch finisher	AR-FN7	<ul style="list-style-type: none"> Simultaneous installation with the finisher (AR-FN6) is inhibited. The duplex module (AR-DU3) is required. The stand/3 x 500 sheet paper drawer (AR-D27) or the stand/MPD & 2000 sheet paper drawer (AR-D28) is required.
11	Finisher	AR-FN6	<ul style="list-style-type: none"> Simultaneous installation with the saddle finisher (AR-FN7) is inhibited. Any one of the multi paper drawer (AR-MU2), the stand/3 x 500 sheet paper drawer (AR-D27), or the stand/MPD & 2000 sheet paper drawer (AR-D28) is required.
12	Mail-bin stacker	AR-MS1	<ul style="list-style-type: none"> Any one of the multi paper drawer (AR-MU2), the stand/3 x 500 sheet paper drawer (AR-D27), or the stand/MPD & 2000 sheet paper drawer (AR-D28) is required.
13	Fax expansion kit	AR-FX12	<ul style="list-style-type: none"> The scanner rack (AR-RK2) and the stand/3 x 500 sheet paper drawer (AR-D27), or the stand/MPD & 2000 sheet paper drawer is required. The B/W scanner module/DSPF (AR-EF3) is required.

(2) Other options

Option			Installing conditions
Paper exit unit	Punch unit	AR-PN1	For saddle stitch finisher (AR-FN7)
Function expansion options	PS3 expansion kit	AR-PK6	
	Network scanner expansion kit	AR-NS3	
	Sharpdesk 1 licence kit	AR-U11M	For network scanner expansion kit (AR-NS3)
	Sharpdesk 5 licence kit	AR-U15M	
	Sharpdesk 50 licence kit	AR-U1AM	
	Sharpdesk 100 licence kit	AR-U1BM	
	Data security kit (CC version)	AR-FR21	
	Data security kit (Commercial version)	AR-FR21U	
	Bar code font	AR-PF1	
	Flash ROM kit	AR-PF2	
FAX-related option	Fax memory (8 MB)	AR-MM9	For fax expansion kit (AR-FX12)

C. List of combination of peripheral devices

As shown in the table below, some other peripheral devices (B) may be needed for installation of a peripheral device (A) and some peripheral devices cannot be installed together.

		B																
A																		
			BW scanner module/DSPF	Scanner rack	Multi purpose drawer	Stand/3 x 500 sheet paper drawer	Stand/MPD & 2000 sheet	Duplex module/bypass tray	Duplex module	Saddle stitch finisher	Finisher	Mail-bin stacker	Exit tray	Upper exit tray extension	Punch unit	Cover option at right side	Multi-function controller board	Print server card
	Related to scanner feature																	
	B/W scanner module/DSPF	AR-EF3	—	○	×	○ ^{*1}											○	
	Scanner rack	AR-RK2	○ ^{*1}	—	×	○ ^{*1}											○	
	Related to paper feed unit																	
	Multi purpose drawer	AR-MU2	×	×	—	×	×			×					×			
	Stand/3 x 500 sheet paper drawer	AR-D27			×	—	×											
	Stand/MPD & 2000 sheet paper drawer	AR-D28			×	×	—											
	Duplex module/bypass tray	AR-DU4				○ ^{*1}	—		×						×			
	Duplex module	AR-DU3				○ ^{*1}		—										
	Output units																	
	Saddle stitch finisher	AR-FN7			×	○ ^{*1}	×	○	—	×		×						
	Finisher	AR-FN6				○ ^{*1}			×	—	×		×	×				
	Mail-bin stacker	AR-MS1				○ ^{*1}				×	—		×					
	Exit tray	AR-TE3					○ ^{*1}	×	×	×	—		×					
	Upper exit tray extension	AR-TE4							×	×		—						
	Cover option at right side	AR-TE5															—	
	Punch unit	AR-PN1			×	○ ^{*1}	×	○	○	×		×		—				
	Related to extension of functions and others																	
	PS3 expansion kit	AR-PK6															—	
	Network scanner expansion kit	AR-NS3	○ ^{*1}	○	×	○ ^{*1}										○	○	
	Facsimile expansion kit	AR-FX12	○ ^{*1}	○	×	○ ^{*1}										○		
	Fax memory (8 MB)	AR-MM9	○ ^{*1}	○	×	○ ^{*1}										○	○	
	Bar code font	AR-PF1																—
	Flash ROM kit	AR-PF2																—
	Data security kit (CC version)	AR-FR21																—
	Data security kit (Commercial version)	AR-FR21U																—

○ = Must be installed together.

○^{*1} = Any of the units must be installed together.

×

[3] SPECIFICATIONS

1. Basic Specification

A. Base Engine

(1) Form

Console type

(2) Engine speed

Paper size	AR-M355N	AR-M455N
A4, 8.5" x 11"	35ppm (31ppm*)	45ppm (40ppm*)
A4R, 8.5" x 11"R	25ppm	30ppm
A5R/5.5" x 8.5"R, Invoice-R	35ppm	45ppm
B5	35ppm	45ppm
B5R, Exective-R	25ppm	30ppm
B4/8.5" x 14	20ppm	22ppm
A3/11" x 17"	17ppm	20ppm
8K	17ppm	20ppm
16K	35ppm	45ppm

* Paper feed from Manual bypass tray

(3) Engine composition


Photoconductor type	OPC (diameter of photoconductor : ø30mm)
Record method	Electrophotograph (laser)
Development method	Dry-type dual-component magnetic brush development
Charge method	Charged saw-tooth method
Transfer method	Transfer roller
Cleaning method	Counter blade
Fusing method	Heat roller

(4) Engine resolution

Resolution	Read: 600dpi Write :600dpi
Smoothing	Write :1200dpi equivalent
Gradation	Write :2 levels

(5) Printable area

The print area of this product is shown below.



If a printer driver for Windows or Macintosh is used for printing, the printable area will be smaller. The actual printable area depends on the printer driver to be used.

(in mm)

Paper size	A	B	C	D	E
A3	297	420	4	289	4
B4	257	364	4	242	4
A4	210	297	4	202	4
B5	182	257	4	168	4
A5	148	210	4	140	4
Japanese postcard	100	148	4	92	4
Ledger	279	432	4	271	4
Legal	216	356	4	208	4
Foolscap	216	330	4	208	4
Letter	216	279	4	208	4
Executive	184	267	4	183	4
Invoice	140	2162	4	132	4
Com-10 (envelope)	105	241	4	97	4
C5 (envelope)	162	229	4	154	4
Monarch (envelope)	98	191	4	90	4
DL (envelope)	110	220	4	102	4
ISO B5(envelope)	176	250	4	168	4

(6) Warm-up

Warm-up time	less than 80 seconds
Pre-heat requirement	Required
Jam recovery time	Target: about 30 seconds (Under standard condition of 60 seconds left after side cover opening, polygon motor halt)

(7) Power source

Voltage	100V system 100-127V
Frequency	50/60Hz
Power cord	Inlet type

(8) Power consumption

	AR-M355N	AR-M455N
Max. Power consumption		
Energy consumption efficiency		

(9) Energy Star benchmark

	AR-M355N	AR-M455N
Low power mode	184.75W	223.25W
Recovery time from low power mode	Max. 30 sec.	Max. 30 sec. (Recommendation)
Sleep mode	Less than 80W	Less than 95W
Transition time to sleep mode	60 min. (Max. 240 min.)	90 min. (Max. 240 min.)

(10) Noise

At working	less than 6.8B
At waiting mode	less than 5.0B

* Showing noise benchmark in each model as a whole system.

(11) Dimensions

External dimensions (W x D x H)	16.9" x 21.7" x 18.5" (428 x 552 x 475 mm) (Only main unit)
Occupied space dimensions (W x D)	25.7" x 22.3" (654 x 567 mm) *1
Weight	Approx. 85.7 lb (38.9kg) (include developer and controller board)

*1: With multi purpose tray (AR-MU1)

B. Document Feeding Equipment

(1) One-drawer tray (included in the base engine)

Paper feed method	One-drawer tray
Sizes to be fed	A4, B5, 8.5" x 11"
Paper capacity	500 sheets (at 80g/m ²)
Media available for paper feeding	Plain paper 60 - 105g/m ² , 16 - 28lbs
Paper type	Plain, recycled, pre-printed, pre-punched, color, letter head
Paper size switching	To be switched by user (paper size to be entered from the operation panel).
Dehumidification heater	Not provided
Balance detection	Provided (paper empty and 3 steps)
Default size setting	100V system
	8.5" x 11"
Mounting/demounting of the tray	Provided

C. Output Equipment

(1) Face-down Exit Tray (included in the base engine)

Output position/method	Face-down output at the upper side of main unit
Output paper capacity	400 sheets (80g/m ² sheet)
Output paper size	A3, B4, A4, A4R, B5, B5R, A5R 11" x 17", 8.5" x 14", 8.5" x 13", 8.5" x 11", 8.5" x 11"R, 5.5" x 8.5"R Executive, postal card, Monarch (98 x 191), 8K, 16K, 16KR Com-10 (105 x 241), DL (110 x 220), C5 (162 x 229), ISO B5 (176 x 250)
Spec of media for paper output	Tracing paper : 52 ~ 59g/m ² / 14 ~ 15lbs Plain paper : 60 ~ 128g/m ² / 16 ~ 34lbs Index paper : 176g/m ² / 47lbs Cover paper : 205g/m ² / 54 ~ 55lbs Transparency film
Remaining paper detection	Not provided
Exit tray full detection	Provided

2. Specific Function

A. Printer Function

(1) Platform

IBM PC/AT (Include compatible machine)
Macintosh

(2) Support OS

Custom PS	Windows 95/98/Me Windows NT 4.0 Windows 2003 server Windows 2000 server Windows 2000 Windows XP
Custom PCL5e/6(XL)	Windows 95/98/Me Windows NT 4.0 Windows 2003 server Windows 2000 server Windows 2000 Windows XP
PPD	Windows 95/98/Me Windows NT 4.0 Windows 2003 server Windows 2000 server Windows 2000 Windows XP MacOS 8.6 - 9.x, 10.1.5, 10.2 - 10.2.8 (except for Mac OS 10.2.2), 10.3-10.3.3

(3) PDL emulation

PCL6 compatible, PCL5e compatible, PostScript 3 compatible
--

(4) Windows driver function

a. General

Function	PCL5e	PCL6	PS	PPD file *1 (for Windows XP)
Copies	1-999			
Orientation	Portrait Landscape			Portrait Landscape-A Landscape-B (*2)
Duplex	1-sided 2-sided (Left /top/ right binding)			1-sided 2-sided (Long / short binding) (*2)
Booklet	Invoice on Letter Letter on Ledger A5 on A4 A4 on A3 B5 on B4 Letter on Letter Ledger on Ledger A4 on A4 A3 on A3 B4 on B4			Yes (2up booklet only) (*2)
Binding edge	Left / top / right			—
N-up	2/4/6/8/9/16			2 / 4 / 6 / 9 / 16 (*2)
N-up order	Z / Reversed Z / N / Reversed N			Z (*2)
N-up border	Yes / No			Always Yes (*2)

*1: For printing, PS driver bundled with the Windows is required.

*2: Since the function is of PS driver bundled with Windows, specification may vary according to the OS.

b. Paper Input

Function	PCL5e	PCL6	PS	PPD file *1 (for Windows XP)
Paper size	A3 / B4 / A4 / B5 / A5 / Ledger / Legal / Foolscap / Letter / Executive /Invoice/8k / 16k /COM10/C5/ Monarch/DL			
Paper type	Plain Letter Head Pre-Print Pre-Punch Recycle Color Label Heavy Paper Transparency Envelope			
Custom paper type	7 type			—
Source selection	Automatic Tray 1/2/3/4 Bypass-tray			
Cover	Yes/No User can select from 1-sided/2-sided/ No print			—
Insert page	Yes/No User can select from 1-sided/2-sided/ No print			—
Transparency inserts	No Yes (Blank) Yes (Printed)			—

*1: For printing, PS driver bundled with the Windows is required.

c. Paper Output

Function	PCL5e	PCL6	PS	PPD file *1 (for Windows XP)
Output tray selection	Center tray			
	Finisher <ul style="list-style-type: none">• Top tray• Offset tray			
	Saddle Stitch Finisher <ul style="list-style-type: none">• Offset tray			
	Mailbin stacker <ul style="list-style-type: none">• Mailbin top tray• Mailbin (1-7)			
	Duplex module <ul style="list-style-type: none">• Left tray			
Staple	Finisher <ul style="list-style-type: none">• No staple• 1 staple• 2 staples			Saddle Stitch Finisher <ul style="list-style-type: none">• No staple• 1 staple• 2 staples
	Saddle Stitch Finisher <ul style="list-style-type: none">• No staple• 1 staple• 2 staples			
Offset cancel	Yes/No			

*1: For printing, PS driver bundled with the Windows is required.

d. Graphic

Function	PCL5e	PCL6	PS	PPD file *1 (for Windows XP)
Resolution setting	600/300 dpi		600dpi	600dpi
Half-tone setting	—	No	Screen frequency 8.0 to 360.0 in 0.1 steps Screen angle 0.0 to 360.0 in 0.1 steps	—
Graphics mode	Raster HP-GL2	Raster Vector	—	—
Smoothing	Yes/No			
Toner save	Yes / No			
Photo enhancement	—	Yes/No	—	—
Negative image	—	—	Yes / No	
Mirror image	—	—	Horizontal Vertical	Horizontal (*2)
Zoom	—	—	25-400% (XY zoom)	1-1000% (*2)
Fit to page	Yes / No			—

*1: For printing, PS driver bundled with the Windows is required.

*2: Since the function is of PS driver bundled with Windows, specification may vary according to the OS.

e. Font

Function	PCL5e	PCL6	PS	PPD file *1 (for Windows XP)
Download font	Bitmap TrueType		Bitmap Type1 TrueType	Auto Outline Bitmap Native TrueType (*2)

f. Others

Function	PCL5e	PCL6	PS	PPD file *1 (for Windows XP)
Configuration setting	Yes			
Watermark	Yes			Yes (functionality is limited)
Edge to edge	Yes			—
Line width setting	—			
Form overlay	Yes			—
Print hold	Yes			—
Confidential print	Yes			—
Sample print	Yes			—
Print accounting	Yes			—
Quick sets	Yes			—
Auto configuration	Yes			—
Job end notification	Yes			—
Tandem print	Yes			—
Carbon print	Yes			—
Multi-enlargement	—			
XY zoom	—	—	Yes	—
Cover insert + pamphlet	Yes			—
Document filing	Yes			—

*1: For printing, PS driver bundled with the Windows is required.

*2: Since the function is of PS driver bundled with Windows, specification may vary according to the OS.

(5) Macintosh driver functions

a. General

Function	Macintosh PPD file (for Mac OS X ver10.2.8)
Copies	1-999
Orientation	Portrait Landscape-A Landscape-B (*1)
Duplex	1-sided 2-sided Pamphlet (Right /left /top binding)
Booklet	Yes
N-up	2/4/6/9/16 (*1)
N-up order	Z / reversed Z / N / reversed N (*1)
N-up border	None / Single hairline / Single thin line / Double hairline / Double thin line (*1)

*1: Since the function is of PS driver bundled with Macintosh, specification may vary according to the OS.

b. Paper input

Function	Macintosh PPD file (for Mac OS X ver10.2.8)
Paper size	A3 / B4 / A4 / B5 / A5 / Japanese Postcard / Ledger / Legal / Foolscap / Letter / Executive / Invoice/ 8K / 16K/ COM10/C5/Monarch/DL
Paper type	Plain / Letter Head / Pre-Print / Pre-Punch / Recycle / Color / Label / Heavy Paper / Transparency / Envelope
Custom paper type	7
Source selection	Automatic Tray 1/2/3/4 Bypass-tray
Different 1st page	Yes / No (*1)
Cover / insert page	– (On OS9, user can select from: No/First Page/Last Page) (*1)
Transparency inserts	No Yes (Blank) Yes (Printed)

*1: Since the function is of PS driver bundled with Macintosh, specification may vary according to the OS.

c. Paper output

Function	Macintosh PPD file (for Mac OS X ver10.2.8)
Output tray selection	Center tray
	Finisher • Top tray • Offset tray
	Saddle Stitch Finisher • Offset tray
	Mailbin stacker • Mailbin top tray • Mailbin (1-7)
	Duplex module • Left tray
Staple	Finisher • No staple • 1 staple • 2 staples
	Saddle Stitch Finisher • No staple • 1 staple • 2 staples
Offset	Yes/No

d. Graphic

Function	Macintosh PPD file (for Mac OS X ver10.2.8)
Resolution setting	600dpi
Halftone setting	–
Graphics mode	–
Smoothing	Yes/No
Toner save	Yes / No
Photo enhancement	Yes/No
Negative image	–
Mirror image	–
Zoom	1-100000 (*1)
Fit to page	–

*1: Since the function is of PS driver bundled with Macintosh, specification may vary according to the OS.

e. Font

Function	Macintosh PPD file (for Mac OS X ver10.2.8)
Download font	– (Selectable only on MacOS9.x.x - LaserWriter) (*1)

f. Others

Function	Macintosh PPD file (for Mac OS X ver10.2.8)
Configuration setting	Yes
Watermark	Yes
Edge to edge	Yes
Form overlay	—
Print hold	Yes
Confidential print	Yes (PIN selection)
Sample print	Yes
Print accounting	Yes
Quick sets	—
Auto configuration	— (OS9: Yes)
Job end notification	—
Tandem print	Yes
Carbon print	—
Multi-enlargement	—
XY zoom	—
Cover insert + pamphlet	—
Document filing	Yes (*1)

*1: Since the function is of PS driver bundled with Macintosh, specification may vary according to the OS.

(6) Compatibility

PCL 5e compatibility	Target for PCL5e is to be compatible with HP LaserJet 4050. Small margin difference, rendering difference by different font family, default and transfer function difference is not to be included in the compatibility. All the PCL commands are not necessarily included in the compatibility.
PCL6 compatibility	Target for PCL6 is to be compatible with HP LaserJet 4050. Small margin difference, rendering difference by different font family, default and transfer function difference is not to be included in the compatibility. All the PCL commands are not necessarily included in the compatibility.
PostScript Compatibility	PostScript is targeted to be compatible with Adobe PostScript as performed in HP LaserJet 4050. Small margin difference, rendering difference by different font family, default and transfer function difference is not to be included in the compatibility.

B. Image send function

(1) Mode

Scanner (Scan to E-mail, Scan to Sharpdesk, Scan to FTP, Scan to HDD), FAX, Internet FAX

(2) Support system

Mode	Scanner	Internet FAX	FAX
Supported server	SMTP server FTP server	POP server SMTP server ESMTP server	—

(3) Support image

Format	TIFF, PDF, TIFF-F, TIFF-FX		
	Scanner	Internet FAX	FAX
Compression method	Uncompressed, G3 (1-dimension) *1, G4 *3 *1 G3 (1-dimension) = MH (Modified Huffman) *3 G4 = MMR (Modified MR)	MH, MMR	MH, MR, MMR, JBIG

(4) Image process

Mode	Scanner	Internet FAX	FAX
Half tone reproduction	Equivalent to 256 levels		
Exposure adjustment	Auto + 5 steps		
Quality selection	Half-tone ON/OFF (It's not effective for the following resolution with *.)		
Resolution (Varies with the file type/ transmission method)	200 x 200dpi *	200 x 100dpi *	Normal (203.2 x 97.8dpi) *
	300 x 300dpi	200 x 200dpi	Small letter (203.2 x 195.6dpi)
	400 x 400dpi	200 x 400dpi	Fine (203.2 x 391dpi)
	600 x 600dpi	400 x 400dpi	Extra fine (406.4 x 391dpi)
	—	600 x 600dpi	—

(5) Specified destination

Mode	Scanner	Internet FAX	FAX
LDAP	Yes (Also can be stored in one-touch address.)		
Specified destination	Specifying by one-touch or group, manual destination entry		
One-touch keys (Max. number of keys to be stored.)	Max. 999 destinations In this, FTP and Desktop are 200 destinations.		
Group*	To be registered from one-touch and manual destination entry 500		
Program	Yes		
Manual destination entry	Soft Keyboard		Input via the numeric keys, # key and * key.
Chain dialing (Manual destination entry)	—		Up to 64-digit with pause key
Resend	This is used to recall the last destination.		
Speed dialing	This is used to recall address control number by using numeric keys.		

(6) Specified multiple destinations

Mode	Scanner	Internet FAX	FAX
Specified destination	Specifying by one-touch or group, manual destination entry.		
Max. number of Manual destination entry*	Total of 5000 destinations including group and relay broadcast.		
Sequential broadcasting	Yes (E-mail only. It is not available for FTP/Desktop.)		Yes
Simultaneous FAX transmission	—		Yes

* Manual destination entry: Entry other than One-touch, using numeric keys or soft keyboard.

* In the case of broadcast transmission including fax destination, the resolution level for fax mode is applied.

* In the case of broadcast transmission with Internet FAX and Scanner destinations, the resolution level of Internet FAX mode is applied.

* In the case of broadcast transmission, the compression format set with the key operator programs is applied.

(7) Functions

Mode	Scanner	Internet FAX	FAX
Transmit function	Memory transmit	— Data is sent by memory transmit when upper limit is set.	Yes
	On-hook	—	Yes
	Quick online transmit	—	Yes
	Direct transmit	—	At on-hook only
	Auto reduction transmit	—	Yes: A3 → B4, A3 → A4, B4 → A4
	Rotation transmit	Yes	
	Scaling transmit	Yes (Scaling from regular size to regular size only. Some functions does not allow rotation transmit)	
	Re-call mode	Error	—
		Busy	—
	No. of times/interval is set via key operator program.		
	Book original transmit	Yes	
	Long length original transmit	Yes	Yes
	Specified pages per file	Yes	—
	Maximum number of send data	Yes	
	Sender name	Max.999 destinations	

	Mode	Scanner	Internet FAX	FAX
Receive function	Auto receive	—	Yes	
	Manual receive	—	Yes	
	Memory receive	—	Yes	
	Reduction receive for standard size	—	Yes	
	Scaling receive for specified size	—		
	Rotation receive	—	Yes	
	Divided receive	—	Yes: To be defined by key operator program	
	Duplex receive	—	Yes: To be defined by key operator program	
	2 in 1 receive	—		
	Address/Domain-specified reception is enabled.		Yes 50 address	-
	Address/Domain-specified reception is disabled.		Yes 50 address	Only the specified number
	External phone connection	—		Yes
	Answering phone connection	—	No (Remedy for PAT)	
	Transfer function at output trouble	—	Yes	
	Auto startup mode	—	Yes	
Special function	Time setting	Yes		
	Transmit request	—		Yes
	Remote transmit	—		Yes
	Cover function	—		No
	Print at sender	—	Yes	
	Page division	Yes		
	Page combination	No		
	Confidential (machine at the other end)	—		Yes (F code method)
	Transmit broadcast direction	—		Yes (F code method)
	Transmit message	—		
	Edge erase	Yes		
	Center erase	Yes		
	2 in 1	Yes		
	Card shot	Yes		
	Report/ List function	Transmit/receive record	Yes	
Transmit/receive result		No	Yes	
Address/phone directory list		Yes		
Group list		Yes		
ID/Sender's address list)		—		
Sender list		Print administrator address.	No Described in the key operation list	
Confidential box check list		—		Yes (Integrated to the memory box list)
Transmit group list		—		Yes (Integrated to the memory box list)
Program list		Yes		
Reserved transmit list		—		
Memory box list		—		Yes (FAX mode only)
Memory clear notice list		— (It's possible that this is output in case of errors.)		
Others		PC-facsimile transmission	—	PC-iFAX

(8) Transmission method

Mode	Scanner	Internet FAX	FAX
Transmission time	—	—	2 seconds (level: Super G3/JBIG) 6 seconds (G3 ECM)
Modem speed	—	—	33.6kbps → 2.4kbps automatic fallback
Intercommunication	—	—	Super G3/G3
Communication line	—	—	General telephone line (PSTN), Private branch exchange(PBX), FAX line
ECM	—	—	Yes

(9) Record size

Mode	Scanner	Internet FAX	FAX
Max. record width	—	293mm	—
Record size	—	A3-A5, 11" x 17"- 5.5" x 8.5"	A3-A5, 11" x 17"- 5.5" x 8.5"

(10) F code transmission

Mode	Scanner	Internet FAX	FAX
Sub address	—	—	Yes
Passcode	—	—	Yes

C. Copy function

(1) Copy Speed

	AR-M355N			AR-M455N		
	Actual	Reduction	Enlargement	Actual	Reduction	Enlargement
A4, 8.5" x 11"	35	35	35	45	45	45
A4R, 8.5" x 11"R	25	25	25	30	30	30
A5R, 5.5" x 8.5"R, Invoice-R	35	35	35	45	45	45
B5	35	35	35	45	45	45
B5R, Executive-R	25	25	25	30	30	30
B4, 8.5" x 14"	20	20	20	22	22	22
A3, 11" x 17"	17	17	17	20	20	20
Extra, Envelope	17	17	17	20	20	20

* Figures in reduction/enlargement are represented by those at the ratio to show slowest speed

(2) First copy time

Conditions: A4 or 8.5"x11" from front tray of PPC, with polygon motor running.

	AR-M355N	AR-M455N
Document glass *1	Less than 5.3 seconds	Less than 4.6 seconds
DSPF	Less than 6.0 seconds	Less than 5.3 seconds

*1: During OC mode

(3) Job speed

	AR-M355N	AR-M455N
S → S *1	33 cpm (94%)	42 cpm (93%)
S → D *2	32 cpm (91%)	40 cpm (88%)
D → D *3	32 cpm (91%)	40 cpm (88%)

*1: S → S : A4 / 8.5" x 11" original 5 sheets copy 5sets

*2: S → D : A4 / 8.5" x 11" original 10 sheets copy 5sets

*3: D → D : A4 / 8.5" x 11" original 5 sheets (10 pages) copy 5sets

(4) Continuous copy

Max. multiple number	999 pages
----------------------	-----------

(5) Copy Ratio

Copy ratio	AB series : 25%, 50%, 70%, 81%, 86%, 100%, 115%, 122%, 141%, 200%, 400% Inch series : 25%, 50%, 64%, 77%, 100%, 121%, 129%, 200%, 400%
Zoom	25 - 400% 25 - 200% (Copy from DSPF)
Independent scaling	4

(6) Exposure/Copy Quality Process

Exposure mode	Binary: Text(auto/manual), Text/photo, Photo 256 levels: Not provided
Manual steps	9 steps
Toner save mode	Standard

(7) Copy Function

Function	APS	Yes
	AMS	Yes
	XY zoom	Yes
	Paper type select	Yes (By type setting)
	Auto tray switching	Yes
	Rotation copy	Yes
	Electronic sort	Yes
	Rotation sort	Yes
	Reserved copy	Yes
	Prior tray setting	No
	Recall/register of program	Yes
	Document filing	Yes
	Proof copy	No
	Preheat function	Yes (To be set up by the key operator program)
	Auto power shut-off function	Yes (To be set up by the key operator program)
	Account control	Yes 500 accounts
	Process control	Yes
	Tandem copy	Yes (via network)
	Tab copy	No
	Book copy	Yes
	Irregular original size input	Yes
	Irregular paper size input	Yes

Special function	Margin shift	Yes
	Edge erase/Center erase	Yes
	Dual page copying	Yes
	Covers/Inserts/Tab Inserts	Yes
	Transparency insert	Yes
	Centering	No
	Multi shot (Nin1)	Yes (2 in 1 / 4 in 1) (Centering: Yes)
	Card shot	Yes
	Pamphlet copy	Yes (Centering: Yes)
	2-sided copy orientation change	Yes
	Job build	Yes (max.10000 sheets)
	Negative image	Yes
	Shading	No
	Mirror image	Yes
	Multi-page enlargement	No
	Repeat	No
	Date stamp	Yes
	Stamp	Yes
	Character stamp	Yes
	Page stamp	Yes

Yes: Standard Function

No: Not provided

3. B/W Scanner Module (DSPF)

(1) Form

Scanner (Document glass) / DSPF standard
Operation panel integral type
(common hardware for all the destinations)

(2) Resolution / Gradation

Reading resolution (dpi)					
Copy mode					
Magnification	25 - 99	100	101 - 200	201 - 400	—
OC	600x600	600x600	600x600	600x600	—
OC (High speed): Text/Auto	600x600	600x300	600x600	600x600	—
OC (High speed): Others	600x600	600x300	600x600	600x600	—
DSPF/SPF (standard)	600x300	600x300	600x600	-	—
DSPF/SPF (high quality)	600x600	600x600	600x600	-	—
Input and transmitting resolution (dpi)					
FAX transmit mode and scanner/fax multicasting mode					
Selection mode	Standard	Fine	Super fine	Ultra fine	600dpi sending
Input resolution: OC	600 x391.2	600x391.2	600x391.2	600x391.2	—
Input resolution: DSPF	600x300	600x300	600x300	600x300	—
Transmitting resolution	203.2x97.8	203.2x195.6	203.2x391	406.4x391	—
Internet-FAX					
	200x100	200x200	200x400	400x400	600x600
Scanner mode					
Selection mode	Standard	Fine	Super fine	Ultra fine	—
Input resolution: OC	600x391.2	600x391.2	600x391.2	600x600	—
Input resolution: DSPF	600x300	600x300	600x300	600x300	—
Transmitting resolution	200x200	300x300	400x400	600x600	—
Reading level					
256 tones					
Exposure lamp					
Electrodeless xenon lamp					
Output level					
Binary					

(3) Document Glass

Reading area	297 x 431.8 (mm) 11.7" x 17"
Original alignment	Left edge / Rear corner alignment
Original size detection	Provided (Standard size only)
Sizes to be detected	Automatic (one detection unit to be used with software modification by destination)
Inch-1	11" x 17", 8.5" x 14", 8.5" x 11", 8.5" x 11"R, 5.5" x 8.5"
Inch-2	11" x 17", 8.5" x 13", 8.5" x 11", 8.5" x 11"R, 5.5" x 8.5"
AB-1	A3, B4, A4, A4R, B5, B5R, A5
AB-2	A3, A4, A4R, A5, B5, B5R, 216 x 330 mm
AB-3	8K, A4, A4R, A5, B4, 16K, 16KR

OR guide display	Rear left side (Print display)	Original reference position "⇒"
	Left side OR guide (Print display)	(From the Interior side) 5-1/2, A5R, B5R, A4R/A5, 8.5", B4R/B5, 11", A3R/A4
	Interior side OR guide (Print display)	(From the left side) 5-1/2, A5, B5, A4/A5R, 8-1/2, B5R, 11", A4R, 13", 14", B4R, A3R, 17"
	Interior side OR guide	Book marks are at A4 and 8-1/2 positions.
	The position available to attach the staple position guide label when the optional finisher (desktop console type) is equipped.	

(4) DSPF/SPF

Type	DSPF	One-scan-dual-side scanning method DSPF with OC integrated
Scan speed	Standard mode	45 opm
	High quality mode	22.5 opm
Original alignment	Center alignment	
Original size	A3, B4, A4, A4R, B5, B5R, A5, A5R 11"x17", 8.5"x14", 8.5"x13", 8.5"x11", 8.5"x11"R, 5.5"x8.5", 5.5"x8.5"R, 8K, 16K, 16KR (Long size original up to 800mm in FAX, e-mail and iFAX mode)	
Original paper weight	50~128g/m ² , 15~34lbs	
Original stack capacity	Max. 50 sheets (Max. 30 sheets for A3, B4, 11" x 17", 8.5" x 14") (Max. 15 sheets for A3, B4, 11" x 17", 8.5" x 14" over 105g/m ²) or, Total thickness less than Max. 6.5mm (at 50 to 80g/m ² , 15 to 21lbs) Max. 5.0mm (at 80 to 128g/m ² , 21 to 34lbs)	
Not transportable original type	Transparency film, secondary original paper, tracing paper, carbon paper, thermal paper, original with crumple/crimp/rip, original with attachment/clipping, original with many punch holes (with 2 or 3 holes acceptable), original preprinted with ink-ribbon.	
Original size detection	Provided	
Sizes to be detected	Automatic (one detection unit to be used with software modification by destination)	
	Inch-1	11" x 17", 8.5" x 14", 8.5" x 11", 8.5" x 11"R, 5.5" x 8.5", A4, A3
	Inch-2	11" x 17", 8.5" x 13", 8.5" x 11", 8.5" x 11"R, 5.5" x 8.5", A4, A3
	AB-1	A3, B4, A4, A4R, B5, B5R, A5, A3, 8.5" x 11", 11" x 17" 216 x 330 mm
	AB-2	A3, B4, A4, A4R, B5, B5R, A5, 8.5" x 11", 11" x 17", 216 x 330 mm
Original tray guide display	Center of the tray (inscribed display)	Original reference position "←" Original face-down placement indication "⏏"
	Original Guide (inscribed display)	(From Center) B5R, A4R/A5, 8.5", B4R/B5, 11", A3R/A4
	The position available to attach the staple position guide label when the optional finisher (desktop console type) is equipped.	

(5) Power Source

Supplied from the main unit

(6) Dimensions

External dimensions (WxDxH)	808 x 619x180 mm
Occupied space dimensions (WxD)	945 x 619 mm (When the tray is extended)
Weight	Approx. 19.5 kg

(7) Display device at scanner part

Type	Dot map LCD, touch panel
Display dot number	640 x 240 dots (dot pitch 0.24x0.24 mm)
LCD operating dimension	153.5 x 57.5 mm
LCD back-light	Fluorescent tube method
LCD brightness adjustment	Provided

(8) Key

Mode selection area	Job status key Document filing key (* online display LED/data in-memory display LED) Image send key (busy display LED/data in-memory display LED) Copy mode key User definition key
Basic input area	Start key CA key 10-key Clear key * key #/P key

* For pirnter

(9) Touch sense method

Resistive film method

(10) Used character in the LCD

Dot	8 x 16 , 16 x 16 dots
Bold display	O

4. Rack for Scanner

(1) Dimensions

Strength	60 kg
External dimensions (W x D x H)	30 x 415 x 860 mm (Single goods)
Occupied space dimensions (W x D)	575 x 415 mm (State of installation) (2pieces)
Weight	Approx.5 kg (2pieces)

[4] CONSUMABLE PARTS

1. Supply system table

A. USA/CANADA

NO	Name	Content	Life	Product name	Remark
1	Toner cartridge (Black)	Toner cartridge (with IC) (Toner : Net weight 750 g) x 10	350k (35k x 10)	AR-455MT	*Life setup is based on A4 6%
2	Developer (Black)	Developer (Developer : Net weight 500 g) x 10	1000k (100k x 10)	AR-455MD	
3	Drum	OPC drum x1	200k	AR-455DR	
4	50K maintenance kit	Cleaner blade x1 Drum separation pawl x4 Screen grid x1 Toner reception seal x1 Side malt F x1 Side malt R x1 Charging plate x1	50K	AR-450KC1	
5	100K maintenance kit	Transfer roller x1 Discharging plate x1 Paper dust removing unit x1 DV blade x1 DV side seal F x1 DV side seal R x1	100K	AR-450KA1	
6	Upper heat roller kit	Upper heat roller x1 Fusing separation pawl (Upper) x4	200K	AR-450UH	
7	Lower heat roller kit	Lower heat roller x1 Fusing separation pawl (Lower) x2	200K	AR-450LH	
8	Cleaner blade	Cleaner blade x10	50K(x10)	AR-450CB	AR-450CB=(AR-450BL)x10
9	Cleaning roller	Cleaning roller x10 Bearing x20	200K(x10)	AR-450CR	AR-450CR=(AR-450RC)x10
10	Staple cartridge	Staple cartridge x3	3000x3	AR-SC1	Common with cartridge for AR-FN4 & AR-FN6
11	Staple cartridge	Staple cartridge x3	5000x3	AR-SC2	Common with cartridge for AR-FN7

Note 1: Print on Master/individual carton:Toner/Developer in 2 languages (English/French), DR in 4 languages (English/French/German/Spanish).

Note 2: Packed with machine: DR 50K/Developer UN/Process UN

Note 3: The other maintenance parts which are not listed above are registered as service parts.

2. Production number identification

A. Drum cartridge

The lot number, printed on the front side flange, is composed of 10 digits, each digit showing the following content:

1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	----


- 1 Number
For this model, this digit is 2.
- 2 Alphabet
Indicates the model conformity code. T for this model.
- 3 Number
Indicates the end digit of the production year.
- 4 Number or X, Y, Z
Indicates the production month.
X stands for October, Y November, and Z December.
- 5/6 Number
Indicates the production day on the month.
- 7 Number or X, Y, Z
Indicates the month of packing.
X stands for October, Y November, and Z December.
- 8/9 Number
Indicates the day of the month of packing.
- 10 Alphabet
Indicates the production factory. "A" for Nara Plant.

B. Toner cartridge

The lot number is of 7 digits, and each digit indicates as follows.
The lot number shall be printed in the position shown in the figure.

1	2	3	4	5	6	7
---	---	---	---	---	---	---

- 1 Version number (A - sequentially revised)
- 2 Numeral figure
Indicates the end digit of the production year.
- 3 Alphabet
Indicates the production factory. (B for SOCC)
- 4 Destination code
- 5,6 Numeral figures
Indicates the production day.
- 7 Numeral figure or X, Y, Z
Indicates the production month.
X stands for October, Y November, and Z December.



C. Developer cartridge


The lot number is of 8 digit, and each digit indicates as follows.
The lot number shall be printed on the bag.

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---


- 1 Alphabet
Indicates the production factory.
- 2 Number
Indicates the production year.
- 3/4 Number
Indicates the production month.
- 5/6 Number
Indicates the production day.
- 7 Hyphen
- 8 Number
Indicates the production lot.

3. Environmental conditions

A. Operating conditions



B. Storage conditions



[6] UNPACKING AND INSTALLATION



1. Installing procedure flowchart

There are many combinations between this machine and option units. For installing option units, observe the following procedures for efficiency.

To install the devices efficiently, follow the procedure below.

Some peripheral devices may have been installed as standard devices depending on the main unit model.

Part of descriptions and illustrations may be different.




* For installation of an option unit, refer to the Service Manual of the option unit.


2. Note for installation place

Improper installation may damage this product. Please note the following during initial installation and whenever the machine is moved.

- 1) The machine should be installed near an accessible power outlet for easy connection.
- 2) Be sure to connect the power cord only to a power outlet that meets the specified voltage and current requirements. Also make certain the outlet is properly grounded.
 - For the power supply requirements, see the name plate of the main unit.
- 3) Do not install your machine in areas that are:
 - damp, humid, or very dusty
 - exposed to direct sunlight
 - poorly ventilated
 - subject to extreme temperature or humidity changes, e.g., near an air conditioner or heater.
- 4) Be sure to allow the required space around the machine for servicing and proper ventilation.



3. Unpacking procedure




Check the following items are included in the package.

Operating Manual (Common/Copier/Key Operation)
Install Guide
CD-ROM for Printer
CD-ROM for Network Interface
Maintenance card/Maintenance case

4. Machine installing procedure


Note: In advance to installation of the machine, the paper feed option units (AR-D27/AR-D28/AR-MU2) should have been installed.

A. Remove the locking tape




B. Setting related to process


- 1) Open the left door and the front door.



- 2) Remove the developer cartridge from the machine.



- 3) Remove the top cover of the developer cartridge.




- 4) While rotating the MG roller, supply developer into the developer cartridge evenly.

Note that the MG roller must be rotated in the arrow direction as shown in the figure below.

Use of a metal scale or a screwdriver (-) facilitates the procedure.


Note: Before opening the developer seal, shake it 4 or 5 times.




- 5) Attach the top cover to the developer cartridge and install the cartridge to the machine.

C. Toner cartridge settings


- 1) Remove a new toner cartridge from the package and shake it horizontally five or six times.




- 2) Insert a new toner cartridge.
Push the cartridge in until it locks securely into place.



- 3) Gently remove the sealing tape from the cartridge.




- 4) Return the cartridge lock lever.




D. Setting related to fusing

- 1) Put down the right and the left levers of the fusing unit in the arrow direction.




E. Paper setting


- 1) Pull out the first stage paper feed tray.
Slowly pull out the tray until it stops.



- 2) While pressing the paper holding plate, remove the fixing pin.



- Put paper in the tray, and close the paper feed tray.



5. Automatic developer adjustment


- Attach the cabinets which were removed.
- Close the left door.

At that time, keep the front door open.

Note: The automatic developer adjustment must be performed by entering the simulation mode with the front door open. If the power is turned on with the front door closed, warm-up is performed to supply toner to the developing unit. As a result, the reference toner density cannot be obtained.

- Insert the power plug into the power outlet.
- Go through the modes specified in Simulation 25-2.
- Close the front door.

(LCD Display)



- Press the [START] key, and the automatic developer adjustment will be performed.

During execution of the automatic developer adjustment, "EXECUTING..." is displayed and the toner sensor value is indicated on the LCD. (DEVE REFERENCE)

- After about 2 min, the adjustment value is stored in the machine. Check that the mode was normally completed.

Normal end: Returns to the initial window (PRESS START display).

Abnormal end: Returns to the initial window (PRESS START display), and indicates the trouble display (TROUBLE! EE-**).

In case of an error end, remove the cause of the error, and execute the automatic developer adjustment again.

- Turn off/on the power, and the machine returns to the normal mode and enters the warm-up mode.

6. Print test

- After completion of warm-up (normal mode), select [CUSTOM SETTINGS] → [Data list up] to display the menu.
- Print [ALL SETUP LIST] to check and confirm the print quality.
- Press the [CUSTOM SETTINGS] key again to return to the normal menu.

[7] DISASSEMBLY AND ASSEMBLY, MAINTENANCE

1. Self print of set values

Use of SIM 22-6 allows to print the set values and the jam history of the machine.

These values must be printed before execution of maintenance or disassembly procedures.

2. Maintenance System Table

A. Scanner / DSPF

Maintenance cycle : 200K

× Check (Clean, replace, or adjust as necessary.) ○ Clean

▲ Replace

△ Adjust

☆ Lubricate

□ Move position

Unit name	Part name		When calling	100K	200K	300K	400K	500K	600K	700K	800K	Remark
Optical section	Mirror/Lens/Reflector/Sensors		○	○	○	○	○	○	○	○	○	
	Table glass/Dust-proof glass/OC		○	○	○	○	○	○	○	○	○	
	White reference glass		○	○	○	○	○	○	○	○	○	
	Rails			☆	☆	☆	☆	☆	☆	☆	☆	
	Drive belt/Drive wire/Pulley			×	×	×	×	×	×	×	×	
DSPF	Paper feed section	Pick-up roller	○	○	○	○	○	○	○	○	○	Note 2
		Paper feed roller	○	○	○	○	○	○	○	○	○	Note 2
		Separation mylar lower	○	○	○	○	○	○	○	○	○	Note 2
		Separation pad	○	○	○	○	○	○	○	○	○	Note 2
	Transport section	PS roller	○	○	○	○	○	○	○	○	○	
		Exposure section (Dust-proof glass)	○	○	○	○	○	○	○	○	○	
	Paper exit section	Paper exit roller	○	○	○	○	○	○	○	○	○	
	Other	Sensors		○	○	○	○	○	○	○	○	For cleaning, blow air.

Note 2: Replacement reference: Replace by using the SPF counter value as an indication.

Paper feed section pickup roller, paper feed roller, separation pad, separation lower mylar lower:
100K or 1 year

B. Engine section

Maintenance cycle : 200K

× Check (Clean, replace, or adjust as necessary.) ○ Clean

▲ Replace

△ Adjust

☆ Lubricate

□ Move position

Unit name	Part name	When calling	100K	200K	300K	400K	500K	600K	700K	800K	Remark
Drum peripheral	Drum		×	▲	×	▲	×	▲	×	▲	Replace at 200K or 1 year.
	Cleaner blade		×	▲	×	▲	×	▲	×	▲	
	Toner reception seal		×	▲	×	▲	×	▲	×	▲	
	Side molt F		×	▲	×	▲	×	▲	×	▲	
	Side molt R		×	▲	×	▲	×	▲	×	▲	
	Transfer roller	×	×	▲	×	▲	×	▲	×	▲	
	Discharge plate	×	×	▲	×	▲	×	▲	×	▲	
	TR bearing (F/R)		×	×	×	▲	×	×	×	▲	
	Transfer roller collar		×	×	×	▲	×	×	×	▲	
	After-transfer star ring		×	×	×	×	×	×	×	×	
	TR gear	×	×	▲	×	▲	×	▲	×	▲	
	Drum separation pawl unit		×	▲	×	▲	×	▲	×	▲	
	MC unit	×	○	▲	○	▲	○	▲	○	▲	Includes the screen grid, the charging plate, and the MC cleaner. ○: Charging plate cleaning by the MC cleaner
	Paper guide	○	○	○	○	○	○	○	○	○	
Developing section	Developer		▲	▲	▲	▲	▲	▲	▲	▲	Supplied when installing
	DV blade		×	▲	×	▲	×	▲	×	▲	
	DSD collar		○	○	○	○	○	○	○	○	
	DV side seal F		×	▲	×	▲	×	▲	×	▲	
	DV side seal R		×	▲	×	▲	×	▲	×	▲	
	Toner cartridge		—	—	—	—	—	—	—	—	Attached when installing./ 750g, user replacement for every 35K.
Fusing section	Upper heat roller	×	×	▲	×	▲	×	▲	×	▲	
	Lower heat roller	×	×	▲	×	▲	×	▲	×	▲	
	Upper separation pawl	○	○	▲	○	▲	○	▲	○	▲	
	Lower separation pawl	○	○	▲	○	▲	○	▲	○	▲	
	Thermistor	×	×	×	×	×	×	×	×	×	Clean and remove paper dust.
	Upper heat roller gear		×	▲	×	▲	×	▲	×	▲	
	Paper guides	○	○	○	○	○	○	○	○	○	
	Gears		☆	☆	☆	☆	☆	☆	☆	☆	
	CL roller	×	×	▲	×	▲	×	▲	×	▲	
	CL roller bearing	×	×	▲	×	▲	×	▲	×	▲	
Filters	Ozone filter		▲	▲	▲	▲	▲	▲	▲	▲	
Paper feed section	Pick-up roller	×	×	×	×	×	×	×	×	×	Note 1
	Paper feed roller	×	×	×	×	×	×	×	×	×	Note 1
	Separation roller	×	×	×	×	×	×	×	×	×	Note 1
	Torque limiter	×	×	×	×	×	×	×	×	×	Note 1
Transport section	PS follower roller	×	○	○	○	○	○	○	○	○	
Paper exit reverse section	Transport rollers	×	○	○	○	○	○	○	○	○	
	Transport paper guides	○	○	○	○	○	○	○	○	○	
	Paper dust remover unit	○	○	▲	○	▲	○	▲	○	▲	
	Optical reflection sensor	○	○	○	○	○	○	○	○	○	PS roller unit section
Drive section	Gears (Specified position)	×	☆	☆	☆	☆	☆	☆	☆	☆	
	Belts	×	×	×	×	×	×	×	×	×	
Image quality		×	×	×	×	×	×	×	×	×	
Other	Sensors		×	×	×	×	×	×	×	×	Cleaning is performed by air blowing.

Note 1: Replacement reference: Use the counter value of each paper feed port as the replacement reference.

Paper feed roller/Separation pad/Torque limiter section (Include Desk, Multi purpose): 100K or 1 years

C. Peripheral devices

Maintenance cycle : 50K

× Check (Clean, replace, or adjust as necessary.) ○ Clean

▲ Replace

△ Adjust

☆ Lubricate

□ Move position

Option name	Part name		When calling	100K	200K	300K	400K	500K	600K	700K	800K	Remark
Finisher	Transport section	Transport rollers	○	○	○	○	○	○	○	○	○	
		De-curler roller	(○)×	○	○	○	○	○	○	○	○	
		Transport paper guides	×	○	○	○	○	○	○	○	○	
	Drive section	Gears	×	☆	☆	☆	☆	☆	☆	☆	☆	(Specified position)
		Belts	×	×	×	×	×	×	×	×	×	
	Other	Sensors	×	×	×	×	×	×	×	×	×	
		Discharge brush	×	×	×	×	×	×	×	×	×	
	Staple unit											Replace unit at 200K staple.
	Staple cartridge											User replacement for every 3000 pcs.
Mail-bin stacker	Transport section	Transport rollers	×	○	○	○	○	○	○	○	○	
		Transport paper guides	×	○	○	○	○	○	○	○	○	
	Drive section	Gears	×	☆	☆	☆	☆	☆	☆	☆	☆	(Specified position)
		Belts	×	×	×	×	×	×	×	×	×	
	Other	Sensors	×	×	×	×	×	×	×	×	×	
		Discharge brush	×	×	×	×	×	×	×	×	×	
Saddle finisher, punch unit	Transport section	Transport rollers	×	○	○	○	○	○	○	○	○	
		Transport paper guides	×	○	○	○	○	○	○	○	○	
	Drive section	Gears	×	☆	☆	☆	☆	☆	☆	☆	☆	(Specified position)
		Belts	×	×	×	×	×	×	×	×	×	
	Other	Sensors	×	×	×	×	×	×	×	×	×	
		Discharge brush	×	×	×	×	×	×	×	×	×	
	Staple unit											Replace unit at 300K staple.
	Staple cartridge											User replacement for every 5000 pcs.
	Punch unit											Replace unit at 1000K.
ADU + Manual feed	Paper feed separation section	Paper feed rollers	(○)×	(○)×	(○)×	(○)×	(○)×	(○)×	(○)×	(○)×	(○)×	Note 3
	Transport section	Transport rollers	×	○	○	○	○	○	○	○	○	
		Transport paper guides	×	○	○	○	○	○	○	○	○	
	Drive section	Gears	×	☆	☆	☆	☆	☆	☆	☆	☆	(Specified position)
		Belts	×	×	×	×	×	×	×	×	×	
	Other	Sensors	×	×	×	×	×	×	×	×	×	

Note 3: Replacement reference: Use the counter value of each paper feed port as the replacement reference.

Paper feed section pickup roller, paper feed roller, separation pad: 100K or 1 year

[9] SIMULATION

1. Outline and purpose

The simulation has the following functions to grasp the machine operating status, identify the trouble position and causes in an earlier stage, and make various setups and adjustments speedily for improving the serviceability of the machine.

- 1) Various adjustments
- 2) Setup of specifications and functions
- 3) Canceling troubles
- 4) Operation check
- 5) Various counters check, setup, and clear
- 6) Machine operating status (operation history) data check, clear
- 7) Transfer of various data (adjustments, setup, operations, counters)

The operating procedures and the displays differ depending on the form of the operation panel of the machine.

2. Code-type simulation

A. Operating procedures and operations

* Entering the simulation mode


- 1) Copy mode key ON → Program key ON → Asterisk (*) key ON → CLEAR key ON → Asterisk (*) key ON → Ready for input of a main code of simulation
- 2) Entering a main code with the 10-key → START key ON
- 3) Entering a sub code with the 10-key → START key ON
- 4) Select an item with the scroll key and the item key.
- 5) The machine enters the mode corresponding to the selected item.

Press START key or EXECUTE key to start the simulation operation.

To cancel the current simulation mode or to change the main code and the sub code, press the user setup key.

* Canceling the simulation mode to return to the normal mode

- 1) Press CA key.



B. Simulation list

(1) Main/ Sub

Code		Function (Purpose)
Main	Sub	
1	1	Used to check the operations of the scanner (read) unit and its control circuit.
	2	Used to check the operation of sensor and detector in the scanning (read) section and the related circuit.
2	1	Used to check the operations of the automatic document feeder unit and the control circuit.
	2	Used to check the operations of the sensors and detectors in the automatic document feeder unit and the related circuits.
	3	Used to check the operations of the loads in the automatic document feeder unit and the control circuits.
3	2	Used to check the operation of sensor and detector in the finisher and the related circuit.
	3	Used to check the operation of the load in the finisher and the control circuit.
	6	Used to adjust the stacking capacity of the finisher. (Used to adjust the alignment plate (jogger) stop position in the finisher paper width direction. The adjustment is made by changing the alignment plate home position in the paper width direction by software.)
	10	Console finisher adjustment
	20	Used to check the mail bin stacker sensor.
	21	Used to check the operations of the mail bin stacker loads.
4	2	Used to check the operations of the sensors and detectors in the paper feed section (desk paper feed/large capacity tray) and the related circuit.
	3	Used to check the operations of the loads in the paper feed section (desk paper feed/large capacity tray) and the related circuit.
5	1	Used to check the operation of the display, LCD in the operation panel, and control circuit.
	2	Used to check the operation of the heater lamp and the control circuit.
6	1	Used to check the operation of the paper transport system loads and the control circuit.
	2	Used to check the operations of each fan motor and its control circuit.
7	1	Used to set the operating conditions of aging.
	6	Used to set the intermittent aging cycle.
	8	Used to set the warm-up time display YES/NO.
8	1	Used to check and adjust the operations of the developing voltage of each color and the control circuit.
	2	Used to check and adjust the operation of the main charger grid voltage in each printer mode and the control circuit.
	6	Used to check and adjust the operation of the transfer voltage and the control circuit.
	17	Used to check and adjust the operation of the transfer voltage and the related circuit. (Transfer belt cleaning mode)
9	1	Used to check and adjust the operation of the load (clutch/solenoid) in the duplex section and the control circuit.
	2	Used to check the operations of the sensors and detectors in the duplex section and its control circuit.
10	1	Used to check the operations of the toner motor and the related circuit.

Code		Function (Purpose)
Main	Sub	
13	0	Used to cancel the self-diag "U1" trouble. (Only when FAX is installed.)
14	0	Used to cancel excluding the self-diag U1/LCC/ U2/PF troubles.
15	0	Used to cancel the self-diag "U6-09, F3-12, 22" (large capacity paper feed tray, paper feed trays 1, 2) troubles.
16	0	Used to cancel the self-diag U2 troubles.
17	0	Used to cancel the PF troubles (when the copy inhibit command from the host computer is received).
21	1	Used to set the maintenance cycle.
22	1	Used to check the print count value in each section and each operation mode. (Used to check the maintenance timing.)
	2	Used to check the total numbers of misfeed and troubles. (When the number of misfeed is considerably great, it is judged as necessary for repair. The misfeed rate is obtained by dividing this count value with the total counter value.)
	3	Used to check misfeed positions and the misfeed count of each position. (If the misfeed count is considerably great, it may be judged as necessary to repair.)
	4	Used to check the trouble (self diag) history.
	5	Used to check the ROM version of each unit (section).
	6	Used to output the list of the setting and adjustment data (simulations, FAX soft switch, counters).
	7	Used to display the key operator code. (This simulation is used when the customer forgets the key operator code.)
	8	Used to check the number of use of the finisher, the SPF, and the scan (reading) unit.
	9	Used to check the number of use (print quantity) of each paper feed section.
	10	Used to check the system configuration (option, internal hardware).
	11	Used to check the use frequency (send/receive) of FAX. (Only when FAX is installed)
	12	Used to check the SPF misfeed positions and the number of misfeed at each position. (When the number of misfeed is considerably great, it can be judged as necessary for repair.)
	13	Used to check the operating time of the process section (OPC drum, DV unit, toner bottle).
	19	Used to check the values of the counters related to the scan mode and the internet FAX mode.
	23	2 Used to check the trouble history of paper jam and misfeed. (If the number of misfeed and troubles is considerably great, it may be judged as necessary to repair.)
	80	Used to check the operations of the sensors and detectors in the paper feed and transport section.
	1	Used to clear the misfeed counter, the misfeed history, the trouble counter, and the trouble history. (The counters are cleared after completion of maintenance.)
	2	Used to clear the number of use (the number of prints) of each paper feed section.
	3	Used to clear the number of use of the finisher, SPF, and the scan (reading) unit.
	4	Used to reset the maintenance counter.
	5	Used to reset the developer counter. (The developer counter of the DV unit which is installed is reset.)

Code		Function (Purpose)
Main	Sub	
24	6	Used to reset the copy counter.
	7	Used to clear the OPC drum counter. (Perform this simulation when the OPC drum is replaced.)
	9	Used clear the printer mode print counter and the self print mode print counter.
	10	Used to clear the FAX counter. (Only when FAX is installed)
	11	Used to reset the OPC drum rotation time, and the DV unit rotation time counter. The developer counter in the DV unit installed is reset.
	15	Used to clear the counters related to the scan mode and the internet FAX mode.
25	1	Used to check the operations of the developing section (toner concentration, humidity and toner concentration sensor, humidity sensor, temperature sensor output can be monitored.)
	2	Used to make the initial setting of toner concentration when replacing developer.
26	3	Used to set the specifications of the auditor. Setting must be made according to the auditor use conditions.
	5	Used to set the count mode of the total counter and the maintenance counter.
	6	Used to set the specifications (paper, fixed magnification ratio, etc.) of the destination.
	10	Used to set the network scanner trial mode.
	18	Used to set YES/NO of toner save operation. (This function is valid only in Japan and UK versions. (Depends on the destination setting of SIM26-6.) For the other destinations, the same setting can be made by the user program P22.)
	30	Used to set the operation mode conforming to the CE mark (Europe safety standards). (Conforming to soft start when driving the fusing heater lamp.)
	35	Used to set whether the same continuous troubles are displayed as one trouble or the series of troubles with SIM 22-4 when the same troubles occur continuously.
	38	Used to set CONTINUE/STOP of printing when maintenance timing is over and the count value reaches 110% of replacement timing (life).
	41	Used to set YES/NO of the automatic magnification ratio selection (AMS) in the pamphlet mode.
	50	Black-White reverse YES/NO setting
27	52	Used to set whether non-print paper (insertion paper, cover paper) (blank image print paper) is counted up or not.
	68	Used to set ENABLE/DISABLE of the CA key cancel function of print stop.
	1	Used to set the specifications for operations in case of communication trouble between the host computer and MODEM (machine side). (When communication trouble occurs between the host computer MODEM and the machine, the self diag display (U7-00) is printed and setting for inhibition of print or not is made.)
	5	Used to enter the machine tag No. (This function allows to check the tag No. of the machine with the host computer.)
30	1	Used to check the operation of sensors and detectors in other than the paper feed section and the operations of the related circuits.
	2	Used to check the operation of sensors and detectors in the paper feed section and the related circuits.

Code		Function (Purpose)
Main	Sub	
40	1	Used to check the operation of the manual feed tray paper size detector and the related circuit. (The operation of the manual feed tray paper size detector can be monitored with the LCD display.)
	2	Used to adjust the manual paper feed tray paper width detector detection level.
	7	Used to enter the manual paper feed tray paper width adjustment value.
	11	Used to check the multi-purpose tray width detection adjustment value.
	12	Used to check the multi-purpose tray width detection adjustment value.
41	1	Used to check the operation of the document size sensor and the related circuit. (The operation of the document size sensor can be monitored with the LCD display.)
	2	Used to adjust the document size sensor sensing level.
	3	Used to check the operation of the document size sensor and the related circuit. (The document size sensor output level can be monitored with the LCD display.)
43	1	Used to set the fusing temperature in each operation mode.
44	1	Used to set enable/disable of correction operations in the image forming (process) section.
	9	Used to check the data related to the image forming section correction (process correction) result (corrected main charger grid voltage, the developing bias voltage, and the laser power voltage in each print mode). (This simulation allows to check that correction is performed normally or not.)
	14	Used to check the output level of the temperature sensor and the humidity sensor.
	16	Used to check the toner concentration control data.
46	2	Used to adjust the copy density in all the copy modes (Auto, Text, Text/Photo, and Photo mode).
	9	Used to adjust the print density for each density level (display value) in the copy mode (binary - Text mode). An optional print density can be set for each density level (display value).
	10	Used to adjust the print density for each density level (display value) in the copy mode (binary - Text/Photo mode). An optional print density can be set for each density level (display value).
	11	Used to adjust the print density for each density level (display value) in the copy mode (binary - Photo mode). An optional print density can be set for each density level (display value).
	12	Used to adjust the print density in the FAX mode (all modes).
	13	Used to adjust the print density in the FAX mode (each normal mode). (Only when FAX is installed.)
	14	Used to adjust the print density in the FAX mode (each fine mode). (Only when FAX is installed.)
	15	Used to adjust the print density in the FAX mode (each super fine mode). (Only when FAX is installed.)
	16	Used to adjust the print density in the FAX mode (each ultra fine mode). (Only when FAX is installed.)
	17	Used to set the gain in shading correction.

Code		Function (Purpose)
Main	Sub	
46	18	Used to adjust the gamma (density gradient) in the copy mode.
	19	Used to set the auto mode operation specifications in each mode (copy, scan, FAX).
	20	Used to adjust the copy density correction in the SPF copy mode for the document table copy mode. The adjustment is made so that the copy density becomes the same as that of the document table copy mode.
	21	Used to adjust the scanner exposure level in all the scanner modes.
	22	Used to adjust the scanner exposure level in the normal text mode.
	23	Used to adjust the scanner exposure level in the fine text mode.
	24	Used to adjust the scanner exposure level (in the super fine text mode).
	25	Used to adjust the scanner exposure level in the ultra fine text mode.
	27	Used to adjust the gamma (density gradient) of the network scanner mode.
	31	Used to adjust sharpness of the copy mode.
	39	Used to adjust sharpness of the FAX mode.
	45	Used to adjust the image density in the FAX mode (600dpi).
	46	Used to adjust sharpness of the scanner mode.
48	1	Used to adjust the copy magnification ratio (in the main scanning and the sub scanning directions).
	5	Used to adjust the copy magnification ratio in the sub scanning direction.
50	1	Used to adjust the copy image position and the void area (image loss) adjustment on print paper in the copy mode. (The similar adjustment can be performed with SIM 50-5 and 50-2 (Simplified method).) (Document table mode)
	2	Used to adjust the document scan position, the image print position, and the void area (image loss). (Simple adjustment) (This adjustment is the simple method of SIM 50-1.) (Document table mode)
	5	Used to adjust the print image position and the void area (image loss) on print paper. (Adjustment as the print engine) (This adjustment is reflected on all the FAX/printer/copy modes.)
	6	Used to adjust the copy image position and void area (image loss) on print paper in the copy mode. (The similar adjustment can be performed with SIM 50-7 (simple method).) (SPF mode)
	7	Used to adjust the copy image position and void area (image loss) on print paper in the copy mode. (The similar adjustment can be performed with SIM 50-6.) (SPF mode)
	10	Used to adjust the print image off-center position. (Adjusted separately for each paper feed section.)
	12	Used to adjust the scan image off-center position. (Adjusted separately for each scan mode.)
	27	Used to adjust the image loss of the scan image in the FAX/scan mode.
51	2	Used to adjust the contact pressure of paper on the resist roller of each section (each paper feed, duplex feed and SPF paper feed of the copier). (This adjustment is required when the print image position variations are considerably great or when paper jams occur frequently.)

Code		Function (Purpose)
Main	Sub	
53	6	Used to adjust the DSPF width detection level.
	7	Used to enter the SPF width detection adjustment value.
	8	Used to adjust the document scan start position. (Used to adjust the scanner scan position in the SPF mode front scan.)
55	1	Used to set the specifications of the engine control operations. (PCU PWB)
	2	Used to set the specifications of the scanner control operations. (Scanner control PWB)
	3	Used to set the specifications of the controller operations. (MFP control PWB)
56	1	Used to transfer the MFP controller data. (Used to repair the PWB.)
60	1	Used to check the MFP control (DRAM) operations (read/write).
61	1	Used to check the operation of the scanner (write) unit (LSU).
	2	Used to adjust the laser power (absolute value) in the copy mode.
	3	Used to adjust the laser power (absolute value) in the FAX mode.
	4	Used to adjust the laser power (absolute value) in the printer mode.
62	1	Used to format the hard disk.
	2	Used to check the operation of the hard disk (read/write). (Only in the model with a disk installed) (Partial check)
	3	Used to check the operation of the hard disk (read/write). (All areas check)
	6	Used to check the operations of the hard disk. (The self diag operation of the SMART function is executed.)
	7	Used to check the operations of the hard disk. (The result of the self diag operation of the SMART function is printed out.)
	8	Used to format the hard disk (the system area excluded).
63	10	Used to delete a job complete list (also to delete job log data)
	11	Used to delete document filing data. (The management area (standard folder, user folder) is cleared.)
	11	Used to delete document filing data. (The management area (standard folder, user folder) is cleared.)
64	1	Used to check the result of shading correction. (The shading correction data are displayed.)
	2	Used to execute shading.
	7	Used to adjust the white plate scan start position for shading. (Document table mode)
64	1	Used to check the operation of the printer section (self-print operation). (The print pattern, the paper feed mode, the print mode, the print quantity, and the density can be optionally set.)
65	1	Used to adjust the touch panel (LCD display section) detection position.
	2	Used to check the result of the touch panel (LCD display) detection position adjustment. (The coordinates are displayed.)
66	1	Used to change and check the FAX soft switch functions. (Used to change and check the functions provided for the FAX soft switches.) (Only when FAX is installed)
	2	Used to clear the FAX soft switch function data and to set to the default. (Excluding the adjustment values.) (Only when FAX is installed)

Code		Function (Purpose)
Main	Sub	
66	3	Used to check the operation of the FAX PWB memory (read/write). (This adjustment is required when the PWB is replaced with a new one.) (Only when FAX is installed)
	4	Used to check the output operation of data signals in each data output mode of FAX. (Used to check the operation of MODEM.) Send level: Max. (Only when FAX is installed)
	5	Used to check the output operation of data signals in each data output mode of FAX. (Used to check the operation of MODEM.) An output is sent at the send level set by the soft switch. (Only when FAX is installed)
	6	Used to print the confidential pass code. (Used when the confidential pass code is forgotten.) (Only when FAX is installed)
	7	Used to print the image memory data (memory send/receive). (Only when FAX is installed)
	8	Used to check the output operation of various sound signals of FAX. (Used to check the operation of the sound output IC.) Send level: Max. (Only when FAX is installed)
	9	Used to check the output operation of various sound signals of FAX. (Used to check the operation of the sound output IC.) An output is sent at the send level set by the soft switch. (Only when FAX is installed)
	10	Used to clear all data of the image memory (memory send/receive). The confidential data are also cleared at the same time. (Only when FAX is installed)
	11	Used to check the output operation of FAX G3 mode 300bps. (Used to check the operation of MODEM.) Send level: Max. (Only when FAX is installed)
	12	Used to check the output operation of FAX G3 mode 300bps. (Used to check the operation of MODEM.) An output is send at the send level set by the soft switch. (Only when FAX is installed)
	13	Used to enter (set) the number of FAX dial signal output test. (The dial number set by this simulation is outputted when the dial signal output test is made by SIM 66-14 - 16.) (Only when FAX is installed)
	14	Used to set the make time in the FAX pulse dial mode (10pps) and to test the dial signal output. (The dial number signal set by SIM 66-13 is outputted.) Used to check troubles in dialing and to check the operation. (Only when FAX is installed)
	15	Used to set the make time in the FAX pulse dial mode (20pps) and to test the dial signal output. (The dial number signal set by SIM 66-13 is outputted.) Used to check troubles in dialing and to check the operation. (Only when FAX is installed)
	16	Used to check the dial signal (DTMF) output in the FAX tone dial mode. (The dial number signal set by SIM 66-13 is outputted.) The send level can be set to an optional level. Used to check troubles in dialing and to check the operation. (Only when FAX is installed)
	17	Used to check the dial signal (DTMF) output in the FAX tone dial mode. Send level: Max. Used to check the operation. (Only when FAX is installed)

Code		Function (Purpose)
Main	Sub	
66	18	Used to check the dial signal (DTMF) output in the FAX tone dial mode. An output is sent at the send level set by the soft switch. Used to check the operation. (Only when FAX is installed)
	19	Used to back-up the HDD data into the Flash memory (optional FAX expansion memory: AR-MM9). (Only when FAX is installed)
	20	Used to read the back-up data by SIM 66-19 to the SRAM/HDD. (Only when FAX is installed)
	21	Used to print information related to FAX (various registrations, communication management, file management, system error protocol). (Only when FAX is installed)
	22	Used to adjust the handset volume. (Only when the FAX is installed.)
	23	Used to download the FAX program. (Only when FAX is installed) Not used in the market. (For development)
	24	Used to clear the FAST memory data. (Only when FAX is installed)
	25	Used to register the FAX number for Modem dial-in. (Only when FAX is installed) Not used in the market. (For development)
	26	Used to register external telephone numbers for Modem dial-in. (Only when FAX is installed) Not used in the market. (For development)
	27	Used to register the transfer number for voice warp. (Only when FAX is installed) Not used in the market. (For development)
	29	Used to clear data related to an address book (one-touch registration, program registration/ expansion, relay memory box registration, each table content).
	30	Used to check the change in the TEL/LIU status. (Only when FAX is installed)
	31	Used to check the relay operation. (Only when FAX is installed)
	32	Used to check the receive data (fixed data) from the line. (Only when FAX is installed)
	33	Used to check the signal (BUSY TONE/CNG/ CED/FNET/DTMF) detection. (Only when FAX is installed)
	34	Used to measure the communication time of test image data. (Only when FAX is installed)
	35	Modem program reloading (Only when FAX is installed) Not used in the market. (For development)
	36	Used to check interface between MFPC controller and MDMC. (Check of the data line or the command line) (Only when FAX is installed)
	39	Used to set the destination specifications. (Only when FAX is installed)
	42	PIC program rewriting (Only when FAX is installed)
	43	PIC adjustment value writing (Only when FAX is installed)
67	60	Used to set the ACR data. (Only when FAX is installed)
	2	Used to check the operation of the parallel I/F of the printer. (This simulation is for production only, and requires a special tool for execution. Not used in the market.)
	11	Used to set YES/NO of the parallel I/F select signal of the printer.
	16	Used to check the operation of the network card.

C. Details

1

1-1

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the scanner (read) unit and its control circuit.
Section	Optical (Image scanning)
Item	Operation

Operation/Procedure

- 1) Select the operation mode with 10-key.
- 2) Press START key.

The scanner performs scanning at the speed corresponding to the operation mode.

1	TOP SPEED	Top speed (220mm/s)
2	HIGH SPEED	High speed (168.7mm/s)
3	MIDDLE SPEED	Middle speed (110mm/s)
4	LOW SPEED	Low speed (55mm/s)

SIMULATION 1-1
SCANNER CHECK. SELECT 1-4, AND PRESS START.
1. TOP SPEED
2. HIGH SPEED
3. MIDDLE SPEED
4. LOW SPEED

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and scanning is stopped.

SIMULATION 1-1
SCANNER CHECK. EXECUTING...
1. TOP SPEED
2. HIGH SPEED
3. MIDDLE SPEED
4. LOW SPEED

1-2

Purpose	Operation test/Check
Function (Purpose)	Used to check the operation of sensor and detector in the scanning (read) section and the related circuit.
Section	Optical (Image scanning)
Item	Operation

Operation/Procedure

The sensor and detector operation conditions are displayed.

The active sensors and detectors are highlighted.

- The scanner (read) unit is in the home position.: "MHPS" section is highlighted.
- The scanner (read) unit is not in the home position.: "MHPS" is normally displayed.

MHPS	Optical system home position
------	------------------------------

SIMULATION 1-2
SCANNER SENSOR CHECK..
MHPS

2

2-1

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the automatic document feeder unit and the control circuit.
Section	DSPF
Item	Operation

Operation/Procedure

- 1) Select the operation mode with 10-key.
- 2) Press START key.

The SPF repeat paper feed, transport, and paper exit at the speed corresponding to the operation mode.

The operation can be stopped by [CUSTOM SETTINGS] key.

1	HIGH SPEED	High speed
2	LOW SPEED	Low speed

SIMULATION 2-1
SPF AGING TEST. SELECT 1-2, AND PRESS START.
1. HIGH SPEED
2. LOW SPEED

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.

SIMULATION 2-1
SPF AGING TEST. EXECUTING...
1. HIGH SPEED
2. LOW SPEED

2-2

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the sensors and detectors in the automatic document feeder unit and the related circuits.
Section	DSPF
Item	Operation

Operation/Procedure

The operating conditions of the sensors and detectors are displayed.

The active sensors and detectors are highlighted.

SPFSET	SPF sensor
SOCD	Open/close sensor
SCOV	Paper feed cover sensor
SPED	Document set sensor
SPPD	Resist front detection sensor
SPOD	Document paper exit sensor
SWDn	Document width sensor (n → 1 (inside) - 6 (outside))
SPLSn	Document length sensor (n → 1 (inside) - 2 (outside))
CISSET	CIS installation detection
STSET	Stamp unit installation sensor
SWD_LEN	SPF guide plate position (unit: 0.1mm)
SWD_AD	SPF document width detection volume output AD value

SIMULATION 2-2			
SPF SENSOR CHECK.			
SPFSET	SOC	SCOV	SPED
SPPD	SPOD	SWD6	SWD5
SWD4	SWD3	SWD2	SWD1
SPLS2	SPLS1	CISSET	STSET
SWD_LEN: 2100		SWD_AD: 600	

2-3

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the loads in the automatic document feeder unit and the control circuits.
Section	DSPF
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the target of operation check with 10-key.
- 2) Press START key.

The load selected in procedure 1 is operated.

Press [CUSTOM SETTINGS] key to stop the operation of the load.

1	MOTOR(H)	Motor high speed
2	MOTOR(L)	Motor low speed
3	SDSS	SPF gate solenoid
4	SPFS	SPF pick-up solenoid
5	SPFC	SPF paper feed clutch
6	SRRC	SPF resist roller clutch
7	STMP	Stamp solenoid

SIMULATION 2-3			
SPF LOAD TEST. SELECT 1-7, AND PRESS START.			
1.MOTOR(H)	2.MOTOR(L)		
3.SDSS	4.SPFS	5.SPFC	6.SRRC
7.STMP			

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.

SIMULATION 2-3			
SPF LOAD TEST. EXECUTING...			
1.MOTOR(H)	2.MOTOR(L)		
3.SDSS	4.SPFS	5.SPFC	6.SRRC
7.STMP			

3

3-2

Purpose	Operation test/Check
Function (Purpose)	Used to check the operation of sensor and detector in the finisher and the related circuit.
Section	Finisher
Item	Operation

Operation/Procedure

The operating conditions of the sensors and detectors are displayed.

The active sensors and detectors are highlighted.

Built-in finisher	
STHP	Stapler HP detection
POD	Tray 2 paper exit detection
SCID	Staple compiler paper entry detection
PID	Paper entry detection
T2PD	Tray 2 paper empty detection
T2DN	Tray 2 lower limit detection
T2UP	Tray 2 upper limit detection
JRHP	Jogger R HP
JFHP	Jogger (F) HP
SCID2	Staple compiler paper entry detection 2
STTHP2	Staple rotation HP detection 2
STTHP1	Staple rotation HP detection 1
STUHP	Staple shift HP detection
PSHP	Pusher HP detection
PPD	Paper hold return detection
DSW2	Staple replacement door open detection
DSW1	Compiler jam cancel door open detection
24VM	24V power supply
T1PF	Tray 1 full detection
STSP	Stapling ready detection
STLS	Cartridge inside spare staple empty detection
STNC	Cartridge empty detection
DOPD	Interface unit door open detection
MMLK	Main drive motor lock detection
SCPD	Staple compiler paper empty detection
Console finisher	
FSSS	Stapler safety switch
FJS	Joint switch
FFDSW	Front door switch
FTCS	Upper cover sensor
FFDS	Front door sensor
FSPS	Self prime sensor
FSUC	Stapler connection detection
FSS	Staple sensor
FSTHPS	Stapler HP sensor
FSHP	Slide HP sensor
FLE	Lift lock sensor
FLLS	Lift lower limit sensor
FULS	Lift upper limit sensor
FFE	Bookbinding clock sensor
FFES	Bookbinding paper sensor
FFRHPS	Bookbinding roller HP sensor
FFHPS	Bookbinding HP sensor
FFPS	Bookbinding position sensor
FSL	Paper surface sensor
FBES	Tray paper sensor
FOBHP	Paper exit belt HP sensor
FAS	Alignment tray sensor
FRJHP	Alignment HP sensor R
FFJHP	Alignment HP sensor F
FARHP	Bundle roller HP sensor
FPHPS	Paddle HP sensor
FES	Entry port sensor

- The following units are added when the punch unit is installed to the console finisher:

FPE	Punch motor encoder
FPSHP	Punch side register HP
FPUC	Punch connection detection
FPDS	Punch dust sensor
FPDSS4	Punch side register sensor 4
FPDSS3	Punch side register sensor 3
FPDSS2	Punch side register sensor 2
FPDSS1	Punch side register sensor 1
FPTS	Punch timing sensor

(Built-in finisher)

SIMULATION 3-3			
FINISHER SENSOR CHECK.			
PID	SCID	SCID2	PPD
SCPD	POD	TIPF	T2UP
T2DN	T2PD	STSP	STLS
STNC	STHP	JFHP	JRHP
PSHP	STUHP	STHP1	
STTHP2	DOPD	DSW1	DSW2
24VM	MMLK		

(Console finisher)

SIMULATION 3-2						
FINISHER SENSOR CHECK.						
FSSS	FJS	FFDSW	FTCS	FFDS		
FSPS	FSUC	FSS	FSTHPS	FSHPS	FLE	FLLS
FULS	FFE	PFES	FFRHPS	FFHPS	FFPS	FSLS
FBES	FOBHPS	FAS	FRJHPS	FFJHPS	FARHPS	FPHPS
FES						
(FPE) (FPSHPS) (FPUC) (FPDS) (FPDSS4) (FPDSS3) (FPDSS2)						
(FPDSS1) (FPFS)						

() : Added when the punch unit is installed.

3-3

Purpose	Operation test/Check
Function (Purpose)	Used to check the operation of the load in the finisher and the control circuit.
Section	Finisher
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the target of operation check with 10-key.
 - 2) Press START key.
- The load selected in procedure 1 is operated.
- Press [CUSTOM SETTINGS] key to stop the operation of the load.

Built-in finisher		
1	T2S	Tray 2 solenoid
2	T2OM	Paper exit motor
3	SPS	Stopper solenoid
4	SCRS	Roller pressure release solenoid
5	PPS	Rear edge h folding solenoid
6	SCGS	Compiler gate solenoid
7	STTM	Staple rotation motor
8	STUM	Stapler shift motor
9	MM	Main drive motor
10	EVM	Elevator motor
11	STM	Staple motor
12	JRM	Jogger motor rear
13	JFM	Jogger motor front
14	PSM	Pusher motor
Console finisher		
1	FFC	Folding clutch
2	FPSM	Puncher side register motor
3	FPNM	Punch motor
4	FLM	Shift motor
5	FFSM	Stapler motor
6	FSM	Slide motor
7	FRJM	Alignment motor R
8	FFJM	Alignment motor F
9	FAM	Bundle exit motor
10	FPM	Paddle motor
11	FFM	Transport motor

SIMULATION 3-3	
FINISHER LOAD TEST. SELECT 1- , AND PRESS START.	
	2

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.

SIMULATION 3-3	
FINISHER LOAD TEST. EXECUTING...	
	2

3-6

Purpose	Adjustment
Function (Purpose)	Used to adjust the stacking capacity of the finisher. (Used to adjust the alignment plate (jogger) stop position in the finisher paper width direction. The adjustment is made by changing the alignment plate home position in the paper width direction by software.)
Section	Finisher
Item	Operation

Operation/Procedure

Enter the adjustment value with 10 digit key pad and press START key. The jogger moves to LT position (Inch series) or A4 position (AB series) according to the entered value, and stops there.

SIMULATION 3-6	
FINISHER JOGGER ADJUSTMENT. INPUT VALUE 40-60, AND PRESS START.	
	50

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.

Stops when the operation is terminated.

SIMULATION 3-6	
FINISHER JOGGER ADJUSTMENT. MOVING...	
	50

3-10

Purpose	Adjustment
Function (Purpose)	Console finisher adjustment
Section	Finisher
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the target of operation check with 10-key.
- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.
- 4) Press [START] key. (The entered value is stored.)

Item		Set range	Initial value	1STEP
1	Saddle binding position adjustment	0 - 400	200	0.0707mm
2	Saddle folding position adjustment	0 - 400	200	0.0525mm
3	Front alignment position adjustment	0 - 20	10	0.367mm
4	Rear alignment position adjustment	0 - 20	10	0.367mm

	Item	Set range	Initial value	1STEP
5	Staple rear one-position binding position adjustment	0 - 200	100	0.04374mm
6	Staple front one-position binding position adjustment	0 - 200	100	0.04374mm
7	Staple 2-position binding center adjustment	0 - 200	100	0.04374mm
8	Staple 2-position binding pitch adjustment	0 - 99	50	0.04374mm
9	Punch center adjustment (Slide direction)	47 - 53	50	1mm
10	Punch hole position adjustment (Paper feed direction)	0 - 99	50	0.105mm

SIMULATION 3-10

CONSOLE FINISHER SETTING. SELECT 1-10, AND PRESS START.
 1.SADDLE POSITION 2.FOLDING POSITION
 3.FRONT ADJUST
 4.REAR ADJUST 5.STAPLE REAR
 6.STAPLE FRONT 7.STAPLE BOTH
 8.STAPLE PITCH 9.PUNCH CENTER
 10.PUNCH HOLE

1

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.

SIMULATION 3-10

CONSOLE FINISHER SETTING. INPUT VALUE, AND PRESS START.
 1.SADDLE POSITION

200

3-20

Purpose	Operation test/Check
Function (Purpose)	Used to check the mail bin stacker sensor.
Section	Mail bin stacker
Item	Operation

Operation/Procedure

The operating conditions of the sensors and detectors are displayed.

The active sensors and detectors are highlighted.

MPFD1	Tray 1 paper full detection
MPFD2	Tray 2 paper full detection
MPFD3	Tray 3 paper full detection
MPFD4	Tray 4 paper full detection
MPFD5	Tray 5 paper full detection
MPFD6	Tray 6 paper full detection
MPFD7	Tray 7 paper full detection
MPFD8	Tray 8 paper full detection
MPID	Interface unit paper entry detection
MPPD1	Paper transport sensor 1
MPPD2	Paper transport sensor 2
MPPD3	Paper transport sensor 3
MPPD4	Paper transport sensor 4
MPPD5	Paper transport sensor 5
M24VM	24V power supply
MDD1	Jam cancel door
MDOPD	Interface unit door

SIMULATION 3-20

MAIL BOX SENSOR CHECK.

MPFD1 MPFD2 MPFD3 MPFD4 MPFD5 MPFD6 MPFD7
 MPFD8 MPID MPPD1 MPPD2 MPPD3 MPPD4 MPPD5
 M24VM MDD1 MDOPD

3-21

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the mail bin stacker loads.
Section	Mail bin stacker
Item	Operation

Operation/Procedure

1) Select the number corresponding to the target of operation check with 10-key.

2) Press [START] key.

The load selected in procedure 1 is operated.

Press [CUSTOM SETTINGS] key to stop the operation of the load.

1	MM	Main motor
2	GSOL1	Gate solenoid 1
3	GSOL2	Gate solenoid 2
4	GSOL3	Gate solenoid 3
5	GSOL4	Gate solenoid 4
6	GSOL5	Gate solenoid 5
7	GSOL6	Gate solenoid 6
8	GSOL7	Gate solenoid 7

SIMULATION 3-21

MAIL BOX LOAD TEST. SELECT 1-8 AND PRESS START.

1.MM
 2.GSOL1
 3.GSOL2
 4.GSOL3
 5.GSOL4
 6.GSOL5
 7.GSOL6
 8.GSOL7

2

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.

SIMULATION 3-21

MAIL BOX LOAD TEST. EXECUTING...

1.MM
 2.GSOL1
 3.GSOL2
 4.GSOL3
 5.GSOL4
 6.GSOL5
 7.GSOL6
 8.GSOL7

2

3-30

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the sensors and detectors in the inserter.
Section	Inserter
Item	

Operation/Procedure

The operating conditions of the sensors and detectors are displayed.

The active sensors and detectors are highlighted.

TH_SEN	Sub tray pull-out detection
TS_SEN	Sub tray storage detection
T_SEN	Inserter tray paper size detection
EMP_SEN	Inserter tray empty detection
REG_SEN	Inserter resist sensor
TIM_SEN	Inserter timing sensor detection
JCK_SEN	Inserter cover open/close sensor
H_SEN	Inserter reverse sensor
HI_SEN	Inserter paper exit sensor
HYK_SEN	Inserter reverse unit open/close sensor
S_SW	Inserter set SW
KC_SEN	Base cover open/close sensor

TH_SEN	Sub tray pull-out detection
P_ST_SW	Insertor start SW
P_MO_SW	Insertor staple mode select SW
P_PN_SW	Insertor punch select SW

SIMULATION 3-30

INSERTER SENSOR CHECK.

TH_SEN	TS_SEN	T_SEN	EMP_SEN
REG_SEN	TIM_SEN	JCK_SEN	H_SEN
HI_SEN	HYK_SEN	S_SW	KC_SEN
P_ST_SW	P_MO_SW	P_PN_SW	

3-31

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the loads in the insertor and the related circuits.
Section	Insertor
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the target of operation check with 10-key.
- 2) Press [START] key.
The load selected in procedure 1 is operated.
Press [CUSTOM SETTINGS] key to stop the operation of the load.

1	K_MOT	Reverse motor
2	Y_MOT	Horizontal transport motor
3	H_MOT	Insertor reverse
4	F_SOL	Insertor flapper solenoid
5	R_CL	Insertor resist clutch
6	P_LED	Insertor operation panel upper LED

SIMULATION 3-31

INSERTER LOAD TEST. SELECT 1-6, AND PRESS START.

- | | | |
|----------|----------|----------|
| 1. K_MOT | 2. Y_MOT | 3. H_MOT |
| 4. F_SOL | 5. R_CL | 6. P_LED |

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.

SIMULATION 3-31

INSERTER LOAD TEST. EXECUTING...

2. Y_MOT

3-32

Purpose	Setting (Adjustment)
Function (Purpose)	Insertor paper width detection level setting.
Section	Insertor
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the adjustment item with 10-key.
- 2) Press [START] key.
- 3) Enter the setting (adjustment) value with 10-key.
- 4) Press [START] key.

1	MAX. POSITION	Max. position
2	POSITION 1	Adjustment point 1
3	POSITION 2	Adjustment point 2
4	MIN. POSITION	Min. width

SIMULATION 3-32

INSERTER TRAY VALUE SETTING. SELECT 1-4, AND PRESS START.

- | | |
|--------------------|-----|
| 1. MAX. POSITION : | 72 |
| 2. POSITION 1 : | 380 |
| 3. POSITION 2 : | 710 |
| 4. MIN. POSITION : | 804 |

Press [START] key.

Press [CUSTOM SETTINGS] key.

SIMULATION 3-32

INSERTER TRAY VALUE SETTING. INPUT VALUE 0-1023, AND PRESS START.

1. MAX. POSITION

4

4-2

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the sensors and detectors in the paper feed section (desk paper feed/large capacity tray) and the related circuit.
Section	Paper feed
Item	Operation

Operation/Procedure

The operating conditions of the sensors and detectors are displayed.

The active sensors and detectors are highlighted.

<Desk>

DDRS	Desk door sensor
DSPD2	Desk cassette 2 remaining paper quantity sensor
DSPD1	Desk cassette 1 remaining paper quantity sensor
DCSS24	Desk cassette 2 paper rear edge sensor 4
DCSS23	Desk cassette 2 paper rear edge sensor 3
DCSS22	Desk cassette 2 paper rear edge sensor 2
DCSS21	Desk cassette 2 paper rear edge sensor 1
DLUD2	Desk cassette 2 upper limit sensor
DPED2	Desk cassette 2 paper sensor
DPFD3	Desk paper transport sensor 3
DCSS14	Desk cassette 1 paper rear edge sensor 4
DCSS13	Desk cassette 1 paper rear edge sensor 3
DCSS12	Desk cassette 1 paper rear edge sensor 2
DCSS11	Desk cassette 1 paper rear edge sensor 1
DLUD1	Desk cassette 1 upper limit sensor
DPED1	Desk cassette 1 paper sensor
DPFD2	Desk paper transport sensor 2
MCSS4	MP tray size detection 4
MCSS3	MP tray size detection 3
MCSS2	MP tray size detection 2
MCSS1	MP tray size detection 1
MCSPD	MP tray remaining quantity detection
MCLUD	MP tray upper limit detection
MCPED	MP tray paper empty detection
DPFD1	MP tray transport detection

SIMULATION 4-2

DESK SENSOR CHECK.

DDRS	DPFD1	DPFD2	DPFD3
MCLUD	DLUD1	DLUD2	MCSPD
DSPD1	DSPD2	MCPED	DPED1
DPED2	MCSS1	MCSS2	MCSS3
MCSS4	DCSS11	DCSS12	DCSS13
DCSS14		DCSS21	DCSS22
DCSS23	DCSS24		

<LCC>

TDRS	Tandem side door sensor
TTSD	Tandem tray sensor
TLUD2	Tandem tray 2 upper limit sensor
TLUD1	Tandem tray 1 upper limit sensor
TSPD2	Tandem tray 2 remaining quantity sensor
TSPD1	Tandem tray 1 remaining quantity sensor
TPED2	Tandem tray 2 paper sensor
TPED1	Tandem tray 1 paper sensors
TPFD3	Tandem paper transport sensor 3
TPFD2	Tandem paper transport sensor 2
MCSS4	MP tray size detection 4
MCSS3	MP tray size detection 3
MCSS2	MP tray size detection 23
MCSS1	MP tray size detection 1
MCSPD	MP tray remaining quantity detection
MCLUD	MP tray upper limit detection
MCPED	MP tray paper empty detection
TPFD1	MP tray transport detection

SIMULATION 4-2

LCC SENSOR CHECK.

TDRS	TTSD	TPFD1	TPFD2
TPFD3	MCLUD	TLUD1	TLUD2
MCSPD	TSPD1	TSPD2	MCPED
TPED1	TPED2	MCSS1	MCSS2
MCSS3	MCSS4		

4-3

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the loads in the paper feed section (desk paper feed/large capacity tray) and the related circuit.
Section	Paper feed
Item	Operation

Operation/Procedure

1. Select the number corresponding to the target of operation check with 10-key.
2. Press [START] key.
The load selected in procedure 1 is operated.
Press [CUSTOM SETTINGS] key to stop the operation of the load.

<Desk>

1	DLUM2	Desk lift-up motor 2
2	DLUM1	Desk lift-up motor 1
3	MCLUM	Desk multi lift-up motor
4	DPFCL	Desk paper transport clutch
5	DPCL2	Desk paper feed clutch 2
6	DPCL1	Desk paper feed clutch 1
7	MCPCL	Desk multi paper feed clutch
8	DMM	Desk transport motor

<LCC>

1	TLUM2	LCC lift-up motor 2
2	TLUM1	LCC lift-up motor 1
3	MCLUM	LCC multi lift-up motor
4	TPFCL	LCC transport clutch
5	TPCL2	LCC paper feed clutch 2
6	TPCL1	LCC paper feed clutch 1
7	MCPCL	LCC multi paper feed clutch
8	TMM	LCC transport motor

SIMULATION 4-3

LCC LOAD TEST. SELECT 1- , AND PRESS START.
1.

2

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.

SIMULATION 4-3

LCC LOAD TEST. EXECUTING...
1.

2

5

5-1

Purpose	Operation test/Check
Function (Purpose)	Used to check the operation of the display, LCD in the operation panel, and control circuit.
Section	Operation (Display/Operation key)
Item	Operation

Operation/Procedure

The LCD is changed as shown below. (The contrast changes every 2sec from the current level to MAX → MIN → the current level. During this period, each LED is lighted.

SIMULATION 5-1

After 6.0sec

Press [CUSTOM SETTINGS] key, and the operation is stopped.

SIMULATION 5-1

5-2

Purpose	Operation test/Check
Function (Purpose)	Used to check the operation of the heater lamp and the control circuit.
Section	Fixing (Fusing)
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the target of operation check with 10-key.
- 2) Press [START] key.
The load selected in procedure 1 performs ON/OFF operation.
Press [CUSTOM SETTINGS] key to stop the operation of the load.
The ON/OFF operation of the selected heater lamp is repeated every 500ms five times.

1	HL1 (LOWER)	Heater lamp 1 (Lower)
2	HL2 (UPPER)	Heater lamp 2 (Upper)

SIMULATION 5-2
HEATER LAMP TEST. SELECT 1-2, AND PRESS START.
1.HL1 (LOWER)
2.HL2 (UPPER)

2

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.
The operation is repeated the specified number of times before stopping.

SIMULATION 5-2
HEATER LAMP TEST. EXECUTING...
1.HL1 (LOWER)
2.HL2 (UPPER)

2

5-3

Purpose	Operation test/Check
Function (Purpose)	Used to check the operation of the scanner lamp and the control circuit.
Section	Optical (Image scanning)
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the target of operation check with 10-key.
- 2) Press [START] key.
The load selected in procedure 1 turns ON for 10sec.
Press [CUSTOM SETTINGS] key to stop the operation.
The copy lamp or CIS is turned on for 10sec and turned off.

NOTE: CIS: only when the DSPF is installed.

SIMULATION 5-3
COPY LAMP TEST. SELECT 1-2, AND PRESS START.
1.COPY LAMP
2.CIS

1

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped after 10sec.

SIMULATION 5-3
COPY LAMP TEST. EXECUTING...
1.COPY LAMP
2.CIS

1

6

6-1

Purpose	Operation test/Check
Function (Purpose)	Used to check the operation of the paper transport system loads and the control circuit.
Section	Paper transport (Discharge/Switchback/Transport)
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the target of operation check with 10-key.
- 2) Press [START] key.
The load selected in procedure 1 operates.
Press [CUSTOM SETTINGS] key to stop the operation.

1	MSWPR	MSW power relay
2	HLPR	Heater power relay
3	DCPR	DC power relay
4	MM	Main motor
5	DM	Drum motor
6	POM_FW	Paper exit motor forward rotation
7	POM_RV	Paper exit motor reverse rotation
8	CPFC	Paper feed clutch
9	RRC	Resist roller clutch
10	TRC	Transport roller clutch
11	FGS_FIN	Finisher gate solenoid
12	LUM	Tray 1 lift-up motor
13	TRC_DSK	Desk clutch sync signal
14	PSPS	Separation pawl solenoid
15*1	MCM	MP drive motor control signal
16*1	MCPCL	MP tray paper feed clutch signal
17*1	MCFL	MP tray transport clutch signal
18*1	MCLUM	MP tray lift-up motor signal
19*2	MPFS	Manual paper feed solenoid signal
20*2	MPFC	Manual paper feed clutch signal
21*2	MSS	Manual paper feed gate solenoid

*1: Displayed when OPTION of multi-purpose only.

*2: Displayed when manual feed OPTION is added.

SIMULATION 6-1
FEED OUTPUT CHECK. SELECT 1-22, AND PRESS START.
1.MSWPR 2.HLPR 3.DCPR 4.MM 5.DM 6.DSB_FW
7.DSB_RV 8.CPFC 9.RRC 10.TR 11.FGS_FIN
12.LUM 13.TRD_DSK 14.PSPS
15.MCM 16.MCPCL 17.MCFL 18.MCLUM
19.MPFS 20.MPFC 21.MSS 22.MSWS

2

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped immediately or after repeating the operation several times.

SIMULATION 6-1
FEED OUTPUT CHECK. EXECUTING...
1.MSWPR 2.HLPR 3.DCPR 4.MM 5.DM 6.DSB_FW
7.DSB_RV 8.CPFC 9.RRC 10.TR 11.FGS_FIN
12.LUM 13.TRD_DSK 14.PSPS
15.MCM 16.MCPCL 17.MCFL 18.MCLUM
19.MPFS 20.MPFC 21.MSS 22.MSWS

2

6-2

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of each fan motor and its control circuit.
Section	Other
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the target of operation check with 10-key.
- 2) Press [START] key.
The load selected in procedure 1 operates.
Press [CUSTOM SETTINGS] key to stop the operation.

1	Fan motor high speed
2	Fan motor low speed
3	Cooling fan motor (Controller/HDD)

SIMULATION 6-2

FAN MOTOR CHECK. SELECT 1-3, AND PRESS START.

- 1.FMHi
- 2.FMLo
- 3.CFM-ICU/HDD

2

Press [START] key, and the operation is started.

Press [CUSTOM SETTINGS] key, and the operation is stopped.

SIMULATION 6-2

FAN MOTOR CHECK..

- 2.FMLo

2

7

7-1

Purpose	Setting
Function (Purpose)	Used to set the operating conditions of aging.
Section	
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the operating condition of aging with 10-key.
The combined mode of 0 - 6 mode and 10, 20, or 30 mode can be set.
In that case, the number corresponding to one of 0 - 6 mode and the number corresponding to one of 10, 10, and 30 mode are added and the sum number is entered.
- 2) Press [START] key.
The condition selected in procedure 1) is set.
The setting of this simulation is kept valid until the power is turned off.

0	NO MISS FEED DETECTION	No jam detection
1	AGING	Aging mode
2	AGING/NO MISS FEED DETECTION.	No jam detection, aging mode
3	AGING/NO MISS FEED DETECTION/NO WARM UP/NO TEMPERATURE CONTROL.	No jam detection/ no warm-up/ no fusing temperature control, aging mode
4	NO WARM UP.	No warm-up
5	AGING/INTERVAL.	Intermittent aging mode
6	AGING/INTERVAL/NO MISS FEED DETECTION.	No jam detection intermittent aging mode
+10	NO PROCESS UNIT CHECK.	Above +10: No process unit (including the developing unit) detection
+20	NO SHADING.	Above +20: No shading
+30	NO PROCESS UNIT CHECK/NO SHADING.	Above +30: No process unit detection /no shading

SIMULATION 7-1

AGING TEST SETTING. SELECT 0-36, AND PRESS START.

- 0.NO MISS FEED DETECTION
- 1.AGING
- 2.AGING/NO MISS FEED DETECTION.
- 3.AGING/NO MISS FEED DETECTION/NO WARM UP/NO TEMPERATURE CONTROL.
- 4.NO WARM UP.
- 5.AGING/INTERVAL.
- 6.AGING/INTERVAL/NO MISS FEED DETECTION.
- +10:NO PROCESS UNIT CHECK.
- +20:NO SHADING.
- +30:NO PROCESS UNIT CHECK/NO SHADING.

2

Press [START] key to start registration and operation.

The operation mode is kept until the power is turned off or setting is made again.

7-6

Purpose	Setting
Function (Purpose)	Used to set the intermittent aging cycle.
Section	
Item	Operation

Operation/Procedure

- 1) Enter the intermittent aging cycle (unit: sec) with 10-key.
- 2) Press [START] key.
The time entered in procedure 1) is set.
* Set range of interval time: 1 - 999 (sec)
Set the intermittent aging mode cycle of 7-1 with 10-key. (Unit: sec)

SIMULATION 7-6INTERVAL AGING CYCLE SETUP. INPUT TIME AND PRESS START.
(1-999, UNIT: sec)

10

7-8


Purpose	Setting
Function (Purpose)	Used to set the warm-up time display YES/NO.
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the warm-up time display YES/NO.
- 2) Press [START] key, and the number selected in procedure 1) is set.

* The setting of this simulation is kept valid until the power is turned off.

The warm-up time is displayed in the unit of second.



8

8-1

Purpose	Adjustment/Operation test/Check
Function (Purpose)	Used to check and adjust the operations of the developing voltage of each color and the control circuit.
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)


Operation/Procedure

- 1) Enter the number corresponding to the adjustment item with 10-key.
 - 2) Press [START] key.
 - 3) Enter the adjustment value with 10-key.
 - 4) Press [START] key.
- (The set value is stored, and the output corresponding to the set value is outputted for 30sec.)

Press [CUSTOM SETTINGS] key to stop the operation.

(The developing bias output voltage adjustment and output check can be made in each print mode.)

	Item		Set range	Default
1	AUTO	Auto mode	0 - 745	485
2	CHARACTER	Text mode		
3	MIX	Text/Photo mode		
4	PHOTO	Photo mode		
5	PRINTER	Printer mode		
6	FAX	FAX mode		
7	PLUS	Reverse developing bias voltage	0 - 255	150



8-2

Purpose	Adjustment/Operation test/Check
Function (Purpose)	Used to check and adjust the operation of the main charger grid voltage in each printer mode and the control circuit.
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)

Operation/Procedure


- 1) Enter the number corresponding to the adjustment item with 10-key.
- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.
- 4) Press [START] key.

(The set value is stored, and the output corresponding to the set value is outputted for 30sec.)

Press [CUSTOM SETTINGS] key to stop the operation.

(The main charger grid output voltage adjustment and output check can be made in each print mode.)

	Item		Set range	Default
1	AUTO	Auto mode	200 - 900	645
2	CHARACTER	Text mode		
3	MIX	Text/Photo mode		
4	PHOTO	Photo mode		
5	PRINTER	Printer mode		
6	FAX	FAX mode		



8-6

Purpose	Adjustment/Operation test/Check				
Function (Purpose)	Used to check and adjust the operation of the transfer voltage and the control circuit.				
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)/Transfer				


Operation/Procedure

- 1) Enter the number corresponding to the adjustment item with 10-key.
- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.
- 4) Press [START] key.
(The set value is stored, and the voltage corresponding to the set value is outputted for 30sec.)

Press [CUSTOM SETTINGS] key to stop the operation.

(The transfer output voltage adjustment and output check can be made in each print mode.)

Item			Set range	Default	
				AR-M355N	AR-M455N
1	FRONT	Long side print mode	0 - 620	220	267
2	BACK	Back side print mode		267	310



8-17

Purpose	Operation test/Check
Function (Purpose)	Used to check and adjust the operation of the transfer voltage and the related circuit. (Transfer belt cleaning mode)
Section	Image process (Photoconductor/Developing/Transfer/Cleaning)
Item	Operation

Operation/Procedure


- 1) Enter the number corresponding to the adjustment item with 10-key.
- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.
- 4) Press [START] key.

(The set value is stored, and the voltage corresponding to the set value is outputted for 30sec.)

Press [CUSTOM SETTINGS] key to stop the operation.

(The transfer output voltage adjustment and output check can be made in the transfer belt cleaning mode.)

Item			Set range	Default	
				AR-M355N	AR-M455N
1	SHF FRONT	AC component	0 - 240	120	160
2	SHV BACK	AC component	0 - 240	120	160
3	THV-	DC component	0 - 1250	780	780



9


9-1

Purpose	Operation test/Check
Function (Purpose)	Used to check and adjust the operation of the load (clutch/solenoid) in the duplex section and the control circuit.
Section	Duplex
Item	Operation

Operation/Procedure

- 1) Select the number corresponding to the target of the operation check with 10-key.
 - 2) Press [START] key.
- The load selected in procedure 1) is operated.
Press [CUSTOM SETTINGS] key to stop the operation.

1	ADMEN1	ADU motor 1 control signal
2	ADMEN2	ADU motor 2 control signal
3	DGS	ADU gate solenoid




9-2

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the sensors and detectors in the duplex section and its control circuit.
Section	Duplex
Item	Operation

Operation/Procedure

The operating conditions of the sensors and detectors are displayed.
The active sensors and detectors are highlighted.

ADUSET	ADU installation detection
DSW_D	ADU cabinet open detection
AINPD	ADU paper entry detection
APOD	ADU paper exit detection
APPD1	ADU paper detection 1
APPD2	ADU paper detection 2



10

10-1

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the toner motor and the related circuit.
Section	Process (Developing)
Item	Operation

Operation/Procedure


- 1) Select the number corresponding to the target of the operation check with 10-key.
- 2) Press [START] key.

The load selected in procedure 1) is operated for 10sec.

Press [CUSTOM SETTINGS] key to stop the operation.

NOTE: Never execute this simulation with toner in the toner hopper.
If executed, excessive toner will enter the developing section, causing an overtone trouble. Be sure to remove the toner motor from the toner hopper before execution.

1	Toner motor rotation start
2	Cancel (The display returns to the main code entry menu.)



13


13-0

Purpose	Clear/Cancel (Trouble etc.)
Function (Purpose)	Used to cancel the self-diag "U1" trouble. (Only when FAX is installed.)
Section	FAX
Item	Trouble

Operation/Procedure

- 1) Select 1 (YES) with 10-key.
- 2) Press [START] key. (The trouble display is canceled.)

1	YES	After canceling U1 trouble, the machine returns to the main code entry standby mode.
2	NO	Without canceling U1 trouble, the machine returns to the main code entry standby mode.



14

14-0

Purpose	Clear/Cancel (Trouble etc.)
Function (Purpose)	Used to cancel excluding the self-diag U1/LCC/ U2/PF troubles.
Item	Trouble Error

Operation/Procedure

- 1) Select 1 (YES) with 10-key.
- 2) Press [START] key. (The trouble display is canceled.)

1	YES	After canceling the trouble other than U1, U2, PF, and LCC, the machine returns to the main code entry standby mode.
2	NO	Without canceling the trouble, the machine returns to the main code entry standby mode.

SIMULATION 14

TROUBLE CANCELLATION. (OTHERS)
 ARE YOU SURE?
 1. YES
 2. NO

1

15

15-0

Purpose	Clear/Cancel (Trouble etc.)
Function (Purpose)	Used to cancel the self-diag "U6-09, F3-12, 22" (large capacity paper feed tray, paper feed trays 1, 2) troubles.
Section	LCC
Item	Trouble

Operation/Procedure

- 1) Select 1 (YES) with 10-key.
- 2) Press [START] key. (The trouble display is canceled.)

1	YES	After canceling the LCC trouble, the machine returns to the main code entry standby mode.
2	NO	Without canceling the trouble, the machine returns to the main code entry standby mode.

SIMULATION 15

LCC TROUBLE CANCELLATION.
 ARE YOU SURE?
 1. YES
 2. NO

1

16

16-0

Purpose	Clear/Cancel (Trouble etc.)
Function (Purpose)	Used to cancel the self-diag U2 troubles.
Section	MFP control PWB, PCU PWB, scanner control PWB
Item	Trouble

Operation/Procedure

- 1) Select 1 (YES) with 10-key.
- 2) Press [START] key. (The trouble display is canceled.)

1	YES	After canceling the U2 trouble, the machine returns to the main code entry standby mode.
2	NO	Without canceling the trouble, the machine returns to the main code entry standby mode.

SIMULATION 16

U2 TROUBLE CANCELLATION.
 ARE YOU SURE?
 1. YES
 2. NO

1

17

17-0

Purpose	Clear/Cancel (Trouble etc.)
Function (Purpose)	Used to cancel the PF troubles (when the copy inhibit command from the host computer is received).
Section	Communication unit (TEL/LIU/MODEM etc.)
Item	Trouble Error

Operation/Procedure

- 1) Select 1 (YES) with 10-key.
- 2) Press [START] key. (The trouble display is canceled.)

1	YES	After canceling the PF trouble, the machine returns to the main code entry standby mode.
2	NO	Without canceling the trouble, the machine returns to the main code entry standby mode.

SIMULATION 17

PF TROUBLE CANCELLATION.
 ARE YOU SURE?
 1. YES
 2. NO

1

21

21-1

Purpose	Setting
Function (Purpose)	Used to set the maintenance cycle.
Item	Specifications Counter

Operation/Procedure

- 1) Enter the number corresponding to the maintenance timing display.
- 2) Press [START] key. The condition entered in procedure 1) is set.

Maintenance timing display		Set range
0	Default (Differs depending on the model.)	0 - 999
1 - 300	Maintenance display at 1K - 300K	
999	No maintenance display	

SIMULATION 21-1

MAINTENANCE CYCLE SETUP. INPUT VALUE 0-999, AND PRESS START.

0: DEFAULT
1-300: MAINTENANCE CYCLE (1K-300K)
999: FREE

0

22

22-1

Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)
Function (Purpose)	Used to check the print count value in each section and each operation mode. (Used to check the maintenance timing.)
Item	Counter

Operation/Procedure

Various print counter values are displayed.

TOTAL	Total counter
DRUM	Drum counter
TONER	Toner counter
DEVE	Developer counter
MAINTENANCE	Maintenance counter
TOTAL OUTPUT	Total output quantity
COPIES	Copy effective paper counter
PRINTER	Printer counter
FAX	FAX print counter
I-FAX OUTPUT	iFAX print counter
DOC FILING OUTPUT	Document filing print counter
RIGHT SIDE OUTPUT	Right paper exit counter
OTHERS	Other print counter (List print , etc.)

SIMULATION 22-1

COUNTER DATA DISPLAY.

TOTAL: ***** DRUM: ***** TONER: *****
DEVE: ***** MAINTENANCE: *****
TOTAL OUTPUT: ***** COPIES: *****
PRINTER: ***** FAX OUTPUT: *****
I-FAX OUTPUT: ***** DOC FILING OUTPUT: *****
RIGHT SIDE: ***** OTHERS: *****

22-2

Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)
Function (Purpose)	Used to check the total numbers of misfeed and troubles. (When the number of misfeed is considerably great, it is judged as necessary for repair. The misfeed rate is obtained by dividing this count value with the total counter value.)
Item	Trouble

Operation/Procedure

The paper jam/trouble counter value is displayed.

PAPER JAM	Number of paper jams
SPF JAM	Number of SPF jams
TROUBLE	Number of troubles

SIMULATION 22-2

JAM/TROUBLE COUNTER DATA DISPLAY.

PAPER JAM: ***** SPF JAM: *****
TROUBLE: *****

22-3

Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)
Function (Purpose)	Used to check misfeed positions and the misfeed count of each position. (If the misfeed count is considerably great, it may be judged as necessary to repair.)
Section	Sections other than SPF/DSPF section
Item	Trouble Misfeed

Operation/Procedure

The history of paper jams and misfeed is displayed.

The misfeed history is displayed sequentially from the latest one. The max. 100 items of misfeed history can be recorded. The data may be used to identify trouble position.

The latest 100 items of paper jam history are displayed. (Refer to the jam cause code table below.)

(Jam cause code)

Code	Description
NO_JAM_CAUSE	No jam. Also used to cancel a jam.
TRAY2	Tray 2 paper feed jam (MPFD not-reaching)
MPFDND1	MPFD not-reaching jam (Desk tray 1 feed paper)
MPFDND2	MPFD not-reaching jam (Desk tray 2 feed paper)
MPFDNTD	MPFD not-reaching jam (Tandem desk feed paper)
MPFDST2	MPFD remaining jam (Machine tray 3 feed paper)
MPFDSD1	MPFD remaining jam (Desk tray 1 feed paper)
MPFDSD2	MPFD remaining jam (Desk tray 2 feed paper)
MPFDSTD	MPFD remaining jam (Tandem desk feed paper)
PPD1NMF	PPD1 not-reaching jam (Manual feed tray paper)
TRAY1	Tray 1 feed paper jam (PPD1 not-reaching)
PPD1NT2	PPD1 not-reaching jam (Machine tray 2 feed paper)
PPD1ND1	PPD1 not-reaching jam (Desk tray 1 feed paper)
PPD1ND2	PPD1 not-reaching jam (Desk tray 2 feed paper)

Operation/Procedure

The trouble history is displayed.

The trouble history is displayed sequentially from the latest one.

The max. 100 items can be stored. (The oldest one is deleted sequentially. The trouble position can be identified by the data.)

TROUBLE HISTORY.

(10 lines, 80 digits = 800 characters)

Operation/Procedure

The ROM version of each section can be checked. When there is any problem in the software, use this simulation to check the ROM version of each section and revise the version if necessary.

```

SIMULATION 22-5
ROM VERSION DATA DISPLAY.
S/N:      0000000000
MFP:      1.00      (LANGUAGE:1.00)
PCU:      1.00      BOOT:      1.00
SCANNER:  1.00      FAX:      1.00
FINISHER: 1.00      NIC:      1.00
DESK:     1.00      MAIL BIN: 1.00
PUNCH UNIT: 1.00

```

Operation/Procedure

When installing or servicing this machine, execute this simulation to print and save various setting and adjustment data for next servicing. (For example, memory trouble, PWB replacement, etc.)

2) Press [START] key.

The various setting and adjustment data are printed out. (The print paper cannot be selected optionally.)

```
graph TD; 1[1] --> 0[0]; 0 --> 1;
```

SIMULATION 22-6
DATA PRINT MODE. SELECT SETTING, AND PRESS START.
0. TRAY SELECT :AUTO ONLY
1. PRINT START

Select 1 and press
[START] key.

Press [CUSTOMSETTING] key or
[START] key.

SIMULATION 22-6
DATA PRINT MODE. EXECUTING...
0. TRAY SELECT :1

Operation/Procedure
The key operator code is displayed.

KEY OPERATOR CODE DISPLAY.
CODE: *****

22-8	
Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)
Function (Purpose)	Used to check the number of use of the finisher, the SPF, and the scan (reading) unit.
Section	Optical (Image scanning) Finisher
Item	Counter

Operation/Procedure

The values of the finisher counter, the scanner (read), counter, and the SPF related counters are displayed.

SPF	Document feed quantity
SCAN	Number of scans
STAPLER	Number of stapling
PUNCH	Number of punching
STAMP	Number of SPF finish stamps

SIMULATION 22-8

```
ORG./STAPLE COUNTER DATA DISPLAY.
SPF: *****
SCAN: *****
STAPLER: *****      PUNCH: *****
STAMP: *****
```

22-9	
Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)
Function (Purpose)	Used to check the number of use (print quantity) of each paper feed section.
Section	Paper feed, ADU
Item	Counter

Operation/Procedure

The values of the paper feed related counters are displayed.

TRAY1	Use quantity of tray 1
TRAY2	Use quantity of tray 2 (Multi purpose tray)
TRAY3/LCC1	Use quantity of tray 3/LCC left tray (Common to Desk/LCC)
TRAY4/LCC2	Use quantity of tray 4/LCC right tray
BPT	Use quantity of manual feed tray
ADU	Use quantity of duplex paper feed

SIMULATION 22-9

```
PAPER FEED COUNTER DATA DISPLAY.
TRAY1:      *****      TRAY2:      *****
TRAY3/LCC1: *****      TRAY4/LCC2: *****
BPT:        *****      ADU:          *****
```

22-10	
Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)
Function (Purpose)	Used to check the system configuration (option, internal hardware).
Item	Specifications Options

Operation/Procedure

The system configuration is displayed. (The model names of the installed devices and options are displayed.)

MACHINE	AR-311S, AR-351S/AR-M355U, AR-451S/AR-M455U, AR-311FP, AR-351FP/AR-M351U, AR-451FP/AR-M451U, AR-311N, AR-351N/M355N/M351N, AR-451N/M455N/M451N
SPF	(Model code)
FINISHER	NONE/ (Model code)
MAIL BIN	NONE/ (Model code)
PUNCH	NONE/ (Model code)

DESK/LCC	NONE/ (Model code)
ADU	NONE/ (Model code)
SYSTEM MEMORY	Memory capacity (MB)
HDD	Hard disk capacity (MB)
ICU	Board type
NIC	NONE/ (Model code)
NSCN	NONE/ (Network scanner)
PS3	NONE/ (PS3 expansion kit)
FAX	NONE/ (Model code)
FAX MEMORY	FAX expansion memory capacity (MB)
HAND SET	NONE/ (Model code)
STAMP	Finisher stamp NONE/ (Model code)
PCU TYPE	PCU PWB type (JPN: Japan/ EX100: EX Japan 100V/ EX200: EX Japan 200V)

(Model code list)

Item	Display	Content
MACHINE	AR-311S	31-sheet S model
	AR-351S/AR-M355U	35-sheet S/U model
	AR-451S/AR-M455U	45-sheet S/U model
	AR-311FP	31-sheet FP model (Local printer standard provision model)
	AR-351FP/AR-M351U	35-sheet FP/U model (Local printer standard provision model)
	AR-451FP/AR-M451U	45-sheet FP/U model (Local printer standard provision model)
	AR-311N	31-sheet N model
	AR-351N/M355N/M351N	35-sheet N model
	AR-451N/M455N/M451N	45-sheet N model
SPF	----	Document feed unit not installed
	AR-EF4	Document feed unit (SPF) installed
	AR-EF3	Duplex document feed unit (DSPF) installed
FINISHER	----	After-work unit not installed
	AR-FN6	Built-in finisher installed
	AR-FN7	Console finisher installed
MAIL BIN	----	Mail bin not installed
	AR-MS1	Mail bin installed
Punch unit	----	Punch unit not installed
	AR-PN1A	Punch unit 2 holes
	AR-PN1B	Punch unit 3 holes
	AR-PN1C	Punch unit 4 holes
	AR-PN1D	Punch unit 4 holes wide hole
ADU	----	Duplex module not installed
	AR-DU3	Duplex module installed
	AR-DU4	Duplex module + manual feed unit installed
DESK	----	Paper feed desk not installed
	AR-MU2	Multi-purpose tray installed
	AR-D27	Paper feed desk installed
	AR-D28	Tandem desk installed
ICU	TYPE-U/S	For U/S model board
	TYPE-U/FP	For U/FP model board
	TYPE-N	For N model board
MEMORY	0MB	No expansion memory
	***MB	Expansion memory ***MB
HD	0MB	Hard disk not installed
	****MB	Hard disk installed (AR-HD3)
NIC	----	NIC not installed
	AR-NC7J	NIC installed

22-19

Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)
Function (Purpose)	Used to check the values of the counters related to the scan mode and the internet FAX mode.
Section	Scanner
Item	Counter

Operation/Procedure

The values of the counters related to the scan mode and the internet FAX mode are displayed.

NETWORK SCANNER ORIGINAL COUNTER	Document scan quantity (OC, SPF total quantity)
MAIL COUNTER	Number of times of mail send
FTP COUNTER	Number of times of FTP send
INTERNET-FAX ORIGINAL COUNTER	Document scan quantity (OC, SPF, total quantity)
INTERNET-FAX SEND	Number of times of internet FAX send
INTERNET-FAX RECEIVE	Number of times of internet FAX receive
INTERNET-FAX OUTPUT	Internet FAX print quantity
SCAN TO HDD	Scan to HDD record quantity
INTERNET-FAX SEND IMAGES	IFAX send quantity counter
MAIL SEND IMAGES	MAIL send quantity counter
FTP SEND IMAGES	FTP send quantity counter

SIMULATION 22-19

NETWORK SCANNER AND INTERNET-FAX COUNTER DISPLAY.

```

NETWORK SCANNER ORIGINAL COUNTER: *****
MAIL COUNTER: *****
FTP COUNTER: *****
INTERNET-FAX ORIGINAL COUNTER: *****
INTERNET-FAX SEND: *****
INTERNET-FAX RECEIVE: *****
INTERNET-FAX OUTPUT: *****
SCAN TO HDD : *****
INTERNET-FAX SEND IMAGES: *****
MAIL SEND IMAGES: *****
FTP SEND IMAGES: *****

```

23

23-2

Purpose	Adjustment/Setup/Operation data output/Check (Display/Print)
Function (Purpose)	Used to check the trouble history of paper jam and misfeed. (If the number of misfeed and troubles is considerably great, it may be judged as necessary to repair.)
Item	Trouble

Operation/Procedure

- 1) Select "1. PRINT START."
- 2) Press [START] key.

The trouble history of paper jam and misfeed is printed.

This data can be cleared by SIM 24-1.

SIMULATION 23-2

JAM/TROUBLE DATA PRINT MODE. SELECT SETTING, AND PRESS START.

- ```

0. TRAY SELECT : AUTO ONLY
1. PRINT START

```

1

Press [START] key.

Press [CUSTOM SETTINGS] key or [START] key.

SIMULATION 23-2

JAM/TROUBLE DATA PRINT MODE.. EXECUTING...

- ```

0. TRAY SELECT : 1

```

0

23-80

Purpose	Operation test/Check
Function (Purpose)	Used to check the operations of the sensors and detectors in the paper feed and transport section.
Section	Paper feed, paper transport
Item	Operation

Operation/Procedure

- 1) Select "2. PRINT PATTERN."
- 2) Press [START] key.
- 3) Select "1" (Paper transport time data) with 10-key.
- 4) Press [START] key.

The list of the ON time of the sensors and the detectors of the paper transport section is printed. When a paper jam or misfeed is generated, the ON time of each sensor and detector is checked to check if the operation of the sensor and the detector, paper feed, and transport are normal or not.

0	TRAY SELECT AUTO ONLY	Auto only (No selection allowed)
1	PRINT START	Print execution Print of the set data is executed.
2	PRINT PATTERN	Print pattern 1. Paper transport time data

SIMULATION 23-80

DATA PRINT MODE. SELECT SETTING, AND PRESS START.

- ```

0. TRAY SELECT : AUTO ONLY
1. PRINT START
2. PRINT PATTERN: 1

```

1

Select 1 and press [START] key.

Press [CUSTOM SETTING] key or [START] key.

SIMULATION 23-80

DATA PRINT MODE. EXECUTING...

- ```

0. TRAY SELECT : 1

```

0

Select 2 and press [START] key.

Press [CUSTOM SETTING] key or [START] key.

SIMULATION 23-80

DATA PRINT MODE. INPUT VALUE, AND PRESS START.

- ```

(PRINT PATTERN)
INPUT 1.

```

1

## 24-1

|                           |                                                                                                                                                                   |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                                                                                                                        |
| <b>Function (Purpose)</b> | Used to clear the misfeed counter, the misfeed history, the trouble counter, and the trouble history. (The counters are cleared after completion of maintenance.) |
| <b>Item</b>               | Counter                                                                                                                                                           |

**Operation/Procedure**

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

|   |           |                      |
|---|-----------|----------------------|
| 1 | PAPER JAM | Number of paper jams |
| 2 | SPF JAM   | Number of SPF jams   |
| 3 | TROUBLE   | Number of troubles   |

SIMULATION 24-1  
JAM/ TROUBLE COUNTER DATA CLEAR. SELECT1-3, AND PRESS START.

1. PAPER JAM
2. SPF JAM
3. TROUBLE

Press [START] key. Press [CUSTOM SETTINGS] key or [START] key.

SIMULATION 24-1  
\* COUNTER DATA CLEAR.  
ARE YOU SURE?

1. YES
2. NO

\* = PAPER JAM, SPF JAM, TROUBLE

## 24-2

|                           |                                                                                    |
|---------------------------|------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                                         |
| <b>Function (Purpose)</b> | Used to clear the number of use (the number of prints) of each paper feed section. |
| <b>Section</b>            | Paper feed                                                                         |
| <b>Item</b>               | Counter                                                                            |

**Operation/Procedure**

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

|   |            |                                    |
|---|------------|------------------------------------|
| 1 | TRAY1      | Tray 1 use quantity                |
| 2 | TRAY2      | Tray 2 use quantity                |
| 3 | TRAY3/LCC1 | Tray 3/LCC left tray use quantity  |
| 4 | TRAY4/LCC2 | Tray 4/LCC right tray use quantity |
| 5 | BPT        | Manual feed tray use quantity      |
| 6 | ADU        | Duplex feed quantity               |

SIMULATION 24-2  
PAPER FEED COUNTER DATA CLEAR. SELECT1-6, AND PRESS START.

1. TRAY1
2. TRAY2
3. TRAY3/LCC1
4. TRAY4/LCC2
5. BPT
6. ADU

Press [START] key. Press [CUSTOM SETTINGS] key or [START] key.

SIMULATION 24-2  
\* COUNTER DATA CLEAR.  
ARE YOU SURE?

1. YES
2. NO

\* = TRAY1, TRAY2, TRAY3/LCC1, TRAY4/LCC2, BPT, ADU

## 24-3

|                           |                                                                                    |
|---------------------------|------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                                         |
| <b>Function (Purpose)</b> | Used to clear the number of use of the finisher, SPF, and the scan (reading) unit. |
| <b>Section</b>            |                                                                                    |
| <b>Item</b>               | Counter                                                                            |

**Operation/Procedure**

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

|   |         |                                     |
|---|---------|-------------------------------------|
| 1 | SPF     | SPF paper pass quantity             |
| 2 | SCAN    | Number of times of document scan    |
| 3 | STAPLER | Number of times of stapling         |
| 4 | PUNCH   | Number of times of punching         |
| 5 | STAMP   | Number of times of SPF finish stamp |

SIMULATION 24-3  
ORG./STAPLE COUNTER DATA CLEAR. SELECT 1-5, AND PRESS START.

1. SPF
2. SCAN
3. STAPLER
4. PUNCH
5. STAMP

Press [START] key. Press [CUSTOM SETTINGS] key or [START] key.

SIMULATION 24-3  
\* COUNTER DATA CLEAR.  
ARE YOU SURE?

1. YES
2. NO


\* = SPF, SCAN, STAPLER, PUNCH, STAMP

|                           |                                        |
|---------------------------|----------------------------------------|
| 24-4                      |                                        |
| <b>Purpose</b>            | Data clear                             |
| <b>Function (Purpose)</b> | Used to reset the maintenance counter. |
| <b>Item</b>               | Counter                                |

#### Operation/Procedure

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

|   |             |                     |
|---|-------------|---------------------|
| 1 | MAINTENANCE | Maintenance counter |
|---|-------------|---------------------|




|                           |                                 |
|---------------------------|---------------------------------|
| 24-6                      |                                 |
| <b>Purpose</b>            | Data clear                      |
| <b>Function (Purpose)</b> | Used to reset the copy counter. |
| <b>Item</b>               | Counter Copy                    |

#### Operation/Procedure

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

|   |      |                              |
|---|------|------------------------------|
| 1 | COPY | Copy effective paper counter |
|---|------|------------------------------|




|                           |                                                                                                          |
|---------------------------|----------------------------------------------------------------------------------------------------------|
| 24-5                      |                                                                                                          |
| <b>Purpose</b>            | Data clear                                                                                               |
| <b>Function (Purpose)</b> | Used to reset the developer counter. (The developer counter of the DV unit which is installed is reset.) |
| <b>Section</b>            | Image process (Photoconductor/Developing/Transfer/Cleaning)                                              |
| <b>Item</b>               | Counter Developer                                                                                        |

#### Operation/Procedure

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

|   |              |                     |
|---|--------------|---------------------|
| 1 | DV CARTRIDGE | Developer cartridge |
|---|--------------|---------------------|



|                           |                                                                                              |
|---------------------------|----------------------------------------------------------------------------------------------|
| 24-7                      |                                                                                              |
| <b>Purpose</b>            | Data clear                                                                                   |
| <b>Function (Purpose)</b> | Used to clear the OPC drum counter. (Perform this simulation when the OPC drum is replaced.) |
| <b>Section</b>            | Image process (Photoconductor/Developing/Transfer/Cleaning)                                  |
| <b>Item</b>               | Counter Photo conductor                                                                      |

#### Operation/Procedure

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

After replacing the OPC drum, be sure to clear the OPC drum counter.

|   |      |                  |
|---|------|------------------|
| 1 | DRUM | OPC drum counter |
|---|------|------------------|

|                                                                                         |   |
|-----------------------------------------------------------------------------------------|---|
| <u>SIMULATION 24-7</u><br>DRUM COUNTER DATA CLEAR. SELECT1, AND PRESS START.<br>1. DRUM | 1 |
|-----------------------------------------------------------------------------------------|---|

Press [START] key. Press [CUSTOM SETTINGS] key or [START] key.

|                                                                                     |   |
|-------------------------------------------------------------------------------------|---|
| <u>SIMULATION 24-7</u><br>* COUNTER DATA CLEAR.<br>ARE YOU SURE?<br>1. YES<br>2. NO | 1 |
|-------------------------------------------------------------------------------------|---|

\* = DRUM

24-9

|                           |                                                                                  |
|---------------------------|----------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                                       |
| <b>Function (Purpose)</b> | Used clear the printer mode print counter and the self print mode print counter. |
| <b>Section</b>            | Printer                                                                          |
| <b>Item</b>               | Counter                                                                          |

#### Operation/Procedure

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

After replacing the OPC drum, be sure to clear the OPC drum counter.

|   |         |                                                 |
|---|---------|-------------------------------------------------|
| 1 | PRINTER | Printer counter (Print mode)                    |
| 2 | OTHERS  | Other effective paper counter (Self print mode) |

|                                                                                                                     |   |
|---------------------------------------------------------------------------------------------------------------------|---|
| <u>SIMULATION 24-9</u><br>PRINTER/OTHERS COUNTER DATA CLEAR. SELECT1-2, AND PRESS START.<br>1. PRINTER<br>2. OTHERS | 1 |
|---------------------------------------------------------------------------------------------------------------------|---|

Press [START] key. Press [CUSTOM SETTINGS] key or [START] key.

|                                                                                     |   |
|-------------------------------------------------------------------------------------|---|
| <u>SIMULATION 24-9</u><br>* COUNTER DATA CLEAR.<br>ARE YOU SURE?<br>1. YES<br>2. NO | 1 |
|-------------------------------------------------------------------------------------|---|

\* = PRINTER, OTHERS

24-10

|                           |                                                             |
|---------------------------|-------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                  |
| <b>Function (Purpose)</b> | Used to clear the FAX counter. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                         |
| <b>Item</b>               | Counter                                                     |

#### Operation/Procedure

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

|   |              |                                |
|---|--------------|--------------------------------|
| 1 | FAX SEND     | Number of times of FAX send    |
| 2 | FAX RECEIVE  | Number of times of FAX receive |
| 3 | FAX OUTPUT   | FAX print quantity             |
| 4 | SEND IMAGES  | Send quantity                  |
| 5 | SEND TIME    | Send time                      |
| 6 | RECEIVE TIME | Receive time                   |

|                                                                                                                                                                                        |   |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|
| <u>SIMULATION 24-10</u><br>FAX COUNTER DATA CLEAR. SELECT1-6, AND PRESS START.<br>1. FAX SEND<br>2. FAX RECEIVED<br>3. FAX OUTPUT<br>4. SEND IMAGES<br>5. SEND TIME<br>6. RECEIVE TIME | 1 |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---|

Press [START] key. Press [CUSTOM SETTINGS] key or [START] key.

|                                                                                      |   |
|--------------------------------------------------------------------------------------|---|
| <u>SIMULATION 24-10</u><br>* COUNTER DATA CLEAR.<br>ARE YOU SURE?<br>1. YES<br>2. NO | 1 |
|--------------------------------------------------------------------------------------|---|

\* = FAX SEND, FAX RECEIVED, FAX OUTPUT, SEND IMAGES, SEND TIME, RECEIVE TIME

24-11

|                           |                                                                                                                                           |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                                                                                                |
| <b>Function (Purpose)</b> | Used to reset the OPC drum rotation time, and the DV unit rotation time counter. The developer counter in the DV unit installed is reset. |
| <b>Section</b>            | Image process (Photoconductor/Developing/Transfer/Cleaning)                                                                               |
| <b>Item</b>               | Counter Developer                                                                                                                         |

#### Operation/Procedure

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

|   |               |                        |
|---|---------------|------------------------|
| 1 | DRUM ROTATION | OPC drum rotation time |
| 2 | DV ROTATION   | DV unit rotation time  |

SIMULATION 24-11  
 TIMER DATA CLEAR. SELECT1-2, AND PRESS START.  
 1. DRUM ROTATION  
 2. DV ROTATION

Press [START] key. Press [CUSTOM SETTINGS] key or [START] key.

SIMULATION 24-11  
 \* TIMER DATA CLEAR.  
 ARE YOU SURE?  
 1. YES  
 2. NO

\* = DRUM ROTATION, DV ROTATION

24-15

|                           |                                                                                |
|---------------------------|--------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                                     |
| <b>Function (Purpose)</b> | Used to clear the counters related to the scan mode and the internet FAX mode. |
| <b>Item</b>               | Counter                                                                        |

#### Operation/Procedure

- 1) Select the counter to be cleared with 10-key.
- 2) Press [START] key.  
The confirmation to clear is opened.
- 3) Select Yes/NO of counter clear with 10-key.  
YES: Clear  
NO: Not clear
- 4) Press [START] key.

|    |                                  |                                                                    |
|----|----------------------------------|--------------------------------------------------------------------|
| 1  | NETWORK SCANNER ORIGINAL COUNTER | Document scan quantity counter in the network scanner mode         |
| 2  | MAIL COUNTER                     | Number of times of mail send                                       |
| 3  | FTP COUNTER                      | Number of times of FTP send                                        |
| 4  | INTERNET-FAX ORIGINAL COUNTER    | Internet FAX document scan quantity (Total quantity of OC and SPF) |
| 5  | INTERNET-FAX SEND                | Number of times of internet FAX send                               |
| 6  | INTERNET-FAX RECEIVE             | Number of times of internet FAX receive                            |
| 7  | INTERNET-FAX OUTPUT              | Internet FAX print quantity                                        |
| 8  | SCAN TO HDD                      | SCAN TO HDD record quantity                                        |
| 9  | INTERNET-FAX SEND IMAGES         | IFAX send quantity counter                                         |
| 10 | MAIL SEND IMAGES                 | MAIL send quantity counter                                         |
| 11 | FTP SEND IMAGES                  | FTP send quantity counter                                          |

SIMULATION 24-15  
 NETWORK SCANNER AND INTERNET-FAX COUNTER CLEAR. SELECT1-3, AND PRESS START.  
 1. NETWORK SCANNER ORIGINAL COUNTER  
 2. MAIL COUNTER  
 3. FTP COUNTER  
 4. INTERNET-FAX ORIGINAL COUNTER: \*\*\*\*\*  
 5. INTERNET-FAX SEND: \*\*\*\*\*  
 6. INTERNET-FAX RECEIVE: \*\*\*\*\*  
 7. INTERNET-FAX OUTPUT: \*\*\*\*\*  
 8. SCAN TO HDD: \*\*\*\*\*  
 9. INTERNET-FAX SEND IMAGES: \*\*\*\*\*  
 10. MAIL SEND IMAGES: \*\*\*\*\*  
 11. FTP SEND IMAGES: \*\*\*\*\*

Press [START] key. Press [CUSTOM SETTINGS] key or [START] key.

SIMULATION 24-15  
 \* COUNTER DATA CLEAR.  
 ARE YOU SURE?  
 1. YES  
 2. NO

\* = NETWORK SCANNER ORIGINAL, MAIL, FTP, INTERNET-FAX ORIGINAL COUNTER, INTERNET-FAX SEND, INTERNET-FAX RECEIVE, INTERNET-FAX OUTPUT, SCAN TO HDD, INTERNET-FAX SEND IMAGES, MAIL SEND IMAGES, FTP SEND IMAGES

25

25-1

|                           |                                                                                                                                                                                     |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                                |
| <b>Function (Purpose)</b> | Used to check the operations of the developing section (toner concentration, humidity and toner concentration sensor, humidity sensor, temperature sensor output can be monitored.) |
| <b>Section</b>            | Process (Developing section)                                                                                                                                                        |
| <b>Item</b>               | Operation                                                                                                                                                                           |

#### Operation/Procedure

Press [START] key.

The developing motor and the OPC drum motor rotate, and the toner concentration detection level and the humidity sensor detection level and the temperature sensor detection level are displayed.

SIMULATION 25-1  
 TONER SENSOR OUTPUT MONITOR. PRESS START.  
 HUMIDITY AREA : 70.0 - 72.5  
 TEMPERATURE AREA: 70.0 - 72.5  
 DEVE REFERENCE : 128

Press [START] key. Press [CUSTOM SETTINGS] key, and the operation is stopped immediately or after 3 min.

SIMULATION 25-1  
 DV MONITOR. EXECUTING...  
 HUMIDITY AREA : 70.0 - 72.5  
 TEMPERATURE AREA: 70.0 - 72.5  
 DEVE REFERENCE : 128

25-2

|                           |                                                                                   |
|---------------------------|-----------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                           |
| <b>Function (Purpose)</b> | Used to make the initial setting of toner concentration when replacing developer. |
| <b>Section</b>            | Image process (Photoconductor/Developing/Transfer/Cleaning)                       |
| <b>Item</b>               |                                                                                   |

**Operation/Procedure**

- 1) Press [START] key.

The developing motor rotates for 2 min and the toner concentrations sensor makes sampling of toner concentration 16 times, and the detection level is displayed.

After the developing motor stops, the average value of toner concentration sampling is set as the reference toner concentration level.

NOTE: When the above operation is interrupted on the way, the reference toner concentration level is not set. Also when error code of EE-EL or EE-EU is displayed, the reference toner concentration level is not set normally.

(Default: 114)

- 2) The humidity near the developing tank at the developing adjustment is registered.

SIMULATION 25-2

AUTOMATIC DV ADJUSTMENT. PRESS START.  
 HUMIDITY AREA : 70.0 - 72.5  
 TEMPERATURE AREA: 70.0 - 72.5  
 DEVE REFERENCE : 114

Press [START] key.

Press [CUSTOM SETTINGS] key, and the operation is stopped immediately or after 3 min.

SIMULATION 25-2

AUTOMATIC DV ADJUSTMENT. EXECUTING...  
 HUMIDITY AREA : 70.0 - 72.5  
 TEMPERATURE AREA: 70.0 - 72.5  
 DEVE REFERENCE : 114

26-5

|                           |                                                                              |
|---------------------------|------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                      |
| <b>Function (Purpose)</b> | Used to set the count mode of the total counter and the maintenance counter. |
| <b>Item</b>               | Specifications Counter                                                       |

**Operation/Procedure**

- 1) Select the number corresponding to the counter to be set with 10-key.
- 2) Press [START] key.
- 3) Select the count mode with 10-key.
- 4) Press [START] key.

Set the count-up (1 or 2) for A3/WLT paper.

(Select the target counter.)

|   |                            |                                       |
|---|----------------------------|---------------------------------------|
| 1 | TOTAL COUNTER              | Total counter                         |
| 2 | MAINTENANCE (DRUM) COUNTER | Maintenance counter/ OPC drum counter |
| 3 | DV COUNTER                 | Developer counter                     |

(Count-up)

|   |            |            |         |
|---|------------|------------|---------|
| 1 | 1 COUNT UP | 1 count-up |         |
| 2 | 2 COUNT UP | 2 count-up | Default |

SIMULATION 26-5

A3 (LEDGER) COUNT UP MODE SETTING. SELECT 1-3, AND PRESS START.  
 1. TOTAL COUNTER 1  
 2. MAINTENANCE (DRUM) COUNTER 1  
 3. DV COUNTER

Press [START] key.

Press [CUSTOM SETTINGS] key.

SIMULATION 26-5

A3 (LEDGER) COUNT UP MODE SETTING. SELECT 1-2, AND PRESS START.  
 1. TOTAL COUNTER  
 (1: 1COUNT UP, 2: 2COUNT UP)

26

26-3

|                           |                                                                                                              |
|---------------------------|--------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                      |
| <b>Function (Purpose)</b> | Used to set the specifications of the auditor. Setting must be made according to the auditor use conditions. |
| <b>Section</b>            | Auditor                                                                                                      |
| <b>Item</b>               | Specifications                                                                                               |

**Operation/Procedure**

- 1) Select the number corresponding to the auditor mode with 10-key.
- 2) Press [START] key.

|   |        |                       |
|---|--------|-----------------------|
| 1 | P10    | Built-in auditor mode |
| 2 | VENDOR | Coin vendor mode      |
| 3 | OTHERS | Other                 |

(Default: 1)

SIMULATION 26-3

AUDITOR SETUP. SELECT 1-3, AND PRESS START.  
 1. P10  
 2. VENDOR  
 3. OTHERS

26-6

|                           |                                                                                             |
|---------------------------|---------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                     |
| <b>Function (Purpose)</b> | Used to set the specifications (paper, fixed magnification ratio, etc.) of the destination. |
| <b>Item</b>               | Specifications Destination                                                                  |

**Operation/Procedure**

- 1) Select the number corresponding to the destination with 10-key.
- 2) Press [START] key.

After completion of setting, the machine is automatically reset.

|    |           |                          |
|----|-----------|--------------------------|
| 1  | USA       | United States of America |
| 2  | CANADA    | Canada                   |
| 3  | INCH      | Inch series EX           |
| 4  | JAPAN     | Japan                    |
| 5  | AB_B      | AB series B5             |
| 6  | EUROPE    | Europe                   |
| 7  | UK        | UK                       |
| 8  | AUSTRALIA | Australia                |
| 9  | AB_A      | AB series A5             |
| 10 | CHINA     | China                    |

Since this simulation cannot change the Fax destination, use SIM 66-2 to change the FAX destination.



SIMULATION 26-6  
 DESTINATION SETUP. SELECT 1-10, AND PRESS START.  
 1.USA 2.CANADA 3.INCH  
 4.JAPAN 5.AB\_B  
 6.EUROPE 7.UK 8.AUSTRALIA  
 9.AB\_A 10.CHINA

1

SIMULATION 26-30  
 CE MARK CONTROL SETTING. SELECT 0-1, AND PRESS START.  
 0. NO  
 1. YES

1

26-10

|                           |                                             |
|---------------------------|---------------------------------------------|
| <b>Purpose</b>            | Setting                                     |
| <b>Function (Purpose)</b> | Used to set the network scanner trial mode. |
| <b>Item</b>               | Operation                                   |

#### Operation/Procedure

- 1) Select START/END of the network scanner trial mode with 10-key.
  - 2) Press [START] key.
- Max. 500 menus can be scanned.

|   |       |                   |         |
|---|-------|-------------------|---------|
| 0 | END   | Trial mode cancel | Default |
| 1 | START | Trial mode start  |         |

SIMULATION 26-10  
 NETWORK SCANNER TRIAL SETTING. SELECT 0-1, AND PRESS START.  
 0.END  
 1.START

1

26-18

|                           |                                                                                                                                                                                                                                        |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                                                                                                                                                |
| <b>Function (Purpose)</b> | Used to set YES/NO of toner save operation. (This function is valid only in Japan and UK versions. (Depends on the destination setting of SIM26-6.) For the other destinations, the same setting can be made by the user program P22.) |
| <b>Item</b>               | Specifications      Operation mode                                                                                                                                                                                                     |

#### Operation/Procedure

- 1) Select YES/NO of the toner save mode with 10-key.
- 2) Press [START] key.

|   |     |                             |         |
|---|-----|-----------------------------|---------|
| 0 | YES | Toner save mode is set.     |         |
| 1 | NO  | Toner save mode is not set. | Default |

SIMULATION 26-18  
 TONER SAVE MODE SETTING. SELECT 0-1, AND PRESS START.  
 0. YES  
 1. NO

1

26-30

|                           |                                                                                                                                                     |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                                                             |
| <b>Function (Purpose)</b> | Used to set the operation mode conforming to the CE mark (Europe safety standards). (Conforming to soft start when driving the fusing heater lamp.) |
| <b>Item</b>               | Specifications      Operation mode (Common)                                                                                                         |

#### Operation/Procedure

- 1) Select the number corresponding to the operation mode with 10-key.
- 2) Press [START] key.

|   |     |                                                        |
|---|-----|--------------------------------------------------------|
| 0 | NO  | CE mark control NO (Normal operation)                  |
| 1 | YES | CE mark control YES (Heater lamp soft start operation) |

(Default: 1 for Europe, 0 for the others)

26-35

|                           |                                                                                                                                                                  |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                                                                          |
| <b>Function (Purpose)</b> | Used to set whether the same continuous troubles are displayed as one trouble or the series of troubles with SIM 22-4 when the same troubles occur continuously. |
| <b>Section</b>            |                                                                                                                                                                  |
| <b>Item</b>               | Specifications                                                                                                                                                   |

#### Operation/Procedure

- 1) Select the number corresponding to the operation mode with 10-key.
- 2) Press [START] key.

|   |      |                                                                                                                                                               |
|---|------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | ONCE | When two or more troubles of a same kind occur continuously, the troubles are displayed as one trouble in the trouble history of SIM22-4.                     |
| 1 | ANY  | When two or more troubles of a same kind occur continuously, the troubles are displayed straightly as two or more troubles in the trouble history of SIM22-4. |

(Default: 0)

SIMULATION 26-35  
 TROUBLE MEMORY MODE SETTING. SELECT 0-1, AND PRESS START.  
 0. ONCE  
 1. ANY

1

26-38

|                           |                                                                                                                                      |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                                              |
| <b>Function (Purpose)</b> | Used to set CONTINUE/STOP of printing when maintenance timing is over and the count value reaches 110% of replacement timing (life). |
| <b>Section</b>            | Other                                                                                                                                |
| <b>Item</b>               | Specifications                                                                                                                       |

#### Operation/Procedure

- 1) Select the number corresponding to the operation mode with 10-key.
- 2) Press [START] key.

|   |                |                |
|---|----------------|----------------|
| 0 | PRINT CONTINUE | Print continue |
| 1 | PRINT STOP     | Print stop     |

(Default: 0)

SIMULATION 26-38  
 LIFE OVER SETTING. SELECT 0-1, AND PRESS START.  
 0. PRINT CONTINUE  
 1. PRINT STOP

1



## 26-41

|                           |                                                                                               |
|---------------------------|-----------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                       |
| <b>Function (Purpose)</b> | Used to set YES/NO of the automatic magnification ratio selection (AMS) in the pamphlet mode. |
| <b>Section</b>            |                                                                                               |
| <b>Item</b>               | Specifications      Operation mode (Common)                                                   |

### Operation/Procedure

- 1) Enter the number corresponding to whether AMS operation is automatically performed or nor in the center binding mode with the 10-key.
- 2) Press [START] key.

|   |     |                           |
|---|-----|---------------------------|
| 0 | NO  | AMS/APS selection allowed |
| 1 | YES | AMS is forcibly operated. |

(Default: 1 for Europe and UK, 0 for the others)

SIMULATION 26-41  
PAMPHLET MODE AMS SETTING. SELECT 0-1, AND PRESS START.  
0. NO  
1. YES

## 26-50

|                           |                                    |
|---------------------------|------------------------------------|
| <b>Purpose</b>            | Setting                            |
| <b>Function (Purpose)</b> | Black-White reverse YES/NO setting |
| <b>Item</b>               | Specifications      Operation      |

### Operation/Procedure

- 1) Select ENABLE/DISABLE of the B/W reverse mode with 10-key.
- 2) Press [START] key.

|   |         |                          |         |
|---|---------|--------------------------|---------|
| 0 | DISABLE | B/W reverse mode DISABLE |         |
| 1 | ENABLE  | B/W reverse mode ENABLE  | Default |

SIMULATION 26-50  
B/W REVERSE MODE SETTING. SELECT 0-1, AND PRESS START.  
0. DISABLE  
1. ENABLE

## 26-52

|                           |                                                                                                                    |
|---------------------------|--------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                            |
| <b>Function (Purpose)</b> | Used to set whether non-print paper (insertion paper, cover paper) (blank image print paper) is counted up or not. |
| <b>Section</b>            | Paper transport (Discharge/Switchback/Transport)                                                                   |
| <b>Item</b>               | Specifications      Operation mode                                                                                 |

### Operation/Procedure

- 1) Select YES/NO of the non-print paper count-up with 10-key.
- 2) Press [START] key.

Non-print paper means an insert paper (without copying) in the OHP insertion mode, a cover (without copying) in the cover insertion mode, back surface, and white paper in the duplex exit mode (CA, etc.).

|   |                  |             |
|---|------------------|-------------|
| 0 | NO (NO COUNT UP) | No count up |
| 1 | YES (COUNT UP)   | Count up    |

(Default: 0 for Japan and Australia, 1 for the other)

The target counters are as follows:

- Copies counter
- Printer counter
- Department management counter

- Total counter
- Effective paper counter

SIMULATION 26-52  
BLANK PAPER COUNT UP SETTING. SELECT 0-1, AND PRESS START.  
0. NO (NO COUNT UP)  
1. YES (COUNT UP)

## 26-68

|                           |                                                                         |
|---------------------------|-------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                 |
| <b>Function (Purpose)</b> | Used to set ENABLE/DISABLE of the CA key cancel function of print stop. |
| <b>Section</b>            |                                                                         |
| <b>Item</b>               | Specifications      Operation                                           |

### Operation/Procedure

- 1) Select ENABLE/DISABLE of the CA key cancel function of print stop with 10-key.
- 2) Press [START] key.

|   |                     |         |
|---|---------------------|---------|
| 0 | DISABLE             | Disable |
| 1 | ENABLE (PRINT STOP) | Enable  |

(Default: 1)

SIMULATION 26-68  
CA KEY CANCEL MODE SETTING. SELECT 0-1, AND PRESS START.  
0. DISABLE  
1. ENABLE (PRINT STOP)

## 27

### 27-1

|                           |                                                                                                                                                                                                                                                                                                                      |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                                                                                                                                                                                                                              |
| <b>Function (Purpose)</b> | Used to set the specifications for operations in case of communication trouble between the host computer and MODEM (machine side). (When communication trouble occurs between the host computer MODEM and the machine, the self diag display (U7-00) is printed and setting for inhibition of print or not is made.) |
| <b>Section</b>            | Communication unit (TEL/LIU/MODEM etc.)                                                                                                                                                                                                                                                                              |
| <b>Item</b>               | Specifications      Operation mode                                                                                                                                                                                                                                                                                   |

### Operation/Procedure

- 1) Select the number corresponding to the operation mode with 10-key.
- 2) Press [START] key.

|   |     |                                                                                                                                                                   |
|---|-----|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | YES | Though a communication trouble occurs between the host computer and the MODEM (machine side), there is no effect on the machine operations.                       |
| 1 | NO  | When a communication trouble occurs between the host computer and the MODEM (machine side), the self diag display (U7-00) is displayed and printing is inhibited. |

(Default: 0)

SIMULATION 27-1  
DISABLING OF U7-00 TROUBLE. SELECT 0-1, AND PRESS START.  
0. YES  
1. NO

| Operation/Procedure |
|---------------------|
|---------------------|

1) Enter the tag number with 10-key.

- 2) Press [START] key.

TAG # SETTING. INPUT VALUE, AND PRESS START.  
PRESENT: 00010000  
NEW: 00009999

\_\_\_\_\_

| Operation/Procedure                   | Frequency | Personnel  | Equipment                           | Materials              | Time           | Cost            | Notes                                                    |
|---------------------------------------|-----------|------------|-------------------------------------|------------------------|----------------|-----------------|----------------------------------------------------------|
| 1. Preparation of the test area       | Once      | Technician | Hand saw, Hammer, Drill             | Concrete, Wood, Screws | 15 min         | \$50.00         | Ensure the area is clear and safe for testing.           |
| 2. Installation of the test equipment | Once      | Technician | Test equipment, Screws, Nuts        | Concrete, Wood         | 30 min         | \$100.00        | Follow the manufacturer's instructions for installation. |
| 3. Calibration of the test equipment  | Once      | Technician | Calibration weights, Test equipment | Concrete, Wood         | 15 min         | \$50.00         | Ensure the equipment is calibrated correctly.            |
| 4. Data collection                    | Once      | Technician | Test equipment                      | Concrete, Wood         | 10 min         | \$20.00         | Record the data carefully.                               |
| 5. Analysis of the data               | Once      | Technician | Computer, Software                  | Concrete, Wood         | 15 min         | \$30.00         | Interpret the data and draw conclusions.                 |
| 6. Reporting of the results           | Once      | Technician | Report form, Pen                    | Concrete, Wood         | 10 min         | \$10.00         | Provide a clear and concise report.                      |
| 7. Cleanup                            | Once      | Technician | Hand saw, Hammer, Drill             | Concrete, Wood, Screws | 15 min         | \$50.00         | Remove all equipment and debris from the test area.      |
| <b>Total</b>                          |           |            |                                     |                        | <b>1.00 hr</b> | <b>\$310.00</b> |                                                          |

The operating conditions of sensors and detectors are displayed.

The active sensors and detectors are highlighted

|  |  |
|--|--|
|  |  |
|--|--|

```
SENSOR CHECK..
PPD1 POD1 POD2 POD3 DSWL
DSWF
```

\_\_\_\_\_

| Operation/Procedure |
|---------------------|
|---------------------|

The operating conditions of sensors and detectors are displayed.

The active sensors and detectors are highlighted

---

```
TRAY SENSOR CHECK..
CSS PED LUD
MCSET MCDRS MCPDP MCLUD MCPED MCSPD MCSS1 MCSS2
MCSS3 MCSS4 (MP Tray size: A4)
MPFSET MPED MPLD MPLS1 MPLS2
 (Bypass Tray size: A3)
```

© 2006 The Authors  
Journal compilation © 2006 Blackwell Publishing Ltd

| Operation/Procedure |
|---------------------|
|---------------------|

The operating conditions of sensors and detectors are displayed.

The active sensors and detectors are highlighted

|      |                              |
|------|------------------------------|
| MPID | Manual tray length detection |
|------|------------------------------|

[illegible]

```

BYPASS TRAY SENSOR CHECK..

MPLD MPLS1 MPLS2
BYPASS_WIDTH: 2100 BYPASS_AD: 600
(Bypass Tray width size: A4/A3)


```

40-2

|                           |                                                                                 |
|---------------------------|---------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                      |
| <b>Function (Purpose)</b> | Used to adjust the manual paper feed tray paper width detector detection level. |
| <b>Section</b>            | Paper feed                                                                      |
| <b>Item</b>               | Operation                                                                       |

**Operation/Procedure**

- 1) Open the manual paper feed guide to the max. width.
  - 2) Select MAX POSITION with 10-key.
  - 3) Press [START] key.  
The max. width detection level is recognized.
  - 4) Press [CUSTOM SETTINGS] key.
  - 5) Set the manual paper feed guide to A4R size width.
  - 6) Select POSITION with 10-key.
  - 7) Press [START] key.  
The A4R width detection level is recognized.
  - 8) Press [CUSTOM SETTINGS] key.
  - 9) Set the manual paper feed guide to A5/A5R size width.
  - 10) Select POSITION2 with 10-key.
  - 11) Press [START] key.  
The A5R width detection level is recognized.
  - 12) Press [CUSTOM SETTINGS] key.
  - 13) Open the manual paper feed guide to the min. width.
  - 14) Select MIN POSITION with 10-key.
  - 15) Press [START] key.  
The min. width detection level is recognized.
- If the above procedures are not completed normally, "ERROR" is displayed. If completed normally, "COMPLETE" is displayed.




40-7

|                           |                                                                        |
|---------------------------|------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment/Setup                                                       |
| <b>Function (Purpose)</b> | Used to enter the manual paper feed tray paper width adjustment value. |
| <b>Section</b>            | Paper feed                                                             |
| <b>Item</b>               | Operation                                                              |

**Operation/Procedure**

- 1) Select the number corresponding to the set item with 10-key.
- 2) Press [START] key.
- 3) Enter the set value with 10-key.
- 4) Press [START] key.

|   |               |                    |
|---|---------------|--------------------|
| 1 | MAX. POSITION | Max. width         |
| 2 | POSITION 1    | Adjustment point 1 |
| 3 | POSITION 2    | Adjustment point 2 |
| 4 | MIN. POSITION | Min. value         |



40-11

|                           |                                                                        |
|---------------------------|------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                   |
| <b>Function (Purpose)</b> | Used to check the multi-purpose tray width detection adjustment value. |
| <b>Section</b>            | Paper feed                                                             |
| <b>Item</b>               | Operation                                                              |

**Operation/Procedure**

The operating conditions of sensors and detectors are displayed.  
The active sensors and detectors are highlighted.  
The paper width detection level is also displayed.

|                    |                                                                                                               |
|--------------------|---------------------------------------------------------------------------------------------------------------|
| MCSS1              | Tray 3 size detection 1                                                                                       |
| MCSS2              | Tray 3 size detection 2                                                                                       |
| MCSS3              | Tray 3 detection size 3                                                                                       |
| MCSS4              | Tray 3 size detection 4                                                                                       |
| Multi Purpose Tray | (MPT width direction detection size is displayed.) A4/A3, 11X, B5/B4, 8.5X, A4R, B5R, A5R, 5.5X, 7.25X, EXTRA |

```

SIMULATION 40-11
TRAY3 SENSOR CHECK..
MCSS1 MCSS2 MCSS3 MCSS4
(Multi Purpose Tray width size: A4/A3)

```

40-12


|                           |                                                                        |
|---------------------------|------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment/Setup                                                       |
| <b>Function (Purpose)</b> | Used to check the multi-purpose tray width detection adjustment value. |
| <b>Section</b>            | Paper feed                                                             |
| <b>Item</b>               | Operation                                                              |

**Operation/Procedure**

- 1) Open the paper feed tray 2 paper feed guide to the max. width position.
- 2) Select MAX POSITION with 10-key.
- 3) Press [START] key.  
The max. width detection level is recognized.
- 4) Press [CUSTOM SETTINGS] key.
- 5) Open the paper feed tray 3 paper feed guide to the min. width position.
- 6) Select MIN POSITION with 10-key.
- 7) Press [START] key.

The min. width detection level is recognized.

If the above procedures are not completed normally, "ERROR" is displayed. If completed normally, "COMPLETE" is displayed.



41-2


|                           |                                                        |
|---------------------------|--------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                             |
| <b>Function (Purpose)</b> | Used to adjust the document size sensor sensing level. |
| <b>Section</b>            | Other                                                  |
| <b>Item</b>               | Operation                                              |

**Operation/Procedure**

- 1) Open the document cover and select NO ORIGINAL with 10-key without placing any document on the document table.
- 2) Press [START] key.  
The sensor level is set without document on the document table.
- 3) Place an A3 document on the document table, and select A3 ORIGINAL with 10-key.
- 4) Press [START] key.

The sensor level is set when detection the document.

If the above procedures are not completed normally, "ERROR" is displayed. If completed normally, "COMPLETE" is displayed.



41

41-1

|                           |                                                                                                                                                                     |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                |
| <b>Function (Purpose)</b> | Used to check the operation of the document size sensor and the related circuit. (The operation of the document size sensor can be monitored with the LCD display.) |
| <b>Section</b>            | Other                                                                                                                                                               |
| <b>Item</b>               | Operation                                                                                                                                                           |

**Operation/Procedure**

The operating conditions of sensors and detectors are displayed.  
The active sensors and detectors are highlighted.

|         |                                  |                                                              |
|---------|----------------------------------|--------------------------------------------------------------|
| OCSW    | Document cover status            | Open: Normal display<br>Close: Highlighted                   |
| PD1 - 7 | Document detection sensor status | No document: Normal display<br>Document present: Highlighted |

**SIMULATION 41-1**  
PD SENSOR CHECK..  
OCSW PD1 PD2 PD3 PD4 PD5 PD6 PD7

41-3

|                           |                                                                                                                                                                 |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                            |
| <b>Function (Purpose)</b> | Used to check the operation of the document size sensor and the related circuit. (The document size sensor output level can be monitored with the LCD display.) |
| <b>Section</b>            | Other                                                                                                                                                           |
| <b>Item</b>               | Operation                                                                                                                                                       |

**Operation/Procedure**

The detection output level (A/D value) of the document sensors (PD1 - PD7) is displayed in real time.

\* The value in [ ] on the side of each sensor name indicates the threshold value.

The light receiving value (A/D value) and the threshold value (A/D value) of PD1 - PD7 are in the range of 1 - 255. The default of threshold value is 128.

|         |                           |                                                                                       |
|---------|---------------------------|---------------------------------------------------------------------------------------|
| OCSW    | Original cover status     | Open: Normal display<br>Close: Highlighted                                            |
| PD1 - 7 | PD sensor detection level | The value in [ ] indicates the adjustment threshold value (SIM41-2 adjustment value). |

#### SIMULATION 41-3

PD SENSOR DATA DISPLAY.

OCSW

PD1[128]: 200 PD2[128]: 200  
PD3[128]: 50 PD4[128]: 52  
PD5[128]: 51 PD6[128]: 50  
PD7[128]: 52

#### SIMULATION 44-1

PROCESS CORRECTION VALUE SETTING. INPUT VALUE 0-255 AND PRESS START.

BIT0:Vg1, BIT1:Ld1, BIT2:Vg2, BIT3:Ld2  
BIT4:Vb1, Vb2  
BIT5:Vg3, Vb3, Ld3  
BIT6:Vbr  
BIT7:Vg4, Vb4, Ld4

111

43

43-1

|                           |                                                            |
|---------------------------|------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                    |
| <b>Function (Purpose)</b> | Used to set the fusing temperature in each operation mode. |
| <b>Section</b>            | Fixing (Fusing)                                            |
| <b>Item</b>               | Operation                                                  |

#### Operation/Procedure

- 1) Select the number corresponding to the setting mode with 10-key.
- 2) Press [START] key.
- 3) Press [CUSTOM SETTINGS] key.
- 4) Press [START] key.

| Item |                 |                        | Default |
|------|-----------------|------------------------|---------|
| 1    | INSIDE NORMAL   | Heater inside/normal   | 190     |
| 2    | OUTSIDE NORMAL  | Heater outside/normal  | 190     |
| 3    | INSIDE PREHEAT  | Heater inside/preheat  | 150     |
| 4    | OUTSIDE PREHEAT | Heater outside/preheat | 150     |

#### SIMULATION 43-1

FUSER TEMPERATURE SET. SELECT 1-4, AND PRESS START.

1. INSIDE NORMAL 190  
2. OUTSIDE NORMAL 190  
3. INSIDE PREHEAT 150  
4. OUTSIDE PREHEAT 150

1

Press [START] key.

Press [CUSTOM SETTINGS] key.

#### SIMULATION 43-1

FUSER TEMPERATURE SET. INPUT VALUE, AND PRESS START.

1. INSIDE NORMAL

190

44

44-1

|                           |                                                                                             |
|---------------------------|---------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                     |
| <b>Function (Purpose)</b> | Used to set enable/disable of correction operations in the image forming (process) section. |
| <b>Section</b>            | Image process (Photoconductor/Developing/Transfer/Cleaning)                                 |
| <b>Item</b>               | Operation                                                                                   |

#### Operation/Procedure

When bit =1, correction is made.

| Bit | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7                 | 6   | 5                 | 4          | 3   | 2   | 1   | 0   |
|-----|----|----|----|----|----|----|---|---|-------------------|-----|-------------------|------------|-----|-----|-----|-----|
|     | 0  | 0  | 0  | 0  | 0  | 0  | 0 | 0 | Vg4<br>Vb4<br>Ld4 | Vbr | Vg3<br>Vb3<br>Ld3 | Vb1<br>Vb2 | Ld2 | Vg2 | Ld1 | Vg1 |

44-4

|                           |                                                                                                   |
|---------------------------|---------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setup                                                                                             |
| <b>Function (Purpose)</b> | Used to set the target image (reference) density level in the developing bias voltage correction. |
| <b>Section</b>            | Process (OPC drum, developing, transfer, cleaning)                                                |
| <b>Item</b>               | Data                                                                                              |

#### Operation/Procedure

- 1) Select the number corresponding to the setting mode with 10-key.
- 2) Press [START] key.
- 3) Enter the set value.
- 4) Press [START] key.

| Item |                  |                                                                              |
|------|------------------|------------------------------------------------------------------------------|
| 1    | TEMP. AREA *1    | Process environment temperature forcible setting value (0 - 99°C /normal: 0) |
| 2    | HUMIDITY AREA *1 | Process environment humidity forcible setting value (0 - 99°C /normal: 0)    |
| 3    | S_WT             | Vb rising correction standby time (0 - 180 sec/default: 90)                  |
| 4    | Vb1              | Vb correction amount (first rotation) (0 - 150V/default: 50)                 |
| 5    | Vb2              | Vb correction amount (second rotation) (0-50V/default: 15)                   |

\*1: Only when this value is 0, control is made with the actual measurement value of the process thermistor (temperature/humidity). When it is not 0, control is made with the forcible setting value.

#### SIMULATION 44-4

PROCESS CONTROL VALUE SETTING. SELECT 1-5 AND PRESS START.

1. TEMP. AREA 0  
2. HUMIDITY AREA 0  
3. S\_WT 100  
4. Vb1 50  
5. Vb2 50

3

Press [START] key.

Press [CUSTOM SETTINGS] key.

#### SIMULATION 44-4

PROCESS CONTROL VALUE SETTING. INPUT VALUE, AND PRESS START.

3. S\_WT

101

|                           |                                                                                                                                                                                                                                                                                                        |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 44-9                      |                                                                                                                                                                                                                                                                                                        |
| <b>Purpose</b>            | Adjustment/Setup/Operation data output/Check (Display/Print)                                                                                                                                                                                                                                           |
| <b>Function (Purpose)</b> | Used to check the data related to the image forming section correction (process correction) result (corrected main charger grid voltage, the developing bias voltage, and the laser power voltage in each print mode). (This simulation allows to check that correction is performed normally or not.) |
| <b>Section</b>            | Image process (Photoconductor/Developing/Transfer/Cleaning)                                                                                                                                                                                                                                            |
| <b>Item</b>               | Data      Operation data (Machine condition)                                                                                                                                                                                                                                                           |

#### Operation/Procedure

|                    |                                  |
|--------------------|----------------------------------|
| DRUM ROTATION TIME | Drum rotation time (sec)         |
| DEVE ROTATION TIME | Developer rotation time (sec)    |
| Vg1 - Vg4          | Grid voltage correction value    |
| Vb1 - Vb4          | Developing bias correction value |
| Ld1 - Ld4          | Laser power correction value     |
| DESTINATION 1      | Machine CRUM destination (1-9)   |
| DESTINATION 2      | CRUM destination (1-9)           |

```

SIMULATION 44-9
PROCESS CONTROL DATA DISPLAY.
DRUM ROTATION TIME: 01234567(sec)
DEVE ROTATION TIME: 01234567(sec)
Vg1: 30(V) Vg2: 30(V) Vg3: 30(V) Vg4: 30(V)
Vb1: 30(V) Vb2: 10(V) Vb3: 30(V) Vb4: 10(V)
Ld1 Ld2 Ld3 Ld4
DESTINATION1: 1
DESTINATION2: 1

```

|                           |                                                                                   |
|---------------------------|-----------------------------------------------------------------------------------|
| 44-14                     |                                                                                   |
| <b>Purpose</b>            | Adjustment/Setup/Operation data output/Check (Display)                            |
| <b>Function (Purpose)</b> | Used to check the output level of the temperature sensor and the humidity sensor. |
| <b>Section</b>            | Image process (Photoconductor/Developing)                                         |
| <b>Item</b>               | Operation                                                                         |

#### Operation/Procedure

The output levels of the temperature thermistor and the humidity thermistor in the developing unit are displayed.

|        |                                   |         |
|--------|-----------------------------------|---------|
| TH-DV  | Developing temperature thermistor | 0 - 255 |
| HUS-DV | Developing humidity thermistor    | 0 - 255 |

```

SIMULATION 44-14
SENSOR DATA DISPLAY MONITOR.
TH-DV: 255
HUS-DV: 255

```

|                           |                                                        |
|---------------------------|--------------------------------------------------------|
| 44-16                     |                                                        |
| <b>Purpose</b>            | Adjustment/Setup/Operation data output/Check (Display) |
| <b>Function (Purpose)</b> | Used to check the toner concentration control data.    |
| <b>Section</b>            | Image process (Developing)                             |
| <b>Item</b>               | Operation                                              |

#### Operation/Procedure

|                      |                                            |
|----------------------|--------------------------------------------|
| HUMIDITY AREA        | Humidity area                              |
| INT HUMIDITY AREA    | Humidity area in development adjustment    |
| TEMPERATURE AREA     | Temperature area                           |
| INT TEMPERATURE AREA | Temperature area in development adjustment |
| TARGET LEVEL         | Toner control reference value              |

|               |                                           |
|---------------|-------------------------------------------|
| DEV REF       | Development adjustment registration value |
| HUM (TARGET)  | Humidity correction value                 |
| TMP (TARGET)  | Target value of humidity correction       |
| LIFE (TARGET) | Target value of temperature correction    |
| LIFE (TARGET) | Environment correction value              |
|               | Target value of environment correction    |

```

SIMULATION 44-16
TONER CONTROL STANDARD LEVEL DISPLAY.
HUMIDITY AREA: 11
INT HUMIDITY AREA: 7
TEMPERATURE AREA: 6
INT TEMPERATURE AREA: 6
TARGET LEVEL=DEV REF+HUM(TARGET)+TMP(TARGET)+LIFE(TARGET)
133 = 118 + 10(10) + 0(0) + 5(5)

```

## 46

|                           |                                                                                                 |
|---------------------------|-------------------------------------------------------------------------------------------------|
| 46-2                      |                                                                                                 |
| <b>Purpose</b>            | Adjustment                                                                                      |
| <b>Function (Purpose)</b> | Used to adjust the copy density in all the copy modes (Auto, Text, Text/Photo, and Photo mode). |
| <b>Item</b>               | Picture quality      Density                                                                    |

#### Operation/Procedure

- 1) Select the number corresponding to the copy mode to be adjusted with 10-key. (Select one of 3 - 6.)
- 2) Press [START] key.
- 3) Enter the copy density level with 10-key.

|   | Item        | Set range                 | Default        |
|---|-------------|---------------------------|----------------|
| 0 | TRAY SELECT | Paper feed tray selection |                |
| 1 | COPY START  | Copy START (Default)      |                |
| 2 | EXP LEVEL   | Exposure level selection  |                |
| 3 | AE 3.0      | AE mode                   | 0 - 99      50 |
| 4 | CH 3.0      | Text mode 3.0             |                |
| 5 | MIX 3.0     | Text/Photo mode 3.0       |                |
| 6 | PHOTO 3.0   | Photo mode 3.0            |                |

- 4) Press P key or [START] key.

The adjustment value is set.

When [START] key is pressed, copying is performed and the adjustment value is simultaneously set.

Check the density of the printed copy image.

|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |

NOTE: When the copy image density is adjusted with this simulation, the copy image densities of all the copy modes are changed to the copy image density level set with this simulation.

That is, the copy image density of each copy mode set with SIM 46-9, 10, 11 is changed to the copy image density level adjusted with this simulation.

To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)




- Enter the number corresponding to the paper feed tray to be used with 10-key.

- Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When START key is pressed, the adjustment value is set and copying is performed.



46-9

|                           |                                                                                                                                                                                             |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                                                                                                                  |
| <b>Function (Purpose)</b> | Used to adjust the print density for each density level (display value) in the copy mode (binary - Text mode). An optional print density can be set for each density level (display value). |
| <b>Item</b>               | Picture quality Density                                                                                                                                                                     |

#### Operation/Procedure

- Select the number corresponding to the copy density adjustment level with 10-key. (Select one of 3 - 11.)
- Press [START] key.
- Enter the copy density level with 10-key.

|    | Item        | Set range                 | Default      |
|----|-------------|---------------------------|--------------|
| 0  | TRAY SELECT | Paper feed tray selection |              |
| 1  | COPY START  | Copy START (Default)      |              |
| 2  | EXP LEVEL   | Exposure level selection  |              |
| 3  | 1.0         | Exposure level 1.0        | 0 - 99<br>50 |
| 4  | 1.5         | Exposure level 1.5        |              |
| 5  | 2.0         | Exposure level 2.0        |              |
| 6  | 2.5         | Exposure level 2.5        |              |
| 7  | 3.0         | Exposure level 3.0        |              |
| 8  | 3.5         | Exposure level 3.5        |              |
| 9  | 4.0         | Exposure level 4.0        |              |
| 10 | 4.5         | Exposure level 4.5        |              |
| 11 | 5.0         | Exposure level 5.0        |              |

- Press [P] key or [START] key.  
The adjustment value is set.  
When [START] key is pressed, copying is performed and the adjustment value is set simultaneously.  
Check the density of printed copy image.


|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |

To select paper (paper feed tray), perform the following procedures.

- Enter 0 with 10-key.
- Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- Enter the number corresponding to the paper feed tray to be used with 10-key.
- Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When START key is pressed, the adjustment value is set and copying is performed.



46-10

|                           |                                                                                                                                                                                                   |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                                                                                                                        |
| <b>Function (Purpose)</b> | Used to adjust the print density for each density level (display value) in the copy mode (binary - Text/Photo mode). An optional print density can be set for each density level (display value). |
| <b>Item</b>               | Picture quality                                                                                                                                                                                   |

#### Operation/Procedure

- 1) Select the number corresponding to the copy density adjustment level with 10-key. (Select one of 3 - 11.)
- 2) Press [START] key.
- 3) Enter the copy density level with 10-key.

| Item |             |                           | Set range | Default |
|------|-------------|---------------------------|-----------|---------|
| 0    | TRAY SELECT | Paper feed tray selection | 0 - 99    | 50      |
| 1    | COPY START  | Copy START (Default)      |           |         |
| 2    | EXP LEVEL   | Exposure level selection  |           |         |
| 3    | 1.0         | Exposure level 1.0        |           |         |
| 4    | 1.5         | Exposure level 1.5        |           |         |
| 5    | 2.0         | Exposure level 2.0        |           |         |
| 6    | 2.5         | Exposure level 2.5        |           |         |
| 7    | 3.0         | Exposure level 3.0        |           |         |
| 8    | 3.5         | Exposure level 3.5        |           |         |
| 9    | 4.0         | Exposure level 4.0        |           |         |
| 10   | 4.5         | Exposure level 4.5        |           |         |
| 11   | 5.0         | Exposure level 5.0        |           |         |

- 4) Press [P] key or [START] key.  
The adjustment value is set.  
When [START] key is pressed, copying is performed and the adjustment value is set simultaneously.  
Check the density of printed copy image.

|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |


To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray to be used with 10-key.
- 4) Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When START key is pressed, the adjustment value is set and copying is performed.





46-11

|                           |                                                                                                                                                                                              |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                                                                                                                   |
| <b>Function (Purpose)</b> | Used to adjust the print density for each density level (display value) in the copy mode (binary - Photo mode). An optional print density can be set for each density level (display value). |
| <b>Item</b>               | Picture quality Density                                                                                                                                                                      |

#### Operation/Procedure

- 1) Select the number corresponding to the copy density adjustment level with 10-key. (Select one of 3 - 11.)
- 2) Press [START] key.
- 3) Enter the copy density level with 10-key.

| Item |             |                           | Set range | Default |
|------|-------------|---------------------------|-----------|---------|
| 0    | TRAY SELECT | Paper feed tray selection | 0 - 99    | 50      |
| 1    | COPY START  | Copy START (Default)      |           |         |
| 2    | EXP LEVEL   | Exposure level selection  |           |         |
| 3    | 1.0         | Exposure level 1.0        |           |         |
| 4    | 1.5         | Exposure level 1.5        |           |         |
| 5    | 2.0         | Exposure level 2.0        |           |         |
| 6    | 2.5         | Exposure level 2.5        |           |         |
| 7    | 3.0         | Exposure level 3.0        |           |         |
| 8    | 3.5         | Exposure level 3.5        |           |         |
| 9    | 4.0         | Exposure level 4.0        |           |         |
| 10   | 4.5         | Exposure level 4.5        |           |         |
| 11   | 5.0         | Exposure level 5.0        |           |         |

- 4) Press [P] key or [START] key.  
The adjustment value is set.  
When [START] key is pressed, copying is performed and the adjustment value is set simultaneously.  
Check the density of printed copy image.


|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |

To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray to be used with 10-key.
- 4) Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When START key is pressed, the adjustment value is set and copying is performed.



46-12

|                           |                                                               |
|---------------------------|---------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                    |
| <b>Function (Purpose)</b> | Used to adjust the print density in the FAX mode (all modes). |
| <b>Item</b>               | Picture quality                                               |

#### Operation/Procedure

- 1) Select the adjustment item of FAX EXP. LEVEL with 10-key.
- 2) Press [START] key.
- 3) Enter the print density level with 10-key.

|   | Item           |                           | Set range | Default |
|---|----------------|---------------------------|-----------|---------|
| 0 | TRAY SELECT    | Paper feed tray selection |           |         |
| 1 | COPY START     | Copy START (Default)      |           |         |
| 2 | FAX EXP. LEVEL | FAX mode print density    | 0 - 99    | 50      |

- 4) Press [P] key or [START] key.

The adjustment value is set.

When [START] key is pressed, printing is performed and the adjustment value is set simultaneously.

Check the density of printed image.

|                |             |               |
|----------------|-------------|---------------|
| Normal display |             | NOW PRINTING. |
| ERROR display  | Door open   | DOOR OPEN.    |
|                | Jam         | JAM           |
|                | Paper empty | PAPER EMPTY.  |

NOTE: When the FAX print image density is adjusted with this simulation, the print image densities of all the FAX modes are changed to the image density level set with this simulation.


That is, the print image density of each FAX mode set with SIM 46-13, 14, 15 is changed to the print image density level adjusted with this simulation.

To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray to be used with 10-key.
- 4) Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When START key is pressed, the adjustment value is set and copying is performed.



|                           |                                                                                                    |
|---------------------------|----------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                         |
| <b>Function (Purpose)</b> | Used to adjust the print density in the FAX mode (each normal mode). (Only when FAX is installed.) |
| <b>Item</b>               | Picture quality                                                                                    |

**Operation/Procedure**

- 1) Select the number corresponding to one of the following adjustment items with 10-key.
  - \* Manual mode (Print density adjustment level)
  - \* Auto mode
- 2) Press [START] key.
- 3) Enter the print density level with 10-key.

|   | Item        | Set range                 | Default |
|---|-------------|---------------------------|---------|
| 0 | TRAY SELECT | Paper feed tray selection |         |
| 1 | PRINT START | Print start (Default)     |         |
| 2 | EXP LEVEL   | Exposure level selection  |         |
| 3 | AUTO        | Auto                      | 0 - 99  |
| 4 | 1.0         | Exposure level 1          | 50      |
| 5 | 2.0         | Exposure level 2          |         |
| 6 | 3.0         | Exposure level 3          |         |
| 7 | 4.0         | Exposure level 4          |         |
| 8 | 5.0         | Exposure level 5          |         |

- 4) Press [P] key or [START] key.  
The adjustment value is set.  
When [START] key is pressed, printing is performed and the adjustment value is set simultaneously.  
Check the density of printed image.

|                |             |               |
|----------------|-------------|---------------|
| Normal display |             | NOW PRINTING. |
| ERROR display  | Door open   | DOOR OPEN.    |
|                | Jam         | JAM           |
|                | Paper empty | PAPER EMPTY.  |


To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray to be used with 10-key.
- 4) Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

When the sum of the above set value (1 - 5) and 20 is set, the mode is changed to the duplex print mode.

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When [START] key is pressed, the adjustment value is set and copying is performed.



|                           |                                                                                                  |
|---------------------------|--------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                       |
| <b>Function (Purpose)</b> | Used to adjust the print density in the FAX mode (each fine mode). (Only when FAX is installed.) |
| <b>Item</b>               | Picture quality                                                                                  |

**Operation/Procedure**

- Select the number corresponding to one of the following adjustment items with 10-key. (Select one of 3 - 14.)
  - \* Normal mode (Print density adjustment level)
  - \* Normal mode (Print density adjustment level) (Half-tone mode)
  - \* Auto mode
  - \* Auto mode (Half-tone mode)
- Enter the print density level with 10-key.

| Item |             | Set range                    | Default      |
|------|-------------|------------------------------|--------------|
| 0    | TRAY SELECT | Paper feed tray selection    |              |
| 1    | PRINT START | Print start (Default)        |              |
| 2    | EXP LEVEL   | Exposure level selection     |              |
| 3    | AUTO        | Auto                         | 0 - 99<br>50 |
| 4    | 1.0         | Exposure level 1             |              |
| 5    | 2.0         | Exposure level 2             |              |
| 6    | 3.0         | Exposure level 3             |              |
| 7    | 4.0         | Exposure level 4             |              |
| 8    | 5.0         | Exposure level 5             |              |
| 9    | AUTO (H)    | Auto (Half-tone)             |              |
| 10   | 1.0 (H)     | Exposure level 1 (Half-tone) |              |
| 11   | 2.0 (H)     | Exposure level 2 (Half-tone) |              |
| 12   | 3.0 (H)     | Exposure level 3 (Half-tone) |              |
| 13   | 4.0 (H)     | Exposure level 4 (Half-tone) |              |
| 14   | 5.0 (H)     | Exposure level 5 (Half-tone) |              |

- Press [P] key or [ATART] key.  
The entered value is set.  
When [START] key is pressed, printing is performed and the adjustment value is set simultaneously.  
Check the density of print image.


|                |             |               |
|----------------|-------------|---------------|
| Normal display |             | NOW PRINTING. |
| ERROR display  | Door open   | DOOR OPEN.    |
|                | Jam         | JAM           |
|                | Paper empty | PAPER EMPTY.  |

To select paper (paper feed tray), perform the following procedures.

- Enter 0 with 10-key.
- Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- Enter the number corresponding to the paper feed tray to be used with 10-key.
- Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When [START] key is pressed, the adjustment value is set and copying is performed.



|                           |                                                                                                        |
|---------------------------|--------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                             |
| <b>Function (Purpose)</b> | Used to adjust the print density in the FAX mode (each super fine mode). (Only when FAX is installed.) |
| <b>Item</b>               | Picture quality                                                                                        |

#### Operation/Procedure

- Select the number corresponding to one of the following adjustment items with 10-key. (Select one of 3 - 14.)
  - \* Normal mode (Print density adjustment level)
  - \* Normal mode (Print density adjustment level) (Half-tone mode)
  - \* Auto mode
  - \* Auto mode (Half-tone mode)
- Press [START] key.
- Enter the print density level with 10-key.

| Item |             |                              | Set range | Default |
|------|-------------|------------------------------|-----------|---------|
| 0    | TRAY SELECT | Paper feed tray selection    | 0 - 99    | 50      |
| 1    | PRINT START | Print start (Default)        |           |         |
| 2    | EXP LEVEL   | Exposure level selection     |           |         |
| 3    | AUTO        | Auto                         |           |         |
| 4    | 1.0         | Exposure level 1             |           |         |
| 5    | 2.0         | Exposure level 2             |           |         |
| 6    | 3.0         | Exposure level 3             |           |         |
| 7    | 4.0         | Exposure level 4             |           |         |
| 8    | 5.0         | Exposure level 5             |           |         |
| 9    | AUTO (H)    | Auto (Half-tone)             |           |         |
| 10   | 1.0 (H)     | Exposure level 1 (Half-tone) |           |         |
| 11   | 2.0 (H)     | Exposure level 2 (Half-tone) |           |         |
| 12   | 3.0 (H)     | Exposure level 3 (Half-tone) |           |         |
| 13   | 4.0 (H)     | Exposure level 4 (Half-tone) |           |         |
| 14   | 5.0 (H)     | Exposure level 5 (Half-tone) |           |         |

- Press [P] key or [START] key.  
The entered value is set.  
When [START] key is pressed, printing is performed and the adjustment value is set simultaneously.  
Check the density of print image.


|                |             |               |
|----------------|-------------|---------------|
| Normal display |             | NOW PRINTING. |
| ERROR display  | Door open   | DOOR OPEN.    |
|                | Jam         | JAM           |
|                | Paper empty | PAPER EMPTY.  |

To select paper (paper feed tray), perform the following procedures.

- Enter 0 with 10-key.
- Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- Enter the number corresponding to the paper feed tray to be used with 10-key.
- Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When START key is pressed, the adjustment value is set and copying is performed.



|                           |                                                                                                        |
|---------------------------|--------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                             |
| <b>Function (Purpose)</b> | Used to adjust the print density in the FAX mode (each ultra fine mode). (Only when FAX is installed.) |
| <b>Item</b>               | Picture quality                                                                                        |

**Operation/Procedure**

- Select the number corresponding to one of the following adjustment items with 10-key. (Select one of 3 - 14.)
  - \* Normal mode (Print density adjustment level)
  - \* Normal mode (Print density adjustment level) (Half-tone mode)
  - \* Auto mode
  - \* Auto mode (Half-tone mode)
- Press [START] key.
- Enter the print density level with 10-key.

| Item |             | Set range                    | Default |
|------|-------------|------------------------------|---------|
| 0    | TRAY SELECT | Paper feed tray selection    |         |
| 1    | PRINT START | Print start (Default)        |         |
| 2    | EXP LEVEL   | Exposure level selection     |         |
| 3    | AUTO        | Auto                         | 0 - 99  |
| 4    | 1.0         | Exposure level 1             | 50      |
| 5    | 2.0         | Exposure level 2             |         |
| 6    | 3.0         | Exposure level 3             |         |
| 7    | 4.0         | Exposure level 4             |         |
| 8    | 5.0         | Exposure level 5             |         |
| 9    | AUTO (H)    | Auto (Half-tone)             |         |
| 10   | 1.0 (H)     | Exposure level 1 (Half-tone) |         |
| 11   | 2.0 (H)     | Exposure level 2 (Half-tone) |         |
| 12   | 3.0 (H)     | Exposure level 3 (Half-tone) |         |
| 13   | 4.0 (H)     | Exposure level 4 (Half-tone) |         |
| 14   | 5.0 (H)     | Exposure level 5 (Half-tone) |         |

- Press [P] key or [START] key.  
The entered value is set.  
When [START] key is pressed, printing is performed and the adjustment value is set simultaneously.  
Check the density of print image.


|                |             |               |
|----------------|-------------|---------------|
| Normal display |             | NOW PRINTING. |
| ERROR display  | Door open   | DOOR OPEN.    |
|                | Jam         | JAM           |
|                | Paper empty | PAPER EMPTY.  |

To select paper (paper feed tray), perform the following procedures.

- Enter 0 with 10-key.
- Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- Enter the number corresponding to the paper feed tray to be used with 10-key.
- Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When [START] key is pressed, the adjustment value is set and copying is performed.



|                           |                                             |
|---------------------------|---------------------------------------------|
| <b>Purpose</b>            | Setting                                     |
| <b>Function (Purpose)</b> | Used to set the gain in shading correction. |
| <b>Section</b>            | Optical (Image scanning) CCD, CIS           |
| <b>Item</b>               | Operation                                   |


**Operation/Procedure**

- Enter the number corresponding to the adjustment item
- Press [START] key.
- Enter the shading gain change value with 10-key.
- Press [START] key.

There is normally no need to change the shading gain with this simulation.

Only when the scanned image density is unsatisfactory though shading is performed, the above procedure is performed.

| Item |          | Set range | Default |
|------|----------|-----------|---------|
| 1    | CCD ODD  | 0 - 255   | 112     |
| 2    | CCD EVEN |           |         |
| 3    | CIS      |           | 128     |



46-18

|                           |                                                               |
|---------------------------|---------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                    |
| <b>Function (Purpose)</b> | Used to adjust the gamma (density gradient) in the copy mode. |
| <b>Item</b>               | Picture quality      Density                                  |

#### Operation/Procedure

(Copy mode selection)

- 1) Select the number corresponding to the copy mode to be adjusted with 10-key. (Select one of 3 - 14.)
- 2) Press [START] key.

(Print mode selection in the FAX mode)

- 1) Enter 2 with 10-key.
- 2) Press [START] key.
- 3) Select the number corresponding to one of the following adjustment items. (Select one of 3 - 14.)
  - \* Normal mode (Print density adjustment level)
  - \* Normal mode (Print density adjustment level) (Half-tone mode)
  - \* Auto mode
  - \* Auto mode (Half-tone mode)

|    | Item        | Set range                 | Default         |
|----|-------------|---------------------------|-----------------|
| 0  | TRAY SELECT | Paper feed tray selection |                 |
| 1  | PRINT START | Print start (Default)     |                 |
| 2  | EXP LEVEL   | Exposure level selection  |                 |
| 3  | OC_AE       | AE mode (OC)              | 0 - 127      64 |
| 4  | OC_CHARA    | Text mode (OC)            |                 |
| 5  | OC_MIX      | Text/Photo mode (OC)      |                 |
| 6  | OC_PHOTO    | Photo mode (OC)           |                 |
| 7  | SPF1_AE     | AE mode (SPF1)            |                 |
| 8  | SPF1_CHARA  | Text mode (SPF1)          |                 |
| 9  | SPF1_MIX    | Text/Photo mode (SPF1)    |                 |
| 10 | SPF1_PHOTO  | Photo mode (SPF1)         |                 |
| 11 | SPF2_AE     | AE mode (SPF2)            |                 |
| 12 | SPF2_CHARA  | Text mode (SPF2)          |                 |
| 13 | SPF2_MIX    | Text/Photo mode (SPF2)    |                 |
| 14 | SPF2_PHOTO  | Photo mode (SPF2)         |                 |
| 15 | CIS_AE      | AE mode (CIS)             |                 |
| 16 | CIS_CHARA   | Text mode (CIS)           |                 |
| 17 | CIS_MIX     | Text/Photo mode (CIS)     |                 |
| 18 | CIS_PHOTO   | Photo mode (CIS)          |                 |

#### Exposure level

|    | Item                                      |
|----|-------------------------------------------|
| 3  | AUTO      Auto                            |
| 4  | 1.0      Exposure level 1                 |
| 5  | 2.0      Exposure level 2                 |
| 6  | 3.0      Exposure level 3                 |
| 7  | 4.0      Exposure level 4                 |
| 8  | 5.0      Exposure level 5                 |
| 9  | AUTO (H)      Auto (Half-tone)            |
| 10 | 1.0 (H)      Exposure level 1 (Half-tone) |
| 11 | 2.0 (H)      Exposure level 2 (Half-tone) |
| 12 | 3.0 (H)      Exposure level 3 (Half-tone) |
| 13 | 4.0 (H)      Exposure level 4 (Half-tone) |
| 14 | 5.0 (H)      Exposure level 5 (Half-tone) |

- 4) Press [START] key.

|                |               |              |
|----------------|---------------|--------------|
| Normal display | NOW PRINTING. |              |
| ERROR display  | Door open     | DOOR OPEN.   |
|                | Jam           | JAM          |
|                | Paper empty   | PAPER EMPTY. |

(Gamma adjustment)

After completion of the above procedures, perform the following procedures.

- 1) Enter the gamma level with 10-key.
- 2) Enter [P] key or [CUSTOM SETTINGS] key.

When [START] key is pressed, printing is performed and the adjustment value is set simultaneously.

Check the gamma density (copy density in the low density area and the high density area) of printed copy image. The greater the adjustment value is, the greater the gamma value is, resulting in a higher contrast.

(Copy condition setting in this simulation)


To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray to be used with 10-key.
- 4) Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When START key is pressed, the adjustment value is set and copying is performed.





|                           |                                                                                    |
|---------------------------|------------------------------------------------------------------------------------|
| 46-19                     |                                                                                    |
| <b>Purpose</b>            | Adjustment                                                                         |
| <b>Function (Purpose)</b> | Used to set the auto mode operation specifications in each mode (copy, scan, FAX). |
| <b>Item</b>               | Picture quality Density                                                            |

#### Operation/Procedure

(Toner save operation YES/NO setting in the auto mode)

- 1) Select "1. AE MODE" with 1-key.
- 2) Press [START] key.
- 3) Select the number corresponding to the operation specifications with 10-key.
- 4) Press [START] key.

When [START] key is pressed, the adjustment value is set.

(Operation setting in the auto copy mode)

- 1) Select the number corresponding to the mode with 10-key. (Select one of 2 - 4.)
- 2) Press [START] key.
- 3) Select the number corresponding to the operation mode with 10-key.


4) Press [START] key.

|   |                        |                         |
|---|------------------------|-------------------------|
| 1 | AE MODE                | AE mode                 |
| 2 | AE STOP MODE (COPIER)  | AE fixed mode (Copier)  |
| 3 | AE STOP MODE (SCANNER) | AE fixed mode (Scanner) |
| 4 | AE STOP MODE (FAX)     | AE fixed mode (FAX)     |

| Mode          | Set value | Item                                                                                           | Default                       |
|---------------|-----------|------------------------------------------------------------------------------------------------|-------------------------------|
| AE mode       | 1         | Image quality priority mode (Normal mode)<br>* Gamma is sharp to provide high contrast images. | 2                             |
|               | 2         | Toner consumption priority mode<br>* Gamma is mild to provide low contrast images.             |                               |
| AE fixed mode | 0         | AE fixed OFF                                                                                   | 1 (COPIER)<br>0 (SCANNER/FAX) |
|               | 1         | AE fixed ON                                                                                    |                               |

AE fixed OFF: The automatic density (exposure) control is performed in real time. (The density level is changed in real time according to the document pattern.)

AE fixed ON: The density at the lead edge of the document is scanned, and the overall density (exposure) level is determined according to the scanned density level. (Overall density level fixed)





|                           |                                                                                                                                                                                                             |         |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------|
| <b>Purpose</b>            | Adjustment                                                                                                                                                                                                  |         |
| <b>Function (Purpose)</b> | Used to adjust the copy density correction in the SPF copy mode for the document table copy mode. The adjustment is made so that the copy density becomes the same as that of the document table copy mode. |         |
| <b>Section</b>            | SPF                                                                                                                                                                                                         |         |
| <b>Item</b>               | Picture quality                                                                                                                                                                                             | Density |

#### Operation/Procedure

(Adjustment mode selection)

- 1) Select the number corresponding to the copy mode to be adjusted with 10-key.  
SPF front frame side (Front surface copy), SPF rear frame side (Front surface copy), SPF (Back surface copy) (Select one of 3 - 5.)

- 2) Press [SATART] key.

(Copy density level adjustment)

- 1) Enter the density correction value with 10-key.
- 2) Press [P] key or [START] key.

(Copy condition setting in this simulation)


To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray to be used with 10-key.
- 4) Press [START] key. (The paper feed tray is selected.)

NOTE: When [P] key is pressed after entering an adjustment value in this simulation, the adjustment value is set. When START key is pressed, the adjustment value is set and copying is performed.

| Item          | Content                                                                                                                                                                                                                                                     | Set range | Default |
|---------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------|---------|
| 0 TRAY SELECT | Paper feed tray selection<br>1: TRAY1<br>2: TRAY2<br>3: TRAY3<br>4: TRAY4<br>5: Manual feed                                                                                                                                                                 | —         | —       |
| 1 PRINT START | Print start (Default)                                                                                                                                                                                                                                       | —         | —       |
| 2 EXP LEVEL   | Exposure level selection<br>3: Exposure level 1.0<br>4: Exposure level 1.5<br>5: Exposure level 2.0<br>6: Exposure level 2.5<br>7: Exposure level 3.0<br>8: Exposure level 3.5<br>9: Exposure level 4.0<br>10: Exposure level 4.5<br>11: Exposure level 5.0 | —         | —       |
| 3 SPF (FRONT) | SPF (front) (front frame side)                                                                                                                                                                                                                              | 0 - 255   | 128     |
| 4 SPF (REAR)  | SPF (front) (rear frame side)                                                                                                                                                                                                                               |           |         |
| 5 DSPF        | DSPF (Back surface)                                                                                                                                                                                                                                         |           |         |

- "Set value - 128" is added to the shading adjustment value (SIM 46-17).



|                           |                                                                     |         |
|---------------------------|---------------------------------------------------------------------|---------|
| <b>Purpose</b>            | Adjustment                                                          |         |
| <b>Function (Purpose)</b> | Used to adjust the scanner exposure level in all the scanner modes. |         |
| <b>Item</b>               | Picture quality                                                     | Density |


#### Operation/Procedure

- 1) Select "SCANNER EXP. LEVEL" with 10-key.
- 2) Press [START] key.
- 3) Enter the image density adjustment value.
- 4) Press [P] key or [START] key.

NOTE: When this simulation is performed to adjust the scan image densities, all the image densities in all the scan modes are changed to the image density level set with this simulation. That is, the image densities set with SIM 46-22, 23, 24, 25, and 45 are changed to the image density level set with this simulation.

| Item                 | Content             | Set range | Default |
|----------------------|---------------------|-----------|---------|
| 0 SCANNER EXP. LEVEL | Image density level | 0 - 99    | 50      |

NOTE: Only the set value is changed and no printing is performed.



46-22


|                           |                                                                    |
|---------------------------|--------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                         |
| <b>Function (Purpose)</b> | Used to adjust the scanner exposure level in the normal text mode. |
| <b>Item</b>               | Picture quality Density                                            |

#### Operation/Procedure

- 1) Select the number corresponding to one of the following adjustment items with 10-key. (Select one of 0 - 5.)
  - \* Normal mode (Image density adjustment level)
  - \* Auto mode
- 2) Press [START] key.
- 3) Enter the image density adjustment value with 10-key.
- 4) Press [START] key or press [CUSTOM SETTINGS] key.  
The adjustment value is set.

| Item |      |                  | Set range | Default |
|------|------|------------------|-----------|---------|
| 0    | AUTO | Auto             | 0 - 99    | 50      |
| 1    | 1.0  | Exposure level 1 |           |         |
| 2    | 2.0  | Exposure level 2 |           |         |
| 3    | 3.0  | Exposure level 3 |           |         |
| 4    | 4.0  | Exposure level 4 |           |         |
| 5    | 5.0  | Exposure level 5 |           |         |

NOTE: Only the set value is changed and no printing is performed.



46-23


|                           |                                                                  |
|---------------------------|------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                       |
| <b>Function (Purpose)</b> | Used to adjust the scanner exposure level in the fine text mode. |
| <b>Item</b>               | Picture quality Density                                          |

#### Operation/Procedure

- 1) Select the number corresponding to one of the following adjustment items with 10-key. (Select one of 0 - 11.)
  - \* Normal mode (Image density adjustment level)
  - \* Normal mode (Image density adjustment level) (Half-tone mode)
  - \* Auto mode
  - \* Auto mode (Half-tone mode)
- 2) Press [START] key.
- 3) Enter the image density adjustment value with 10-key.
- 4) Press [START] key or press [P] key.  
The adjustment value is set.

| Item |          |                              | Set range | Default |
|------|----------|------------------------------|-----------|---------|
| 0    | AUTO     | Auto                         | 0 - 99    | 50      |
| 1    | 1.0      | Exposure level 1             |           |         |
| 2    | 2.0      | Exposure level 2             |           |         |
| 3    | 3.0      | Exposure level 3             |           |         |
| 4    | 4.0      | Exposure level 4             |           |         |
| 5    | 5.0      | Exposure level 5             |           |         |
| 6    | AUTO (H) | Auto (Half-tone)             |           |         |
| 7    | 1.0 (H)  | Exposure level 1 (Half-tone) |           |         |
| 8    | 2.0 (H)  | Exposure level 2 (Half-tone) |           |         |
| 9    | 3.0 (H)  | Exposure level 3 (Half-tone) |           |         |
| 10   | 4.0 (H)  | Exposure level 4 (Half-tone) |           |         |
| 11   | 5.0 (H)  | Exposure level 5 (Half-tone) |           |         |

NOTE: Only the set value is changed and no printing is performed.



46-24


|                           |                                                                          |         |
|---------------------------|--------------------------------------------------------------------------|---------|
| <b>Purpose</b>            | Adjustment                                                               |         |
| <b>Function (Purpose)</b> | Used to adjust the scanner exposure level (in the super fine text mode). |         |
| <b>Item</b>               | Picture quality                                                          | Density |

**Operation/Procedure**

- 1) Select the number corresponding to one of the following adjustment items with 10-key. (Select one of 0 - 11.)
    - \* Normal mode (Image density adjustment level)
    - \* Normal mode (Image density adjustment level) (Half-tone mode)
    - \* Auto mode
    - \* Auto mode (Half-tone mode)
  - 2) Press [START] key.
  - 3) Enter the image density adjustment value with 10-key.
  - 4) Press [START] key or press [P] key.
- The adjustment value is set.

| Item |          |                              | Set range | Default |
|------|----------|------------------------------|-----------|---------|
| 0    | AUTO     | Auto                         | 0 - 99    | 50      |
| 1    | 1.0      | Exposure level 1             |           |         |
| 2    | 2.0      | Exposure level 2             |           |         |
| 3    | 3.0      | Exposure level 3             |           |         |
| 4    | 4.0      | Exposure level 4             |           |         |
| 5    | 5.0      | Exposure level 5             |           |         |
| 6    | AUTO (H) | Auto (Half-tone)             |           |         |
| 7    | 1.0 (H)  | Exposure level 1 (Half-tone) |           |         |
| 8    | 2.0 (H)  | Exposure level 2 (Half-tone) |           |         |
| 9    | 3.0 (H)  | Exposure level 3 (Half-tone) |           |         |
| 10   | 4.0 (H)  | Exposure level 4 (Half-tone) |           |         |
| 11   | 5.0 (H)  | Exposure level 5 (Half-tone) |           |         |

NOTE: Only the set value is changed and no printing is performed.



46-25


|                           |                                                                        |         |
|---------------------------|------------------------------------------------------------------------|---------|
| <b>Purpose</b>            | Adjustment                                                             |         |
| <b>Function (Purpose)</b> | Used to adjust the scanner exposure level in the ultra fine text mode. |         |
| <b>Item</b>               | Picture quality                                                        | Density |

**Operation/Procedure**

- 1) Select the number corresponding to one of the following adjustment items with 10-key. (Select one of 0 - 11.)
    - \* Normal mode (Image density adjustment level)
    - \* Normal mode (Image density adjustment level) (Half-tone mode)
    - \* Auto mode
    - \* Auto mode (Half-tone mode)
  - 2) Press [START] key.
  - 3) Enter the image density adjustment value with 10-key.
  - 4) Press [START] key or press [P] key.
- The adjustment value is set.

| Item |          |                              | Set range | Default |
|------|----------|------------------------------|-----------|---------|
| 0    | AUTO     | Auto                         | 0 - 99    | 50      |
| 1    | 1.0      | Exposure level 1             |           |         |
| 2    | 2.0      | Exposure level 2             |           |         |
| 3    | 3.0      | Exposure level 3             |           |         |
| 4    | 4.0      | Exposure level 4             |           |         |
| 5    | 5.0      | Exposure level 5             |           |         |
| 6    | AUTO (H) | Auto (Half-tone)             |           |         |
| 7    | 1.0 (H)  | Exposure level 1 (Half-tone) |           |         |
| 8    | 2.0 (H)  | Exposure level 2 (Half-tone) |           |         |
| 9    | 3.0 (H)  | Exposure level 3 (Half-tone) |           |         |
| 10   | 4.0 (H)  | Exposure level 4 (Half-tone) |           |         |
| 11   | 5.0 (H)  | Exposure level 5 (Half-tone) |           |         |

NOTE: Only the set value is changed and no printing is performed.



# 46-27

|                           |                                                                          |
|---------------------------|--------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                               |
| <b>Function (Purpose)</b> | Used to adjust the gamma (density gradient) of the network scanner mode. |
| <b>Item</b>               | Picture quality                                                          |

## Operation/Procedure

(Scanner mode selection)

- 1) Select the number corresponding to the scanner mode to be adjusted with 10-key. (Select one of 1 - 9.)
- 2) Press [START] key.

(Gamma adjustment)

- 1) Enter the gamma level with 10-key.
- 2) Press [START] key.

The greater the adjustment value is, the greater the gamma is, resulting in a higher contrast.

|    | Item          | Set range | Default |
|----|---------------|-----------|---------|
| 1  | OC_Fine.HT    | 0 - 127   | 64      |
| 2  | OC_SFine.HT   |           |         |
| 3  | OC_UFine.HT   |           |         |
| 4  | SPF1_Fine.HT  |           |         |
| 5  | SPF1_SFine.HT |           |         |
| 6  | SPF1_UFine.HT |           |         |
| 7  | SPF2_Fine.HT  |           |         |
| 8  | SPF2_SFine.HT |           |         |
| 9  | SPF2_UFine.HT |           |         |
| 10 | CIS_Fine.HT   |           |         |
| 11 | CIS_SFine.HT  |           |         |
| 12 | CIS_UFine.HT  |           |         |

### SIMULATION 46-27

GAMMA SETUP (SCANNER). SELECT 1-12, AND PRESS START.

|                |    |                 |    |                 |    |
|----------------|----|-----------------|----|-----------------|----|
| 1.OC_Fine.HT   | 64 | 2.OC_SFine.HT   | 64 | 3.OC_UFine.HT   | 64 |
| 4.SPF1_Fine.HT | 64 | 5.SPF1_SFine.HT | 64 | 6.SPF1_UFine.HT | 64 |
| 7.SPF2_Fine.HT | 64 | 8.SPF2_SFine.HT | 64 | 9.SPF2_UFine.HT | 64 |
| 10.CIS_Fine.HT | 64 | 11.CIS_SFine.HT | 64 | 12.CIS_UFine.HT | 64 |

# 46-31

|                           |                                            |
|---------------------------|--------------------------------------------|
| <b>Purpose</b>            | Adjustment                                 |
| <b>Function (Purpose)</b> | Used to adjust sharpness of the copy mode. |
| <b>Item</b>               | Picture quality                            |

## Operation/Procedure

(Copy mode selection)

- 1) Select the number corresponding to the copy mode to be adjusted with 10-key. (Select one of 1 - 16.)
- 2) Press [START] key.

(Sharpness adjustment)

- 1) Enter the sharpness level with 10-key.
- 2) Press [START] key.

The greater the adjustment value is, the greater the sharpness is.

|    | Item       | Set range | Default |
|----|------------|-----------|---------|
| 1  | OC_AE      | 1 - 5     | 3       |
| 2  | OC_CHARA   |           |         |
| 3  | OC_MIX     |           |         |
| 4  | OC_PHOTO   |           |         |
| 5  | SPF1_AE    |           |         |
| 6  | SPF1_CHARA |           |         |
| 7  | SPF1_MIX   |           |         |
| 8  | SPF1_PHOTO |           |         |
| 9  | SPF2_AE    |           |         |
| 10 | SPF2_CHARA |           |         |
| 11 | SPF2_MIX   |           |         |
| 12 | SPF2_PHOTO |           |         |
| 13 | CIS_AE     |           |         |
| 14 | CIS_CHARA  |           | 4       |
| 15 | CIS_MIX    |           | 3       |
| 16 | CIS_PHOTO  |           |         |

\* SPF1: DSPF front surface (CCD)

\* SPF2: DSPF back surface (CCD)

### SIMULATION 46-31

SHARPNESS LEVEL SETUP. SELECT 1-12, AND PRESS START.

|               |   |              |   |               |   |
|---------------|---|--------------|---|---------------|---|
| 1.OC_AE       | 3 | 2.OC_CHARA   | 3 | 3.OC_MIX      | 3 |
| 4.OC_PHOTO    | 3 | 5.SPF1_AE    | 3 | 6.SPF1_CHARA  | 3 |
| 7.SPF1_MIX    | 3 | 8.SPF1_PHOTO | 3 | 9.SPF2_AE     | 3 |
| 10.SPF2_CHARA | 3 | 11.SPF2_MIX  | 3 | 12.SPF2_PHOTO | 3 |
| 13.CIS_AE     | 3 | 14.CIS_CHARA | 4 | 15.CIS_MIX    | 3 |
| 16.CIS_PHOTO  | 3 |              |   |               |   |

Press [START] key.

Press [CUSTOM SETTINGS] key.

### SIMULATION 46-31

SHARPNESS LEVEL SETUP. INPUT VALUE 0-3, AND PRESS START.

1.OC\_AE

3

# 46-39

|                           |                                           |
|---------------------------|-------------------------------------------|
| <b>Purpose</b>            | Adjustment                                |
| <b>Function (Purpose)</b> | Used to adjust sharpness of the FAX mode. |
| <b>Item</b>               | Picture quality                           |

## Operation/Procedure

- 1) Enter the sharpness level with 10-key.
- 2) Press [START] key.

The greater the adjustment value is, the greater the sharpness is.

Default: 3 (Normal), 1 (Halftone)

**SIMULATION 46-39**  
FAX SHARPNESS LEVEL SETUP. SELECT 1-12, AND PRESS START.

|                   |                   |                  |
|-------------------|-------------------|------------------|
| 1:OC_NORMAL       | 2:OC_FINE         | 3:OC_FINE (H)    |
| 4:OC_SFINE        | 5:OC_SFINE (H)    | 6:OC_UFINE       |
| 7:OC_UFINE (H)    | 8:OC_600          | 9:OC_600 (H)     |
| 10:SPF1_NORMAL    | 11:SPF1_FINE      | 12:SPF1_FINE (H) |
| 13:SPF1_SFINE     | 14:SPF1_SFINE (H) | 15:SPF1_UFINE    |
| 16:SPF1_UFINE (H) | 17:SPF1_600       | 18:SPF1_600 (H)  |
| 19:SPF2_NORMAL    | 20:SPF2_FINE      | 21:SPF2_FINE (H) |
| 22:SPF2_SFINE     | 23:SPF2_SFINE (H) | 24:SPF2_UFINE    |
| 25:SPF2_UFINE (H) | 26:SPF2_600       | 27:SPF2_600 (H)  |
| 28:CIS_NORMAL     | 29:CIS_FINE       | 30:CIS_FINE (H)  |
| 31:CIS_SFINE      | 32:CIS_SFINE (H)  | 33:CIS_UFINE     |
| 34:CIS_UFINE (H)  | 35:CIS_600        | 36:CIS_600 (H)   |

Press [START] key.

Press [CUSTOM SETTINGS] key.

**SIMULATION 46-39**  
FAX SHARPNESS LEVEL SETUP. INPUT VALUE 1-3, AND PRESS START.

1:OC\_NORMAL

46-45

|                           |                                                            |
|---------------------------|------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                 |
| <b>Function (Purpose)</b> | Used to adjust the image density in the FAX mode (600dpi). |
| <b>Item</b>               | Picture quality                                            |

#### Operation/Procedure

- 1) Select the number corresponding to one of the following adjustment items with 10-key. (Select one of 0 - 11.)
    - \* Normal mode (Image density adjustment level)
    - \* Normal mode (Image density adjustment level) (Half-tone mode)
    - \* Auto mode
    - \* Auto mode (Half-tone mode)
  - 2) Press [START] key.
  - 3) Enter the image density adjustment value with 10-key.
  - 4) Press [START] key or press [P] key.
- The adjustment value is set.

|    | Item     |                              | Set range | Default |
|----|----------|------------------------------|-----------|---------|
| 0  | AUTO     | Auto                         | 0 - 99    | 50      |
| 1  | 1.0      | Exposure level 1             |           |         |
| 2  | 2.0      | Exposure level 2             |           |         |
| 3  | 3.0      | Exposure level 3             |           |         |
| 4  | 4.0      | Exposure level 4             |           |         |
| 5  | 5.0      | Exposure level 5             |           |         |
| 6  | AUTO (H) | Auto (Half-tone)             |           |         |
| 7  | 1.0 (H)  | Exposure level 1 (Half-tone) |           |         |
| 8  | 2.0 (H)  | Exposure level 2 (Half-tone) |           |         |
| 9  | 3.0 (H)  | Exposure level 3 (Half-tone) |           |         |
| 10 | 4.0 (H)  | Exposure level 4 (Half-tone) |           |         |
| 11 | 5.0 (H)  | Exposure level 5 (Half-tone) |           |         |

**SIMULATION 46-45**  
EXP.LEVEL SETUP FAX(600dpi). SELECT 0-14, AND PRESS START.

0. TRAY SELECT 1 1.PRINT START

|             |    |            |    |            |
|-------------|----|------------|----|------------|
| 2.EXP LEVEL | 1  |            |    |            |
| 3.AUTO      | 50 | 4.1.0      | 50 | 5.2.0      |
| 6.3.0       | 50 | 7.4.0      | 50 | 8.5.0      |
| 9.AUTO (H)  | 50 | 10.1.0 (H) | 50 | 11.2.0 (H) |
| 12.3.0 (H)  | 50 | 13.4.0 (H) | 50 | 14.5.0 (H) |

Select other than 0 - 2, and press [START] key.

Press [CUSTOM SETTINGS] key.

**SIMULATION 46-45**  
EXP.LEVEL SETUP FAX(600dpi), INPUT VALUE 0-99, AND PRESS START.

2.AUTO

Select 1, and press [START] key.

Press [START] key.

Press [CUSTOM SETTINGS] key, or terminate copying.

**SIMULATION 46-45**  
EXP.LEVEL SETUP FAX(600dpi). NOW PRINTING.

Select 0, and press [START] key.

Press [START] key, or press [CUSTOM SETTINGS] key.

**SIMULATION 46-45**  
EXP.LEVEL SETUP FAX(600dpi). SELECT 1-5, AND PRESS START. (FEED TRAY)

|          |          |          |          |
|----------|----------|----------|----------|
| 3. TRAY1 | 2. TRAY2 | 3. TRAY3 | 4. TRAY4 |
| 5: BPT   |          |          |          |

Select 2, and press [START] key.

Press [START] key, or press [CUSTOM SETTINGS] key.

**SIMULATION 46-45**  
EXP. LEVEL SETUP FAX(600dpi). SELECT 3-8, AND PRESS START. (EXP. LEVEL SELECT)

|            |            |            |
|------------|------------|------------|
| 3.AUTO     | 4.1.0      | 5.2.0      |
| 6.3.0      | 7.4.0      | 8.5.0      |
| 9.AUTO (H) | 10.1.0 (H) | 11.2.0 (H) |
| 12.3.0 (H) | 13.4.0 (H) | 14.5.0 (H) |

46-46


|                           |                                               |
|---------------------------|-----------------------------------------------|
| <b>Purpose</b>            | Adjustment                                    |
| <b>Function (Purpose)</b> | Used to adjust sharpness of the scanner mode. |
| <b>Item</b>               | Picture quality                               |

#### Operation/Procedure

- 1) Enter the sharpness level with 10-key.
- 2) Press [START] key.

The greater the adjustment value is, the greater the sharpness is.  
Set range: 1 - 3

Default: 3 (Normal), 1 (Halftone)



**48**

48-1

|                           |                                                                                                     |
|---------------------------|-----------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                          |
| <b>Function (Purpose)</b> | Used to adjust the copy magnification ratio (in the main scanning and the sub scanning directions). |
| <b>Section</b>            | Optical (Image scanning)                                                                            |
| <b>Item</b>               | Picture quality                                                                                     |

#### Operation/Procedure

(Adjustment mode selection)

- 1) Select the number corresponding to the copy mode to be adjusted with 10-key. (Select one of 3 - 7.)
- 2) Press [START] key.

|   | Item          | Set range                                                       | Default |
|---|---------------|-----------------------------------------------------------------|---------|
| 0 | TRAY SELECT   | Paper feed tray selection                                       | 50      |
| 1 | COPY START    | Copy START (Default)                                            |         |
| 2 | MAGNIFICATION | Print magnification ratio                                       |         |
| 3 | CCD (MAIN)    | SCAN main scanning magnification ratio adjustment (CCD)         |         |
| 4 | CCD (SUB)     | SCAN sub scanning magnification ratio adjustment (CCD)          |         |
| 5 | SPF (MAIN)    | SPF front surface magnification ratio adjustment (Main scan)    |         |
| 6 | SPF (SUB)     | SPF front surface magnification ratio adjustment (Sub scan)     |         |
| 7 | CIS (MAIN)    | SPF back surface magnification ratio adjustment (CIS main scan) |         |

(Copy magnification ratio adjustment)

- 1) Select the number corresponding to the copy magnification ratio adjustment mode to be adjusted with 10-key. (Select one of 3 - 7.)
- 2) Press [START] key.
- 3) Enter the copy magnification ratio adjustment value with 10-key.
- 4) Press [P] key or [START] key.

When the [START] key is pressed, copying is performed and the adjustment value is set simultaneously.

The copy magnification ratio in the sub scan direction can be adjusted by changing the scan speed (motor RPM).

|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |

The greater the value is, the greater the correction is. One step corresponds to 0.1% adjustment.

(Copy condition setting in this simulation)

\* To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray of the selected paper with 10-key. (Select one of 1 - 5.)
- 4) Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

When the total of the above set value (1 - 5) and 10 is entered, the mode is changed to the duplex mode.

\* The copy magnification ratio can be set with the following

- 1) Enter 2 with 10-key.
- 2) Press [START] key.
- 3) Enter the copy magnification ratio with 10-key.
- 4) Press [START] key.

|           |           |
|-----------|-----------|
| Set range | 25 - 400% |
|-----------|-----------|

NOTE: When [P] key is pressed after entering the adjustment value, the adjustment value is set. When [START] key is pressed instead, the adjustment value is set and copying is performed.





Front frame void area = 3.5mm      Rear frame void area = 3.5mm  
If, as shown above, the front and the rear void areas are not even,  
use SIM 50-5 to adjust the image off-center position.

|                              | Item              | Content                                            | Set range | Default |
|------------------------------|-------------------|----------------------------------------------------|-----------|---------|
| 0                            | TRAY SELECT       | Paper feed tray selection                          | 1 - 6     | —       |
| 1                            | COPY START        | Copy START (Default)                               | —         | —       |
| 2                            | MAGNIFICATION     | Print magnification ratio                          | 25 - 400% | —       |
| (Lead edge adjustment value) |                   |                                                    |           |         |
| 3                            | RRCA              | Document scan start position                       | 0 - 99    | 50      |
| 4                            | RRCB              | Resist roller clutch ON timing adjustment value    |           |         |
| 10                           | SIDE2 ADJ.        | Correction value for RRCB when refereeing from ADU | 1 - 99    | 50      |
| (Image loss set value)       |                   |                                                    |           |         |
| 5                            | LEAD              | Lead edge image loss set value                     | 0 - 99    | 15      |
| 6                            | SIDE              | Side image loss set value                          |           | 20      |
| (Void set value)             |                   |                                                    |           |         |
| 7                            | LEAD_EDGE (DENA)  | Lead edge void set value                           | 0 - 99    | 35      |
| 8                            | TRAIL_EDGE (DENB) | Rear edge void adjustment value                    |           |         |
| 9                            | FRONT/REAR        | Front/Rear void adjustment value                   |           |         |

NOTE: When [P] is pressed after entering an adjustment value, the adjustment value is set. When [START] key is pressed instead, the adjustment value is set and copying is performed.)

|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |

(Copy condition in this simulation)

\* To select paper (paper feed tray), perform the following procedures.


- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray of the target paper with 10-key.
- 4) Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

\* To set the magnification ratio, perform the following procedure.

- 1) Enter 2 with 10-key.
- 2) Press [START] key.
- 3) Enter the copy magnification ratio with 10-key.
- 4) Press [START] key.

|           |              |
|-----------|--------------|
| Set range | 25 - 400 (%) |
|-----------|--------------|



|                           |                                                                                                                                                                                                    |                |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------|
| 50-2                      |                                                                                                                                                                                                    |                |
| <b>Purpose</b>            | Adjustment                                                                                                                                                                                         |                |
| <b>Function (Purpose)</b> | Used to adjust the document scan position, the image print position, and the void area (image loss). (Simple adjustment) (This adjustment is the simple method of SIM 50-1.) (Document table mode) |                |
| <b>Item</b>               | Picture quality                                                                                                                                                                                    | Image position |

### Operation/Procedure

(Lead edge image loss/void area adjustment)

- 1) Set the RRGV value of SIM 50-1 to 80 - 99.
- 2) Set the lead edge image loss adjustment value (LEAD EDG) and the paper lead edge void adjustment value (DENA) to the values specified below.  
  
(Standard set value) Lead edge image loss: 1.5mm  
Paper lead edge void: 3.5mm (DENA: 35)  
  
\* Set the adjustment value of LEAD to 15. (Enter 15 as the adjustment value of LEAD and press [P] key.)  
  
\* Set the adjustment value of DENA to 35. (Enter 35 as the adjustment value of DENA and press [P] key.)
- 3) Set the adjustment value of L1 to 0. (Enter 0 as the adjustment value of L1, and press [P] key.)
- 4) Set the adjustment value of L2 to 0. (Enter 0 as the adjustment value of L2, and press [P] key.)



- If, as shown above, the front and the rear void areas are not even, use SIM 50-5 to adjust the image off-center position.

|                           |                                                                                                                                                                                           |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                                                                                                                |
| <b>Function (Purpose)</b> | Used to adjust the print image position and the void area (image loss) on print paper. (Adjustment as the print engine) (This adjustment is reflected on all the FAX/printer/copy modes.) |
| <b>Section</b>            |                                                                                                                                                                                           |
| <b>Item</b>               | Picture quality                                                                                                                                                                           |

**Operation/Procedure**

(Print image off-center position adjustment)

- 1) Enter the number corresponding to the paper feed tray to be adjusted with 10-key. (Select one of 10 - 16.) (Table 1)
- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.
- 4) Press [P] key or [START] key. When [START] key is pressed, the adjustment value is set and printing is performed. (Table 2)  
Check the off-center of the self-print pattern of print-out.  
(Shift for the adjustment value change: 0.1mm/step)

The greater the adjustment value is, the more the print image is shifted to the front.

(Lead edge void area adjustment)

- 1) Set the lead edge void adjustment value (DENA) as specified below.  
(Standard set value) Paper lead edge void: 3.5mm (DENA: 35)  
\* Set the adjustment value of DENA to 35. Enter 35 as the adjustment value of DENA, and press [P] key.
- 2) Check the lead edge void area on the self print pattern.  
(Enter 1 and press [START] key.)
- 3) If the adjustment result is not satisfactory, perform the following procedures.  
\* If the lead edge void area is not 3.5mm:  
Change the adjustment value of RRCB and perform the adjustment. (Change the adjustment value of RRCB and press [START] key.)  
(Shift for the adjustment value change: 0.1mm/step)

(Front/rear frame direction void area adjustment)

Adjust so that the total of the front/rear direction void areas is 7.0mm. (Change the adjustment values of FRONT/REAR, and press [START] key.)

Front frame void area = 3.5mm      Rear frame void area = 3.5mm

(Paper resist adjustment)

- 1) Enter the number corresponding to the paper feed tray to be adjusted with 10-key. (Select one of 3 - 9.) (Table 1)
- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.
- 4) Press [P] key or [START] key. When [START] key is pressed, the adjustment value is set and printing is performed. (Table 2)

If the relative positions of paper and print images vary or a paper jam occurs, change the adjustment value.

(Print condition setting in this simulation)

\* To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray to be used with 10-key. (Select one of 1 - 5.) (Table 3)
- 4) Press [START] key. (The paper feed tray is selected.)

When the total of the above set value (1 - 5) and 10 is entered, the mode is changed to the duplex print mode.

NOTE: When [P] key is pressed after entering the adjustment value in this simulation, the adjustment value is set. When [START] key is pressed instead, the adjustment value is set and copying is performed.

(Table 1)


| Item                              |                   |                                                    | Set range | Default  |          |
|-----------------------------------|-------------------|----------------------------------------------------|-----------|----------|----------|
|                                   |                   |                                                    |           | AR-M355N | AR-M455N |
| 0                                 | TRAY SELECT       | Paper feed tray selection (1 - 6)                  | —         | —        |          |
| 1                                 | PRINT START       | Print start (Default)                              | —         | —        |          |
| (Lead edge adjustment value)      |                   |                                                    |           |          |          |
| 2                                 | RRCB              | Resist roller clutch ON timing adjustment value    | 0 - 99    | 50       |          |
| 3                                 | SIDE2 ADJ.        | Correction value for RRCB when refereeing from ADU |           | 50       |          |
| (Resist adjustment value)         |                   |                                                    |           |          |          |
| 4                                 | T1                | Tray 1 adjustment                                  | 0 - 99    | 65       | 60       |
| 5                                 | T2                | Tray 2 adjustment                                  |           | 55       | 50       |
| 6                                 | DESK              | Tray 4 adjustment                                  |           | 55       | 50       |
| 7                                 | BPT               | Manual feed tray adjustment                        |           | 60       | 55       |
| 8                                 | ADU               | Adjustment when paper is fed again from ADU        |           | 55       | 50       |
| (Off-center set value) Self print |                   |                                                    |           |          |          |
| 9                                 | T1                | Tray 1 adjustment                                  | 0 - 99    | 50       |          |
| 10                                | T2                | Tray 2 adjustment                                  |           |          |          |
| 11                                | T3                | Tray 3 adjustment                                  |           |          |          |
| 12                                | T4                | Tray 4 adjustment                                  |           |          |          |
| 13                                | BPT               | Manual feed tray adjustment                        |           |          |          |
| 14                                | ADU               | Adjustment when paper is fed again from ADU        |           |          |          |
| (Void set value)                  |                   |                                                    |           |          |          |
| 15                                | LEAD_EDGE (DENA)  | Lead edge void set value                           | 0 - 99    | 35       |          |
| 16                                | TRAIL_EDGE (DENB) | Rear edge void adjustment value                    |           |          |          |
| 17                                | FRONT/REAR        | Front/Rear void adjustment value                   |           |          |          |

(Table 2)

|                |             |               |
|----------------|-------------|---------------|
| Normal display |             | NOW PRINTING. |
| ERROR display  | Door open   | DOOR OPEN.    |
|                | Jam         | JAM           |
|                | Paper empty | PAPER EMPTY.  |

(Table 3)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |



50-6

|                           |                                                                                                                                                                                        |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                                                                                                             |
| <b>Function (Purpose)</b> | Used to adjust the copy image position and void area (image loss) on print paper in the copy mode. (The similar adjustment can be performed with SIM 50-7 (simple method).) (SPF mode) |
| <b>Section</b>            |                                                                                                                                                                                        |
| <b>Item</b>               | Picture quality                                                                                                                                                                        |

#### Operation/Procedure

(Lead edge image loss adjustment) (Table 1)

- Set the front and back surface image loss adjustment values (LEAD EDGE) as specified below:

(Standard set value) Lead edge image loss: 1.5mm (LEAD: 1.5) Paper lead edge: 3.5mm (DENA: 35)

\* Set the adjustment value of LEAD to 15. (Enter 15 as the adjustment value of LEAD EDGE, and press [P] key.)

- Make a duplex copy at 100% with the SPF, and check that the lead edge (image loss) is 1.5mm either on the front surface and the back surface. (Select the duplex mode in the paper selection mode of SIM 50-6.) (Table 3) (Enter 100 as the copy magnification ratio set value (MAGNIFICATION), and press [START] key.)

If the adjustment result is not satisfactory, perform the following procedures:

- Change the adjustment values of SIDE1 and SIDE2, and perform the adjustment. (Change the adjustment values of SIDE1 and SIDE2, and press [START] key.)

SIDE1: SPF front surface document lead edge scan position adjustment value

SIDE2: SPF back surface document lead edge scan position adjustment value

(Shift for the adjustment value change: 0.1mm/step)

(The image scan start timing is determined with the detection timing of the document lead edge by the detector SPPD4.)

Repeat procedures 2) and 3) until a satisfactory result is obtained.

(Rear edge image loss adjustment)

- Use the SPF at 100% to make a duplex copy, and check that the rear edge image loss is 1.5mm on the front and the back surfaces. (Select the duplex mode in the paper selection mode of SIM 50-6.) (Enter 100 as the copy magnification ratio set value (MAGNIFICATION), and press [START] key.)

If the adjustment value is not satisfactory, perform the following procedure.

- Change the adjustment value of TRAIL EDGE. Change the adjustment value of TRAIL EDGE, and press [START] key.

Repeat the above procedures until a satisfactory result is obtained.

(Front/rear frame direction image loss adjustment)

Set the adjustment value of the front surface and the back surface (FRONT/REAR) to 20. (Enter 20 as the adjustment value of FRONT/REAR, and press [P] key.)

When the adjustment value is changed, the image position is shifted in the front/rear frame direction.

NOTE: When [P] key is pressed after entering the adjustment value, the adjustment value is set. When [START] key is pressed instead, the adjustment value is set and copying is performed. (Table 2)

(Copy condition setting in this simulation)

\* To select paper (paper feed tray), perform the following procedures.

- Enter 0 with 10-key.
- Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- Enter the number corresponding to the paper feed tray to be used with 10-key. (Table 3)
- Press [START] key. (The paper feed tray is selected.)

\* To set the copy magnification ratio, perform the following procedure.

- Enter 2 with 10-key.
- Press [START] key.
- Enter the copy magnification ratio with 10-key.
- Press [START] key.

|           |              |
|-----------|--------------|
| Set range | 25 - 200 (%) |
|-----------|--------------|

(Table 1)

| Item                           |               |                                                             | Set range | Default |
|--------------------------------|---------------|-------------------------------------------------------------|-----------|---------|
| 0                              | TRAY SELECT   | Paper feed tray selection                                   | 1 - 6     | —       |
| 1                              | COPY START    | Copy START (Default)                                        | —         | —       |
| 2                              | MAGNIFICATION | Print magnification ratio                                   | 25 - 200% | —       |
| (Lead edge adjustment value)   |               |                                                             |           |         |
| 3                              | SIDE1         | Front surface document scan start position adjustment value | 0 - 99    | 50      |
| 4                              | SIDE2         | Back surface document scan start position adjustment value  |           |         |
| (Image loss set value: SIDE 1) |               |                                                             |           |         |
| 5                              | LEAD_EDGE     | Front surface lead edge image loss set value                | 0 - 99    | 15      |
| 6                              | FRONT_REAR    | Front surface side edge image loss set value                |           | 20      |
| 7                              | TRAIL_EDGE    | Front surface rear edge image loss set value                | 0 - 20    | 0       |

| Item                           |            |                                             | Set range | Default |
|--------------------------------|------------|---------------------------------------------|-----------|---------|
| (Image loss set value: SIDE 2) |            |                                             |           |         |
| 8                              | LEAD_EDGE  | Back surface lead edge image loss set value | 0 - 99    | 15      |
| 9                              | FRONT/REAR | Back surface side edge image loss set value |           | 20      |
| 10                             | TRAIL_EDGE | Back surface rear edge image loss set value | 0 - 20    | 0       |


(Table 2)

|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |

(Table 3)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

When the total of the above set value and 10 is entered, the mode is changed to the duplex mode (DD), and a duplex copy is made.



50-7

|                           |                                                                                                                                                                        |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                                                                                             |
| <b>Function (Purpose)</b> | Used to adjust the copy image position and void area (image loss) on print paper in the copy mode. (The similar adjustment can be performed with SIM 50-6.) (SPF mode) |
| <b>Section</b>            |                                                                                                                                                                        |
| <b>Item</b>               | Picture quality                                                                                                                                                        |

#### Operation/Procedure

(Lead edge image loss adjustment)

- 1) Set the front and back surface image loss adjustment values (LEAD EDGE) as specified below:

(Standard set value) Lead edge image loss: 1.5mm (LEAD: 1.5) Paper lead edge void: 3.5mm (DENA: 35)

\* Set the adjustment value of LEAD to 15. (Enter 15 as the adjustment value of LEAD EDGE, and press [P] key.)

- 2) Set the adjustment value of L4 to 0. (Enter 0 as the adjustment value of L4, and press [P] key.)
- 3) Set the adjustment value of L5 to 0. (Enter 0 as the adjustment value of L5, and press [P] key.)
- 4) Make a copy at 200% with the SPF, and calculate the values of L4 and L5. (Enter 200 as the set value of the copy magnification ratio set value (MAGNIFICATION) and press [START] key.)

L4 = Distance (mm) from the image lead edge position to the scale of 10mm x 10

L5 = Distance (mm) from the image lead edge position to the paper lead edge x 10

- 5) Enter the above values as the set values of L4 and L5. (Enter the adjustment values of L4 and L5, and press [P] key.)

(The image scan start timing is determined with the detection timing of the document lead edge by the detector SPPD4.)

If the adjustment result is not satisfactory, perform the above procedures again or adjust with SIM 50-1.

NOTE: If the adjustment result of the above procedures is not satisfactory, though the adjustment value is changed individually, the adjustment cannot be completed normally.

Repeat procedures 2) - 6) until a satisfactory result is obtained.

(Rear edge image loss adjustment)

Adjust so that the rear edge image loss is 3.5mm. (Change the adjustment value of TRAIL EDGE, and press [START] key.)

(Front/rear frame direction image loss adjustment)

Set the adjustment value of SIDE to 20. (Enter 20 as the adjustment value of SIDE, and press [P] key.)

When the adjustment value is changed, the image position is shifted in the front/rear frame direction.

NOTE: When [P] key is pressed after entering the adjustment value, the adjustment value is set. When [START] key is pressed instead, the adjustment value is set and copying is performed. (Table 2)

(Copy condition setting in this simulation)

\* To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray to be used with 10-key. (Table 3)
- 4) Press [START] key. (The paper feed tray is selected.)

\* To set the copy magnification ratio, perform the following procedure.

- 1) Enter 2 with 10-key.
- 2) Press [START] key.

- 3) Enter the copy magnification ratio with 10-key.
- 4) Press [START] key.

|           |              |
|-----------|--------------|
| Set range | 25 - 200 (%) |
|-----------|--------------|

(Table 1)

| Item                           |               |                                                                                  | Set range | Default |
|--------------------------------|---------------|----------------------------------------------------------------------------------|-----------|---------|
| 0                              | TRAY SELECT   | Paper feed tray selection (1 - 6)                                                | —         | —       |
| 1                              | COPY START    | Copy START (Default)                                                             | —         | —       |
| 2                              | MAGNIFICATION | Print magnification ratio (25 - 200%)                                            | —         | —       |
| (Lead edge adjustment value)   |               |                                                                                  |           |         |
| 3                              | L4            | Distance from the front surface image lead edge to the scale of 10mm (SPF: 200%) | 0 - 999   | —       |
| 4                              | L5            | Distance from the back surface image lead edge to the scale of 10mm (SPF: 200%)  |           | —       |
| (Image loss set value: SIDE 1) |               |                                                                                  |           |         |
| 5                              | LEAD_EDGE     | Front surface lead edge image loss set value                                     | 0 - 99    | 15      |
| 6                              | FRONT_REAR    | Front surface side edge image loss set value                                     |           | 20      |
| 7                              | TRAIL_EDGE    | Front surface rear edge image loss set value                                     | 0 - 20    | 0       |
| (Image loss set value: SIDE 2) |               |                                                                                  |           |         |
| 8                              | LEAD_EDGE     | Back surface lead edge image loss set value                                      | 0 - 99    | 15      |
| 9                              | FRONT/REAR    | Back surface side edge image loss set value                                      |           | 20      |
| 10                             | TRAIL_EDGE    | Back surface rear edge image loss set value                                      | 0 - 20    | 0       |


(Table 2)

|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |

(Table 3)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

When the total of the above set value and 10 is entered, the mode is changed to the duplex mode (DD), and a duplex copy is made.



50-10

|                           |                                                                                                        |
|---------------------------|--------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                             |
| <b>Function (Purpose)</b> | Used to adjust the print image off-center position. (Adjusted separately for each paper feed section.) |
| <b>Item</b>               | Picture quality Image position                                                                         |

#### Operation/Procedure

(Print image off-center position adjustment)

NOTE: This simulation cannot provide an accurate adjustment. Do not use.

- 1) Enter the number corresponding to the number of the paper feed tray to be adjusted with 10-key. (Select one of 3 - 9.)

| Item                          |               |                                             | Set range | Default |
|-------------------------------|---------------|---------------------------------------------|-----------|---------|
| 0                             | TRAY SELECT   | Paper feed tray selection                   | 1 - 6     | —       |
| 1                             | COPY START    | Copy START (Default)                        | —         | —       |
| 2                             | MAGNIFICATION | Print magnification ratio                   | 25 - 400% | 100     |
| (Off-center adjustment value) |               |                                             |           |         |
| 3                             | TRAY1         | Tray 1 adjustment                           | 0 - 99    | 50      |
| 4                             | TRAY2         | Tray 2 adjustment                           |           |         |
| 5                             | TRAY3         | Tray 3 adjustment                           |           |         |
| 6                             | TRAY4         | Tray 4 adjustment                           |           |         |
| 7                             | BPT           | Manual feed tray adjustment                 |           |         |
| 8                             | ADU           | Adjustment when paper is fed again from ADU |           |         |

- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.
- 4) Press [P] key or [START] key. When [START] key is pressed, the adjustment value set and copying is performed.

|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |

(Image off-center adjustment)

- 1) Enter 1 with 10-key.
- 2) Press [START] key. The adjustment pattern is printed.
- 3) Check the off-center of the printed image.  
(UNIT: 0.1mm/step When the adjustment value is increased, the print image is shifted to the front direction.)

NOTE: This adjustment can be performed with SIM 50-5.

(Copy condition setting in this simulation)

\* To select paper (paper feed tray), perform the following procedures.

- 1) Enter 0 with 10-key.
- 2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)
- 3) Enter the number corresponding to the paper feed tray to be used with 10-key. (Select one of 1 - 5)
- 4) Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |


When the total of the above set value (1 - 5) and 10 is entered, the mode is changed to the duplex print mode.

\* To set the copy magnification ratio, perform the following procedure.

- 1) Enter 2 with 10-key.
- 2) Press [START] key.
- 3) Enter the copy magnification ratio with 10-key.
- 4) Press [START] key.

|           |              |
|-----------|--------------|
| Set range | 25 - 400 (%) |
|-----------|--------------|

NOTE: When [P] key is pressed after entering the adjustment value in this simulation, the adjustment value is set. When [START] key is pressed, the adjustment value is set and copying is performed.



#### 50-12

| Purpose                   | Adjustment                                                                                   |
|---------------------------|----------------------------------------------------------------------------------------------|
| <b>Function (Purpose)</b> | Used to adjust the scan image off-center position. (Adjusted separately for each scan mode.) |
| <b>Section</b>            |                                                                                              |
| <b>Item</b>               | Picture quality Image position                                                               |

#### Operation/Procedure

(Select the scan mode to be adjusted.)

- 1) Enter the number corresponding to the scan mode to be adjusted with 10-key. (Select one of 3 - 5.)

| Item                      |               |                              | Set range | Default |
|---------------------------|---------------|------------------------------|-----------|---------|
| 0                         | TRAY SELECT   | Paper feed tray selection    | 1 - 5     | —       |
| 1                         | COPY START    | Copy START (Default)         | —         | —       |
| 2                         | MAGNIFICATION | Print magnification ratio    | 25 - 400% | 100     |
| (Resist adjustment value) |               |                              |           |         |
| 3                         | PLATEN        | OC mode adjustment           | 0 - 99    | 50      |
| 4                         | SPF SIDE1     | SPF front surface adjustment |           |         |
| 5                         | SPF SIDE2     | SPF back surface adjustment  |           |         |

- 2) Press [START] key.



(Scan off-center position adjustment)

1) Enter the scan image position adjustment value with 10-key.

2) Press [P] key or [START] key.

When [START] key is pressed, the adjustment value is set and copying is performed.

|                |             |              |
|----------------|-------------|--------------|
| Normal display |             | NOW COPYING. |
| ERROR display  | Door open   | DOOR OPEN.   |
|                | Jam         | JAM          |
|                | Paper empty | PAPER EMPTY. |

Check the off-center of the printed image.

Repeat the above procedures until a satisfactory result is obtained.

(UNIT: 0.1mm/step When the adjustment value is increased, the print image is shifted to the front direction.)

(Copy condition setting in this simulation)

\* To select paper (paper feed tray), perform the following procedures.

1) Enter 0 with 10-key.

2) Press [START] key. (The mode is changed to the paper feed tray selection mode.)

3) Enter the number corresponding to the paper feed tray to be used with 10-key. (Select one of 1 - 6)

4) Press [START] key. (The paper feed tray is selected.)

|   |       |             |
|---|-------|-------------|
| 1 | TRAY1 | TRAY1       |
| 2 | TRAY2 | TRAY2       |
| 3 | TRAY3 | TRAY3       |
| 4 | TRAY4 | TRAY4       |
| 5 | BPT   | Manual feed |

When the total of the above set value (1 - 5) and 10 is entered, the mode is changed to the duplex print mode.

\* To set the copy magnification ratio, perform the following procedure.

1) Enter 2 with 10-key.


2) Press [START] key.

3) Enter the copy magnification ratio with 10-key.

4) Press [START] key.

|           |              |
|-----------|--------------|
| Set range | 25 - 400 (%) |
|-----------|--------------|

NOTE: When [P] key is pressed after entering the adjustment value in this simulation, the adjustment value is set. When [START] key is pressed, the adjustment value is set and copying is performed.



50-27

|                           |                                                                       |
|---------------------------|-----------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                            |
| <b>Function (Purpose)</b> | Used to adjust the image loss of the scan image in the FAX/scan mode. |
| <b>Item</b>               | Picture quality                                                       |

#### Operation/Procedure

(Select the scan mode to be adjusted.)

1) Enter the number corresponding to the adjustment item with 10-key.

2) Press [START] key.

3) Enter the adjustment value with 10-key.


4) Press [START] key.

(Shift for the adjustment value change: 1.0mm/step)

| Item     |                  | Set range            | Default    |
|----------|------------------|----------------------|------------|
| FAX send |                  |                      |            |
| 1        | OC (LEAD_EDGE)   | 0 - 10<br>(Unit 1mm) | 3<br>(3mm) |
| 2        | OC (FRONT/REAR)  |                      |            |
| 3        | OC (TRAIL_EDGE)  |                      |            |
| 4        | SPF (LEAD_EDGE)  |                      |            |
| 5        | SPF (FRONT/REAR) |                      |            |
| 6        | SPF (TRAIL_EDGE) |                      |            |
| 7        | CIS (LEAD_EDGE)  |                      |            |
| 8        | CIS (FRONT/REAR) |                      |            |
| 9        | CIS (TRAIL_EDGE) |                      |            |







## 53

### 53-6

|                           |                                                |
|---------------------------|------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                     |
| <b>Function (Purpose)</b> | Used to adjust the DSPF width detection level. |
| <b>Section</b>            |                                                |
| <b>Item</b>               | Operation                                      |

#### Operation/Procedure

- Set the SPF paper feed guide to the max. position.
  - Select "MAX. POSITION" with 10-key.
  - Press [START] key.  
The max. width detection level is recognized.
  - Press [CSUTOM SETTING] key.
  - Set the SPF paper feed guide to A4R size position.
  - Select POSITION 1 with 10-key.
  - Press [START] key.  
The A4R width detection level is recognized.
  - Press [CSUTOM SETTING] key.
  - Set the SPF paper feed guide to A5R size position.
  - Select POSITION 2 with 10-key.
  - Press [START] key.  
The A5R width detection level is recognized.
  - Press [CSUTOM SETTING] key.
  - Set the SPF paper feed guide to the min. position.
  - Select "MIN. POSITION" with 10-key.
  - Press [START] key.  
The min. width detection level is recognized.
- If the above procedures are not completed normally, ERROR is displayed. When completed normally, COMPLETE is displayed.

### 53-7


|                           |                                                              |
|---------------------------|--------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment/Setup/Operation data output/Check (Display/Print) |
| <b>Function (Purpose)</b> | Used to enter the SPF width detection adjustment value.      |
| <b>Section</b>            | DSPF                                                         |
| <b>Item</b>               | Operation                                                    |

#### Operation/Procedure

- Enter the number corresponding to the set item with 10-key.

|   | Item          | Set range             | Default  |
|---|---------------|-----------------------|----------|
| 1 | MAX. POSITION | Max. width            | 0 - 1023 |
| 2 | POSITION 1    | Adjustment position 1 | 66       |
| 3 | POSITION 2    | Adjustment position 2 | 456      |
| 4 | MIN. POSITION | Min. width            | 713      |
|   |               |                       | 791      |

- Press [START] key.
- Enter the set value with 10key.
- Press [START] key.



53-8

|                           |                                                                                                                            |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                                                                 |
| <b>Function (Purpose)</b> | Used to adjust the document scan start position.<br>(Used to adjust the scanner scan position in the SPF mode front scan.) |

**Operation/Procedure**

(Automatic adjustment)


- 1) Select 1 or 2 with 10-key.
- 2) Press [START] key.

(Manual feed adjustment)

- 1) Enter the adjustment value with 10key.
- 2) Press [START] key.

When an adjustment error occurs, the trouble code (E7-17) is displayed simultaneously with "COMPLETED."

| Item |        |                                                      | Set range                     | Default |
|------|--------|------------------------------------------------------|-------------------------------|---------|
| 1    | AUTO   | Automatic adjustment                                 | —                             | —       |
| 2    | MANUAL | Manual feed adjustment<br>(Direct entry of a number) | 1 - 70<br>(1 count:<br>0.1mm) | 32      |



55


55-1

|                           |                                                                            |
|---------------------------|----------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                    |
| <b>Function (Purpose)</b> | Used to set the specifications of the engine control operations. (PCU PWB) |
| <b>Section</b>            |                                                                            |
| <b>Item</b>               | Operation      Specifications                                              |

**Operation/Procedure**

This simulation is used to change and check the engine soft SW. Set this setting to the default.

There is no need to change this setting in the market.




55-2

|                           |                                                                                         |
|---------------------------|-----------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                 |
| <b>Function (Purpose)</b> | Used to set the specifications of the scanner control operations. (Scanner control PWB) |
| <b>Section</b>            |                                                                                         |
| <b>Item</b>               | Operation      Specifications                                                           |

**Operation/Procedure**

This simulation is used to change and check the scanner soft SW. Set this setting to the default.

There is no need to change this setting in the market.




## 55-3

|                           |                                                                                |
|---------------------------|--------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                        |
| <b>Function (Purpose)</b> | Used to set the specifications of the controller operations. (MFP control PWB) |
| <b>Section</b>            |                                                                                |
| <b>Item</b>               | Operation Specifications                                                       |

**Operation/Procedure**

This simulation is used to change and check the controller soft SW. Set this setting to the default.

There is no need to change this setting in the market.



## 56

## 56-1

|                           |                                                                     |
|---------------------------|---------------------------------------------------------------------|
| <b>Purpose</b>            | Data transfer                                                       |
| <b>Function (Purpose)</b> | Used to transfer the MFP controller data. (Used to repair the PWB.) |
| <b>Section</b>            | MFP controller                                                      |
| <b>Item</b>               | Data transfer                                                       |

**Operation/Procedure**

- 1) Select the number corresponding to the data transfer mode with 10-key.

|   |                                            |                                                                                                                                                                                       |
|---|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 | ALL (EEPROM, SRAM, FlashROM) → HDD         | All the contents of memory are transferred to HDD. (Similar to execution of items 3 and 5.)                                                                                           |
| 2 | HDD → ALL (EEPROM, SRAM, FlashROM)         | The HDD contents are transferred to all the memories. (Similar to execution of items 4 and 6.)                                                                                        |
| 3 | EEPROM → HDD                               | Transfer from EEPROM to HDD                                                                                                                                                           |
| 4 | HDD → EEPROM                               | Transfer from HDD to EEPROM                                                                                                                                                           |
| 5 | SRAM (+ FAX Memory, + Option Memory) → HDD | Transfer from SRAM to HDD. When, however, the FAX memory or an option memory (for FAX memory) * is installed, the contents of the Fax memory are also transferred to HDD.             |
| 6 | HDD → SRAM (+ FAX Memory, + Option Memory) | Transfer from HDD to SRAM. When, however, the FAX memory or an option memory (for FAX memory) * is installed, the contents HDD are transferred to the FAX memory as well as the SRAM. |
| 7 | FontROM → HDD                              | Transfer from the font ROM to HDD                                                                                                                                                     |

\*: When Flash ROM or OP\_Flash ROM is not installed, transfer is not made.

- 2) Press [START] key.

- 3) The confirmation menu is opened to confirm YES/NO of data transfer. Select one.

|   |     |                                |
|---|-----|--------------------------------|
| 1 | YES | Data transfer is executed.     |
| 2 | NO  | Data transfer is not executed. |


- 4) Press [START] key.

After completion of transfer, the transfer result is displayed.

If there is no error, the machine is automatically reset after completion of data transfer.

If there is an error, "NG" is displayed. (The machine is not reset.)

When restoring from HDD, fit the configurations of the Flash ROM and the optional Flash ROM at back-up.



## 60

## 60-1

|                           |                                                               |
|---------------------------|---------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                          |
| <b>Function (Purpose)</b> | Used to check the MFP control (DRAM) operations (read/write). |
| <b>Section</b>            | ICU                                                           |
| <b>Item</b>               | Operation                                                     |

**Operation/Procedure**


- 1) Enter the number corresponding to the memory to be checked with 10-key.

|   |           |                   |
|---|-----------|-------------------|
| 1 | MFP DRAM  | ERD image memory  |
| 2 | ASIC DRAM | ASIC image memory |

- 2) Press [START] key.

The memory read/write operation is started.

After starting the operation, "NOW CHECKING" is displayed during checking. When read/write is normally completed, "OK" is displayed. If an error occurs, "NG" is displayed.



## 61


### 61-1

|                           |                                                                |
|---------------------------|----------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                           |
| <b>Function (Purpose)</b> | Used to check the operation of the scanner (write) unit (LSU). |
| <b>Section</b>            | Scanner (write) unit (LSU)                                     |
| <b>Item</b>               | Operation                                                      |

#### Operation/Procedure

Used to check if the LSU delivers output of the sync signal (HSYNC/) or not.

"NOW CHECKING" is displayed during checking. When the test is normally completed, "OK" is displayed. If an error occurs, "NG" is displayed.



### 61-2

|                           |                                                                   |
|---------------------------|-------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                        |
| <b>Function (Purpose)</b> | Used to adjust the laser power (absolute value) in the copy mode. |
| <b>Section</b>            | Scanner (write) unit (LSU)                                        |
| <b>Item</b>               | Operation                                                         |


#### Operation/Procedure

- 1) Select the number corresponding to the adjustment mode with 10-key.

| Item |        |                    | Set range | Default  |          |
|------|--------|--------------------|-----------|----------|----------|
|      |        |                    |           | AR-M355N | AR-M455N |
| 1    | AE     | Auto exposure mode | 67 - 150  | 86       | 110      |
| 2    | CHARA. | Text mode          |           | 86       | 110      |
| 3    | MIX    | Text/Photo mode    |           | 86       | 110      |
| 4    | PHOTO  | Photo mode         |           | 86       | 110      |

- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.
- 4) Enter [START] key.

NOTE: Be sure to set the default value. If not, a trouble may occur in the LSU.



### 61-3

|                           |                                                                  |
|---------------------------|------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                       |
| <b>Function (Purpose)</b> | Used to adjust the laser power (absolute value) in the FAX mode. |
| <b>Section</b>            | Scanner (write) unit (LSU)                                       |
| <b>Item</b>               | Operation                                                        |


#### Operation/Procedure

- 1) Select the number corresponding to the adjustment mode with 10-key.
- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.

|           |                                 |
|-----------|---------------------------------|
| Set range | 67 - 150                        |
| Default   | 86 (AR-M355N)<br>110 (AR-M455N) |

- 4) Enter [START] key.

NOTE: Be sure to set the default value. If not, a trouble may occur in the LSU.



61-4

|                           |                                                                      |
|---------------------------|----------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                           |
| <b>Function (Purpose)</b> | Used to adjust the laser power (absolute value) in the printer mode. |
| <b>Section</b>            | Scanner (write) unit (LSU)                                           |
| <b>Item</b>               | Operation                                                            |


#### Operation/Procedure

- 1) Select the number corresponding to the adjustment mode with 10-key.
- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.

|           |                                 |
|-----------|---------------------------------|
| Set range | 67-150                          |
| Default   | 76 (AR-M355N)<br>100 (AR-M455N) |

- 4) Enter [START] key.

NOTE: Be sure to set the default value. If not, a trouble may occur in the LSU.



62

62-1

|                           |                               |
|---------------------------|-------------------------------|
| <b>Purpose</b>            | Data clear                    |
| <b>Function (Purpose)</b> | Used to format the hard disk. |
| <b>Section</b>            | MFP controller (HDD)          |
| <b>Item</b>               | Clear                         |


#### Operation/Procedure

- 1) Select YES/NO of hard disk format.

|   |     |           |
|---|-----|-----------|
| 1 | YES | Execution |
| 2 | NO  | Cancel    |

- 2) Press [START] key.

During formatting, "EXECUTING" is displayed. When formatting is completed normally, "OK" is displayed. If not, "NG" is displayed.



62-2

|                           |                                                                                                                      |
|---------------------------|----------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                 |
| <b>Function (Purpose)</b> | Used to check the operation of the hard disk (read/write). (Only in the model with a disk installed) (Partial check) |
| <b>Section</b>            | MFP controller (HDD)                                                                                                 |
| <b>Item</b>               | Operation                                                                                                            |


#### Operation/Procedure

- 1) Select YES/NO of hard disk read/write check.

|   |     |           |
|---|-----|-----------|
| 1 | YES | Execution |
| 2 | NO  | Cancel    |

- 2) Press [START] key.

During testing, "EXECUTING" is displayed. When test is completed normally, "OK" is displayed. If not, "NG" is displayed.



|                           |                                                                              |
|---------------------------|------------------------------------------------------------------------------|
| <b>62-3</b>               |                                                                              |
| <b>Purpose</b>            | Operation test/Check                                                         |
| <b>Function (Purpose)</b> | Used to check the operation of the hard disk (read/write). (All areas check) |
| <b>Section</b>            | MFP controller (HDD)                                                         |
| <b>Item</b>               | Operation                                                                    |


#### Operation/Procedure

- 1) Select YES/NO of hard disk read/write check.

|   |     |           |
|---|-----|-----------|
| 1 | YES | Execution |
| 2 | NO  | Cancel    |

- 2) Press [START] key.

During testing, "EXECUTING" is displayed. When test is completed normally, "OK" is displayed. If not, "NG" is displayed.



|                           |                                                                                                             |
|---------------------------|-------------------------------------------------------------------------------------------------------------|
| <b>62-6</b>               |                                                                                                             |
| <b>Purpose</b>            | Operation test/Check                                                                                        |
| <b>Function (Purpose)</b> | Used to check the operations of the hard disk. (The self diag operation of the SMART function is executed.) |
| <b>Section</b>            | MFP controller (HDD)                                                                                        |
| <b>Item</b>               | Clear                                                                                                       |

#### Operation/Procedure


- 1) Select the number corresponding to the self diag check mode.

|   |                    |                |
|---|--------------------|----------------|
| 1 | SHORT SELF-TEST    | Partial test   |
| 2 | EXTENDED SELF-TEST | All areas test |

- 2) Press [START] key.

During the self diag operation, "EXECUTING" is displayed.

If the self diag is completed normally, "0" is displayed. If not, any value but 0 is displayed.



|                           |                                                                                                                              |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------|
| <b>62-7</b>               |                                                                                                                              |
| <b>Purpose</b>            | Operation test/Check                                                                                                         |
| <b>Function (Purpose)</b> | Used to check the operations of the hard disk. (The result of the self diag operation of the SMART function is printed out.) |
| <b>Section</b>            | MFP controller (HDD)                                                                                                         |
| <b>Item</b>               | Clear                                                                                                                        |


#### Operation/Procedure

- 1) Enter 1 with 10-key.

|   |             |                                             |
|---|-------------|---------------------------------------------|
| 0 | TRAY SELECT | Tray select auto only (Selection inhibited) |
| 1 | PRINT START | Print start                                 |

- 2) Press [START] key.

The result of the hard disk operation check (the self diag operation of the SMART function) is printed out.



62-8

|                           |                                                          |
|---------------------------|----------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                               |
| <b>Function (Purpose)</b> | Used to format the hard disk (the system area excluded). |
| <b>Section</b>            | MFP controller (HDD)                                     |
| <b>Item</b>               | Clear                                                    |


**Operation/Procedure**

- 1) Select YES/NO of hard disk (the system area excluded) format.

|   |     |           |
|---|-----|-----------|
| 1 | YES | Execution |
| 2 | NO  | Cancel    |

- 2) Press [START] key.

During formatting, "EXECUTING" is displayed. When formatting is completed normally, "OK" is displayed. If not, "NG" is displayed.



62-10

|                           |                                                                  |
|---------------------------|------------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                       |
| <b>Function (Purpose)</b> | Used to delete a job complete list (also to delete job log data) |
| <b>Section</b>            | MFP controller (HDD)                                             |
| <b>Item</b>               | Clear                                                            |

**Operation/Procedure**


- 1) Select YES/NO of deleting the job complete list.

|   |     |           |
|---|-----|-----------|
| 1 | YES | Execution |
| 2 | NO  | Cancel    |

- 2) Press [START] key.

During formatting, "EXECUTING" is displayed. When formatting is completed normally, "OK" is displayed. If not, "NG" is displayed.

NOTE: When executed, this function also deletes the complete queues of E-MAIL, FAX and IFAX, reservation data associated with the image send function, bulletin board data, and confidential data.



62-11

|                           |                                                                                                       |
|---------------------------|-------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                                                            |
| <b>Function (Purpose)</b> | Used to delete document filing data. (The management area (standard folder, user folder) is cleared.) |
| <b>Section</b>            | MFP controller (HDD)                                                                                  |
| <b>Item</b>               | Clear                                                                                                 |

**Operation/Procedure**


- 1) Select YES/NO of deleting the document filing data.

|   |     |           |
|---|-----|-----------|
| 1 | YES | Execution |
| 2 | NO  | Cancel    |

- 2) Press [START] key.

During formatting, "EXECUTING" is displayed. When formatting is completed normally, "OK" is displayed. If not, "NG" is displayed.

NOTE: When executed, this function internally executes the same function as SIM66-10; deleting reservation data, bulletin board data, and confidential data.



## 63-1

|                           |                                                                                              |
|---------------------------|----------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment/Setup/Operation data output/Check (Display/Print)                                 |
| <b>Function (Purpose)</b> | Used to check the result of shading correction. (The shading correction data are displayed.) |
| <b>Section</b>            | Optical (Image scanning)                                                                     |
| <b>Item</b>               | Operation                                                                                    |

## Operation/Procedure

| CCD data                            |                                  |
|-------------------------------------|----------------------------------|
| Values                              | Description                      |
| ODD GAIN                            | Od pixel gain adjustment value   |
| EVEN GAIN                           | Even pixel gain adjustment value |
| ODD MAX                             | Od pixel MAX                     |
| ODD MIN                             | Od pixel MIN                     |
| ODD AVE                             | Od pixel average                 |
| EVEN MAX                            | Even pixel MAX                   |
| EVEN MIN                            | Even pixel MIN                   |
| EVEN AVE                            | Even pixel average               |
| ODD OFFSET                          | Black offset                     |
| EVEN OFFSET                         | Even offset                      |
| ODD DEV                             | Odd standard deviation           |
| EVEN DEV                            | Even standard deviation          |
| CIS data : Only when DSPF installed |                                  |
| Values                              | Description                      |
| GAIN                                | Gain adjustment value            |
| MAX                                 | Pixel MAX                        |
| MIN                                 | Pixel MIN                        |
| AVE                                 | Pixel average                    |
| OFFSET                              | Black offset                     |
| DEV                                 | Standard deviation               |

```

SIMULATION 63-1
SHADING DATA DISPLAY.
(CCD)
ODD GAIN: 128
EVEN GAIN: 128 OFFSET: 126 MAX.: 128
MIN.: 128 AVE.: 128

(CIS)
GAIN: 128 OFFSET: 128 MAX.: 128
MIN.: 128 AVE.: 128 DEV.: 128

```

## 63-2

|                           |                          |
|---------------------------|--------------------------|
| <b>Purpose</b>            | Adjustment               |
| <b>Function (Purpose)</b> | Used to execute shading. |
| <b>Section</b>            | Optical (Image scanning) |
| <b>Item</b>               | Operation                |

## Operation/Procedure

- 1) Enter the number corresponding to the shading mode to be executed.

|   |              |                                                                         |
|---|--------------|-------------------------------------------------------------------------|
| 1 | OC SHADING   | OC analog level correction and shading correction (Document table mode) |
| 2 | DSPF SHADING | DSPF analog level correction and shading correction                     |

- 2) Press [START] key.

During execution, "EXECUTING" is displayed. When execution is completed normally, "COMPLETED" is displayed.

```

SIMULATION 63-2
SHADING EXECUTION. SELECT1-2, AND PRESS START.
1. OC SHADING
2. DSPF SHADING

```

1

Press [START] key.

```

SIMULATION 63-2
SHADING EXECUTING...
1. OC SHADING

```

Completion

Press [CUSTOM SETTINGS] key.

```

SIMULATION 63-2
SHADING COMPLETED.
1. OC SHADING

```

1

## 63-7

|                           |                                                                                       |
|---------------------------|---------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                                            |
| <b>Function (Purpose)</b> | Used to adjust the white plate scan start position for shading. (Document table mode) |
| <b>Section</b>            | Laser (Exposure)                                                                      |
| <b>Item</b>               | Operation                                                                             |

## Operation/Procedure

- 1) Enter 1 with 10-key.
- 2) Press [START] key.
- 3) Enter the adjustment value with 10-key.
- 4) Press [START] key.

When a shading error occurs, this adjustment value is changed.

| Item |     |          | Set range | Default |
|------|-----|----------|-----------|---------|
| 1    | CCD | CCD scan | 1 - 16    | 6       |

```

SIMULATION 63-7
SHADING POSITION ADJUSTMENT. PRESS START.
1. CCD 0

```

1

Press [START] key.

Press [CUSTOM SETTINGS] key or [START] key.

```

SIMULATION 63-7
SHADING POSITION ADJUSTMENT. INPUT VALUE 1-16, AND
PRESS START.
1. CCD

```

0



|                           |                                                                                                                                                                                                 |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                                            |
| <b>Function (Purpose)</b> | Used to check the operation of the printer section (self-print operation), (The print pattern, the paper feed mode, the print mode, the print quantity, and the density can be optionally set.) |
| <b>Section</b>            |                                                                                                                                                                                                 |
| <b>Item</b>               | Operation                                                                                                                                                                                       |

#### Operation/Procedure

(Various print patterns output) (Table 1)

- 1) Select PRINT PATTERN with 10-key.
- 2) Enter the number corresponding to the print pattern to be printed with 10-key.
- 3) Press [START] key.
- 4) Select PRINT START with 10-key.
- 5) Press [START] key.

(Print condition setting in this simulation)

\* To select paper (paper feed tray), perform the following procedures.

- 1) Select TRAY SELECT with 10-key.
- 2) Press [START] key.
- 3) Enter the number corresponding to the paper feed tray of the target paper with 10-key.
- 4) Press [START] key. (The paper feed tray is selected.)

\* To adjust the print density, perform the following procedures.

- 1) Select DENSITY with 10-key.
- 2) Enter the adjustment value with 10-key.
- 3) Press [START] key.

\* To set the print quantity, perform the following procedures.

- 1) Select MULTI with 10-key.
- 2) Enter the print quantity with 10-key.
- 3) Press [START] key.

\* To set the print quality mode, perform the following procedures.

- 1) Select MODE with 10-key.
- 2) Enter the number corresponding to the print quality mode with 10-key.
- 3) Press [START] key.

\* To set the print level, perform the following procedures.

- 1) Select LEVEL with 10-key.
- 2) Enter the adjustment value with 10-key.
- 3) Press [START] key.

NOTE: In some print patterns, changing the level may not change the picture quality.

\* To set duplex/simplex print, perform the following procedures.

- 1) Select DUPLEX with 10-key.
- 2) Enter the number corresponding to the operation mode with 10-key.
- 3) Press [START] key.

(Table 1)


|   |                                                                                                                                                                                                     |                                                                                                                                                                                                                                       |
|---|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 0 | TRAY SELECT<br>1. TRAY1<br>2. TRAY2<br>3. TRAY3<br>4. TRAY4<br>5. BPT                                                                                                                               | Paper feed tray<br>1: Tray 1<br>2: Tray 2<br>3: Tray 3<br>4: Tray 4<br>5: Manual feed                                                                                                                                                 |
| 1 | PRINT START                                                                                                                                                                                         | Print execution (Printing of the set data is executed.)                                                                                                                                                                               |
| 2 | PRINT PATTERN                                                                                                                                                                                       | Print pattern (Note 1)                                                                                                                                                                                                                |
| 3 | DENSITY                                                                                                                                                                                             | Graphic density (Valid only when No. 79, 80 or 84 is selected.)                                                                                                                                                                       |
| 4 | MULTI                                                                                                                                                                                               | Print quantity                                                                                                                                                                                                                        |
| 5 | MODE<br>1. STANDARD<br>2. SMOOTHING<br>3. TONER SAVE<br>4. HALF TONE<br>5. SMOOTHING + TONER SAVE<br>6. SMOOTHING + HALF TONE<br>7. TONER SAVE + HALF TONE<br>8. SMOOTHING + TONER SAVE + HALF TONE | Print mode<br>1. Standard<br>2. Smoothing ON<br>3. Smoothing ON<br>3. Toner save ON<br>4. Half tone ON<br>5. Smoothing + toner save<br>6. Smoothing + half tone<br>7. Toner save + half tone<br>8. Smoothing + toner save + half tone |
| 6 | LEVEL                                                                                                                                                                                               | (Parameter of print image process)                                                                                                                                                                                                    |
| 7 | DUPLEX<br>1. NO<br>2. YES                                                                                                                                                                           | Duplex<br>0: NO (Simplex)<br>1: YES (Duplex)                                                                                                                                                                                          |

(Note 1) Print pattern

| NO | ENGINE PATTERN | CONTROLLER | PATTERN                           |
|----|----------------|------------|-----------------------------------|
| 1  | ○              |            | For off-center adjustment         |
| 2  | ○              |            | Main scanning direction 1 by 5    |
| 3  | ○              |            | Main scanning direction 1mm-pitch |
| 4  | ○              |            | Main scanning direction 3 by 3    |
| 5  | ○              |            | Sub scanning direction 1 by 1     |
| 6  | ○              |            | Sub scanning direction 1 by 5     |
| 7  | ○              |            | Sub scanning direction 2 by 4     |
| 8  | ○              |            | Sub scanning direction 3 by 3     |
| 9  | ○              |            | Right oblique 1 by 2              |
| 10 | ○              |            | Right oblique 1 by 5              |
| 11 | ○              |            | Right oblique 2 by 4              |
| 12 | ○              |            | Right oblique 3 by 3              |
| 13 | ○              |            | Left oblique 1 by 2               |
| 14 | ○              |            | Left oblique 1 by 5               |
| 15 | ○              |            | Left oblique 2 by 4               |
| 16 | ○              |            | Left oblique 3 by 3               |
| 17 | ○              |            | Dot 1 by 1                        |
| 18 | ○              |            | Dot 3 by 3                        |
| 19 | ○              |            | Dot                               |
| 20 | ○              |            | Solid black                       |
| 21 | ○              |            | Main scanning direction 1 by 1    |
| 22 | ○              |            | Main scanning direction 5 by 1    |
| 23 | ○              |            | Main scanning direction 4 by 2    |
| 24 | ○              |            | Main scanning direction 3 by 3    |
| 25 | ○              |            | Sub scanning direction 1 by 1     |
| 26 | ○              |            | Sub scanning direction 5 by 1     |
| 27 | ○              |            | Sub scanning direction 4 by 2     |
| 28 | ○              |            | Sub scanning direction 3 by 3     |
| 29 | ○              |            | Right oblique 2 by 1              |
| 30 | ○              |            | Right oblique 5 by 1              |

| NO | ENGINE PATTERN | CONTROLLER | PATTERN                                                    |
|----|----------------|------------|------------------------------------------------------------|
| 31 | ○              |            | Right oblique 4 by 2                                       |
| 32 | ○              |            | Right oblique 3 by 3                                       |
| 33 | ○              |            | Left oblique 2 by 1                                        |
| 34 | ○              |            | Left oblique 5 by 1                                        |
| 35 | ○              |            | Left oblique 4 by 2                                        |
| 36 | ○              |            | Left oblique 3 by 3                                        |
| 37 | ○              |            | Dot 1 by 1                                                 |
| 38 | ○              |            | Dot 3 by 3                                                 |
| 39 | ○              |            | Dot                                                        |
| 40 | ○              |            | Solid white                                                |
| 50 |                | ○          | All surface 1 by 1 (Vertical)                              |
| 51 |                | ○          | All surface 1 by 1 (Horizontal)                            |
| 52 |                | ○          | All surface 1 by 2 (Vertical)                              |
| 53 |                | ○          | All surface 1 by 2 (Horizontal)                            |
| 54 |                | ○          | All surface 1 by 3 (Vertical)                              |
| 55 |                | ○          | All surface 1 by 3 (Horizontal)                            |
| 56 |                | ○          | All surface 1 by 4 (Vertical)                              |
| 57 |                | ○          | All surface 1 by 4 (Horizontal)                            |
| 58 |                | ○          | All surface 1 by 5 (Vertical)                              |
| 59 |                | ○          | All surface 1 by 5 (Horizontal)                            |
| 60 |                | ○          | All surface 2 by 2 (Vertical)                              |
| 61 |                | ○          | All surface 2 by 2 (Horizontal)                            |
| 62 |                | ○          | All surface 2 by 3 (Vertical)                              |
| 63 |                | ○          | All surface 2 by 3 (Horizontal)                            |
| 64 |                | ○          | All background                                             |
| 65 |                | ○          | Special pattern                                            |
| 66 |                | □          | For every other 1 block width<br>128 pixels/ 32 gradations |
| 67 |                | □          | For every other 1 block width<br>128 pixels/ 16 gradations |
| 68 |                | □          | For every other 1 block width<br>128 pixels/ 8 gradations  |
| 69 |                | ○          | 1-dot pattern                                              |
| 70 |                | ○          | Print adjustment pattern with<br>scale (Vertical)          |
| 71 |                | ○          | Grid pattern                                               |
| 72 |                | ○          | Slant line 45 degrees                                      |
| 73 |                | ○          | Slant line 26.6 degrees                                    |
| 74 |                | ○          | Slant line 63.4 degrees                                    |
| 75 |                | ○          | ID/BG pattern                                              |
| 76 |                | ○          | Dot pattern 12.5%                                          |
| 77 |                | ○          | Dot pattern 28%                                            |
| 78 |                | ○          | Dot pattern 50%                                            |
| 79 |                | □          | All surface effort diffusion<br>background                 |
| 80 |                | ○          | All surface dither process<br>background                   |
| 81 |                | ○          | For every other 1 block width<br>128 pixels/ 32 gradations |
| 82 |                | ○          | For every other 1 block width<br>128 pixels/ 16 gradations |
| 83 |                | ○          | For every other 1 block width<br>128 pixels/ 8 gradations  |
| 84 |                | ○          | Memory check pattern                                       |
| 85 |                | ○          | Cleaning check pattern                                     |
| 86 |                | ○          | Offset check pattern                                       |
| 87 |                | ○          | Test B image (For aging)                                   |
| 88 |                | ○          | 6% printer chart                                           |
| 89 |                | ○          | 5% printer chart                                           |
| 90 |                |            | Toner quantity measuring<br>chart                          |
| 91 |                |            | Radiation chart                                            |
| 98 |                |            | Data printing                                              |

□: Error diffusion process



## 65

65-1

|                           |                                                                          |
|---------------------------|--------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment                                                               |
| <b>Function (Purpose)</b> | Used to adjust the touch panel (LCD display section) detection position. |
| <b>Section</b>            | Operation (Display/Operation key)                                        |
| <b>Item</b>               |                                                                          |

### Operation/Procedure

Touch the four cross marks (+) sequentially. The coordinates of pressed positions are set.

When the coordinates setting is completed normally, the display turns gray. When all the four points are set, the display returns to the normal state.




65-2

|                           |                                                                                                                           |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment/Setup/Operation data output/Check (Display/Print)                                                              |
| <b>Function (Purpose)</b> | Used to check the result of the touch panel (LCD display) detection position adjustment. (The coordinates are displayed.) |
| <b>Section</b>            | Operation (Display/Operation key)                                                                                         |
| <b>Item</b>               |                                                                                                                           |

### Operation/Procedure

When the touch panel is touched, the X and Y coordinate values of the touched point and the coordinate values of the specified point are displayed. The coordinate values set with SIM 65-1 are used as the reference.



## 66

66-1

|                           |                                                                                                                                                                   |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                                                                           |
| <b>Function (Purpose)</b> | Used to change and check the FAX soft switch functions. (Used to change and check the functions provided for the FAX soft switches.) (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                               |
| <b>Item</b>               |                                                                                                                                                                   |

### Operation/Procedure

Setting of soft switches other than SW1 can be changed and checked.

- 1) Enter the soft switch number to be checked or changed with 10-key.  
The current set state is displayed.

- 2) Enter the number corresponding to the bit to be changed with 10-key.  
(Example) When the bit of 5 is to be changed, enter 5.  
The set value of 1/0 is alternatively changed every time when the target key is pressed.
- 3) After completion of setting of all the bits, press [START] key.

#### SIMULATION 66-1

FAX SOFT SW. SETTING. SELECT 2-120, AND PRESS START.

1

Press [START] key.

Press [CUSTOM SETTINGS] key or [START] key.

#### SIMULATION 66-1

FAX SOFT SW. SETTING. INPUT DATA No (1-8), AND PRESS START.

OFT SW-2:

1 2 3 4 5 6 7 8  
00001001

66-2

|                           |                                                                                                                                            |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data clear                                                                                                                                 |
| <b>Function (Purpose)</b> | Used to clear the FAX soft switch function data and to set to the default. (Excluding the adjustment values.) (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                        |
| <b>Item</b>               | Data                                                                                                                                       |

### Operation/Procedure

- 1) Set the destination code with 10-key.

|            |                 |             |                 |
|------------|-----------------|-------------|-----------------|
| Japan      | 0 0 0 0 0 0 0 0 | Finland     | 0 0 1 1 1 1 0 0 |
| U.S.A.     | 1 0 1 1 0 1 0 1 | Norway      | 1 0 0 0 0 1 0 0 |
| Australia  | 0 0 0 0 1 0 0 1 | Denmark     | 0 0 1 1 0 0 0 1 |
| U.K.       | 1 0 1 1 0 1 0 0 | Netherlands | 0 1 1 1 1 0 1 1 |
| France     | 0 0 1 1 1 1 0 1 | Italy       | 0 1 0 1 1 0 0 1 |
| Germany    | 0 0 0 0 0 1 0 0 | Switzerland | 1 0 1 0 0 1 1 0 |
| Sweden     | 1 0 1 0 0 1 0 1 | Austria     | 0 0 0 0 1 0 1 0 |
| Newzealand | 0 1 1 1 1 1 1 0 | Indonesia   | 0 1 0 1 0 1 0 0 |
| China      | 0 0 1 0 0 1 1 0 | Thailand    | 1 0 0 1 0 0 1 1 |
| Singapore  | 1 0 0 1 1 1 0 0 | Malaysia    | 0 1 1 0 1 1 0 0 |
| TW         | 1 1 1 1 1 1 1 0 | India       | 0 1 0 1 0 0 1 1 |
| Other1     | 1 1 1 1 1 1 0 1 | Philippines | 1 0 0 0 1 0 0 1 |
| Other2     | 1 1 1 1 1 1 0 0 | Hongkong    | 0 1 0 1 0 0 0 0 |
| Other3     | 1 1 1 1 1 0 1 1 |             |                 |

The codes other than the above are recognized as Japan.

- 2) Press [START] key.
- 3) The confirmation menu of YES/NO of clear is displayed. Select one.

|   |     |                         |
|---|-----|-------------------------|
| 1 | YES | FAX soft SW is cleared. |
| 2 | NO  | Not cleared.            |

- 4) Press [START] key.

The soft switch (except for the adjustment values) is cleared according to the destination selected in procedure 1).

NOTE: When the FAX BOX is not installed, initialization including the adjustment value is performed. (The adjustment value is stored in the FAX BOX.)

**SIMULATION 66-2**  
 FAX SOFT SW. CLEAR (WITHOUT ADJUSTMENT VALUE).  
 INPUT COUNTRY CODE, AND PRESS START.

1 2 3 4 5 6 7 8  
**00000000**

Press [START] key.

**SIMULATION 66-2**  
 FAX SOFT SW. CLEAR.  
 ARE YOU SURE?

**JAPAN**

1: YES  
 2: NO

**1**

66-3

|                           |                                                                                                                                                                     |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                |
| <b>Function (Purpose)</b> | Used to check the operation of the FAX PWB memory (read/write). (This adjustment is required when the PWB is replaced with a new one.) (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                 |
| <b>Item</b>               | Data                                                                                                                                                                |

#### Operation/Procedure

- 1) Enter the number corresponding to the memory to be checked with 10-key.
- 2) Press [START] key.

In the case of All, all memories are checked only once.

|                            |                   |
|----------------------------|-------------------|
| Check connection wire list |                   |
| NO CHECK                   | Not checked yet.  |
| CHECKING                   | Checking          |
| OK                         | Check complete OK |
| NG                         | Check complete NG |

The error address or the data line is displayed individually.

|                        |           |
|------------------------|-----------|
| Target memory of check |           |
| MFP SRAM               | SRAM      |
| MFP FLASH              | FLASH ROM |
| MFP OP.FLASH           |           |
| MODEM EEPROM           |           |
| MODEM SRAM (G/A)       |           |
| MODEM SRAM             |           |
| MODEM SDRAM            |           |

When "repeat" is selected, the operation is repeated until the result is "NG" or [CUSTOMSETTING] is pressed.

**SIMULATION 66-3**  
 FAX PWB MEMORY CHECK INPUT 1-13, AND PRESS START.

1. All Memory Device Check (once)  
 2. MFP SRAM (once) 3. MFP SRAM (repeat)  
 4. MFP FLASH+ OP.FLASH (once)  
 5. MFP FLASH+ OP>FLASH (repeat)  
 6. MODEM EEPROM (once) 7. MODEM EEPROM (repeat)  
 8. MODEM SRAM (G/A) (once) 9. MODEM SRAM (G/A) (repeat)  
 10. MODEM SRAM (once) 11. MODEM SRAM (repeat)  
 12. MODEM SDRAM (once) 13. MODEM SDRAM (repeat)

Press [START] key.

Press [CUSTOM SETTINGS] key.

**SIMULATION 66-3**  
 FAX PWB MEMORY CHECK  
 MFP SRAM: CHECKING  
 MFP FLASH: NO CHECK  
 MFP OP.FLASH: NO CHECK  
 MODEM EEPROM: NG:A0010000  
 MODEM SRAM (G/A): NO CHECK  
 MODEM SRAM: NG All  
 MODEM SDRAM: OK

When "repeat" is selected and  
 [CUSTOM SETTINGS] key is pressed.

When Check is "once," the display stops at the result display.  
 When [CUSTOM SETTINGS] key is pressed, the display returns to the initial display.

66-4

|                           |                                                                                                                                                                            |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                       |
| <b>Function (Purpose)</b> | Used to check the output operation of data signals in each data output mode of FAX. (Used to check the operation of MODEM. ) Send level: Max. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                        |
| <b>Item</b>               | Operation                                                                                                                                                                  |

#### Operation/Procedure

- 1) Enter the number corresponding to the output mode with 10-key.


- 2) Press [START] key.

The output is delivered at the max. send level.

|    |          |           |    |          |          |
|----|----------|-----------|----|----------|----------|
| 1  | NOSIGNAL | No signal | 17 | 12.0 V33 | 12.0 V33 |
| 2  | 33.6 V34 | 26.4 V34  | 18 | 14.4 V17 | 14.4 V17 |
| 3  | 31.2 V34 | 31.2 V34  | 19 | 12.0 V17 | 12.0 V17 |
| 4  | 28.8 V34 | 28.8 V34  | 20 | 9.6 V17  | 9.6 V17  |
| 5  | 26.4 V34 | 26.4 V34  | 21 | 7.2 V17  | 7.2 V17  |
| 6  | 24.0 V34 | 24.0 V34  | 22 | 9.6 V29  | 9.6 V29  |
| 7  | 21.6 V34 | 21.6 V34  | 23 | 7.2 V29  | 7.2 V29  |
| 8  | 19.2 V34 | 19.2 V34  | 24 | 4.8 V27t | 4.8 V27t |
| 9  | 16.8 V34 | 16.8 V34  | 25 | 2.4 V27t | 2.4 V27t |
| 10 | 14.4 V34 | 14.4 V34  | 26 | 0.3 FLG  | 0.3 FLG  |
| 11 | 12.0 V34 | 12.0 V34  | 27 | CED 2100 | CED 2100 |
| 12 | 9.6 V34  | 9.6 V34   | 28 | CNG 1100 | CNG 1100 |
| 13 | 7.2 V34  | 7.2 V34   | 29 | 0.3 V21  | 0.3 V21  |
| 14 | 4.8 V34  | 4.8 V34   | 30 | ANSam    | ANSam    |
| 15 | 2.4 V34  | 2.4 V34   | 31 | RINGER   | RINGER   |
| 16 | 14.4 V33 | 14.4 V33  | 32 | No RBT   | No RBT   |

When [CUSTOM SETTINGS] key is pressed during execution, execution is stopped.

When a number is entered and [START] key is pressed during execution, the kind of signal can be changed.



66-5

|                           |                                                                                                                                                                                                                      |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                                                                 |
| <b>Function (Purpose)</b> | Used to check the output operation of data signals in each data output mode of FAX. (Used to check the operation of MODEM.) An output is sent at the send level set by the soft switch. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                                                                  |
| <b>Item</b>               | Operation                                                                                                                                                                                                            |

#### Operation/Procedure


- 1) Enter the number corresponding to the output mode with 10-key.
- 2) Press [START] key.

The output is delivered at the send level set with the soft switch.

|    |          |           |    |          |          |
|----|----------|-----------|----|----------|----------|
| 1  | NOSIGNAL | No signal | 17 | 12.0 V33 | 12.0 V33 |
| 2  | 33.6 V34 | 26.4 V34  | 18 | 14.4 V17 | 14.4 V17 |
| 3  | 31.2 V34 | 31.2 V34  | 19 | 12.0 V17 | 12.0 V17 |
| 4  | 28.8 V34 | 28.8 V34  | 20 | 9.6 V17  | 9.6 V17  |
| 5  | 26.4 V34 | 26.4 V34  | 21 | 7.2 V17  | 7.2 V17  |
| 6  | 24.0 V34 | 24.0 V34  | 22 | 9.6 V29  | 9.6 V29  |
| 7  | 21.6 V34 | 21.6 V34  | 23 | 7.2 V29  | 7.2 V29  |
| 8  | 19.2 V34 | 19.2 V34  | 24 | 4.8 V27t | 4.8 V27t |
| 9  | 16.8 V34 | 16.8 V34  | 25 | 2.4 V27t | 2.4 V27t |
| 10 | 14.4 V34 | 14.4 V34  | 26 | 0.3 FLG  | 0.3 FLG  |
| 11 | 12.0 V34 | 12.0 V34  | 27 | CED 2100 | CED 2100 |
| 12 | 9.6 V34  | 9.6 V34   | 28 | CNG 1100 | CNG 1100 |
| 13 | 7.2 V34  | 7.2 V34   | 29 | 0.3 V21  | 0.3 V21  |
| 14 | 4.8 V34  | 4.8 V34   | 30 | ANSam    | ANSam    |
| 15 | 2.4 V34  | 2.4 V34   | 31 | RINGER   | RINGER   |
| 16 | 14.4 V33 | 14.4 V33  | 32 | No RBT   | No RBT   |

When [CUSTOM SETTINGS] key is pressed during execution, execution is stopped.

When a number is entered and [START] key is pressed during execution, the kind of signal can be changed.



66-6


|                           |                                                                                                                             |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | User data output/Check (Display/Print)                                                                                      |
| <b>Function (Purpose)</b> | Used to print the confidential pass code. (Used when the confidential pass code is forgotten.) (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                         |
| <b>Item</b>               | Data                                                                                                                        |

#### Operation/Procedure

1) Enter 1 with 10-key and press [START] key.

|   |             |             |
|---|-------------|-------------|
| 1 | PRINT START | Print start |
|---|-------------|-------------|

The paper is automatically selected with the size saved in the image memory.



66-7

|                           |                                                                                         |
|---------------------------|-----------------------------------------------------------------------------------------|
| <b>Purpose</b>            | User data output/Check (Display/Print)                                                  |
| <b>Function (Purpose)</b> | Used to print the image memory data (memory send/receive). (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                     |
| <b>Item</b>               | Data                                                                                    |


#### Operation/Procedure

All image data stored in the image memory are printed.

\* The confidential receive data are also printed.

|   |             |             |
|---|-------------|-------------|
| 1 | PRINT START | Print start |
|---|-------------|-------------|

The paper is automatically selected with the size saved in the image memory.



|                           |                                                                                                                                                                         |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                    |
| <b>Function (Purpose)</b> | Used to check the output operation of various sound signals of FAX. (Used to check the operation of the sound output IC.) Send level: Max. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                     |
| <b>Item</b>               | Operation                                                                                                                                                               |

#### Operation/Procedure


- 1) Enter the number corresponding to the output mode with 10-key.
- 2) Press [START] key.

The output is delivered at the max. level.

|    |          |             |    |                |                   |
|----|----------|-------------|----|----------------|-------------------|
| 1  | NONE     | Mute        | 11 | MESSAGE 9      | Message 9         |
| 2  | PAUSE    | Pause sound | 12 | MESSAGE 10     | Message 10        |
| 3  | MESSAGE1 | Message 1   | 13 | MESSAGE 11     | Message 11        |
| 4  | MESSAGE2 | Message 2   | 14 | MESSAGE 12     | Message 12        |
| 5  | MESSAGE3 | Message 3   | 15 | MESSAGE 13     | Message 13        |
| 6  | MESSAGE4 | Message 4   | 16 | MESSAGE 14     | Message 14        |
| 7  | MESSAGE5 | Message 5   | 17 | MESSAGE 15     | Message 15        |
| 8  | MESSAGE6 | Message 6   | 18 | ALARM          | Alarm             |
| 9  | MESSAGE7 | Message 7   | 19 | RINGER         | Call ring         |
| 10 | MESSAGE8 | Message 8   | 20 | EXT.TEL.RINGER | External TEL ring |

When the number is entered during execution, the kind of signal can be changed.

When [START] key is pressed, the voice message is sent. When [CUSTOM SETTINGS] key is pressed, it is stopped.



|                           |                                                                                                                                                                                                                    |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                                                               |
| <b>Function (Purpose)</b> | Used to check the output operation of various sound signals of FAX. (Used to check the operation of the sound output IC.) An output is sent at the send level set by the soft switch. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                                                                |
| <b>Item</b>               | Operation                                                                                                                                                                                                          |

#### Operation/Procedure


- 1) Enter the number corresponding to the output mode with 10-key.
- 2) Press [START] key.

The output is delivered at the send level set with the soft SW.

|    |          |             |    |                |                   |
|----|----------|-------------|----|----------------|-------------------|
| 1  | NONE     | Mute        | 11 | MESSAGE 9      | MESSAGE 9         |
| 2  | PAUSE    | Pause sound | 12 | MESSAGE10      | MESSAGE 10        |
| 3  | MESSAGE1 | MESSAGE 1   | 13 | MESSAGE11      | MESSAGE 11        |
| 4  | MESSAGE2 | MESSAGE 2   | 14 | MESSAGE12      | MESSAGE 12        |
| 5  | MESSAGE3 | MESSAGE 3   | 15 | MESSAGE13      | MESSAGE 13        |
| 6  | MESSAGE4 | MESSAGE 4   | 16 | MESSAGE14      | MESSAGE 14        |
| 7  | MESSAGE5 | MESSAGE 5   | 17 | MESSAGE15      | MESSAGE 15        |
| 8  | MESSAGE6 | MESSAGE 6   | 18 | ALARM          | Alarm             |
| 9  | MESSAGE7 | MESSAGE 7   | 19 | RINGER         | Call ring         |
| 10 | MESSAGE8 | MESSAGE 8   | 20 | EXT.TEL.RINGER | External TEL ring |

When the number is entered during execution, the kind of signal can be changed.

When [START] key is pressed, the voice message is sent. When [CUSTOM SETTINGS] key is pressed, it is stopped.



66-10

|                           |                                                                                                                                                         |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | User data output/Check (Display/Print)                                                                                                                  |
| <b>Function (Purpose)</b> | Used to clear all data of the image memory (memory send/receive). The confidential data are also cleared at the same time. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                     |
| <b>Item</b>               | Data                                                                                                                                                    |

**Operation/Procedure**

- 1) Select YES/NO of image memory clear with 10-key.

|   |     |                                 |
|---|-----|---------------------------------|
| 1 | YES | Image memory clear is executed. |
| 2 | NO  | Clear is not executed.          |

- 2) Press [START] key.

The SRAM image data management table and image data in the Flash ROM area and HD (except for filing images) are cleared.

|                    |     |
|--------------------|-----|
| SIMULATION 66-10   |     |
| IMAGE MEMORY CLEAR |     |
| ARE YOU SURE?      |     |
| 1.                 | YES |
| 2.                 | NO  |

Press [START] key to clear.

|                                  |  |
|----------------------------------|--|
| SIMULATION 66-10                 |  |
| IMAGE MEMORY CLEAR EXECUTING.... |  |
| +++++                            |  |

The processing status of image memory clear is displayed with "+,."

66-11

|                           |                                                                                                                                                 |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                            |
| <b>Function (Purpose)</b> | Used to check the output operation of FAX G3 mode 300bps. (Used to check the operation of MODEM.) Send level: Max. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                             |
| <b>Item</b>               | Operation                                                                                                                                       |

**Operation/Procedure**


- 1) Select the number corresponding to the output mode with 10-key.
- 2) Press [START] key.

The signal is sent in the max. send level.

|   |           |           |   |        |        |
|---|-----------|-----------|---|--------|--------|
| 1 | NO SIGNAL | No signal | 4 | 00000  | 00000  |
| 2 | 11111     | 11111     | 5 | 010101 | 010101 |
| 3 | 11110     | 11110     | 6 | 00001  | 00001  |

When the number is entered during execution, the kind of signal can be changed.

When [CUSTOM SETTINGS] key is pressed during execution, the operation is stopped.



66-12

|                           |                                                                                                                                                                                            |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                                       |
| <b>Function (Purpose)</b> | Used to check the output operation of FAX G3 mode 300bps. (Used to check the operation of MODEM.) An output is sent at the send level set by the soft switch. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                                        |
| <b>Item</b>               | Operation                                                                                                                                                                                  |

**Operation/Procedure**


- 1) Select the number corresponding to the output mode with 10-key.
- 2) Press [START] key.
- The signal is sent in the send level set with the soft switch.

|   |           |           |   |        |        |
|---|-----------|-----------|---|--------|--------|
| 1 | NO SIGNAL | No signal | 4 | 00000  | 00000  |
| 2 | 11111     | 11111     | 5 | 010101 | 010101 |
| 3 | 11110     | 11110     | 6 | 00001  | 00001  |

When the number is entered during execution, the kind of signal can be changed.

When [CUSTOM SETTINGS] key is pressed during execution, the operation is stopped.





66-13

|                           |                                                                                                                                                                                                                |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                                                                                                                        |
| <b>Function (Purpose)</b> | Used to enter (set) the number of FAX dial signal output test. (The dial number set by this simulation is outputted when the dial signal output test is made by SIM 66-14 - 16. ) (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                                                            |
| <b>Item</b>               | Data                                                                                                                                                                                                           |

#### Operation/Procedure

- 1) Enter the dial number with 10-key.  
Use 10-key, [\*] key, and [#] key to enter the number. The upper limit is 20 digits.  
When [CLEAR] key is pressed, the mode returns to the initial state.
- 2) Press [START] key.

SIMULATION 66-13  
DIAL TEST NUMBER SETTING. 0-9:[0-9], \*:[\*], #:[#]  
INPUT NUMBER AND PRESS START.  
0123456789\*#01234567

66-14

|                           |                                                                                                                                                                                                                                                     |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting/Operation test/Check                                                                                                                                                                                                                        |
| <b>Function (Purpose)</b> | Used to set the make time in the FAX pulse dial mode (10pps) and to test the dial signal output. (The dial number signal set by SIM 66-13 is outputted.) Used to check troubles in dialing and to check the operation. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                                                                                                 |
| <b>Item</b>               | Operation                                                                                                                                                                                                                                           |

#### Operation/Procedure

- 1) Enter 0 with 10-key.
  - 2) Press [START] key.
- The dial signal is outputted.


#### (Dial pulse make time setting)

- 1) Enter 1 with 10-key.
- 2) Press [START] key.
- 3) Enter the set value with 10-key.
- 4) Press [START] key.

|   |           |                                       |
|---|-----------|---------------------------------------|
| 0 | EXECUTE   | Execute                               |
| 1 | MAKE TIME | Dial pulse make time setting (0 - 15) |

The dial signal is sent with the set value + 29ms.

When [CUSTOM SETTINGS] key is pressed during execution, the operation is stopped.



66-15

|                           |                                                                                                                                                                                                                                                     |
|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting/Operation test/Check                                                                                                                                                                                                                        |
| <b>Function (Purpose)</b> | Used to set the make time in the FAX pulse dial mode (20pps) and to test the dial signal output. (The dial number signal set by SIM 66-13 is outputted.) Used to check troubles in dialing and to check the operation. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                                                                                                 |
| <b>Item</b>               | Operation                                                                                                                                                                                                                                           |

#### Operation/Procedure

- 1) Enter 0 with 10-key.
  - 2) Press [START] key.
- The dial signal is outputted.


#### (Dial pulse make time setting)

- 1) Enter 1 with 10-key.
- 2) Press [START] key.
- 3) Enter the set value with 10-key.
- 4) Press [START] key.

|   |           |                                       |
|---|-----------|---------------------------------------|
| 0 | EXECUTE   | Execute                               |
| 1 | MAKE TIME | Dial pulse make time setting (0 - 15) |

The dial signal is sent with the set value + 9ms.

When [CUSTOM SETTINGS] key is pressed during execution, the operation is stopped.



66-16

|                           |                                                                                                                                                                                                                                                                           |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting/Operation test/Check                                                                                                                                                                                                                                              |
| <b>Function (Purpose)</b> | Used to check the dial signal (DTMF) output in the FAX tone dial mode. (The dial number signal set by SIM 66-13 is outputted.) The send level can be set to an optional level. Used to check troubles in dialing and to check the operation. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                                                                                                                       |
| <b>Item</b>               | Operation                                                                                                                                                                                                                                                                 |

#### Operation/Procedure


- 1) Enter 0 with 10-key.
  - 2) Press [START] key.
- The dial signal is outputted.

(Dial pulse make time setting)

- 1) Enter 1 or 2 with 10-key.
- 2) Press [START] key.
- 3) Enter the set value with 10-key.
- 4) Press [START] key.

| Item |          |                        | Set range |
|------|----------|------------------------|-----------|
| 0    | EXECUTE  | Execution              |           |
| 1    | HIGH     | High group level       | 0 - 15dB  |
| 2    | HIGH LOW | High group - Low group | 0 - 15    |

When [CUSTOM SETTINGS] key is pressed during execution, the operation is stopped.



66-17


|                           |                                                                                                                                                   |
|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                                                           |
| <b>Function (Purpose)</b> | Used to check the dial signal (DTMF) output in the FAX tone dial mode. Send level: Max. Used to check the operation. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                               |
| <b>Item</b>               | Operation                                                                                                                                         |

#### Operation/Procedure

- 1) Enter the DTMF signal (1 - 9, 0, \*, #) to be sent with 10-key.
- 2) Press [START] key.

The signal is sent in the max. send level.

When [CUSTOM SETTINGS] key is pressed during execution, the operation is stopped.



66-18


|                           |                                                                                                                                                                                              |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                                                                                                                      |
| <b>Function (Purpose)</b> | Used to check the dial signal (DTMF) output in the FAX tone dial mode. An output is sent at the send level set by the soft switch. Used to check the operation. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                                                          |
| <b>Item</b>               | Operation                                                                                                                                                                                    |

**Operation/Procedure**

- 1) Enter the DTMF signal (1 - 9, 0, \*, #) to be sent with 10-key.
- 2) Press [START] key.

The signal is sent in the send level set with the soft SW.

When [CUSTOM SETTINGS] key is pressed during execution, the operation is stopped.



66-19

|                           |                                                                                                                          |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data transfer                                                                                                            |
| <b>Function (Purpose)</b> | Used to back-up the HDD data into the Flash memory (optional FAX expansion memory: AR-MM9). (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                      |
| <b>Item</b>               | Data                                                                                                                     |

**Operation/Procedure**

- 1) Select YES/NO of data transfer (backup).

|   |     |                         |
|---|-----|-------------------------|
| 1 | YES | Backup is executed.     |
| 2 | NO  | Backup is not executed. |

- 2) Press [START] key.

This function is valid only when the AR-MM9 is installed.

**Backup contents**

- Address book data (FAX, Mail, Address)
  - Item name
  - Fine name
  - FAX receive select table
  - IFAX receive YES/NO
  - Polling allow number
  - Memory box
  - Sender name
  - Soft SW
- One-touch dial
- FTP expansion
- Group expansion
- Program
- Use index
- Standard sender
- IFAX sender registration
- FAX sender registration

The other contents are not backed up.

SIMULATION 66-19

ADDRESS DATA BACK UP. (WRITE TO FLASH ROM)  
ARE YOU SURE?  
1. YES  
2. NO

1

Press [START] key.

SIMULATION 66-19

ADDRESS DATA BACK UP. (WRITE TO FLASH ROM) EXECUTING...

1

After completion of backup

66-20


|                           |                                                                                          |
|---------------------------|------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Data transfer                                                                            |
| <b>Function (Purpose)</b> | Used to read the back-up data by SIM 66-19 to the SRAM/HDD. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                      |
| <b>Item</b>               | Data                                                                                     |

**Operation/Procedure**

- 1) Select YES/NO of data transfer.

|   |     |                         |
|---|-----|-------------------------|
| 1 | YES | Backup is executed.     |
| 2 | NO  | Backup is not executed. |

- 2) Press [START] key.




66-21

|                           |                                                                                                                                                                  |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Adjustment/Setup/Operation data output/Check (Display/Print)                                                                                                     |
| <b>Function (Purpose)</b> | Used to print information related to FAX (various registrations, communication management, file management, system error protocol). (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                                              |
| <b>Item</b>               | Data                                                                                                                                                             |

**Operation/Procedure**

- 1) Enter the number corresponding to the information (item) to be printed with 10-key.
- 2) Press [START] key.

|   |                 |                                      |
|---|-----------------|--------------------------------------|
| 1 | REGISTERED      | Various registration information     |
| 2 | MANAGEMENT      | Communication management information |
| 3 | FILE MANAGEMENT | File management information          |
| 4 | SYSTEM ERROR    | System error information             |
| 5 | PROTOCOL        | Protocol information                 |




|                           |                                                                      |
|---------------------------|----------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                              |
| <b>Function (Purpose)</b> | Used to adjust the handset volume. (Only when the FAX is installed.) |
| <b>Section</b>            | FAX                                                                  |
| <b>Item</b>               | Operation                                                            |

#### Operation/Procedure

- 1) Enter the number corresponding to the volume with 10-key.
- 2) Press [START] key.

|   |        |        |
|---|--------|--------|
| 1 | MIN    | Small  |
| 2 | MIDDLE | Medium |
| 3 | MAX    | Large  |


Selection of 1, 2, and 3 can be made during execution.



|                           |                                                                                                             |
|---------------------------|-------------------------------------------------------------------------------------------------------------|
| <b>66-23</b>              |                                                                                                             |
| <b>Purpose</b>            | Setting                                                                                                     |
| <b>Function (Purpose)</b> | Used to download the FAX program. (Only when FAX is installed)<br>Not used in the market. (For development) |
| <b>Section</b>            | FAX                                                                                                         |
| <b>Item</b>               |                                                                                                             |

#### Operation/Procedure

- 1) Turn OFF the power.
  - 2) Remove the protect pin.
  - 3) Turn ON the power.
  - 4) Enter the SIM 66-23 mode.
  - 5) Press [START] key.
- During operation, "EXECUTING" is displayed. When the operation is completed normally, "COMPLETE" is displayed.
- If an error occurs, "FAIL" is displayed.
- 6) Turn OFF the power, and attach the protect pin.




|                           |                                                                  |
|---------------------------|------------------------------------------------------------------|
| <b>66-24</b>              |                                                                  |
| <b>Purpose</b>            | Clear                                                            |
| <b>Function (Purpose)</b> | Used to clear the FAST memory data. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                              |
| <b>Item</b>               | Data                                                             |

#### Operation/Procedure

- 1) Select YES/NO of data clear.

|   |     |                              |
|---|-----|------------------------------|
| 1 | YES | FAST memory data is cleared. |
| 2 | NO  | Not cleared.                 |

- 2) Press [START] key.



|                           |                                                                                                                              |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------|
| <b>66-25</b>              |                                                                                                                              |
| <b>Purpose</b>            | Setting                                                                                                                      |
| <b>Function (Purpose)</b> | Used to register the FAX number for Modem dial-in. (Only when FAX is installed)<br>Not used in the market. (For development) |
| <b>Section</b>            | FAX                                                                                                                          |
| <b>Item</b>               | Data                                                                                                                         |

#### Operation/Procedure

- 1) Enter the Modem dial-in FAX number (1 - 9, 0, \*, #) with 10-key.
- 2) Press [START] key.

SIMULATION 66-25  
M-D-IN FAX NUMBER SETTING. 0-9:[0-9],\*:[\*],#:[#]  
INPUT NUMBER AND PRESS START.  
0123456789\*#01234567

|                           |                                                                                                                                          |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| <b>66-26</b>              |                                                                                                                                          |
| <b>Purpose</b>            | Setting                                                                                                                                  |
| <b>Function (Purpose)</b> | Used to register external telephone numbers for Modem dial-in. (Only when FAX is installed)<br>Not used in the market. (For development) |
| <b>Section</b>            | FAX                                                                                                                                      |
| <b>Item</b>               | Data                                                                                                                                     |

#### Operation/Procedure

- 1) Enter the Modem dial-in FAX number (1 - 9, 0, \*, #) with 10-key.
- 2) Press [START] key.

SIMULATION 66-26  
M-D-IN EXTEL NUMBER SETTING. 0-9:[0-9],\*:[\*],#:[#]  
INPUT NUMBER AND PRESS START.  
0123456789\*#01234567

|                           |                                                                                                                                |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| <b>66-27</b>              |                                                                                                                                |
| <b>Purpose</b>            | Setting                                                                                                                        |
| <b>Function (Purpose)</b> | Used to register the transfer number for voice warp. (Only when FAX is installed)<br>Not used in the market. (For development) |
| <b>Section</b>            | FAX                                                                                                                            |
| <b>Item</b>               | Data                                                                                                                           |

#### Operation/Procedure

- 1) Enter the voice warp transfer number (1 - 9, 0, \*, #) with 10-key.
- 2) Press [START] key.

SIMULATION 66-27  
V-WP TRANSMIT NUMBER SETTING. 0-9:[0-9],\*:[\*],#:[#]  
INPUT NUMBER AND PRESS START.  
0123456789\*#01234567

|                           |                                                                                                                                                             |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>66-29</b>              |                                                                                                                                                             |
| <b>Purpose</b>            | Clear                                                                                                                                                       |
| <b>Function (Purpose)</b> | Used to clear data related to an address book (one-touch registration, program registration/ expansion, relay memory box registration, each table content). |
| <b>Section</b>            | FAX, Network scanner                                                                                                                                        |
| <b>Item</b>               | Data                                                                                                                                                        |

#### Operation/Procedure

- 1) Select YES/NO of data clear.

|   |     |                               |
|---|-----|-------------------------------|
| 1 | YES | Address book data is cleared. |
| 2 | NO  | Not cleared.                  |

- 2) Press [START] key.

SIMULATION 66-29  
ADDRESS DATA CLEAR.  
ARE YOU SURE?  
1. YES  
2. NO

1

|                           |                                                                              |
|---------------------------|------------------------------------------------------------------------------|
| <b>66-30</b>              |                                                                              |
| <b>Purpose</b>            | Operation test/Check                                                         |
| <b>Function (Purpose)</b> | Used to check the change in the TEL/LIU status. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                          |
| <b>Item</b>               | Operation                                                                    |

#### Operation/Procedure

The TEL/LIU state is displayed.

When the state is changed, it is highlighted.

|      |                            |
|------|----------------------------|
| HS1  | Polarity reverse signal    |
| HS2  | Polarity reverse signal    |
| RHS  | Handset hook SW            |
| EXHS | External telephone hook SW |

SIMULATION 66-30  
TEL/LIU SENSOR CHECK.  
HS1 HS2 **RHS** EXHS

1

|                           |                                                                 |
|---------------------------|-----------------------------------------------------------------|
| <b>66-31</b>              |                                                                 |
| <b>Purpose</b>            | Operation test/Check                                            |
| <b>Function (Purpose)</b> | Used to check the relay operation. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                             |
| <b>Item</b>               | Operation                                                       |

#### Operation/Procedure

- 1) Enter the number corresponding to the check item with 10-key.
- 2) Press [START] key.

SIMULATION 66-31  
TEL/LIU SETTING.  
INPUT 0-1, AND PRESS START.  
1. **MPXA** 2. CION 3. MR 4. EC  
5. **S.** 6. **CML** 7. DP 8.

1 2 3 4 5 6 7 8  
**10001100**

66-32

|                           |                                                                                         |
|---------------------------|-----------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                    |
| <b>Function (Purpose)</b> | Used to check the receive data (fixed data) from the line. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                     |
| <b>Item</b>               | Operation                                                                               |

**Operation/Procedure**

When check is completed normally, "OK" is displayed. In case of an error, "NG" is displayed.

(Display message)

|          |                         |
|----------|-------------------------|
| CHECKING | Checking                |
| OK       | Checking completed (OK) |
| NG       | Checking completed (NG) |

SIMULATION 66-32  
RECEIVED DATA CHECK.  
CHECKING... (OK or NG)

66-33

|                           |                                                                                                 |
|---------------------------|-------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                            |
| <b>Function (Purpose)</b> | Used to check the signal (BUSY TONE/CNG/ CED/FNET/DTMF) detection. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                             |
| <b>Item</b>               | Operation                                                                                       |

**Operation/Procedure**

The detected signal is highlighted.

SIMULATION 66-33  
SIGNAL DETECT CHECK.  
BUSY TONE **CNG** CED FNET DTMF

66-34

|                           |                                                                                         |
|---------------------------|-----------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                    |
| <b>Function (Purpose)</b> | Used to measure the communication time of test image data. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                     |
| <b>Item</b>               | Operation                                                                               |

**Operation/Procedure**

Communication test is performed to measure the time (ms).

Send is made under the following conditions.

|                     |             |
|---------------------|-------------|
| Communication means | Memory send |
| Image quality       | Normal text |
| Density             | Light       |
| ECM                 | ON          |
| Sender record       | OFF         |

SIMULATION 66-34  
COMMUNICATION TIME DISPLAY.  
  
\* \* \* \* \* ms

66-35

|                           |                                                                                                   |
|---------------------------|---------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                                                           |
| <b>Function (Purpose)</b> | Modem program reloading (Only when FAX is installed)<br>Not used in the market. (For development) |
| <b>Section</b>            | FAX                                                                                               |
| <b>Item</b>               | Data                                                                                              |

**Operation/Procedure**

1) Select YES/NO of Modem program reload.

|   |     |                                |
|---|-----|--------------------------------|
| 1 | YES | Modem block reload is cleared. |
| 2 | NO  | Not reloaded.                  |

2) Press [START] key.

When reload is completed normally, "OK" is displayed. In case of an error, "CHECK SUM" is displayed.

The result of Modem reload is displayed.

|          |                  |
|----------|------------------|
| COMPLETE | Reload completed |
| 81       | Check sum error  |
| 82       | Write error      |
| 83       | Delete error     |
| 84       | Verify error     |
| NG       | Due to loader NG |

SIMULATION 66-35  
MODEM PROGRAM RELOAD.  
ARE YOU SURE?  
1. YES  
2. NO

1

Press [START] key.

SIMULATION 66-35  
MODEM PROGRAM RELOAD. EXECITOMG...  
LOADER... xxxxx  
MODEM... xxxxx

After completion of reloading

SIMULATION 66-35  
MODEM PROGRAM RELOAD.  
LOADER... OK  
MODEM... COMPLETE

66-36

|                           |                                                                                                                                     |
|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                |
| <b>Function (Purpose)</b> | Used to check interface between MFPC controller and MDMC. (Check of the data line or the command line) (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                                                                                 |
| <b>Item</b>               | Operation                                                                                                                           |

**Operation/Procedure**


1) Enter the number corresponding to the check mode with 10-key.

|   |             |                        |
|---|-------------|------------------------|
| 1 | MFPC ← MDMC | Date line once only    |
| 2 | MFPC → MDMC | Date line once only    |
| 3 | MFPC ← MDMC | Data line repeat       |
| 4 | MFPC → MDMC | Data line repeat       |
| 5 | MFPC ← MDMC | Command line once only |
| 6 | MFPC → MDMC | Command line once only |
| 7 | MFPC ← MDMC | Command line repeat    |
| 8 | MFPC → MDMC | Command line repeat    |

2) Press [START] key.

When check is completed normally, "OK" is displayed. In case of an error, "NG" is displayed.


When check is "repeat," the operation is continued until the result is NG or [CUSTOM SETTINGS] key is pressed.



|                           |                                                                          |
|---------------------------|--------------------------------------------------------------------------|
| <b>66-39</b>              |                                                                          |
| <b>Purpose</b>            | Setting                                                                  |
| <b>Function (Purpose)</b> | Used to set the destination specifications. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                                      |
| <b>Item</b>               | Specifications Operation                                                 |

#### Operation/Procedure

- Enter the number corresponding to the destination.
- Press [START] key.



|                           |                                                    |
|---------------------------|----------------------------------------------------|
| <b>66-42</b>              |                                                    |
| <b>Purpose</b>            | Setting                                            |
| <b>Function (Purpose)</b> | PIC program rewriting (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                |
| <b>Item</b>               | Operation                                          |

#### Operation/Procedure

- The confirmation window is displayed. Select whether rewriting of the program into PIC installed in the FAX VOX is performed or not.

NOTE: Release the write protect notch.

FAX program writing enabled (Jumpers and DIP SW depending on the model.)


|   |     |           |
|---|-----|-----------|
| 1 | YES | Execution |
| 2 | NO  | Cancel    |

- Press [START] key.

When reload is completed normally, "OK" is displayed. In case of an error, "NG" is displayed.

NG cause:

- Write protect is set.
- PIC is not installed.
- Access error to PIC



|                           |                                                           |
|---------------------------|-----------------------------------------------------------|
| <b>66-43</b>              |                                                           |
| <b>Purpose</b>            | Setting                                                   |
| <b>Function (Purpose)</b> | PIC adjustment value writing (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                       |
| <b>Item</b>               | Operation                                                 |

#### Operation/Procedure

To execute this simulation, FAX program writing must be allowed. (Jumpers and DIP SW depending on the model.) The adjustment values in PIC are changed or rewritten.

- Enter the number corresponding to the set item with 10-key.
- Press [START] key.
- Enter the set value.
- Press [P] key.
- Select 0.

- 6) The confirmation window is displayed. Select whether the PIC adjustment values are written or not.

|     |                                                                                   |
|-----|-----------------------------------------------------------------------------------|
| YES | The adjustment values are collectively written into PIC installed in the FAX BOX. |
| NO  | No writing                                                                        |

When writing of the PIC adjustment values is normally completed, "OK" is displayed. In case of an error, "NG" is displayed.

| Item | Content           | Set range                                               | Default |
|------|-------------------|---------------------------------------------------------|---------|
| 0    | WRITING to PIC    | Writing to PIC                                          | —       |
| 1    | ci_level_judge    | Number of sensing until the CI signal level is setteld. | 1-15    |
| 2    | ci_cycle_min      |                                                         | 0-254   |
| 3    | ci_cycle_max      |                                                         | 0-254   |
| 4    | ci_range          |                                                         | 0-127   |
| 5    | ci_count          |                                                         | 1-15    |
| 6    | ci_detect         |                                                         | 1-15    |
| 7    | fnet_level_judge  |                                                         | 1-15    |
| 8    | fnet_range        |                                                         | 0-74    |
| 9    | fnet_time_out     |                                                         | 76-255  |
| 10   | fnet_count        |                                                         | 1-15    |
| 11   | poff_time         |                                                         | 0-15    |
| 12   | mswon_level_judge |                                                         | 2-15    |

66-60

|                           |                                                        |
|---------------------------|--------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                |
| <b>Function (Purpose)</b> | Used to set the ACR data. (Only when FAX is installed) |
| <b>Section</b>            | FAX                                                    |
| <b>Item</b>               | Operation                                              |

#### Operation/Procedure

- 1) Enter the number corresponding to the set item with 10-key.  
The item list menu can be switched by pressing [P] key.


- 2) Press [START] key.

- 3) Enter the set value.

- 4) Press [START] key.

This simulation can be executed when soft SW 24-4 and 24-5 are set to 1. Display/Not display is switched by soft SW 24-4 and 24-5.

The digit limitation and characters allowed to be inputted depend on the input item.





67-2

|                           |                                                                                                                                                                              |
|---------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                                                                                                                                                         |
| <b>Function (Purpose)</b> | Used to check the operation of the parallel I/F of the printer. (This simulation is for production only, and requires a special tool for execution. Not used in the market.) |
| <b>Section</b>            | MFP controller                                                                                                                                                               |
| <b>Item</b>               | Operation Interface/Communication                                                                                                                                            |

**Operation/Procedure**

(Display message)

|          |                                         |
|----------|-----------------------------------------|
| WAITING  | Waiting                                 |
| READY    | Check start OK                          |
| OK       | Check end (Normal)                      |
| STAGE*NG | Check end (Error in stage *. *: 1 - 11) |

SIMULATION 67-2CENTRO PORT CHECK.  
CENTRO PORT: **READY**↓  
IWith READY displayed,  
press [START] key.↑  
Press [CUSTOM SETTINGS] key.SIMULATION 67-2CENTRO PORT CHECK.  
CENTRO PORT: **OK** (or **STAGE7 NG**)

67-11

|                           |                                                                      |
|---------------------------|----------------------------------------------------------------------|
| <b>Purpose</b>            | Setting                                                              |
| <b>Function (Purpose)</b> | Used to set YES/NO of the parallel I/F select signal of the printer. |
| <b>Section</b>            | MFP controller                                                       |
| <b>Item</b>               | Operation Interface/Communication                                    |

**Operation/Procedure**

- 1) Enter the number corresponding to the select IN signal YES/NO setting with 10-key.

| Item |     | Default |
|------|-----|---------|
| 0    | OFF | 1       |
| 1    | ON  |         |

- 2) Press [START] key.

When the printer parallel I/F is used and a trouble is generated in the communication between the PC and the printer, change the setting of this simulation.

SIMULATION 67-11CENTRO SELECT IN SIGNAL SETTING. SELECT 0-1, AND PRESS  
START.  
0. OFF  
1. ON

67-16

|                           |                                                  |
|---------------------------|--------------------------------------------------|
| <b>Purpose</b>            | Operation test/Check                             |
| <b>Function (Purpose)</b> | Used to check the operation of the network card. |
| <b>Section</b>            | MFP controller                                   |
| <b>Item</b>               | Operation Interface/Communication                |

**Operation/Procedure**

During check, "CHECKING" is displayed. When check is completed normally, "OK" is displayed. In case of an error, "NG" is displayed.

(Display message)


|          |                    |
|----------|--------------------|
| CHECKING | Checking           |
| OK       | Check end (Normal) |
| NG       | Check end (Error)  |

SIMULATION 67-16NETWORK INTERFACE CARD CHECK.  
NIC: CHECKING↓  
Check end↑  
Press [CUSTOM SETTINGS] key.SIMULATION 67-16NETWORK INTERFACE CARD CHECK.  
NIC: OK (or NG)

### 3. Other related items

#### (1) Simulation adjustment value/ Set value data

Each controller is provided with an EEPROM. The adjustment/set values are collected to the MFP controller. If they are changed, they are sent back and saved.



#### ● Data saved by the PCU PWB

| Counters                                      | Adjustment value                                                                                  | Other                                           |
|-----------------------------------------------|---------------------------------------------------------------------------------------------------|-------------------------------------------------|
| Drum rotation time counter (Accumulated time) | Developing bias voltage value                                                                     | Serial number                                   |
| Developer unit rotation time counter          | Cleaning mode developing bias voltage value                                                       | Trouble history                                 |
| Toner supply time (Block IC CHIP)             | Main high voltage adjustment                                                                      | Tray 1 size                                     |
| Drum rotating time (Block IC CHIP)            | Transfer charger voltage value                                                                    | LCC size                                        |
| Total counter                                 | Transfer belt cleaning voltage value                                                              | Manual destination information                  |
| Maintenance counter                           | Toner concentration reference value                                                               |                                                 |
| Developing counter                            | Density correction start set time (Developer unit)                                                | Tray 2 destination information                  |
| Drum counter                                  | Density correction rotation time (Developer tank)                                                 |                                                 |
| Toner cartridge counter                       | Density correction amount (Developer tank)                                                        | Tray 1 paper remaining quantity data            |
| Valid paper counter                           | Correction execution direction, upper/lower limit (Developer tank)                                | Tray 2 paper remaining quantity data            |
| Tray 1 paper feed counter                     | Toner concentration temperature correction (low temperature side) correction amount               | Tray 3 paper remaining quantity data            |
| Tray 2 paper feed counter                     | Toner concentration temperature correction (low temperature side) set temperature                 | Tray 4 paper remaining quantity data            |
| Tray 3 paper feed counter                     | Toner concentration temperature correction (low temperature side) release temperature             | Final toner concentration sensor output value   |
| Tray 4 paper feed counter                     | Toner concentration temperature correction (high temperature side) correction amount              | Toner cartridge IC CHIP destination             |
| Manual paper feed counter                     | Toner concentration temperature correction (high temperature side) judgment temperature           | Counter mode setting                            |
| ADU paper feed counter                        | Toner concentration temperature correction (high temperature side) judgment voltage               | White paper exit count setting                  |
| Staple counter                                | Toner concentration temperature correction (high temperature side) correction value               | Trouble memory mode setting                     |
| Punch counter                                 | Toner concentration temperature correction (low temperature side) release time                    | Fusing operation mode (Prevention against curl) |
| Main unit right-side paper exit counter       | Toner concentration temperature correction (high temperature side) toner concentration delay time | CE mark conforming operation mode               |
|                                               | Multi-purpose width adjustment value                                                              | Maintenance cycle                               |
|                                               | Manual width adjustment value                                                                     | Print stop setting when developer life over     |
| Saddle staple counter                         | Heater lamp temperature (Center, normal control)                                                  | Saddle alignment operation priority mode        |
|                                               | Lead edge adjustment                                                                              |                                                 |
|                                               | Led edge void set value                                                                           |                                                 |
|                                               | Rear edge void set value                                                                          |                                                 |
|                                               | Side edge setting                                                                                 |                                                 |
|                                               | Print off-center adjustment value                                                                 |                                                 |
|                                               | Resist amount adjustment value                                                                    |                                                 |
|                                               | Laser power adjustment value                                                                      |                                                 |
|                                               | PPD1 sensor adjustment                                                                            |                                                 |
|                                               | Process correction inhibit allow set value                                                        |                                                 |
|                                               | Developing bias rising correction wait time                                                       |                                                 |
|                                               | Developing bias rising correction adjustment value                                                |                                                 |
|                                               | Built-in finisher jogger position adjustment                                                      |                                                 |
|                                               | Saddle adjustment value                                                                           |                                                 |

● Data saved by the scanner control PWB

| Counters               | Adjustment value                            | Other                                       |
|------------------------|---------------------------------------------|---------------------------------------------|
| Scan counter           | Document lead edge adjustment value         | Exposure mode set value                     |
| SPF paper pass counter | Document off-center adjustment value        | Scanner serial number                       |
| SPF stamp counter      | Document image loss amount adjustment value | Document image loss amount adjustment value |
|                        | Magnification ratio adjustment value        |                                             |
|                        | SPF resist amount adjustment value          |                                             |
|                        | Exposure motor speed adjustment value       |                                             |
|                        | Platen document detection adjustment value  |                                             |
|                        | SPF size width detection adjustment value   |                                             |
|                        | Touch panel adjustment value                |                                             |
|                        | Exposure level adjustment value             |                                             |
|                        | γ change value                              |                                             |
|                        | OC/SPF exposure correction value            |                                             |
|                        | Shading adjustment value (CCD/CIS)          |                                             |
|                        | CCD shading start position adjustment value |                                             |

● Data saved by the MFP control PWB

| Counters                | Adjustment value   | Other                                                   |
|-------------------------|--------------------|---------------------------------------------------------|
| Copy counter            | FAX SOFT SW., etc. | Trouble history                                         |
| Printer counter         |                    | JAM history                                             |
| FAX receive counter     |                    | Destination setting                                     |
| FAX send counter        |                    | Language setting                                        |
| All valid paper counter |                    | Toner save mode setting                                 |
| Trouble counter         |                    | 13" setting                                             |
| JAM counter             |                    | Auditor setting                                         |
|                         |                    | Counter mode setting                                    |
|                         |                    | Trouble memory mode setting                             |
|                         |                    | Center binding mode AMS setting                         |
|                         |                    | PC/MODEM communication trouble detection YES/NO setting |
|                         |                    | Tag number set value                                    |
|                         |                    | Printers set values                                     |
|                         |                    | Network set value                                       |

# [10] TROUBLE CODES

## 1. General

When a trouble occurs in the machine or when the life of a consumable part is nearly expired or when the life is expired, the machine detects and displays it on the display section. This allows the user and the serviceman to take the suitable action. In case of a trouble, this feature notifies the occurrence of a trouble and stops the machine to minimize the damage.

- 1) Securing safety. (The machine is stopped on detection of a trouble.)
- 2) The damage to the machine is minimized. (The machine is stopped on detection of a trouble.)
- 3) By displaying the trouble content, the trouble position can be quickly identified. (This allows to perform an accurate repair, improving the repair efficiency.)
- 4) Preliminary warning of running out of consumable parts allows to arrange for new parts in advance of running out. (This avoids stopping of the machine due to running out the a consumable part.)

## 2. Trouble codes list

| Trouble codes |    | Contents                                                                                   | Remark                          | Trouble detection |
|---------------|----|--------------------------------------------------------------------------------------------|---------------------------------|-------------------|
| C1            | 00 | MC trouble                                                                                 |                                 | PCU               |
| E6            | 11 | CSI shading trouble (White correction)                                                     | When the scanner is installed   | SCANNER           |
|               | 14 | CIS communication trouble                                                                  | When the scanner is installed   | SCANNER           |
| E7            | 01 | System data trouble                                                                        |                                 | ICU               |
|               | 02 | Laser trouble                                                                              |                                 | PCU               |
|               | 03 | HDD trouble                                                                                | With HDD installed              | Controller        |
|               | 06 | Decode error trouble                                                                       |                                 | Controller        |
|               | 10 | Shading trouble (Black correction)                                                         | When the scanner is installed   | SCANNER           |
|               | 11 | Shading trouble (White correction all pixel adjustment)                                    | When the scanner is installed   | SCANNER           |
|               | 14 | CCD communication trouble                                                                  | When the scanner is installed   | SCANNER           |
|               | 17 | SPF scanning position adjustment trouble (Detected only when executing an adjustment SIM.) |                                 |                   |
|               | 50 | LSU connection trouble                                                                     |                                 | PCU               |
|               | 80 | Communication trouble (ICU detection) between ICU and scanner                              | When the scanner is installed   | ICU               |
|               | 90 | Communication trouble (ICU detection) between ICU and PCU                                  | When the scanner is installed   | ICU               |
| F1            | 00 | Finisher communication trouble                                                             | With Finisher installed         | PCU               |
|               |    | Mail-bin stacker communication trouble                                                     | With Mail bin stacker installed | PCU               |

| Trouble codes |    | Contents                                                               | Remark                          | Trouble detection |
|---------------|----|------------------------------------------------------------------------|---------------------------------|-------------------|
| F1            | 02 | Finisher transport motor abnormality                                   | With Finisher installed         | PCU               |
|               |    | Mail-bin stacker transport motor abnormality                           | With Mail bin stacker installed |                   |
|               | 03 | Console finisher paddle motor trouble                                  | With Console Finisher installed | PCU               |
|               | 06 | Console finisher slide motor trouble                                   | With Console Finisher installed | PCU               |
|               | 08 | Finisher staple shift motor trouble                                    | With Finisher installed         | PCU               |
|               | 10 | Finisher stapler motor trouble                                         | With Finisher installed         | PCU               |
|               |    | Console finisher stapler motor trouble                                 | With Console Finisher installed | PCU               |
|               | 11 | Finisher bundle exit motor trouble                                     | With Finisher installed         | PCU               |
|               |    | Console finisher bundle exit motor trouble                             | With Console Finisher installed | PCU               |
|               | 12 | Mail-bin stacker gate trouble                                          | With Mail bin stacker installed | PCU               |
|               | 15 | Finisher lift motor trouble                                            | With Finisher installed         | PCU               |
|               |    | Console finisher lift motor trouble                                    | With Console Finisher installed | PCU               |
|               | 19 | Finisher front alignment motor trouble                                 | With Finisher installed         | PCU               |
|               |    | Console finisher front alignment motor trouble                         | With Console Finisher installed | PCU               |
|               | 20 | Finisher rear alignment motor trouble                                  | With Finisher installed         | PCU               |
|               |    | Console finisher rear alignment motor trouble                          | With Console Finisher installed | PCU               |
|               | 30 | Console finisher communication trouble                                 | With Console Finisher installed | PCU               |
|               | 31 | Console finisher fold sensor trouble                                   | With Console Finisher installed | PCU               |
|               | 32 | Communication trouble between the console finisher and the punch unit. | With Console Finisher installed | PCU               |
|               | 33 | Console finisher punch side registration motor trouble                 | With Console Finisher installed | PCU               |
|               | 34 | Console finisher punch motor trouble                                   | With Console Finisher installed | PCU               |
|               | 35 | Console finisher punch side registration sensor trouble                | With Console Finisher installed | PCU               |

| Trouble codes | Contents                                                                                            | Remark                          | Trouble detection |
|---------------|-----------------------------------------------------------------------------------------------------|---------------------------------|-------------------|
| F1            | 36 Console finisher punch timing sensor trouble                                                     | With Console Finisher installed | PCU               |
|               | 37 Console finisher backup RAM trouble                                                              | With Console Finisher installed | PCU               |
|               | 38 Console finisher punch backup RAM trouble                                                        | With Console Finisher installed | PCU               |
|               | 39 Console finisher punch dust sensor trouble                                                       | With Console Finisher installed | PCU               |
|               | 40 Console finisher punch power interruption trouble                                                | With Console Finisher installed | PCU               |
|               | 80 Finisher power abnormality                                                                       | With Finisher installed         | PCU               |
|               | Mail-bin stacker power abnormality                                                                  | With Mail bin stacker installed | PCU               |
|               | 81 Console finisher transport motor abnormality                                                     | With Console Finisher installed | PCU               |
|               | 87 Finisher staple rotation motor trouble                                                           | With Finisher installed         |                   |
| F2            | 00 Toner control sensor open/sensor trouble                                                         |                                 | PCU               |
|               | 02 Toner supply abnormality                                                                         |                                 | PCU               |
|               | 04 Improper cartridge (life cycle error, etc.)                                                      |                                 | PCU               |
|               | 05 CRUM error                                                                                       |                                 | PCU               |
|               | 39 Process thermistor trouble                                                                       |                                 | PCU               |
| F3            | 12 Machine no. 1 tray lift-up trouble                                                               |                                 | PCU               |
|               | 22 Machine tray 2 lift-up trouble                                                                   | Multi-purpose tray              | PCU               |
| F6            | 00 Communication trouble (ICU detection) between ICU and FAX                                        | When the Fax board is installed | ICU               |
|               | 01 FAX expansion flash memory abnormality (ICU detection)                                           | When the Fax board is installed | ICU               |
|               | 04 FAX modem operation abnormality                                                                  | When the Fax board is installed | FAX               |
|               | 20 FAX write protect cancel                                                                         | When the Fax board is installed | FAX               |
|               | 21 Combination abnormality of the TEL/LIU PWB and the FAX soft switch                               | When the Fax board is installed | FAX               |
|               | 97 FAX-BOX skating trouble                                                                          | When the Fax board is installed | FAX               |
|               | 98 Combination error of the FAX-BOX destination information and the machine destination information | When the Fax board is installed | FAX               |
| F7            | 01 FAX board EEPROM read/write error                                                                | When the Fax board is installed | FAX               |
| H2            | 00 Thermistor open (HL1)                                                                            |                                 | PCU               |
|               | 01 Thermistor open (HL2)                                                                            |                                 | PCU               |
| H3            | 00 Fusing section high temperature trouble (HL1)                                                    |                                 | PCU               |
|               | 01 Fusing section high temperature trouble (HL2)                                                    |                                 | PCU               |

| Trouble codes | Contents                                              | Remark                          | Trouble detection |
|---------------|-------------------------------------------------------|---------------------------------|-------------------|
| H4            | 00 Fusing section low temperature trouble (HL1)       |                                 | PCU               |
|               | 01 Fusing section low temperature trouble (HL2)       |                                 | PCU               |
| H5            | 01 5-time continuous POD1 not-reaching jam detection  |                                 | PCU               |
| L1            | 00 Scanner feed trouble                               | When the scanner is installed   | SCANNER           |
| L3            | 00 Scanner return trouble                             | When the scanner is installed   | SCANNER           |
| L4            | 01 Main motor lock detection                          |                                 | PCU               |
|               | 02 Drum motor lock detection                          |                                 | PCU               |
|               | 30 Controller fan motor lock detection                |                                 |                   |
| L6            | 10 Polygon motor lock detection                       |                                 | PCU               |
| L8            | 01 No fullwave signal                                 |                                 | PCU               |
|               | 02 Full wave signal width abnormality                 |                                 | PCU               |
| U1            | 01 FAX battery abnormality                            | With FAX board installed        | Controller        |
|               | 02 RTC read abnormality (common with FAX, on ICU PWB) | When the Fax board is installed | ICU               |
| U2            | 00 EEPROM read/write error (ICU)                      |                                 | Controller        |
|               | 11 Counter check sum error (ICU)                      |                                 | Controller        |
|               | 12 Adjustment value check sum error (ICU)             |                                 | Controller        |
|               | 22 SRAM memory check sum error (ICU)                  |                                 | ICU               |
|               | 23 SRAM memory individual data check sum error (ICU)  |                                 |                   |
|               | 50 HD section individual data check sum error (ICU)   |                                 |                   |
|               | 80 EEPROM read/write error (Scanner)                  | When the scanner is installed   | SCANNER           |
|               | 81 Memory check sum error (Scanner)                   | When the scanner is installed   | SCANNER           |
|               | 90 EEPROM read/write error (PCU)                      |                                 | PCU               |
| U6            | 91 Memory check sum error (PCU)                       |                                 | PCU               |
|               | 00 Desk/LCC communication trouble                     | With Paper feed desk installed  | PCU               |
|               | 01 Desk/LCC No. 1 tray lift-up trouble                | With Paper feed desk installed  | PCU               |
|               | 02 Desk No. 2 tray/LCC1 lift-up trouble               | With Paper feed desk installed  | PCU               |
|               | 03 Desk No. 3 tray/LCC2 lift-up trouble               | With Paper feed desk installed  | PCU               |
| U7            | 10 Desk/LCC transport motor trouble                   | With Paper feed desk installed  | PCU               |
|               | 00 RIC communication trouble                          |                                 | Controller        |

| Trouble codes |    | Contents                                        | Remark           | Trouble detection |
|---------------|----|-------------------------------------------------|------------------|-------------------|
| CH            | -- | Door open (CH ON)                               |                  | PCU               |
|               | 00 | No developer cartridge                          |                  | PCU               |
|               | 01 | No toner cartridge                              |                  | PCU               |
|               | 02 | No drum cartridge                               |                  | PCU               |
| EE            | EL | Auto developer adjustment trouble (Over-toner)  | Only during DIAG | PCU               |
|               | EU | Auto developer adjustment trouble (Under-toner) | Only during DIAG | PCU               |
| PC            | -- | Personal counter not installed                  |                  | Controller        |
| PF            | -- | RIC copy inhibit signal is received.            |                  | Controller        |
| --            | -- | Auditor not ready                               |                  | Controller        |

### 3. Details of trouble codes

| MAIN | SUB | Details          |                                                                                                                                                                                                          |
|------|-----|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| C1   | 00  | Content          | MC trouble                                                                                                                                                                                               |
|      |     | Detail           | Main charger output abnormality (Output open)<br>Trouble signal is outputted from the high voltage transformer.                                                                                          |
|      |     | Cause            | The main charger is not installed properly.<br>The main charger is not assembled properly.<br>Disconnection of connector of high voltage transformer.<br>High voltage harness disconnection or breakage. |
|      |     | Check and remedy | Use the SIM 8-2 to check the main charger output.<br>Check for disconnection of the main charger.<br>Replace the high voltage unit.                                                                      |
| E6   | 11  | Content          | CSI shading trouble (White correction)                                                                                                                                                                   |
|      |     | Details          | The CIS white reference plate scan level is abnormal when the lamp is on.                                                                                                                                |
|      |     | Cause            | Abnormal harness installation to CIS unit<br>Dirt on the white reference plate.<br>CIS lighting error<br>CIS unit installation trouble<br>CIS unit abnormality<br>Scanner PWB abnormality                |
|      |     | Check & Remedy   | Clean the white reference plate.<br>Check CIS light quantity (SIM 5-3) and lighting.<br>Check CIS unit harness.<br>Check scanner PWB.                                                                    |
|      | 14  | Content          | CIS communication trouble                                                                                                                                                                                |
|      |     | Details          | Communication trouble (clock sync) between scanner PWB and CIS-ASIC                                                                                                                                      |
|      |     | Cause            | Abnormal harness installation to CIS unit<br>CIS unit abnormality<br>Scanner PWB abnormality                                                                                                             |
|      |     | Check & Remedy   | Check CIS unit harness.<br>Check CIS unit.<br>Check scanner PWB.                                                                                                                                         |

| MAIN | SUB | Details          |                                                                                                                                                                                                                                                                                                                    |
|------|-----|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E7   | 01  | Content          | System data trouble                                                                                                                                                                                                                                                                                                |
|      |     | Detail           | When in data storage/acquiring of the HDD system area, the HDD responds an error and does not respond for 30sec, it is judged as a trouble.                                                                                                                                                                        |
|      |     | Cause            | The HDD is not properly installed to the ICU PWB.<br>The HDD does not work for the ICU PWB.<br>ICU PWB abnormality                                                                                                                                                                                                 |
|      |     | Check and remedy | Check installation of the HDD to the ICU PWB.<br>Check harness connection of the HDD from the ICU PWB.<br>Use SIM62-2, 3 to check the HDD read/write.<br>Replace the HDD.<br>Replace the ICU PWB.                                                                                                                  |
| E7   | 02  | Content          | Laser trouble                                                                                                                                                                                                                                                                                                      |
|      |     | Detail           | BD signal from LSU is kept OFF, or ON.                                                                                                                                                                                                                                                                             |
|      |     | Cause            | The connector of LSU or the harness in LSU is disconnected or broken.<br>The polygon motor does not rotate normally.<br>The laser home position sensor in LSU is shifted.<br>The proper voltage is not supplied to the power line for laser.<br>Laser emitting diode trouble<br>PCU PWB trouble<br>ICU PWB trouble |
|      |     | Check and remedy | Check for disconnection of the LSU connector.<br>Use SIM 61-1 to check LSU operation.<br>Check that the polygon motor rotates normally or not.<br>Check light emission of laser emitting diode.<br>Replace the LSU unit.<br>Replace the PCU PWB.<br>Replace the ICU PWB.                                           |
|      | 03  | Content          | HDD trouble                                                                                                                                                                                                                                                                                                        |
|      |     | Detail           | HDD connection failure<br>If the HDD responds an error or does not respond for 30sec, it is judged as an error. (Other than the system area)<br>Data abnormality in the file management area (when the cluster chain is broken)                                                                                    |
|      |     | Cause            | HDD is not installed properly to the ICU PWB.<br>HDD does not operate properly in the ICU PWB.<br>ICU PWB trouble                                                                                                                                                                                                  |
|      |     | Check and remedy | Check installation of HDD to the ICU PWB.<br>Check connection of the harness of HDD to the ICU PWB.<br>Use SIM 62-2, -3 to check read/write of HDD.<br>Replace HDD.<br>Replace ICU PWB.                                                                                                                            |

| MAIN | SUB | Details          |                                                                                                                                                                                                                           |
|------|-----|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E7   | 06  | Content          | Decode error trouble                                                                                                                                                                                                      |
|      |     | Detail           | A decode error occurs during making of an image.                                                                                                                                                                          |
|      |     | Cause            | Data error during input from PCI to PM.<br>PM trouble<br>Data error during image compression/transfer.<br>ICU PWB abnormality                                                                                             |
|      |     | Check and remedy | Check insertion of the PWB. (PCI bus)<br>If the error occurred in a FAX job, check installation of the FAX PWB.<br>For the other cases, check the ICU PWB.<br>Replace the ICU PWB.                                        |
|      | 10  | Content          | Shading trouble (Black correction)                                                                                                                                                                                        |
|      |     | Details          | CCD black scan level abnormality when the copy lamp is off.                                                                                                                                                               |
|      |     | Cause            | Abnormal installation of flat cable to CCD unit.<br>CCD unit abnormality<br>Scanner PWB abnormality                                                                                                                       |
|      |     | Check & Remedy   | Check installation of CCD unit flat cable.<br>Check CCD unit.<br>Check scanner PWB.                                                                                                                                       |
|      | 11  | Content          | Shading trouble (White correction all pixel adjustment)                                                                                                                                                                   |
|      |     | Details          | CCD white reference plate scan level abnormality when the copy lamp is ON.                                                                                                                                                |
|      |     | Cause            | Abnormal installation of flat cable to CCD unit.<br>Dirt on mirror, lens, white reference plate<br>Copy lamp lighting abnormality<br>Abnormal installation of CCD unit<br>CCD unit abnormality<br>Scanner PWB abnormality |
|      |     | Check & Remedy   | Clean mirror, lens, and white reference plate.<br>Check copy lamp light quantity (SIM 5-3) and lighting.<br>Check CCD unit.<br>Check scanner PWB.                                                                         |
|      | 14  | Content          | CCD communication trouble                                                                                                                                                                                                 |
|      |     | Details          | Communication trouble (clock sync) between scanner PWB and CCD-ASIC                                                                                                                                                       |
|      |     | Cause            | Abnormal installation of harness to CCD unit<br>CCD unit abnormality<br>Scanner PWB abnormality                                                                                                                           |
|      |     | Check & Remedy   | Check CCD unit harness.<br>Check CCD unit.<br>Check scanner PWB.                                                                                                                                                          |
|      | 17  | Content          | SPF scanning position adjustment trouble (Detected only when executing an adjustment SIM.)                                                                                                                                |
|      |     | Details          | The black Mylar which serves as the reference of the SPF scanning position is not detected.                                                                                                                               |
|      |     | Cause            | Black Mylar installing failure on the SPF side                                                                                                                                                                            |
|      |     | Check & Remedy   | Check the SPF black Mylar.                                                                                                                                                                                                |

| MAIN | SUB | Details          |                                                                                                                                                                |                                                                                                                                                                                            |
|------|-----|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| E7   | 50  | Content          | LSU connection trouble                                                                                                                                         |                                                                                                                                                                                            |
|      |     | Detail           | An LSU which does not conform to the machine is installed.                                                                                                     |                                                                                                                                                                                            |
|      |     | Cause            | LSU connection trouble<br>PCU PWB trouble<br>LSU trouble                                                                                                       |                                                                                                                                                                                            |
|      |     | Check and remedy | Check LSU PWB. Check PCU PWB.<br>Check connection of the connector and the harness between PCU and LSU.                                                        |                                                                                                                                                                                            |
|      | 80  | Content          | Communication trouble (ICU detection) between ICU and scanner                                                                                                  |                                                                                                                                                                                            |
|      |     | Details          | Communication establishment error/<br>Fleming/Parity/Protocol error                                                                                            |                                                                                                                                                                                            |
|      |     | Cause            | Defective connection of slave unit PWB connector<br>Defective harness between slave unit PWB and ICU PWB<br>Slave unit PWB mother board connector pin breakage |                                                                                                                                                                                            |
|      |     | Check & Remedy   | Check connector and harness of slave unit PWB and ICU PWB.<br>Check grounding of machine.                                                                      |                                                                                                                                                                                            |
|      | 90  | Content          | Communication trouble (ICU detection) between ICU and PCU                                                                                                      |                                                                                                                                                                                            |
|      |     | Details          | Communication establishment error/<br>Fleming/Parity/Protocol error                                                                                            |                                                                                                                                                                                            |
|      |     | Cause            | Defective connection of slave unit PWB connector<br>Defective harness between slave unit PWB and ICU PWB<br>Slave unit PWB mother board connector pin breakage |                                                                                                                                                                                            |
|      |     | Check & Remedy   | Check connector and harness of slave unit PWB and ICU PWB.<br>Check grounding of machine.                                                                      |                                                                                                                                                                                            |
|      | F1  | 00               | Content                                                                                                                                                        | Finisher communication trouble                                                                                                                                                             |
|      |     |                  | Detail                                                                                                                                                         | Communication cable test error after turning on the power or exiting from SIM.<br>Communication error with the finisher                                                                    |
|      |     |                  | Cause                                                                                                                                                          | Improper connection or disconnection of connectors and harness between the machine and the finisher.<br>Finisher control PWB trouble<br>Control PWB (PCU) trouble<br>Malfunction by noises |
|      |     |                  | Check and remedy                                                                                                                                               | Canceled by turning OFF/ON the power.<br>Check connectors and harness in the communication line.<br>Replace the finisher control PWB or PCU PWB.                                           |

| MAIN | SUB | Details          |                                                                                                                                                                                                           |
|------|-----|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F1   | 00  | Content          | Mail-bin stacker communication trouble                                                                                                                                                                    |
|      |     | Detail           | Communication cable test error after turning on the power or exiting from SIM.<br>Communication error with the Mail-bin stacker.                                                                          |
|      |     | Cause            | Improper connection or disconnection of connector and harness between the machine and the Mail-bin stacker.<br>Mail-bin stacker control PWB trouble<br>Control PWB (PCU) trouble<br>Malfunction by noises |
|      |     | Check and remedy | Canceled by turning OFF/ON the power.<br>Check harness and connector in the communication line.<br>Replace the Mail-bin stacker PWB or PCU PWB.                                                           |
|      | 02  | Content          | Finisher transport motor abnormality                                                                                                                                                                      |
|      |     | Detail           | Transport motor drive trouble                                                                                                                                                                             |
|      |     | Cause            | Motor lock<br>Motor RPM abnormality<br>Overcurrent to the motor<br>Finisher control PWB trouble                                                                                                           |
|      |     | Check and remedy | Use SIM 3-3 to check the transport motor operation.                                                                                                                                                       |
|      | 02  | Content          | Mail-bin stacker transport motor abnormality                                                                                                                                                              |
|      |     | Detail           | Transport motor trouble                                                                                                                                                                                   |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Mail-bin stacker control PWB trouble                                                                                                   |
|      |     | Check and remedy | Use SIM3-21 to check the transport motor operation.                                                                                                                                                       |
|      | 03  | Content          | Console finisher paddle motor trouble                                                                                                                                                                     |
|      |     | Detail           | Paddle motor operation abnormality                                                                                                                                                                        |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                                                                                   |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                                                  |
|      | 06  | Content          | Console finisher slide motor trouble                                                                                                                                                                      |
|      |     | Detail           | Slide motor operation abnormality                                                                                                                                                                         |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                                                                                   |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                                                  |
|      | 08  | Content          | Finisher staple shift motor trouble                                                                                                                                                                       |
|      |     | Detail           | Staple motor drive trouble                                                                                                                                                                                |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Finisher control PWB trouble                                                                                                           |
|      |     | Check and remedy | Use SIM3-3 to check operations of the staple motor.                                                                                                                                                       |
|      | 10  | Content          | Finisher stapler motor trouble                                                                                                                                                                            |
|      |     | Detail           | Stapler motor operation abnormality                                                                                                                                                                       |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                                                                                   |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                                                  |

| MAIN | SUB | Details          |                                                                                                                                                 |
|------|-----|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| F1   | 10  | Content          | Console finisher stapler motor trouble                                                                                                          |
|      |     | Detail           | Stapler motor operation abnormality                                                                                                             |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                         |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                        |
|      | 11  | Content          | Finisher bundle exit motor trouble                                                                                                              |
|      |     | Detail           | Bundle exit motor operation abnormality                                                                                                         |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                         |
|      |     | Check and remedy | Use SIM 3-3 to check the bundle exit motor operation and the paddle solenoid operation, or use SIM 3-2 to check the boomerang rotations sensor. |
|      | 11  | Content          | Console finisher bundle exit motor trouble                                                                                                      |
|      |     | Detail           | Bundle exit motor operation abnormality                                                                                                         |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                         |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                        |
|      | 12  | Content          | Mail-bin stacker gate trouble                                                                                                                   |
|      |     | Detail           | Gate operation abnormality                                                                                                                      |
|      |     | Cause            | Gate lock<br>Mail-bin stacker control PWB trouble                                                                                               |
|      |     | Check and remedy | Use SIM3-21 to check the transport gate operation.                                                                                              |
|      | 15  | Content          | Finisher lift motor trouble                                                                                                                     |
|      |     | Detail           | Lift motor operation abnormality                                                                                                                |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Finisher control PWB trouble                                                 |
|      |     | Check and remedy | Use SIM3-3 to check the lift motor operation.                                                                                                   |
|      | 15  | Content          | Console finisher lift motor trouble                                                                                                             |
|      |     | Detail           | Lift motor operation abnormality                                                                                                                |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                         |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                        |
|      | 19  | Content          | Finisher front alignment motor trouble                                                                                                          |
|      |     | Detail           | Front alignment motor operation abnormality                                                                                                     |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Finisher control PWB trouble                                                 |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                        |



| MAIN | SUB | Details          |                                                                                                                                                                                                           |
|------|-----|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F1   | 19  | Content          | Console finisher front alignment motor trouble                                                                                                                                                            |
|      |     | Detail           | Front alignment motor operation abnormality                                                                                                                                                               |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                                                                                   |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                                                  |
|      | 20  | Content          | Finisher rear alignment motor trouble                                                                                                                                                                     |
|      |     | Detail           | Rear alignment motor operation abnormality                                                                                                                                                                |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Finisher control PWB trouble                                                                                                           |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                                                  |
|      | 20  | Content          | Console finisher rear alignment motor trouble                                                                                                                                                             |
|      |     | Detail           | Rear alignment motor operation abnormality                                                                                                                                                                |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                                                                                   |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                                                  |
|      | 30  | Content          | Console finisher communication trouble                                                                                                                                                                    |
|      |     | Detail           | Communication cable test error after turning on the power or exiting from SIM.<br>Communication error with the console finisher                                                                           |
|      |     | Cause            | Improper connection or disconnection of connector and harness between the machine and the console finisher.<br>Console finisher control PWB trouble<br>Control PWB (PCU) trouble<br>Malfunction by noises |
|      |     | Check and remedy | Canceled by turning OFF/ON the power.<br>Check connectors and harness in the communication line.<br>Replace the console finisher control PWB or PCU PWB.                                                  |
|      | 31  | Content          | Console finisher fold sensor trouble                                                                                                                                                                      |
|      |     | Detail           | Sensor input value abnormality                                                                                                                                                                            |
|      |     | Cause            | Sensor breakage<br>harness breakage<br>Console finisher control PWB trouble                                                                                                                               |
|      |     | Check and remedy | Use SIM3-2 to check the sensor operation.                                                                                                                                                                 |

| MAIN | SUB | Details          |                                                                                                                                                                                                             |
|------|-----|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F1   | 32  | Content          | Communication trouble between the console finisher and the punch unit.                                                                                                                                      |
|      |     | Detail           | Communication err between the console finisher and the punch unit.                                                                                                                                          |
|      |     | Cause            | Improper connection or disconnection of connector and harness between the console finisher and the punch unit.<br>Console finisher control PWB trouble<br>Control PWB (PCU) trouble<br>Malfunction by noise |
|      |     | Check and remedy | Canceled by turning OFF/ON the power.<br>Check connectors and harness in the communication line.<br>Replace the console finisher control PWB.                                                               |
|      | 33  | Content          | Console finisher punch side registration motor trouble                                                                                                                                                      |
|      |     | Detail           | Punch side registration motor operation abnormality                                                                                                                                                         |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                                                                                     |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                                                    |
|      | 34  | Content          | Console finisher punch motor trouble                                                                                                                                                                        |
|      |     | Detail           | Punch motor operation abnormality                                                                                                                                                                           |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                                                                                     |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                                                    |
|      | 35  | Content          | Console finisher punch side registration sensor trouble                                                                                                                                                     |
|      |     | Detail           | Sensor input value abnormality                                                                                                                                                                              |
|      |     | Cause            | Sensor breakage<br>Harness disconnection<br>Console finisher control PWB trouble                                                                                                                            |
|      |     | Check and remedy | Use SIM3-2 to check the sensor operation.                                                                                                                                                                   |
|      | 36  | Content          | Console finisher punch timing sensor trouble                                                                                                                                                                |
|      |     | Detail           | Sensor input value abnormality                                                                                                                                                                              |
|      |     | Cause            | Sensor breakage<br>Harness disconnection<br>Console finisher control PWB trouble                                                                                                                            |
|      |     | Check and remedy | Use SIM3-2 to check the sensor operation.                                                                                                                                                                   |
|      | 37  | Content          | Console finisher backup RAM trouble                                                                                                                                                                         |
|      |     | Detail           | Backup RAM contents are disturbed.                                                                                                                                                                          |
|      |     | Cause            | Console finisher control PWB trouble<br>Malfunction by noise                                                                                                                                                |
|      |     | Check and remedy | Replace the console finisher control PWB.                                                                                                                                                                   |
|      | 38  | Content          | Console finisher punch backup RAM trouble                                                                                                                                                                   |
|      |     | Detail           | Punch unit backup RAM contents are disturbed.                                                                                                                                                               |
|      |     | Cause            | Punch control PWB trouble<br>Malfunction by noise                                                                                                                                                           |
|      |     | Check and remedy | Replace the punch control PWB.                                                                                                                                                                              |

| MAIN | SUB | Details          |                                                                                                                                                                           |
|------|-----|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F1   | 39  | Content          | Console finisher punch dust sensor trouble                                                                                                                                |
|      |     | Detail           | Punch dust sensor detection trouble                                                                                                                                       |
|      |     | Cause            | When the punch dust sensor is not normally detected.                                                                                                                      |
|      |     | Check and remedy | Sensor breakage<br>Harness disconnection<br>Punch control PWB trouble                                                                                                     |
|      | 40  | Content          | Console finisher punch power interruption trouble                                                                                                                         |
|      |     | Detail           | When power interruption of the punch unit is detected                                                                                                                     |
|      |     | Cause            | Though 24V is supplied to the punch unit, the punch unit detects power interruption.                                                                                      |
|      |     | Check and remedy | Harness disconnection<br>Punch control PWB trouble                                                                                                                        |
|      | 80  | Content          | Finisher power abnormality                                                                                                                                                |
|      |     | Detail           | The 24V power is not supplied to the finisher PWB.                                                                                                                        |
|      |     | Cause            | Improper connection or disconnection of connector and harness<br>Finisher control PWB trouble<br>Power unit trouble                                                       |
|      |     | Check and remedy | Use SIM3-2 to check the sensor.                                                                                                                                           |
|      | 80  | Content          | Mail-bin stacker power abnormality                                                                                                                                        |
|      |     | Detail           | The 24V power is not supplied to the Mail-bin stacker PWB.                                                                                                                |
|      |     | Cause            | Improper connection or disconnection of connector and harness<br>Mail-bin stacker control PWB trouble<br>Power unit trouble                                               |
|      |     | Check and remedy | Use SIM3-20 to check the sensor operation.                                                                                                                                |
|      | 81  | Content          | Console finisher transport motor abnormality                                                                                                                              |
|      |     | Detail           | Transport motor trouble                                                                                                                                                   |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Console finisher control PWB trouble                                                                   |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                  |
|      | 87  | Content          | Finisher staple rotation motor trouble                                                                                                                                    |
|      |     | Detail           | Front staple rotation motor trouble                                                                                                                                       |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Finisher control PWB trouble                                                                           |
|      |     | Check and remedy | Use SIM3-3 to check the motor operation.                                                                                                                                  |
| F2   | 00  | Content          | Toner control sensor open/sensor trouble                                                                                                                                  |
|      |     | Detail           | Toner control sensor output open                                                                                                                                          |
|      |     | Cause            | Connector harness trouble<br>Connector disconnection<br>Sensor trouble                                                                                                    |
|      |     | Check and remedy | Check connection of the toner control sensor.<br>Check connection of connector and harness to the main PWB.<br>Check for disconnection of harness.<br>Replace the sensor. |

| MAIN | SUB | Details          |                                                                                                                                                                                                                                                        |
|------|-----|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F2   | 02  | Content          | Toner supply abnormality                                                                                                                                                                                                                               |
|      |     | Detail           | Toner control sensor output value becomes under-toner too earlier.                                                                                                                                                                                     |
|      |     | Cause            | Connector harness trouble<br>Toner concentration sensor trouble<br>Toner cartridge trouble                                                                                                                                                             |
|      |     | Check and remedy | Check connection of the connector in the toner motor section.<br>Check connection of connector and harness to the main PWB.<br>Check for disconnection of harness.<br>Toner concentration sensor output check SIM25-1.<br>Replace the toner cartridge. |
|      | 04  | Content          | Improper cartridge (life cycle error, etc.)                                                                                                                                                                                                            |
|      |     | Detail           | An improper process cartridge is inserted.                                                                                                                                                                                                             |
|      |     | Cause            | IC chip trouble<br>Improper cartridge                                                                                                                                                                                                                  |
|      |     | Check and remedy | Insert a proper cartridge.                                                                                                                                                                                                                             |
|      | 05  | Content          | CRUM error                                                                                                                                                                                                                                             |
|      |     | Detail           | Communication with IC chip cannot be made.                                                                                                                                                                                                             |
|      |     | Cause            | IC chip trouble<br>IC chip contact failure<br>Improper cartridge                                                                                                                                                                                       |
|      |     | Check and remedy | Insert a proper cartridge.<br>Is the cartridge installed properly?                                                                                                                                                                                     |
|      | 39  | Content          | Process thermistor trouble                                                                                                                                                                                                                             |
|      |     | Detail           | Output value abnormality of the temperature sensor of temperature/humidity sensor                                                                                                                                                                      |
|      |     | Cause            | Temperature/humidity sensor abnormality<br>Temperature/humidity sensor harness connection failure<br>PCU PWB trouble                                                                                                                                   |
|      |     | Check and remedy | Check connection of the harness and the connector of the temperature/humidity sensor.<br>Replace the temperature/humidity sensor.<br>Check PCU PWB.                                                                                                    |
|      | 58  | Content          | Process humidity sensor breakdown                                                                                                                                                                                                                      |
|      |     | Detail           | Process humidity sensor open or short                                                                                                                                                                                                                  |
|      |     | Cause            | Temperature/humidity sensor harness connection failure<br>Temperature/humidity sensor abnormality<br>PCU PWB trouble                                                                                                                                   |
|      |     | Check and remedy | Check connection of the harness and the connector of the temperature/humidity sensor.<br>Replace the temperature/humidity sensor.<br>Check PCU PWB.                                                                                                    |
| F3   | 12  | Content          | Machine no. 1 tray lift-up trouble                                                                                                                                                                                                                     |
|      |     | Detail           | LUD does not turn ON in the specified time.                                                                                                                                                                                                            |
|      |     | Cause            | LUD trouble<br>No. 1 tray lift-up trouble<br>Check connection of harness between the PCVU PWB, lift-up unit, and paper feed unit.                                                                                                                      |
|      |     | Check and remedy | Check LUD, and their harness and connectors.<br>Check the lift-up unit.                                                                                                                                                                                |

| MAIN | SUB | Details          |                                                                                                                                                                                                                                            |
|------|-----|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F3   | 22  | Content          | Machine tray 2 lift-up trouble                                                                                                                                                                                                             |
|      |     | Detail           | MCLUD does not turn ON in the specified time.                                                                                                                                                                                              |
|      |     | Cause            | MCLUD trouble<br>No. 2 tray lift-up motor trouble<br>Harness disconnection of the PCU PWB, the lift-up unit, and the paper feed unit.                                                                                                      |
|      |     | Check and remedy | Check MCLUD, and their harness and connectors.<br>Check the lift-up unit.                                                                                                                                                                  |
| F6   | 00  | Content          | Communication trouble (ICU detection) between ICU and FAX                                                                                                                                                                                  |
|      |     | Details          | Communication establishment error/<br>Fleming/Parity/Protocol error                                                                                                                                                                        |
|      |     | Cause            | Slave unit PWB connector disconnection<br>Harness abnormality between slave unit PWB and ICU PWB.<br>Slave unit PWB mother board connector pin breakage<br>Slave unit ROM abnormality/No ROM/<br>Reverse insertion of ROM/ROM pin breakage |
|      |     | Check & Remedy   | Check connector harness between slave unit PWB and ICU PWB.<br>Check grounding of machine.<br>Check slave unit PWB ROM.                                                                                                                    |
|      | 01  | Content          | FAX expansion flash memory abnormality (ICU detection)                                                                                                                                                                                     |
|      |     | Details          | Flash memory cannot be deleted.                                                                                                                                                                                                            |
|      |     | Cause            | Flash memory cannot be deleted.                                                                                                                                                                                                            |
|      |     | Check & Remedy   | Check the FAX image storage Flash memory.<br>Use SIM 66-10 to clear the flash memory.                                                                                                                                                      |
|      | 04  | Content          | FAX modem operation abnormality                                                                                                                                                                                                            |
|      |     | Details          | FAX PWB modem chip operation abnormality                                                                                                                                                                                                   |
|      |     | Cause            | SW101 in the FAX PWB tries to perform normal operation on the boot side.<br>Modem chip operation abnormality in FAX PWB                                                                                                                    |
|      |     | Check & Remedy   | Set SW101 on the FAX PWB to other than the boot side, and turn on the power again.<br>Replace FAX PWB.                                                                                                                                     |
|      | 20  | Content          | FAX write protect cancel                                                                                                                                                                                                                   |
|      |     | Detail           | The write protect jumper of the FAX interface PWB is released.                                                                                                                                                                             |
|      |     | Cause            | The FAX write protect pin is set to Write Enable.<br>FAX interface PWB trouble<br>FAX PWB trouble                                                                                                                                          |
|      |     | Check and remedy | Check the write protect pin in the FAX interface PWB.<br>Replace the FAX PWB. Replace the FAX interface PWB.                                                                                                                               |

| MAIN | SUB | Details          |                                                                                                                                                                                                                                      |
|------|-----|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| F6   | 21  | Content          | Combination abnormality of the TEL/LIU PWB and the FAX soft switch                                                                                                                                                                   |
|      |     | Detail           | Combination abnormality of the TEL/LIU PWB and the FAX PWB information (soft switch)<br>Or the TEL/LIU PWB is not a new one for new MDMC PWB.                                                                                        |
|      |     | Cause            | The destination of the installed TEL/LIU PWB differs.<br>The FAX PWB information (soft switch) differs.<br>TEL/LIU PWB trouble                                                                                                       |
|      |     | Check and remedy | Check the destination of the TEL/LIU PWB.<br>Check the FAX PWB information (soft switch).<br>Replace the TEL/LIU PWB.                                                                                                                |
|      | 97  | Content          | FAX-BOX skating trouble<br>The FAX-BOX PWB is not one for the AR-FX12. (FAX detection)                                                                                                                                               |
|      |     | Detail           | The FAX-BOX MODEM controller is not one for the AR-FX12.                                                                                                                                                                             |
|      |     | Cause            | The FAX-BOX Modem controller PWB information (hard detection) is not for the AR-FX12. (The Modem controller PWB for the AR-FX5 or the AR-FX6 is used.)                                                                               |
|      |     | Check and remedy | Check the FAX-BOX modem controller PWB.<br>Replace it with a modem controller PWB for the AR-FX12.                                                                                                                                   |
|      | 98  | Content          | Combination error of the FAX-BOX destination information and the machine destination information                                                                                                                                     |
|      |     | Detail           | Combination error of the FAX-BOX destination information and the machine destination information                                                                                                                                     |
|      |     | Cause            | Because of improper combination between the destination information stored in the EEPROM on the FAX-BOX PWB and that of the machine (set with SIM 26-6).                                                                             |
|      |     | Check and remedy | Check the destination of the FAX-BOX.<br>Check the machine destination with SIM 26-6.<br>Use a proper combination of the machine and the FAX-BOX.                                                                                    |
| F7   | 01  | Content          | FAX board EEPROM read/write error                                                                                                                                                                                                    |
|      |     | Details          | EEPROM access error (read/write)                                                                                                                                                                                                     |
|      |     | Cause            | EEPROM trouble<br>FAX PWB EEPROM access circuit trouble                                                                                                                                                                              |
|      |     | Check & Remedy   | When replacing the EEPROM, use SIM66-4/5 (Signal send level) and SIM66-14/15/16 (Dial test) for adjustment. However, note that all the soft switches are reset to the initial values.<br>No need to adjust when the PWB is replaced. |

| MAIN | SUB          | Details          |                                                                                                                                                                                                                                                                                                                                                              |
|------|--------------|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| H2   | 00...<br>HL1 | Content          | Thermistor open<br>Fusing unit not installed                                                                                                                                                                                                                                                                                                                 |
|      |              | Detail           | Thermistor is open.<br>(An input voltage of 2.95V or above is detected.)<br>Fusing unit not installed                                                                                                                                                                                                                                                        |
|      | 01...<br>HL2 | Cause            | Thermistor trouble<br>Control PWB trouble<br>Fusing section connector disconnection<br>AC power trouble<br>Fusing unit not installed                                                                                                                                                                                                                         |
|      |              | Check and remedy | Check harnesses and connectors from the thermistor to the control PWB.<br>Use SIM14 to clear the self diag display.                                                                                                                                                                                                                                          |
| H3   | 00...<br>HL1 | Content          | Fusing section high temperature trouble                                                                                                                                                                                                                                                                                                                      |
|      |              | Detail           | The fusing temperature exceeds 241.5°C. (An input voltage of 0.35V or above is detected.)<br>Fusing temperature control is started, and 242°C is detected three or more times continuously in sampling in the specified interval. (Every 300msec)                                                                                                            |
|      | 01...<br>HL2 | Cause            | Thermistor trouble<br>Control PWB trouble<br>Fusing section connector disconnection<br>AC power trouble                                                                                                                                                                                                                                                      |
|      |              | Check and remedy | Use SIM5-2 to check the heater lamp <b>Blinking operation.</b><br>If the heater lamp blinks normally:<br>Check the thermistor and its harness.<br>Check the thermistor input circuit in the control PWB.<br><b>If the heater lamp keep lighting:</b><br>Check the AC PWB and the lamp control circuit in the control PWB.<br>Use SIM14 to cancel the trouble |

| MAIN | SUB          | Details          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------|--------------|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| H4   | 00...<br>HL1 | Content          | Fusing section low temperature trouble                                                                                                                                                                                                                                                                                                                                                                                                                             |
|      |              | Detail           | The set temperature is not reached within the specified time (3 min) after turning on the power relay.<br>When the heater lamp is not turned off in the specified time (3minutes) from starting warm-up.<br>After completion of warm-up operation, a temperature 50°C lower than the temperature control level is detected 5 times continuously in sampling in the specified interval. (every 300msec)                                                             |
|      | 01...<br>HL2 | Cause            | Thermistor trouble<br>Heater lamp trouble<br>Control PWB trouble<br>Thermostat trouble<br>AC power trouble<br>Interlock switch trouble                                                                                                                                                                                                                                                                                                                             |
|      |              | Check and remedy | Use SIM5-2 to check the heater lamp <b>Blinking operation.</b><br>If the heater lamp blinks normally:<br>Check the thermistor and its harness.<br>Check the thermistor input circuit in the control PWB.<br><b>If the heater lamp does not light:</b><br>Check for heater lamp disconnection and thermostat disconnection.<br>Check the interlock switch.<br>Check the AC PWB and the lamp control circuit in the control PWB.<br>Use SIM14 to cancel the trouble. |
| H5   | 01           | Content          | 5-time continuous POD1 not-reaching jam detection                                                                                                                                                                                                                                                                                                                                                                                                                  |
|      |              | Detail           | 5-time continuous POD1 not-reaching jam detection                                                                                                                                                                                                                                                                                                                                                                                                                  |
|      |              | Cause            | A fusing section jam is not properly removed. (Jam paper remains.)<br>POD1 sensor trouble, or harness disconnection<br>Improper installation of fusing unit                                                                                                                                                                                                                                                                                                        |
|      |              | Check and remedy | Check jam paper in the fusing section. (winding, etc.)<br>Check POD1 sensor harness, and check the fusing unit installation.<br>Use SIM14 to cancel the trouble.                                                                                                                                                                                                                                                                                                   |
| L1   | 00           | Content          | Scanner feed trouble                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|      |              | Details          | Scanner feed is not completed within the specified time.                                                                                                                                                                                                                                                                                                                                                                                                           |
|      |              | Cause            | Scanner unit abnormality<br>Scanner wire disconnection                                                                                                                                                                                                                                                                                                                                                                                                             |
|      |              | Check & Remedy   | Check scanning with SIM 1-1.                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| L3   | 00           | Content          | Scanner return trouble                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|      |              | Details          | Scanner return is not completed within the specified time.                                                                                                                                                                                                                                                                                                                                                                                                         |
|      |              | Cause            | Scanner unit abnormality<br>Scanner wire disconnection                                                                                                                                                                                                                                                                                                                                                                                                             |
|      |              | Check & Remedy   | Check scanning with SIM 1-1.                                                                                                                                                                                                                                                                                                                                                                                                                                       |

| MAIN | SUB | Details          |                                                                                                                                                                                                                          |
|------|-----|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| L4   | 01  | Content          | Main motor lock detection                                                                                                                                                                                                |
|      |     | Detail           | The motor lock signal is detected for 1.5sec during rotation of the main motor.                                                                                                                                          |
|      |     | Cause            | main motor trouble<br>Check connection of harness between the PCU PWB and the main motor.<br>Control circuit trouble                                                                                                     |
|      |     | Check and remedy | Use SIM25-1 to check the main motor operation.<br>Check harness and connector between the PCU PWB and the main motor.                                                                                                    |
|      | 02  | Content          | Drum motor lock detection                                                                                                                                                                                                |
|      |     | Detail           | The motor lock signal is detected for 1.5sec during rotation of the drum motor.                                                                                                                                          |
|      |     | Cause            | Drum motor trouble<br>Improper connection of harness between the PCU PWB and the drum motor.<br>Control circuit trouble                                                                                                  |
|      |     | Check and remedy | Use SIM6-1 to check the drum motor operation.<br>Check harness and connector between the PCU PWB and the drum motor.                                                                                                     |
|      | 30  | Content          | Controller fan motor lock detection                                                                                                                                                                                      |
|      |     | Detail           | The motor lock signal is detected during rotation of the controller fan motor.<br>The motor lock signal is detected during rotation of the HDD fan motor.                                                                |
|      |     | Cause            | Fan motor trouble<br>Improper connection of the harness between the controller PWB and the fan motor.<br>Control circuit trouble                                                                                         |
|      |     | Check and remedy | Use SIM 6-2 to check the fan motor operation.<br>Check the harness and the connector between the controller PWB and the fan motor.                                                                                       |
| L6   | 10  | Content          | Polygon motor lock detection                                                                                                                                                                                             |
|      |     | Detail           | It is judged that the polygon motor lock signal is not outputted.<br>Lock signal is checked in the interval of 10sec after starting the polygon motor, and it is judged that the polygon motor does not rotate normally. |
|      |     | Cause            | The LSU connector or harness in the LSU is disconnected or broken.<br>Polygon motor trouble                                                                                                                              |
|      |     | Check and remedy | Use SIM61-1 to check the polygon motor operation.<br>Check connector and harness connection.<br>Replace LSU.                                                                                                             |

| MAIN | SUB | Details          |                                                                                                                                                                                     |
|------|-----|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| L8   | 01  | Content          | No fullwave signal                                                                                                                                                                  |
|      |     | Detail           | Full wave signal is not detected.                                                                                                                                                   |
|      |     | Cause            | The PCU PWB connector or the power unit harness is disconnected or broken.<br>PCU PWB trouble<br>12V power source trouble                                                           |
|      |     | Check and remedy | Check connection of the harness and connector.<br>Replace PCU PWB.<br>Replace the power unit.<br>Replace the controller connection mother board.                                    |
|      | 02  | Content          | Full wave signal width abnormality                                                                                                                                                  |
|      |     | Detail           | It is judged as full wave signal frequency abnormality.<br>(When the detection cycle is judged as 69Hz or above or 42.5Hz or below)                                                 |
|      |     | Cause            | The connector or harness of the PCU PWB and the power PWB is disconnected.<br>PCU PWB trouble<br>Power unit trouble                                                                 |
|      |     | Check and remedy | Check connection of the harness and connector.<br>Replace the PCU PWB.<br>Replace the power unit.                                                                                   |
|      | U1  | Content          | FAX battery abnormality                                                                                                                                                             |
|      |     | Detail           | FAX backup SRAM battery voltage fall                                                                                                                                                |
|      |     | Cause            | Battery life<br>Battery circuit abnormality                                                                                                                                         |
|      |     | Check and remedy | Check that the battery voltage is about 2.5V or above.<br>Check the battery circuit.                                                                                                |
|      | 02  | Content          | RTC read abnormality<br>(common with FAX, on ICU PWB)                                                                                                                               |
|      |     | Details          | The value read from RTC on ICU PWB is [EE]h (abnormal).                                                                                                                             |
|      |     | Cause            | RTC circuit abnormality<br>Battery voltage fall<br>Battery circuit abnormality                                                                                                      |
|      |     | Check & Remedy   | Set the time again with key operation, and check that time advances properly.<br>Check RTC circuit.<br>Check that battery voltage is about 2.5V or above.<br>Check battery circuit. |
| U2   | 00  | Content          | EEPROM read/write error (ICU)                                                                                                                                                       |
|      |     | Detail           | EEPROM write error                                                                                                                                                                  |
|      |     | Cause            | EEPROM trouble<br>EEPROM is not initialized.<br>ICU PWB EEPROM access circuit trouble                                                                                               |
|      |     | Check and remedy | Check that EEPROM is properly inserted.<br>Save the counter/adjustment values with the simulation.<br>Use SIM16 to cancel U2 trouble.<br>Replace the ICU PWB.                       |

| MAIN | SUB | Details          |                                                                                                                                                                                                                             |
|------|-----|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U2   | 11  | Content          | Counter check sum error (ICU)                                                                                                                                                                                               |
|      |     | Detail           | Counter data area check sum error                                                                                                                                                                                           |
|      |     | Cause            | EEPROM trouble<br>Control circuit trouble by noise<br>ICU PWB EEPROM access circuit trouble                                                                                                                                 |
|      |     | Check and remedy | Check that EEPROM is properly inserted.<br>Save the counter/adjustment values with the DIAG simulation.<br>Use DIAG (SIM16) to cancel U2 trouble.<br>Replace the ICU PWB.                                                   |
|      | 12  | Content          | Adjustment value check sum error (ICU)                                                                                                                                                                                      |
|      |     | Detail           | Adjustment data area check sum error                                                                                                                                                                                        |
|      |     | Cause            | EEPROM trouble<br>Control circuit trouble by noise<br>ICU PWB EEPROM access circuit trouble                                                                                                                                 |
|      |     | Check and remedy | Check that EEPROM is properly inserted.<br>Save the counter/adjustment values with the simulation.<br>Use SIM16 to cancel U2 trouble.<br>Replace the ICU PWB.                                                               |
|      | 22  | Content          | SRAM memory check sum error (ICU)                                                                                                                                                                                           |
|      |     | Detail           | MFPC section SRAM memory check sum error                                                                                                                                                                                    |
|      |     | Cause            | SRAM trouble<br>Control circuit runaway due to noises<br>ICU PWB SRAM access circuit trouble                                                                                                                                |
|      |     | Check and remedy | Initialize the communication management table registered in the SRAM and the FAX soft switch.<br>Since the registered data are deleted, register the data again.<br>Use SIM16 to cancel U2 trouble.<br>Replace the ICU PWB. |
|      | 23  | Content          | SRAM memory individual data check sum error (ICU)                                                                                                                                                                           |
|      |     | Detail           | Check sum error for every data in the SRAM memory of the MFPC section (Communication management table, sender registration data, etc.)                                                                                      |
|      |     | Cause            | SRAM trouble<br>Control circuit runaway due to noises<br>ICU PWB SRAM access circuit trouble                                                                                                                                |
|      |     | Check and remedy | Automatically initialize the data related to the check sum error by turning OFF/ON the power.<br>Since the registered data are deleted, register the data again.<br>Use SIM16 to cancel U2 trouble.<br>Replace the ICU PWB. |

| MAIN | SUB | Details          |                                                                                                                                                                                                                                                         |
|------|-----|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U2   | 50  | Content          | HD section individual data check sum error (ICU)                                                                                                                                                                                                        |
|      |     | Detail           | Check sum error for every individual data in HD of the MFPC section (One-touch, Group, Program, etc.)                                                                                                                                                   |
|      |     | Cause            | HDD write/read error<br>Control circuit runaway due to noises<br>ICU PWB HD access circuit trouble                                                                                                                                                      |
|      |     | Check and remedy | Automatically initialize the data related to the check sum error by turning OFF/ON the power.<br>Since the registered data are deleted, register the data again.<br>Use SIM 16 to cancel the U2 trouble.<br>Replace the HD PWB.<br>Replace the ICU PWB. |
|      | 80  | Content          | EEPROM read/write error (Scanner)                                                                                                                                                                                                                       |
|      |     | Details          | Scanner EEPROM write error                                                                                                                                                                                                                              |
|      |     | Cause            | EEPROM abnormality<br>EEPROM which is not initialized is installed.<br>Scanner PWB EEPROM access circuit abnormality                                                                                                                                    |
|      |     | Check & Remedy   | Check that EEPROM is set properly.<br>Record counter/adjustment values with the simulation to protect the data from being deleted.<br>Cancel U2 trouble with SIM 16.<br>Replace scanner PWB.                                                            |
|      | 81  | Content          | Memory check sum error (Scanner)                                                                                                                                                                                                                        |
|      |     | Details          | Scanner memory check sum error                                                                                                                                                                                                                          |
|      |     | Cause            | EEPROM trouble<br>Control circuit freeze by noises<br>Scanner PWB EEPROM access circuit trouble                                                                                                                                                         |
|      |     | Check & Remedy   | Check that EEPROM is set properly.<br>Record counter/adjustment values with the simulation to protect the data from being deleted.<br>Cancel U2 trouble with SIM 16.<br>Replace scanner PWB.                                                            |
|      | 90  | Content          | EEPROM read/write error (PCU)                                                                                                                                                                                                                           |
|      |     | Detail           | PCU EEPROM write error                                                                                                                                                                                                                                  |
|      |     | Cause            | EEPROM trouble<br>EEPROM which is not initialized is installed.<br>PCU PWB EEPROM access circuit trouble                                                                                                                                                |
|      |     | Check and remedy | Check that EEPROM is properly inserted.<br>Record counter/adjustment values with the simulation to protect the data from being deleted.<br>Use SIM16 to cancel U2 trouble.<br>Replace the Controller PWB.                                               |
|      | 91  | Content          | Memory check sum error (PCU)                                                                                                                                                                                                                            |
|      |     | Detail           | PCU memory check sum error                                                                                                                                                                                                                              |
|      |     | Cause            | EEPROM trouble<br>EEPROM is not initialized.<br>PCU PWB EEPROM access circuit trouble<br>Hang of control circuit due to noises                                                                                                                          |
|      |     | Check and remedy | Check that EEPROM is properly inserted.<br>Save the counter/adjustment values with the simulation.<br>Use SIM16 to cancel U2 trouble.<br>Replace the Controller PWB.                                                                                    |

| MAIN | SUB | Details          |                                                                                                                                                 |
|------|-----|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| U6   | 00  | Content          | Desk/LCC communication trouble                                                                                                                  |
|      |     | Detail           | Desk/LCC communication error<br>Communication cable test error after turning on the power or exiting SIM.                                       |
|      |     | Cause            | Improper connection or disconnection of connector and harness<br>Desk control PWB trouble<br>Control PWB (PCU) trouble<br>Noise or interference |
|      |     | Check and remedy | Canceled by turning OFF/ON the power.<br>Check connection of the harness and connector in the communication line.                               |
|      | 01  | Content          | Desk/LCC No. 1 tray lift-up trouble                                                                                                             |
|      |     | Detail           | Desk/LCC No. 1 tray lift-up trouble                                                                                                             |
|      |     | Cause            | Sensor trouble<br>Desk control PWB trouble<br>Gear breakage<br>Lift-up motor trouble                                                            |
|      |     | Check and remedy | Use SIM4-2 to check the lift-up sensor detection.<br>Use SIM4-3 to check the lift-up motor operation.                                           |
|      | 02  | Content          | Desk No. 2 tray/LCC1 lift-up trouble                                                                                                            |
|      |     | Detail           | Desk No. 2 tray/LCC lift-up trouble                                                                                                             |
|      |     | Cause            | Sensor trouble<br>Desk control PWB trouble<br>Gear breakage<br>Lift-up motor trouble                                                            |
|      |     | Check and remedy | Use SIM4-2 to check the lift-up sensor detection.<br>Use SIM4-3 to check the lift-up motor operation.                                           |
|      | 03  | Content          | Desk No. 3 tray/LCC2 lift-up trouble                                                                                                            |
|      |     | Detail           | Desk no. 3 tray lift-up trouble                                                                                                                 |
|      |     | Cause            | Sensor trouble<br>Desk control PWB trouble<br>Gear breakage<br>Lift-up motor trouble                                                            |
|      |     | Check and remedy | Use SIM4-2 to check the lift-up sensor detection.<br>Use SIM4-3 to check the lift-up motor operation.                                           |
|      | 10  | Content          | Desk/LCC transport motor trouble                                                                                                                |
|      |     | Detail           | Desk/LCC transport motor operation trouble                                                                                                      |
|      |     | Cause            | Motor lock<br>Motor rpm abnormality<br>Overcurrent to the motor<br>Desk control PWB trouble                                                     |
|      |     | Check and remedy | Use SIM4-3 to check the transport motor operation.                                                                                              |
| U7   | 00  | Content          | RIC communication trouble                                                                                                                       |
|      |     | Detail           | RIC communication trouble<br>Communication cable test error after turning on the power or exiting SIM.                                          |
|      |     | Cause            | Disconnection of connector and harness<br>RTC control PWB trouble<br>Control PWB (ICU) trouble<br>Noise or interference                         |
|      |     | Check and remedy | Canceled by turning OFF/ON the power.<br>Check connector and harness in the communication line.                                                 |

| MAIN | SUB | Details          |                                                                                                                                                                          |
|------|-----|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| EE   | EL  | Content          | Auto developer adjustment trouble (Over-toner)                                                                                                                           |
|      |     | Detail           | The toner concentration output is detected as 1.5V or below in the auto development adjustment.                                                                          |
|      |     | Cause            | Toner concentration sensor trouble<br>Charging voltage, developing voltage abnormality<br>Insufficient toner concentration<br>Developing unit trouble<br>PCU PWB trouble |
|      |     | Check and remedy | Use SIM25-2 to perform auto developer adjustment.                                                                                                                        |
|      | EU  | Content          | Auto developer adjustment trouble (Under-toner)                                                                                                                          |
|      |     | Detail           | The toner concentration output is detected as 3.5V or above in the auto development adjustment.                                                                          |
|      |     | Cause            | Insufficient toner concentration<br>Charging voltage, developing voltage abnormality<br>Insufficient toner concentration<br>Developing unit trouble<br>PCU PWB trouble   |
|      |     | Check and remedy | Use SIM25-2 to perform auto developer adjustment.                                                                                                                        |
|      | PF  | Content          | RIC copy inhibit signal is received.                                                                                                                                     |
|      |     | Detail           | Copy inhibit command from RIM (host) is received.                                                                                                                        |
|      |     | Cause            | Judged by the host.                                                                                                                                                      |
|      |     | Check and remedy | Inform to the host.                                                                                                                                                      |
|      | CE  | Content          | Another communication error occurs.                                                                                                                                      |
|      |     | Detail           | Communication error                                                                                                                                                      |
|      |     | Cause            | Improper connection of the network cable                                                                                                                                 |
|      |     | Check and remedy | Check the connection of the network cable.                                                                                                                               |
|      | 01  | Content          | The print server card is broken down or is not installed.                                                                                                                |
|      |     | Detail           | Print server card connection trouble                                                                                                                                     |
|      |     | Cause            | The print server card is not installed on the controller.<br>Print server card control PWB trouble                                                                       |
|      |     | Check and remedy | 1. Check that the print server card is installed on the controller.<br>2. Output the NIC Config. Page to check the NIC version.<br>3. Replace the NIC.                   |

| MAIN | SUB | Details          |                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------|-----|------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CE   | 02  | Content          | The specified mail server or FTP server is not found.                                                                                                                                                                                                                                                                                                                                                                                                   |
|      |     | Detail           | The specified mail server or the FTP server is not found.                                                                                                                                                                                                                                                                                                                                                                                               |
|      |     | Cause            | Improper connection of the network cable<br>Network setup trouble<br>An error occurs in the SMTP server/ FTP server/ NTS.                                                                                                                                                                                                                                                                                                                               |
|      |     | Check and remedy | 1. Check that the network cable is properly connected.<br>2. Check that the connected network supports TCP/IP protocol.<br>3. Check from the web page that the address of the FTP server or the desktop PC is properly set as the primary/secondary e-mail server address.<br>4. When the above address is described with the Hostname, check that the DNS server is properly set or not.<br>5. Check the SMTP server/ FTP server/ NTS for any trouble. |
|      | 03  | Content          | The specified server suspends response during transmission of images.                                                                                                                                                                                                                                                                                                                                                                                   |
|      |     | Detail           | The specified server suspends response during transmission of images.                                                                                                                                                                                                                                                                                                                                                                                   |
|      |     | Cause            | Improper connection of the network cable<br>An error occurs in the SMTP server/ FTP server/ NTS.                                                                                                                                                                                                                                                                                                                                                        |
|      |     | Check and remedy | 1. Check that the network cable is properly connected.<br>2. Check the SMTP server/ FTP server/ NTS for any trouble.                                                                                                                                                                                                                                                                                                                                    |
|      | 04  | Content          | The account name or the password for the FTP server is invalid.                                                                                                                                                                                                                                                                                                                                                                                         |
|      |     | Detail           | The entered account name of the FTP server or the password for authentication is invalid.                                                                                                                                                                                                                                                                                                                                                               |
|      |     | Cause            | Improper connection of the network cable<br>Improper registration of the account name or improper password registered in the FTP server as the destination                                                                                                                                                                                                                                                                                              |
|      |     | Check and remedy | 1. Check that the network cable is properly connected.<br>2. Check the account name or the password registered in the FTP server as the destination.                                                                                                                                                                                                                                                                                                    |
|      | 05  | Content          | The directory of the FTP server is invalid.                                                                                                                                                                                                                                                                                                                                                                                                             |
|      |     | Detail           | The entered directory of the FTP server is invalid.                                                                                                                                                                                                                                                                                                                                                                                                     |
|      |     | Cause            | Improper connection of the network cable<br>Check for existence of the directory name in the FTP server registered as the destination.                                                                                                                                                                                                                                                                                                                  |
|      |     | Check and remedy | 1. Check that the network cable is properly connected.<br>2. Check for existence of the directory name in the FTP server registered as the destination.                                                                                                                                                                                                                                                                                                 |

| MAIN | SUB | Details          |                                                                                                                                                                                                                                                                                                                                                    |
|------|-----|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| CE   | 06  | Content          | The specified mail server (POP3) is not found.                                                                                                                                                                                                                                                                                                     |
|      |     | Detail           | The specified mail server (POP3) is not found.<br>POP3 server access error                                                                                                                                                                                                                                                                         |
|      |     | Cause            | Improper connection of the network cable<br>Network setup trouble<br>An error occurs in the POP3 server.                                                                                                                                                                                                                                           |
|      |     | Check and remedy | 1. Check connection of the network cable.<br>2. Check that the connected network supports TCP/IP protocol.<br>3. Check on the Web page that the POP3 server address is correctly set.<br>4. When the above address is described with the Hostname, check that the DNS server is properly set or not.<br>5. Check for any error in the POP3 server. |
|      | 07  | Content          | The entered account name of the POP3 server or the password for authentication is invalid.                                                                                                                                                                                                                                                         |
|      |     | Detail           | The entered account name of the POP3 server or the password for authentication is invalid.<br>POP3 server authentication check error                                                                                                                                                                                                               |
|      |     | Cause            | Improper connection of the network cable<br>Improper account name or password registered in the POP3 server                                                                                                                                                                                                                                        |
|      |     | Check and remedy | 1. Check connection of the network cable.<br>2. Check that the account name or the password registered for the POP3 server is correct.                                                                                                                                                                                                             |
|      | 08  | Content          | The specified mail server (POP3) is not found.                                                                                                                                                                                                                                                                                                     |
|      |     | Detail           | The specified mail server (POP3) is not found.<br>POP3 server time out error                                                                                                                                                                                                                                                                       |
|      |     | Cause            | Improper connection of the network cable<br>An error occurs in the POP3 server.                                                                                                                                                                                                                                                                    |
|      |     | Check and remedy | 1. Check connection of the network cable.<br>2. Check for any error in the POP3 server.                                                                                                                                                                                                                                                            |



## 4. Other related items

### (1) Self diag operation

The machine always monitors its own status. When it detects any abnormality or a status which requires warning, it performs the self diag operation to display the trouble or warning message as follows:

|         |                   |                                                                                                                                                       |
|---------|-------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| Warning | Content           | This message is displayed to warn mainly the user to inform that a consumable part is near life, etc. It is no direct relation with machine troubles. |
|         | Machine operation | The machine operation may be stopped and may be not.                                                                                                  |
|         | Message clear     | The message may be automatically cleared by replacement or supply of the consumable part, or may be cleared by the specified simulation operation.    |
| Trouble | Content           | This message is a trouble message related to a machine trouble.                                                                                       |
|         | Machine operation | The machine operation is stopped.                                                                                                                     |
|         | Message clear     | This message may be automatically cleared by repairing the trouble, or may be cleared by the specified simulation operation.                          |


### (2) Power ON trouble detection function

- When the power is turned on, if the stored trouble is H3, H4, H5, U1, U2, PF, U6 (LCC-related sub code 09 only), L4 (paper exit fan-related sub code 31 only), or U6 (sub code 2, 3), it is immediately judged as a trouble.

\* E7-50 and 60 are not judged as a storing trouble, (Detected every time when the power is turned on.)

| Trouble code | Storing    | Trouble cancel command simulation |
|--------------|------------|-----------------------------------|
| H3, H4, H5   | PCU        | SIM 14                            |
| U1           | ICU        | SIM 13                            |
| U2           | Each block | SIM 16                            |
| PF           | ICU        | SIM 17                            |
| U6-09        | PCU        | SIM 15                            |
| L4-31        | PCU        | SIM 14                            |
| U6-2, 3      | PCU        | SIM 15                            |

### (3) Basic flow of countermeasures



#### (4) List of trouble modes

##### ● Troubles where the machine can be operated under some conditions

When a trouble occurs, the dialogue is displayed and OK button is added to the trouble message.

| Trouble content                                            | Judgment block | Trouble code                                                          | Operation enable mode           |          |               |           |       |            |                          |
|------------------------------------------------------------|----------------|-----------------------------------------------------------------------|---------------------------------|----------|---------------|-----------|-------|------------|--------------------------|
|                                                            |                |                                                                       | Copy read (including interrupt) | FAX send | Email receive | FAX print | Print | List print | Notification to FASThost |
| Scanner section breakdowns (Mirror motor, lens, copy lamp) | Scanner        | L1, L3, U2 (80, 81)                                                   | ×                               | ×        | ×             | ○         | ○     | ○          | ○                        |
| FAX board breakdown                                        | ICU/FAX        | F6, F7                                                                | ○                               | ×        | ○             | ×         | ○     | ○          | ×                        |
| FAX power OFF                                              | ICU            |                                                                       | ○                               | ×        | ○             | ×         | ○     | ○          | ×                        |
| Network error                                              | ICU            | CE                                                                    | ○                               | ○        | ×             | ○         | ○     | ○          | ×                        |
| Staple breakdown                                           | PCU            | F1 (10)                                                               | Δ2                              | ○        | ○             | Δ2        | Δ2    | Δ2         | ○                        |
| Paper feed tray breakdown                                  | PCU            | F3, U6 (LCC)                                                          | Δ3                              | ○        | ○             | Δ3        | Δ3    | Δ3         | ○                        |
| PCU section breakdowns (Motor, fusing section, etc.)       | PCU            | C1, C2, C3, H2, H3, H4, H5, L4 (excluding L4-30), L8, U2 (90, 91), F2 | ×                               | ○        | ○             | ×         | ×     | ×          | ○                        |
| After-process breakdown                                    | PCU            | F1                                                                    | Δ5                              | ○        | ○             | Δ5        | Δ5    | Δ5         | ○                        |
| Laser breakdown                                            | PCU            | E7 (02 only), L6                                                      | ×                               | ○        | ○             | ×         | ×     | ×          | ○                        |
| HDD breakdown                                              | ICU            | E7 (03)                                                               | ×                               | ×        | ×             | ×         | ×     | ×          | ○                        |
| CCD breakdowns (Shading, etc.)                             | Scanner        | E7 (10, 11, 14)                                                       | ×                               | ×        | ×             | ○         | ○     | ○          | ○                        |
| CIS breakdowns (Shading, etc.)                             | Scanner        | E6 (10, 11, 14)                                                       | Δ6                              | Δ6       | Δ6            | ○         | ○     | ○          | ○                        |
| Scanner communication trouble                              | ICU            | E7 (80)                                                               | ×                               | ×        | ×             | ○         | ○     | ○          | ○                        |
| PCU communication trouble                                  | ICU            | E7 (90)                                                               | ×                               | ×        | ×             | ×         | ×     | ×          | ○                        |
| FAX backup battery voltage fall                            | ICU            | U1 (01, 02)                                                           | ○                               | ×        | ×             | ○         | ○     | ○          | ○                        |
| HDD registration data sum error                            | ICU            | U2 (50)                                                               | ○                               | ×        | ×             | ○         | ○     | ○          | ○                        |
| Thermistor trouble (trouble history)                       | PCU            | F2 (39, 58)                                                           | ○                               | ○        | ○             | ○         | ○     | ○          | ○                        |

##### ● Troubles where the machine cannot be operated

When a trouble occurs, the dialogue is displayed. OK button is not added to the trouble message, and only setting can be performed. The message remains displayed until the trouble is canceled.

| Trouble content                       | Judgment block | Trouble code            | Operation enable mode           |          |               |           |       |            |                          |
|---------------------------------------|----------------|-------------------------|---------------------------------|----------|---------------|-----------|-------|------------|--------------------------|
|                                       |                |                         | Copy read (including interrupt) | FAX send | Email receive | FAX print | Print | List print | Notification to FASThost |
| Memory                                | ICU            | U2 (00, 11, 12, 22, 23) | ×                               | ×        | ×             | ×         | ×     | ×          | ○                        |
| External communication disable (RICA) | ICU            | U7, PF                  | ×                               | ×        | ×             | ×         | ×     | ×          | ○                        |
| Image memory trouble, decode error    | ICU            | E7 (01, 06)             | ×                               | ×        | ×             | ×         | ×     | ×          | ○                        |
| Skating check error                   | ICU/PCU        | E7 (50)                 | ×                               | ×        | ×             | ×         | ×     | ×          | ×                        |
| Controller fan motor trouble          | ICU            | L4-30                   | ×                               | ×        | ×             | ×         | ×     | ×          | ×                        |

\* For FAX communication, refer to the "Image send, receive (FAX call request and FAX call-in)".

\* The machine may be operated under some conditions.

Δ1: When detected except when in a job, the machine can be operated in the OC mode.

Δ2: Can be operated except in the staple mode.

Δ3: When detected except in a job, the machine can be operated except with the breakdown tray.

Δ4: Can be operated with some restriction on the image quality depending on the destination. (Low density print)

Δ5: When detected except in a job, can be operated except in the trouble paper exit section.

Δ6: When detected except in a job, can be operated in the single surface scan mode.

## (5) Communication specification when a trouble occurs

The image send/receive specifications when a trouble occurs are as shown below.

| Trouble                                                                                              | Send reservation | Print | FAX call request | FAX call-in | LAN send | LAN receive | Precaution                                             |
|------------------------------------------------------------------------------------------------------|------------------|-------|------------------|-------------|----------|-------------|--------------------------------------------------------|
| PCU breakdowns (Excluding C1, C2, C3, H2, H3, H4, H5, L4, L8, U2-90, U2-91, and skating check error) | ○                | ×     | ○                | ○ Note      | ○        | ○ Note      | There is a risk that the memory is full.               |
| Scanner breakdowns (L1, L3, U2-80, U2-81)                                                            | ×                | ○     | ○                | ○           | ○        | ○           |                                                        |
| F6, F7 (FAX breakdown)                                                                               | ×                | ○     | ×                | ×           | ○        | ○           |                                                        |
| F1 (Paper exit section breakdown)                                                                    | ○                | Δ4    | ○                | ○           | ○        | ○           |                                                        |
| F3, U6 (Paper feed tray breakdown)                                                                   | ○                | Δ2    | ○                | ○           | ○        | ○           |                                                        |
| E7 (01, 06) (ICU breakdown)                                                                          | ×                | ×     | ×                | ×           | ○        | ○           |                                                        |
| E7-02 (Laser breakdown)                                                                              | ○                | ×     | ○                | ○ Note      | ×        | ○ Note      | There is a risk that the memory is full.               |
| E7-03 (HD breakdown)                                                                                 | ×                | ×     | ×                | ×           | ×        | ×           |                                                        |
| E7 (10, 11, 14) (CCD breakdown)                                                                      | ×                | ○     | ○                | ○           | ○        | ○           |                                                        |
| E6 (10, 11, 14) (CIS breakdown)                                                                      | Δ6               | ○     | ○                | ○           | ○        | ○           |                                                        |
| E7-80 (Scanner communication trouble)                                                                | ×                | ○     | ○                | ○           | ○        | ○           |                                                        |
| E7-90 (PCU communication trouble)                                                                    | ×                | ×     | ×                | ×           | ×        | ×           |                                                        |
| E7 (50) (Skating check error)                                                                        | ×                | ×     | ×                | ×           | ×        | ×           |                                                        |
| U2 (00, 11, 12, 22) (ICU memory error)                                                               | ×                | ×     | ×                | ×           | ×        | ×           |                                                        |
| U2 (22, 23) (SRAM check sum error)                                                                   | ×                | ×     | ×                | ×           | ×        | ×           |                                                        |
| U2-50 (HD check sum error)                                                                           | ×                | ×     | ×                | ×           | ×        | ×           |                                                        |
| U7 (RIC external communication disable), PF                                                          | ×                | ×     | ×                | ×           | ×        | ×           | Inhibition of use by a customer having outstanding fee |
| U1 (Backup battery voltage fall)                                                                     | ×                | Δ3    | ×                | ×           | ×        | ×           | Transfer enable                                        |
| L4-30 (Controller fan motor trouble)                                                                 | ×                | ×     | ×                | ×           | ×        | ×           |                                                        |
| Door open                                                                                            | ○                | ×     | ○                | ○ Note      | ○        | ○ Note      | There is a risk that the memory is full.               |
| Toner empty                                                                                          | ○                | ×     | ○                | ○ Note      | ○        | ○ Note      | There is a risk that the memory is full.               |
| Process cartridge uninstalled, etc.                                                                  | ○                | ×     | ○                | ○ Note      | ○        | ○ Note      | There is a risk that the memory is full.               |
| Paper empty                                                                                          | ○                | ×     | ○                | ○ Note      | ○        | ○ Note      | There is a risk that the memory is full.               |
| Paper JAM                                                                                            | ○                | ×     | ○                | ○ Note      | ○        | ○ Note      | There is a risk that the memory is full.               |
| Document JAM                                                                                         | ×                | ○     | ○                | ○           | ○        | ○           |                                                        |
| Simulation                                                                                           | ×                | ×     | ×                | ×           | ×        | ×           |                                                        |
| Key operation (Communication disable)                                                                | ×                | ×     | ×                | ×           | ×        | ×           |                                                        |

Δ2: Enable except for the trouble tray

\* When, however, a paper feed tray trouble is detected during a job, the engine is stopped and printing is disabled.

Δ3: The display goes to the FAX status check menu and the list can be printed.: The received document is outputted.

Δ4: Paper exit is enabled except for the trouble paper exit tray

\* When, however, a paper feed tray trouble is detected during a job, the engine is stopped and printing is disabled.

Δ5: Only the operation related to image quality can be executed depending on the destination. (low density print)

Δ6: The operation can be executed in the single surface scanning mode.

## (6) Writing to the trouble memory

In case of a same trouble in this machine, selection is made with the simulation to write into the trouble memory or not. If this simulation is set, any trouble is written into the trouble memory unconditionally.

(SIMULATION. 26-35)

0: A same trouble as the previous one is not written. (Default)

1: Any trouble is written into the trouble memory unconditionally.

## [12] ROM VERSION-UP METHOD

### 1. General

Firmware update is executed by collectively writing the files with each ROM inserted to its specified slot.

If update by collective writing is failed by power interruption during the update process, etc., insert a preliminary ROM into the controller PWB and make update for each ROM individually. The update process flow in such a case is shown in "G. Update process flow."

The files for update can be transferred from a PC in which printer setting is made (regardless of Centro, USB, or TCP/IP connection type) to the printer by the use of File2PRN.EXE described later. In the other cases, use FCOPY.EXE to transfer the files.

### 2. Cautions

- In this method, verify for each byte is not made in order to shorten the writing time. The reliability of writing is assured by comparing the sum value. If the operation should be abnormal, make updater (C.) by the controller PWB.
- When the power is turned off during writing, the process may be failed and the machine may not be booted. In this case, refer to "E. Power OFF during update."
- After completion of update, the update window may be displayed by resetting the DIP switch on the controller PWB and booting the machine normally. In this case, the PCU and the scanner may not have been updated normally. Refer to "F. Update window when normal booting."
- It takes a longer time (about 5 minute) to write to the PWB's on the PCU, the scanner, and the FAX ROM than to write by CN6 of the controller PWB. This is because the difference in the communication speeds of the PWB's, etc. Also when the version of the software which is updated is the same, the process may be completed quickly.

### 3. Flash ROM update procedures

#### A. Preliminary arrangement

##### (1) Necessary tools

- 1) A machine with the operating ROM in it
- 2) A spare PCU ROM, a controller boot ROM, a scanner ROM (which operate normally) (Used when writing is failed.)
- 3) A PC operating on Windows with a USB or a parallel port. (When File2PRN is used, it must be set as a printer.)
- 4) USB cable or Centronics cable (Used to connect the PC and the controller PWB.)
- 5) File2PRN.EXE (Used to transfer the files to the machine connected with the USB, network, or parallel port. For the network connection, IP address setting is required. However, it is not mentioned here.), or FCOPY.EXE (parallel port file transfer tool). For the operating procedures of them, refer to <Reference> described later.
- 6) Compression files for update (SFU files for each of the PCU, the scanner, the FAX, the controller boot ROM and the MAIN ROM, or the collective SFU file)

##### (2) DIP switch setting on the back of the machine


When updating the ROM, the DIP switches on the back of the machine must be set properly.

###### a) DIP switches

ON the back of the machine, there are following DIP switches from the controller PWB:

- Diag mode switch (on the left)
- Write protect switch (on the right)

The switches are set to the upper side (protect) in normal operation. When they are set to the lower side, the diag mode and write protect are released. (Refer to the figure below.) When writing each ROM, set the switches to the lower side. (Default: Upper side). When update is completed, be sure to reset the switches to the upper side.)




##### (3) Controller PWB slot

The Flash Rom slots of the controller PWB are CN4, CN5, and CN6. Normally the BOOT ROM is inserted to CN4, and the main ROM is inserted to CN5, and CN6 is empty. When, however, the controller PWB is used to make a ROM, CN6 is used.

##### (4) Operation panel

When the machine is booted by the diag mode, each operation is performed with the hard keys of the scanner. The window display is made by the LCD panel. The keys used in the diag mode are assigned as follows:

|                     |                      |
|---------------------|----------------------|
| START key           | → OK key             |
| Document filing key | → Up/Down select key |
| FAX/Image send key  | → Up/Down select key |
| Job status key      | → Menu key           |
| Clear key           | → BACK key           |



## B. Update procedure 1 (Writing with each ROM inserted to the specified slot)

In this case, the ROM's on the PCU, FAX, and the scanner must be operating ROM's. An empty ROM which cannot boot the machine cannot be used for writing.

### (1) Preparation

- 1) Set the DIP switches on the back of the machine to the diag mode (lower side) and the write protect switch to the release side (lower side).
- 2) Check to confirm that the scanner unit is connected with the machine.
- 3) Check to confirm that the FAX unit is connected with the machine. (When the FAX is installed.)
- 4) Connect the PC and the controller PWB with the Centronics cable or USB cable.
- 5) Turn on the power of the PC and the machine to be updated.

### (2) Update procedures

- 1) When the machine is booted, the following display is shown.

```
Version Check
CONF: *****
```

- 2) Press MENU key a few times to display the following window. (In addition, when File2PRN.EXE is used, select the connection type (USB or parallel) with the Up/Down select key.)

```
Firm Update
From Parallel
```

- 3) Press OK key, and the following window is displayed.

```
Firm Update
Waiting Data
```

- 4) When files are transferred from the PC by Fcopy.EXE or File2PRN.EXE (collective files or a separate file for each ROM), the LED flashes and the display is changed sequentially as shown below. When the scanner is updated, the back-light of the LCD is instantaneously turned off. Since it is not a breakdown, do not turn off the power but wait for a while. When "Result: OK" is displayed after completion of writing (several minutes), press Up/Down key to check that there is no "Result: NG" for each ROM. (When, however, the collective files are updated with the machine which has no FAX installed, "Result: NG" is displayed for FAX.) When "Result: NG" is displayed, refer to (D.).

```
Firm Update ***
Receiving Data
```

↓

```
Firm Update
Writing Data
```

↓

```
Firm Update ***
Result: OK
```

- 5) Reboot the machine, and use Up/Down key on the window of 1) to check to confirm that the version of the updated software has been updated.
- 6) Turn off the power, and reset the DIP switches to the upper side (normal side).

## C. Update procedures 2 (Writing to each ROM by use of CN6 of the controller PWB)

By use of an empty slot of the controller PWB, writing can be made to an empty ROM which is not operating.

### (1) Preparation

- 1) Set the DIP switch on the back of the machine to the diag mode (lower side), and set the write protect switch to the release side (lower side).
- 2) Insert one of the ROM's of the PCU, the SCN, and the FAX into the empty slot (CN6) of the controller PWB.
- 3) Check to confirm that the scanner unit is connected with the machine.
- 4) Check to confirm that the FAX unit is connected with the machine. (When the FAX is installed.)
- 5) Connect the PC and the controller PWB with the Centronics cable or USB cable.
- 6) Turn on the power of the PC and the machine to be updated.

### (2) Update procedures

- 1) When the machine is booted, the following window is displayed.

```
Version Check
CONF: *****
```

- 2) Press MENU key a few times to display the following window. (In addition, when File2PRN.EXE is used, press Up/Down key to select the connection type (USB or parallel).)

```
CN Update
From Parallel
```

- 3) Press OK key, and the following window is displayed.

```
CN Update
Waiting Data
```

- 4) When files are transferred from the PC by the use of Fcopy.EXE or File2PRN.EXE, the data LED flashes and the window is changed sequentially as follows. The LED finishes flashing in a few minutes, and "Writing: OK" is displayed.

```
CN Update
Receiving Data
```

- 5) Press OK key, and the following window is displayed.

```
CN Update ***-> CN5
Writing OK?
```

- 6) Use Up/Down key to select the slot No. to which the ROM is inserted, and press OK key. The LED flashes and the window is changed sequentially as shown below. After completion of writing (several minutes), check to confirm that "Result: OK" is displayed.

```
CN Update ***-> CN6
Writing Data
```

↓

```
CN Update ***-> CN6
Result: OK
```

- 7) After turning off the power, replace the ROM to which writing is made with the ROM of the specified slot of the PWB, and turn on the power and check the operation and the version. (Use Up/Down key to check on the window of 1).)
- 8) Turn off the power, and reset the DIP switches to the upper side (protect side, normal side).

## D. In case of “Result: NG”

### (1) Possible causes of “Result: NG”

There are following possible causes of “Result: NG.”

- 1) The DIP switch of write protect is not set properly.
  - The write protect switch of the controller PWB is not set to the release side (lower side).
    - If the write protect switch is not set to the release side, data are not written into the ROM. Set the DIP switch properly, and retry updating.
- 2) The FAX cable is not connected. The FAX is NG.
  - Writing is not made. Connect properly and retry writing.
- 3) In rare cases, the ROM is broken down.
  - Check the ROM, and retry writing. If the trouble remains, replace the ROM.

(\* There are three types of ROM device: the common type for the PCU and the scanner, the common type for BOOT and MAIN, and the exclusive type for FAX.)

## E. Turning off the power during update

When the power is turned off during the update process, though the machine is booted, data writing cannot be assured. Retry update as follows.

- 1) When the power is turned off during update process of (B.)

Retry the update procedure of (B.). If the machine is not booted or the hard keys are not invalid (\*\*), or retry of the update is failed again, replace the ROM's with the spare one of the PCU, the controller BOOT, and the scanner ROM, and try the update procedure of (C.) for the replaced ROM's.  
(\*\* When the backlight of the display is lighted but the hard keys are invalid, all LED's flash.)
- 2) When the power is turned off during update process of (C.)

Retry updating.

## F. Update window display in normal booting

After completion of updating, when the power is turned off and the DIP switches on the back of the machine are set to the normal side and the machine is booted, the update window is displayed as shown below instead of the normal boot window, the PCU or the scanner may not have been properly updated.

Version Check  
CONF: \*\*\*\*\*

At that time, use Up/Down key to check the version of the PCU or the scanner. If the version is displayed as “BootMode,” or if the key operation is invalid (all the LED's are flashing), retry updating as follows.

- 1) When the key operation is possible and the version is displayed as “BootMode”


Turn off the power and retry the update procedure of (B.). At that time, be sure to set the DIP switches properly. After updating again, if the result is still NG, replace the ROM's with the spare one of the PCU and the scanner ROM, and perform the update procedure of (C.) for the replaced ROM's.
- 2) When the key operation is invalid



Turn off the power and replace the ROM's with the spare one of the PCU and the scanner ROM, and perform the update procedure of (C.) for the replaced ROM's. Be sure to set the DIP switches properly.


## G. Update process flow

The brief descriptions on the update procedures are as follows. For turning off during update, refer to “E. Turning off the power during update.”

If the update window is displayed after booting with the DIP switches on the back of the machine set to the normal side, refer to “F. Update window display in normal booting.”







## <Reference> File transfer procedures

### (1) File transfer by Fcopy.EXE

For file transfer by Fcopy, put Fcopy.exe and the files in a same directory, and boot the MS-DOS. Go to the directory of the files, and type "Fcopy file name" and transfer is made. In the following case, the SFU file is in the C:\ROM directory and it is transferred.

```

C:\ROM>dir
volume in drive C has no label
volume Serial Number is 000X-00X0
Directory of C:\ROM


<DIR> 10-28-03 13:24p .
<DIR> 10-28-03 13:24p ..
FCOPY EXE 18,771 10-28-03 14:15p fcopy.exe
TEST SFU 1,768,960 10-28-03 15:20p test.sfu
P021100 MOT 645,700 10-28-03 15:26p P021100.mot
MT1B01-2 SFU 155,648 10-28-03 16:10p mt1b0100..sfu
P021100 SFU 106,840 10-28-03 17:12p P021100.sfu
MT1B01-1 SFU 155,648 10-28-03 18:11p mt1b0100.suf..suf
6 File(s) 66 bytes
2 dir(s) 2,240.79 MB free

C:\ROM>fcopy test.sfu
Outputting test.sfu to LPT1
0% completed

```

### (2) File transfer by File2PRN.EXE

For file transfer by File2PRN, the machine to which the files are transferred must be set as a printer. The connection types as a printer are parallel port, network, and USB. For transfer by the network connection, IP address setting is required. It is not described here. For transfer of the files, execute File2PRN.EXE, and the following window is displayed.



Enter the path of the transfer file to "Input File Path." (Or press Reference button and select a file to be transferred.) Then select the target printer in "Select Printer." Select a parallel port connection printer or a USB connection printer depending on the connection type. After completion of the above transfer file selection and the target printer setting, press Send button to transfer the file.

For the file transfer by USB connection, refer to "<Reference> (3) File transfer by USB connection."

### (3) File transfer by USB connection

When update is made by File2PRN and USB connection, USB is used as a printer port similar to the other connections (parallel, network).

#### [Setup]

- 1) Set the machine as a printer which is connected to the PC in a connection type other than USB.
- 2) Boot the machine in the diag mode conforming to the normal ROM update procedures.
- 3) Connect the PC and the machine with the USB cable.
- 4) The PC system detects a new hardware by Plug & Play function.
- 5) The driver of SHARP AR-M455N is automatically installed. (Note that the model name is displayed as SHARP AR-M455N regardless of the actual model name.)
- 6) Follow the normal ROM update procedures to bring the machine into the data reception status.
- 7) Execute File2PRN, specify the printer registered in procedure 7), and execute file transfer.

(Example: SHARP AR-M455N SPDL2 on USB001)





## 1. Block diagram









## Scanner (1/3)










SCN  
cnt  
PWB  
(2/3)







# Engine (1/4)






U  
/B


| CN3          |    |
|--------------|----|
| 24FMN-BIRK-A |    |
| RS           | 1  |
| R/W          | 2  |
| EN           | 3  |
| D0           | 4  |
| D1           | 5  |
| D2           | 6  |
| D3           | 7  |
| D4           | 8  |
| D5           | 9  |
| D6           | 10 |
| D7           | 11 |
| +5V1         | 12 |
| +5V1         | 13 |
| GND2         | 14 |
| GND2         | 15 |
| KEY1         | 16 |
| KEY2         | 17 |
| KEY3         | 18 |
| KEY4         | 19 |
| KEY5         | 20 |
| KEY6         | 21 |
| LED1\        | 22 |
| LED2\        | 23 |
| LED3\        | 24 |

| CN16         |        |
|--------------|--------|
| S32B-PHDSS-B |        |
| TEST3        | 1 BR   |
| TEST2        | 2 BR   |
| GND2         | 3 BR   |
| /SYNC        | 4 GY   |
| GND2         | 5 GY   |
| GND2         | 6 GY   |
| GND2         | 7 GY   |
| LSU_S/H      | 8 BR   |
| VRB          | 9 GY   |
| GND2         | 10 GY  |
| GND2         | 11 GY  |
| TEST         | 12 BR  |
| VIDEO        | 13 LBR |
| /VIDEO       | 14 BR  |
| /LDON        | 15 GY  |
| GND2         | 16 GY  |
| GND2         | 17 GY  |
| +5V2         | 18 BL  |
| GND2         | 19 GY  |
| +5V2         | 20 BL  |
| +24V1        | 21 RD  |
| +24V1        | 22 RD  |
| /VFM1        | 23 BR  |
| GND2         | 24 GY  |
| /START       | 25 BR  |
| /VFM1        | 26 BR  |
| /PMCLK       | 27 BR  |
| /READY       | 28 BR  |
| GND2         | 29 GY  |
| GND2         | 30 GY  |
| +5V LD       | 31 BL  |
| GND2         | 32 GY  |



## Engine (2/4)


MAIN  
DRIVE




DM




NO ASSEMBLY




NO ASSEMBLY




TONER HOPPER



TM1




MAIN  
DRIVE



MM





TONER HOPPER




CRU  
PWB

PHNR-02-H+BU02P-TR-P-H




PSPS




PCU  
PWB




DEVELOPER UNIT




SHORT JIG






### Engine (100V series) (3/4)


## FUSING UNIT





## Engine (200V series) (4/4)

## FUSING UNIT





OPTION (1/1)

