

7. Parts catalog

How to use this parts catalog


The following legend is used in the parts catalog:

Asm-Index	Part number	Units/mach	Units/FRU	Description
-----------	-------------	------------	-----------	-------------

- **Asm-index:** identifies the assembly and the item in the diagram. For example, 3-1 indicates assembly 3 and the item number 1.
- **Part number:** identifies the unique number that identifies this FRU.
- **Units/mach:** refers to the number of units actually used in the machine or product.
- **Units/FRU:** refers to the number of units packaged together and identified by the part number.
- **NS:** (Not shown) in the Asm-Index column indicates that the part is procurable but is not pictured in the illustration.
- **PP:** (Parts Packet) in the parts description column indicates the part is contained in a parts packet.
- Model information used in the parts catalog.

Machine type and model	Description
7013-235	X264dn
7013-432	X363dn
7013-436	X364dn
7013-43W	X364dw


Assembly 1: Covers



Assembly 1: Covers

Asm-Index	Part number	Units/mach	Units/FRU	Description
1-1	40X5614	1	1	Top cover assembly
2	40X5377	1	1	Rear upper and lower cover assembly
3	40X5375	1	1	Right side cover
4	40X5398	1	1	Optional 250-sheet tray
4	40X5399	1	1	Optional 550-sheet tray
5	40X5394	1	1	250-sheet (Tray 2) assembly
5	40X5395	1	1	550-sheet (Tray 2) assembly
6	40X2855	1	4	Tray 2 wear strips (550-sheet tray only)
7	40X5382	1	6	Wear strips (250-sheet trays, optional and primary)
8	40X5381	1	1	Main tray
9	40X5379	1	1	Front door cover
10	40X5448	1	1	Nameplate cover
11	40X5806	1	1	Lower AIO access assembly
12	40X5778	1	1	Front access door cover
13	40X5374	1	1	Left side cover

Assembly 2: Scanner




Assembly 2: Scanner

Asm-Index	Part number	Units/mach	Units/FRU	Description
2-1	40X5470	1	1	ADF input tray
2	40X5477	1	1	ADF rear simplex cover
2	40X5478	1	1	ADF rear duplex cover
3	40X5779	1	1	Flatbed assembly
4	40X5621	1	1	Right scanner cover
5	40X5622	1	1	ADF cable
6	40X5615	1	1	Tub cover
7	40X5623	1	1	Operator panel cable
8	40X5624	1	1	USB cable
9	40X5617	1	1	Operator panel X234/X364
9	40X5618	1	1	Operator panel X363
10	40X5616			Nameplate cover
11	40X0064	1	1	Bezel (French OP X264)
11	40X0089	1	1	Bezel (French OP X363)
11	40X0109	1	1	Bezel (French OP X364)
11	40X0118	1	1	Bezel (Italian OP X264)
11	40X0119	1	1	Bezel (Italian OP X363)
11	40X0128	1	1	Bezel (Italian OP X364)
11	40X0139	1	1	Bezel (German OP X264)
11	40X0146	1	1	Bezel (German OP X363)
11	40X0155	1	1	Bezel (German OP X364)
11	40X0158	1	1	Bezel (Spanish OP X264)
11	40X0166	1	1	Bezel (Spanish OP X363)
11	40X0167	1	1	Bezel (Spanish OP X364)
11	40X0169	1	1	Bezel (Brazilian Portuguese OP X264)
11	40X0170	1	1	Bezel (Brazilian Portuguese OP X363)
11	40X0171	1	1	Bezel (Brazilian Portuguese OP X364)
11	40X0172	1	1	Bezel (Dutch OP X264)
11	40X0173	1	1	Bezel (Dutch OP X363)
11	40X0175	1	1	Bezel (Dutch OP X364)
11	40X0176	1	1	Bezel (Danish OP X264)
11	40X0177	1	1	Bezel (Danish OP X363)
11	40X0178	1	1	Bezel (Danish OP X364)
11	40X0180	1	1	Bezel (Norwegian OP X264)
11	40X0181	1	1	Bezel (Norwegian OP X363)
11	40X0184	1	1	Bezel (Norwegian OP X364)
11	40X0185	1	1	Bezel (Swedish OP X264)
11	40X0186	1	1	Bezel (Swedish OP X363)
11	40X0214	1	1	Bezel (Swedish OP X364)
11	40X0227	1	1	Bezel (Finnish OP X264)
11	40X0242	1	1	Bezel (Finnish OP X363)
11	40X0243	1	1	Bezel (Finnish OP X364)
11	40X0247	1	1	Bezel (Russian OP X264)

Assembly 2: Scanner

Asm-Index	Part number	Units/ mach	Units/ FRU	Description
11	40X0261	1	1	Bezel (Russian OP X363)
11	40X0262	1	1	Bezel (Russian OP X364)
11	40X0315	1	1	Bezel (Polish OP X264)
11	40X0316	1	1	Bezel (Polish OP X363)
11	40X0317	1	1	Bezel (Polish OP X364)
11	40X0318	1	1	Bezel (Turkish OP X264)
11	40X0319	1	1	Bezel (Turkish OP X363)
11	40X0320	1	1	Bezel (Turkish OP X364)
11	40X0321	1	1	Bezel (Bulgarian OP X264)
11	40X0322	1	1	Bezel (Bulgarian OP X363)
11	40X0323	1	1	Bezel (Bulgarian OP X364)
11	40X0324	1	1	Bezel (Czech OP X264)
11	40X0325	1	1	Bezel (Czech OP X363)
11	40X0326	1	1	Bezel (Czech OP X364)
11	40X0327	1	1	Bezel (Hungarian OP X264)
11	40X0328	1	1	Bezel (Hungarian OP X363)
11	40X0329	1	1	Bezel (Hungarian OP X364)
11	40X0330	1	1	Bezel (Japanese OP X264)
11	40X0331	1	1	Bezel (Japanese OP X363)
11	40X0332	1	1	Bezel (Japanese OP X364)
11	40X0333	1	1	Bezel (Korean OP X264)
11	40X0334	1	1	Bezel (Korean OP X363)
11	40X0335	1	1	Bezel (Korean OP X364)
11	40X0336	1	1	Bezel (Traditional Chinese OP X264)
11	40X0337	1	1	Bezel (Traditional Chinese OP X363)
11	40X0338	1	1	Bezel (Traditional Chinese OP X364)
11	40X0339	1	1	Bezel (Simplified Chinese OP X264)
11	40X0340	1	1	Bezel (Simplified Chinese OP X363)
11	40X0341	1	1	Bezel (Simplified Chinese OP X364)
11	40X5771	1	1	Bezel (ASM op panel SB X264)
11	40X5772	1	1	Bezel (ASM op panel SB X363)
11	40X5773	1	1	Bezel (ASM op panel SB X364)
12	40X5620	1	1	Left scanner cover
13	40X0168	1	1	Simplex ADF
13	40X5468	1	1	Duplex ADF
14	40X5472	1	1	ADF separator pad
15	40X5471	1	1	ADF separator roll
NS	40X5539	1	1	Flatbed cushion (simplex ADF)
NS	40X5535	1	1	Flatbed cushion (duplex ADF)
NS	40X5807	1	1	ADF maintenance kit


Assembly 3: Electronics



Assembly 3: Electronics

Asm-Index	Part number	Units/ mach	Units/ FRU	Description
3-1	40X5344	1		Fuser assembly, 110 V
1	40X5345	1		Fuser assembly, 220 V
1	40X5346	1		Fuser assembly, 100 V
2	40X5365	1	1	Duplex and media sensor assembly
3	40X5360	1	1	Access door open sensor assembly
4	40X5392	1	1	Cooling fan (screws included)
5	40X5385	1	1	Toner low sensor
6	40X5612	1	1	Controller board, X264
6	40X5613	1	1	Controller board, X363/X364
7	40X5361	1		LVPS/HVPS card assembly, 110 V/100 V
7	40X5362	1		LVPS/HVPS card assembly, 220 V
8	40X5366	1	1	Manual input sensor assembly
9	40X5369	1	1	Manual feed solenoid
10	40X5371	1	1	MPF feed clutch
11	40X5370	1	1	Media feed (ACM) clutch
12	40X5626	1		LSU (printhead)
NS	40X5320			Wireless antenna with clip
NS	40X5036			802.11 B/G/N wireless card assembly
NS	40X5056			Fax card

Assembly 4: Frame



Assembly 4: Frame

Asm-Index	Part number	Units/ mach	Units/ FRU	Description
3-1	40X5364	1		Transfer roll, bearings, gear, spring (CBM)
2	40X5372	1		Media exit guide assembly (redrive)
3	40X5397	1	1	Front mounts
4	40X5396	N/A		Screws, miscellaneous
			4	TP2NCX3X6PF-Ni
			4	TP2C-4.0+8PF-Ni
			4	M3.0*0.5+6PF-Ni
			2	M3.0*0.5+4PF-Ni
			2	M3.5*0.6+6P-Ni
5	40X5380	1	1	Complete duplex assembly
6	40X5453	1	1	Media (ACM) drive assembly
7	40X5451	2	2	Paper feed, ACM tires
7	40X5440	1	2	Tray 2 paper feed tires
8	40X5358	1	1	MPF tray assembly (X36x series only)
9	40X5383	1	1	Upper front frame assembly
10	40X5368	1	1	Manual feed clutch CBM
11	40X5367	1	1	Main drive gearbox (in motor)
12	40X5363	1	1	Duplex gear drive CBM

Assembly 5: Options

Asm-Index	Part number	Units/mach	Units/FRU	Description
NS	40X6339	1	1	64MB NAND flash memory
NS	40X1368	1	1	USB cable, packaged (2 m)

Assembly 6: Power cords

Asm-Index	Part number	Units/mach	Units/FRU	Description
NS	40X0297	1		Power cord, 1.8M (straight)– USA, Canada
NS	40X0278	1		Power cord, 6 foot (straight)– Europe and others
NS	40X0288	1		Power cord, 8 foot (straight)– Argentina
NS	40X0286	1		Power cord, 8 foot (straight)– United Kingdom
NS	40X0275	1		Power cord, 6 foot (straight)– Israel
NS	40X0274	1		Power cord, 6 foot (straight)– Switzerland
NS	40X0276	1		Power cord, 6 foot (straight)– South Africa
NS	40X0287	1		Power cord, 6 foot (straight)– Traditional Italy
NS	40X0279	1		Power cord, 6 foot (straight)– Denmark
NS	40X4596	1		Power cord, 6 foot (straight)– Brazil
NS	40X0282	1		Power cord, 1.8M (straight)– PRC
NS	40X0270	1		Power cord, 2.5M (straight)– Japan
NS	40X0280	1		Power cord, 1.8M (straight)– Korea
NS	40X0281	1		Power cord, 1.8M (straight)– Taiwan
NS	40X0296	1		Power cord, 1.8M (straight)– Australia

Index

Numerics

840.xx service check **2-44**

A

abbreviations **1-12**

acronyms **1-12**

ADF cover closed sensor test **3-19**

ADF cover open service check **2-48**

ADF duplex service check **2-51**

ADF edge erase **3-29**

ADF feed errors service check **2-50**

ADF input tray

removal **4-8**

ADF manual registration **3-30**

ADF paper jam service check **2-49**

ADF paper present sensor test **3-18**

ADF separator pad

removal **4-11**

ADF separator roll

removal **4-12**

ADF streak service check **2-48**

B

Button Test **3-7**

C

CACHE Test **3-8**

CCD service check **2-46**

Charge Roll, diagnostics mode **3-14**

compatibility **1-5**

Config Menu

description **3-1**

configuration menu **3-26**

ADF edge erase **3-29**

available tests **3-26**

Demo Mode **3-28**

disable scanner **3-31**

Energy Conserve **3-28**

Event Log **3-27**

Exit Config Menu **3-32**

Factory Defaults **3-28**

FB edge erase **3-30**

font sharpening **3-32**

format fax storage **3-29**

min copy memory **3-29**

Panel Menus **3-27**

PPDS Emulation **3-27**

Prt Quality Pages **3-26**

prt quality pages **3-26**

Reports

Menu Settings Page **3-27**

reports **3-27**

menu settings page **3-27**

scanner manual registration **3-30**

USB scan to local **3-26**

control panel **1-2**

controller card

service check **2-26**

D

defaults

factory defaults **3-28**

Demo Mode **3-28**

diagnostics menu

available tests **3-2**

Base Sensor Test **3-12**

Base Sensor Tests

Fuser Exit **3-12**

Input **3-12**

Duplex Tests

Quick Test **3-9**

Top Margin **3-10**

Duplex tests

left margin **3-9**

sensor test **3-10**

Event Log

Clear Log **3-16**

exit diagnostics **3-22**

Hardware Tests

Button Test **3-7**

CACHE Test **3-8**

DRAM Test **3-7**

Panel Test **3-7**

Input Tray tests

feed tests **3-11**

miscellaneous tests **3-6**

motor detect **3-6**

print tests **3-6**

Printer Setup

configuration ID **3-13**

defaults **3-12**

engine setting 1 through 4 **3-13**

model name **3-13**

page counts **3-12**

serial number **3-13**

printer setup **3-12**

registration **3-4**

Scanner Tests

ASIC test **3-17**

Scanner Tests

sensor test **3-17**

ADF cover closed sensor test **3-19**

ADF paper present sensor test **3-18**

FB Cover closing sensor test **3-19**

home sensor test **3-19**

sensor 1 test **3-20**

sensor 2 test **3-21**

Scanner tests

feed test **3-17**

Diagnostics Mode
 description **3-1**
 diagnostics mode—
 EP Setup
 Charge Roll **3-14**
 EP Defaults **3-14**
 Fuser Temp **3-14**
 Gap Adjust **3-14**
 Print Contrast **3-14**
 Transfer **3-14**
 digital imaging specifications **1-9**
 disable scanner **3-31**
 DRAM Test **3-7**
 duplex
 Quick Test **3-9**
 Top Margin **3-10**
 duplex ADF rear cover
 removal **4-18**

E

Energy Conserve **3-28**
 EP Defaults **3-14**
 error messages
 service error codes **2-17**
 user attendance messages **2-6**
 ESD-sensitive parts **4-1**
 event log
 configuration menu **3-27**
 Exit config menu **3-32**

F

Factory Defaults **3-28**
 factory defaults **3-28**
 fan
 parts catalog **7-8**
 service check **2-27**
 fax reception service check **2-55**
 fax specifications **1-11**
 miscellaneous **1-11**
 phone network connectivity **1-11**
 scan resolutions **1-11**
 fax transmission service check **2-53**
 FB cover closing sensor test **3-19**
 FB edge erase **3-30**
 flatbed home position service check **2-47**
 Flatbed home sensor test **3-19**
 flatbed motor service check **2-46**
 Font sharpening **3-32**
 format fax storage **3-29**
 frame, parts catalog **7-9**
 fuser
 parts catalog **7-8**
 service check **2-29**
 Fuser Temp **3-14**

G

Gap Adjust **3-14**

H

handling ESD-sensitive parts **4-1**

L

lithium battery **v-xv, 4-23**
 locations
 front views **5-1**
 rear views **5-2**
 lubrication specifications **6-1**
 LVPS/HVPS
 parts catalog **7-8**
 service check **2-29**

M

maintenance kits **6-1**
 manually register a duplex ADF **3-30**
 manually register the flatbed **3-31**
 media jams **3-34**
 menu settings page **3-27**
 menus
 Menu Settings Page **3-27**
 messages
 service error codes **2-17**
 user attendance messages **2-6**
 min copy memory **3-29**
 miscellaneous tests **3-6**
 models
 comparison **1-1**
 diagrams **5-1, 5-2**
 operator panels **1-2**
 trays available **1-6**
 modem - fax card service check **2-52**
 motor detect test **3-6**

O

operator panel
 LCD— **2-2**
 LED—
 service check **2-31**
 overview **1-2**

P

Panel Menus **3-27**
 Panel Test **3-7**
 panel, control **1-2**
 Paper jams **3-34**
 paper jams
 avoiding **3-34**
 parts catalog
 covers **7-2**
 electronics **7-7**
 frame **7-9**
 options **7-11**
 password, panel menus **3-27**
 power-on self test (POST) **2-1**
 symptoms **2-23**
 PPDS Emulation **3-27**
 Print Contrast **3-14**
 print media
 trays by model **1-6**
 types and sizes **1-7**

- print quality pages
 - using **2-36**
- print quality problems
 - service check **2-36**
 - solving **2-40**
- print tests **3-6**
- printer registration **3-4**
- printer symptom table **2-24**
- printhead
 - service check **2-43**
- Prt Quality Pgs
 - configuration menu **3-26**

Q

- Quick Test (duplex) **3-9**

R

- removals
 - ADF input tray **4-8**
 - ADF separator pad **4-11**
 - ADF separator roll **4-12**
 - duplex ADF rear cover **4-18**
 - procedures **4-2**
- reports **3-27**
 - event log **3-27**
 - menu settings page **3-27**
 - Print Quality Pages **3-26**
 - Quick Test (duplex) **3-9**

S

- safety information **xv**
- safety inspection guide **6-1**
- scan and copy specifications **1-10**
- scan fax and copy symptoms **2-25**
- Scanner ASIC test **3-17**
- Scanner manual registration **3-30**
- SE Menu **3-33**
- sensor 2 test **3-21**
- Sensor test **3-20**
- sensors
 - fuser exit
 - Base Sensor Test **3-12**
 - input
 - Base Sensor Test **3-12**
- service checks **2-26**
 - ADF paperfeed **2-49**
 - ADF streak **2-48**
 - black page **2-46**
 - controller card **2-26**
 - cooling fan **2-27**
 - cover interlock switch **2-27**
 - dead machine **2-28**
 - flatbed **2-47**
 - flatbed motor **2-46**
 - fuser **2-29**
 - LVPS/HVPS **2-29**
 - main motor **2-30**
 - modem / fax card **2-52**
 - networking **2-34**
 - operator panel **2-31**

- paper feed **2-31**
 - paper jam during POST **2-31**
 - paper never picks **2-32**
 - paper picks but stops **2-31**
 - paper picks sheets **2-32**
 - paper trees, curls **2-33**
- print quality **2-36**
 - black page **2-37**
 - blank page **2-36**
 - heavy background **2-37**
 - image density **2-38**
 - light print **2-39**
 - partial blank image **2-38**
 - poor fusing of image **2-38**
 - toner on back of page **2-39**
 - white or black lines **2-39**
- printhead **2-43**
- scanner, fax, copy
 - 840xx error check **2-44**
 - ADF cover open **2-48**
 - ADF duplex service check **2-51**
 - ADF feed errors **2-50**
 - ADF paper am **2-49**
 - black page or blank page **2-46**
 - CCD service check **2-46**
 - escalating a fax issue to second-level support **2-57**
 - fax reception service check **2-55**
 - fax transmission service check **2-53**
 - flatbed home position **2-47**
 - flatbed motor **2-46**
 - modem service check **2-52**
- transfer roll **2-43**
- service error codes **2-17**
- special tools **1-12**
- specifications
 - connectivity **1-5**
 - digital imaging **1-9**
 - fax **1-11**
 - input trays **1-6**
 - memory **1-3**
 - operating systems **1-5**
 - photoconductor capacity **1-6**
 - print media **1-7**
 - scan and copy **1-10**
 - toner capacity **1-6**
- start **2-1**
- symptom tables **2-23**
 - POST **2-23**
 - printer **2-24**
- symptoms
 - scan fax and copy **2-25**

T

test pages

print quality test pages **3-26**

Quick Test (duplex) **3-9**

tools **1-12**

Transfer **3-14**

transfer roll

parts catalog **7-10**

service check **2-43**

U

USB scan to local **3-26**

user attendance messages **2-6**

Part number index

P/N	Description	Page
40X0064	Bezel (French OP X264) - - - - -	7-5
40X0089	Bezel (French OP X363) - - - - -	7-5
40X0109	Bezel (French OP X364) - - - - -	7-5
40X0118	Bezel (Italian OP X264) - - - - -	7-5
40X0119	Bezel (Italian OP X363) - - - - -	7-5
40X0128	Bezel (Italian OP X364) - - - - -	7-5
40X0139	Bezel (German OP X264) - - - - -	7-5
40X0146	Bezel (German OP X363) - - - - -	7-5
40X0155	Bezel (German OP X364) - - - - -	7-5
40X0158	Bezel (Spanish OP X264) - - - - -	7-5
40X0166	Bezel (Spanish OP X363) - - - - -	7-5
40X0167	Bezel (Spanish OP X364) - - - - -	7-5
40X0168	Simplex ADF - - - - -	7-6
40X0169	Bezel (Brazilian Portuguese OP X264) - - - - -	7-5
40X0170	Bezel (Brazilian Portuguese OP X363) - - - - -	7-5
40X0171	Bezel (Brazilian Portuguese OP X364) - - - - -	7-5
40X0172	Bezel (Dutch OP X264) - - - - -	7-5
40X0173	Bezel (Dutch OP X363) - - - - -	7-5
40X0175	Bezel (Dutch OP X364) - - - - -	7-5
40X0176	Bezel (Danish OP X264) - - - - -	7-5
40X0177	Bezel (Danish OP X363) - - - - -	7-5
40X0178	Bezel (Danish OP X364) - - - - -	7-5
40X0180	Bezel (Norwegian OP X264) - - - - -	7-5
40X0181	Bezel (Norwegian OP X363) - - - - -	7-5
40X0184	Bezel (Norwegian OP X364) - - - - -	7-5
40X0185	Bezel (Swedish OP X264) - - - - -	7-5
40X0186	Bezel (Swedish OP X363) - - - - -	7-5
40X0214	Bezel (Swedish OP X364) - - - - -	7-5
40X0227	Bezel (Finnish OP X264) - - - - -	7-5
40X0242	Bezel (Finnish OP X363) - - - - -	7-5
40X0243	Bezel (Finnish OP X364) - - - - -	7-5
40X0247	Bezel (Russian OP X264) - - - - -	7-5
40X0261	Bezel (Russian OP X363) - - - - -	7-6
40X0262	Bezel (Russian OP X364) - - - - -	7-6
40X0270	Power cord, 1.77M (straight)– Japan - - - - -	7-12
40X0274	Power cord, 6 foot– Switzerland - - - - -	7-12
40X0275	Power cord, 6 foot (straight)– Israel - - - - -	7-12
40X0276	Power cord, 6 foot– South Africa - - - - -	7-12
40X0278	Power cord, 6 foot (straight)– Europe and others - - - - -	7-12
40X0279	Power cord, 6 foot (straight)– Denmark - - - - -	7-12
40X0280	Power cord, 1.77M (straight)– Korea - - - - -	7-12
40X0281	Power cord, 1.77M (straight)– Taiwan - - - - -	7-12
40X0282	Power cord, 1.77M (straight)– PRC - - - - -	7-12
40X0286	Power cord, 6 foot– United Kingdom - - - - -	7-12
40X0287	Power cord, 6 foot (straight)– Traditional Italy - - - - -	7-12
40X0288	Power cord, 6 foot– Argentina - - - - -	7-12
40X0296	Power cord, 1.8M (straight)– Australia - - - - -	7-12
40X0297	Power cord, 1.77M (straight)– USA, Canada - - - - -	7-12
40X0315	Bezel (Polish OP X264) - - - - -	7-6
40X0316	Bezel (Polish OP X363) - - - - -	7-6
40X0317	Bezel (Polish OP X364) - - - - -	7-6
40X0318	Bezel (Turkish OP X264) - - - - -	7-6
40X0319	Bezel (Turkish OP X363) - - - - -	7-6
40X0320	Bezel (Turkish OP X364) - - - - -	7-6

40X0321	Bezel (Bulgarian OP X264)	7-6
40X0322	Bezel (Bulgarian OP X363)	7-6
40X0323	Bezel (Bulgarian OP X364)	7-6
40X0324	Bezel (Czech OP X264)	7-6
40X0325	Bezel (Czech OP X363)	7-6
40X0326	Bezel (Czech OP X364)	7-6
40X0327	Bezel (Hungarian OP X264)	7-6
40X0328	Bezel (Hungarian OP X363)	7-6
40X0329	Bezel (Hungarian OP X364)	7-6
40X0330	Bezel (Japanese OP X264)	7-6
40X0331	Bezel (Japanese OP X363)	7-6
40X0332	Bezel (Japanese OP X364)	7-6
40X0333	Bezel (Korean OP X264)	7-6
40X0334	Bezel (Korean OP X363)	7-6
40X0335	Bezel (Korean OP X364)	7-6
40X0336	Bezel (Traditional Chinese OP X264)	7-6
40X0337	BBezel (Traditional Chinese OP X363)	7-6
40X0338	Bezel (Traditional Chinese OP X364)	7-6
40X0339	Bezel (Simplified Chinese OP X264)	7-6
40X0340	Bezel (Simplified Chinese OP X363)	7-6
40X0341	Bezel (Simplified Chinese OP X364)	7-6
40X1368	USB cable, packaged (2 m)	7-11
40X2855	Tray 2 wear strips (550-sheet tray only)	7-3
40X4596	Power cord, 6 foot (straight)– Brazil	7-12
40X5036	802.11 B/G/N wireless card assembly	7-8
40X5056	Fax card	7-8
40X5320	Wireless antenna with clip	7-8
40X5344	Fuser assembly, 110 V	7-8
40X5345	Fuser assembly, 220 V	7-8
40X5346	Fuser assembly, 100 V	7-8
40X5358	MPF tray assembly (X36x series only)	7-10
40X5360	Access door open sensor assembly	7-8
40X5361	LVPS/HVPS card assembly, 110 V/100 V	7-8
40X5362	LVPS/HVPS card assembly, 220 V	7-8
40X5363	Duplex gear drive CBM	7-10
40X5364	Transfer roll, bearings, gear, spring (CBM)	7-10
40X5365	Duplex and media sensor assembly	7-8
40X5366	Manual input sensor assembly	7-8
40X5367	Main drive gearbox (in motor)	7-10
40X5368	Manual feed clutch CBM	7-10
40X5369	Manual feed solenoid	7-8
40X5370	Media feed (ACM) clutch	7-8
40X5371	MPF feed clutch	7-8
40X5372	Media exit guide assembly (redrive)	7-10
40X5374	Left side cover	7-3
40X5375	Right side cover	7-3
40X5377	Rear upper and lower cover assembly	7-3
40X5379	Front door cover	7-3
40X5380	Complete duplex assembly	7-10
40X5381	Main tray	7-3
40X5382	Wear strips (250-sheet trays, optional and primary)	7-3
40X5383	Upper front frame assembly	7-10
40X5385	Toner low sensor	7-8
40X5392	Cooling fan (screws included)	7-8
40X5394	Tray 2 assembly	7-3
40X5395	550-sheet (Tray 2) assembly	7-3
40X5396	Screws, miscellaneous	7-10
40X5397	Front mounts	7-10
40X5398	Optional 250-sheet tray	7-3

40X5399	Optional 550-sheet tray	7-3
40X5440	Tray 2 paper feed tires	7-10
40X5448	Nameplate cover	7-3
40X5451	Paper feed, ACM tires	7-10
40X5453	Media (ACM) drive assembly	7-10
40X5468	Duplex ADF	7-6
40X5470	ADF input tray	7-5
40X5471	ADF separator roll	7-6
40X5472	ADF separator pad	7-6
40X5477	ADF rear simplex cover	7-5
40X5478	ADF rear duplex cover	7-5
40X5535	Flatbed cushion (duplex ADF)	7-6
40X5539	Flatbed cushion (simplex ADF)	7-6
40X5612	Controller board, X264	7-8
40X5613	Controller board, X363/X364	7-8
40X5614	Top cover assembly	7-3
40X5615	Tub cover	7-5
40X5616	Nameplate cover	7-5
40X5617	Operator panel X234/X364	7-5
40X5618	Operator panel X363	7-5
40X5620	Left scanner cover	7-6
40X5621	Right scanner cover	7-5
40X5622	ADF cable	7-5
40X5623	Operator panel cable	7-5
40X5624	USB cable	7-5
40X5626	LSU (printhead)	7-8
40X5771	Bezel (ASM op panel SB X264)	7-6
40X5772	Bezel (ASM op panel SB X363)	7-6
40X5773	Bezel (ASM op panel SB X364)	7-6
40X5778	Front access door cover	7-3
40X5779	Flatbed assembly	7-5
40X5806	Lower AIO access assembly	7-3
40X5807	ADF maintenance kit	7-6
40X6339	64MB NAND flash memory	7-11